digital

PROGRAMMED DATA PROCESSOR - 8/S USERS HANDBOOK

Copyright 1966 by Digital Equipment Corporation

PDP is a registered trademark of Digital Equipment Corporation.

CONTENTS

Introduction		v
Chapter 1	Memory and Processor Functional Operation	1
Chapter 2	Memory and Processor Instructions	7
Chapter 3	Memory and Processor Basic Programming	20
Chapter 4	Program Interrupt	27
Chapter 5	Memory Parity	29
Chapter 6	Basic 1OT Programming	31
Chapter 7	Teletype and Control	35
Chapter 8	High Speed Perforated Tape Reader and Control Type PC02	41
Chapter 9	High Speed Tape Punch Control Type PC03	43
Chapter 10	Analog-To Digital Converter Type 138E and Multiplexer Control Type 139E	45
Chapter 11	Digital-To-Analog Converter Type AA01A	50
Chapter 12	Incremental Plotter and Control Type 350B	51
Chapter 13	Card Reader and Control Type CR01C	55
Chapter 14	Card Reader and Control Type 451	59
Chapter 15	Automatic Line Printer and Control Type 645	62
Chapter 16	Standard PDP-8/S Operation	66
Chapter 17	PDP-8/S Input/Output Facilities	74
Chapter 18	Programmed Data Transfers	7.6
Chapter 19	Installation Planning	95
Appendix 1	Instructions	98
Appendix 2	Codes	104
Appendix 3	Scales of Notation	108
Appendix 4	Powers of Two	109
Appendix 5	Octal-Decimal Conversion	110
Appendix 6	Perforated Tape Lander Sequences	117




Figure 1. The PDP-8/S System

INTRODUCTION

Digital Equipment Corporation's Programmed Data Processor-8/S (PDP-8/S) is designed for use as a small scale general-purpose computer, an independent information handling facility in a larger computer system, or as a control element in a complex processing system. The PDP-8/S is a one-address, fixed word length, serial computer using a word length of 12-bits plus parity and two's complement arithmetic. Cycle time of the 4096-word random address magnetic core memory is 8 microseconds. Standard features of the system include indirect addressing and facilities for instruction skipping and program interruption as functions of input/output device conditions.

Addition is performed in 36 microseconds with one number in the accumulator. Subtraction is performed in 64 microseconds with the subtrahend in the accumulator. Multiplication is performed in approximately 5.35 milliseconds by a subroutine that operates on two signed 12-bit numbers that produce a 24-bit product, leaving the 12 most significant bits in the accumulator. Division of two signed 12-bit numbers is performed in approximately 7.38 milliseconds by a subroutine that produces a 12-bit remainder in core memory.

Flexible, high capacity, input/output capabilities of the computer operate a variety of peripheral equipment. In addition to standard teletype and perforated tape equipment, the system can operate in conjunction with all non-data break optional devices offered in the PDP-8 family line. Equipment of special design is easily adapted for connection into the PDP-8/S system. The computer is not modified with the addition of peripheral devices.

The PDP-8/S is completely self-contained requiring no special power sources or environmental conditions. A single source of a 115-volts, 60 cycle, single phase power operates the machine. An internal power supply produces all of the required operating voltages. Standard FLIP CHIP Modules utilizing hybrid silicon circuits insure reliable operation in ambient temperatures between 32 and 130 degrees Fahrenheit.

COMPUTER ORGANIZATION

The PDP-8/S consists of a central processor, a memory unit, and input/output equipment and facilities. All arithmetic, logic, and system control operations of the standard PDP-8/S are performed by the processor. The central processor and memory are independent and asynchronous. The processor requests memory cycles only when required, each memory cycle consisting of a read followed by a write operation. Input and output addresses and data buffering for the core memory are performed by registers of the processor, and operation of the memory is under control of its own timing logic.

Interface circuits for the processor allow bussed connections to a variety of peripheral equipment. Each input/output device is responsible for detecting its own selection code and for providing any necessary input or output gating. Individually programmed data transfers between the processor and peripheral equipment take place through the processor accumulator. Standard features of the PDP-8/S also allow peripheral equipment to perform certain control functions such as instruction skipping, and a transfer of program control when initiated by a program interrupt.

Standard peripheral equipment provided with each PDP-8/S system consists of a Teletype Model 33 Automatic Send/Receive set and a Teletype control. The Teletype unit is a standard machine operating from serial 11 unit code characters at a rate of 10 characters per second. The teletype provides a means of supplying data to the computer from perforated tape or by the keyboard, and supplies data as an output from the computer in the form of perforated tapes or typed copy. The Teletype control serves as a serial-to-parallel converter for Teletype inputs to the computer, and serves as a parallel-to-serial converter for computer output signals to the Teletype unit. The Teletype control functions are performed by two functional modules which are built from monolithic integrated circuits and mounted on two standard double size FLIP CHIP cards.

SYMBOLS

The following special symbols are used throughout this handbook to explain the function of equipment and instructions:

Symbol	Explanation
A = > B	The content of register A is transferred into register B
O = > A	Register A is cleared to contain all binary zeros
Αį	Any given bit in A
A5	The content of bit 5 of register A
A5(1)	Bit 5 of register A contains a 1
A6 - 11	The content of bits 6 through 11 of register A
A6 - 11 => BO - 5	The content of bits 6 through 11 of register A is transferred into bits 0 through 5 of register B
Y	The content of any core memory location
V	Inclusive OR
₩	Exclusive OR
<u>^</u>	AND
Ā	Ones complement of the content of A




Figure 2. PDP-8/S Major Register Block Diagram

CHAPTER 1

MEMORY AND PROCESSOR FUNCTIONAL DESCRIPTION

MAJOR REGISTERS

To store, retrieve, control, and modify information and to perform the required logical, arithmetic, and data processing operations, the central processor employes the logic components shown in Figure 2 and described in the following paragraphs.

ACCUMULATOR (AC)

Arithmetic and logic operations are performed in this 12-bit register. Under programmed control, the AC can be cleared or complemented, its content can be rotated right or left with the link. The content of the memory buffer register can be added to the content of the AC and the result left in the AC. The content of both of these registers may be combined by logical operation and the result left in the AC. An inclusive OR may be performed between the AC and the switch register on the operator console and the results left in the AC. The accumulator also serves as an input/output register. All programmed information transfers between memory and an external device pass through the accumulator. In addition to these functions, the accumulator also serves as a buffer for the switch register during manual console operation. Loading an address into the program counter is accomplished by loading the content of the switch register into the accumulator and then serially transferring the content of the accumulator through the adder to the program counter register.

LINK (L)

This one-bit register is used to extend the arithmetic facilities of the accumulator. It is used as the carry register for two's complement arithmetic. Overflow into the L from the AC can be checked by the program to greatly simplify and speed up single and multiple precision arithmetic routines. Under program control the link can be cleared and/or complemented, and it can be rotated as part of the accumulator.

PROGRAM COUNTER (PC)

The program sequence (the order in which instructions are performed) is determined by the PC. This 12-bit register contains the address of the memory locations from which the next instruction will be taken. Information enters the PC from the memory via the memory address register and from the switch register on the operator console via the accumulator and adder. Information in the PC is transferred to the memory address register to determine the memory address from which each instruction is taken. Incrementation of the contents of the PC is performed through the adder and establishes the successive memory locations of the program and provides skipping of instructions based upon a programmed test of information or external conditions.

MEMORY ADDRESS REGISTER (MA)

The address in memory which is currently selected for reading or writing is contained in this 12-bit register. Therefore, 4096 words of memory can be addressed directly by this register. Data is transmitted to the MA from the PC or from the memory buffer register.

SWITCH REGISTER (SR)

Information can be manually set into the switch register for transfer into the PC as an address by means of the LOAD ADDRESS key, or into the MB if data is to be stored in core memory by means of the DEPOSIT key. The switch register may also be interrogated by programmed instruction and its contents placed in the accumulator. All transfers from SR occur through the accumulator.

MEMORY BUFFER REGISTER (MB)

All information transferred between the memory and the processor are temporarily held in the MB. Information can be transferred into the MB from the accumulator or program counter register. The MB can transmit or receive data from an external memory in either serial form or parallel form. Information is read from a memory location in 4 microseconds and rewritten in the same location in another 4 microseconds of one 8 microsecond memory cycle.

INSTRUCTION REGISTER (IR)

This 4-bit register contains the operation code of the instruction currently being performed by the machine. The three most significant bits of the current instruction plus the indirect address bit are loaded into the IR from the memory buffer register during a Fetch cycle. The content of the IR is decoded to produce the 8 basic instructions and affects the cycles and states entered in each step in the program.

PARITY BIT (PB)

Information stored in the memory contains 12 data bits plus one parity bit. The parity bit is transferred from the memory to the PB register and held until the data word is used. After the data word residing in the MB is used, the content of the PB is checked against the parity tester to determine whether bits have been dropped. New data sent to the MB has its parity stored in PB for writing along with the data word into memory.

PARITY TEST (PT)

The PT is a one-bit register which continually examines the output of the memory buffer register. Whenever MB is shifted, the parity test flip-flop generates a new parity bit for the 12-bit data word contained in the MB. The content of the PT is compared with the content of the PB, and if they are not the same, a parity error is generated.

PARITY GENERATOR (PG)

The Parity Generator examines all incoming data to the MB and generates a new parity bit. The parity bit is then transferred into the PB register just prior to requesting a write memory cycle.

SKIP TEST (SKP)

The skip test flip-flop examines the output of the AC during the microinstructions which test the content of the AC. If the SKP is set, the PC is incremented by one, causing the processor to skip the next instruction. An external input to the SKP allows peripheral hardware to generate a skip request during an IOT instruction.

SERIAL ADDER (SA)

The SA is a one-bit full serial adder and includes a carry flip-flop, which is used to hold the carry between successive bit additions, and a constant generator, which provides a + constant used in incrementing either the PC, the AC, or the MB. During a TAD instruction, the MB and AC are shifted bit by bit through the serial adder and the output of the serial adder is shifted into the front end of the AC and L. The incrementing and loading of the PC is performed through the adder. A zero detector (ZD) continuously observes the output of the adder during its use for instructions such as ISZ.

MAJOR STATE GENERATOR

Two more major states are entered serially to execute program instructions. The major state generator establishes one state for each computer timing cycle, every instruction requiring three basic states; the fetch state, the execute state, and the end state. In some cases the execute and end state of the instructions may occur simultaneously. This is so if the instruction does not require the use of the memory during the execute portion of the instruction, or if the use of the serial adder is required both during the execute and end states. In addition to these basic states, there are index and defer states and the break states. Entry into each state is produced as a function of the current instruction and the current state.

The major states of the machine are also referred to as word times, for during these times the data or instruction words are shifted between registers in the central processor.

BIT TIME GENERATOR

A major state or word time consists of a set of timing pulses provided by the bit time generator. There are 14 consecutive pulses to each word time. The first 12 of the 14 pulses 8T 0 through 11, are used for inter-register shifting in the processor. The 13th pulse is used for housekeeping operations inside the central processor as checking parity, generating parity alarm, requesting memory cycles if necessary, and handling the link during a TAD, or IAC instruction. The 14th pulse is always the final pulse in any word time and is always responsible for the setting of the next word time as a function of the current instruction and the current word time.

DESCRIPTION OF MAJOR STATES (WORD TIMES)

Fetch Word Time (F)

During this state, the instruction word which was previously placed in the MB by a memory read request is shifted to the IR and the MA. The MB is also shifted end around on itself so that the contents of the MB remains intact. At the same time, the program counter is incremented through the adder in preparation for the next instruction. All of these operations occur simultaneously during bit times 0-11. On bit time 12, parity test is executed on the instruction and a memory read request is set up if required. Also during bit time 12 and group I operate instructions, the accumulator is cleared if required, the link is cleared if required, or the complement link function occurs if required. If the instruction which is now residing in the IR is a two cycle instruction, on bit time 13, word time X (execute state) and word time E state (end state) are entered simultaneously. If the instruction is a 3-cycle instruction, only word time X is entered. If the instruction is an indirect address instruction and does not refer to one of eight auto-index locations (10-17₈) then word time D (defer state) is entered. If the instruction contains an indirect address and does refer to one of the eight auto-indexed locations, then the index word time is entered (I state).

Execute Word Time (X)

All arithmetic and logical manipulations of the AC and MB are performed during word time X. Input/output transfers also occur during word time X. At the conclusion of the execute state, word time E (end state) is always entered.

End Word Time (E)

Regardless of whether or not word time E occurs simultaneously with word time X, its function is always to bring the next instruction to be executed out of the memory into the memory buffer. In addition, if a skip request is present during ISZ, JMS, operate group 2, or IOT instructions, the PC is incremented through the serial adder. Since the PC was already incremented during word time F, the processor effectively skips the next instruction. At the termination of the end state, word time F is always entered unless a priority interrupt is present on the interrupt bus and the interrupt is enabled in which case the break word time is entered.

Index Word Time (I)

During word time I (index) the content of the memory buffer, which holds one of the eight auto-index locations. (10_{8} - 17_{8}) is incremented by one and replaced in the memory. The incremented content of the auto-index location is still in the memory buffer when the deferred state is entered. This word will be sent as a 12-bit word to the MA and used as the address of the instruction during the Defer Word time.

Defer Word Time (D)

Word time D is always entered after word time I, or after word time F when an indirect bit (IR3) is present. During the word time, the content of the memory buffer is

sent to the memory address register to be used as a 12-bit address for the instruction operand. On termination of the defer state, the execute state or the execute and end states are entered depending on whether the basic instruction was a two or three cycle instruction.

Break Word Time (B)

Should an interrupt request be present on the interrupt fine at the completion of word time E, the break state is entered and the content of the program counter is transferred to the MB. A 1 is placed in the program counter and a 0 is placed in the MA. A memory write request is then initiated which will cause the content of the MB (previous C (PC)) to be saved in location 0. The interrupt control is disabled during the break state. At the termination of the break state, the end state is always entered, and the next instruction will be taken from the current content of the program counter or location 1 in the memory.

INTERFACE

The input/output portion of the PDP-8/S is extremely flexible and interfaces readily with special equipment, especially in real time data processing and control environments. The PDP-8/S utilizes a "bus" I/O system rather than the more conventional "radial" system. The "bus" system allows a single set of data and control lines to communicate with all I/O devices. The bus simply goes from one device to the next. No additional connections to the computer are required. A "radial" system requires that a different set of signals be transmitted to each device; and thus the computer must be modified when new devices are added. The PDP-8/S need not be modified when adding new peripheral devices.

External devices receive two types of information from the computer: data and control signals. Computer output data is present as static levels on 12 lines. These levels represent a 12-bit word to be transmitted in parallel to a device. Data signals are received at all devices but are sampled only by the appropriate one in response to a control signal. Control signals are of two types: levels and timing pulses. Six static levels and their complement are supplied by the MB on 12 lines. These times contain a code representing the device from which action is required. Each device recognizes its own code and performs its function only when this code is present. There are three timing pulses which may be programmed to occur. These IOP pulses are separated in time by 1 μ sec and are brought to all devices on 3 lines. These pulses are used by a device only when it is selected by the appropriate code on the level lines. They may be used to perform sequential functions in an external register, such as clear and read, or any other function requiring one, two, or three sequential pulses.

Peripheral devices transmit information to the computer on four types of "busses". These are the information bus, the clear AC bus, the skip bus, and the program interrupt bus. The information bus consists of 12 lines normally held at —3 volts by load resistors within the computer. Whenever one of these lines is brought to ground, a binary 1 will be placed in the corresponding accumulator bit. Each device may use the input bus only when it is selected; and thus, these input lines are time shared among all of the connected devices. The skip bus is electrically identical to the information bus. However, when it is driven to ground the next sequential instruction will be skipped. It too can be used only by the device currently selected and is effectively time shares. The program interrupt bus may be driven to ground at any time by any device whether currently selected or not. When more than one device is connected to the interrupt bus they should also be connected to the skip bus so the program can identify the device requesting program interruption.

The transmission of device selection levels and timing pulses is completely under program control. A single instruction can select any one of 64 devices and transmit up to three IOP timing pulses. Since the timing pulses are individually programmable, one might be used to strobe data into an external device buffer, another to transmit data to the computer, and the third to test a status flip-flop and drive the skip bus to ground if it is in the enabling state.

CHAPTER TWO

MEMORY AND PROCESSOR INSTRUCTIONS

Instruction words are of two types: memory reference and augmented. Memory reference instructions store or retrieve data from core memory, while augmented instructions do not. All instructions utilize bits 0-2 to specify the operation code. Operation codes of 08 through 58 specify memory reference instructions, and codes of 68 and 78 specify augmented instructions. Since the PDP-8/S operates asynchronously from its memory machine timing is not a multiple of the memory cycle time. Every word time for major states represents a processor time of 10 microseconds. Thus a two cycle instruction requires 20 microseconds worth of processor time. If a major state requires a memory reference, another 8 microseconds is added to the processor cycle time. Example: a two cycle instruction requiring one memory reference consists of 20 microseconds worth of processor time plus 8 microseconds worth of memory cycle time for a total execution time of 28 microseconds. Indirect addressing increases the execution time for the memory reference instruction by 18 microseconds; i.e., 10 microseconds worth of processor time and 8 microseconds worth of memory time. Indirect addressing referencing one of the eight auto-index locations adds an additional 18 microseconds to an indirect memory reference instruction. Augmented instruction, input/output transfer and operate, are performed in two or three machine cycles each requiring one memory reference cycle. Therefore they require either 28 microseconds or 38 microseconds total time.

MEMORY REFERENCE INSTRUCTIONS

Since the PDP-8/S system contains a 4096-word core memory, 12 bits are required to address all locations. To simplify addressing, the core memory is divided into blocks, or pages, of 128 words (2008 addresses). Pages are numbered 08 through 378 and each field of 4096-words of core memory uses 32 pages. The seven address bits (bits 5 through 11) of a memory reference instruction can address any location in the page on which the current instruction is located by placing a 1 in bit 4 of the instruction. By placing a 0 in bit 4 of the instruction, any location in page 0 can be addressed directly from any page of core memory. All other core memory locations can be addressed indirectly by placing a 1 in bit 3 and placing a 7-bit effective address in bits 5 through 11 of the instruction to specify the location in the current page or page 0 which contains the full 12-bit abosolute address of the operand.




Figure 3. Memory Reference Instruction Bit Assignments

Word format of memory reference instructions is shown in Figure 3 and the instructions performed as follows:

LOGICAL AND (AND Y)

Octal Code: 0

Indicators: AND, FETCH, EXECUTE, END

Execution Time: 36 microseconds with direct addressing, 54 microseconds with indirect

addressing, 72 microseconds with auto-indexing

Parity Test: instruction, operand

Operation: The AND operation is performed between the content of memory location Y and the contents of the AC. The result is left in the AC, the original content of the AC is lost, and the content of Y is restored. Corresponding bits of the AC and Y are operated upon independently. This instruction, often called extract or mask, can be considered as a bit-by-bit multiplication. Example:

Original		Final
_ACi	Yi	ACi
0	0	n
Ö	i	ō
1	0	0
1	1	l

Symbol: ACj AYi= ACj

TWO'S COMPLEMENT ADD (TAD Y)

Octal Code: 1

Indicators: TAD, FETCH, EXECUTE, END

Execution Time: 36 microseconds with direct addressing, 54 microseconds with indirect

addressing, 72 microseconds with auto-indexing

Parity Test: instruction, operand

Operation: The contents of memory location Y is added to the content of the AC in two's complement arithmetic. The result of this addition is held in the AC, the original content of the AC is lost, and the content of Y is restored. If there is a carry from ACO, the link is complemented. This feature is useful in multiple precision arithmetic.

Symbol: ACO-11 + YO-11 = -> ACO-11

INCREMENT AND SKIP IF ZERO (ISZ Y)

Octal Code: 2

Indicators: ISZ, FETCH, EXECUTE, END

Execution Time, 54 microseconds with direct addressing, 72 microseconds with indirect addressing, 90 microseconds with auto-indexing

Parity Test: instruction, operand

Operation: The content of memory location Y is incremented by one in two's complement arithmetic. If the resultant content of Y equals zero, the content of the PC is incremented by one and the next instruction is skipped. If the resultant content of Y does not equal zero, the program proceeds to the next instruction. The incremented content of Y is restored to memory. The content of the AC is not affected by this instruction.

Symbol: $Y + 1 \Rightarrow Y$ If resultant YO-11=0, then $PC+1 \Rightarrow PC$

DEPOSIT AND CLEAR AC (DCA Y)

Octal Code: 3

Indicators: DCA, FETCH, EXECUTE, END

Execution Time: 46 microseconds with direct addressing, 64 microseconds with indirect addressing, 82 microseconds with auto-indexing

Parity Test: instruction

Operation: The content of the AC is deposited in core memory at address Y and the AC is cleared. The previous content of memory location Y is lost.

Symbol: AC = > Y, then O = > AC

JUMP TO SUBROUTINE (JMS Y)

Octal Code: 4

Indicators: JMS, FETCH, EXECUTE, END

Execution Time: 46 microseconds with direct addressing, 64 microseconds with indirect addressing, 82 microseconds with auto-indexing.

Parity Test: instruction

Operation: The content of the PC is deposited in core memory location Y and the next instruction is taken from core memory location Y + 1. The content of the AC is not affected by this instruction.

Symbol: $PC + 1 \Rightarrow Y$

 $Y + 1 \Rightarrow PC$

JUMP TO Y (JMP Y)

Octal Code: 5

Indicators: JMP, FETCH, EXECUTE, END

Execution Time: 28 microseconds with direct addressing, 46 microseconds with indirect

addressing, 64 microseconds with auto-indexing.

Parity Test: instruction

Operation: Address Y is set into the PC so that the next instruction is taken from core memory address Y. The original content of the PC is lost. The content of the AC is not affected by this instruction.

Symbol: Y => PC

AUGMENTED INSTRUCTIONS

There are two augmented instructions which do not reference memory. They are the input/output transfer (IOT) which has an operation code of 6 and the operate (OPR) which has an operation code of 7. Bits 3-11 within these instructions function as an extension of the operation code and can be microprogrammed to perform several operations within one instruction. The IOT instruction is a 3 processor cycle instruction requiring a fetch, an execute, and an end cycle. Only one memory reference is required for the IOT instruction, the total time of the instruction therefore is 38 microseconds.

During the execute state, a series of three microprogrammed pulses may be generated starting with bit time 0 of word time X and separated from each other by one microsecond intervals. These pulses are used to initiate external functions and are designated as input/output pulses (IOP 1, 2, 4). There are two classes of operate instructions: Group 2 operate instructions are used for testing the accumulator and require 3 processor cycles and 1 memory reference cycle. These instructions therefore require 38 microseconds. Group 1 operate instructions are used for rotating the accumulator and incrementing the accumulator. These instructions require 2 processor cycles and 1 memory reference cycle and therefore execution time is 28 microseconds.

INPUT OUTPUT TRANSFER INSTRUCTION

Microinstructions of the input-output transfer (IOT) instruction initiate operation of peripheral equipment and effect information transfers between the processor and an I/O device. Specifically, when an operation code of 6 is detected, the IOP generator is enabled to produce IOP 1, IOP 2, and IOP 4 pulses as a function of the content of instruction bits 9 through 11. These pulses occur at 1 microsecond intervals designated as event times 3, 2, and 1 as follows:

Instruction Bit	IOP <u>Pulse</u>	IOT <u>Pulse</u>	Event Time
11	IOP 1	IOT 1	ı
10	IOP 2	IOT 2	2
9	IOP 4	IOT 4	3

The IOP pulses are gated in the device selector of the program-selected equipment to produce IOT pulses that enact a data transfer or initiate a control operation. Selection of an equipment is accomplished by bits 3 through 8 of the IOT instruction. These bits form a 6-bit code that enables the device selector in a given device.

The format of the IOT instruction is shown in Figure 4. Operations performed by IOT microinstructions are explained in Section B of this handbook.




Figure 4 IOT Instruction Bit Assignments

OPERATE INSTRUCTION

The operate instruction consists of two groups of microinstructions. Group 1 (OPR 1) is principally for clear, complement, rotate, and increment operations and is designated by the presence of a 0 in bit 3. Group 2 (OPR 2) is used principally in checking the content of the accumulator and link and continuing to, or skipping, the next instruction based on the check. A 1 in bit 3 designates an OPR 2 microinstruction.

Group 1 operate microinstruction format is shown in Figure 5 and the microinstructions are explained in the succeeding paragraphs. Any logical combination of bits within this group can be combined into one microinstruction. For example, it is possible to assign ones to bits 5, 6, and 11; but it is not logical to assign ones to bits 8 and 9 simultaneously since they specify conflicting operations. The only restriction on combining OPR 1 operations within one instruction, other than logical conflicts, is that a rotate operation (bits 8, 9, or 10) may not be combined with the increment AC operation (bit 11) since they are executed during the same bit times.




Figure 5 Group 1 Operate Instruction Bit Assignments

NO OPERATION (NOP)

Octal Code: 7000

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: This command causes a 1 instruction delay in the program (28 microseconds) and then the next sequential instruction is initiated. This command is used to add execution time to a program, such as to synchronize subroutine or loop timing with peripheral equipment timing.

Symbol: None

INCREMENT ACCUMULATOR (IAC)

Octal Code: 7001

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the AC is incremented by one in two's complement arithmetic.

Symbol: AC + 1 => AC

ROTATE ACCUMULATOR LEFT (RAL)

Octal Code: 7004

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 2.8 microseconds

Parity Test: instruction

Operation: The content of the AC is rotated one binary position to the left with the content of the link. The content of bits AC1-11 are shifted to the next greater significant bit, the content of AC0 is shifted into the L, and the content of the L is shifted in AC11.

Symbol: ACj => ACj - 1

ACO => L

L = AC10

ROTATE TWO LEFT (RTL)

Octal Code: 7006

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the AC is rotated two binary positions to the left with the content of the link. This instruction is logically equal to two successive RAL operations.

Symbol: ACj = ACj = 2

AC1 => L

AC0 => AC11

L => AC10

ROTATE ACCUMULATOR RIGHT (RAR)

Octal Code: 7010

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the AC is rotated one binary position to the right with the content of the link. The content of bits ACO-10 are shifted to the next less significant bit, the content of AC11 is shifted into the L, and the content of the L is shifted into AC0.

Symbol: $ACj \Rightarrow ACj + 1$

 $AC11 \Rightarrow L L \Rightarrow AC0$

ROTATE TWO RIGHT (RTR)

Octal Code: 7012

Indicators, OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the AC is rotated two binary positions to the right with the content of the link. This instruction is logically equal to two successive RAR operations.

Symbol: $ACj \Rightarrow ACj + 2$

AC11 = AC0

AC10 = L

L = > AC1

COMPLEMENT LINK (CML)

Octal Code: 7020

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the L is complemented.

Symbol: $\overline{L} \Rightarrow L$

COMPLEMENT ACCUMULATOR (CMA)

Octal Code: 7040

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the AC is set to the one's complement of the current contents

of the AC. The content of each bit of the AC is complemented individually.

Symbol: $\overline{ACj} \Rightarrow ACj$

COMPLEMENT AND INCREMENT ACCUMULATOR (CIA)

Octal Code: 7041

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the AC is converted from a binary value to its equivalent two's complement number. This conversion is accomplished by combining the CMA and IAC commands, thus the one's complement of the content of the AC is incremented by one during bit time 0-11.

Symbol: ACj => ACj,

then $AC + 1 \Rightarrow AC$

CLEAR LINK (CLL)

Octal Code: 7100

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of the L is cleared to contain a 0.

Symbol: 0 => L

SET LINK (STL)

Octal Code: 7120

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The L is set to contain a binary 1. This instruction is logically equal to

combining the CLL and CML commands.

Symbol: $1 \Rightarrow L$

CLEAR ACCUMULATOR (CLA)

Octal Code: 7200

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: The content of each bit of the AC is cleared to contain a binary 0.

Symbol: 0 => AC

SET ACCUMULATOR (STA)

Octal Code: 7240

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 28 microseconds

Parity Test: instruction

Operation: Each bit of the AC is set to contain a binary 1. This operation is logically equal to combining the CLA and CMA commands.

Symbol: 1 => ACj

Group 2 operate microinstruction format is shown in Figure 6 and the primary microinstructions are explained in the following paragraphs. Any logical combination of bits within this group can be composed into one microinstruction. (The instructions constructed by most logical command combinations are listed in Appendix 1.)

If skips are combined in a single instruction the inclusive OR of the conditions determines the skip when bit 8 is a 0; and the AND of the inverse of the conditions determines the skip when bit 8 is a 1. For example, if ones are designated in bits 6 and 7 (SZA and SNL), the next instruction is skipped if either the content of the AC = 0, or the content of L = 1. If ones are contained in bits 5, 7, and 8, the next instruction is skipped if the AC contains a positive number and the L contains a 0.




Figure 6 Group 2 Operate Instruction Bit Assignments

HALT (HLT)

Octal Code: 7402

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: Clears the RUN flip-flop at the end of word time E, just after memory request for the next instruction is executed so that the program stops at the conclusion of the current instructions. This command can be combined with others in the OPR 2 group. In such combinations the operations are executed prior to the program stop.

Symbol: 0 = >RUN

OR WITH SWITCH REGISTER (OSR)

Octal Code: 7404

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The inclusive OR operation is performed between the content of the AC and the content of the SR. The result is left in the AC, the original content of the AC is lost, and the content of the SR is unaffected by this command. When combined with the CLA command, the OSR performs a transfer of the content of the SR in the AC.

Symbol: ACj V SRj = > ACj

SKIP, UNCONDITIONAL (SKP)

Octal Code: 7410

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the PC is incremented by one so that the next sequential

instruction is skipped.

Symbol: PC + 1 = > PC

SKIP ON NON-ZERO LINK (SNL)

Octal Code: 7420

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the L is sampled, and if it contains a 1 the content of the PC is incremented by one so that the next sequential instruction is skipped. If the L contains a 0, no operation occurs and the next sequential instruction is initiated.

Symbol: If L = 1, then PC + 1 = >PC

SKIP ON ZERO LINK (SZL)

Octal Code: 7430

Event Time: 1

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the L is sampled, and if it contains a 0 the content of the PC is incremented by one so that the next sequential instruction is skipped. If the L contains a 1, no operation occurs and the next sequential instruction is initiated.

SKIP ON ZERO ACCUMULATOR (SZA)

Symbol: If L = 0, then PC + 1 = PC

Octal code: 7440

Indicators: OPR, FETCH, EXECUTE, END

Execution TfME: 38 microseconds

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of each bit of the AC is sampled, and if each bit contains a 0 the content of the PC is incremented by one so that the next sequential instruction is skipped. If any bit of the AC contains a 1, no operation occurs and the next sequential instruction is initiated.

Symbol: If ACO - 11 = 0, then PC + 1 => PC

SKIP ON NON-ZERO ACCUMULATOR (SNA)

Octal Code: 7450

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test. instruction

Operation: The content of each bit of the AC is a sampled, and if any bit contains a 1 the content of the PC is incremented by one so that the next sequential instruction is skipped. If all bits of the AC contain a 0, no operation occurs and the next sequential instruction is initiated.

Symbol: If ACO - 11 \neq 0, then PC + 1 => PC

38 microseconds

SKIP ON MINUS ACCUMULATOR (SMA)

Octal Code: 7500

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the most significant bit of the AC is sampled, and if it contains a 1, indicating the AC contains a negative two's complement number, the content of the PC is incremented by one so that the next sequential instruction is skipped. If the AC contains a positive number no operation occurs and program control advances to the next sequential instruction.

Symbol: If ACO = 1, then PC + 1 = \rightarrow PC

SKIP ON POSITIVE ACCUMULATOR (SPA)

Octal Code: 7510

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the most significant bit of the AC is sampled, and if it contains a 0, indicating a positive (or zero) two's complement number, the content of the PC is incremented by one so that the next sequential instruction is skipped. If the AC contains a negative number, no operation occurs and program control advances to the next sequential instruction.

Symbol: If ACO = 0, then PC + 1 = PC

CLEAR ACCUMULATOR (CLA)

Octal Code: 7600

Indicators: OPR, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: Each bit of the AC is cleared to contain a binary 0.

Symbol: 0 = >AC

CHAPTER 3

MEMORY AND PROCESSOR BASIC PROGRAMMING

MEMORY ADDRESSING

The following terms are used in memory address programming:

<u>Term</u>	Definition
Page	A block of 128 core memory locations (200 $_8$ addresses).
Current Page	The page containing the instruction being executed; as determined by bits 0 through 4 of the program counter.
Page Address	An 8-bit number contained in bits 4 through 11 of an instruction which designates one of 256 core memory locations. Bit 4 of a page address indicates that the location is in the current page when a 1, or indicates it is in page 0 when a 0. Bits 5 through 11 designate one of the 128 locations in the page determined by bit 4.
Absolute Address	A 12-bit number used to address any location in core memory.
Effective Address	The address of the operand. When the address of the operand is in the current page or in page 0, the effective address is a page address. Otherwise, the effective address is an absolute address stored in the current page or page 0 and obtained by indirect addressing.

Organization of the standard core memory or any 4096-word field of extended memory is summarized as follows:

Total locations (decimal) Total addresses (octal)	4096 7777
Number of pages (decimal) Page designations (actal)	32 0-37
Number of locations per page (decimal) Addresses within a page (octal)	128 0-177

Four methods of obtaining the effective address are used as specified by combinations of bits 3 and 4.

Bit 3	Bit 4	Effective Address
0	0	The operand is in page 0 at the address specified by bits 5 through $\{1,\dots,n\}$
0	1	The operand is in the current page at the address specified by bits 5 through 11.
1	0	The absolute address of the operand is taken from the content of the location in page 0 designated by bits 5 through 11.
1	1	The absolute address of the operand is taken from the content of the location in the current page designated by bits 5 through 11.

The following example indicates the use of bits 3 and 4 to address any location in core memory. Suppose it is desired to add the content of locations A, B, C, and D to the content of the accumulator by means of a routine stored in page 2. The instructions in this example indicate the operation code, the content of bit 4, the content of bit 3, and a 7-bit address. This routine would take the following form:

Loca	Page 0 ution Content	Loca	Page 1 ition Content	Loca	Page 2 Ition Content	Remarks
				R	TAD 00 A	DIRECT TO DATA IN PAGE 0
				S	TAD 01 B	DIRECT TO DATA IN
				T	TAD 10 M	INDIRECT TO ADDRESS SPECIFIED IN PAGE 0
				υ	TAD 11 N	INDIRECT TO ADDRESS SPECIFIED IN SAME PAGE
					•	
					•	
A M	xxxx C	D D	xxxx xxxx	B N	xxxx D	

Routines using 128 instructions, or less, can be written in one page using direct addresses for looping and using indirect addresses for data stored in other pages. When planning the location of instructions and data in core memory, remember that the following locations are reserved for special purposes:

Address

08
Stores the contents of the program counterfollowing a program interrupt.

18
Stores the first instruction to be executed following a program interrupt.

108 through 178
Auto-indexing.

INDIRECT ADDRESSING

When indirect addressing is specified, the address part (bits 5-11) of a memory reference instruction is interpreted as the address of a location containing not the operand, but containing the address of the operand. Consider the instruction TAD A. Normally, A is interpreted as the address of the location containing the quantity to be added to the content of the AC. Thus, if location 100 contains the number 5432, the instruction TAD 100 causes the quantity 5432 to be added to the content of the AC. Now suppose that location 5432 contains the number 6543. The instruction TAD I 100 (where I signifies indirect addressing) causes the computer to take the number 5432, which is in location 100, as the effective address of the instruction and the number in location 5432 as the operand. Hence, this instruction results in the quantity 6543 being added to the content of the AC.

AUTO-INDEXING

When a location between 10_8 and 17_8 in page 0 of any core memory field is addressed indirectly (by an instruction in which bit 3 is a 1) the content of that location is read, incremented by one, rewritten in the same location, and then taken as the effective address of the instruction. This feature is called auto-indexing. If location 12_8 contains the number 5432 and the instruction DCA I Z 12 is given, the number 5433 is stored in location 12, and the content of the accumulator is deposited in core memory location 5433.

STORING AND LOADING

Data is stored in any core memory location by use of the DCA Y instruction. This instruction clears the AC to simplify loading of the next datum. If the data deposited is required in the AC for the next program operation, the DCA must be followed by a TAD Y for the same address.

All loading of core memory information into the AC is accomplished by means of the TAD Y instruction, preceded by an instruction that clears the AC such as CLA or DCA.

Storing and Loading of information in sequential core memory locations can make excellent use of an auto-indexing register to specify the core memory address.

Program Control

Transfer of program control to any core memory location uses the JMP or JMS instructions. The JMP I (indirect address, 1 in bit 3) is used to transfer program control to any location in core memory which is not in the current page or page 0.

The JMS Y is used to enter a subroutine which starts at location Y+1 in the current page or page 0. The content of the PC+1 is stored in the specified address Y, and address Y+1 is transferred into the PC. To exit a subroutine the last instruction is a JMP I-Y, which returns program control to the location stored in Y.

Indexing Operations

External events can be counted by the program and the number can be stored in core memory. The core memory location used to store the event count can be initialized (cleared) by a CLA command followed by a DCA instruction. Each time the event occurs, the event count can be advanced by a sequence of commands such as CLA, TAD, IAC, and DCA.

The ISZ instruction is used to count repetitive program operations or external events without disturbing the content of the accumulator. Counting a specified number of operations is performed by storing a two's complement negative number equal to the number of iterations to be counted. Each time the operation is performed, the ISZ instruction is used to increment the content of this stored number and check the result. When the stored number becomes zero, the specified number of operations have occurred and the program skips out of the loop and back to the main sequence.

This instruction is also used for other routines in which the content of a memory location is incremented without disturbing the content of the accumulator, such as storing information from an I/O device in sequential memory locations or using core memory locations to count I/O device events.

LOGIC OPERATIONS

The PDP-8/S instruction list includes the logic instruction, AND Y. From this instruction short routines can be written to perform the inclusive OR and exclusive OR operations.

Logical AND

The logic AND operation between the content of the accumulator and the content of a core memory location Y is performed directly by means of the AND Y instruction. The result remains in the AC, the original content of the AC is lost, and the content of Y is unaffected.

Inclusive OR

Assuming value A is in the AC and value B is stored in a known core memory address, the following sequence performs the inclusive OR. The sequence is stated as a utility subroutine called IOR.

```
JM5 IOR
/CALLING SEQUENCE
                                                         (ADDRESS OF B)
                                                         (RETURN)
/ENTER WITH ARGUMENT IN AC; EXIT WITH LOGICAL RESULT IN AC
                  IOR,
                             DCA TEM1
                             TAD 1 IOR
                             DCA TEM2
                             TAD TEM1
                             CMA
                             AND I TEM2
                             TAD TEM1
                             ISZ IOR
                             JMP I IOR
                  TEM1,
                             0
                  TEM2,
```

Exclusive OR

The exclusive OR operation for two numbers, A and B, can be performed by a subroutine called by the mnemonic code XOR. In the following general purpose XOR subroutine, the value A is assumed to be in the AC, and the address of the value B is assumed to be stored in a known memory location.

```
JMS XOR
/CALLING SEQUENCE
                                                        (A) DRESS OF B)
                                                        (RETURN)
/ENTER WITH ARGUMENT IN AC; EXIT WITH LOGICAL RESULT IN AC
                  XOR,
                               0
                               DCA TEM1
                               TAD 1 XOR
                               DCA TEM2
                               TAD TEM1
                               AND 1 TEM2
                                CMA IAC
                               CLL RAL
                               TAD TEMI
                               TAD 1 TEM2
                                ISZ XOR
                                JMP 1 XOR
                  TEM1,
                                0
                  TEM2,
                                0
```

An XOR subroutine can be written using fewer core memory locations by making use of the IOR subroutine; however, such a subroutine takes more time to execute. A faster XOR subroutine can be written by storing the value B in the second instruction of the calling sequence instead of the address of B; however, the resulting subroutine is not as utilitarian as the routine given here.

ARITHMETIC OPERATIONS

One arithmetic instruction is included in the PDP-8/S order code the two's complement add: TAD Y. Using this instruction, routines can easily be written to perform addition, subtraction, multiplication, and division in two's complement arithmetic.

Two's Complement Arithmetic

In two's complement arithmetic addition, subraction, multiplication, and division of binary numbers is performed in accordance with the common rules of binary arithmetic PDP-8/S, as in other machines utilizing complementation techniques, negative numbers are represented as the complement of positive numbers, and subtraction is achieved by complement addition. Representation of negative values in one's complement arithmetic is slightly different from that in two's complement arithmetic.

The one's complement of a number is the complement of the absolute positive value; that is, all ones are replaced by zeros and all zeros are replaced by ones. The two's complement of a number is equal to the one's complement of the positive value plus one.

In one's complement arithmetic a carry from the sign bit (most significant bit) is added to the least significant bit in an end-around carry. In two's complement arithmetic a carry from the sign bit complements the link (a carry would set the link to 1 if it were properly cleared before the operation), and there is no end-around carry.

A one's complement representation of a negative number is always one less than the two's complement representation of the same number. Differences between one's and two's complement representations are indicated in the following list:

Number	1's Complement	2's Complement
+5	000000000101	00000000101
+4	00000000100	00000000100
+3	00000000011	00000000011
+2	00000000010	00000000010
+1	00000000001	0000000001
+0	00000000000	00000000000
-0	111111111111	Nonexistent
_1	11111111110	111111111111
-2	11111111101	111111111110
_3	111111111100	111111111101
-4	11111111011	111111111100
-5	111111111010	111111111111111111111111111111111111111

Note that in two's complement there is only one representation for the number which has the value zero, while in one's complement there are two representations. Note also that complementation does not interfere with sign notation in either one's complement or two's complement arithmetic; bit 0 remains a 0 for positive numbers and a 1 for negative numbers.

To form the two's complement of any number in the PDP-8/S the one's complement is formed, and the result is incremented by one. This is accomplished by the instruction CMA combined with an IAC instruction. Since both of these instructions are functions of the OPR 1 instruction and the actions occur at different event times, they can be combined to form the instruction CIA, Complement and increment AC.

ADDITION

The addition of a number contained in a core memory location and the number contained in the accumulator is performed directly by using the TAD Y instruction, assuming that the binary point is in the same position and that both numbers are properly represented in two's complement arithmetic. Addition can be performed without regard for the sign of either the augend or the addend. Overflow is possible, in which case the result will have an incorrect sign, although the 11 least significant bits will be correct. Following the addition a test for overflow can be made by using the SZL command.

SUBTRACTION

Subtraction is performed by complementing the subtrahend and adding the minuend. As in addition, if both numbers are represented by their two's complement, subtraction can be performed without regard for the sign of either number. Assuming that both numbers are stored in core memory, a routine to find the value of A-B follows:

CLA	
TAD B	/LOAD SUBTRAHEND INTO AC
CIA	COMPLEMENT AND INCREMENT B
TAD A	/AC = A - B

CHAPTER 4

PROGRAM INTERRUPT

The program interrupt feature allows certain external conditions to interrupt the computer program. It is used to speed the information processing of input-output devices or to allow certain alarms to halt the program in progress and initiate another routine. When a program interrupt request is made the computer completes execution of the instruction in progress before acknowledging the request and entering the interrupt mode. A program interrupt is similar to a JMS to location 0; that is, the content of the program counter is stored in location 0, and the program resumes operation in location 1. The interrupt program commencing in location 1 is responsible for identifying the signal causing the interruption, for removing the interrupt condition, and for returning to the original program. Exit from the interrupt program, back to the original program, can be accomplished by a JMP 1-Z 0 instruction.

INSTRUCTIONS

The two instructions associated with the program interrupt synchronization element are IOT microinstructions that do not use the IOP generator. These instructions are:

INTERRUPT TURN ON (ION)

Octal Code: 6001

Event Time: Not applicable

Indicators: IOT, FETCH, EXECUTE, END, ION

Execution Time: 38 microseconds

Parity Test: instructions

Operation: This command enables the computer to respond to a program interrupt request. If the interrupt is disabled when this instruction is given, the computer executes the next instruction, then enables the interrupt. The additional instruction allows exit from the interrupt subroutines before allowing another interrupt to occur. This instruction has no affect upon the condition of the interrupt circuits if it is given when the interrupt is enabled.

Symbol: 1 = > INT. ENABLE

INTERRUPT TURN OFF (IOF)

Octal Code: 6002

Event Time: Not applicable

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instructions

Operation: This command disables the program interrupt synchronization element to prevent interruption of the current program.

Symbol: 0 => INT. ENABLE, INT. DELAY

PROGRAMMING

When an interrupt request is acknowledged, the interrupt is automatically disabled by the program interrupt synchronization circuits (not by instructions). The break state is entered after completion of the current instruction, followed by the end state when the next instruction is taken from core memory location 1. A total of 36 microseconds is therefore needed to complete the break. Usually the instruction stored in location 1 is a JMP, which transfers program control to a subroutine which services the interrupt. At some time during this subroutine an ION instruction must be given. The ION can be given at the end of the subroutine to allow other interrupts to be serviced after program control is transferred back to the original program. In this application, the ION instruction immediately precedes the last instruction in the routine. A delay of one instruction (regardless of the execution time of the instruction in progress at the time the request is made) is inherent in the ION instruction to allow transfer of program control back to the original program before enabling the interrupt. Usually exit from the subroutine is accomplished by a JMP I 0 instruction.

The ION command can be given during the subroutine as soon as it has determined the I/O device causing the interrupt. This latter method allows the subroutine which is handling a low priority interrupt to be interrupted, possibly by a high priority device. Programming of an interrupt subroutine which checks for priority and allows itself to be interrupted, must make provisions to relocate the content of the program counter stored in location 0; so that if interrupted, the content of the PC during the subroutine is stored in location 0, and the content of the PC during the original program is not lost.

MEMORY PARITY

Checking of each word written in and read from memory is provided by the parity checking hardware. Thus each word stored in memory is a 13 bit word consisting of 12 data bits and one parity bit. The parity bit is made either a 0 or a 1 so that an even number of binary ones is always present in every word in memory. Every word which enters the memory buffer from the processor has a new parity bit generated, for writing in the memory. Every word entering the memory buffer from the memory carries with it a parity bit. Every word shifted from the memory buffer into the processor has its parity tested and checked against the parity bit which was placed in the processor by the memory. The memory parity error flag is connected to the interrupt bus and will generate an interrupt if the interrupt is enabled and a parity error occurs.

INSTRUCTIONS

SKIP ON NO MEMORY PARITY ERROR (SMP)

Octal Code: 6101

Event Time: 3

Indicator: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instructions

Operation: The memory parity error flag is sensed and if it contains a O (signifying no error has been detected) the PC is incremented so that the next successive instruction is skipped.

Symbol: If Memory Parity Error Flag = 0, then PC + 1 = > PC

CLEAR MEMORY PARITY ERROR FLAG (CMP)

Octal Code: 6104

Event Time: 2

Indicator: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instructions

Operation: The memory parity error flag is cleared.

Symbol: 0 = Memory Parity Error Flag

PROGRAMMING

Both instructions for this option are used in the program interrupt subroutine and in diagnostic maintenance programs. The SMP command is used as a programmed check for memory parity error. In the program interrupt subroutine this command can be followed by a jump to a portion of the routine that services memory parity as described previously. The CMP command is used to initialize memory parity in preparation for normal programmed operation of the computer.

BASIC IOT PROGRAMMING

Two basic modes of programming can be used to transfer information or control signals between input/output devices and the PDP-8/S. These modes are programmed data transfers and program interrupt. To understand the use which can be made of each of these control modes assume that the PDP-8/S is connected as the primary control element in a system which contains several furnaces or kilns, continuous-belt conveyors which transport products through the furnaces and a visual monitor panel. Assume that each furnace or zone of an oven contains a controller which has a digital temperature readout, and overtemperature and undertemperature alarms which can be set by a digital readin. Next, assume that the conveyor for each oven is automatically loaded with blocks of products spaced at given distances on the conveyor and that the conveyor has a normal speed, a high emergency speed, and a stop control. The following explanation of the use of each of the two control modes in programming this hypothetical system can easily be translated into examples of processing or other control system programs.

PROGRAMMED DATA TRANSFERS

All peripheral equipment transfers information to or from the computer by programmed instructions. This means of communication can be used as the sole method of transferring information or can be used to initialize equipment using the program interrupt or data break facilities. This mode of operation utilizes the IOT instruction which is divided into three parts. Bits 0, 1, and 2 contain an operation code of 6 to specify the IOT microinstruction. Bits 3 through 8 serve as a device selection code which is transmitted to all peripheral equipment and which activates only the equipment designated by a specific code number contained within these bits. Bits 9, 10, and 11 control the IOP generator within the processor and enable or disable generation of IOP1, IOP2, and IOP4 pulses during each IOT instruction. A device selector within each peripheral equipment monitors the device selection lines and enables pulse amplifiers when its assigned select code has been detected within bits 3 through 8 of an IOT instruction. When enabled in this manner the pulse amplifiers produce positive or negative IOT pulses when triggered by an associated IOP pulse. The IOT pulses, in turn, perform data transfers to or from the computer or perform control functions within the peripheral equipment.

Each peripheral equipment can contain one or more device selector. A device selector can consist of a Type W103 Device Selector FLIP CHIP module, or can be constructed of three FLIP-CHIP modules such as the Type R603 Pulse Amplifier, R111 Diode Gate, and R002 Diode Cluster. Regardless of its circuit components, a device selector consists of a 6-input negative diode NAND gate which is enabled only when the select code of the specified device is contained in the instruction. The output from this NAND gate enables gating circuits at the input of each of three pulse amplifiers which are triggered by the IOP1, IOP2, or IOP4 pulse.

SENSE FOR DEVICE READY

In preparation for a normal data transfer the computer program normally checks the ready status of the transmitting or receiving device by means of a skip instruction. This skip instruction can skip on either the ready or not ready status of the device, depending upon the internal operations of that device. In our imaginary PDP-8/S control system, assume that the control for each furnace contains an "up to temperature flag" and an associated

instruction which provides a Skip pulse to the program counter control element when the operating temperature range has been attained. Therefore the programming can contain this skip on up to temperature instruction followed by a JMP instruction which transfers program control back in a loop so that it repeatedly checks the up to temperature flag until the acceptable temperature range has been attained. Then the next step in the program proceeds with an operation, such as initiate loading of the conveyor and movement of the conveyor at the normal speed. In some instances the program will proceed to assemble data so that it can be transferred into or out of the computer.


ASSEMBLE DATA

The ready control described under the previous heading can indicate that a device is operating in a known control mode or that data is ready for transmission. In our example the former condition is true so that data assembly follows the sense for ready operation. To assemble data the program issues commands in one or more IOT instructions to clear and load a buffer with data to be transferred from the accumulator, or to clear and load the accumulator for data to be transferred to a peripheral equipment buffer. In the imaginary control system described earlier, data assembly could consist of an instruction which generates an IOT1 pulse to clear an information buffer, generates an IOT2 pulse to load a temperature setting into the six least significant bits of this buffer and loads the status of the undertemperature and overtemperature flags into the two most significant bits of this buffer.

EFFECT A TRANSFER

Actual data transfer between peripheral equipment and the PDP-8/S accumulator is performed by an IOT instruction. Usually a transfer into the PDP-8/S is performed by an instruction in which an IOT1 pulse is generated to clear the accumulator and a later IOT pulse is generated to strobe the content of an external buffer into the accumulator. In transfers from the accumulator to an external buffer the static accumulator data lines are used to condition gates at the input of a static buffer, then an IOT pulse is generated to actuate the gates and transfer the static conditions into the buffer. In the case of our hypothetical process control system an IOT instruction can be developed to clear the accumulator, then read the content of the data buffer into the accumulator.

The entire sequence of operations described under Programmed Data Transfers is summarized in the following program example, using legitimate memory reference and operate instructions, and using artificial IOT instructions.



PROGRAM INTERRUPT

Urgent requirements for programmed data transfer or programmed control functions by peripheral equipment can be satisfied through use of the program interrupt facility. This facility allows an external device to cause the main computer program to be interrupted and a subroutine to be initiated to service the interrupting device. Use of this facility simplifies basic programming by eliminating the need for checking alarm conditions and allows the alarm conditions themselves to activate corrective operations, rather than waiting for cyclic checking by the main routine.

When the program interrupt feature is used address 0001 is automatically specified as the first address of a subroutine that checks and services the interrupt condition. Usually the instruction stored in this address is a jump to a location where the subroutine really begins. As designated in Chapter 4 of Section A of this handbook the program interrupt subroutine must locate the device causing the interruption, take some corrective action, restore or enable the program interrupt synchronization element of the computer by execution of an ION instruction, and return program control to the main program at

the point at which the interrupt occurred. If only one device is connected to the program interrupt facility no checking is required to locate the interrupting device. However, if many devices are connected to the program interrupt bus (as normally is the case) the interrupt subroutine must perform repeated skip instructions to test the condition of the various devices. This testing should be accomplished by a program-established priority system so that the devices which need servicing in the least amount of time or which require servicing most frequently are checked first, depending upon the application.

In our hypothetical process control system if the overtemperature alarms for each furnace are connected to the program interrupt bus the interrupt subroutine can skip on the condition of the overtemperature flag to a portion of the routine which deenergizes the appropriate furnace and performs any required operations in the control of the conveyor for that oven (such as inhibiting additional loading of the conveyor, removing products from the oven by high speed advance of the conveyor, or by initiating other shut down procedures). The sequence of testing for the furnace cause the temperature alarm can proceed from the first furnace to the last furnace if it is most important to prevent unfired products from entering the defective oven, can be performed from the last to the first furnace if over firing cannot occur, or can be performed in the sequence determined by the various furnace temperatures.

TELETYPE AND CONTROL

TELETYPE MODEL 33 ASR

The standard Teletype Model 33 ASR (automatic send-receive) can be used to type in or print out information at a rate of up to ten characters per second, or to read in or punch out perforated paper tape at a ten characters per second rate. Signals transferred between the 33 ASR and the control logic are standard serial, 11 unit code Teletype signals. The signals consist of marks and spaces which correspond to idle and bias current in the Teletype and to zeros and ones in the control and computer. The start mark and subsequent eight character bits are one unit of time duration and are followed by the stop mark which is two units.

The 8-bit code used by the Model 33 ASR Teletype unit is the American Standard Code for Information Interchange (ASCII) modified. To convert the ASCII code to Teletype code add 200 octal (ASCII + 200 $_8$ = Teletype). This code is read in the reverse of the normal octal form used in the PDP-8/S since bits are numbered from right to left, from 1 through 8, with bit 1 having the least significance. Therefore perforated tape is read:

The Model 33 ASR set can generate all assigned codes except 340 through 374 and 376. Generally codes 207, 212, 215, 240 through 337, and 377 are sufficient for Teletype operation. The Model 33 ASR set can detect all characters, but does not interpret all of the codes that it can generate as commands. The standard number of characters printed per line is 72. The sequence for proceeding to the next line is a carriage return followed by a line feed (as opposed to a line feed followed by a carriage return).

Appendix 2 lists the character code for the Teletype. Punched tape format is as follows:

	Tape Channel			
	87	654	S	321
Binary Code				
(Punch = 1)	10	110		100
Octal Code	2	6		4

TELETYPE CONTROL

Serial information read or written by the Teletype unit is assembled or disassembled by the control for parallel transfer to the accumulator of the processor. The control also provides the program flags which cause a program interrupt or an instruction skip based upon the availability of the Teletype and the processor as a function of the program.

In all programmed operation, the Teletype unit and control are considered as a Teletype in (TTI) as a source of input intelligence from the keyboard or the perforated-tape reader and is considered a Teletype out (TTO) for computer output information to be printed and/or punched on tape. Therefore, two device selectors are used; the select code of 03 initiates operations associated with the keyboard/reader, and the device selector, assigned the select code of 04, performs operations associated with the teleprinter/punch. Parallel input and output functions are performed by corresponding IOT pulses produced by the two device selectors. Pulses produced by IOP1 pulse trigger skip gates; pulses produced by the IOP2 pulse clear the control flags and/or the accumultor; and pulses produced by the IOP4 pulse initiate data transfers to or from the control.

KEYBOARD/READER

The keyboard and tape reader control contains an 8-bit buffer (TTI) which assembles and holds the code for the last character struck on the keyboard or read from the tape. Teletype characters from the keyboard/reader are received serially by the 8-bit shift register TTI. The character code of a Teletype character is loaded into the TTI so that spaces correspond with binary zeros and marks correspond to binary ones. Upon program command the content of the TTI is transferred in parallel to the accumulator. When a Teletype character starts to enter the TTI the control de-energizes a relay in the Teletype unit to release the tape feed latch. When released, the latch mechanism stops tape motion only when a complete character has been sensed, and before sensing of the next character is started. A keyboard flag is set to one, and causes a program interrupt when an 8-bit computer character has been assembled in the TTI from a Teletype character. The program senses the condition of this flag with a KSF microinstruction and issues a KRB microinstruction which clears the AC, clears the keyboard flag, transfers the content of the TTI into the AC, and enables advance of the tape feed mechanism. Instructions for use in supplying data to the computer from the Teletype are:

SKIP ON KEYBOARD FLAG (KSF)

Octal Code: 6031

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The keyboard flag is sensed, and If it contains a binary 1 the content of the PC

is incremented by one so that the next sequential instruction is skipped.

Symbol: If Keyboard Flag = 1, then PC + 1 = > PC

CLEAR KEYBOARD FLAG (KCC)

Octal Code: 6032

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: Both the AC and the keyboard flag are cleared in preparation for

transferring a Teletype character into the AC.

Symbol: 0 = AC

0 = > Keyboard Flag

READ KEYBOARD BUFFER STATIC (KRS)

Octal Code: 6034

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the TTI is transferred into bits 4 through 11 of the AC. This is

a static command in that neither the AC nor the keyboard flag is cleared.

Symbol: TT! V AC 4-11 = > AC 4-11

READ KEYBOARD BUFFER DYNAMIC (KRB)

Octal Code: 6036

Event Time: 2.3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The AC and the keyboard flag are both cleared, then the content of the TTI is transferred into bits 4 through 11 of the AC.

Symbol: 0 = AC, Keyboard Flag TTI V AC 4-11 = AC 4-11

A program sequence loop to read input information into the computer from the Teletype keyboard or tape reader can be written as follows:

LOOK, KSF /SKIP WHEN TTI IS FULL
JMP LOOK

KRB /READ ITI INTO AC

TELEPRINTER/PUNCH

Eight-bit computer characters from the accumulator are loaded in parallel into the 8-bit flip-flop shift register TTO for transmission to the Teletype unit. The control generates the start space, then shifts the eight character bits into the printer selector magnets of the Teletype unit, and then produces the stop mark. This transfer of information from the TTO into the Teletype unit is accomplished in a serial manner at the normal Teletype rate. A teleprinter flag in the teleprinter control is set when the last bit of the Teletype code has been sent to the teleprinter/punch, indicating that the TTO is ready to receive a new character from the AC. The flag is connected to both the program interrupt synchronization element and the PC control (instruction skip) element. Upon detecting the set (binary one) condition of the flag by means of the TSF microinstruction the program issues a TLS microinstruction which clears the flag and loads a new computer character into the TTO.

The instruction list for printing or punching is:

SKIP ON TELEPRINTER FLAG (TSF)

Octal Code: 6041

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The teleprinter flag is sensed, and if it contains a binary 1 the content of the PC is incremented by one so that the next sequential instruction is skipped.

Symbol: If Teleprinter Flag = 1, then PC + 1 = PC

CLEAR TELEPRINTER FLAG (TCF)

Octal Code: 6042

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The teleprinter flag is cleared to 0.

Symbol: 0 = >Teleprinter Flag

LOAD TELEPRINTER AND PRINT (TPC)

Octal Code: 6044

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The TTO is loaded from the content of bits 4 through 11 of the AC; then the Teletype character just loaded is selected, and punched and/or printed.

Symbol: AC 4-11 = > TTO

LOAD TELEPRINTER SEQUENCE (TLS)

Octal Code: 6046

Event Time: 2, 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The teleprinter flag is cleared; then a Teletype character code is transferred from the content of AC 4-11 into the TTO, the character is selected and punched and/or printed.

Symbol: 0 = > Teleprinter FlagAC 4-11 = > TTO

A program sequence loop to print and/or punch a character when the TTO is free can be written as follows:

FREE,	TSF	/SKIP WHEN FREE
	JMP FREE	
	TLS	/LOAD ITO, PRINT OR PUNCH

TELETYPE SYSTEM TYPE LT08

The Teletype facility of the basic computer can be expanded to accommodate several Model 33 or Model 35 Automatic Send Receive or Keyboard Send Receive units by addition of the Type LTO8 option. Each Teletype line added to the PDP-8/S system contains logic elements that are functionally identical to those of the basic Teletype control. Therefore, instructions and programming for each line of the LTO8 equipment are similar to those described previously for the basic Teletype unit. The following device select codes have been assigned for five lines of LTO8 equipment:

Line <u>Unit</u>	Select Codes	
1	40 and 41	
2	42 and 43	
3	44 and 45	
4	46 and 47	
5	11 and 12	

Instruction mnemonics for Teletype equipment in the LT08 system are not recognized by the program assembler (PAL III) and must be defined by the programmer. Mnemonic codes can be defined by the mnemonic code of the comparable basic Teletype microinstruction, suffixed with "LT" and the line number. For example, the following instructions can be defined for line 3:

Mnemonic	Octal	Operation
TSFLT3	6441	Skip if teleprinter 3 flag is a 1.
TCPLT3	6442	Clear teleprinter 3 flag.
TPCLT3	6444	Load teleprinter 3 buffer (TT03) from the content of AC4-11 and print and/or punch the character.
TLS£T3	6446	Load TT03 from the content of AC4-11, clear teleprinter 3 flag, and print and/or punch the character.
KSFLT3	6451	Skip if keyboard 3 flag is a 1.
KCC113	6452	Clear AC and clear keyboard 3 flag.
KRSLT3	6454	Read keyboard 3 buffer (TT13) static. The content of TT13 is loaded into AC4-11 by an OR transfer.
KRBLT3	6456	Clear the AC, clear keyboard 3 flag, and read the content of TT13 into AC4-11.

HIGH SPEED PERFORATED TAPE READER AND CONTROL TYPE PC02

This device senses 8-hole perforated paper or Mylar tape photoelectrically at 300 characters per second. The reader control requests reader movement, transfers data from the reader into the reader buffer (RB), and signals the computer when incoming data is present. Reader tape movement is started by a reader control request to simultaneously release the brake and engage the clutch. The 8-bit reader buffer sets the reader flag to 1 when it has been filled from the reader and transfers data into bits 4 through 11 of the accumulator under program control. The reader flag is connected to the computer program interrupt and instruction skip facilities, and is cleared by IOT pulses. Tape format is as described for the Teletype unit. Computer instructions for the reader are:

SKIP ON READER FLAG (RSF)

Octal Code: 6011

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The reader flag is sensed, and if it contains a binary 1 the content of the PC is incremented by one so that the next sequential instruction is skipped.

Symbol: If Reader Flag = 1, then PC + 1 = PC

READ READER BUFFER (RRB)

Octal Code: 6012

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the reader buffer is transferred into bits 4 through 11 of the AC and the reader flag is cleared. This command does not clear the AC.

Symbol: RB V AC 4-11 = >AC 4-11

0 = > Reader Flag

READER FETCH CHARACTER (RFC)

Octal Code: 6014

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The reader flag and the reader buffer are both cleared, one character is loaded into the reader buffer from tape, and the reader flag is set when this operation is completed.

Symbol: 0 = > Reader Flag, RB

Tape Data = >RB

1 = >Reader Flag when done

A program sequence loop to read a character from perforated tape can be written as follows:

RFC /FETCH CHARACTER FROM TAPE

LOOK, RSF /SKIP WHEN RB FULL

JWb FOOK

CLA

RRB /LOAD AC FROM RB

HIGH SPEED TAPE PUNCH CONTROL TYPE PC03

This option consists of a Royal McBee paper tape punch that perforates 8-hole tape at a rate of 50 characters per second. Information to be punched on a line of tape is loaded in an 8-bit punch buffer (PB) from AC bits 4 through 11. The punch flag becomes a 1 at the completion of punching action, signaling that new information may be transferred into the punch buffer, and punching initiated. The punch flag is connected to the computer program interrupt and instruction skip facility. Tape format is as described in Chapter 2. The punch instructions are:

SKIP ON PUNCH FLAG (PSF)

Octal Code: 6021

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The punch flag is sensed, and if it contains a binary 1 the content of the PC is incremented by one so that the next sequential instruction is skipped.

Symbol: If Punch Flag = 1, then PC + 1 = > PC

CLEAR PUNCH FLAG (PCF)

Octal Code: 6022

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: Both the punch flag and the punch buffer are cleared in preparation for receiving a new character from the computer.

Symbol: 0 = > Punch Flag, PB

LOAD PUNCH BUFFER AND PUNCH CHARACTER (PPC)

Octal Code: 6024

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: An 8-bit character is transferred from bits 4 through 11 of the AC into the punch buffer and then this character is punched. This command does not clear the punch flag or the punch buffer.

Symbol: AC4-11 V PB = > PB

LOAD PUNCH BUFFER SEQUENCE (PLS)

Octal Code: 6026

Event Time: 2, 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The punch flag and punch buffer are both cleared the contents of bits 4 through 11 of the AC is transferred into the punch buffer, the character in the PB is punched in tape, and the punch flag is set when the operation is completed.

Symbol: 0 =>Punch Flag, PB

AC4-11 =>PB

1 =>Punch Flag when done

A program sequence loop to punch a character when the punch buffer is "free" can be written as follows:

FREE, PSF /SKIP WHEN FREE

JMP FREE

PLS /LOAD PB FROM AC AND PUNCH

/CHARACTER

ANALOG-TO DIGITAL CONVERTER TYPE 138E AND MULTIPLEXER CONTROL TYPE 139E

The Type 138E/139E General-purpose Analog-to-Digital Converter and Multiplexer Control combines a versatile, multipurpose converter with a multiplexer to provide a fast, automatic, multichannel scanning and conversion capability. It is intended for use in systems in which computers sample and process analog data from sensors or other external signal sources at high rates. For example, analog data on each of 64 channels can be accepted and concerted into 12-bit digital numbers 415 times per second. Switching point accuracy in this instance is 99.975 per cent, with an additional quantization error of half the least significant bit (LSB). If less resolution and accuracy is required, all 64 channels can be scanned and the analog signals on them converted into 6-bit digital numbers 1,360 times each second.** Switching point accuracy in this case is 99.2 per cent, again with the the additional quantization error of half the digital value of the LSB.

The Type 139 Multiplexer Control can include from 1 to 32 series A100 Multiplexer modules determined by the user. Each module addresser one of two channels for maximum of 64 channels per Type 139E control. In the Individual Address mode, the Type 139 routes the data from any selected channel to the Type 138E converter imput. In the Sequential Address mode, the multiplexer advances its channel address by one each time it receives an increment command, returning to channel zero after scanning the last channel. Sequenced operations can be short-cycled when the number of channels in use is less than the maximum available.*

TABLE 1 ANALOG-TO-DIGITAL CONVERTER TYPE 138E CHARACTERISTICS

Word Length (in bits)	Switching Point Error*** (in percent)	Total Conversion Time (in microseconds)	Conversion Rate (in kc)
6	±1.6	9.0	110.0
7	±0.8	10.5	95.0
8	±0.4	12.0	83.0
9	±0.2	13.5	74.0
10	±0.1	1 <i>7</i> .0	58.5
11	±0.05	25.0	40.0
12	±0.025	35.0	28.5

^{***} $\pm \frac{1}{2}$ LSB for quantizing error.

The Type 138E is a successive approximation converter that measures a 0 to 10 volt analog input signal and provides a binary output indication of the amplitude of the input signal. Output indication accuracy is a function of the conversion time, and is determined by a switch on the front panel. Each of the seven positions of the rotary switch establishes an output word length, conversion accuracy, and conversion time for operation of the converter. Overall conversion error equals switching point error plus a quantization of \pm 1/2 the digital value of the LSB. Converter characteristics selected for each switch position are specified in Table 1.

^{*}Conversion rate = $[(35+2.5)(10^{-6})(64)]^{-1} = 415$ cycles/sec

^{**}Conversion rate = $[(9+2.5)(10^{-6})(64)]^{-1}$ = 1360 cycles/sec

CONVERTER SPECIFICATIONS

Monotonicity: Guaranteed for all settings

Aperture Time: Same as conversion time

Converter Recovery Time: None

Analog Imput: 0 to -10 volts is standard. Bipolar or specific amplitude range input can be accommodated on special request. If a different voltage range is desired, it is recommended that an amplifier be used at the source, since this will also provide a low driving impedance and reduce the possibilities of noise pickup between the source and the converter.

Input Loading: \pm 1 microampere and 125 picofarads for the standard 0 to -10 volt input.

Digital Output: A signed 6 to 12-bit binary number in 2's complement notation. A 0 volt input yields a digital output number of 4000_8 ; a=5 volt input produces 0000_8 ; and a=10 volt input gives an output of 3777_8 .

Controls: Binary readout indicators and a seven-position rotary switch for selecting converter characteristics are provided on the front panel.

The Type 139E Multiplexer Control is intended for use with the Type 138E or Type 189 analog-to-digital conversion system in applications where the PDP-8/S must process sampled analog data from multiple sources at high speeds. Under program control the multiplexer can select from 2 to 64 analog input signal channels for connection to the input of an analog-to-digital converter. Channel selection is provided by Type A100, A101, A102, or A103 Multiplex Switch FLIP CHIP modules. These module types each have slightly different timing, impedance, and power characteristics so that multiplexers can be built for wide differences in application by selecting the appropriate module type. Each module contains two independent, floating, transistor switches letting the user select any multiple of two channels to a maximum of 64. In the individual address mode, the Type 139E routes the analog data from any program-selected channel to the converter input. In the sequential address mode, the multiplexer advances the channel address by one each time it receives an incrementing command, returning to channel zero after scanning the last channel. Sequenced operations can be short-cycled when the number of channels in use is less than the maximum available.

A 6-bit channel address register (CAR) specifies a channel number from 0-778. A channel address may be chosen in one of two ways. It can be specified by the content of bits 6-11 of the AC or by incrementing the content of the CAR.

MULTIPLEXER SPECIFICATIONS

Indicators: Six binary indicators on the front panel give visual indication of the selected channel.

Multiplexer Switching Time: The time required to switch from one channel to any program-specified channel, or to select the next adjacent channel when the content of the CAR is incremented is 2.5 microseconds. This time is measured from when either a select or increment command is received.

Both the converter and multiplexer circuits are constructed entirely of FLIP CHIP modules. Both the Type 138E converter and the Type 139E Multiplex Control (implemented to 24 input channels) circuits can be contained in one standard 64-connector module mounting panel.

The following IOT commands have been assigned to the Type 138E/139E converter system:

SKIP ON A-D FLAG (ADSF)

Octal Code: 6531

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The A-D converter flag is sensed, and if it contains a binary 1 (indicating that the conversion is complete) the content of the PC is incremented by one so that the next instruction is skipped.

Symbol: If A-D Flag = 1, then PC + 1 = >PC

CONVERT ANALOG VOLTAGE TO DIGITAL VALUE (ADCV)

Octal Code: 6532

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The A-D converter flag is cleared, the analog input voltage is converted to a digital value, and then the A-D converter flag is set to 1. The number of binary bits in the digital-value word and the accuracy of the word is determined by the preset switch position.

Symbol: 0 = A-D Flag at start of conversion, then 1 = A-D Flag when conversion is done.

READ A-D CONVERTER BUFFER (ADRB)

Octal Code: 6534

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The converted number contained in the converter buffer (ADCB) is transferred into the AC as a normalized word (shifted into the most significant bits), unused bits of the AC are cleared, and the A-D converter flag is cleared.

Symbol: ADCB = > AC 0 = > A-D Converter Flag

CLEAR MULTIPLEXER CHANNEL (ADCC)

Octal Code: 6541

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The channel address register (CAR) of the multiplexer is cleared in preparation for setting of a new channel.

Symbol: 0 = > CAR

SET MULTIPLEXER CHANNEL (ADSC)

Octal Code: 6542

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The channel address register of the multiplexer is set to the channel specified by bits 6 through 11 of the AC. A maximum of 64 single-ended or 32 differential input channels can be used.

Symbol: AC 6-11 = > CAR

INCREMENT MULTIPLEXER CHANNEL (ADIC)

Octal Code: 6544

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the channel address register of the multiplexer is incremented by one. If the maximum address is contained in the register when this command is given, the minimum address (00) is selected.

Symbol: CAR + 1 = > CAR

A program to cycle through all channels of the converter a given number of times, storing the conversion values at successive core memory locations can be written as follows:

LOOP,	ADIC	/INCREMENT CAR
	ADCV	/INITIATE CONVERSION
	ADSF	/NEEDED FOR CONVERSION
	JMP1	/TIMES GREATER THAN
		/28,5 us
	ADRB	/READ A-D CONVERTER BUFFER
	DCA Z 10	/STORE RESULT IN ADDRESS SPECIFIED
		/BY AUTO-INDEX REGISTER 10
	ISZ CNTR	/INCREMENT CYCLE COUNTER
	JMP LOOP	/REPEAT CYCLE
		/END OF LOOP

Execution of this program loop takes 278 microseconds.

DIGITAL-TO-ANALOG CONVERTER TYPE AA01A

The general purpose Digital-to-Analog Converter Type AAO1A converts 12-bit binary computer output numbers to analog voltages. The basic option consists of three channels, each containing a 12-bit digital buffer register and a digital-to-analog converter (DAC). Digital input to all three registers is provided, in common, by one 12-bit input channel which receives bussed output connections from the PDP-8/S accumulator. Appropriate precision voltage reference supplies are provided for the converters.

One IOT microinstruction simultaneously selects a channel and transfers a digital number into the selected register. Each converter operates continuously on the content of the associated register to provide an analog output voltage.

Type AA01A options can be specified in a wide range of basic configurations: e.g., with from one to three channels, with or without output operational amplifiers, and with internally or externally supplied reference voltages. Configurations with double buffer registers in each channel are also available.

Each single-buffer channel of the equipment is operated by a single IOT command. Select codes of 55, 56, and 57 are assigned to the AAO1A, making it possible to operate nine single-buffered channels or various configurations of double-buffered channels. A typical instruction for the AAO1A is:

LOAD DIGITAL-TO-ANALOG CONVERTER 1 (DAL1)

Octal Code: 6551

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the accumulator is loaded into the digital buffer register of channel 1.

Symbol: AC = > DAC1

The analog output voltage of a standard converter is from ground to -9.9976 volts (other voltages are available in equipment containing output operational amplifiers). All binary input numbers are assumed to be 12 bits in length with negative numbers represented in 2's complement notation. An input of 4000, yields an output of ground potential; an input of 0000_8 yields an output of -5 volts; and an input of 1777_8 yields an output of -10 volts minus the analog value of the least significant digital bit. Output accuracy is $\pm 0.0125\%$ of full scale and resolution is 0.025% of full scale value. Response time, measured directly at the converter output, is 3 microseconds for a full-scale step change to 1 least significant bit accuracy. Maximum buffer register loading rate is 2 megacycles.

INCREMENTAL PLOTTER AND CONTROL TYPE 350B

Two models of California Computer Products Digital Incremental Recorder can be operated from a DEC Type 350 Increment Plotter Control. Characteristics of the four recorders are:

	Step		Paper
CCP	Size	Speed	Width
Model	(inches)	(steps/minute)	(inches)
563	0.01 or 0.005	12,000	31
565	0.01 or 0.005	18,000	12

The principles of operation are the same for the two models of Digital Incremental Recorders. Bidirectional rotary step motors are employed for both the X and Y axes. Recording is produced by movement of a pen relative to the surface of the graph paper, with each instruction causing an incremental step. X-axis deflection is produced by motion of the drum; Y-axis deflection, by motion of the pen carriage. Instructions are used to raise and lower the pen from the surface of the paper. Each incremental step can be in any one of eight directions through appropriate combinations of the X and Y axis instructions. All recording (discrete points, continuous curves, or symbols) is accomplished by the incremental stepping action of the paper drum and pen carriage. Front panel controls permit single-step or continuous-step manual operation of the drum and carriage, and manual control of the pen solenoid. The recorder and control are connected to the computer program interrupt and instruction skip facility.

Instructions for the recorder and control are:

SKIP ON PLOTTER FLAG (PLSF)

Octal Code: 6501

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instructions

Operation: The plotter flag is sensed, and if it contains a 1 the content of the PC is

incremented by one so the next sequential instruction is skipped.

Symbol: If plotter Flag = 1, then PC + 1 = > PC

CLEAR PLOTTER FLAG (PLCF)

Octal Code: 6502

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter flag is cleared in preparation for issuing a plotter operation

command.

Symbol: 0 = > Plotter Flag

PEN UP (PLPU)

Octal Code: 6504

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter pen is raised from the surface of the paper.

Symbol: None

PEN RIGHT (PLPR)

Octal Code: 6511

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter pen is move to the right in either the raised or lower position.

Symbol: None

DRUM UP (PLDU)

Octal Code: 6512

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter paper drum is moved upward. This command can be combined

with the PLPR and PLDD commands.

Symbol: None

DRUM DOWN (PLDD)

Octal Code: 6514

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter paper drum is moved downward.

Symbol: None

PEN LEFT (PLPL)

Octal Code: 6521

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter pen is moved to the left in either the raised or lowered position.

Symbol: None

DRUM UP (PLUD)

Octal Code: 6522

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter paper drum is moved upward. This commod is similar to

command 6512 except that it can be combined with the PLPL or PLPD commands.

Symbol: None

PEN DOWN (PLPD)

Octal Code: 6524

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The plotter pen is lowered to the surface of the paper.

Symbol: None

Program sequence must assume that the pen location is known at the start of a routine since there is no means of specifying an absolute pen location in an incremental plotter. Pen location can be preset by the manual controls on the recorder. During a subroutine, the PDP-8/S can track the location of the pen on the paper by counting the instructions that increment position of the pen and the drum.

CARD READER AND CONTROL TYPE CR01C

The Card Reader and Control Type CR01C reads standard 12-row, 80-column punched cards at a maximum rate of 100 cards per minute. Cards are read by column, beginning with column 1. One select instruction starts the card moving past the read station. Once a card is in motion, all 80 columns are read. Data in a card column is sensed by mechanical star wheels which close an electrical contact when a hole (binary 1) is detected. Column information is read in one of two program selected modes: alphanumeric and binary. In the alphanumeric mode the 12 information bits in one column are automatically decoded and transferred into the least significant half of the accumulator as a 6-bit Hollerith code. Appendix 2 lists the Hollerith card codes. In the binary mode the 12 bits of a column are transferred directly into the accumulator so that the top row (12) is transferred into ACO and the bottom row (9) is transferred into AC11. A punched hole is interpreted as a binary 1 and no hole is interpreted as a binary 0.

Three program flags indicate card reader conditions to the computer. The data ready flag rises and requests a program interrupt when a column of information is ready to be transferred into the AC. A read alphanumeric or read binary command must be issued within 1.5 milliseconds after the data ready flag rises to prevent data loss. The card done flag rises and requests a program interrupt when the card leaves the read station. A new select command must be issued within 25 milliseconds after the card done flag rises to keep the reader operating at maximum speed. Sensing of this flag can eliminate the need for counting columns, or combined with column counting can provide a check for data loss. The reader-not-ready flag can be sensed by a skip command to provide indication of card reader power off, no card in the read station, or that a reader failure has been detected. When this flag is raised the reader cannot be selected and select commands are ignored. The reader-not-ready flag is not connected to the program interrupt facility and cannot be cleared under program control. Manual intervention is required to clear the reader-not-ready flag. Instructions for the CRO1C are:

SKIP ON DATA READY (RCSF)

Octal Code: 6631

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the data ready flag is sensed, and if it contains a 1 (indicating that information for one card column is ready to be read) the content of the PC is incremented by one so the next sequential instruction is skipped.

Symbol: If Data Ready Flag = 1, then PC + 1 = > PC

READ ALPHANUMERIC (RCRA)

Octal Code: 6632

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The 6-bit Hollerith code for the 12 bits of a card column are transferred

into bits 6 through 11 of the AC, and the data ready flag is cleared.

Symbol: AC6-11 V Hollerith Code \Rightarrow > AC6-11 $0 \Rightarrow$ > Data Ready Flag

READ BINARY (RCRB)

Octal Code: 6634

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instructions

Operation: The 12-bit binary code for a card column is transferred directly into the AC, and the data ready flag is cleared. Information from the card column is transferred into the AC so that card row 12 enters ACO, row 11 enters AC1, row 0 enters AC2,... and row 9 enters AC 11.

Symbol: AC V Binary Code = > AC

O = > Data Ready Flag

SKIP ON CARD DONE FLAG (RCSP)

Octal Code: 6671

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the card done flag is sensed, and if it contains a 1 (indicating that the card has passed the read station) the content of the PC is incremented to skip the next sequential instruction.

Symbol: If Card Done Flag = 1, then PC + 1 = > PC

SELECT CARD READER AND SKIP IF READY (RCSE)

Octal Code: 6672

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the reader-not-ready flag is sensed and if it contains a 1 (indicating that the card reader is ready for programmed operation) the PC is incremented to skip the next sequential instruction; a card is started towards the read station from the feed hopper; and the card done flag is cleared. If the reader-not-ready flag contains a 0 (indicating power is off or no card is in the read station) card selection (motion) does not occur and the skip does not occur.

Symbol: If Reader-Not-Ready Flag = 1, then PC + 1 = > PC

0 = > Card Done Flag

CLEAR CARD DONE FLAG (RCRD)

Octal Code: 6674

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The card done flag is cleared. This command allows a program to stop

reading at any point in a card deck.

Symbol: 0 = > Card Done Flag

A logical instruction sequence to read cards is:

START, RCSE /START CARD MOTION AND SKIP IF READY
JMP NOT RDY /JUMP TO SUBROUTINE THAT TYPES OUT

/"CARD READER MANUAL INTERVENTION

/REQUIRED" OR HALTS

NEXT,

RCSF

/DATA READY?

JUMP .-1

/NO, KEEP WAITING

RCRA or RCRB /YES, READ ONE CHARACTER OR ONE

/COLUMN

DCAISTR

/STORE DATA

RCSD

/END OF CARD?

JMP NEXT

/NO, READ NEXT COLUMN

JMP OUT

YES, JUMP TO SUBROUTINE THAT CHECKS

/CARD COUNT OR REPEATS AT START FOR

/NEXT CARD

No validity or registration checking is performed by the CRO1C. A programmed validity check can be made by reading each card column in both the alphanumeric and the binary mode (within the 1.5 millisecond time limitation), then performing a comparison check.

Before commencing a card reading program energize the reader, load the feed hopper with cards, and manually feed the first card to the read station. The function of the manual controls and indicators are as follows (as they appear from the right to left on the card reader):

Function

ON/OFF switch

Controls the application of primary power to the reader. When power is applied, the reader is ready to respond to operation of the other keys or programmed commands.

AUTO/MAN switch

Controls card reading. In the manual position this switch disables the card feed mechanism so that cards must be manually placed on the read table and registered by pressing the REG key. In the automatic position card motion from the feed hopper through the read station is under

program control.

REG switch

When the AUTO/MAN switch is in the AUTO position the REG key is used to feed the first card to the read station. When the AUTO/MAN switch is in the MAN position the REG key is used to feed a card manually placed on the read table.

SKIP switch

This key is not connected on the CROIC and has no effect on equipment operation.

CHECK READER indicator

This lamp is not connected on the CROIC.

READY indicator

Lights when the reader is energized and cards are present in the feed hopper. The plastic card cover should always be used on top of a deck of cards to assure that the ready switch and indicator are activated.

CARD RELEASE pushbutton

When pressed, this pushbutton (adjacent to the read station) releases a card already in the read station.

58

CARD READER AND CONTROL TYPE 451

The Card Reader and Control Type 451A operates at a rate of 200 cards per minute. Cards are read column by column. Column information is read in either alphanumeric or binary mode. The alphanumeric mode converts the 12-bit Hollerith code of one column into the 6-bit binary coded decimal code with code validity checking. The binary mode reads a 12-bit column directly into the PDP-8/S.

The control of the card reader differs from the control of other input devices, in that the timing of the read in sequence is dictated by the device. When the command to fetch a card is given, the card reader reads all 80 columns of information in sequence. To read a column, the program must respond to a flag set as each new column is started. The instruction to read the column must come within 2.2 msec of the flag at 200 cards per minute. The commands for the card reader are:

SKIP ON CARD READER FLAG (CRSF)

Octal Code: 6632

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instructions

Operation: The content of the card reader flag is sensed, and if it contains a 1 (indicating that a card column is present for reading) the content of the PC is incremented by one so that the next sequential instruction is skipped.

Symbol: If card reader flag = 1, then PC + 1 = > PC

READ CARD EQUIPMENT STATUS (CERS)

Octal Code: 6634

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instructions

Operation: The content of the card reader flag and status levels are transferred into the content of bits AC6 through AC9. The AC bit assignments are:

AC6 = Flag is set to 1 (the flag rises after reading each of the 80 rows).

AC7 = Card done.

AC6 = Not ready (covers not in place, power is off, START pushbutton has not been pressed, hopper is empty, stacker is empty, stacker is full, a card is jammed, a validity check error has been detected, or the read circuit is defective).

AC9 = End of the file (EOF) (hopper is empty and operator has pushed EOF pushbutton0.

Symbol: Status = > AC6-9

READ CARD READER BUFFER (CRRB)

Octal Code: 6671

Event Time: 1

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the card column buffer (CCB) is transferred into the AC and the card reader flag is cleared. One CRRB command reads either alphanumeric or binary information.

Symbol: CCB = > AC

SELECT ALPHANUMERIC (CRSA)

Octal Code: 6672

Event Time: 2

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The card reader alphanumeric mode is selected and a card is started moving past the read heads. Information read into the CCB is in 6-bit alphanumeric form (the Hollerith code representing the decoded 12 row character in one column).

Symbol: None

SELECT BINARY (CRSB)

Octal Code: 6674

Event Time: 3

Indicators: IOT, FETCH, EXECUTE, END

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The card reader alphanumeric mode is selected and a card is started moving past the read heads. Information read into the CCB is in 12-bit binary form.

Symbol: None

Upon instruction to read the card reader buffer, the content of the 12-bit CCB is transferred into the AC. In the alphanumeric mode a 6-bit Hollerith code is transferred into AC6 through AC11 and AC0 through AC5 are cleared. In the binary mode the binary content of the 12 bits (or rows) in a card column are transferred into the AC so that row X is read into AC0, row Y into AC1, row 0 into AC2... and row 9 into AC11. The mode is specified by either the CRSA or CRSB command and can be changed while the card is being read.

AUTOMATIC LINE PRINTER AND CONTROL TYPE 645

The line printer can print 300 lines of 120 characters per minute. Each character is selected from a set of 64 available, by a 6-bit binary code (Appendix 2 lists the ASCII character specified for each code). Each 6-bit code is loaded separately into a core storage printing buffer (LPB) from bits 6 through 11 of the AC. The LPB is divided into two 120-character sections. To load one section of the LPB requires 120 load instructions. A print command causes the characters specified by the last loaded section of the LPB to be printed on one line. As printing of one section of the LPB is in progress, the other section can be reloaded. After the last character in a line is printed, the section of the LPB from which characters were just printed is cleared automatically. The section of the LPB that is loaded and printed is alternated automatically within the printer and is not program specified.

The line printer can load characters into the LPB at a 10 µsec rate, clears one section of the LPB in 3 to 6 msec, and moves paper at the rate of one line every 18 msec. When transfer of one code into the LPB is completed, the line printer done flag rises to indicate that the printer is ready to receive another code. When printing of the last character of a section of the LPB is completed, the line printer done flag rises and causes a program interrupt to request reloading of that section of the LPB. A line printer error flag rises and causes a program interrupt if the line printer detects an inoperative condition (printer power off, control circuits not reset, paper supply low, etc.).

A 3-bit format register (FR) in the printer is loaded from bits 9 through 11 of the AC during a print command. This register selects one of eight channels of a perforated tape in the printer to control spacing of the paper. The tape moves in synchronism with the paper until a hole is sensed in the selected channel to halt paper advance. A recommended tape has the following characteristics:

FR Code (Octal)	Paper Spacing	Tape Track
0	1 line	2
1	2 lines	3
2	3 lines	4
3	6 lines (1/4 page)	5
4	11 lines (1/2 page)	6
5	22 lines (3/4 page)	7
6	33 lines (line feed)	8
7	top of form	1

The IOT microinstructions which command the line printer are:

SKIP ON LINE PRINTER ERROR (LSE)

Octal Code: 6651

Event Time: 1

Indicators: IOT, FETCH, EXECUTE

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of line printer error flag is sensed, and if it contains a binary 1, indicating that an error has been detected, the content of the PC is incremented by one so that the next sequential instruction is skipped.

Symbol: If line printer error flag = 1, then PC + 1 = PC

CLEAR PRINTER BUFFER (LCB)

Octal Code: 6652

Event Time: 2

Indicators: IOT, FETCH, EXECUTE

Execution Time: 38 microseconds

Parity Test: instruction

Operation: Both sections of the line printer buffer are cleared in preparation for

receiving new character information.

Symbol: 0 = > LPB

LOAD PRINTER BUFFER (LLB)

Octal Code: 6654

Event Time: 3

Indicators: IOT, FETCH, EXECUTE

Execution Time: 38 microseconds

Parity Test: instruction

Operation: A section of the printer buffer is loaded from the content of bits 6 through 11 of the AC, then the AC is cleared.

Symbol: AC6 - 11 = > LPB, then 0 = > AC

SKIP ON LINE PRINTER DONE FLAG (LSD)

Octal Code: 6661

Event Time: 1

Indicators: IOT, FETCH, EXECUTE

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The content of the line printer done flag is sensed and if it contains a binary 1 the content of the PC is incremented by one so that the next sequential instruction is skipped.

Symbol: If line printer done flag = 1, then PC + 1 => PC

CLEAR LINE PRINTER FLAGS (LCF)

Octal Code: 6662

Event Time: 2

Indicators: IOT, FETCH, EXECUTE

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The line printer done and error flags are cleared.

Symbol: 0 => Line printer done flag 0 => Line printer error flag

CLEAR FORMAT REGISTER (LPR)

Octal Code: 6654

Event Time: 3

Indicators: 10T, FETCH, EXECUTE

Execution Time: 38 microseconds

Parity Test: instruction

Operation: The line printer format register (FR) is cleared then loaded from the content of bits 9 through 11 of the AC, and the AC is cleared. The line contained in the section of the printer buffer (LPB) loaded last is printed. Paper is advanced in accordance with the selected channel of the format tape if the content of AC8 is a 1. If AC8 is a 0 paper advance is inhibited.

```
Symbol: 0 = > FR

AC9 - 11 = > FR

0 = > AC

The content of half of the LPB is printed.

If AC8 = 1, then advance paper according to format tape channel FR.
```

The following routine demonstrates the use of these commands in a sequence which prints an unspecified number of 120-character lines. This sequence assumes that the printer is not in operation, that the paper is manually positioned for the first line of print, and that one-character words are stored in sequential core memory locations beginning at 2000. The PRINT location starts the routine.

PRINT,	LCB	/INITIALIZE PRINTER BUFFER
	CLA	
	TAD LOC	/LOAD INITIAL CHARACTER ADDRESS
	DCA 10	STORE IN AUTO-INDEX REGISTER
LRPT,	TAD CNT	/INITIALIZE CHARACTER COUNTER
	DCA TEMP	
LOOP,	LDŞ	/WAIT UNTIL PRINTING BUFFER READY
	JMP LOOP	
	ĻCF	/CLEAR LINE PRINTER FLAG
	TAD 1 10	/LOAD AC FROM CURRENT CHARACTER
		/ADDRESS
	LLB	/LOAD PRINTING BUFFER
	ISZ TEMP	/TEST FOR 120 CHARACTERS LOADED
	JMP LOOP	
	TAD FRM	/LOAD SPACING CONTROL AND
	LPR	/PRINT A LINE
	JMP LRPT	JUMP TO PRINT ANOTHER LINE
LOC.	1 <i>777</i>	/INITIAL CHARACTER ADDRESS =1
CNT.	—170	/CHARACTER COUNTER = 120 DECIMAL
TEMP.	0	CURRENT CHARACTER ADDRESS
FRM,	10	SPACING CONTROL AND FORMAT

CHAPTER 16

STANDARD PDP-8/S OPERATION

CONTROLS AND INDICATORS

Manual control of the PDP-8/S is exercised by means of keys and switches on the operator console. Visual indications of the machine status and the content of major registers and control flip-flops is also given on this console. Indicator lamps light to denote the presence of a binary 1 in specific register bits and in control flip-flops. The function of these controls and indicators is listed in Table 2, and their location is shown in Figure 7. The functions of all controls and indicators of the Model 33 ASR Teletype unit are described in Table 4, as they apply to operation of the computer. The Teletype console is shown in Figure 8.




Figure 7 PDP-8/S Operator Console

TABLE 2 OPERATOR CONSOLE CONTROLS AND INDICATORS

Control or Indicator	Function			
PANEL LOCK switch	With this key-operated switch turned clockwise, all keys and switches expect the SWITCH REGISTER switches on the operator console are disabled. In this condition the program can not be disturbed by inadvertent key operation. The program can, however, monitor the content of the SR by execution of the OSR instruction. With this switch turned counterclockwise all operator console keys and switches function normally.			

TABLE 2 OPERATOR CONSOLE CONTROLS AND INDICATORS (continued)

Control or Indicator	<u>Function</u>
POWER switch	In the counterclockwise position this key-operated switch removes primary power from the computer, and in the clockwise position it applies power.
START key	Starts the computer program by turning off the program interrupt circuits; clearing the AC, L, MB, and IR; setting the End state, transferring the content of the PC into the MA; and setting the RUN flip-flop requesting a memory cycle. Therefore, the word stored at the address currently held by the PC is taken as the first instruction.
LOAD ADDRESS key	Pressing this key sets the content of the SR into the AC, sets the RUN flip-flop for one cycle, transfers the content of AC into PC serially, sets the content of the INST FIELD switches into the IF, and sets the content of the DATA FIELD switches into the DF.
DEPOSIT key	Lifting this key sends the contents of PC to MA serially, and sets the content of the SR into the ACfrom where it is shifted into the MB during a single machine cycle, and a memory write request is initiated causing the data in MB to be stored at the current content of the MA. The content of the PC is then incremented by one, to allow storing of information in sequential memory addresses by repeated operation of the DEPOSIT key.
EXAMINÉ key	Pressing this key sends the contents of PC to MA serially and sets the content of core memory, at the address specified by the content of the MA, into the MB. The content of the PC is then incremented by one to allow examination of the content of sequential core memory addresses by repeated operation of the EXAMINE key.
CONTINUE key	Pressing this key sets the RUN flip-flop to continue the program in the state and instruction designated by the lighted console indicators, at the address currently specified by the PC.
STOP key	Causes the RUN flip-flop to be cleared at the end of the FETCH cycle in progress at the time the key is pressed.
SINGLE STEP switch	The switch is off in the down position. In the up position, the switch causes the RUN flip-flop to be cleared to disable the timing circuits at the end of one cycle of operation, i.e., the end of each major state. Thereafter, repeated operation of the CONTINUE key steps the program one major state at a time so that the content of registers can be observed in each state. (Note: The machine stops after memory cycles are completed.)
SINGLE INSTRUCTION switch	The switch is off in the up position. In the down position, the switch causes the RUN flip-flop to be cleared at the beginning of the next instruction execution. The computer will always appear to stay in the Fetch state with the MB containing the instruction to be executed. Repeated operation of the CONTINUE key steps the program one instruction at a time.

TABLE 2 OPERATOR CONSOLE CONTROLS AND INDICATORS (continued)

Control or Indicator	<u>Function</u>
SWITCH REGISTER switches	Provide a means of manually setting a 12-bit word into the machine. Switches in the down position correspond to binary zeros, up to ones. The content of this register is loaded into the PC by the LOAD ADDRESS key or into the MB and core memory by the DEPOSIT key. The content of the switch register can be set into the AC under program control of the OSR instruction.
DATA FIELD indicators and switches*	The indicators denote the content of the data field register (DF) and the switches serve as an extension of the SR to load the DF by means of the LOAD ADDRESS key. The DF determines the core memory field of data storage and retrieval.
INST FIELD indicators and switches*	The indicators denote the content of the instruction field register (IF) and the switches serve as an extension of the SR to load the IF by means of the LOAD ADDRESS key. The IF determines the core memory field from which instructions are to be taken.
PROGRAM COUNTER indicators	Indicate the content of the PC. When the machine is stopped, the content of the PC indicates the core memory address of the first instruction to be executed when the START key is operated. The instruction to be executed after the CONTINUE key is operated is currently sitting in the MB and PC indicates the next instruction to be executed.
MEMORY ADDRESS indicators	Indicate the content of the MA. Usually the content of the MA denotes the core memory address of the word currently or previously read or written. After operation of either the DEPOSIT or EXAMINE key, the content of the MA indicates the core memory address at which information was just written or read.
MEMORY BUFFER indicators	Indicate the content of the MB. Usually the content of the MB designates the word just read ar written at the core memory address held in the MA.
ACCUMULATOR indicators	Indicates the content of the AC.
LINK indicator	Indicates the content of the L.
Instruction indicators (AND, TAD, ISZ, DCA, JMS, JMP, IOT, OPR)	Indicate the decoded output of the IR as the instruction currently in progress.
FETCH, INDEX, DEFER, EXECUTE, END, and BREAK indicators	Indicate the primary control state of the machine and that the current processor cycle is a Fetch, Index, Defer, Execute, End or Break cycle, respectively.
ION indicator	Indicates the 1 status of the INT. ENABLE flip-flop. When lit, the program in progress can be interrupted by receipt of a Program Interrupt Request signal from an I/O device.
* Activated only on systems	containing the talence. For the Contract of

^{*} Activated only an systems containing the Memory Extension Control option.

TABLE 2 OPERATOR CONSOLE CONTROLS AND INDICATORS (continued)

Control or Indicator	<u>Function</u>		
PAUSE indicator	Indicates the 1 status of the PAUSE flip-flop when lit. A memory request sets the PAUSE flip-flop to inhibit advance of the processor timing generator. The PAUSE flip-flop is automatically reset by the memory when a memory cycle has been completed and the data has either been removed from the memory buffer for storing in memory or loaded from memory into the memory buffer.		
RUN indicator	Indicates the 1 status of the RUN flip-flop. When lit, the internal timing circuits are enabled and the machine performs instructions.		




Figure 8 Teletype Model 33 ASR Console

TABLE 3 TELETYPE CONTROLS AND INDICATORS

Control or Indicator	Function		
REL. pushbutton	Disengages the tape in the punch to allow tape removal or tape loading.		
B. SP. pushbutton	Backspaces the tape in the punch by one space, allowing manual correction or rub out of the character just punched.		
OFF and ON pushbuttons	Control use of the tape punch with operation of the Teletype keyboard/printer.		
START/STOP/FREE switch	Controls use of the tape reader with operation of the Teletype. In the lower FREE position the reader is disengaged and can be loaded or unloaded. In the center STOP position the reader mechanism is engaged but de-energized. In the upper START position the reader is engaged and operated under program control.		
Keyboard	Provides a means of printing on paper in use as a typewriter and punching tape when the punchON pushbutton is pressed, and provides a means of supplying input data to the computer when the LINE/OFF/LOCAL switch is in the LINE position.		

LINE/OFF/LOCAL switch

Controls application of primary power in the Teletype and controls data connection to the processor. In the LINE position the Teletype is energized and connected as an I/O device of the computer. In the QFF position the Teletype is de-energized. In the LOCAL position the Teletype is energized for off-line operation, and signal connections to the processor are broken. Both line and local use of the Teletype require that the computer be energized through the POWER switch.

OPERATING PROCEDURES

Many means are available for loading and unloading PDP-8/S information. The means used are, of course, dependent upon the form of the information, time limitations, and the peripheral equipment connected to the computer. The following procedures are basic to any use of the PDP-8/S, and although they may be used infrequently as the programming and use of the computer become more sophisticated, they are valuable in preparing the initial programs and learning the function of machine input and output transfers.

Manual Data Storage and Modification

Programs and data can be stored or modified manually by means of the facilities on the operator console. Chief use of manual data storage is made to load the readin mode loader program into the computer core memory. The readin mode (RIM) loader is a program used to automatically load programs into PDP-8/S from perforated tape in RIM format. This program and the RIM tape format are described in Appendix 6 of this handbook and in Digital Program Library descriptions. The RIM program listed in the Appendix can be used as an exercise in manual data storage. To store data manually in the PDP-8/S core memory:

- 1. Turn the PANEL LOCK switch counterclockwise and turn the POWER switch clockwise.
- 2. Set the bit switches of the SWITCH REGISTER (SR) to correspond with the address bits of the first word to be stored. Press the LOAD ADDRESS key and observe that the address set by the SR is held in the PC, as designated by lighted PROGRAM COUNTER indicators corresponding to switches in the 1 (up) position and unlighted indicators corresponding to switches in the 0 (down) position.
- 3. Set the SR to correspond with the data or instruction word to be stored at the address just set into the PC. Lift the DEPOSIT key and observe that the MB, and hence the core memory, hold the word set by the SR.

Also, observe that the PC has been incremented by one so that additional data can be stored at sequential addresses by repeated SR setting and DEPOSIT key operation.

To check the content of an address in core memory, set the address into the PC as in step 2, then press the EXAMINE key. The content of the address is then designed by the MEMORY BUFFER and ACCUMULATOR indicators. The content of the PC is incremented by one with operation of the EXAMINE key, so the content of sequential addresses can be examined by speated operation after the original (or starting) address is loaded. The content of any address can be modified by repeating both steps 2 and 3.

Loading Data Under Program Control

Information can be stored or modified in the computer automatically only by enacting programs previously stored in core memory. For example, having the RIM loader stored in core memory allows RIM format tapes to be loaded as follows:

- 1. Turn the PANEL LOCK switch counterclockwise and turn the POWER switch clockwise.
- 2. Set the Teletype LINE/OFF/LOCAL switch to the LINE position.
- 3. Load the tape in the Teletype reader by setting the START/STOP/FREE switch to the FREE position, releasing the cover guard by means of the latch at the right, loading the tape so that the sprocket wheel teeth engage the feed holes in the tape, closing the cover guard, and setting the switch to the STOP position. Tape is loaded in the back of the reader so that it moves toward the front as it is read. Proper positioning of the tape in the reader finds three bit positions being sensed to the left of the sprocket wheel and five bit positions being sensed to the sprocket wheel.
- 4. Load the starting address of the RIM loader program (not the address of the program to be loaded) into the PC by means of the SR and the LOAD ADDRESS key.
- 5. Press the computer START key and set the 3-position Teletype reader switch to the START position. The tape will be read automatically.

Automatic storing of the binary loader (BIN) program is performed by means of the RIM loader program as previously described. With the BIN loader stored in core memory, program tapes assembled in the program assembly language (PAL III) binary format can be stored as described in the previous procedure except that the starting address of the BIN loader (usually 7777) is used in step 4. When storing a program in this manner, the computer stops and the AC should contain all zeros if the program is stored properly. If the computer stops with a number other than zero in the AC, a checksum error has been detected. When the program has been stored, it can be initiated by loading the program starting address (usually designated on the leader of the tape) into the PC by means of the SR and LOAD ADDRESS key, then pressing the START key.

Off-Line Teletype Operation

The Teletype can be used separately from the PDP-8/S for typing, punching tape, or duplicating tapes. To use the Teletype in this manner:

- 1. Assure that the computer PANEL LOCK switch is turned counterclockwise and turn the POWER switch clockwise.
- 2. Set the Teletype LINE/OFF/LOCAL switch to the LOCAL position.
- 3. If the punch is to be used, load it by raising the cover, manually feeding the tape from the top of the roll into the guide at the back of the punch, advancing the tape through the

punch by manually turning the friction wheel, and then closing the cover. Energize the punch by pressing the ON pushbutton, and produce about two feet of leader. The leader-trailer can be code 200 or 377. To produce the code 200 leader, simultaneously press and hold the CTRL and SHIFT keys with the left hand; press and hold the REPT key; press and release the @ key. When the required amount of leader has been punched release all keys. To produce the 377 code, simultaneously press and hold both the REPT and RUB OUT keys until a sufficient amount of leader has been punched.

If an incorrect key is struck while punching a tape, the tape can be corrected as follows; if the error is noticed after typing and punching N characters, press the punch B. SP. (backspace) pushbutton N+1 times and strike the keyboard RUB OUT key N+1 times. Then continue typing and punching with the character which was in error.

To duplicate and obtain a listing of an existing tape: Perform the procedure under the current heading. Then load the tape to be duplicated as described in step 2 of the procedure under Loading Data Under Program Control, Initiate tape duplication by setting the reader START/STOP/FREE switch in the START position. The punch and teleprinter stop when the tape being duplicated is completely read.

Corrections to insert or delete information on a perforated tape can be made by duplicating the correct portion of the tape, and manually punching additional information or inhibiting punching of information to be deleted. This is accomplished by duplicating the tape and carefully observing the information being typed as the tape is read. In this manner the reader START/STOP/FREE switch can be set to the STOP position just before the point of the correction is typed. Information to be inserted can then be punched manually by means of the keyboard. Information can be deleted by pressing the punch OFF pushbutton and operating the reader until the portion of the tape to be deleted has been typed. It may be necessary to backspace and rub out one or two characters on the new tape if the reader is not stopped precisely on time. The number of characters to be rubbed out can be determined exactly by the typed copy. Be sure to count spaces when counting typed characters. Continue duplicating the tape in the normal manner after making the corrections.

New, duplicated, or corrected perforated tapes should be verified by reading them off line and carefully proofreading the typed copy.

CHAPTER 17

PDP-8/S INPUT/OUTPUT FACILITIES

Since the processing power of a computer system depends largely upon the range and number of peripheral devices that can be connected to it, the PDP-8/S has been designed to interface readily with a broad variety of external equipment.

The simple I/O techniques of the PDP-8/S, the availability of DEC's FLIP CHIP logic circuit modules, and DEC's policy of giving assistance wherever possible allow inexpensive, straight-forward device interfaces to be realized. Should questions arise relative to the computer interface characteristics, the design of device interfaces using DEC modules, or installation planning, customers are invited to telephone the main plant in Maynard, Massachusetts, or any of the sales offices. Digital Equipment Corporation makes no representation that the interconnection of its circuit modules in the manner described herein will not infringe on existing or future patent rights. Nor do the descriptions contained herein imply the granting of license to use, manufacture, or sell equipment constructed in accordance therewith.

The basic PDP-8/S contains a processor and core memory composed of FLIP CHIP circuit modules. These hybrid silicon circuits have an operating temperature range exceeding the limits of 32° to 130°F, so no air-conditioning is required at the computer site. Standard 115v. 60-cps power operates an internal solid-state power supply that produces all required voltages and currents.

High-capacity, high-speed I/O capabilities of the PDP-8/S allow it to operate a variety of peripheral devices in addition to the standard Teletype keyboard/printer, tape reader, and tape punch. DEC options, consisting of an interface and normal data processing equipment, are available for connecting into the computer system. These options include card equipment, line printers, magnetic tape transports, magnetic drums, analog-to-digital converters, CRT displays, and digital plotters. The PDP-8/S system can also accept other types of instruments of hardware devices that have an appropriate interface. Up to 61 devices requiring three programmed command pulses, or up to 193 devices requiring one programmed command pulse can be connected to the computer.

Interfacing of any devices to the computer requires no modifications to the processor and can be achieved in the field.

LOGIC SYMBOLS

Figure 9 defines the symbols used in this handbook to express signals and digital logic circuits.




Figure 9 Logic Symbols




Figure 9 Logic Symbols (continued)

CHAPTER 18

PROGRAMMED DATA TRANSFERS

The majority of I/O transfers take place under control of the PDP-8/S program, taking advantage of control elements built into the computer. The maximum data transfer rate for programmed operations of 12-bit words is 6 kc when no status checking, end transfer check, etc., is done. This speed is well beyond the normal rate required for typical laboratory or process control instrumentation.

The PDP-8/S is a parallel-transfer machine that distributes and collects data in bytes of up to twelve bits. All programmed data transfers take place through the accumulator, the 12-bit arithmetic register of the computer. The computer program controls the loading of information into the accumulator (AC) for an output transfer, and for storing information in core memory from the AC for an input transfer. Output information in the AC is power amplified and supplied to the interface connectors for bussed connection to many peripheral devices. Then the program-selected device can sample these signal lines to strobe AC information into a control or information register. Input data arrives at the AC as pulses received at the interface connectors from bussed outputs of many devices. Gating circuits of the program-selected device produce these pulses. Command pulses generated by the device flow to the input/output skip facility (IOS) to sample the condition of I/O device flags. The IOS allows branching of the program based upon the condition or availability of peripheral equipment, effectively making programmed decisions to continue the current program or jump to another part of the program, such as a subroutine that services an I/O device.

The bussed system of input/output data transfers imposes the following requirements on peripheral equipment:

- a. The ability of each device to sample the select code generated by the computer during IOT instructions and, when selected, to be capable of producing sequential IOT command pulses in accordance with computer-generated IOP pulses. Circuits which perform these functions in the peripheral device are called the device selector (DS).
- b. Each device receiving output data from the computer must contain gating circuits at the input of a receiving register capable of strobing the AC signal information into the register when triggered by a command pulse from the DS.
- c. Each device which supplies input data to the computer must contain gating circuits at the output of the transmitting register capable of sampling the information in the output register and supplying a pulse to the computer input bus when triggered by a command pulse from the DS.
- d. Each device should contain a busy/done flag (flip-flop) and gating circuits which can pulse the computer input/output skip bus upon command from the DS when the flag is set in the binary 1 state to indicate that the device is ready to transfer another byte of information.

Figure 10 shows the information flow within the computer which effects a programmed data transfer with input/output equipment. All instructions stored in core memory as a

program sequence are read into the memory buffer register (MB) for execution. The transfer of the operation code in the three most significant bits (bits 0, 1, and 2) of the instruction into the instruction register (IR) takes place and is decoded to produce appropriate control signals. The computer, upon recognition of the operation code as an IOT instruction, enters an 10 µsec WTX cycle and enables the IOP generator to produce time sequenced IOP pulses as determined by the three least significant bits of the instruction (bits 9, 10, and 11 in the MB). These IOP pulses and the buffered output of the select code from bits 3-8 of the instruction word in the MB are bussed to device selectors in all peripheral equipment. Figure 10 indicates the timing of programmed data transfers and Figure 11 shows the decoding of the IOT instruction.




Figure 10 Programmed Data Transfer Interface Block Diagram




Figure 11 Typical IOT Instruction Decoding

Devices which require immediate service from the computer program, or which take an exorbitant amount of computer time to discontinue the main program until transfer needs are met, can use the program interrupt (PI) facility. In this mode of operation, the computer can initiate operation of I/O equipment and continue the main program until the device requests servicing. A signal input to the PI requesting a program interrupt causes storing of the conditions of the main program and initiates a subroutine to service the device. At the conclusion of this subroutine, the main program is reinstated until another interrupt request occurs.

TIMING AND IOP GENERATOR

When the IR decoder detects an operation code of 68, it identifies an IOT instruction and initiates operation of the IOP generator. The logic circuits of the IOP generator are shown in Figure 12 to consist of three similar channels: each channel consisting of a gated delay, a gated pulse amplifier, and an output pulse amplifier. Operation of the first channel is triggered by BTO of WTX and operation of the other two channels is triggered by the pulse output of the delay in the previous channel. Series connection of the delays produces sequential operation of the three channels.




Figure 12 IOP Generator Logic

The gated pulse amplifier of each channel samples the content of one bit of the instruction when the delay output pulse occurs. If the sampled bit contains a binary 1, the gated pulse amplifier is triggered and the output pulse amplifier is operated to produce an IOP pulse. A diode-capacitor-diode (DCD) gate at the input of each gated pulse amplifier serves as a 2-input AND gate. The binary 1 status of one of the least significant bits of the instruction in the MB supplies the conditioning level of each of these gates. The output of the gated pulse amplifier initiates operation of the output amplifier to generate an IOP pulse which is available at the interface connector as a DEC standard 0.4 μ sec negative pulse. This configuration allows each IOP pulse to be individually programmed, permits a sequence of up to three events to occur within each instruction, and provides 1 μ sec between events for normal device circuit set-up times. The instruction bit that enables or disables generation of each IOP pulse, the corresponding number of the IOT pulse produced in the DS from the IOP pulse, and the event time for each IOP pulse is:

Instruction	IOP	IOT	Event
Bit	Pulse	Pulse	Time
11	IOP 1	101 1	1
10	IOP 2	IOT 2	2
9	IOP 4	IOT 4	3

DEVICE SELECTOR (DS)

Bits 3 through 8 of an IOT instruction serve as a device or subdevice select code. Bus drivers in the processor buffer both the binary 1 and 0 output signals of MB3-8 and distribute them to the interface connectors for bussed connection to all device selectors. Each DS is assigned a select code and is enabled only when the assigned code is present in the MB. When enabled, a DS regenerates IOP pulses as IOT command pulses and transmits these pulses to skip, input, or output gates within the device and/or to the processor to clear the AC.

Each group of three command pulses requires a separate DS channel (W103 module), and each DS channel requires a different select code (or I/O device address). One I/O device can, therefore, use several DS channels. Note that the processor produces the pulses identified as IOP 1, IOP 2, and IOP 4 and supplies them to all device selectors. The device selector produces pulses IOT 1, IOT 2, and IOT 4 which initiate a transfer or effect some control. Figure 13 shows generation of command pulses by several DC channels.




Figure 13 Generation Of IOT Command Pulses by Device Selectors

The logical representation for a typical channel of the DS, using channel 34, is shown in Figure 14. A 6-input NAND gate wired to receive the appropriate signal outputs from MB3-8 for select code 34 activates the channel. In the DS module, the NAND gate contains 14 diode input terminals; 12 of these connect to the complementary outputs of MB3-8, and 2 are open to receive subdevice or control condition signals as needed. Either the 1 or the 0 signal from each MB bit is disconnected by removing the appropriate diode from the NAND gate when establishing the select code. The ground level output of the NAND gate indicates when the IOT instruction selects the device, and can therefore enable circuit operations within the device. This output also enables three gating inverters, allowing them to trigger a pulse amplifier if an IOP pulse occurs. The positive output from each pulse amplifier is an IOT command pulse identified by the select code and the number of the initiating IOP pulse. Three inverters receive the positive IOT pulses to produce complementary IOT output pulses. A pulse amplifier module can be connected in each channel of the DS to provide greater output drive or to produce pulses of a specific duration required by the selected device.




Figure 14 Typical Device Selector (Device 34)

INPUT/OUTPUT SKIP (IOS)

Generation of an IOT pulse can be used to test the condition or status of a device flag, and to continue to or skip the next sequential instruction based upon the results of this test. This operation is performed by a 2-input AND gate in the device connected as shown in Figure 15. One input of the skip gate receives the status level (flag output signal), the second input receives an IOT pulse, and the output drives the computer IOS bus to ground when the skip conditions are fulfilled. When the IOS bus is driven to ground, the content of the program counter is incremented by 1 to advance the program count without executing the instruction at the current program count. In this manner an IOT instruction can check the status of an I/O device flag and skip the next instruction if the device requires servicing. Programmed testing in this manner allows the routine to jump out of sequence to a subroutine that services the device tested.




Figure 15 Use of IOS To Test The Status of an External Device

Assuming that a device is already operating, a possible program sequence to test its availability follows:

Address	Instruction	Remarks
•		
-		
100,	6342	/SKIP IF DEVICE 34 IS READY
101,	5100	/JUMP1
102,	5XXX	/ENTER SERVICE ROUTINE FOR /DEVICE 34

When the program reaches address 100, it executes an instruction skip with 6342. The skip occurs only if device 34 is ready when the IOT 6342 command is given. If device 34 is not ready, the flag signal disqualifies the skip gate, and the skip pulse does not occur. Therefore, the program continues to the next instruction which is a jump back to the skip instruction. In this example, the program stays in the waiting loop until the device is ready to transfer data, at which time the skip gate in the device is enabled and the skip pulse is sent to the computer IOS facility. When the skip occurs, the instruction in location 102 transfers program control to a subroutine to service device 34. This subroutine can load the AC with data and transfer it to device 34, or can load the AC from a register in device 34 and store it in some known core memory address.

ACCUMULATOR

The binary 1 output signal of each flip-flop of the AC, buffered by an inverter, is available at the interface connectors. These computer data output lines are bus connected to all peripheral equipment receiving programmed data output information from the PDP-8/S. A direct-set terminal on each flip-flop of the AC is connected to the interface connectors for bussing to all peripheral equipment supplying programmed data input to the PDP-8/S. A pulse that drives the direct-set terminal to ground causes setting of an AC flip-flop to the binary 1 state. Output and input connections to the accumulator appear in Figure 16.




Figure 16 Accumulator Input and Output

Figure 16 illustrates the twelve bits of the accumulator and the link bit. The status of the link bit is not available to enter into transfers with peripheral equipment (unless it is rotated into the AC). An inverting driver continuously buffers the output signal from each AC flip-flop. These buffered accumulator (BAC) signals are available at the interface connectors.

INPUT DATA TRANSFERS

When ready to transfer data into the PDP-8/S accumulator, the device sets a flag connected to the IOS. The program senses the ready status of the flag and issues an IOT instruction to read the content of the external device buffer register into the AC. If the AC is not cleared before the transfer, the resultant word in the AC is the inclusive OR of the previous word in the AC and the word transferred from the device buffer register.

The illustration in Figure 17 shows that the accumulator has an input bus for each bit flip-flop. Setting a 1 into a particular bit of the accumulator necessitates grounding of the interface input bus by the standard DEC inverter. In the illustration, the 2-input AND

gates set various bits of the accumulator. In this case an IOT pulse is AND combined with the flip-flop state of the external device to conditionally set 1's into the accumulator. (The program must include a clear AC command prior to loading in this manner; otherwise an inclusive OR takes place between the previous content of the accumulator and the content of the data register being read.)




Figure 17 Loading Data into the Accumulator from an External Device

Following the transfer (possibly in the same instruction) the program can issue a command pulse to initiate further operation of the device and/or clear the device flag.

OUTPUT DATA TRANSFERS

The AC is loaded with a word (e.g., by a CLA TAD instruction sequence); then the IOT instruction is issued to transfer the word into the control or data register of the device by an IOT pulse (e.g., IOP 2), and operation of the device is initiated by another IOT pulse (e.g., IOP 4). The data word transferred in this manner can be a character to be operated upon, or can be a control word sampled by a status register to establish a control mode.

Since the BAC interface bus lines continually represent the status of the AC flip-flops, the receiving device can strobe them to sense the value in the accumulator. In Figure 30 a strobe pulse samples six bits of the accumulator to conditionally set an external 6-bit data register. Since this is not a jam transfer, it is necessary first to clear the external data register before setting 1's into it. The readin gates driving the external data register are part of the external device and are not supplied by the computer. The data register can contain any number of flip-flops up to a maximum of twelve. (If more than twelve flip-

flops are involved, two or more transfers must take place.) Obviously the clear pulse and the strobe pulse shown in Figure 30 must occur when the data to be placed in the external data register is held in the accumulator. These pulses therefore must be under computer control to effect synchronization with the operation or program of the computer.




Figure 18 Loading a 6-Bit Word into an External Device from the Accumulator

Figure 19 illustrates the use of two of the pulses being gated by the device selected coded for "34." Pulse IOT 1 clears the data register and IOT 4 strobes the data from the accumulator into the data register. Note that the processor produces the IOP 1, IOP 2, and IOP 4 pulses and supplies them to all device selectors. The program-selected DS produces IOT 1, IOT 2, and IOT 4 pulses which initiate a transfer or effect some control. As indicated in Figure 19 this particular system adds two new microinstructions to the PDP-8/S repertoire. One generates a pulse to clear the data register of device number 34. The other microinstruction produces a pulse to load the data register of device number 34 with the content of the accumulator.




Figure 19 Use of a Device Selector for Activating and Controlling an External Device

PROGRAM INTERRUPT (PI)

When a large amount of computing is required, the program should initiate operation of an I/O device then continue the main program, rather than wait for the device to become ready to transfer data. The program interrupt facility, when enabled by the program, relieves the main program of the need for repeated flag checks by allowing the ready status of I/O device flags to automatically cause a program interrupt. When the program interrupt occurs, program control transfers to a subroutine that determines which device requested the interrupt and initiates an appropriate service routine.

In the example shown in Figure 20, a flag signal from a status flip-flop operates a standard inverter with no collector load. When the status flip-flop indicates the need for device service, the inverter drives the Program Interrupt Request bus to ground to request a program interrupt.




Figure 20 Program Interrupt Request Signal Origin

If only one device is connected to the PI facility, program control can be transferred directly to a routine that services the device when an interrupt occurs. This operation occurs as follows:

Tog	Address	Instruction	Remarks
	1000		/MAIN PROGRAM
	1001		/MAIN PROGRAM CONTINUES
	1002		/INTERRUPT REQUEST OCCURS
		INTERRUF	PT OCCURS
	0000		/PROGRAM COUNT (PC=1003) IS STORED IN 0000
	0001	JMP SR	/ENTER SERVICE ROUTINE
SR	2000		/SERVICE SUBROUTINE FOR INTERRUPTING
			/DEVICE AND SEQUENCE TO RESTORE
	3001	•	/AC, AND RESTORE LIF REQUIRED
	3002	ION	/TURN ON INTERRUPT
	3003	JMP I 0000	/RETURN TO MAIN PROGRAM
	1003		/MAIN PROGRAM CONTINUES
	1004		·

In most PDP-8/S systems numerous devices are connected to the PI facility, so the routine beginning in core memory address 0001 must determine which device requested an interrupt. The interrupt routine determines the device requiring service by checking the flags of all equipment connected to the PI and transfers program control to a service routine for the first device encountered that has its flag in the state required to request a program interrupt. In other words, when program interrupt requests can originate in numerous devices, each device flag connected to the PI must also be connected to the IOS.

MULTIPLE USE OF IOS AND PI

In common practice, more than one device is connected to the PI facility. Therefore, since the computer receives a request that is the inclusive OR of requests from all devices connected to the PI, the IOS must identify the device making the request. When a program interrupt occurs, a routine is entered from address 0001 to sequentially check the status of each flag connected to the PI and to transfer program control to an appropriate service routine for the device whose flag is requesting a program interrupt. Figure 21 shows IOS and PI connections for three typical devices.




Figure 21 Multiple Inputs to IOS and PI Facilities

The following program example illustrates how the program interrupt routine determines the device requesting service:

Tag	Address	Instruction	Remarks
	1000		/MAIN PROGRAM
	1001		/MAIN PROGRAM CONTINUES
	1002	•	/INTERRUPT REQUEST OCCURS
		INTERRUP	T OCCURS
	0000		/STORE PC (PC = 1003)
	0001	JMP FLG CK	/ENTER ROUTINE TO DETERMINE WHICH DEVICE
			/CAUSED INTERRUPT
FLG CK		IOT 6341	/SKIP IF DEVICE 34 IS REQUESTING
		SKP	/NO - TEST NEXT DEVICE
		JMP SR34	/ENTER SERVICE ROUTINE 34
		IOT 6441	/SKIP IF DEVICE 44 IS REQUESTING
		SKP	/NO - TEST NEXT DEVICE
		JMP SR44	/ENTER SERVICE ROUTINE 44
		IOT 6541	/SKIP IF DEVICE 54 IS REQUESTING
		SKP	/NO - TEST NEXT DEVICE
		JMP SR54	/ENTER SERVICE ROUTINE 54

Assume that the device that caused the interrupt is an input device (e.g., tape reader). The following example of a device service routine might apply:

Tag	Instruction	Remarks
SR	DAC TEMP IOT XX DAC I 10 ISZ COUNT SKP JMP END	/SAVE AC /TRANSFER DATA FROM DEVICE BUFFER TO AC /STORE IN MEMORY LIST /CHECK FOR END /NOT END /END. JUMP TO ROUTINE TO HANDLE END OF /LIST CONDITION
	TAD TEMP ION JMP I 0	/RESTORE L AND EPC IF REQUIRED /RELOAD AC /TURN ON INTERRUPT /RETURN TO PROGRAM

If the device that caused the interrupt was essentially an output device (receiving data from computer), the IOT—then—DAC I 10 sequence might be replaced by a TAD I 10—then—IOT sequence.

PDP-8/S PIN LOCATION LIST

(1	
NAME	FROM	PIN	MODULE TYPE/LOAD	Asser.
		A		
		В		
		С		
IC 9	АЗЈ	D	R001/8ma	>
IC 10	A3F	E	R001/8ma	 >
		F		
TC 11	A3D	Н	R001/8ma	D
		J		
SKP	A9K	К	R107/11ma	\rightarrow
		L		,
INT	A40E	М	R107/11ma	
		N		
CLA	Al9R	Р	R603	—⊳
		R		
		S		
		T		
		U		
		V		

r	·			
NAME	FROM	PIN	MODULE TYPE/LOAD	Asser.
		A		
		В		
		С		
IC θ	E3D	D	R001/8ma	⊳
IC 1	E3F	E	R001/8ma	—⊳
		F		
IC 2	E3J	н	R001/8ma	<u> </u>
		J		
IC 3	E3L	K	R001/8ma	>
		L		
IC 4	E3N	М	R001/8ma	—₽
		N		
IC 5	АЗТ	P	R001/8ma	─
		R		
IC 6	A3R	s	R001/8ma	<u></u>
IC 7	A3N	T	R001/8ma	- →
		ט		
IC 8	A3L	v	R001/8ma	- >

NAME	FROM	PIN	MODULE TYPE/LOAD	Asser.
		A		
		В		
		С		
BAC 0 (1)	D5F	D	R107/18ma	<u></u> →
BAC 1 (1)	D5J	E	R107/18ma	>
		F		
BAC 2 (1)	D5L	н	R107/18ma	>
		J		
BAC 3 (1)	D5N	К	R107/18ma	>
		I.		
BAC 4 (1)	D5R	М	R107/18ma	>
		N		
BAC 5 (1)	D5T	P	R107/18ma	>
		R		
BAC 6 (1)	C5F	s	R107/18ma	<u></u> →
BAC 7 (1)	C5J	т	R107/18ma	>
		Ū		
BAC 8 (1)	C5L	V	R107/18ma	>

NAME	FROM	PIN	MODULE TYPE/LOAD	Asser.
		А		
		В		
		C		
		D		
		E		
		F		
· · · · · · · · · · · · · · · · · · ·		H		
		J		
BMB 3 (1)	B37F	К	R107/18ma	
		L		
BMB 3 (0)	В37Л	М	R107/18ma	-
		N		
BMB 4 (1)	B37L	P	R107/18ma	-
		R		
BMB 4 (0)	B37N	s	R107/18ma	-
BMB 5 (1)	B37R	т	R107/18ma	-
		U		
BMB 5 (0)	в37т	v	R107/18ma	-



NAME	FROM	PIN	MODULE TYPE/LOAD	Asser.
		А		
		В		
		С		
BMB 6 (1)	Al7D	D	R107/18ma	-
BMB 6 (0)	Al7F	E	R107/18ma	-
		F		
BMB 7 (1)	Al7R	Н	R107/18ma	
		J		
BMB 7 (0)	C05T	K	R107/18ma	
		L		
BMB 8 (1)	A17T	М	R107/18ma	
		N		
BMB 8 (0)	C13L	P	R107/18ma	
		R		_
		s		
		T		
		U		
		V		

в39

NAME	FROM	PIN	MODULE TYPE/LOAD	Asser.
	=	A		
		В		
		С		
BAC 9 (1)	C5N	D	R107/18ma	>
BAC 10 (1)	C5R	E	R107/18ma	
		F		
BAC 11 (1)	C5D	H	R107/18ma	>
		J		
IOP 1	A40K	K	R107/18ma	_ >
		L		
IOP 2	A40L	М	R107/18ma	
		N		
IOP 4	A40N	P	R107/18ma	
		R		
		s		
		Т		
		ָּט		
B Power Clear	Al7L	V	R107/18ma	

CHAPTER 19 INSTALLATION PLANNING




Figure 23 PDP-8/S-Side View




Figure 23A PDP-8/5 Cabinet Model

POWER REQUIREMENTS

A source of 115v (\pm 17v), 60-cps (\pm 0.5 cps), single-phase power capable of supplying at least 10 amp must be provided to operate a standard PDP-8/S. To allow connection to the power cable of the computer, this source should be provided with a Hubbell 3-terminal, except for the basic table top PDP-8/S grounded-neutral flush receptable (or its equivalent). A table-mounted PDP-8/S is provided with a 15-amp power plug; a rack-mounted PDP-8/S has a 20 amp twist-lock plug; and systems that draw more than 20 amps use a 30-amp twist-lock plug.

APPENDIX 1 INSTRUCTIONS

MEMORY REFERENCE INSTRUCTIONS

		Direct	Addr.	Indirect Addr.	
Mnemonic Symbol	Operation Code	States Entered	Execution Time (µsec)	States Entered	Execution Time (µsec)
AND Y	0	F,X∧E	36	F,D,XAE	54
TAD Y	1	F,XAE	36	F,D,XAE	54
ISZ Y	2	F,X,E	54	F,D,X,E	72
DCA Y	3	F,X,E	46	F,D,X,E	64
Y SML	4	F,X,E	46	F,D,X,E	64
JMP Y	5	F,XAE	28	F,D,ΧΛΕ	46

BASIC IOT MICROINSTRUCTIONS

Mnemonic	Octal	Operation
		PROGRAM INTERRUPT
ION	6001	Turn interrupt on and enable the computer to respond to an interrupt request. When this instruction is given, the computer executes the next instruction, then enables the interrupt. The additional instruc- tion allows exit from the interrupt subroutine before allowing another interrupt to occur.
IOF	6002	Turn interrupt off i.e. disable the interrupt.
HIGH SPI	EED PERFORA	TED TAPE READER AND CONTROL TYPE PC02
RSF	6011	Skip if reader flag is a 1.
RRB	6012	Read the content of the reader buffer and clear the reader flag. (This instruction does not clear the AC.) RB V AC $4\cdot11 =>$ AC $4\cdot11$
RFC	6014	Clear reader flag and reader buffer, fetch one character from tape and load it into the reader buffer, and set the reader flag when done.
HIGH SP	EED PERFORA	ATED TAPE PUNCH AND CONTROL TYPE PC03
PSF PCF	6021	Skip if punch flag is a 1.
PPC	6022 6024	Clear punch flag and punch buffer. Load the punch buffer from bits 4 through I1 of the AC and punch the character. This instruction does not clear the punch flag or punch buffer.) AC 4-11 V PB => PB
PLS	6026	Clear the punch flag, clear the punch buffer, load the punch buffer from the content of bits 4 through 11 of the accumulator, punch the character, and set the punch flag to 1 when done.
	TELE	ETYPE KEYBOARD/READER
KSF	6031	Skip if keyboard flag is a 1.
KCC KRS	6032 6034	Clear AC and clear keyboard flag. Read keyboard buffer static. (This is a static comman in that neither the AC nor the keyboard flag is cleared.)
KRB	6036	TTI V AC $4\cdot11 = >$ AC $4\cdot11$ Clear AC, clear keyboard flag, and read the content of the keyboard buffer into the content of AC $4\cdot11$.

BASIC IOT MICROINSTRUCTIONS (continued)

Mnemonic	Octal	Operation			
TELETYPE TELEPRINTER/PUNCH					
TSF	6041	Skip if teleprinter flag is a 1.			
TCF	6042	Clear teleprinter flag.			
TPC	6044	Load the TTO from the content of AC 4-11 and			
		print and/or punch the character.			
TLS	6046	Load the TTO from the content of AC 4-11, clear the teleprinter flag, and print and /or punch the character.			
0		DISPLAY TYPE 34D AND PRECISION RT DISPLAY TYPE 30N			
DCX	6051	Clear X coordinate buffer.			
DXL	6053	Clear and load X coordinate buffer.			
DAL	0000	AC 2·11 -> XB			
DIX	6054	Intensify the point defined by the content of the X			
		and Y coordinate buffers.			
DXS	6057	Executes the combined functions of DXL followed by			
		DIX.			
DCY	6061	Clear Y coordinate buffer.			
DYL	6063	Clear and load Y coordinate buffer. AC $2.11 = > YB$			
DIY	6064	Intensify the point defined by the content of the X and Y coordinate buffers.			
DYS	6067	Executes the combined functions of DYL followed by DIY.			
	OSCII	LLOSCOPE DISPLAY TYPE 34D			
DSB	6075	Set minimum brightness.			
DSB	6076	Set medium brightness.			
DSB	6077	Set maximum brightness.			
		LIGHT PEN TYPE 370			
DSF	6071	Skip if display flag is a 1.			
DCF	6072	Clear the display flag.			
		MEMORY PARITY			
CMD	6101	Skip if memory parity error flag $= 0$.			
SMP	6101 6104	Clear memory parity error flag.			
CMP	0104	Olean memory parity error mag.			

BASIC IOT MICROINSTRUCTIONS (continued)

Mnemonic	Octal	Operation
	INCREMENTAL	PLOTTER AND CONTROL TYPE 350B
PLSF	6501	Skip if plotter flag is a 1.
PLCF	6502	Clear plotter flag.
PLPU	6504	Plotter pen up. Raise pen off of paper.
PLPR	6511	Plotter pen right.
PLDU	6512	Plotter drum (paper) upward.
PLDD	6514	Plotter drum (paper) downward.
PLPL	6521	Plotter pen left.
PLUD	6522	Plotter drum (paper) upward. (Same as 6512.)
PLPD	6524	Plotter pen down, Lower pen on to paper.
·	•	RPOSE CONVERTER TYPE 138E AND PLEXER CONTROL TYPE 139E
ADSF	6531	Skip if A/D converter flag is a 1.
ADCV	6532	Clear A/D converter flag and convert input voltage
		to a digital number, flag will set to 1 at end of conversion. Number of bits in converted number determined by switch setting, 11 bits maximum.
ADRB	6534	Read A/D converter buffer into AC, left justified, and clear flag.
ADCC	6541	Clear multiplexer channel address register.
ADSC	6542	Set up multiplexer channel as per AC 6-11. Maximum of 64 single ended or 32 differential input channels.
ADIC	6544	Index multiplexer channel address (present address + 1). Upon reaching address limit, increment will cause channel 00 to be selected.
	CARD R	EADER AND CONTROL TYPE CROIC
RCSF	6631	Skip if card reader data ready flag is a 1.
RCRA	6632	The alphanumeric code for the column is read into AC6-11, and the data ready flag is cleared.
RCRB	6634	The binary data in a card column is transferred into ACO-11, and the data ready flag is cleared.
RCSP	6671	Skip if card reader card done flag is a 1.
RCSE	6672	Clear the card done flag, select the card reader and
.,	. • . =	start card motion towards the read station, and skip if the reader-not-ready flag is a 1.
RCRD	6674	Clear card done flag.

GROUP 1 OPERATE MICROINSTRUCTIONS

Млетопіс Symbol	Octal Code	Operation
NOP	7000	No operation. Causes a 1.5 μsec program delay.
IAC	7001	Increment AC. The content of the AC is incremented by one in two's complement arithmetic.
RAL	7004	Rotate AC and L left. The content of the AC and the L are rotated left one place.
RTL	7006	Rotate two places to the left. Equivalent to two successive RAL operations.
RÁR	7010	Rotate AC and L right. The content of the AC and L are rotated right one place.
RTR	7012	Rotate two places to the right. Equivalent to two successive RAR operations.
CML	7020	Complement L.
CMA	7040	Complement AC. The content of the AC is set to the one's complement of its current content.
CIA	7041	Complement and increment accumulator. Used to form two's complement.
CLL	7100	Clear L.
CLL RAL	7104	Shift positive number one left.
CLL RTL	7106	Clear link, rotate two left.
CLL RAR	7110	Shift positive number one right.
CLL RTR	7112	Clear link, rotate two right.
STL	7120	Set link. The L is set to contain a binary 1.
CLA	7200	Clear AC. To be used alone or in OPR 1 combinations.
CLA IAC	7201	Set AC = 1
GLK	7204	Get link. Transfer L into AC 11.
CLA CLL	7300	Clear AC and L.
STA	7240	Set $AC = -1$. Each bit of the AC is set to contain a 1.

GROUP 2 OPERATE MICROINSTRUCTIONS

Mnemonic Symbol	Octal Code	Operation
HLT	7402	Halt. Stops the program after completion of the cycle in process. If this instruction is combined with others in the OPR 2 group the other operations are completed before the end of the cycle.
OSR	7404	OR with switch register. The OR function is performed between the content of the SR and the content of the AC, with the result left in the AC.
SKP	7410	Skip, unconditional. The next instruction is skipped.
SNL	7420	Skip if L ≠: 0.
SZL	7430	Skip if $L = 0$.
SZA	7440	Skip if $AC = 0$.
SNA	7450	Skip if AC \neq 0.
SZA SNL	7460	Skip if $AC = 0$, or $L = 1$, or both.
SNA SZL	747 0	Skip if $AC \neq 0$ and $L = 0$.
SMA	7500	Skip on minus AC. If the content of the AC is a negative number, the next instruction is skipped.
SPA	7510	Skip on positive AC. If the content of the AC is a positive number, the next instruction is skipped.
SMA SNL	7520	Skip if $AC < 0$, or $L = 1$, or both.
SPA SZL	7530	Skip if $AC > 0$ and if $L = 0$.
SMA SZA	7540	Skip if AC \geq 0.
SPA SNA	7550	Skip if $AC > 0$.
CLA	7600	Clear AC. To be used alone or in OPR 2 combina-
		tions.
LAS	7604	Load AC with SR.
SZA CLA	7640	Skip if AC = 0, then clear AC.
SNA CLA	7650	Skip if AC ≠ 0, then clear AC.
SMA CLA	7700	Skip if AC < 0, then clear AC.
SPA CLA	7710	Skip if $AC \ge 0$, then clear AC .

APPENDIX 2 CODES

MODEL 33 ASR/KSR TELETYPE CODE (ASCII) IN OCTAL FORM

Character	8-Bit Code (in octal)	Character	8-Bit Code (in octal)
А	301	<u>!</u>	241
В	302	11	242
С	303	#	243
Ð	304	\$	244
E	30	%	245
F	306	&	246
G	307	1	247
Н	310	(250
I	311)	251
J	312	*	252
K	313	+	253
L	314	,	254
М	315	_	255
N	316		256
0	317	/	257
P	320	:	272
Q	321	;	273
R	322	<	274
S	323	=	275
T	324	>	276
U	325	?	277
٧	326	@	300
W	327	[333
x	330	\	334
Υ	331	j	335
Z	332	A	336
		←	337
0	260		
1	261	Leader/Trailer	200
2	262	Line-Feed	212
3	263	Carriage-Return	215
4	264	Space	240
5	265	Rub-out	377
6	266	Blank	000
7	267		
8	270		
9	271		

MODEL 33 ASR/KSR TELETYPE CODE (ASCII)

IN BINARY FORM MOST SIGNIFICANT BIT LEAST SIGNIFICANT BIT 1 = HOLE PUNCHED = MARK 0 = NO HOLE PUNCHED = SPACE *8 7 6 5 4 \$ 3 2 1 SPACE NULL/IDLE 0 0 0 0 0 00 0 0 1 Α START OF MESSAGE ** olo 0 1 0 В END OF ADDRESS 00 0 1 1 С # END OF MESSAGE 0 1 0 0 0 D \$ END OF TRANSMISSION 0 0 1 0 1 WHO ARE YOU Ε % 0 1 1 0 0 F & ARE YOU 0 0 1 1 1 1 G BELL 0 1 0 0 Н FORMAT EFFECTOR 0 (0 1 0 0 HORIZONTAL TAB Τ) 0 1 0 * 0 1 J LINE FEED 0 1 0 1 1 Κ +**VERTICAL TAB** 0 1 1 0 0 FORM FEED L 0 1 0 1 1 CARRIAGE RETURN Μ 0 1 | 1 | SHIFT OUT 0 N 1 | 1 | 1 ٥ 0 SHIFT IN 1 1 0 0 0 1 ٥ Ρ 0 DCO 0 0 1 0 1 1 READER ON Q 0 1 0 TAPE (AUX ON) 1 0 2 R 1 0 0 1 1 S 3 READER OFF 1 0 0 (AUX OFF) 1 0 Т 4 1 0 1 0 1 U 5 ERROR 1 0 1 1 0 SYNCHRONOUS IDLE V. 6 1 0 1 | 1 | 1 7 LOGICAL END OF MEDIA W 1 1 ololo 8 S O Х 0 0 1 1 1 Υ 9 **S** 1 1 0 1 0 1 Z S 2 0 1 1 1 1 ſ : S 3 1 0 0 1 1 S 4 < 0 1 S 5 1 1 1] ... 1 1 1 0 S 6 >1 1 1 1 RUB OUT ? S 7 1 0 0 SAME 0 1 SAME 1 1 1 1 0 SAME SAME 1

CARD READER CODE

Card Code			Card Code		
Zone Num.	Internal Code	Character	Zone Num.	Internal Code	Character
	01 0000	Blank	11 0	10 1010	A
12 8.3	11 1011		11 1	10 0001	j
12 8-4	11 1100)	11 2	10 0010	К
12 8-5	11 1101]	11 3	10 0011	L
12 8-6	11 1110	<	11 4	10 0100	М
12 8-7	11 1111	+	11 5	10 0101	N
12 —	11 0000	+	11 6	10 0110	0
11 8-3	10 1011	\$	11 7	10 0111	Р
11 8.4	10 1100	*	11 8	10 1000	Q
11 8-5	10 1101	[11 9	10 1001	Ř
11 8-6	10 1110	>	0 8-2	01 1010	:
11 8-7	10 1111	&	0 2	01 0010	S
11 —	10 0000		0 3	01 0011	Т
0 1	01 0001	/	0 4	01 0100	U
0 8.3	01 1011		0 5	01 0101	V
0 8-4	01 1100	(0 6	01 0110	W
0 8.5	01 1101		0 7	01 0111	X
0 8-6	01 1110		0 8	01 1000	Υ
0 8.7	01 1111	%	0 9	01 1001	Z
— 8⋅3	00 1011	.=	- 0	00 1010	0
- 8-4	00 1100	(0	1	00 0001	1
8-5	00 1101	4	- 2	00 0010	2
<u> </u>	00 1110		- 3	00 0011	3
<u> </u>	00 1111	/	_ 4	00 0100	4
12 0	11 1010	?	– 5	00 0101	5
12 1	11 0001	Α	6	00 0110	6
12 2	11 0010	В	_ 7	00 0111	7
12 3	11 0011	C	8	00 1000	8
12 4	11 0100	D	_ 9	00 1001	9
12 5	11 0101	E	All other codes	00 0000	+
12 6	11 0110	F	·		· · · · · · · · · · · · · · · · · · ·
12 7	11 0111	G			
12 8	11 1000	Н			
12 9	11 1001	1			

AUTOMATIC LINE PRINTER CODE

Character (ASCII)	6-Bit Code (in octal)	Character (ASCII)	6-Bit Code (in octal)
@	0		40
A	1	!	41
В	2	"	42
С	3	#	43
D	4	\$	44
E	5	%	45
F	6	&	46
G	7	,	47
Н	10	(50
1	11)	51
J	12	*	52
К	13	+	53
L	14	1	54
M	15	_	55
N	16		56
0	17	/	57
P	20	ø	60
Q	21	1	61
R	22	2	62
S	23	3	63
Т	24	4	64
U	25	5	65
V	26	6	66
W	27	7	67
X	30	8	70
Υ	31	9	71
Z	32	:	72
[33	;	73
\	34	<	74
]	35	=	75
<u>*</u>	36	>	76
←	37	?	77

APPENDIX 3 SCALES OF NOTATION

2" IN DECIMAL

X	21	×	2*	x	2'
0.001	1.00069 33874 62581	0.01	1.00695 55500 56719	0.1	1.07177 34625 36293
0.002	1.00138 72557 11335	0.02	1.01395 94797 90029	0.2	1.14869 83549 97035
0.003	1.00208 16050 79633	0.03	1.02101 21257 07193	0.3	1.23114 44133 44916
0.004	1.00277 64359 01078	0.04	1.02811 38266 56067	0.4	1.31950 79107 72894
0.005	1.00347 17485 09503	0.05	1.03526 49238 41377	0.5	1.41421 35623 73095
0.006	1.00416 75432 38973	0.06	1.04246 57608 41121	0.5	1.51571 65665 10398
0.007	1.00486 38204 23785	0.07	1.04971 66836 23067	0.7	1.62450 47927 12471
0.008	1.00556 05803 98468	0.08	1.05701 80405 61380	0.8	1.74110 11265 92248
0.009	1.00625 78234 97782	0.09	1.06437 01824 53360	0.9	1.86606 59830 73615

101 IN OCTAL

10"		п		10"						10"				n			1	O-r			
		3	1.000 000 0.063 146 0.006 075 0.000 406 0.000 032	314 631 341 217 111 564	463 270 570	146 243 651	31 66 77	2	16 221	351 432 411	035 451 634	762 564 210 520 440	000	10 11 12 13 14.	0,000 0,000 0,000 0,000 0,000	000	000	000	537 043 003	657 136 411	77 32 35
3 641 46 113	200 400		0.000 002 0.000 000 0.000 000 0.000 000	206 157 015 327 001 257	364 745 143	055 152 561	37 75 06	434 432	157 127	115 413	760 542	500 200 400 000	000	15 16 17 18	0.000	000	000	000	000	001	63 14

n log₁₀ 2, n log₂ 10 IN DECIMAL

п	n log _{tå} 2	n log ₂ 10	n	n log ₁₀ 2	n log₂ 10
1	0.30102 99957	3.32192 80949	6	1.80617 99740	19.93156 85693
2	0.60205 99913	6.64385 61898	7	2.10720 99696	23.25349 66642
3	0.90308 99870	9.96578 42847	8	2.40823 99653	26.57542 47591
4	1.20411 99827	13.28771 23795	9	2.70926 99610	29.89735 28540
5	1.50514 99783	16.60964 04744	10	3.01029 99566	33.21928 09489

ADDITION AND MULTIPLICATION TABLES

Multiplication

Binary Scale

 $0 - 1 = \begin{matrix} 0 + 0 & 7 & 0 \\ 1 + 0 & 0 & 1 \\ 1 + 1 & -10 \end{matrix}$ $0 \times 1 = \begin{matrix} 0 \times 0 & 0 & 0 \\ 1 \times 0 & 0 & 1 \\ 1 \times 1 & -1 \end{matrix}$

Octal Scale

0	01	02	03	04	05	06	07	1	02	03	04	05	06	07
ī	02	03	04	05	06	07	10	2	04	06	10	12	14	16
2	03	04	05	06	07	10	11	3	06	11	14	17	22	25
3	04	05	06	07	10	11	12	4	10	14	20	24	30	34
4	05	06	07	10	11	12	13	5	12	17	24	31	36	43
5	06	07	10	11	12	13	14	6	14	22	30	36	44	52
6	07	10	11	12	13	14	15	7	16	25	34	43	52	61
7	10	11	12	13	14	15	16		•					

MATHEMATICAL CONSTANTS IN OCTAL SCALE

π =	3.11037	552421	e =	2.55760	521305 ₆	γ =	0.44742	147707 ₋₈
π ⁻¹ =	0.24276	301556	e-1 =	0.27426	5306614	In $\gamma = -$	0.43127	233602#
$\sqrt{\pi} =$	1.61337	611067 ₈	√e =	1.51411	230704.	$\log_2 \gamma = -$,0.62573	030645.
וח <i>יי</i> =	1.11206	404435	logo e =	0.33626	754251:	√2 ==	1.32404	746320,
l οg 1 π =	1.51544	163223,	log, e =	1.34252	166245,	In 2 =	0.54271	027760
√ 10 =	3.12305	407267	log: 10 =	3.24464	741136.	In 10 =	2.23273	067355.

APPENDIX 4 POWERS OF TWO

```
2 1.0 0.5 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75 5 0.75
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            2<sup>-n</sup>
                                                                                                                                                                                                                                                                                                                                                                                                                                                             n
```

APPENDIX 5 OCTAL-DECIMAL CONVERSION

OCTAL-DECIMAL INTEGER CONVERSION TABLE

OCD												[_			3	4	5	6	7
000 000 000 000 0000 0000 0000 0000 0000			0	1	2	3	4	_5 	6	7	_		0	1	2	<u> </u>	·			
Cotal Decimal Cotal Decimal Cotal Cotal Cotal Decimal Decimal Decimal Cotal Decimal De	0000 0000	0000	0000	0001	0002	0003	0004	0005	0006	0007		0400	0256	0257	D256	0259				
Cotal Checimal Checimal Checimal Checim					0010	1 1 600							4455	0077	0274	0275	0275	0277	0276	0279
Octal Decimal 0000 004 004 005 005 003 003 003 003 004 005 005 005 005 005 005 005 005 005	W											0430	220	D281	07 8 7	กวมส	0284	0285	0286	0287
Octal Decimal 10000 4096 004 0060 01005 007 0108 01092 0073 0044 0055 0105 0070 0108 01070 0108 01105 0109 01105 0109 01105 0109 01105 0109 01105 01105 0110 0110	(Octal) (Decimely	0030	0024	0025	0026		0028					0440	0200	0200	በማወቤ	0291 -	0232	0293	U294	05301
Comparison Com			0032	0041	ሰቡፋን	0043	0044	0045	0046	0047	- 1	0450	2005	0207	ለንዕጽ	ጠን ባር	nann -	0301	D302	U3U3
1000 - 4096 20000 - 1958 20000 - 1958 20000 - 1958 20000 - 2048 2010 - 1958 20000 - 2048 2010 - 1958 20000 - 2048 2010 - 1958	Octal Decimal		AA4B	0.040	0050	0051	0052	0053	0054	QQ55		0460	0304	0305	0306	0307	0308	0309	0310	0319
30000 122888	10000 - 4096		0056	0057	0058	0059	0060	0061	0062	0063	- 1	1	1							
\$\frac{40000}{60000} \cdot \frac{16384}{60000} \cdot \frac{2040}{2040} \cdot \frac{20073}{2070} \cdot \frac{2073}{2040} \cdo				****	2000	2067	0050	0060	0070	0071		0500	0320	0321	0322	0323	0324	0325	0326	0327
SOCIO 20480 O129		0110	LANTS.	0073	0074	1075	0076	ODT7 -	0048	00791		0510	0338	በሚያው	0330	0331	0332	0333	UJ34	0333.
Color Case	50000 - 20480	0120	0080	0061	0082	E800	0084	0085	0086	0087		0520	0336	0337	0338	0339	0340	0341	0346	0351
1000 O512 1000 O512 1000 O512 O110	60000 - 24576	0130	0088	0089	0090	0091	0092	0093	0094	ona 2 [0530	D157	ሰጓፍን	0354	0355	0356	0357	0328	0359
1000 0512 1000 0512 0710 0714 0715	70000 - 28672	0140	0096	0097	0098	0099	0100	0101	0102	0103			0.760	0381	በየጸን	0.763	0364	0365	0366	01011
0200 0128 0129 0120 0121 0122 0123 0124 0125		0150	0104	0105	0100	0115	0116	0103	0118	0119	ĺ		0368	0369	0370	037 L	0372	0373	03/4	03121
0200 0128 0129 0130 0131 0132 0133 0134 0135 0136 0137 0138 0139 0140 0141 0142 0142 0142 0142 0142 0142		0170	0120	0121	0122	0123	0124	0125	0126	0127	- 1	0570	0376	0377	0378	0379	0380	0381	0362	0363
0.000 0.012 0.134 0.134 0.134 0.134 0.145 0.14		1	l							l	.	0600	1867	กาสร	0386	0387	0388	0389	0390	0391
1000 O512 1000 O512 1000 O512 1000 O512 O510 O510 O512 O510		0200	0128	0129	0130	0131	0132	0133	0134	0135	l	0110	0.307	D393	0394	0305	0396	0397	0398	03994
1000 OS12 1000 OS12 OS13 OS15		0210	0136	0137	0138	0139	0140	0140	0150	0151		0600	nann.	DARI	0402	0403	0404	0405	0406	0407
1000 0512 1000 0512 0513 0514 0515		ineen!	lassa	0153	0154	0155	0156	0157	0158	0128	1	0630	nane.	በፈበባ	0410	0411	0412	0413	0414	Q410
1000 O512 1000 O512 1000 O512 O513 O514 O515 O517 O518 O517 O518 O517		0040	10165	0161	0162	N163	0164	0100	0100	0101	.	0640	0416	0417	0418	0419	0428	0429	0430	0431
1000 0512 1010 0512 0710		0.250	10168	ni ka	0170	0171	0172	0113	01/4	0119		Acen	0497	0433	0434	0435	D436	U4 3 (U4 JB	0413
1000 O512 1000 O512 1000 O512 O513 O514 O515			0176	0177	0178	0179	0180	0180	0196	0191		0670	0440	0441	0442	0443	0444	0445	0446	0447
1000		1											i							
1000 O512 1000 O512 O520		0000	0192	0193	0194	0195	0196	0197	0198	0199			0448	0449	0450	0431	0450	0461	0462	0463
1000 0512 1000 1000 0512 1000 0512 1000 0512 1000 0512 1000		0310	0200	0201	6262	0203	0204	0205	0206	0201	Ì	0230	DARA	DARS	0456	0467	0468	D469	0470	UNIL
1000 O512 1000 O512 1000 O512 O513 O514 O515			0208	0209	0210	0211	0212	0213	0211	0213]	0770	0477	0.473	0474	0475	N476	0477	0476	04.13
1000		10	D224	0225	カマツ糸	0227	0228	0229	0230	0231		0240	0490	0491	ハムミラ	0483	0484	0485	0486	1890
1000 O512 1000 O512 1000 O512 O520			0232	0233	0234	0235	0236	0237	02.30	0239		0750	0489	0489	0490	0491	0492	0493	0502	0503
1000 O512 1000 O512 1000 O512 O513 O514 O515 O516 O517 O518 O519 O519 O529 O529 O520 O522		0360	0240	0241	0242	0243	0244	0245	Q246	U24 r		0750	0504	0491	0506	0507	0508	0509	0510	0511
1000 0512 1000 0512 1000 0512 0513 0514 0515 0516 0517 0518 0519 0510 0517 0518 0519 0510 0519 05		0370	0248	0249	0250	0251	0252	0522	0254	0233	J	V110	1000-							
1000 0512 1000 0512 1000 0512 0513 0514 0515 0516 0517 0518 0519 1410 0776 0771 0772 0773 0774 0775 1777 1023 (Octal) (Decimal) 1020 0528 0522 0523 0524 0525 0526 0527 1410 0776 0771 0778 0778 0778 0778 0778 0778 0778 0778 0779 0780 0781 0782 0783 0784 0785 0786 0787 0786 0781 0782 0783 0784 0785 0786 0787 0786 0781 0782 0783 0784 0785 0786 0787 0786 0									6	7	1			1	2	3	4	5	6	7
100 100 0320 0522 0522 0522 0525 0526 0527 0521 1410 0776 0778 0786 0788 0788 0790 0791 1777 1778 0790 0791			<u> </u>								۱,	Γ				0271	0777	0773	0774	0775
to to 1777 1023 1020 0528 0529 0530 0531 0532 0533 0534 0535 0534 0535 0534 0535 0534 0535 0534 0535 0534 0535 0534 0535 0536 0537 0538 0539 0540 0541 0545		1000	0512	0513	0514	0515		0517	051B				4000	4777	4770	0.770	0.3 KU	DYMI	17/64	UIDOI
(Octal) (Decimal) (Octal) (Decimal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octal) (Octa		1010	0.630	0521	0522	0523	0524	0525	0534				1		0000	ハフロフ	0288	0789	0790	0791
1040			1 25 20	0627	6539	กราช	0540	D591	(1394	0543	1	1430	0792	0793	0794	11143	01/96	0.19.1	0120	0.00
1050 0552 0553 0554 0555 0565 0665	(Betal) ((Beenman)	1040																		
1070 0568 0569 0570 0571 0572 0573 0574 0575 0575 0576 0577 0578 0579 0580 0581 0582 0583 0584 0584 0585 0586 0587 0586 0589 0590 0591 05		1050									ŀ	1450	8080	A 2 1 7	กลาส	ORIS	0820	10021	0046	4020
1100		1060	0560	U561	0562	0563	0564	0500	0500	0575	ļ		0824	0825	0826	0827	0828	0829	0830	0831
1110			•										1 -							
1110 0584 0585 0586 0587 0586 0597 0596 0597 0596 0599 0599 0599 0599 0599 0599 0599		1100	0576	0577	0578	0519	0580	0591	0582	0583	ļ		0832	0833	0834	0835	0836	0837	0830 0846	0847
1130 0600 0601 0602 0803 0804 0605 0611 0612 0613 0614 0615 1140 0608 0609 0610 0611 0612 0613 0614 0615 1150 0824 0825 0826 0827 0828 0829 0830 0831 1160 0824 0825 0826 0827 0828 0829 0830 0831 1170 0832 0833 0834 0835 0836 0837 0838 0839 0834 0835 0836 0837 0838 0839 0834 0835 0836 0837 0838 0839 0834 0835 0839 0839 0830 0831 1170 0832 0833 0834 0835 0839 0839 0839 0830 0831 1170 0832 0833 0834 0835 0839 0839 0839 0830 0831 0832 0833 0834 0835 0839 0839 0839 0830 0831 0832 0833 0834 0835 0839 0839 0839 0830 0831 0832 0833 0834 0835 0839 0839 0839 0839 0830 0830 0830 0830		1 3 1 3 4	าไสรดง	1 กรสด	0.586	0587	0586	0209	0530	0397		1 4800	10010	ORAD	ORSO	0851	0602	0000	0004	0855
1140 0508 0609 0610 0611 0612 0613 0614 0615 1500 0823 0836 0887 0878 0879 1150 0816 0617 0618 0619 0620 0621 0822 0823 0834 0835 0836 0887 1150 0824 0825 0836 0837 0838 0839 0890 0891 0892 0893 0894 0895 0896 0897 0898 0899 0891 0892 0893 0894 0895 0896 0897 0898 08999 08999 08999 08999 08999 08999 08999 08999 08999 08999 08999 08999		1120	0593	0593	0594	0595	0595	0605	0606	0607		1 4 6 6 6	AOE A	A957	กลรส	0859	11860	נסטט ו	U074	0.004
1150 0515 0617 0618 0619 0620 0621 0622 0623 0624 0625 0626 0627 0638 0639 0630 0631 1560 0688 0688 0889 0890 0891 0892 0893 0894 0895 0896 0897 0898 0899 0891 0892 0893 0894 0895 0896 0897 0898 0899 0891 0892 0893 0894 0895 0896 0897 0898 0899 08			0 0601) 0609 1 0609	0610	0611	0612	0613	0614	0615	1		noos	A965	DRES	0.067	11866	2050	UO (U	0871
1170 0632 0631 0834 0635 0636 0637 0638 0639 1570 0888 0889 0890 0891 0892 0893 0894 0893 1695 0893 1895 0895 0895 0895 0895 0895 0895 0895 0			A LABIJ	8 0617	nala	0619	0620	0621	0622	0623	H	1550	0872	0873	0874	0875 0891	0870	ORAS	0886	0887
1200 0540 0641 0842 0543 0644 0645 0646 0647 1600 0896 0897 0898 0899 0900 0901 0902 0903 1210 0648 0649 0650 0651 0652 0653 0654 0655 0650 0651 0652 0653 0654 0655 0666 0665 0666		116	0 06Ż-	0625	0626	0527	0628	0629	0630	0631		1560	0880	OSE	0890	0891	0892	0893	0894	0895
1210 0548 0549 0550 0551 0552 0553 0554 0555 0565		117	-								1	1	1							
1210 0648 0849 0850 0851 0852 0863 0864 0865 0866 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868 0867 0868		120	0.064	064	0642	064	0644	0645	0646	0647	·	1600	0896	0897	0098	0899	0900	0901	0902	0903
1230 0664 0665 0666 0687 0688 0687 0670 0671 0670 0671 1630 0920 0921 0922 0923 0924 0925 0933 0934 0935 1240 0872 0673 0674 0675 0676 0675 0676 0675 0678 0679 1650 0936 0937 0938 0939 0930 0934 0935 1260 0688 0684 0685 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0687 0686 0887 0886 0887			പിനമേ	R 0841	9 0650	0651	0653	2 0653	1 10034	0035	1	1	10019	7619	വരിക	. 0915	. (1911-6	0917	0.010	03.12
1240 0372 0873 0674 0675 0876 0877 0678 0679 0678 0679 1660 0937 0938 0939 0940 0941 0942 0943 1250 0685 0681 0682 0683 0684 0685 0686 0687 0689 0690 0691 0692 0693 0694 0695 0694 0695 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697 0696 0697			0 065	6 065	7 0658	0659	0660) ()665) ()663				11636	A LABOR	0921	0922	01123	0924	L USZ) UMZT	03.51
1250 0680 0681 0682 0683 0684 0685 0684 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0685 0885			0 066	9 UGG 2 OB7	3 D674	057	0870	6 0877	06/6	0679	}	1 4 4 4 4	. [^^0	0.070	0070	ודיםח	174.12		09.51	0833
1260 0588 0689 0590 0591 0592 0593 0594 0593 0594 0595 0586 0987 0958 0959		125	n i osa	068	1 0683	2 068	3 0684	4 0683	0000	0687	1	1064	A I AG SA	10037	กรรถ	0939	1 0940) USA I	U9-12	
1300 0704 0705 0706 0707 0708 0709 0710 0711 1700 0960 0961 0962 0963 0964 0965 0966 0967 0971 0972 0973 0974 0975 0976 0971 0972 0973 0974 0975 0976 0976 0977 0978 0979 0976 0976 0977 0978 0979 0978 0979		126	0 068	a nee	0.00	0.69	1 069:	2 069;	069			1660) U944 O952	0945	0954	0955	0956	0957	0958	0959
1310 0712 0718 0714 0715 0716 0717 0718 0719 1710 0966 0960 0970 0971 0972 0973 0974 0975 1310 0712 0720 0721 0722 0723 0724 0725 0726 0727 1720 0976 0977 0978 0979 0980 0981 0982 0983 1320 0728 0729 0730 0731 0732 0733 0734 0745 0745 0745 0747 0748 0749 0750 0751 1730 0984 0985 0986 0987 0988 0980 0990 0991 1340 0736 0737 0738 0739 0740 0741 0742 0743 1740 0992 0993 0994 0995 0998 0997 0998 0999 1350 0744 0745 0746 0747 0748 0749 0750 0751 1750 0750 0750 0750 0750 0750		127	0 069									10"	- 1							
1310 0712 0713 0714 0715 0715 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0717 0718 0718 0717 0718		1,20	o 070	4 070	5 070	6 070	7 070	8 0709	0710	071	ιl			0961	0962	0963	0984	0965	0966	0967
1320 0720 0721 0722 0723 0724 0725 0723 0724 0725		1555	-		- 441	4 651	E 0.71	6 671	7 MIL	s orts	9	171	0 0966	: 0969 : 0077	0970	, V971 1 0479	09/2	. USTO	09/1	
1300 0728 0729 0730 0731 0742 0742 0743 1740 0992 0993 0994 0995 0996 0997 0998 0998 0997		132	0 072	0 072	1 077	7 1177	3 1172		J V!#		• 1	173	0 0984	1 0985	0986	0997	0986	0989	0990	0981
1350 0744 0745 0746 0747 0748 0749 0750 0751 1750 1000 1001 1002 1003 1004 1005 1005		133	072	6 077	9 0/3 17 071	0 013 8 073	9 074	0 074	1 074	2 074	3	174	0 0992	0993	0994	0995	0990	0997		
1360 0752 0753 0754 0755 0755 0755 0757 1770 1016 1017 1018 1019 1020 1021 1022 1023		1:	بممامه	4 074	6 074	E 674	7 074	B 074	075	0 075	1 i	175	0 11000	1001	1002	100	1004	1005		
1370 0760 0761 0762 0163 0164 0163 0164 0163		136	50 075					6 075	7 075 5 070	8 075 8 078	7	177	0 1001 0 1011	8 1011	1019	1011	1020	102		
		13	10 971	0 07E	1 076	3 010	2 016	- 010	J 010	<u> </u>	<u>ا</u>	ننت								

OCTAL-DECIMAL INTEGER CONVERSION TABLE: (continued)

	0	1	2	3	4	5	6	7		0	1	2	3	4	5	6	7]
2000	1024	1075	1026	1000			1030		9464	-	100		 -				1505	1
			1034						2400	1280	1281	1200	1283	1284	1285	1286	1207	2000 10
			1042							1295						1302		to t
			1050															2777 15
			1058							1304								(Octal) (Deci
			1066							1320								
			1074							1328								
			1082							1336								
.010	1000	1001	INOL	1003	1004	1000	1000	1001	2410	1,330	1331	1 220	1223	1340	1341	1342	1343	Octal Decim
100	1088	1089	1090	1091	1092	1003	1004	1005	7500	1344	1245	1246	1247	1240	1946	1250	1261	10000 - 409
110	1096	1097	1098	1099	1100	1101	1102	1103		1352								20000 - 819
120			1106															30000 - 1228
			1114							1360								
			1122															
			1130							1376								
130	1126	1127	1138	1131	1140	1133	1193	1143		1384								70000 - 2867
100	1130	1145	1146	1139	1140	1141	1142	1193		1392								
יטוני	3144	1145	1140	1141	1140	1149	1150	1121	2570	1400	1401	1402	1403	1404	1405	1406	1407	
200	1150	1159	1154	1156	1156	1157	1169		2000									
										1408								
			1162							1416								
220	1170	1103	1170	1170	1100	1113	1100	1113		1424								
230	110	1100	1178	1119	1100	1100	1102	1103		1432								
240	1102	1100	1186	1187	1198	1199	1190	119[1440								
			1194							1448								
			1202						2560	1456	1457	1458	1459	1460	1461	1462	1463	
210	1208	1209	1210	1211	1212	1213	1214	1215	2670	1464	1465	1466	1467	1458	1469	1470	1471	!
200	1216	1317		1016						!								
200	1210	1217	1218	1219	1220	1221	1222	1223		1472								
			1226							:1480								į
			1234						2720	1498	1489	1490	1491	1492	1493	1494	1495	1
			1242						2730	1496	1497	1498	1499	1500	1501	1502	1503	1
			1250						2740	1504	1505	1506	1507	1508	1509	1510	1511	1
			1258						2750	1512	1513	1514	1515	1516	1517	1518	1519]
360 [1254	1265	1266	1267	1268	1269	1270	1271	2760	1520	1521	1522	1523	1524	1525	1526	1527	i
																		ť
2370	1272	1273	1274	1275	1276	1277	1278	1279	2770	1528	1529	1530	1531	1532	1533	1534	1535	ĺ
2370	1272	1273	1274	1275	1276	1277	1276	1279	2770	1528	1529	1530	1531	1532	1533	1534	1535	
370	1272	1273	2	3	1276	1277	1278	1279	2770	1528 a	1529	1530	1531	1532	1533	1534	1535	
370	0	1	2	3	4	5	6	7	2770	1528 0	1529	1530 2	1531	1532	1533	6	7	
370	0	1		3	4	5	6	7	3400	1528 0 1792	1529 I 1793	1530 2 1794	1531 3 1795	1532 4 1796	1533 5 1797	6	7 1799	8000 155
370 000 010	0 1536 1544	1 1537 1545	2 1538 1546	3 1539 1547	1540 1548	5 1541 1549	6 1542 1550	7 1543 1551	3400 3410	0 1792 1800	1529 1 1793 1801	2 1794 1802	3 1795 1803	1532 4 1796 1804	1533 5 1797 1805	6 1798 1806	7 1799 1807	3000 153
000 010	0 1536 1544 1552	1 1537 1545 1553	2 1538 1546 1554	3 1539 1547 1555	4 1540 1548 1556	5 1541 1549 1557	6 1542 1550 1558	7 1543 1551 1559	3400 3410	0 1792 1800	1529 1 1793 1801	2 1794 1802	3 1795 1803	1532 4 1796 1804	1533 5 1797 1805	6 1798 1806	7 1799 1807	to to
370 000 010 020	0 1536 1544 1552	1 1537 1545 1553	2 1538 1546	3 1539 1547 1555	4 1540 1548 1556	5 1541 1549 1557	6 1542 1550 1558	7 1543 1551 1559	3400 3410 3420 3430	0 1792 1800 1808 1816	1529 1 1793 1801 1809 1817	1530 2 1794 1802 1810 1818	3 1795 1803 1811 1819	1532 4 1796 1804 1812 1820	1533 5 1797 1805 1813	6 1798 1806 1814	7 1799 1807 1815 1823	to to 3777 204
370 000 010 020	0 1536 1544 1552 1560	1 1537 1545 1553 1561	2 1538 1546 1554 1562	3 1539 1547 1555 1563	4 1540 1548 1556 1564	5 1541 1549 1557 1565	6 1542 1550 1558 1566	7 1543 1551 1559 1567	3400 3410 3420 3430 3440	0 1792 1800 1808 1816 1824	1529 1 1793 1801 1809 1817 1825	1530 2 1794 1802 1810 1818 1826	3 1795 1803 1811 1819 1827	1532 4 1796 1804 1812 1820 1828	1533 5 1797 1805 1813 1821 1829	6 1798 1806 1814 1822 1830	1535 7 1799 1807 1815 1823 1831	to to
370 3000 3010 3020 3030 3040	0 1536 1544 1552 1560 1568	1 1537 1545 1553 1561 1569	2 1538 1546 1554	3 1539 1547 1555 1563 1571	4 540 548 556 564 572	5 1541 1549 1557 1565 1573	6 1542 1550 1558 1566 1574	7 1543 1551 1559 1567 1575	3400 3410 3420 3430 3440 3450	1528 0 1792 1800 1808 1816 1824 1832	1529 1 1793 1801 1809 1817 1825 1833	1530 2 1794 1802 1810 1818 1826 1834	3 1795 1803 1811 1819 1827 1835	1532 4 1796 1804 1812 1820 1828 1836	1533 5 1797 1805 1813 1821 1829 1837	6 1798 1806 1814 1822 1830 1838	7 1799 1807 1815 1823 1831 1839	to to 3777 204
370 3000 3010 3020 3030 3040 3050	0 1536 1544 1552 1560 1568 1576	1 1537 1545 1553 1561 1569 1577	2 1538 1546 1554 1562 1570	3 1539 1547 1555 1563 1571 1579	4 540 548 556 564 1572 1580	5 1541 1549 1557 1565 1573 1581	6 1542 1550 1558 1566 1574 1582	7 1543 1551 1567 1567 1575 1583	3400 3410 3420 3430 3440 3450	1528 0 1792 1800 1808 1816 1824 1832	1529 1 1793 1801 1809 1817 1825 1833	1530 2 1794 1802 1810 1818 1826 1834	3 1795 1803 1811 1819 1827 1835	1532 4 1796 1804 1812 1820 1828 1836	1533 5 1797 1805 1813 1821 1829 1837	6 1798 1806 1814 1822 1830 1838	7 1799 1807 1815 1823 1831 1839	to to 3777 204
370 000 010 020 030 040 050	0 1536 1544 1552 1560 1568 1576 1584	1 1537 1545 1553 1561 1569 1577 1585	2 1538 1546 1554 1562 1570 1578	3 1539 1547 1555 1563 1571 1579 1587	1540 1548 1556 1564 1572 1580 1588	5 1541 1549 1557 1565 1573 1581 1589	6 1542 1550 1558 1566 1574 1582 1590	7 1543 1551 1559 1567 1575 1583 1591	3400 3410 3420 3430 3440 3450 3460	0 1792 1800 1808 1816 1824 1832 1840	1529 1 1793 1801 1809 1817 1825 1833 1841	1530 2 1794 1802 1810 1818 1826 1834 1842	3 1795 1803 1811 1819 1827 1835 1843	1532 4 1796 1804 1812 1820 1828 1836 1844	1533 5 1797 1805 1813 1821 1829 1837 1845	6 1798 1806 1814 1822 1830 1838 1846	7 1799 1807 1615 1823 1831 1839 1847	to to 3777 204
370 000 010 020 030 040 050	0 1536 1544 1552 1560 1568 1576 1584	1 1537 1545 1553 1561 1569 1577 1585	2 1538 1546 1554 1562 1570 1578 1586	3 1539 1547 1555 1563 1571 1579 1587	1540 1548 1556 1564 1572 1580 1588	5 1541 1549 1557 1565 1573 1581 1589	6 1542 1550 1558 1566 1574 1582 1590	7 1543 1551 1559 1567 1575 1583 1591	3400 3410 3420 3430 3440 3450 3460	1528 0 1792 1800 1808 1816 1824 1832	1529 1 1793 1801 1809 1817 1825 1833 1841	1530 2 1794 1802 1810 1818 1826 1834 1842	3 1795 1803 1811 1819 1827 1835 1843	1532 4 1796 1804 1812 1820 1828 1836 1844	1533 5 1797 1805 1813 1821 1829 1837 1845	6 1798 1806 1814 1822 1830 1838 1846	7 1799 1807 1615 1823 1831 1839 1847	to to 3777 204
370 000 010 020 030 040 050 070	0 1536 1544 1552 1560 1568 1576 1584 1592	1 1537 1545 1553 1561 1569 1577 1585 1593	2 1538 1546 1554 1562 1570 1578 1586	3 1539 1547 1555 1563 1571 1579 1587 1595	4 1540 1548 1556 1564 1572 1580 1588 1598	5 1541 1549 1557 1565 1573 1581 1589 1597	5 1542 1550 1558 1566 1574 1582 1590 1598	7 1543 1551 1559 1567 1575 1583 1591 1599	3400 3410 3420 3430 3440 3450 3460 3470	0 1792 1800 1808 1816 1824 1832 1840	1793 1801 1809 1817 1825 1833 1841 1849	2 1794 1802 1810 1818 1826 1834 1842 1850	3 1795 1803 1811 1819 1827 1835 1843 1851	1532 4 1796 1804 1812 1820 1828 1836 1844 1852	1533 5 1797 1805 1813 1821 1829 1837 1845 1853	6 1798 1806 1814 1822 1830 1838 1846 1854	7 1799 1807 1815 1823 1831 1839 1847 1855	to to 3777 204
370 000 010 020 030 040 050 070	0 1536 1544 1552 1560 1568 1576 1584 1592	1 1537 1545 1553 1561 1569 1577 1585 1593	2 1538 1546 1554 1562 1570 1578 1586 1594	3 1539 1547 1555 1563 1571 1579 1587 1595	4 1540 1548 1556 1564 1572 1580 1588 1596	5 1541 1549 1557 1565 1573 1581 1589 1597	6 1542 1550 1558 1566 1574 1582 1590 1598	7 1543 1551 1559 1567 1575 1583 1591 1599	3400 3410 3420 3430 3440 3450 3460 3470	1792 1800 1808 1816 1824 1832 1840 1848	1529 1 1793 1801 1809 1817 1825 1833 1841 1849	1530 2 1794 1802 1810 1818 1826 1834 1842 1850	3 1795 1803 1811 1819 1827 1835 1843 1851	1532 4 1796 1804 1812 1820 1828 1836 1844 1852	1533 5 1797 1805 1813 1821 1829 1837 1845 1853	6 1798 1806 1814 1822 1830 1838 1846 1854	7 1799 1807 1815 1823 1839 1847 1855 1863	to to 3777 204
370 000 010 020 030 040 050 070	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614	7 1543 1551 1559 1567 1583 1591 1599 1607 1615	3400 3410 3420 3430 3450 3450 3450 3500	1792 1800 1808 1816 1824 1832 1840 1848 1856	1529 1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866	1531 3 1795 1803 1811 1819 1827 1843 1851 1859 1867	1532 4 1796 1804 1812 1820 1828 1836 1844 1852	1533 5 1797 1805 1813 1821 1829 1837 1845 1853	6 1798 1806 1814 1822 1830 1838 1846 1854	1535 7 1799 1807 1815 1823 1839 1847 1855 1873 1871	to to 3777 204
370 000 010 020 030 040 050 070 110 120	0 1536 1544 1552 1568 1576 1584 1592 1600 1608 1616	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619	1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621	6 1542 1550 1558 1566 1574 1582 1590 1698 1606 1614 1622	7 1543 1551 1559 1567 1583 1591 1599 1607 1615 1623	3400 3410 3420 3430 3440 3450 3460 3500 3510 3520	1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872	1529 1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874	1531 3 1795 1803 1811 1819 1827 1843 1851 1859 1867 1875	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877	6 1798 1806 1814 1822 1830 1838 1846 1854	1799 1807 1815 1823 1831 1839 1847 1855 1853 1871 1879	to to 3777 204
370 000 010 020 030 040 050 100 110 120 130	0 1536 1544 1552 1568 1576 1584 1592 1600 1608 1616	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628	5 1541 1549 1557 1565 1573 1589 1597 1605 1613 1621 1629	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631	3400 3410 3420 3430 3440 3450 3460 3510 3520 3530	1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880	1529 1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1981	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882	1531 3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1884	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886	1799 1807 1615 1823 1831 1839 1847 1855 1853 1871 1879 1887	to to 3777 204
000 010 020 030 040 050 070 110 120 130 140	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1626 1634	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635	4 1540 1548 1556 1564 1572 1580 1588 1596 1604 1612 1620 1628 1636	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638	1279 7 1543 1551 1559 1567 1583 1591 1599 1607 1615 1623 1631 1639	3400 3410 3420 3430 3440 3450 3470 3500 3510 3530 3530 3530	1792 1800 1808 1818 1818 1832 1840 1848 1856 1864 1872 1880 1888	1529 1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1881	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890	1531 3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891	1532 4 1796 1804 1812 1820 1836 1844 1852 1860 1868 1876 1884 1892	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894	7 1799 1807 1815 1823 1831 1839 1847 1855 1873 1871 1879 1887	to to 3777 204
370 000 010 020 030 040 050 070 110 120 130 140 150	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1608 1624 1632 1640	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641	2 1538 1546 1554 1562 1578 1586 1594 1602 1610 1618 1626 1634 1642	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643	4 1540 1548 1556 1564 1572 1580 1588 1596 1612 1628 1628 1636 1644	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1637 1645	6 1542 1550 1558 1566 1574 1582 1590 1698 1606 1614 1622 1630 1638 1646	1279 7 1543 1551 1569 1567 1575 1591 1591 1607 1615 1623 1631 1639 1647	3400 3410 3420 3430 3440 3450 3460 3510 3520 3530 3530 3550	1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1888 1896	1529 1 1793 1801 1809 1817 1823 1841 1849 1857 1865 1873 1889 1889	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1898	1531 3 1795 1803 1811 1819 1825 1843 1851 1859 1867 1875 1883 1891 1899	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1878 1878 1878 1878 1878 1878 1878	1533 5 1797 1805 1813 1821 1821 1845 1853 1861 1869 1877 1885 1893 1901	6 1798 1806 1814 1822 1838 1846 1854 1862 1870 1878 1886 1878 1886 1894	1535 7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1895	to to 3777 204
370 0000 010 020 030 040 050 100 110 120 130 140 150 160	0 1536 1544 1552 1560 1568 1578 1592 1600 1608 1616 1624 1632 1640 1648	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1628 1634 1642 1650	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1612 1627 1635 1643 1651	1540 1548 1556 1564 1572 1588 1596 1612 1620 1620 1636 1636 1636 1644 1652	5 1541 1549 1557 1565 1573 1589 1597 1605 1613 1621 1621 1623 1645 1645	6 1542 1550 1558 1566 1574 1590 1698 1606 1614 1622 1630 1638 1646 1634	1279 7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631 1639 1647 1855	3400 3410 3420 3430 3440 3450 3460 3510 3520 3530 3540 3550 3560	1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904	1529 1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1981 1889 1995	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1898 1906	1531 3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1899	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1868 1876 1888 1876 1889 1900 1908	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909	6 1798 1806 1814 1822 1838 1846 1854 1862 1870 1878 1886 1894 1902	1535 7 1799 1807 1815 1823 1831 1839 1847 1855 1871 1879 1887 1895 1903 1911	to to 3777 204
370 0000 010 020 030 040 050 100 110 120 130 140 150 160	0 1536 1544 1552 1560 1568 1578 1592 1600 1608 1616 1624 1632 1640 1648	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649	2 1538 1546 1554 1562 1578 1586 1594 1602 1610 1618 1626 1634 1642	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1612 1627 1635 1643 1651	1540 1548 1556 1564 1572 1588 1596 1612 1620 1620 1636 1636 1636 1644 1652	5 1541 1549 1557 1565 1573 1589 1597 1605 1613 1621 1621 1623 1645 1645	6 1542 1550 1558 1566 1574 1590 1698 1606 1614 1622 1630 1638 1646 1634	1279 7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1623 1631 1639 1647 1855	3400 3410 3420 3430 3440 3450 3460 3510 3520 3530 3540 3550 3560	1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1888 1896	1529 1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1981 1889 1995	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1898 1906	1531 3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1867 1875 1883 1891 1997	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1868 1876 1888 1876 1889 1900 1908	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909	6 1798 1806 1814 1822 1838 1846 1854 1862 1870 1878 1886 1894 1902	1535 7 1799 1807 1815 1823 1831 1839 1847 1855 1871 1879 1887 1895 1903 1911	to to 3777 204
370 3000 3010 3020 3030 3040 3050 3070 3100 3	0 1536 1542 1550 1568 1576 1584 1592 1600 1608 1616 1624 1640 1648 1656	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1641 1649 1657	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1610 1618 1624 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1651 1659	4 1540 1548 1556 1564 1572 1580 1598 1698 1694 1612 1620 1628 1636 1644 1652 1660 1668	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1621 1645 1653 1661	6 1542 1550 1558 1566 1574 1582 1590 1698 1606 1614 1622 1638 1646 1646 1644 1662	1279 7 1543 1551 1559 1567 1575 1591 1599 1607 1615 1623 1631 1639 1647 1855 1663	3400 3410 3410 3420 3430 3450 3460 3510 3520 3530 3540 3550 3560 3570	1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904	1793 1801 1809 1817 1825 1833 1841 1849 1857 1865 1873 1981 1889 1997 1905	1530 2 1794 1802 1810 1818 1826 1834 1850 1858 1866 1874 1882 1890 1898 1906 1914	1531 3 1795 1803 1811 1819 1827 1843 1851 1859 1867 1875 1883 1891 1899 1907	1532 4 1796 1804 1812 1820 1828 1834 1852 1860 1868 1876 1884 1892 1900 1908	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1885 1893 1901 1909	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1878 1878 1886 1894 1902 1910	1535 7 1799 1807 1815 1823 1831 1839 1847 1855 1863 1871 1879 1887 1895 1903 1911 1919	to to 3777 204
370 3000 3010 3020 3030 3040 3050 3050 3100 3100 3110 3	0 1536 1544 1552 1568 1576 1584 1592 1600 1616 1624 1648 1656 1664 1672	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1641 1649 1657	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1618 1626 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1643 1651 1659 1667	4 1540 1548 1556 1564 1572 1588 1596 1604 1612 1628 1636 1636 1646 1652 1660 1668 1676	\$ 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1645 1665 1666 1667 16667	6 1542 1550 1558 1566 1574 1582 1598 1606 1614 1622 1630 1638 1646 1644 1662	7	3400 3410 3420 3430 3450 3470 3510 3520 3530 3540 3550 3560 3560	1792 1800 1808 1816 1822 1840 1848 1856 1864 1872 1888 1896 1904 1912	1529 1 1793 1801 1809 1817 1825 1633 1841 1849 1857 1865 1873 1981 1995 1913	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1889 1898 1906 1914	1531 3 1795 1803 1811 1819 1825 1843 1851 1859 1867 1875 1889 1997 1915 1923	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1868 1876 1889 1900 1908 1916	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1971 1991 1991 1917	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1886 1894 1902 1910 1918	1535 7 1799 1807 1815 1823 1839 1847 1855 1873 1871 1879 1887 1903 1911 1919 1927	to to 3777 204
370 3000 3010 3020 3030 3040 3050 3050 3100 3100 3110 3	0 1536 1544 1552 1568 1576 1584 1592 1600 1616 1624 1648 1656 1664 1672	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1641 1649 1657	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1618 1626 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1643 1651 1659 1667	4 1540 1548 1556 1564 1572 1588 1596 1604 1612 1628 1636 1636 1646 1652 1660 1668 1676	\$ 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1645 1665 1666 1667 16667	6 1542 1550 1558 1566 1574 1582 1598 1606 1614 1622 1630 1638 1646 1644 1662	7	3400 3419 3420 3430 3450 3460 3510 3520 3530 3540 3560 3560 3610	1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1880 1888 1896 1904 1912	1529 1 1793 1801 1809 1817 1823 1841 1649 1857 1865 1873 1981 1995 1913 1921 1929	2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1892 1890 1914	1531 3 1795 1803 1811 1819 1825 1843 1851 1859 1867 1875 1883 1891 1907 1915	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1868 1876 1892 1908 1916	1533 5 1797 1805 1813 1821 1828 1827 1845 1853 1861 1869 1877 1885 1890 1909 1917	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894 1902 1910 1918	1535 7 1799 1807 1815 1823 1839 1847 1855 1873 1879 1887 1995 1903 1911 1919	to to 3777 204
370 0000 010 020 030 050 070 100 110 120 140 150 160 170 200 210 220	0 1536 1544 1552 1560 1568 1576 1592 1600 1616 1624 1632 1640 1648 1656	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1617 1625 1633 1641 1649 1657	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1618 1626 1634 1642 1650 1658	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1619 1627 1635 1643 1651 1659	4 1540 1548 1556 1564 1572 1580 1588 1596 1612 1628 1634 1644 1652 1668 1668 1668	5 1541 1549 1557 1565 1573 1581 1597 1605 1621 1629 1637 1645 1653 1661 1669 1669	6 1542 1550 1558 1566 1574 1582 1598 1696 1696 1638 1646 1644 1662 1670 1678	7	3400 3410 3420 3430 3440 3450 3460 3510 3520 3530 3540 3550 3560 3570	0 1792 1800 1808 1808 1818 1824 1832 1840 1856 1864 1872 1680 1888 1896 1994 1992 1992	1529 1 1793 1801 1809 1819 1825 1633 1841 1849 1857 1865 1873 1981 1995 1913 1921 1929 1937	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1882 1890 1898 1906 1914 1922 1930 1938	1531 3 1795 1803 1811 1819 1827 1827 1828 1843 1851 1859 1867 1875 1883 1891 1899 1907 1915 1923 1931 1931	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1860 1968 1998 1998 1998 1998 1998	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1909 1917 1925 1925 1927 1927 1928	1798 1806 1814 1822 1830 1838 1846 1854 1867 1878 1886 1894 1902 1918	1535 7 1799 1807 1815 1823 1839 1847 1855 1873 1871 1895 1903 1911 1919 1927 1943	to to 3777 204
370 370 3000 3010 9020 9030 9040 9050 1100 1100 1100 1100 1100 1100 1100 1100 12	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656 1664 1672 1680 1688	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657	2 1538 1546 1554 1562 1578 1578 1586 1594 1602 1618 1624 1634 1642 1650 1668 1666 1674 1682 1682 1682	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1627 1635 1643 1651 167 167 167 167 1683 1683 1683	4 1540 1548 1556 1564 1570 1588 1596 1604 1612 1628 1636 1644 1652 1660 1568 1676 1684 1676 1684 1684 1684	5 1541 1549 1557 1565 1573 1589 1597 1605 1629 1629 1637 1645 1653 1661 1669 1679 1699	6 1542 1550 1558 1568 1574 1582 1590 1698 1606 1614 1622 1630 1638 1646 1646 1654 1670 1670	7 1543 1551 1567 1575 1583 1591 1607 1615 1623 1639 1667 1675 1663 1671 1679 1687 1687 1689	3400 3410 3420 3430 3450 3460 3570 3500 3550 3550 3560 3660 3670 3620 3630	0 1792 1800 1808 1816 1816 1816 1816 1818 1818	1529 1 1793 1801 1809 1817 1825 1833 1841 1849 1857 1965 1973 1913 1921 1929 1937 1945	1530 2 1794 1892 1810 1818 1826 1834 1859 1858 1866 1874 1882 1899 1996 1914	1531 3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1967 1875 1883 1899 1907 1915 1923 1931 1939 1947	1532 4 1796 1804 1812 1820 1828 1836 1844 1852 1868 1878 1892 1900 1908 1916 1924 1932 1948	1533 5 1797 1805 1813 1821 1829 1837 1845 1869 1877 1889 1909 1917 1925 1933 1941 1949	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1894 1902 1910 1918 1926 1934 1942 1942	1535 7 1799 1807 1813 1823 1831 1835 1871 1879 1887 1895 1991 1911 1919 1927 1935 1943	to to 3777 204
370 370 300 300 301 301 301 301 301 30	0 1536 1544 1552 1560 1568 1576 1576 1600 1616 1624 1632 1640 1648 1656	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1649 1657 1685 1687 1689	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1618 1624 1634 1634 1650 1658 1666 1674 1682	3 1539 1547 1555 1563 1571 1587 1595 1603 1611 1619 1627 1634 1651 1665 1667 1667 1669	4 1540 1548 1556 1564 1570 1588 1596 1604 1612 1620 1628 1636 1636 1636 1652 1660 1668 1676 1668	5 1541 1549 1557 1565 1573 1589 1597 1605 1621 1629 1645 1653 1661 1669 1677 1685 1693 1701	6 1542 1550 1558 1566 1574 1590 1598 1606 1614 1622 1630 1634 1646 1644 1662	7 1543 1551 1563 1575 1583 1591 1607 1615 1623 1631 1659 1667 16663 1671 1679 1667 1679 1687 1703	3400 3416 3420 3430 3450 3470 3510 3520 3530 3560 3560 3610 3620 3630 3640	1528 0 1792 1800 1808 1816 1822 1840 1856 1856 1856 1858 1890 1912 1922 1928 1932 1944 1952	1529 1 1793 1801 1802 1803 1841 1849 1857 1968 1867 1973 1989 1913 1929 1937 1945 1953	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1906 1914 1922 1930 1938 1946 1946	1531 3 1795 1803 1811 1819 1827 1843 1851 1853 1867 1875 1883 1891 1907 1915	1532 4 1796 1804 1812 1820 1836 1844 1852 1860 1868 1868 1890 1990 1990 1916	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1869 1869 1917 1925 1933 1941 1949 1957	6 1798 1806 1814 1832 1838 1846 1854 1862 1878 1863 1894 1902 1918 1942 1942 1958	1535 7 1799 1807 1815 1823 1831 1847 1855 1873 1871 1985 1993 1911 1919 1927 1935 1949 1959	to to 3777 204
370 000 010 020 030 040 050 100 110 120 140 150 160 170 200 210 220 220 220 225 250	0 1536 1544 2552 1560 1568 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1646 1656 1664 1666 1668 1668 1668	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657 1668 1668 1688 1688 1688 1688 1688 168	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1618 1626 1634 1642 1658 1668 1668 1668 1668 1668 1698 1706	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1659 1667 1668 1669 1707	4 1540 1548 1556 1564 1572 1580 1588 1596 1612 1628 1636 1644 1662 1668 1668 1668 1668 1684 1692	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1629 1629 1645 1669 1669 1669 1669 1701	6 1542 1550 1558 1568 1564 1574 1582 1590 1606 1614 1622 1630 1638 1646 1646 1662 1670 1686 1694 1702	7	3400 3410 3420 3430 3450 3460 3510 3520 3530 3540 3550 3560 3570 3620 3630 3630 3640 3650	0 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1888 1896 1904 1912 1928 1938 1949 1949 1952 1950	1529 1 1793 1801 1809 1817 1825 1831 1849 1857 1865 1873 1981 1993 1993 1993 1995 1995 1995 1995 199	1530 2 1794 1802 1810 1818 1826 1834 1850 1858 1866 1874 1898 1908 1919 1919 1919 1921 1932 1945 1954	1531 3 1795 1803 1811 1819 1827 1835 1851 1867 1875 1875 1875 1875 1997 1917 1915 1923 1931 1947 1993 1993	1532 4 1796 1804 1812 1820 1836 1836 1876 1868 1876 1892 1900 1908 1916 1914 191	1533 5 1797 1805 1813 1821 1829 1835 1845 1853 1861 1899 1907 1917 1923 1941 1949 1941 1945 1955	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1878 1886 1894 1902 1918 1924 1934 1942 1958	1535 7 1799 1807 1815 1823 1831 1847 1855 1873 1871 1879 1993 1911 1919 1927 1943 1959 1959 1957	to to 3777 204
370 370 3000 3010 3020 3030 3040 3050 100 110 120 130 140 150 170 206 210 220 220 220 220 220 220 220	0 1536 1544 1552 1560 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656 1664 1664 1664 1664 1668 1696 1704 1704 1704	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1635 1641 1649 1657 1681 1681 1681 1681 1681 1681 1705	2 1538 1546 1554 1562 1570 1578 1586 1594 1610 1618 1622 1634 1642 1650 1658 1666 1674 1682 1696 1714	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1627 1635 1643 1651 1659 1667 1673 1693 1693 1693 1707	4 1540 1548 1558 1564 1572 1580 1588 1598 1694 1612 1620 1628 1636 1644 1652 1660 1568 1676 1684 1676 1700 1716	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1645 1645 1669 1677 1693 1701 1709	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1644 1662 1670 1678 1670 1770 1718	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1631 1631 1631 1631 1645 1663 1671 1695 1703 1711	3400 3410 3420 3430 3450 3460 3510 3520 3530 3550 3660 3610 3620 3630 3630 3640 3650	1792 1792 1800 1808 1816 1824 1832 1840 1856 1864 1864 1864 1964 1912 1920 1921 1920 1928 1936 1944 1952 1966	1529 1 1793 1801 1809 1801 1809 1807 1825 1833 1984 1857 1905 1913 1921 1929 1937 1945 1959 1969	2 1794 1802 1810 1818 1816 1824 1850 1858 1866 1898 1996 1914 1922 1930 1946 1956	1531 3 1795 1803 1811 1819 1827 1835 1851 1859 1967 1915 1923 1931 1939 1947 1947 1948 1947 1948 1947 1948	1532 4 1796 1804 1812 1820 1836 1836 1852 1860 1868 1876 1892 1900 1916 1924 1948 1958 1948 1958 1958	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1893 1990 1917 1925 1933 1949 1949 1957 1973	6 1798 1806 1814 1822 1830 1838 1846 1854 1870 1878 1894 1992 1910 1918 1934 1950 1950 1950	1535 7 1799 1807 1815 1823 1831 1831 1871 1875 1873 1871 1993 1993 1993 1993 1993 1995 1995 1997 1975	to to 3777 204
370 3000 3010 3020 3030 3040 3050 3070 3100 3110 3140 3	0 1536 1544 1552 1560 1576 1584 1592 1600 1608 1616 1624 1632 1640 1648 1656 1664 1664 1664 1664 1668 1696 1704 1704 1704	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1635 1641 1649 1657 1681 1681 1681 1681 1681 1681 1705	2 1538 1546 1554 1562 1570 1578 1586 1594 1602 1618 1626 1634 1642 1658 1668 1668 1668 1668 1668 1698 1706	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1627 1635 1643 1651 1659 1667 1673 1693 1693 1693 1707	4 1540 1548 1558 1564 1572 1580 1588 1598 1694 1612 1620 1628 1636 1644 1652 1660 1568 1676 1684 1676 1700 1716	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1629 1645 1645 1669 1677 1693 1701 1709	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1638 1646 1644 1662 1670 1678 1670 1770 1718	7 1543 1551 1559 1567 1575 1583 1591 1599 1607 1615 1631 1631 1631 1631 1645 1663 1671 1695 1703 1711	3400 3410 3420 3430 3450 3460 3510 3520 3530 3550 3660 3610 3620 3630 3630 3640 3650	0 1792 1800 1808 1816 1824 1832 1840 1848 1856 1864 1872 1888 1896 1904 1912 1928 1938 1949 1949 1952 1950	1529 1 1793 1801 1809 1801 1809 1807 1825 1833 1984 1857 1905 1913 1921 1929 1937 1945 1959 1969	2 1794 1802 1810 1818 1816 1824 1850 1858 1866 1898 1996 1914 1922 1930 1946 1956	1531 3 1795 1803 1811 1819 1827 1835 1851 1859 1907 1915 1923 1931 1939 1947 1947 1948 1947 1948 1947 1948	1532 4 1796 1804 1812 1820 1836 1836 1852 1860 1868 1876 1892 1900 1916 1924 1948 1958 1948 195	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1893 1990 1917 1925 1933 1949 1949 1957 1973	6 1798 1806 1814 1822 1830 1838 1846 1854 1870 1878 1894 1992 1910 1918 1934 1950 1950 1950	1535 7 1799 1807 1815 1823 1831 1831 1871 1875 1873 1871 1993 1993 1993 1993 1993 1995 1995 1997 1975	to to 3777 204
370 0000 0110 020 030 050 070 110 120 130 140 150 170 200 210 220 220 240 250 270	0 1536 1544 1552 1560 1568 1576 1584 1579 1600 1616 1622 1640 1648 1656 1664 1672 1680 1704 1712 1720	1 1537 1545 1553 1561 1561 1569 1577 1585 1601 1609 1617 1625 1633 1641 1649 1657 1688 1688 1689 1705 1713 1721	2 1538 1546 1554 1562 1570 1578 1584 1610 1618 1622 1634 1642 1650 1658 1666 1674 1682 1714 1722	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1651 1667 1667 1668 1699 1707 1715 1723	4 1540 1548 1556 1564 1572 1580 1588 1696 1612 1620 1628 1636 1644 1652 1660 1676 1684 1696 1700 1716 1724	5 1541 1549 1557 1565 1573 1581 1589 1605 1613 1621 1622 1637 1645 1653 1669 1677 1685 1693 1701 1770 1770 1772 1772	6 1542 1550 1558 1558 1566 1574 1582 1590 1698 1698 1614 1622 1630 1646 1646 1654 1672 1670 1702 1710 1718 1726	7	3400 3419 3420 3430 3450 3450 3510 3520 3530 3540 3550 3660 3670	1792 1792 1792 1800 1808 1816 1824 1832 1840 1848 1866 1864 1964 1912 1920 1928 1928 1944 1952 1946 1956 1968 1976	1529 1 1793 1807 1809 1817 1825 1833 1841 1849 1857 1968 1913 1921 1929 1947 1948 1958 1969 1977	1530 2 1794 1802 1810 1818 1816 1818 1826 1850 1858 1866 1874 1882 1890 1914 1922 1930 1930 1941 1942 1952 1970 1978	1531 3 3 1795 1803 1811 1819 1827 1843 1851 1859 1907 1915 1923 1931 1931 1947 1963 1971 1963 1971 1979	1532 4 1796 1804 1812 1820 1820 1820 1836 1844 1852 1863 1896 1990 1916 1924 1948 1948 1948 1958 1958 1968 1972 1980	1533 5 1797 1805 1821 1823 1821 1827 1845 1853 1861 1869 1917 1925 1927 1928 1927 1928 1931 1949 1957 1958 1973 1981	6 1798 1806 1814 1822 1830 1838 1838 1854 1865 1870 1990 1910 1918 1926 1934 1959 1958 1958 1958	1535 7 1799 1807 1815 1823 1831 1835 1873 1873 1873 1871 1993 1911 1919 1927 1935 1943 1951 1957 1957 1955	to to 3777 204
370 0000 0100 0100 0300 0400 0500 1100 1100 1100 1100 1200 1200 1200 1200 1200 1200 1200 1200 1300 1400 1400 1400 1200 1200 1300 1400 1	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1616 1624 1632 1640 1648 1656 1664 1672 1792 1792 1792	1 1537 1545 1553 1561 1561 1569 1577 1609 1617 1609 1617 1649 1649 1657 1685 1673 1689 1697 1705 1775 1775 1775 1775 1775 1775	2 1538 1546 1554 1562 1570 1578 1578 1586 1594 1610 1618 1626 1634 1642 1650 1658 1666 1674 1689 1706 1708 1714 1712 1713	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1643 1667 1675 1669 1707 1715 1713 1713	4 1540 1548 1556 1564 1572 1580 1596 1604 1612 1628 1636 1648 1652 1660 1668 1676 1684 1700 1708 1716 1716 1714	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1643 1643 1643 1661 1669 1677 1685 1703 1701 1701 1717 1725	6 1542 1550 1558 1566 1574 1582 1690 1614 1622 1638 1646 1648 1662 1670 1678 1710 1718 1718 1718 1718	7	3400 3410 3420 3430 3450 3460 3510 3520 3530 3550 3560 3660 3670 3700	0 1792 1800 1808 1818 1816 1824 1832 1840 1888 1896 1994 1912 1928 1932 1944 1952 1969 1968 1976	1529 1 1793 1801 1809 1817 1825 1841 1849 1857 1865 1873 1981 1897 1995 1913 1921 1929 1945 1953 1961 1969 1977	2 1794 1802 1810 1818 1816 1818 1826 1834 1842 1866 1874 1882 1898 1906 1914 1922 1930 1938 1954 1954 1977 1978	1531 3 1795 1803 1811 1819 1827 1843 1851 1859 1867 1875 1883 1891 1997 1915 1923 1931 1947 1915 1919 1919 1919 1919	1532 4 1796 1804 1812 1820 1820 1820 1820 1836 1844 1852 1860 1868 1892 1990 1990 1916 1924 1948 1948 1948 1956 1968	1533 5 1797 1805 1821 1823 1821 1823 1845 1853 1861 1869 1917 1925 1933 1949 1949 1957 1965 1973 1981	5 1798 1806 1814 1822 1830 1838 1846 1854 1862 1870 1918 1902 1919 1918 1926 1934 1940 1958 1968 1974 1992	1535 7 1799 1807 1813 1823 1831 1853 1871 1879 1887 1903 1911 1919 1927 1935 1943 1959 1959 1975 1983 1991	to to 3777 204
370 0000 0100 0200 0300 0700 1100 1100 1100 1100 1100 1100 1100 1100 1100 1200 1200 1200 1200 1300 1400 1300 1400 1400 1500 1600 1700 1	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1618 1614 1624 1632 1640 1644 1672 1680 1696 1704 1712 1712 1712 1720	1 1537 1545 1553 1561 1561 1561 1575 1593 1601 1609 1617 1625 1633 1641 1649 1657 1665 1673 1681 1705 1705 1713 1721	2 1538 1546 1554 1562 1570 1578 1578 1610 1618 1626 1634 1642 1650 1658 1666 1674 1689 1706 1714 1772 1773	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1643 1659 1707 1715 1699 1707 1715 1713 1773	4 1540 1548 1556 1564 1572 1588 1596 1612 1628 1628 1636 1644 1652 1660 1706 1708 1716 1724	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1621 1637 1645 1653 1701 1708 1717 1708 1717 1725 1773 1774	6 1542 1550 1558 1566 1574 1582 1590 1698 1606 1614 1622 1630 1638 1646 1644 1622 1770 1718 1702 1710 1718 1726 1774	7	3400 3410 3420 3430 3440 3450 3500 3510 3520 3530 3540 3550 3560 3670 3620 3630 3640 3650 3650 3670	0 1792 1800 1808 1816 1816 1824 1832 1832 1832 1848 1856 1960 1984 1992 1992 1992 1993 1956 1958 1976	1529 1 1793 1801 1802 1803 1817 1825 1825 1837 1841 1849 1857 1965 1913 1945 1915 1949 1959 1961 1961 1961 1967 1968 1977 1985 1993	1530 2 1794 1802 1810 1818 1816 1818 1826 1858 1858 1858 1858 1866 1874 1882 1904 1918 1922 1930 1938 1945 1952 1978 1978	1531 3 1795 1803 1811 1819 1827 1835 1843 1851 1859 1907 1915 1919 1919 1923 1931 1939 1947 1919 1998	1532 4 1796 1804 1812 1820 1828 1828 1836 1844 1852 1960 1900 1908 1914 1940 1941 1941 1941 1946 1946 1948 1946 1948 194	1533 5 1797 1805 1821 1821 1829 1837 1845 1853 1864 1853 1901 1909 1917 1999 1917 1995 1995 1997	6 1798 1806 1814 1822 1830 1838 1846 1854 1862 1873 1886 1892 1990 1918 1924 1958 1966 1974 1992 1998	1535 7 1799 1607 1615 1620 1631 1631 1631 1633 1671 1695 1903 1971 1919 1927 1935 1943 1959 1967 1983	to to 3777 204
370 0000 0100 0200 0300 0300 0700 1000 1100 1200 1300 1400 1	0 1536 1544 1552 1560 1568 1576 1600 1608 1616 1644 1632 1640 1648 1672 1720 1720 1728	1 1537 1545 1553 1561 1569 1575 1585 1593 1601 1602 1637 1641 1649 1657 1668 1670 1670 1771 1772 1772 1773 1773	2 1538 1546 1554 1562 1570 1578 1586 1594 1618 1626 1634 1642 1650 1658 1666 1674 1690 1705 1714 1722	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1627 1635 1643 1651 1663 1667 1773 1793 1793 1793 1794	4 1540 1548 1556 1564 1572 1580 1588 1596 1612 1628 1634 1652 1660 1568 1576 1708 1716 1724 1732 1742	5 1541 1549 1557 1565 1573 1589 1597 1605 1613 1629 1637 1645 1669 1701 1703 1701 1772 1773 1773 1774 1774	6 1542 1550 1558 1566 1574 1582 1590 1698 1606 1614 1630 1634 1646 1644 1702 1710 1718 1726 1736	7	3400 3410 3420 3430 3440 3450 3510 3520 3530 3540 3550 3610 3620 3630 3640 3650 3670 3700 3710	0 1792 1800 1808 1816 1816 1824 1832 1840 1848 1856 1864 1972 1920 1921 1920 1928 1936 1936 1956 1956 1956 1956	1529 1 1793 1801 1801 1801 1803 1813 1841 1825 1873 1891 1891 1991 1993 1991 1993 1991 1993 1991 1993 1991 1993 1993 1993 1993 2001	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1996 1914 1922 1930 1945 1956 1976 1978	1531 1795 1803 1811 1819 1827 1843 1843 1843 1849 1867 1873 1891 1995 1993 1997 1915 1967 1979 1987 1996 1997 1997 1997 1900	1532 4 1796 1804 1812 1820 1828 1836 1848 1878 1878 1900 1916 1924 1948 1952 1948 1952 1948 1952 1948 1952 1948 195	1533 5 1797 1805 1813 1821 1829 1845 1845 1875 1893 1901 1917 1925 1933 1949 1957 1961 1968 1973 1981	5 1798 1806 1814 1822 1830 1838 1846 1854 1878 1885 1892 1910 1918 1902 1950 1950 1950 1950 1950 1950 1950 1950	1535 7 1799 1807 1815 1823 1847 1843 1847 1875 1995 1995 1999 1997 1995 1997 1995 1999 1999	to to 3777 204
370 3000 3010 3030 3040 3050 3070 3100 3100 3200 3310 3320 3330	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1608 1616 1648 1648 1672 1648 1672 1688 1774 1772 1772 1772 1772 1774 1774	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1609 1617 1625 1633 1641 1649 1657 1705 1705 1705 1715 1721 1722 1737 1745 1775	2 1538 1546 1554 1578 1586 1578 1586 1594 1602 1618 1622 1634 1642 1650 1656 1656 1656 1714 1722 1730 1738	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1627 1643 1651 1663 1667 1667 1669 1707 1715 1713 1723 1731 1732	4 1540 1548 1556 1564 1576 1580 1588 1596 1602 1628 1636 1636 1636 1636 1636 1636 1636 163	5 1541 1549 1557 1565 1573 1581 1589 1597 1601 1621 1629 1637 1645 1653 1661 1677 1695 1677 1695 1773 1774 1775 1773	6 1542 1550 1558 1566 1574 1582 1590 1598 16046 1614 1662 1638 1646 1652 1710 1718 1726 1778 1778	7	3400 3410 3420 3430 3450 3460 3510 3520 3530 3560 3560 3660 3670 3710 3720 3730	0 1792 1800 1808 1818 1816 1818 1824 1832 1840 1848 1896 1902 1928 1934 1912 1928 1936 1936 1936 1936 1936 1936 1936 1936	1529 1 1793 1801 1802 1803 1813 1841 1845 1873 1981 1993 1994 1995	2 1794 1802 1810 1818 1816 1818 1826 1834 1842 1858 1858 1858 1890 1898 1906 1934 1954 1954 1970 1978	1531 3 1795 1803 1811 1819 1827 1835 1843 1859 1867 1875 1889 1997 1995 1993 1997 1997 1998 2003 2001	1532 4 4 1796 1804 1812 1820 1828 1836 1844 1852 1868 1876 1884 1892 1900 1908 1916 1924 1948 1956 1968 1972 1980 1988 1995 2004 1988	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1985 1991 1999 1997 1995 1993 1994 1997 1988 1997 2005	6 1798 1806 1804 1814 1822 1838 1846 1854 1867 1878 1890 1910 1918 1942 1950 1950 1950 1950 1950 1974 1962	1535 7 1799 1807 1815 1823 1831 1839 1847 1855 1963 1919 1927 1935 1943 1949 1959 1959 1959 1959 1959 1959 1959	to to 3777 204
370 0000 010 020 040 050 100 110 120 130 145 170 200 220 230 240 240 310 320 330 340	0 1536 1544 1552 1560 1568 1576 1576 1600 1608 1616 1642 1632 1640 1648 1656 1704 1712 1720 1720 1720 1736 1744 1750	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 16025 1633 1641 1649 1657 1668 1673 1681 1673 1773 1773 1773 1774 1773 1774 1775	2 1538 1546 1554 1562 1570 1578 1618 1626 1638 1642 1650 1668 1668 1714 1722 1730 1730 1730 1730 1746 1776	3 1539 1547 1553 1563 1571 1579 1587 1595 1603 1611 1619 1627 1635 1663 1665 1667 1675 1663 1675 1675 1675 1773 1773 1773 1773 1773 1774 1775	4 1540 1548 1556 1564 1570 1580 1580 1690 1628 1630 1630 1630 1630 1630 1630 1630 1700 1710 1720 1730 1740 1740 1756 1756	5 1541 1549 1565 1573 1589 1589 1589 1690 1602 1602 1602 1603 1664 1665 1663 1666 1709 1717 1725 1741 1749 1757	6 1542 1550 1558 1558 1578 1590 1698 1698 1698 1698 1698 1698 1698 1698	7	3400 3410 3420 3430 3440 3450 3500 3510 3520 3530 3540 3550 3660 3670 3620 3630 3640 3650 3670 3710 3710 3720 3730	0 1792 1800 1808 1816 1816 1816 1824 1832 1848 1856 1864 1972 1992 1992 1992 1992 1993 1994 1995 1996 1996 1998 1998	1529 1 1793 1801 1802 1802 1803 1803 1803 1803 1803 1803 1803 1803	1530 2 1794 1802 1810 1818 1826 1834 1842 1850 1858 1866 1874 1996 1914 1938 1956 1978 1978 1978	1531 3 1795 1803 1811 1819 1827 1825 1843 1843 1841 1859 1967 1978 1995 1995 1993 1997 1995 1996 1997 1997 1998 2003 2011	1532 4 1796 1804 1812 1820 1828 1836 1848 1852 1868 1876 1868 1976 1990 1916 1924 1932 1948 1952 1968 1972 1988 198	1533 5 1797 1805 1813 1821 1829 1837 1845 1869 1877 1945 1999 1917 1925 1933 1961 1973 1973 1981 1999 1917 1928 1938 1938 1949 1958 1973 1981 1989 1987 1988 198	6 1798 1806 1804 1814 1822 1830 1838 1846 1854 1862 1873 1886 1892 1910 1918 1924 1934 1942 1950 1974 1966 1974 1998 2006 2014	1535 7 1799 1607 1615 1623 1631 1631 1639 1647 1675 1675 1675 1675 1675 1675 1675 167	to to 3777 204
370 3000 3010 3	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1616 1632 1640 1648 1640 1648 1656 1664 1672 1680 1702 1728 1720 1728 1736	1 1537 1545 1553 1561 1569 1567 1585 1593 1601 1609 1609 1633 1641 1649 1657 1705 1707 1707 1707 1707 1707 1707 17	2 1538 1546 1554 1578 1578 1578 1586 1698 1602 1618 1624 1658 1664 1658 1706 1714 1722 1730 1738 1746 1754 1776	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1661 1661 1663 1663 1663 1663 1663	4 1540 1548 1556 1564 1576 1580 1588 1596 1602 1628 1636 1644 1652 1700 1708 1706 1716 1716 1716 1716 1716 1716 1716	5 1541 1549 1557 1565 1573 1581 1581 1581 1621 1623 1623 1623 1645 1653 1764 1763 1770 1770 1771 1772 1773 1741 1774 1775 1775	6 1542 1550 1558 1566 1574 1582 1590 1598 1606 1614 1622 1630 1646 1646 1646 1646 1712 1712 1712 1712 1712 1712 1713 1714 1714 1715 1715 1715	7	3400 3410 3420 3430 3440 3450 3510 3520 3530 3540 3550 3660 3670 3670 3700 3710 3720 3730 3730	0 1792 1800 1808 1816 1816 1824 1832 1848 1856 1864 1872 1992 1992 1992 1994 1992 1996 1996 1996 1996 1996 1996 1996	1529 1 1793 1801 1801 1803 1813 1841 1825 1873 1865 1873 1891 1892 1993 1994 1995 1993 1994 1995 1997 1985 1993 1997 1985 1993 1996 1997 1985 1993 1997 1998 1998 1997 1998 1997 1998	1794 1892 1810 1818 1816 1818 1826 1834 1842 1850 1878 1890 1814 1922 1930 1914 1962 1976 1978 1986 1996 1996 1996 1990 2018	1531 3 1795 1803 1811 1819 1827 1843 1843 1843 1843 1867 1875 1875 1995 1997 1915 1923 1939 1947 1915 1923 1939 1947 1919 1947 1959 1967 1979 1987 1998 2011 2019 2012 2017	1532 4 1796 1804 1812 1820 1828 1836 1848 1878 1868 1878 1900 1916 1924 1948 1956 1968 1972 1988 1998 1918	1533 5 1797 1805 1813 1821 1829 1837 1845 1869 1877 1989 1907 1917 1925 1933 1941 1965 1973 1981 1989 1997 1988 2001 1988 198	6 1798 1806 1814 1822 1830 1838 1846 1854 1865 1873 1886 1990 1910 1910 1942 1942 1942 1958 1968 1974 1982 1998 1998 1998 1998	1535 7 1799 1607 1615 1623 1631 1631 1631 16431 16431 1679 1685 1903 1901 1919 1927 1935 1943 1951 1959 1957 1983 1999 1999 1997 2007 2015	to to 3777 204
370 3000 3010 3020 3040 3050 3060 3070 3	0 1536 1544 1552 1560 1568 1576 1584 1592 1600 1616 1624 1632 1640 1648 1654 1654 1704 1712 1720 1720 1728 1736 1736 1736 1736 1736	1 1537 1545 1553 1561 1569 1577 1585 1593 1601 1607 1625 1631 1649 1657 1668 1668 1668 1673 1705 1705 1715 1729 1737 1745 1775 1776 1777	2 1538 1546 1554 1562 1570 1578 1618 1626 1638 1642 1650 1668 1668 1714 1722 1730 1730 1730 1730 1746 1776	3 1539 1547 1555 1563 1571 1579 1587 1595 1603 1611 1627 1638 1643 1659 1667 1668 1669 1707 1715 1723 1731 1731 1731 1731 1731 1731 1731	4 1540 1548 1556 1564 1576 1580 1588 1596 1620 1620 1620 1628 1636 1636 1636 1636 1636 1636 1636 1716 1732 1740 1774 1774 1774 1774 1774 1774 1774	5 1541 1549 1557 1565 1573 1581 1589 1597 1605 1613 1629 1645 1653 1664 1677 1695 1773 1774 1774 1775 1773 1774 1775 1776 1776 1776 1776 1776 1776	6 1542 1550 1558 1566 1574 1590 1598 1606 1614 1662 1670 1778 1678 1778 1778 1778 1778 1778 1778	7	3400 3410 3420 3430 3450 3510 3520 3530 3560 3560 3660 3670 3710 3720 3730 3740 3740 3750	0 1792 1800 1808 1816 1816 1816 1824 1832 1848 1856 1864 1972 1992 1992 1992 1992 1993 1994 1995 1996 1996 1998 1998	1529 1 1793 1801 1802 1803 1813 1841 1845 1873 1981 1993 1994 1995	2 1794 1802 1810 1818 1816 1818 1826 1834 1842 1858 1858 1898 1906 1934 1954 1954 1954 1970 1978 1986 1994 2002 2018 2003	1531 3 1795 1803 1811 1819 1827 1835 1843 1851 1867 1875 1889 1997 1995 1993 1997 1995 1997 1997 1998 2001 2012 2013 2012 2013 2012 2012 2013 2014 2015 2016 2017 2018 201	1532 4 1796 1804 1812 1820 1828 1836 1848 1852 1868 1875 1884 1892 1990 1998 1995 1948 1995 1998 199	1533 5 1797 1805 1813 1821 1829 1837 1845 1853 1861 1869 1877 1985 1999 1999 1999 1999 1997 2005 1998 1997 2005 2012 2021 2022 2027	6 1798 1806 1814 1822 1830 1846 1854 1864 1862 1870 1910 1918 1992 1910 1918 1942 1950 1950 1962 1974 1992 1998 2006 1998 2002 2032 2032	1535 7 1799 1807 1815 1823 1831 1839 1847 1855 1969 1967 1993 1991 1997 1983 1999 2007 2015 2023 2031	to to 3777 204

OCTAL-DECIMAL INTEGER CONVERSION TABLE (continued)

	1			2		4	 5	6	7		ĺ			2	3	4	5	5	7
Ī									2055	ſ	4400	2204	2305	2706	2307	2308	2309	2310	2311
4000 2048 to to	4000 4010	2056	2057	2050 2058	2059	2060	206 L	2062	2063		4410	2312	2313	2314	2315	2316	2317	2318	2319
4777 2559	4D20	2064	2065	2066 2074	2067	2058	2069	2070	2071		4420	2320 232B	2321	2330	2331	2324 2332	2333	2334	2335
(Octal) (Decimal)	4040:	2080	2081	2082	2083	2084	2085	2086	2087]		4440	2336	2337	2338	2339	2340	2341	2342	2343
O-tal Desimal	4050	2088	2089	2090	2091	2092	2093	2094	2095		4450	2344	2345 2353	2346	2347	2348	2349	2350 2358	
Octal Decimal 10000 - 4096	4050	2096	2097	2098 2106	2107	2100	2102	2110	2111	. 1	4470	2360	2361	2362	2363	2364	2365	2366	2367
20000 - 8192	: I								1	1			2252		0071	2372	2272	2274	2225
30000 - 12288 40000 - 16384	4100	2112	2113	2114 2122	2115	2115	2117	2118	21191		4500 4510	2376	2377	2378	2379	2380	2381	2382	2383
50000 20480	4120	2128	2129	2130	2131	2132	2133	2134	2135]	!	4520	2384	2385	2386	2387	2388	2389	2390	2391
60000 - 24576 70000 - 28672	4130	2136	2137	2138	2139	2140	2141	2142	2143		4530	2392	2393	2394	2395	2396 2404	2397	2398	2407
,0000	4140	2194	2153	2146 2154	2155	2156	2157	215B	2159		4550	2408	2409	2410	2411	2412	2413	2414	2415
	4160	2150	2161	2162	2163	2164	2165	2166	2167]	1	4560	2416	2417	2418	2419	2420	2421	2422	2423
	4170	2168	2169	2170	2171	2172	2173	2174	\$112							2428			
	4200	2176	2177	2178	2179	2180	2181	2182	2183		4600	2432	2433	2434	2435	2436 2444	2437	2438	2439
	4210	2184	2185	2186 2194	2195	2196	2197	2198	2199		4620	2448	2449	2450	245 L	2452	2453	2454	2455
	4230	2200	2201	2202	2203	22D4	2205	2206	2207		4630	2456	2457	2458	2459	2460	246L	2462	2463
·	4240	2208	2209	2210	2211	2212	2213	2214	2215	۱ }	4640	2464	2455	2466	2467	2468 2476	2477	2478	2479
	4260	2224	2225	2218 2226	2227	2228	2229	2230	2231	{	4660	2480	2481	2482	2483	2484	2485	2486	2487
	4270	2232	2233	2234	2235	2236	2237	2238	2239	i	4670	2488	2489	2490	2491	2492	2493	2494	2495
ı	4300	2240	2241	2242	2243	2244	2245	2246	2247				2497			2500	2501	2502	2503
Ï	4310	2248	2249	2250 2258	2251	2252	2253	2254	2255		4720	2504	2505	2506	2515	2508 2516	2517	2518	2519
	4330	2264	2265	2266	2267	2268	2269	2270	2271		4730	2520	2521	2522	2523	2524	2525	2526	2527
	14340 !	2272	2273	2274	2275	2276	2277	2278	2279		4740	2528	2529 2537	2530	2531	2532 2540	2533	2534	2535
	4360	2288	2289	2282 2290	2291	2292	2293	2294	2295		4760	2544	2545	2546	2547	2548	2549	2550	2551
	4370	2296	2297	2298	2299	2300	2301	2302	2303	; ;	4770	2552	2553	2554	2555	2556	2557	2558	2559
	- 1			,	3	4	5	6	7			0	1	2	3	4	5	6	7
1	ا 	0	. ' .	2	3	4	5		\dashv	١ ١	5400					_			
5000 2560	5000 5010	2560	— 2561	2562	2563	 2564	2565	2566	2567		5410	2816 2824	2817 2825	2818 2825	2819 2827	2820 2828	2821 2829	2822 2830	2823 2831
to to	5010	2560 2568 2576	2561 2569 2577	2562 257D 257B	2563 2571 2579	2564 2572 2580	2565 2573 2581	2566 2574 2582	2567 2575 2583		5410 5420	2816 2824 2832	2817 2825 2833	2818 2826 2834	2819 2827 2835	2820 2828 2836	2821 2829 2837	2822 2830 2838	2823 2631 2839
	5010 5020 5030	2560 2568 2576 2576	2561 2569 2577 2585	2562 2570 2578 2586	2563 2571 2579 2587	2564 2572 2580 2588	2565 2573 2581 2589	2566 2574 2582 2590	2567 2575 2583 2591		5410 5420 5430 5440	2816 2824 2832 2840 2848	2817 2825 2833 2841 2849	2818 2825 2834 2842 2850	2819 2827 2835 2843 2851	2820 2828 2836 2844 2852	2821 2829 2837 2845 2853	2822 2830 2838 2846 2854	2823 2631 2839 2847 2855
to to 5777 3071	5010 5020 5030 5040 5050	2560 2568 2576 2584 2592 2600	2561 2569 2577 2585 2593 2601	2562 2570 2578 2586 2594 2602	2563 2571 2579 2587 2587 2595 2603	2564 2572 2580 2588 2596 2604	2565 2573 2581 2589 2597 2605	2566 2574 2582 2590 2598 2606	2567 2575 2583 2591 2599 2607		5410 5420 5430 5440 5450	2816 2824 2832 2840 2848 2856	2817 2825 2833 2641 2849 2857	2818 2825 2834 2842 2850 2858	2819 2827 2835 2843 2851 2859	2820 2828 2836 2844 2852 2860	2821 2829 2837 2845 2853 2861	2822 2930 2838 2846 2854 2862	2823 2831 2839 2847 2855 2863
to to 5777 3071	5010 5020 5030 5040 5050 5060	2560 2568 2576 2584 2592 2600 2608	2561 2569 2577 2585 2593 2601 2609	2562 2570 2578 2578 2586 2594 2602 2610	2563 2571 2579 2587 2595 2603 2611	2564 2572 2580 2588 2596 2604 2612	2565 2573 2581 2589 2597 2605 2613	2566 2574 2582 2590 2598 2606 2614	2567 2575 2583 2591 2599 2607 2615		5410 5420 5430 5440 5450 5460	2816 2824 2832 2840 2848 2856 2864	2817 2825 2833 2641 2849 2857 2865	2818 2825 2834 2842 2850 2858 2866	2819 2827 2835 2843 2851 2859 2867	2820 2828 2836 2844 2852 2860 2868	2821 2829 2837 2845 2853 2861 2869	2822 2830 2838 2846 2854 2862 2870	2823 2831 2839 2847 2855 2863
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070	2560 2568 2576 2584 2592 2600 2608 2616	2561 2569 2577 2585 2593 2601 2609 2617	2562 2570 2578 2586 2594 2602 2610 2618	2563 2571 2579 2587 2587 2595 2603 2611 2619	2564 2572 2580 2588 2596 2604 2612 2620	2565 2573 2581 2589 2597 2605 2613 2621	2566 2574 2582 2590 2598 2606 2614 2622	2567 2575 2583 2591 2599 2607 2615 2623		5410 5420 5430 5440 5450 5460 5470	2816 2824 2832 2840 2848 2856 2864 2872	2817 2825 2833 2641 2849 2857 2865 2873	2818 2825 2834 2842 2850 2858 2866 2874	2819 2827 2835 2843 2851 2859 2867 2875	2820 2628 2836 2844 2852 2860 2868 2876	2821 2829 2837 2845 2853 2861 2869 2877	2822 2930 2838 2846 2854 2862 2870 2878	2823 2831 2839 2847 2855 2863 2871 2879
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070	2560 2568 2576 2584 2592 2600 2608 2616	2561 2569 2577 2585 2593 2601 2609 2617	2562 2570 2578 2586 2594 2602 2610 2618	2563 2571 2579 2587 2587 2595 2603 2611 2619	2564 2572 2580 2588 2596 2504 2612 2620	2565 2573 2581 2589 2597 2605 2613 2621	2566 2574 2582 2590 2598 2606 2614 2622 2630	2567 2575 2583 2591 2599 2607 2615 2623		5410 5420 5430 5440 5450 5460 5470 5500 5510	2816 2824 2832 2840 2848 2856 2864 2872 2880 2888	2817 2825 2833 2641 2849 2857 2865 2873 2881 2889	2818 2825 2834 2842 2850 2858 2866 2874 2882 2890	2819 2827 2835 2843 2851 2859 2867 2875 2883 2891	2820 2828 2836 2844 2852 2860 2868 2876 2884 2892	2821 2829 2837 2845 2853 2861 2869 2877 2885 2893	2822 2830 2838 2846 2854 2862 2870 2878 2866 2894	2823 2831 2839 2847 2855 2863 2871 2879 2887 2895
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5100 5110	2568 2576 2584 2592 2600 2608 2616 2624 2632	2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641	2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2642	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643	2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644	2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645	2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2646	2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647		5410 5420 5430 5440 5450 5470 5500 5510 5520	2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896	2817 2825 2833 2641 2849 2857 2865 2873 2881 2889 2897	2818 2825 2834 2834 2850 2858 2866 2874 2882 2890 2898	2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2899	2820 2828 2836 2844 2852 2860 2868 2376 2884 2892 2900	2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901	2822 2830 2838 2846 2854 2862 2870 2878 2866 2894 2902	2823 2831 2839 2847 2855 2863 2871 2879 2887 2895 2903
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5100 5110 5120	2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2640 2648	2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649	2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2642 2650	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 2651	2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2652	2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653	2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2648 2654	2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655		5410 5420 5430 5440 5450 5460 5470 5500 5510 5520 5530	2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904	2817 2825 2833 2641 2849 2857 2865 2873 2881 2889 2897 2905	2818 2825 2834 2834 2850 2858 2866 2874 2882 2890 2898 2906	2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2899 2907	2820 2628 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908	2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909	2822 2830 2838 2846 2854 2862 2870 2878 2886 2894 2902 2910	2823 2831 2839 2847 2855 2863 2871 2879 2887 2895 2903 2911
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5100 5110 5120 5130	2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2640 2648 26564	2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2655	2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2642 2650 2656 2666	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 2651 2659 2667	2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2652 2660 2668	2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669	2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2646 2654 2662 2670	2567 2575 2583 2591 2599 2607 2615 2623 2631 2639 2647 2655 2663 2671		5410 5420 5430 5440 5450 5460 5470 5500 5510 5520 5530 5540	2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904 2912 2920	2817 2825 2833 2641 2849 2857 2865 2873 2881 2881 2897 2905 2913 2921	2818 2826 2834 2842 2850 2858 2866 2874 2882 2890 2898 2906 2914 2922	2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2899 2907 2915 2923	2820 2828 2836 2844 2852 2860 2868 2876 2884 2892 2900 2908 2916 2924	2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925	2822 2830 2838 2846 2854 2862 2870 2878 2866 2894 2902 2910 2918 2925	2823 2831 2839 2847 2855 2863 2871 2879 2887 2895 2903 2911 2919 2927
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5110 5120 5130 5140 5150 5160	2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2640 2648 2656 2664 2672	2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2665 2673	2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2642 2658 2658 2666 2674	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 26519 2657 2667 2675	2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2650 2660 2668 2676	2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669 2677	2566 2574 2582 2590 2598 2606 2614 2622 2630 2634 2654 2654 2654 2670 2678	2567 2575 2583 2591 2599 2607 2615 2623 2631 2631 2631 2637 2655 2663 2671 2679		5410 5420 5430 5440 5450 5460 5470 5510 5520 5530 5540 5550 5560	2816 2824 2832 2840 2848 2856 2864 2872 2888 2896 2904 2912 2920 2928	2817 2825 2833 2641 2849 2857 2865 2873 2881 2897 2905 2913 2921 2929	2818 2825 2834 2842 2850 2858 2866 2874 2882 2898 2906 2914 2912 2930	2819 2827 2835 2843 2851 2859 2867 2875 2883 2899 2907 2915 2923 2931	2820 2828 2836 2844 2852 2860 2868 2876 2884 2890 2908 2908 2916 2924 2932	2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2901 2901 2925 2933	2822 2830 2838 2846 2854 2862 2870 2878 2866 2894 2902 2910 2918 2925 2934	2823 2831 2839 2847 2855 2863 2871 2879 2887 2895 2903 2911 2919 2927 2935
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5110 5120 5130 5140 5150 5160	2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2640 2648 2656 2664 2672	2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2665 2673	2562 2570 2578 2586 2594 2602 2610 2618 2626 2634 2642 2650 2656 2666	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 26519 2657 2667 2675	2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2650 2660 2668 2676	2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2645 2653 2661 2669 2677	2566 2574 2582 2590 2598 2606 2614 2622 2630 2634 2654 2654 2654 2670 2678	2567 2575 2583 2591 2599 2607 2615 2623 2631 2631 2631 2637 2655 2663 2671 2679		5410 5420 5430 5440 5450 5460 5470 5510 5520 5530 5540 5550 5570	2816 2824 2832 2840 2848 2856 2864 2872 2880 2888 2896 2904 2912 2920 2928 2936	2817 2825 2633 2641 2849 2857 2865 2873 2881 2889 2897 2905 2913 2921 2929 2937	2818 2825 2834 2842 2850 2858 2866 2874 2882 2890 2898 2906 2914 2922 2930 2938	2819 2827 2835 2843 2859 28675 2887 2891 2899 2907 2915 2923 2939	2820 2828 2836 2844 2860 2868 2876 2892 2900 2908 2916 2924 2932 2940	2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925 2933 2941	2822 2830 2838 2846 2854 2862 2870 2878 2886 2894 2902 2910 2918 2925 2934 2942	2823 2831 2839 2845 2855 2863 2871 2879 2895 2895 2911 2919 2927 2935 2943
to to 5777 3071	5010 5020 5030 5040 5050 5060 5100 5110 5120 5130 5140 5170	2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2648 2656 2664 2672 2880 2688	2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2649 2657 2665 2673 2681 2689	2562 2578 2578 2584 2602 2610 2618 2626 2634 2650 2658 2666 2674 2682 2690	2563 2571 2579 2587 2587 2603 2611 2619 2627 2634 2651 2659 2667 2683 2681	2564 2572 2580 2588 2596 2604 2612 2620 2628 2636 2644 2652 2660 2668 2676 2684 2692	2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2653 2661 2669 2677 2685	2566 2574 2582 2590 2690 2614 2622 2630 2638 2634 2654 2654 2654 2654 2654 2654 2654 265	2567 2575 2583 2591 2607 2615 2623 2631 2631 2631 2631 2655 2663 2671 2679 2687		5410 5420 5430 5440 5450 5460 5470 5510 5520 5530 5540 5550 5570	2816 2824 2832 2840 2848 2856 2864 2872 2880 2890 2904 2912 2928 2936	2817 2825 2833 2641 2849 2857 2865 2873 2881 2889 2905 2913 2921 2929 2937	2818 2826 2834 2842 2858 2858 2866 2874 2892 2996 2914 2922 2938 2946	2819 2827 2835 2843 2859 2867 2875 2883 2899 2907 2915 2923 2931 2939 2947	2820 2828 2836 2844 2860 2868 2876 2884 2890 2908 2918 2924 2932 2940 2948	2821 2829 2837 2845 2853 2861 2869 2877 2885 2893 2909 2917 2925 2933 2941 2949	2822 2930 2838 2846 2854 2862 2970 2878 2886 2894 2990 2918 2925 2934 2942	2823 2831 2839 2845 2855 2863 2871 2879 2895 2895 2911 2919 2927 2935 2943
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5110 5120 5130 5140 5150 5170	2560 2568 2576 2576 2592 2600 2608 2616 2624 2632 2640 2648 26564 2672 2680 2688	2561 2569 2577 2585 2601 2609 2617 2625 2633 2649 2657 2665 2673 2681 2689 2697	2562 2570 2578 2578 2594 2602 2610 2618 2626 2634 2642 2658 2658 2674 2682 2690 2698	2563 2571 2579 25875 2603 2611 2619 26343 2659 2667 2667 2667 2683 2691 2699	2564 2572 2580 2588 2596 2604 2612 2620 2636 2636 2636 2676 2684 2692 2700	2565 2573 2581 2589 2597 2605 2613 2621 2629 2637 2661 2669 2677 2685 2693 2701	2566 2574 2582 2590 2598 2606 2614 2622 2630 2638 2654 2654 2654 2670 2678 2686 2694 2702	2567 2575 2583 2591 2593 2607 2615 2623 2631 2639 2631 2671 2655 2663 2671 2679 2687 2695 2695 2703		5410 5420 5430 5440 5450 5460 5470 5510 5520 5530 5550 5550 5570 5600 5620	2816 2824 2832 2848 2856 2864 2872 2880 2888 2896 2904 2912 2928 2936 2944 2950 2950	2817 2823 2833 2641 2849 2857 2865 2873 2881 2889 2897 2905 2913 2929 2937 2945 2951	2818 2826 2834 2850 2858 2866 2874 2882 2890 2898 2906 2914 29230 2938 2958 2958	2819 2827 2835 2843 2851 2859 2867 2875 2883 2891 2899 2907 2915 2931 2939 2947 2953	2820 2628 2836 2836 2852 2860 2868 2376 2884 2892 2900 2908 2918 2932 2940 2948 29564	282! 2829 2837 28453 2861 2869 2877 2885 2991 2909 2917 2933 2941 2949 2949 2955	2822 2830 2838 2854 2854 2862 2870 2878 2886 2894 2902 2910 2918 2925 2934 2942 2950 2958 2966	2823 2831 2831 2832 2855 2863 2871 2879 2887 2895 2903 2911 2915 2913 2913 2913 2915 2951 2951 2951 2951 2951 2951 2951
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5110 5120 5130 5150 5150 5170 5220 5230	2560 2568 2576 2584 2592 2600 2608 2616 2624 2632 2648 2656 2664 2672 2680 2688 2696 2712	2561 2569 2577 2585 2593 2601 2609 2617 2625 2649 2657 2665 2673 2681 2689 2713	2562 2570 2578 2578 2594 2602 2618 2626 2634 2650 2658 2656 2674 2682 2698 2714	2563 2571 2579 2587 2587 2587 2587 2619 2627 2635 2643 2659 2657 2657 2683 2691 2692 2692 2707 2715	2564 2572 2580 2580 2596 2604 2612 2620 2628 2636 2644 2652 2660 2676 2684 2692 2708 27708 2716	2565 2573 2581 2581 2597 2605 2613 2621 2629 2637 2645 2653 2661 2667 2685 2693 2709 2717	2566 2574 2582 2598 2606 2614 2622 2638 2646 2662 2678 2662 2710 2710 2710	2567 2575 2583 25991 2607 2615 2623 2631 2639 2647 2653 2663 2679 2687 2679 2687 2695 2711 2719		5410 5420 5430 5440 5450 5460 5470 5510 5520 5530 5530 5550 5570 5600 5610 5630	2816 2824 2832 2840 2848 2856 2864 2872 2880 2896 2912 2928 2912 2928 2936 2956	2817 2825 2833 2641 2849 2857 2865 2873 2881 2889 2897 2905 2913 2921 2929 2937 2945 2953 2961 2961	2818 2826 2834 2834 2850 2858 2866 2874 2882 2890 2898 2914 2922 2930 2938 2954 2956 2957	2819 2827 2835 2843 2851 2859 2867 2875 2883 2899 2915 2923 2931 2939 2947 2955 2951	2820 2628 2836 2844 2852 2860 2868 2876 2884 2892 29008 2918 2924 2932 2940 2948 2956 2956 2957	2821 2829 2837 2853 2861 2869 2877 2885 2991 2909 2917 2923 2941 2949 2957 2957 2965 2973	2822 2930 2838 2846 2854 2862 2870 2878 2866 2894 2900 2918 2925 2934 2950 2958 2958 29574	2823 2831 2832 2832 2855 2863 2879 2887 2891 2991 2913 2913 2913 2913 2959 2959 2959 2975
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5110 5120 5130 5140 5150 5170 5210 5220 5230 5240	2560 2568 2576 2584 2592 2608 2616 2624 2632 2648 2656 2664 2672 2888 2596 2704 2712 2712 2712	2561 2569 2569 2577 2585 2593 2601 2609 2617 2625 2633 2649 2657 2665 2673 2681 2689 2703 2703 2703 2713 2721	2562 2578 2578 2594 2602 2618 2626 2636 2642 2658 2666 2674 2682 2698 2706 2714 2712	2563 2579 2579 2587 2595 2603 2611 2619 2627 2635 2659 2667 2675 2683 2691 2699 2707 2715 2715 2712	2564 2572 2588 2596 2604 2612 2620 2628 2636 2636 2644 2656 2668 2676 2676 2700 2700 2702 2716 27124	2565 2573 2581 2581 2597 2605 2613 2621 2629 2637 2645 2661 2669 2677 2685 2701 2707 2717 2717 2717	2566 2574 2582 2592 2598 2606 2614 2622 2630 2638 2654 2662 2670 2678 2686 2702 2718 2726	2567 2575 2583 2591 2599 2607 2613 2623 2631 2631 2639 2647 2655 2663 2671 2679 2687 2703 2711 2719 2719		5410 5420 5430 5440 5450 5460 5470 5500 5520 5530 5540 5550 5560 5630 5630 5630	2814 2824 2832 2840 2848 2856 2864 2872 2880 2992 2912 2920 2928 2936 2944 2952 2968 2976	2817 2825 2833 2641 2849 2857 2865 2873 2881 2897 2993 2921 2929 2937 2945 2953 2961 2961 2967 2967	2818 2826 2834 2834 2850 2858 2866 2874 2892 2930 2938 2938 2946 2954 2952 2970 2978	2819 2827 2835 2843 2851 2859 2875 2899 29915 2923 2931 2939 2947 2955 2967 2979	2820 2828 2836 2844 2852 2866 2876 2884 2976 2908 2918 2924 2932 2940 2948 2956 2956 2964 2978	2821 2829 2837 2846 2853 2861 2869 2877 2885 2901 2917 2925 2933 2941 2949 2957 2965 2967 2968 2973 2981	2822 2930 2838 2846 2854 2862 2870 2878 2866 2894 2900 2918 2925 2934 2950 2958 2958 29574	2823 2831 2831 2832 2855 2863 2871 2879 2887 2895 2903 2911 2915 2913 2913 2913 2915 2951 2951 2951 2951 2951 2951 2951
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5110 5120 5130 5140 5150 5170 5200 5210 5220 5220 5220 5240 5240	2560 2568 2578 2584 2592 2600 2608 2616 2624 2632 2640 2656 2664 2672 2880 2704 27704 27704 27704 27704 27704 27704 27704 27736	2561 2569 2577 2585 2593 2609 2617 2625 2633 2641 2649 2657 2665 2673 2681 2729 2713 2721 2722 2737	2562 2578 2578 2578 2594 2594 2610 2618 2626 2634 2642 2658 2666 2674 2682 2890 2714 2722 2730	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2651 2657 2667 2667 2699 2707 2715 2723 2731 2731 2731	2564 2562 2588 2596 2596 2596 2612 2620 2628 2636 2636 2636 2636 2636 2676 2724 2724 2732 2732 2732	2565 2573 2581 2589 2597 2605 2613 2621 2637 2645 2653 2661 2669 2677 2685 2701 2705 2717 2725 2733 2731	2566 2574 2582 2590 2598 2614 2622 2638 2638 2634 2654 2662 2702 2710 2718 2726 2712 2734 2734	25677 25752 2583 25931 25999 26077 26155 2623 2631 2639 2639 26677 26695 2707 2711 2719 27177 2719 27277 2735 2743		5410 5420 5430 5440 5440 5440 5510 5520 5520 5530 5540 5570 5620 5620 5630 5640 5650 5650 5650 5650	2816 2824 2832 2840 2852 2852 2864 2872 2888 2994 2912 2920 2928 2936 2936 2944 2952 2952 2958 2958 2958 2958 2958 2958	2817 2825 2833 2641 2849 2857 2865 2873 2895 2995 2995 2995 2921 2922 2937 2945 2953 2953 2953 2953 2953 2953 2953 295	2818 2826 2834 2842 2850 2858 2866 2874 2890 2914 2922 2930 2930 2946 2954 2954 2954 2958 2970 2978	2819 2827 2835 2843 2851 2859 2867 2875 2893 2997 2915 2923 2931 2939 2947 2955 2957 2957 2957 2957 2957 2957 295	2820 2828 2836 2844 2852 2860 2868 2972 2990 2998 2994 2932 2940 2940 2944 2955 2964 2972 2988 2998 2998	2821 2829 2837 2845 2853 2861 2869 2877 2989 2917 2925 2933 2941 2949 2957 2989 2989 2997	2822 2830 2838 2846 2854 2862 2870 2878 2992 2910 2925 2934 2942 2950 2958 2958 2954 2966 2974 2962 2998	2823 2839 2847 2855 2879 2879 2887 2993 2919 2927 2919 2927 2915 2943 2959 2959 2959 2959 2959 2959 2959 295
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5110 5120 5130 5140 5150 5170 5210 5220 5230 5240	2560 2568 2578 2584 2592 2600 2608 2616 2624 2632 2640 2656 2664 2672 2880 2704 27704 27704 27704 27704 27704 27704 27704 27736	2561 2569 2577 2585 2593 2609 2617 2625 2633 2641 2649 2657 2665 2673 2681 2729 2713 2721 2722 2737	2562 2578 2578 2594 2602 2618 2626 2636 2642 2658 2666 2674 2682 2698 2706 2714 2712	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2651 2657 2667 2667 2699 2707 2715 2723 2731 2731 2731	2564 2562 2588 2596 2596 2596 2612 2620 2628 2636 2636 2636 2636 2636 2676 2724 2724 2732 2732 2732	2565 2573 2581 2589 2597 2605 2613 2621 2637 2645 2653 2661 2669 2677 2685 2701 2705 2717 2725 2733 2731	2566 2574 2582 2590 2598 2614 2622 2638 2638 2634 2654 2662 2702 2710 2718 2726 2712 2734 2734	25677 25752 2583 25931 25999 26077 26155 2623 2631 2639 2639 26677 26695 2707 2711 2719 27177 2719 27277 2735 2743		5410 5420 5430 5440 5440 5440 5510 5520 5520 5530 5540 5570 5620 5620 5630 5640 5650 5650 5650 5650	2816 2824 2832 2840 2852 2852 2864 2872 2888 2994 2912 2920 2928 2936 2936 2944 2952 2952 2958 2958 2958 2958 2958 2958	2817 2825 2833 2641 2849 2857 2865 2873 2895 2995 2995 2995 2921 2922 2937 2945 2953 2953 2953 2953 2953 2953 2953 295	2818 2826 2834 2850 2850 2866 2874 2892 2890 2914 2922 2930 2930 2946 2954 2954 2954 2954 2954 2954 2954 2954	2819 2827 2835 2843 2851 2867 2875 2883 2891 2923 2923 2939 2939 2947 2955 2987 2987 2995 2987 2995 2997 2997 2997 2997	2820 2836 2844 2852 2860 2868 2876 2892 2900 2918 2924 2932 2932 2940 2948 2956 2964 2972 2988 2996 3004	282! 2829 2837 2845 2853 2851 2869 2877 2985 2917 2925 2933 2949 2957 2957 2965 2973 2989 2997 3005	2822 2830 2838 2846 2854 2870 2878 2902 2910 2918 2925 2934 2934 2950 2958 2959 2998 2998 2998 2998 2998	2823 2839 2847 2853 2871 2872 2887 2895 2905 2911 2917 2927 2935 2943 2959 2959 2959 2959 2959 2997 2995 2997 2995 2997 2995
to to 5777 3071	5010 5020 5040 5050 5060 5070 5100 5110 5120 5130 5140 5170 5220 5220 5220 5220 5220 5220 5220 52	2560 2568 2576 2592 2692 2692 2616 2624 2640 2648 2652 2888 2696 2704 2712 2712 2712 2712 2712 2712 2714	2561 2569 2577 2585 2593 2601 2609 2617 2625 2633 2641 2697 2665 2673 2681 2682 2705 2713 2721 2727 2727 2737 2737 2737	2562 2570 2578 2586 2602 2618 26264 2636 2642 2650 2658 2674 2682 2796 2796 2714 2722 2738 2746	2563 2571 2579 2587 2595 2603 2611 2619 2627 2635 2643 2659 2675 2683 2699 2707 2715 2723 2731 2731 2731 2731 2731 2731 2735	2564 2572 2580 2588 2596 2612 2620 2628 2636 2644 2650 2676 2676 2724 27700 2716 2724 2732 2732 2732 2732 2734 2756	2565 2573 2581 2582 2597 2695 2613 2621 2643 2653 2653 2653 2653 2701 2702 2717 2725 2733 2741 2749	2566 2574 2582 2590 2696 2614 2622 2630 2638 2645 2645 2672 2710 2718 2726 2710 2718 2726 2734 2734 2750 2758	2567 2575- 25783 25991 25999 2697- 2615- 2623 2631- 2631- 2645- 2655- 2655- 2687- 2687- 2793- 27		5410 5420 5430 5440 5450 5510 5510 5510 5530 5540 5550 5550 5570 5600 5620 5630 5640 5650 5650 5650 5650 5650 5650 565	2816 2824 2832 2840 2848 2856 2856 2864 2912 2920 2928 2936 2952 2952 2952 2952 2952 2952 2952 295	2817 2825 2833 2641 2849 2857 2865 2873 2881 2925 2913 2921 2929 2937 2945 2953 2961 2979 2979 2979 2970 2970 2970 2970 2970	2818 2826 2834 2834 2858 2866 2874 2882 2890 2914 3922 2930 2938 2945 2954 2970 2978 2978 2970 2978 2986 2994 3002	2819 2819 2827 2835 2843 2859 2867 2875 2883 2991 2915 2923 2939 2947 2955 2953 2971 2979 2997 2997 2997 2997 2997 2997	2820 2836 2844 2852 2860 2868 2876 2908 2918 2990 2948 2956 2964 2972 2980 2980 2996 3004	282; 2829 2837 2845 2853 2869 2877 2885 2893 2901 2917 2925 2933 2941 2949 2957 2985 2987 3005	2822 2830 2838 2846 2854 2862 2970 2918 2925 2934 2942 2950 2958 2966 2974 2962 2998 3006	2823 2838 2847 2858 2879 2879 2887 2897 2993 2911 2919 2927 2935 2943 2951 2958 2957 2958 2967 2975 2983 2999 3007
to to 5777 3071	5010 5020 5030 5040 5050 5060 5100 5110 5130 5140 5150 5200 5220 5220 5220 5220 5220 522	2560 2568 2576 2582 2692 2692 2616 2642 2640 2648 2656 2648 2672 2880 2704 2712 2712 2712 2712 2712 2712 2712 271	2561 2569 2577 2585 2609 2617 2625 2633 2649 2657 2663 2663 2705 2705 2713 2713 2721 2727 2737 2745 2753 2761	2562 2570 2578 2578 25962 2562 2618 2626 2634 2656 2658 2666 2658 2664 2658 2664 2754 2714 2714 2714 2714 2714 2714	2563 2571 2579 2587 2587 2583 2611 2619 2627 2633 2651 2659 2663 2657 2659 2707 2715 2715 2715 2715 2715 2715 2715 271	2564 2572 2580 2588 2564 2612 2620 2628 2632 2632 2644 2632 2660 2660 2708 27700 2700 2718 2714 2732 2740 2734 2748 2748 2756	2565 2573 2581 2589 2597 2697 2613 2621 2629 2637 2645 2653 2761 2709 2717 2717 2717 2717 2717 2717 2717 271	2566 2574 2582 2590 2598 2614 2622 2638 2638 2648 2654 2662 2278 2678 2734 2732 2730 2732 2732 2732 2732 2732 2732	2567 2575 2575 2599 2599 2599 2607 2615 2623 2631 2637 2647 2655 2663 2871 2871 2872 2735 2711 2727 2735 2737 2737 2737 2737 2737 2737		5410 5420 5430 5450 5460 5500 5510 5520 5530 5550 5550 5550 5550 560 5630 5630	2816 2824 2832 2840 2856 2864 2872 2880 2912 2912 2912 2928 2936 2944 2952 2968 2976 2988 2976 2988 3000 3008	2817 2825 2833 2641 2857 2865 2873 2881 2897 2905 2913 2929 2937 2945 2959 2977 2985 2977 2977 2977 2977 2977 2977 2977 297	2818 2818 2825 2834 2850 2850 2850 2850 2866 2914 2922 2930 2933 2946 2954 2954 2954 2954 2954 2954 2954 2954	2819 2827 2835 2843 2859 2867 2875 2889 2907 2915 2923 2931 2939 2947 2955 2967 2979 2987 2995 3003 3011 3019	2820 2836 2844 2852 2860 2868 2876 2990 2918 2924 2932 2932 2940 2956 2956 2958 3004 3012 3020	282! 2829 2837 2846 2853 2861 2869 2877 2885 2893 2901 2909 2917 2925 2933 2941 2949 2957 2969 2987 2983 2981 2989 2997 3005 3013 3021	2822 2830 2838 2846 2854 2862 2870 2878 2992 2910 2942 2942 2942 2950 2950 2966 2974 2962 2974 2992 3006 3014 3030	2823 2839 2847 2863 2874 2879 28875 29903 2911 2912 2927 2935 2943 2951 2959 2959 2959 3007 3015 30031
to to 5777 3071	5010 5020 5040 5050 5060 5070 5110 5120 5130 5140 5150 5210 5220 5230 5240 5220 5250 5250 5250 5250 5310 5320 5320 5320 5320 5320 5320 5320 532	2560 2568 2576 2592 2600 2608 2616 2642 2648 2656 2664 2880 2880 2888 2704 2712 2712 2720 2728 2736 2744	2561 2569 2577 2585 2601 2609 2617 2623 2641 2649 2657 2673 2681 2729 2705 2713 2721 2727 2737 2745 2753 2761 2753 2761 2753 2761 2753	2562 2570 2578 2594 2602 2618 2634 2642 2650 2658 2666 2678 2714 2722 2738 2746 27746 27762 27762 27762	2563 2571 2579 2587 2687 2603 2611 2619 2627 2643 2651 2659 2643 2655 2883 2891 2707 2715 2723 2731 2731 2732 2731 2732 2731 2732 2731 2732 2732	2564 2572 2580 2588 2504 2612 2620 2628 2636 2636 2636 2636 2636 2636 2708 2716 2718 2718 2718 2718 2718 2718 2718 2718	2565 2573 2581 2589 2605 2613 2621 2629 2637 2653 2661 2685 2709 2717 2725 2733 2741 2749 2757 2765 2773 2781	2566 2574 2582 2590 2606 2614 2622 2630 2638 2654 2662 2678 2678 2710 2710 2710 2714 2724 2750 2742 2750 2758 2766 2774 2774 2774 2774 2774 2774 2775	2567 2575 2583 2591 2697 2615 2623 2631 2631 2632 2647 2655 2663 2687 2707 2711 2719 2727 2711 2719 2751 2751 2751 2751 2751 2753 2753 2753 2753 2753 2753 2753 2753		5410 5420 5430 5440 5450 5500 5510 5520 5530 5550 5560 5570 5600 5610 5620 5630 5650 5650 5650 5650 5650 5650 565	2816 2824 2832 2840 2856 2856 2864 2912 2920 2928 2936 2944 2952 2968 2968 2978 2968 2978 2968 2978 2968 2978 2978 2978 2978 2978 2978 2978 297	2817 2825 2833 2841 2857 2865 2897 2905 2991 2991 2929 2937 2945 2953 2969 2977 2985 2987 2987 2987 3006 3017 3025 3033	2818 2818 2826 2834 2834 2836 2858 2866 2974 2890 2914 2952 2930 2938 2952 2952 2952 2958 2952 2952 2953 2953 2953 2953 2953 2954 3002 3018 3018 3034	2819 2819 2827 2835 2843 2859 2867 2875 2883 2899 2907 2915 2931 2939 2947 2953 2971 2979 2979 2979 3003	2820 2828 2836 2844 2846 2868 2860 2868 2972 2908 2918 2924 2932 2940 2948 2956 3004 3012 3020 3036	282! 2829 2837 2845 2853 2861 2869 2877 2885 2991 2909 2917 2909 2917 2933 2941 2957 2965 2973 2981 2997 3005	2822 2830 2838 2846 2846 2870 2878 2884 2992 2910 2912 2925 2934 2942 2950 2950 2950 2950 2966 2974 2992 3006 3014 3022 3030 3030	2823 2839 2847 2847 2863 2871 2887 2903 2913 2927 2927 2943 2959 2959 2959 2959 2959 3007 3015 3023 3031 3031
to to 5777 3071	5010 5020 5050 5050 5050 5050 5050 5050	2560 2568 2576 2592 2600 2608 2616 2632 2640 2656 2664 2872 2880 2886 2704 2712 2728 2728 2728 2736 2744 2728 2736 2768 2776	25619 25747 2585 2593 2601 2609 2617 2625 2633 2641 2649 2657 2665 2673 2681 2682 2727 2727 2737 2745 2753 27745 2753 2759 2759 2759 2759 2759 2759 2759 2759	2562 257D 2578 2588 2594 2602 2618 2626 2618 2626 2650 2650 2674 2682 2706 2714 2730 2730 2730 2746 2756 2776 2776 2776 2776 2778	2563 2571 2579 2587 2603 2619 2627 2635 2643 2651 2672 2673 2673 2673 2773 2733 2733 2733	2564 2572 2580 2588 2604 2612 2620 2628 2632 2632 2632 2674 2772 27748 27748 27754 27772 27782 27782	2565 2573 2581 2587 2587 2697 2605 2613 2621 2629 2637 2645 2653 2661 2709 2717 2785 2733 2741 2749 2757 2773 2749 2757 2773 2789	2566 2574 2582 2590 2696 2614 2622 2630 2642 2654 2654 2654 2670 2712 2710 2712 2712 2712 2714 2715 2716 2716 2716 2716 2718 2718 2718 2718 2718 2718 2718 2718	2567 2575 2575 2583 2599 2607 2613 2639 2647 2655 2663 2671 2679 2687 2791 2792 2797 2793 2793 2793 2793 2793 2793		5410 5420 5430 5440 5450 5450 5520 5520 5530 5540 5550 5550 5550 560 560 560 560 560 560	2816 2824 2832 2848 2856 2868 2872 2880 2992 29936 2994 2994 2995 2996 2998 2996 3008 3008 3008 3008 3008 3008 3008	2817 2825 2833 2841 2857 2857 2867 2873 2995 2997 2913 2921 2929 2937 2945 2993 2995 2993 2995 2993 2995 2993 3001 3009 3017 3025 3034	2818 2818 2826 2834 2842 2858 2866 2874 2892 29964 2922 2930 2945 2962 2970 2986 2994 3002 3010 3026 3034	2819 2819 2827 2835 2843 2859 2867 2875 2883 2939 2907 2915 2923 2931 2939 2947 2953 3003 3011 3019 3027 3033 3043	2820 2828 2836 2844 2852 2860 2938 2936 2930 2932 2940 2932 2940 2932 2940 2932 2940 3036 3036 3036 3036 3044	2821 2829 2837 2845 2853 2861 2869 2877 2901 2909 2917 2925 2933 2941 2949 2949 2949 2949 2949 3003 3013 3021 3029 3043 3043	2822 2830 2838 2846 2862 2870 2878 2902 2918 2925 2936 2942 2990 2998 2996 3006 3014 3022 3030 3046	2823 2838 2839 2847 2855 2863 2867 2895 2903 2911 2912 2927 2927 2935 2943 2951 2959 3007 3013 3013 3031 3047
to to 5777 3071	5010 5020 5030 5040 5050 5060 5070 5120 5120 5150 5170 5220 5230 5240 5250 5250 5250 5250 5250 5250 525	2560 2568 25784 2592 2600 2608 2616 2648 2656 2654 2656 2704 2712 2712 2712 2712 2714 2720 27160	25619 2577 2585 2577 2585 2601 2617 2625 2649 2657 2665 2668 2705 2713 2721 2721 2727 2727 2727 2737 2745 2753 2761 2753 2761 2762 2773 2774 2775 2775 2775 2775 2775 2775 2775	2562 257D 257B 2586 2586 2610 2612 2612 2613 2642 2658 2658 2666 2698 2704 2714 2722 2714 2762 2714 2762 2714 2762 2774	2563 2571 2579 2587 2585 2603 2611 2619 2627 2635 2635 2635 2635 2657 2575 2707 2715 2723 2737 2737 2747 2755 2763 2779 2779 2779 2779 2779 2779 2779 277	2564 2562 2580 2588 2594 2612 2620 2628 2620 2628 2630 2678 2670 2772 2774 2774 2774 2774 2774 2774 27	2565 2573 2581 2589 2609 2603 2613 2621 2653 2653 2653 2701 2709 2717 2725 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2715 2717 2717	2566 2574 2582 2590 2606 2614 2622 2630 2638 2654 2662 2670 2718 2726 2734 2734 2734 2734 2734 2734 2734 2734	2567 2575 2583 2599 2607; 2615 2623 2631 2647 2655 2663 2671 2717 2719 2727 2735 2735 2751 2759 2765 2775 2775 2775 2775 2775 2775 2775		5410 5420 5430 5440 5450 5460 5520 5510 5520 5530 5540 5550 5560 5660 5670 5710 5710 5710 5710 5710 5710 5710	2816 2824 2832 2848 2856 2868 2904 2912 2920 2936 2936 2944 2952 2968 2976 2984 2976 3008 3018 3028 3040 3040 3040 3040 3040	2817 2825 2631 2849 2857 2865 2873 2881 2895 2912 2929 2937 2945 2951 2959 2951 2959 2977 2985 3007 3017 3025 3033 3041 3049	2818 2814 2826 2834 2858 2866 2858 2866 2896 2996 2996 2996 2996 2996 299	2819 2819 2827 2835 2843 2859 2867 2875 2893 2907 2915 2923 2939 2947 2955 2967 2979 3002 3011 3019 3027 3043 3043 3051 3051	2820 2828 2836 2844 2860 2868 2876 2889 2930 2938 2934 2932 2940 2948 2955 3004 3012 3020 3028 3036 3043 3043 3050 3060	282; 282; 2849 2837 2843 2861 2869 2877 2985 2937 2941 2949 2957 2965 2973 2981 2989 2989 2989 3021 3029 3037 3045 3053 3063	2822 2830 2838 2846 2862 2970 2910 2910 2913 2925 2934 2950 2958 3014 3022 3030 3014 3022 3030 3038 3046 3062	2823 2839 2847 2857 2863 2871 2887 2891 2913 2927 2927 2943 2959 2959 2959 2963 2991 3007 3015 3023 3047 3055 3063
to to 5777 3071	5010 5020 5050 5050 5050 5050 5050 5050	2560 2568 2576 2584 2592 2600 2608 2616 2648 2656 2648 2656 2672 2880 2704 2712 2712 2712 2712 2720 2738 2744 2792 2784 2784 2784 2784 2784 2784 2784 278	25619 2577 2585 2593 2601 2609 2607 2649 2657 2665 2705 2705 2705 2713 2721 2721 2727 2727 2727 2727 2727	2562 257D 2578 2586 2594 2602 2618 2626 2634 22650 2658 2674 2682 2714 2722 2730 2718 2742 2778 2778 2778 2778 2778 2778 277	2563 2571 2579 2587 2587 2683 2619 2625 2643 2651 2659 2667 2773 2773 2773 2773 2773 27747 2775 2776 2776 2776 2776 2777 2776 2776	2564 2572 2580 2588 2604 2612 2620 2632 2632 2632 2632 2632 2632 2732 2732	2565 2573 2581 2587 2587 2695 2605 2629 2637 2645 2653 2701 2709 2717 2715 2713 2715 2715 2715 2715 2715 2715 2715 2715	2566 2574 2582 2590 2606 2614 2622 2630 2638 2654 2662 2670 2718 2726 2734 2734 2734 2734 2734 2734 2734 2734	2567 2575 2583 2599 2607 2613 2623 2631 2639 2647 2655 2673 2679 2712 2735 2711 2715 2715 2715 2715 2715 2715 271		5410 5420 5430 5440 5450 5460 5520 5510 5520 5530 5540 5550 5560 5660 5670 5710 5710 5710 5710 5710 5710 5710	2816 2824 2832 2848 2856 2868 2904 2912 2920 2936 2936 2944 2952 2968 2976 2984 2976 3008 3018 3028 3040 3040 3040 3040 3040	2817 2825 2633 2841 2857 2865 2905 2913 2921 2905 2913 2921 2953 2953 2953 2953 2953 2953 2953 2953	2818 2814 2826 2834 2858 2866 2858 2866 2896 2996 2996 2996 2996 2996 299	2819 2819 2827 2835 2843 2859 2867 2875 2893 2907 2915 2923 2939 2947 2955 2967 2979 3002 3011 3019 3027 3043 3043 3051 3051	2820 2828 2836 2844 2860 2868 2876 2889 2930 2938 2934 2932 2940 2948 2955 3004 3012 3020 3028 3036 3043 3043 3050 3060	282; 282; 2849 2837 2843 2861 2869 2877 2985 2937 2941 2949 2957 2965 2973 2981 2989 2989 2989 3021 3029 3037 3045 3053 3063	2822 2830 2838 2846 2862 2970 2910 2910 2913 2925 2934 2950 2958 3014 3022 3030 3014 3022 3030 3038 3046 3062	2823 2839 2847 2857 2863 2871 2887 2891 2913 2927 2927 2943 2959 2959 2959 2963 2991 3007 3015 3023 3047 3055 3063

OCTAL-DECIMAL INTEGER CONVERSION TABLE (continued)

										_											
	0	L L	2	3	4	5	6	7		ſ	ø	1	2	3	4	5	6	7			
$\overline{}$								••••	Γ	5400	3328	3329	3330	3331	3332	3333	3334	3335	6000	1 3072	,
6000	3072		3074	3075	3076	3077	3078 3086	3079 3087					3338					3343	to	to	_
6010 6020	3080	3081 3089	3082 3090	3083	3084 3092	3085 3093		3095			3344		3346	3347	334B	3349	3350	3351	6777		3
6030		3097		3099		3101		3103		6430	3352		3354	3355	3356	3357	3358	3359	(Octa	l) (Decim	ıal)
6040			3106	3107				3111			3360		3362	3383	3384	3365		3367			
6050	3112	3113	3114			3117				6450		3369	3370	3371	3372 3380	3373 3381	3374 3382	3375			
	3120		3122	3123	3124	3125	3126	3127		6460 6470	3376 3384		3378 3386	3379 3387		3389		3391		I Decima	
6070	3128	3129	\$130	21.21	3134	3133	3137	3133	- 1	77.0	5201	Q 400	-,							00 4096 00 8192	
6100	3136	3137	3138	3139	3140	3141	3142	3143	I	6500				3395		3397				0 - 12288	
	3144		3146	3147	3148		3150	3151		6510	3400			3403		3405				0 . 16384	
6120			3154		3156	3157		3159		6520				3411		3413		3415		00 - 20480	
6130		3161	3162			3165		3167		6530 6540				3427		3429		3431		00 - 24576	
6140	3168 3176		3170	3171 3179		3173 3181				6550	3432	3433	3434	3435	3436	3437	3438	3439	7000	00 - 28672	
6160	3184					3189						3441	3442	3443	3444	3445	3446	3447			
	3192		3194			3197			I	6570	3448	3449	3450	3451	3452	3453	3454	3455			
ł									i	:				2450	0.460	2444	2463	3483			
	3200				3204	3205	3206	3207			3456 3464		3458 3466	3459 3467	3460 3468	3461 3469		3471			
	3208		3210 3218		3212	3213 3221	3214	3215		6620	3472		3474	3475	3476	3477		3479			
	3216 3224		3218		3228	3229	3230	3231		6630	3480	3481	3482	3483	34B4	3485	3496	3487			
	3232		3234		3236	3237	3238	3239		8640	3488	3489	3490	3491	3492	3493	3494	3495			
6250	3240	3241	3242	3243	3244	3245	3248	3247		6650		3497		3499	3500	3501					
	3248		3250	3251	3252	3253		3255		6660		3505		3507 3515		3509 3517		3519			
6270	3256	3257	3258	3259	3260	3261	3262	3263		6870	3212	3513	3314	2212	4316	2011	2314	4413			
4200	2001	2265	3266	3267	3268	3269	3270	3271		6700	3520	3521	3522	3523	3524	3525	3526	3527			
6300	3284 3272		3274	3275	3276	3277		3279		6710	3528		3530	3531	3532	3533	3534	3535			
	3280		3282			3285		3287		6720	3536		3538	3539	3540	3541	3542	3543			
	3288		3290	3291		3293		3295		6730	3544		3546	3547		3549	3550	3551 3559			
6340	3296	3297	3298	3299	3300		3302	3303		6740	3552		3554	3555 3563		3557 3565	3558 3566	3567			
	3304	3305	3306	3307	3308	3309	3310	3311 3319		6760	3568	3561 3569	3570			3573		3575			
	3312 3320	3313	3314	3315	3334	3317 3325	3326	3327		6770	3576	3577	3578	3579		3581	3582				
0310	3340	DULI		0020	444.		V														
																	 -		1		
			2	3	4	5	6	7			0	1	2	3	4	5	6	7			
	0	1	2	3							_								700	10 + 358	34
7000	0 3584	3585	3586	3587	3588	3589	3590	3591		7400	3840	3841	3842	3843	3844	3845	3846	3847	700 to	to	,
7010	3584 3592	3585 3593	3586 3594	3587 3595	3588 3596	3589 3597	3590 3598	3591 3599		7410	3840 3848	3841 3849	3842 3850	3843 3851	3844 3852	3845 3853	3846 3854	3847 3855 3863	777	to 409	95
7010 7020	3584 3592 3600	3585 3593 3601	3586 3594 3602	3587 3595 3603	3588 3596 3604	3589 3597 3605	3590 3598 3608	3591			3840 3848 3856	3841 3849 3857	3842 3850 3858 3868	3843 3851 3859 3867	3844 3852 3860 3868	3845 3853 3861 3869	3846 3854 3862 3870	3847 3855 3853 3871	to	to 409	95
7010 7020 7030	3584 3592 3600 3600	3585 3593 3601 3609	3586 3594 3602 3810	3587 3595 3603 3611	3588 3596 3604	3589 3597 3605 3613	3590 3598 3608 3614 3622	3591 3599 3607 3615 3623		7410 7420 7430 7440	3840 3848 3856 3864 3872	3841 3849 3857 3865 3873	3842 3850 3858 3868 3874	3843 3851 3859 3867 3875	3844 3852 3860 3868 3876	3845 3853 3861 3869 3877	3846 3854 3862 3870 3878	3847 3855 3863 3871 3879	777	to 409	95
7010 7020 7030 7040	3584 3592 3600 3608 3616 3624	3585 3593 3601 3609 3617 3625	3586 3594 3602 3610 3618 3826	3587 3595 3603 3611 3619 3627	3588 3596 3604 3612 3620 3628	3589 3597 3605 3613 3621 3629	3590 3598 3608 3614 3622 3630	3591 3599 3607 3615 3623 3631		7410 7420 7430 7440 7450	3840 3848 3856 3864 3872 3880	3841 3849 3857 3865 3873 3881	3842 3850 3858 3868 3874 3882	3843 3851 3859 3867 3875 3883	3844 3852 3860 3868 3876 3884	3845 3853 3861 3869 3877 3885	3846 3854 3862 3870 3878 3886	3847 3855 3863 3871 3879 3887	777	to 409	95
7010 7020 7030	3584 3592 3600 3608 3616 3624 3632	3585 3593 3601 3609 3617 3625 3633	3586 3594 3602 3610 3618 3626 3634	3587 3595 3603 3611 3619 3627 3635	3588 3596 3604 3612 3620 3628 3636	3589 3597 3605 3613 3621 3629 3637	3590 3598 3608 3614 3622 3630 3638	3591 3599 3607 3615 3623 3631 3639		7410 7420 7430 7440 7450 7460	3840 3848 3856 3864 3872 3880 3888	3841 3849 3857 3865 3873 3881 3889	3842 3850 3858 3868 3874 3882 3896	3843 3851 3859 3857 3875 3883 3891	3844 3852 3860 3868 3876 3884 3892	3845 3853 3861 3869 3877 3885 3893	3846 3854 3862 3870 3878 3886 3894	3847 3855 3863 3871 3879 3887 3895	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050	3584 3592 3600 3608 3616 3624 3632	3585 3593 3601 3609 3617 3625	3586 3594 3602 3610 3618 3626 3634	3587 3595 3603 3611 3619 3627 3635	3588 3596 3604 3612 3620 3628 3636	3589 3597 3605 3613 3621 3629 3637	3590 3598 3608 3614 3622 3630 3638	3591 3599 3607 3615 3623 3631		7410 7420 7430 7440 7450	3840 3848 3856 3864 3872 3880 3888	3841 3849 3857 3865 3873 3881 3889	3842 3850 3858 3868 3874 3882 3896	3843 3851 3859 3857 3875 3883 3891	3844 3852 3860 3868 3876 3884 3892	3845 3853 3861 3869 3877 3885 3893	3846 3854 3862 3870 3878 3886 3894 3902	3847 3855 3863 3871 3879 3887 3895 3903	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7070	3584 3592 3600 3608 3616 3624 3632 3640	3585 3593 3601 3609 3617 3625 3633 3641	3586 3594 3602 3610 3618 3626 3634 3642	3587 3595 3603 3611 3619 3627 3635 3843	3588 3596 3604 3612 3620 3628 3636 3644	3589 3597 3605 3613 3621 3629 3637 3645	3590 3598 3608 3614 3622 3630 3638	3591 3599 3607 3615 3623 3631 3639		7410 7420 7430 7440 7450 7460	3840 3848 3858 3864 3872 3880 3888 3896	3841 3849 3857 3865 3873 3881 3889 3897	3842 3850 3858 3868 3874 3882 3890 3898	3843 3851 3859 3867 3875 3883 3891 3899	3844 3852 3860 3868 3876 3884 3892 3900	3845 3853 3861 3869 3877 3885 3893 3901	3846 3854 3862 3870 3878 3886 3894 3902	3847 3855 3863 3871 3879 3887 3895 3903	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7070	3584 3592 3600 3808 3616 3624 3632 3640	3585 3593 3601 3609 3617 3625 3633 3641 3649	3586 3594 3602 3810 3618 3626 3634 3642	3587 3595 3603 3611 3619 3627 3635 3643	3588 3596 3604 3612 3620 3628 3636 3644	3589 3597 3605 3613 3621 3629 3637 3645 3653	3590 3598 3608 3614 3622 3630 3638 3646	3591 3599 3607 3615 3623 3639 3647 3655 3663		7410 7420 7430 7440 7450 7460 7470 7500 7510	3840 3848 3858 3864 3872 3888 3896 3904 3912	3841 3849 3857 3865 3873 3889 3897 3905 3913	3842 3850 3858 3868 3874 3882 3896 3998	3843 3851 3859 3867 3875 3883 3891 3899	3844 3852 3860 3868 3876 3884 3892 3900 3908	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917	3846 3854 3862 3810 3678 3886 3894 3902 3910 3918	3847 3855 3863 3871 3879 3887 3895 3903	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7070	3584 3592 3600 3608 3616 3624 3632 3640 3656	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665	3586 3594 3602 3610 3618 3626 3634 3642 3650 3658 3666	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667	3588 3596 3604 3612 3620 3628 3636 3644 3652 3660 3668	3589 3597 3605 3613 3621 3629 3637 3645 3653 3661 3669	3598 3598 3608 3614 3622 3630 3638 3646 3554 3862 3670	3591 3599 3607 3615 3623 3631 3639 3647 3655 3663 3671		7410 7420 7430 7440 7450 7460 7470 7500 7510 7520	3840 3848 3856 3864 3872 3880 3896 3896 3904 3912 3920	3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921	3842 3850 3858 3868 3874 3882 3890 3898 3906 3914	3843 3851 3859 3867 3875 3891 3899 3907 3915 3923	3844 3852 3860 3868 3876 3884 3892 3900 3908 3916 3924	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925	3846 3854 3862 3870 3678 3886 3894 3902 3910 3918 3926	3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7070 7100 7110	3584 3592 3600 3608 3616 3624 2632 3640 3658 3658 3664	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673	3586 3594 3602 3618 3618 3626 3634 3642 3658 3658 3666 3674	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3675	3588 3596 3604 3612 3620 3628 3636 3644 3652 3660 3668 3678	3589 3597 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677	3598 3598 3608 3614 3622 3630 3638 3646 3554 3652 3670 3678	3591 3599 3607 3615 3623 3631 3639 3647 3655 3663 3671 3879		7410 7420 7430 7440 7450 7460 7470 7500 7510 7520 7530	3840 3848 3856 3864 3872 3880 3896 3896 3904 3912 3920 3928	3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3929	3842 3850 3858 3868 3874 3882 3890 3898 3914 3972 3930	3843 3851 3859 3867 3875 3891 3899 3907 3915 3923	3844 3852 3860 3868 3876 3884 3892 3900 3916 3924 3932	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933	3846 3854 3862 3870 3678 3886 3894 3902 3910 3918 3926 3934	3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7110 7120 7130 7140	3584 3592 3600 3608 3616 3624 2632 3640 3656 3656 3664 3672 3880	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681	3586 3594 3602 3610 3618 3626 3634 3642 3850 3658 3666 3674 3682	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3675 3683	3588 3596 3604 3612 3620 3636 3644 3652 3660 3668 3678	3589 3597 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677 3685	3590 3598 3608 3614 3622 3630 3638 3646 3654 3662 3670 3678 3686	3591 3599 3607 3615 3623 3631 3639 3647 3655 3663 3671 3679 3687		7410 7420 7430 7440 7450 7460 7470 7500 7510 7520 7530 7540	3840 3848 3856 3864 3872 3880 3896 3896 3904 3912 3920 3928 3936	3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3929 3937	3842 3850 3858 3868 3874 3882 3896 3914 3922 3930 3938	3843 3851 3859 3867 3863 3891 3899 3907 3915 3923 3931	3844 3852 3860 3868 3876 3884 3892 3900 3916 3924 3932 3940	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941	3846 3854 3862 3870 3878 3886 3894 3902 3918 3918 3926 3934	3847, 3855, 3863, 3871, 3879, 3887, 3895, 3903, 3911, 3919, 3927, 3935, 3943,	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7070 7110 7120 7130 7140 7150	3584 3592 3600 3608 3616 3624 2632 3640 3656 3656 3664 3672 3680 3688	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681 3689	3586 3594 3602 3610 3618 3626 3634 3642 3850 3658 3666 3674 3682 3690	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3675 3683 3691	3588 3596 3604 3612 3620 3636 3644 3652 3660 3668 3678 3684 3692	3589 3597 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677 3685 3693	3590 3598 3608 3614 3622 3630 3638 3646 3654 3662 3670 3678 3686 3694	3591 3599 3607 3615 3623 3631 3639 3647 3655 3663 3671 3679 3687		7410 7420 7430 7440 7450 7470 7500 7510 7520 7530 7540 7550	3840 3848 3856 3864 3872 3880 3896 3904 3912 3920 3928 3936 3944	3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3921 3929 3937 3945	3842 3850 3858 3868 3874 3882 3898 3906 3914 3922 3930 3938 3946	3843 3851 3859 3867 3867 3863 3891 3899 3907 3915 3923 3931 3939 3947	3844 3852 3860 3868 3876 3884 3892 3900 3916 3924 3932 3940	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949	3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3934 3934 3950 3958	3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3943 3951 3959	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7110 7110 7120 7130 7140 7150 7160	3584 3592 3600 3608 3616 3624 3632 3640 3656 3656 3664 3672 3880 3688 3688	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3673 3689 3689	3586 3594 3602 3610 3618 3526 3634 3642 3650 3656 3674 3682 3690 3698	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3667 3683 3691 3699	3588 3596 3604 3612 3620 3628 3636 3644 3652 3668 3678 3684 3692	3589 3597 3605 3613 3621 3629 3637 3645 3653 3669 3677 3685 3693	3590 3598 3608 3614 3622 3630 3638 3646 3654 3662 3670 3678 3686 3694	3591 3599 3607 3615 3623 3631 3639 3647 3655 3663 3671 3679 3687 3695 3703		7410 7420 7430 7440 7450 7460 7470 7500 7510 7520 7530 7540	3840 3848 3856 3864 3872 3880 3896 3904 3912 3920 3928 3936 3944 3952	3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3929 3937 3945 3953	3842 3850 3858 3868 3874 3898 3998 3906 3918 3922 3930 3938 3946 3954	3843 3851 3859 3867 3875 3883 3891 3899 3907 3913 3923 3923 3923 3939 3947	3844 3852 3860 3868 3876 3884 3900 3908 3916 3924 3932 3940 3948	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957	3846 3854 3862 3870 3878 3886 3894 3902 3910 3918 3926 3934 3942 3950 3958	3847 3855 3863 3871 3879 3887 3895 3903 3911 3919 3927 3935 3943 3951 3959	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7070 7110 7120 7130 7140 7150	3584 3592 3600 3608 3616 3624 3632 3640 3656 3656 3664 3672 3680 3688 3698	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681 3689 3697 3705	3586 3594 3602 3610 3618 3626 3634 3642 3658 3666 3674 2682 3690 3698 3706	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3667 3699 3707	3588 3596 3604 3612 3620 3636 3636 3644 3652 3660 3568 3678 3692 3700 3708	3589 3597 3605 3613 3629 3637 3645 3653 3661 3669 3677 3685 3693 3701	3590 3598 3608 3614 3622 3630 3638 3646 3654 3662 3670 3678 3686 3702 3710	3591 3599 3607 3615 3623 3631 3639 3647 3655 3663 3671 3879 3687 3587 3703 3711		7410 7420 7430 7440 7450 7460 7570 7520 7520 7530 7540 7550 7560 7570	3840 3848 3856 3864 3872 3886 3896 3904 3912 3920 3928 3934 3944 3952 3960	3841 3849 3857 3865 3873 3881 3889 3905 3913 3921 3929 3937 3945 3953 3961	3842 3850 3858 3874 3892 3898 3914 3972 3930 3938 3946 3954 3962	3843 3851 3859 3867 3895 3899 3907 3915 3923 3931 3939 3947 3955 3963	3844 3852 3860 3868 3876 3892 3900 3916 3924 3932 3940 3948 3956	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965	3846 3854 3862 3970 3678 3894 3902 3918 3926 3934 3942 3950 3958 3958	3847 3855 3863 3871 3887 3895 3903 3911 3919 3927 3935 3943 3959 3967	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7110 7110 7120 7130 7140 7150 7160	3584 3592 3600 3608 3616 3624 3632 3640 3656 3656 3664 3672 3680 3688 3698	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3681 3689 3697 3705	3586 3594 3602 3610 3618 3626 3634 3642 3850 3658 3666 3674 3682 3690 3698 3706	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3693 3707	3588 3596 3604 3612 3620 3636 3644 3652 3668 3678 3684 3692 3700 3708	3589 3597 3605 3613 3629 3637 3645 3653 3661 3669 3677 3685 3693 3701 3709	3590 3598 3608 3612 3630 3638 3646 3654 3670 3678 3686 3702 3710	3591 3599 3607 3613 3623 3631 3639 3647 3655 3663 3671 3679 3687 3703 3711		7410 7420 7430 7440 7450 7460 7510 7510 7520 7530 7540 7550 7560 7570	3840 3848 3856 3864 3872 3886 3896 3904 3912 3920 3928 3936 3944 3952 3968	3841 3849 3857 3865 3873 3881 3889 3905 3913 3921 3929 3937 3945 3953 3961	3842 3850 3858 3874 3898 3906 3914 3972 3930 3938 3946 3954 3962	3843 3851 3859 3867 3873 3891 3899 3907 3915 3923 3931 3939 3947 3955 3963	3844 3852 3860 3868 3876 3892 3900 3916 3916 3932 3940 3948 3956 3964	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965	3846 3854 3862 3870 3878 3894 3902 3910 3918 3934 3934 3950 3958 3958	3847 3855 3863 3871 3879 3887 3993 3911 3919 3927 3935 3943 3951 3959 3967	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7100 71100 7120 7130 7140 7150 7160 7170 7200 7210	3584 3592 3600 3608 3616 3624 3632 3640 3656 3656 3664 3672 3880 3688 3696 3704	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3681 3689 3697 3705	3586 3594 3602 3610 3618 3626 3634 3642 3850 3656 3674 3682 3690 3698 3706	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3697 3699 3707	3588 3596 3604 3612 3620 3636 3644 3652 3660 3668 3676 3684 3692 3700 3708	3589 3597 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677 3685 3693 3701 3709	3590 3598 3608 3614 3622 3630 3638 3646 3654 3670 3678 3686 3694 3702 3710	3591 3599 3607 3613 3623 3631 3639 3647 3655 3663 3671 3879 3687 3703 3711		7410 7420 7430 7440 7450 7460 7510 7520 7530 7540 7560 7560 7570 7600 7610	3840 3848 3856 3864 3872 3880 3896 3904 3912 3928 3936 3944 3952 3960	3841 3849 3857 3865 3873 3881 3889 3897 3905 3913 3929 3937 3945 3953 3961	3842 3850 3858 3878 3878 3898 3906 3912 3930 3938 3946 3954 3962 3970	3843 3851 3859 3867 3893 3997 3915 3923 3931 3939 3947 3955 3963	3844 3852 3860 3868 3876 3892 3900 3916 3916 3932 3940 3948 3956 3964	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3941 3949 3957 3965	3846 3854 3862 3870 3878 3894 3902 3910 3918 3934 3942 3950 3958 3958	3847 3855 3863 3871 3879 3887 3903 3911 3919 3927 3935 3943 3951 3959 3967	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7100 7110 7120 7130 7140 7150 7160 7170 7200 7210 7220	3584 3592 3600 3616 3624 3632 3640 3656 3656 3656 3672 3680 3688 3698 3704	3585 3593 3601 3609 3617 3625 3633 3641 3649 3657 3665 3673 3689 3721 3721 3721	3586 3594 3602 3618 3626 3634 3642 3658 3658 3666 3674 3682 3698 3706 3714 3722 3730	3587 3595 3603 3611 3619 3627 3635 3643 3659 3667 3675 3689 3699 3707 3715 3723 3731	3588 3596 3604 3612 3620 3628 3636 3644 3652 3660 3668 3676 3684 3670 3718 3718	3589 3597 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677 3685 3701 3709 3717 3725	3590 3598 3604 3612 3630 3638 3646 3654 3662 3670 3678 3788 3702 3710 3718 3726 3734	3591 3599 3695 3615 3623 3631 3639 3647 3655 3663 3671 3878 3703 3711 3719 3727 3735		7410 7420 7430 7440 7450 7460 7510 7520 7530 7540 7560 7570 7670 7600 7610 7620	3840 3856 3856 3864 3872 3880 3896 3912 3920 3928 3936 3936 3944 3952 3960	3841 3849 3857 3867 3881 3889 3897 3905 3913 3921 3929 3937 3945 3953 3961	3842 3850 3858 3864 3874 3882 3896 3914 3972 3938 3946 3954 3962	3843 3851 3859 38675 3883 3891 3899 3915 3923 3931 3931 3939 3947 3955 3963	3844 3852 3860 3868 3876 3884 3892 3900 3916 3924 3932 3940 3948 3956 3964	3845 3853 3861 3869 3877 3885 3893 3901 3909 3917 3925 3933 3943 3957 3965	3846 3854 3862 3870 3878 3886 3894 3918 3918 3918 3934 3943 3950 3958 3974 3982 3974	3847, 3855, 3863, 3879, 3887, 3895, 3903, 3911, 3919, 3927, 3934, 3959, 3967, 3983, 3994,	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7100 7120 7130 7140 7150 7160 7170 7200 7210 7220 7230	3584 3592 3600 3616 3624 3640 3656 3640 3658 3668 3672 3880 3698 3704 3712 3720 3720 3738	3585 3593 3601 3607 3607 3625 3633 3641 3649 3657 3687 3705 3713 3713 3723 3737	3586 3594 3612 3612 3618 3626 3634 3658 3666 3674 3682 3698 3706 3714 3730 3730 3738	3587 3593 3611 3619 3627 3635 3643 3651 3659 3667 3683 3691 3699 3707 3715 3723 3731	3588 3596 3604 3612 3620 3628 3636 3644 3652 3660 3664 3692 3700 3716 3716 37124 37124	3589 3597 3605 3613 3621 3629 3637 3645 3653 3661 3669 3677 3685 3701 3701 3717 3717 3717 3717	3590 3598 3608 3618 3622 3630 3646 3554 3652 3670 3678 3718 3718 3718 3734	3591 3599 3615 3615 3615 3633 3647 3655 3663 3871 3879 3687 3703 3711 3719 3737 3737 3743		7410 7420 7430 7440 7450 7460 7510 7520 7530 7540 7560 7560 7570 7600 7610	3840 3856 3864 3872 3880 3896 3904 3912 3920 3928 3936 3944 3952 3960 3968 3978 3984 3992	3841 3849 3857 3857 3881 3889 3905 3913 3921 3945 3953 3945 3953 3969 3977 3969	3642 3850 3858 3868 3874 3898 3914 3922 3938 3948 3954 3970 3978 3978 3978	3843 3851 3859 3875 3883 3891 3907 3915 3923 3947 3953 3963 3971 3971 3987 3987 3987 3987 3987 3987 3987 3987	3844 3352 3860 3868 3876 3892 3900 3916 3924 3940 3948 3956 3972 3980 3988 4004	3845 3853 3861 3869 3877 3885 3990 3917 3925 3933 3941 3949 3957 3965 3973 3981 3981 3981 3981 3981 3981	3846 3854 3870 3878 3894 3910 3918 3924 3950 3958 3958 3974 3982 3978 3986 4006	3847, 3855, 3871, 3879, 3887, 3911, 3919, 3927, 3951, 3953, 3953, 3954, 3959, 3967, 3975, 3983, 3999, 4007,	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7110 7120 7140 7150 7160 7170 7210 7210 7210 7210 7210 7210 721	3584 3592 3600 3616 3624 3632 3640 3656 3672 3888 3704 3712 3720 3720 3720 3732 3738	3585 3593 3609 3617 3625 3633 3641 3649 3687 3689 3689 3713 3721 3722 3737 3733	3586 3594 3602 3618 3626 3634 3642 3650 3658 3690 3794 3714 3722 3730 3748	3587 3595 3613 3611 3619 3625 3643 3651 3659 3693 3797 3715 3723 3731 3732 3747	3588 3596 3604 3612 3620 3636 3636 3668 3678 3692 3700 3708 3712 3748 3748 3758	3589 3597 3613 3621 3621 3637 3645 3653 3663 3663 3701 3709 3717 3725 3733 3749 3749 3749	3590 3598 3614 3622 3630 3654 3654 3654 3702 3710 3718 3726 3734 3742 3758	3591 3599 3607 3615 3623 3631 3633 3637 3655 3685 3703 3711 3719 3727 3735 3759 3759		7410 7420 7430 7440 7450 7450 7550 7520 7530 7540 7550 7560 7570 7620 7620 7630 7640 7650	3840 3848 3856 3864 3872 3880 3904 3912 3928 3916 3944 3952 3968 3976 3968 3976	3841 3849 3857 3857 3865 3873 3889 3897 3905 3929 3929 3945 3945 3945 3945 3945 3945 3945 394	3842 3850 3858 3874 3868 3998 3914 3922 3930 3948 3954 3954 3978 3978 4002	3843 3851 3859 3867 3867 3891 3997 3915 3923 3931 3947 3963 3963 3963 3963 3963 3963 3963 396	3844 3852 3860 3868 3876 3892 3900 3918 3924 3932 3948 3956 3964 3980 3988 4004 4012	3845 3853 3861 3869 3877 3865 3893 3901 3909 3917 3925 393 3941 3957 3965 3973 3981 3981 3981 4005	3846 3852 3870 3870 3910 3910 3918 3943 3945 3958 3958 3958 3986 4006 4014	3847, 3853, 3863, 3863, 3871, 3897, 3903, 3918, 3927, 393, 3943, 3959, 3967, 3983, 3998, 3998, 3998, 4007, 4015,	to 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7100 7120 7130 7140 7150 7160 7170 7200 7210 7220 7230	3584 3592 3600 3616 3616 3632 3640 3656 3656 3656 3674 3704 3712 3720 3736 3736 3736 3736 3736 3736 3736	3585 3593 3601 3617 3623 3633 3641 3649 3657 3667 3687 3687 3687 3713 3713 3713 3713 3713 3713 3713	3586 3594 3602 3610 3618 3626 3634 3658 3658 3658 3658 3658 3674 3659 3706 3714 3730 3730 3740 3754 3754	3587 3595 3611 3619 3627 3643 3659 3667 3669 3691 3707 3715 3723 3731 3731 3731 3755 3755	3588 3596 3612 3620 3636 3636 3644 3652 3668 3678 3692 3718 3718 3718 3718 3718 3746 3748	3589 3597 3605 3613 3629 3637 3645 3653 3653 3661 3767 3709 3717 3725 3733 3741 3741 3741 3741 3757	3590 3598 3614 3622 3630 3638 3646 3854 3870 3710 3718 3726 3734 3742 3750 3758 3758	3591 3599 3697 3615 3623 3631 3632 3633 3647 3655 3663 3673 3687 3687 3787 3773 3773 3773		7410 7420 7430 7440 7450 7510 7520 7530 7540 7550 7560 7570 7610 7620 7630 7640 7650	3840 3848 3858 3868 3872 3888 3898 3912 3923 3912 3928 3956 3956 3968 3976 4000 4008	3841 3849 3857 3857 3865 3889 3897 3905 3913 3921 3922 3933 3945 3953 3953 4001 4009	3842 3850 3858 3868 3874 3898 3998 3998 3914 3914 3914 3914 3914 4010 4010 4010	3843 3851 3859 3867 3893 3993 3907 3915 3923 3931 3933 3931 3933 3943 3953 3963 3971 3963 3971 3993 3971 3993	3844 3852 3860 3868 3876 3992 3916 3924 3939 3948 3956 3964 3972 3980 3988 3998 4004	3845 3853 3861 3867 3893 3991 3993 3941 3943 3943 3943 3943 39	3846 3852 3870 3873 3982 3914 3918 3934 3950 3950 3950 3950 3950 3950 3950 3950	3847, 3853, 3863, 3871, 3879, 3895, 3903, 3919, 3927, 3933, 3943, 3951, 3967, 3983, 3994, 3994, 4015, 4023,	tc 777 (Oct	to 409	95
7010 7020 7020 7030 7040 7050 7160 7110 7120 7130 7130 7140 7150 7210 7220 7220 7230 7230 7230	3584 3592 3600 3616 3624 3632 3640 3656 3664 3688 3696 3704 3712 3720 3720 3720 3732 3732	3585 3593 3601 3617 3623 3633 3641 3649 3657 3667 3687 3687 3687 3713 3713 3713 3713 3713 3713 3713	3586 3594 3602 3610 3618 3626 3634 3658 3658 3658 3658 3658 3674 3659 3706 3714 3730 3730 3740 3754 3754	3587 3595 3613 3611 3619 3625 3643 3651 3659 3693 3797 3715 3723 3731 3732 3747	3588 3596 3612 3620 3636 3636 3644 3652 3668 3678 3692 3718 3718 3718 3718 3718 3746 3748	3589 3597 3605 3613 3629 3637 3645 3653 3653 3661 3767 3709 3717 3725 3733 3741 3741 3741 3741 3757	3590 3598 3614 3622 3630 3654 3654 3654 3702 3710 3718 3726 3734 3742 3758	3591 3599 3697 3615 3623 3631 3632 3633 3647 3655 3663 3673 3687 3687 3787 3773 3773 3773		7410 7420 7430 7440 7450 7510 7520 7530 7540 7550 7560 7570 7610 7620 7630 7640 7650	3840 3848 3858 3868 3872 3888 3898 3912 3923 3912 3928 3956 3956 3968 3976 4000 4008	3841 3849 3857 3857 3865 3889 3897 3905 3913 3921 3922 3933 3945 3953 3953 4001 4009	3842 3850 3858 3868 3874 3898 3998 3998 3914 3914 3914 3914 3914 4010 4010 4010	3843 3851 3859 3867 3893 3993 3907 3915 3923 3931 3933 3931 3933 3943 3953 3963 3971 3963 3971 3993 3971 3993	3844 3852 3860 3868 3876 3892 3900 3918 3924 3932 3948 3956 3964 3980 3988 4004 4012	3845 3853 3861 3867 3893 3991 3993 3941 3943 3943 3943 3943 39	3846 3852 3870 3873 3982 3914 3918 3934 3950 3950 3950 3950 3950 3950 3950 3950	3847, 3853, 3863, 3871, 3879, 3895, 3903, 3919, 3927, 3933, 3943, 3951, 3967, 3983, 3994, 3994, 4015, 4023,	tc 777 (Oct	to 409	95
7010 7020 7030 7040 7050 7060 7070 7100 7120 7130 7140 7150 7150 7200 7210 7220 7230 7240 7250 7260 7270	3584 3592 3600 3616 3632 3640 3656 3672 3880 3704 3712 3720 3720 3720 3752 3752 3760 3760	3585 3593 3601 3609 3615 3625 3625 3633 3641 3687 3687 3705 3705 3713 3721 3721 3723 3753 3753 3761 3769	3586 3594 3602 3610 3618 3626 3634 3650 3658 3666 3698 3706 3714 3722 3730 3740 3750 3770	3587 3595 3603 3611 3619 3627 3635 3651 3653 3693 3707 3715 3723 3731 3731 3731 3755 3763 3771	3588 3596 3596 3604 3612 3628 3636 3644 3652 3668 3684 3700 3708 3712 3724 3732 3748 3756 3764 3772	3589 3605 3613 3621 3629 3637 3653 3661 3672 3685 3693 3717 3701 3717 3725 3737 3737 3737 3737 3744 3757 3765 3773	3590 3598 3608 3614 3622 3630 3638 3646 3672 3678 3686 3702 3718 3742 3742 3758 3758 3758 3758 3758	3591 3599 3607 3615 3623 3631 3631 3671 3687 3687 3687 3703 3703 3711 3727 3735 3759 3759 3759		7410 7420 7430 7440 7450 7510 7520 7530 7540 7550 7660 7650 7650 7660 7650 7660 7650	3640 3648 3856 3864 3870 3880 3890 3912 3920 3928 3936 3944 3952 3968 3976 4008 4016 4024	3841 3849 3857 3865 3873 3887 3905 3913 3929 3929 3945 3953 3961 4009 4017 4025 4017 4025	3842 3850 3858 3874 3914 3922 3930 3914 3954 3954 4002 4010 4016 4026	3843 3851 3859 3867 3867 3863 3893 3913 3913 3913 3947 3953 3963 3971 3971 3973 3963 4003 4011 4011 4011	3844 3852 3860 3868 3872 3900 3918 3918 3940 3948 3956 3964 3960 4020 4020 4020 4020 4020 4020	3845 3853 3861 3889 3877 3901 3917 3925 3933 3957 3949 3957 3965 3913 3949 4005 4005 4013 4024	3846 3854 3862 3870 3878 3902 3910 3918 3934 3950 3950 3950 3950 3950 4006 4014 4030 4030	3847, 3853, 3871, 3879, 3873, 3873, 3873, 3911, 3919, 3927, 3934, 3951, 3959, 3967, 3974, 4074, 4074, 4074, 4074, 4074, 4074, 4074, 4074,	to 777	to 409	95
7010 7020 7030 7040 7050 7070 7100 7110 7120 7130 7146 7177 7206 7216 7217 7227 7236 7244 7236 7247 7256 7277	3584 3592 3600 3616 3624 3632 3640 3656 3672 3888 3696 3704 3712 3720 3730 3736 3736 3736 3736 3736 3736 373	3585 3593 3601 3809 3617 3625 3633 3641 3689 3687 3705 3713 3721 3721 3737 3743 3753 3753 3753	3586 3594 3602 3610 3618 3626 3634 3656 3658 3690 3704 3712 3730 3746 3777 3777 3777	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3675 3707 3715 3723 3731 3731 3747 3755 3763	3588 3596 3596 3604 3612 3628 3636 3644 3652 3760 3708 3708 3718 3718 3732 3740 3732 3740 3732 3740 3732 3740 3732 3740 3732 3740 3732 3740 3732 3740 3752 3752 3752 3752 3752 3752 3752 3752	3589 3605 3613 3629 3637 3645 3653 3663 3677 3685 3701 3709 3717 3725 3732 3744 3749 3749 3757 3773	3590 3598 3614 3622 3638 3646 3654 3670 3878 3878 3710 3718 3718 3728 3734 3742 3750 3774 3774 37782	3591 3599 3697 3615 3623 3631 3639 3663 3671 3685 3703 3711 3719 3727 3737 3743 3751 3758 3787		7410 7420 7430 7440 7450 7510 7520 7550 7550 7550 7550 7560 7660 7670 7620 7660 7670 7670 7700 7710	3840 3872 3886 3886 3896 3994 3912 3928 3935 3944 3952 3960 3968 3976 4016 4046 4046 4046 4046	3841 3849 3857 3865 3873 3889 3995 3929 3929 3929 3945 3969 3977 3965 4007 4007 4025 4025 4025 4024	3842 3850 3858 3868 3873 3898 3918 3918 3918 3918 3918 3954 3954 4018 4018 4028 4014 4018	3843. 3859 3867 3875 3893 3893 3893 3993 3913 3993 3947 3963 3979 3963 3979 4003 4011 4041 4042 4043 4044	3844 3852 3850 3868 3872 3900 3916 3924 3932 3940 3940 3948 3956 3968 4012 4012 4012 4012 4012 4012	3845 3853 3861 3889 3909 3917 3925 3933 3941 3949 3957 3969 4013 4021 4021 4023 4037	3846 3854 3862 3470 3878 3894 3910 3918 3934 3958 3958 3958 4006 4014 4014 4038 4038 4038 4046	3847, 3855, 3863, 3871, 3873, 3911, 3919, 3927, 3927, 3933, 3943, 3951, 3967, 4015, 4023, 4031, 4044, 4044,	to 777	to 409	95
7010 7020 7030 7040 7050 7070 7100 7110 7110 7130 7140 7177 7200 7210 7210 7220 7230 7240 7250 7270 7270 7270 7270 7270 7270 727	3584 3592 3600 3606 3616 3636 3640 3656 3688 3688 3698 3704 3712 3720 3736 3744 3752 3752 3752 3752 3758	3585 3593 3593 3601 3609 3617 3625 3633 3641 3687 3687 3793 3793 3793 3793 3793 3793 3753 3763 3763 3763 3763 3763 3763 376	3586 3594 3602 3610 3618 3626 3634 3666 3674 3682 3730 3714 3722 3730 3746 3776 3777 3778	3587 3595 3603 3611 3619 3627 3635 3643 3651 3659 3707 3715 3723 3731 3747 3752 3771 3775 3771 3775 3771	3588 3596 3604 3612 3620 3636 3644 3652 3668 3678 3678 3708 3772 3732 3748 3748 3772 3748 3772 3748 3772	3589 3605 3613 3629 3637 3645 3653 3653 3669 3877 3865 3701 3709 3717 3725 3749 3749 3757 3749 3757	3590 3598 3608 3614 3632 3630 3654 3864 3874 3702 3718 3726 3734 3750 3752 3752 3752 3752 3752 3752 3752 3752	3591 3599 3807 3615 3623 3631 3639 3647 3655 3673 3703 3711 3719 3727 3743 3751 3763 3773 3783 3783 3783		7410 7420 7440 7450 7460 7510 7510 7520 7550 7540 7650 7660 7670 7620 7670 7670 7670 7670 7770 77	3840 3856 3864 3872 3890 3990 3916 3928 3936 3946 3968 3968 3968 4016 4024 4042 4042 4042 4044	3841 3849 3857 3865 3873 3883 3897 3905 3913 3929 3937 3945 3953 4003 4017 4003 4017 4025	3842 3850 3858 3868 3874 3912 3913 3914 3912 393 3944 4010 4010 4010 4010 4010 4010 4010 4	3843 3851 3859 3867 3883 3889 3907 3915 3923 3933 3934 3955 3963 3971 3963 4003 4011 4027 4043 4043 4043 4043 4043 4043 4043 404	3844 3852 3850 3858 3876 3884 3990 3908 3924 3924 3923 3940 3955 3964 3972 3968 4004 4028 4028 4028 4038 4048	3845 3853 3861 3869 3877 3885 3893 3997 3957 3941 3957 3965 3973 4003 4021 4024 4024 4035 4024 4035 4045	3846 3862 3870 3870 3994 3992 3910 3933 3958 3958 3958 3958 4004 1022 4030 4030	3847, 3855, 3863, 3871, 3879, 3895, 3903, 3911, 3919, 3959, 3959, 3967, 4023, 4031, 4044, 4047, 4047,	to 777	to 409	95
7010 7020 7030 7040 7050 7070 7100 7110 7120 7130 7146 7177 7206 7216 7217 7227 7236 7244 7236 7247 7256 7277	3584 3592 3600 3616 3624 3632 3640 3656 3656 3656 3702 3704 3712 3720 3720 3720 3758 3758	3585 3593 3601 3809 3617 3625 3633 3641 3689 3687 3705 3713 3721 3721 3737 3743 3753 3753 3753	3586 3594 3602 3610 3618 3626 3634 3666 3698 3796 3714 3722 3730 3734 3766 3714 3772 3776 3776	3587 3595 3603 3611 3627 3635 3643 3659 3867 3699 3707 3715 3737 3737 3747 3747 3747 3747 3747 374	3588 3596 3604 3612 3620 3636 3636 3668 3694 3700 3718 3724 3740 3740 3740 3772 3740 3740 3740 3772	3589 3605 3613 3629 3637 3645 3653 3653 3653 3709 3713 3725 3773 3725 3725 3737 3749 3757 3765 3773	3590 3698 3608 3614 3630 3638 3646 3652 3670 3710 3710 3712 3728 3734 3758 3758 3758 3758 3758 3758 3758 3758	3591 3599 3807 3615 3623 3631 3639 3647 3655 3703 3711 3719 3727 3733 3743 3753 3763 3775 3783 3783 3783 3783 3783 3783 378		7410 7420 7440 7450 7450 7550 7550 7550 7550 755	3840 3858 3868 3892 3994 3952 3952 3952 3958 3958 3968 3976 408 408 408 408 408 408 408 408 408 408	3841 3849 3857 3865 3889 3897 3905 3929 3929 3929 3953 3969 3977 4001 4025 4044 4044 4044 4044 4044	3842 3850 3858 3868 3882 3898 3906 3912 3930 3930 3954 4002 4010 4010 4014 4026 4034 4044 4044 4058	3843 3851 3859 3867 3873 3893 3993 3993 3993 3993 3993 399	3844 3852 3860 3888 3890 3918 3924 3932 3948 3948 3948 3948 4022 4022 4022 4028 4044 4044 4044 40	3845 3853 3861 3859 3877 3885 3893 3901 3908 3957 3957 3957 4005 4021 4021 4023 4023 4043 4043 4043	3846 3864 3870 3870 3994 3902 3910 3918 3934 3942 3933 3958 3966 4010 4010 4030 4030 4040 4040 4040 4040	3847, 3855, 3853, 3879, 3887, 3895, 3903, 3911, 3919, 3927, 3935, 3943, 3959, 3967, 3983, 3999, 4007, 4015, 4031, 4043, 4043, 4045, 4045, 4045, 4045,	to 777	to 409	95
7010 7020 7030 7040 7050 7070 7110 7110 7130 7140 7150 7177 7200 7210 7220 7230 7340 7350 7370 7370 7370 7370 7370 7370 737	3584 3592 3600 3600 3606 3624 3656 3672 3880 3704 3712 3720 3720 3730 3752 3752 3752 3752 3752 3752 3752 3752	3585 3593 3601 3609 3637 3633 3641 3649 3687 3773 3773 3773 3773 3773 3773 3773	3586 3594 3602 3618 3626 3638 3642 3650 3652 3650 3690 3798 3798 3798 3798 3798 3798 3798 3798	3587 3595 3603 3611 3627 3635 3643 3651 3659 3693 3707 3715 3739 3737 3737 3747 3755 3747 3755 3747 3755 3747 3755 3747 3755 3747 3755 3747 3755 3747 3755 3747 3755 3747 3755 3757 3757	3588 3596 3604 3612 3628 3636 3644 3652 3700 3708 3712 3723 3724 3732 3732 3732 3732 3732 373	3589 3605 3613 3629 3637 3645 3663 3663 3663 3709 3717 3725 3733 3709 3717 3725 3737 3749 3749 3773 3781 3781 3781 3781 3781 3781 3781	3590 3698 3608 3614 3630 3633 3646 3654 3694 3702 3718 3718 3718 3718 3718 3718 3718 3718	3591 3599 3607 3615 3623 3631 3633 3647 3685 3703 3711 3719 3727 3735 3743 3751 3775 3775 3775 3775 3775 3775 377		7410 7420 7440 7450 7450 7550 7550 7550 7550 7560 7570 7600 7610 7620 7670 7720 7720 7720 7720 7720 772	3840 3856 3868 3896 3896 3904 3912 3920 3923 3944 3952 3968 3984 3992 4016 4024 4046 4048 4048 4046 4046 4046 4046 404	3841 3849 3857 3865 3873 3881 3989 3929 3929 3953 3961 4099 4017 4023 4024 4034 4034 4044 4044 4044 4044	3842 3850 3858 3868 3898 3908 3918 3922 3930 3948 3948 4016 4018 4024 4034 4034 4056 4056 4056	3843 3851 3859 3875 3883 3893 3993 3915 3915 3915 3916 3916 3916 3916 3916 3916 3916 3916	3844 3852 3850 3858 3876 3884 3892 3993 3998 3996 3996 4012 4028 4012 4020 4044 4044 4052 4064 4065 4064 4064 4064 4064 4064 4064	3845 3853 3861 3889 3897 3895 3997 3995 3933 3949 3949 3949 4041 4021 4033 4041 4044 4044 4044 4044 4053 4063	3846 3862 3870 3870 3886 3894 3992 3993 3998 3998 4014 1022 4036 4046 4046 4046 4056 4056 4056 4056 405	3847, 3855, 3863, 3871, 3893, 3993, 3993, 3993, 3951, 3959, 3959, 3967, 4023, 4024, 4024, 4034, 4044,	to 777	to 409	95
7010 7020 7040 7050 7060 7070 7100 7110 7120 7120 7140 7170 7210 7210 7210 7210 7240 7250 7240 7277 7300 7310 7320 7331 7331 7331	3584 3592 3600 3608 3624 3636 3640 3656 3672 3880 3772 3792 3792 3792 3758 3758 3758 3778 3778 3778 3778 3778	3585 3593 3601 3609 3635 3631 3641 3649 3687 3705 3713 3721 3721 3737 3745 3737 3745 3737 3753 3777 3783 3809 3809 3809 3809	3586 3594 3612 3618 3626 3634 3658 3658 3698 3796 3714 372 3730 3738 3749 3770 3770 3770 3783 3794 3794 3794 3794 3810 3810	3587 3595 3603 3611 3627 3635 3643 3651 3659 3675 3675 3707 3715 3723 3737 3737 3737 3737 3747 3747 3747	3588 3596 3604 3612 3620 3636 3652 3660 3768 3778 3778 3778 3778 3778 3778 3778	3589 3605 3613 3629 3633 3645 3653 3653 3665 3693 3773 3725 3725 3709 3717 3725 3765 3773 3783 3783 3783 3783 3783 3783 378	3590 3598 3608 3612 3630 3638 3638 3638 3638 3638 3710 3718 3728 3758 3758 3774 3768 3774 3758 3758 3758 3768 3774 3758 3758 3758 3758 3758 3758 3758 3758	3591 3599 3607 3615 3623 3631 3633 3647 3655 3703 3713 3713 3713 3713 3713 3713 3713	1	7410 7420 7440 7450 7450 7510 7520 7550 7550 7560 7660 7660 7660 7660 766	3840 3853 3864 3863 3868 3898 3898 3928 3945 3952 3960 3968 3976 4006 4016 4024 4032 4044 4044 4044 4044 4044 4044	3841 3847 3857 3865 3873 3881 3889 3903 3922 3923 3953 3963 3965 3973 4001 4017 4025 4033 4044 4055 4065 4073	3842 3850 3858 3858 3874 3898 3998 3914 3922 3930 3938 3946 4026 4026 4026 4036 4046 4056 4056 4056 4056 4056 4056 405	3843 3859 3851 3875 3883 3891 3997 3997 3997 3997 3997 4003 4011 4042 4043 4043 4043 4043 4043 4043 4043	3844 3852 3860 3888 3876 3898 3916 3924 3948 3948 3948 3964 3964 4012 4012 4028 4012 4028 4036 4046 4046 4046 4046 4046 4046 4046	3845 3853 3861 3877 3885 3893 3901 3909 3917 3923 3943 3943 3949 3949 405 4013 4029 4037 4045 4045 4061 4061 4061 4061 4061 4061 4061 4061	3846 3854 3862 3878 3886 3894 3910 3918 3922 3950 3938 3966 4014 4014 4034 4044 4045 4046 4046 4046 4046 4046 404	3847, 3855, 3863, 3871, 3879, 3897, 3959, 3967, 3959, 4003, 4003, 4004, 4074,	to 777	to 409	95
7010 7020 7030 7040 7050 7070 7110 7110 7130 7140 7150 7177 7200 7210 7220 7230 7340 7350 7370 7370 7370 7370 7370 7370 737	3584 3592 3600 3616 3624 3636 3640 3656 3668 3672 3880 3772 3720 3720 3738 3752 3752 3752 3752 3752 3752 3752 3752	3585 3593 3601 3609 3639 3635 3631 3649 3655 3673 3705 3713 3721 3753 3753 3753 3753 3753 3753 3753 3765 3765	3586 3594 3602 3810 3826 3638 3642 3652 3652 3652 3652 3706 3714 3714 3714 3714 3714 3716 3716 3716 3716 3716 3716 3716 3716	3587 3595 3603 3611 3659 3663 3651 3659 3675 3707 3715 3723 3737 3747 3755 3777 3778 3778 3778 3778 3778 377	3588 3596 3604 3612 3636 3636 3636 3652 3668 3692 3700 3712 3712 3712 3712 3712 3712 3712 3712	3589 3605 3613 3629 3637 3653 3653 3653 3653 3653 3773 3709 3717 3725 3737 3749 3773 3773 3773 3773 3773 3773	3590 3698 3608 3614 3652 3673 3678 3878 3712 3718 3718 3718 3774 3778 3778 3778 3778 3778 3778 377	3591 3599 3607 3615 3623 3631 3639 3667 3695 3703 3711 3719 3727 3735 3743 3751 3763 3763 3775 3783 3791 3793 3793 3793 3793 3793 3793 379		7410 7420 7440 7450 7450 7550 7550 7550 7550 755	3840 3856 3868 3896 3896 3904 3912 3920 3923 3944 3952 3968 3984 3992 4016 4024 4046 4048 4048 4046 4046 4046 4046 404	3841 3849 3857 3665 3673 3881 3889 3915 3929 3945 3953 3945 3953 3969 4017 4009 4017 4044 4044 4044 4044 4044 4044 4044	3842 3850 3858 3858 3898 3916 3922 3930 3946 3946 3946 4010 4010 4010 4010 4010 4010 4010 40	3843 3859 3851 3859 3893 3993 3993 3993 3993 3993 3993	3844 3852 3850 3858 3876 3884 3892 3993 3998 3996 3996 4012 4028 4012 4020 4044 4044 4052 4064 4065 4064 4064 4064 4064 4064 4064	3845 3853 3861 3887 3897 3893 3990 3993 3943 3943 3943 3943 3956 3973 4045 4033 4029 4037 4045 4045 4045 4047 4047	3846 3854 3862 3870 3878 3886 3994 3910 3918 3928 3930 3950 3950 3950 3950 3960 4014 4014 4014 4014 4014 4014 4014 40	3847, 3853, 3871, 3895, 3995, 3995, 3995, 3995, 3995, 3995, 3995, 3995, 3995, 3995, 4007, 4015, 4019,	to 777	to 409	95

OCTAL-DECIMAL FRACTION CONVERSION TABLE

.074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .119140 .175 .244140 .275 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .378 .496093	Octal	Decimal	Octal	Decimal	Octal	Decimal	Octal	Decimal
.002 .003906 .102 .120905 .201 .251903 .301 .370596002 .003906 .102 .120809 .202 .255850 .303 .378596003 .003899 .103 .1308899 .203 .255850 .303 .388589004 .007812 .104 .122812 .201 .257812 .304 .328312005 .009785 .105 .134765 .205 .257812 .304 .328312006 .01718 .106 .156718 .206 .207 .257815 .305 .384765007 .013671 .107 .128871 .207 .265871 .307 .398671007 .013673 .110 .108871 .207 .265871 .307 .398671010 .015625 .110 .104025 .210 .255825 .310 .309625011 .017578 .111 .14378 .211 .276778 .311 .302578012 .015511 .112 .144331 .212 .260931 .312 .394531013 .02484 .113 .146884 .213 .271484 .314 .394631014 .023437 .114 .148337 .214 .271484 .314 .394634015 .025399 .115 .150390 .215 .275390 .315 .409390016 .027343 .116 .15243 .216 .277343 .116 .02543017 .028296 .117 .154296 .217 .279296 .317 .404296020 .031290 .120 .158259 .220 .221259 .320 .404296021 .033293 .121 .158293 .221 .253290 .321 .404296022 .031596 .122 .161656 .222 .255136 .322 .410156023 .037109 .123 .162109 .223 .287109 .323 .412019024 .039962 .124 .164662 .224 .2259062 .324 .41209025 .031015 .125 .166615 .225 .225136 .322 .414062026 .04908 .126 .167968 .227 .224921 .327 .419021027 .044921 .127 .109921 .227 .2394321 .337 .419021027 .044921 .127 .109921 .227 .2394321 .337 .419021037 .046875 .130 .11875 .230 .230 .330883 .336 .43687 .334 .447368037 .046875 .130 .11875 .230 .231 .328687 .330 .421875039 .062734 .133 .17734 .233 .302734 .333 .42734031 .08688 .131 .173828 .231 .288628 .331 .439639 .334 .447368037 .050486 .137 .188546 .233 .306860 .335 .447068037 .050486 .137 .188556 .235 .231616 .322 .416015037 .046975 .130 .11875 .230 .23083 .330834 .334 .447368037 .06046 .137 .188556 .235 .231616 .332 .34687 .334 .449269036 .066976 .137 .188556 .237 .331699 .335 .449099 .335 .449099 .336 .447069037 .050486 .136 .136994 .231 .334687 .334 .449099 .335 .449099 .336 .449099 .336 .449099 .336 .449099 .336 .449099 .336 .449099 .336			. 100	. 125000	.200	. 250000	300	.375000
0.004 0.07812					,201	. 251953	. 301	
.094 .097812 .104 .132912 .204 .392812 .004 .392812 .006 .39076 .3006 .392812 .004 .392812 .004 .392812 .006 .00171 .006 .011718 .106 .136718 .206 .261718 .305 .386718 .006 .01718 .006 .00171 .007 .1017 .138671 .207 .20727 .2072 .007578 .101 .107578 .111 .112578 .211 .205921 .311 .00273 .012 .01551 .111 .146311 .212 .205931 .311 .30273 .012 .015 .022447 .114 .146311 .212 .20591 .311 .309131 .103 .024844 .311 .166384 .212 .27437 .313 .398134 .106 .022447 .114 .148637 .214 .274477 .313 .398134 .016 .022447 .313 .398134 .016 .0224407 .313 .398134 .016					, 202	. 253306	. 302	.378906
					.203	. 255899	. 303	.380859
					,204	, 257812	. 304	
0.00				. 134765	. 205	. 250765	. 305	, 384765
0.10				. 136718	. 206	.261718	, 306	.386718
011 01578		.013671	. 107	. 138671	. 207	. 263671	.307	.388671
.011 .01578		. 015625	, 110	. 140625	, 210	. 265625	.310	. 390625
.012 .019531 .112 .144531 .212 .209531 .312 .394331 .013 .021484 .313 .46184 .213 .271484 .313 .396184 .014 .023437 .114 .164347 .214 .271447 .314 .396147 .015 .025390 .115 .150390 .215 .275390 .315 .400390 .016 .027341 .116 .152343 .216 .275390 .315 .400390 .016 .027341 .116 .152343 .216 .275390 .317 .404296 .007 .0073203 .121 .152295 .220 .281250 .320 .400250 .021 .031203 .121 .158293 .221 .283203 .321 .408293 .022 .03156 .122 .160156 .222 .281155 .322 .401156 .023 .021 .031203 .121 .158293 .221 .283203 .321 .408293 .022 .03156 .122 .160156 .222 .281155 .322 .410156 .023 .03100 .123 .162109 .223 .287109 .323 .412109 .024 .33962 .124 .164062 .224 .289062 .324 .410062 .025 .041015 .125 .166015 .225 .201015 .225 .416015 .026 .027 .044921 .127 .169921 .227 .294921 .327 .419921 .033 .42888 .311 .40828 .037 .037 .04921 .127 .169921 .227 .294921 .327 .419921 .030 .046875 .130 .171875 .230 .296875 .330 .421875 .303 .06867 .334 .428828 .331 .338838 .3388838 .338838 .3388838 .3388838 .338838 .3388838 .33888 .33888 .33888 .33888 .33888 .33888 .3388	.011	.017578	.111	. 1-12578	.211	. 267578		
.013 .021484	.012	.019531	.112	. 144531	.212			
.014 .023437	.013	.021484	. 113	.146484	.213	.271484		
.016	.014	.023437	, 114	.148437	.214	. 273437		
.016	.015	.025390	, 115	, 150390	.215	,275300	r	
.017 .029296	.016	. 027343	, 116	. 152343	. 216	, 277343		
0.00	.017	.029296	. 117	. 154296			1	
021	.020	.031250	. 120	. 156250			,	
0.022							I	
.023							I	
.024 .039062 .124 .164062 .224 .289062 .324 .414062 .025 .041015 .125 .166015 .225 .291015 .325 .416015 .026 .042968 .126 .167968 .226 .2292968 .326 .417968 .027 .044921 .127 .169921 .227 .229921 .327 .419921 .030 .046875 .130 .171875 .230 .296875 .330 .421875 .031 .048828 .131 .173828 .231 .298828 .331 .429828 .032 .00781 .132 .175781 .232 .300781 .332 .426781 .033 .052734 .133 .177734 .223 .300781 .332 .426781 .033 .052734 .133 .177734 .223 .300781 .332 .426781 .034 .054667 .134 .179687 .234 .304687 .333 .427734 .034 .054667 .134 .179687 .234 .304687 .333 .427734 .036 .056640 .135 .181640 .235 .306840 .335 .431640 .036 .058593 .136 .183993 .226 .398593 .336 .433593 .037 .060546 .137 .185546 .237 .101646 .337 .430546 .037 .060546 .137 .185546 .237 .101646 .337 .430546 .041 .06453 .141 .189453 .241 .314453 .341 .439453 .042 .066406 .142 .191406 .242 .116406 .342 .441406 .044 .070312 .144 .193140 .244 .320312 .044 .446312 .044 .070312 .144 .19312 .244 .320312 .044 .446314 .044 .070312 .144 .19312 .244 .320312 .044 .446312 .044 .070312 .144 .19312 .244 .320312 .044 .446319 .046 .074218 .146 .199218 .246 .324218 .346 .440218 .046 .074218 .146 .199218 .246 .324218 .346 .440218 .046 .074218 .146 .199218 .246 .324218 .346 .440218 .046 .074218 .146 .199218 .246 .324218 .346 .440218 .055 .072265 .145 .197265 .255 .325 .33593 .356 .45899 .155 .212890 .255 .337890 .355 .45890 .155 .212890 .255 .337890 .355 .45890 .155 .212890 .255 .337890 .355 .468990 .155 .212890 .255 .337890 .355 .468990 .160 .218750 .260 .347550 .366 .398593 .156 .22656 .262 .347558 .362 .478656 .060 .093750 .160 .218750 .2265 .260 .347550 .366 .468750 .066 .093750 .160 .218750 .2265 .250 .328125 .350 .46993 .356 .468990 .055 .087890 .155 .212890 .255 .337890 .355 .468990 .156 .212890 .255 .337890 .355 .468990 .160 .218750 .260 .347550 .366 .39843 .356 .468830 .066 .09969 .163 .224608 .266 .35468 .366 .469468 .266 .35468 .366 .469468 .266 .35468 .366 .469468 .266 .35468 .366 .469468 .266 .35468 .366 .469468 .266 .35468 .366 .469468 .266 .35468 .366 .4							I	
.025		-						
.026 .042968								
.027								
.030								
.031			1				,	
.032 .050781								
0.32								
.034 .054687								
.035 .056640								. 427734
.036							1	.429687
.037 .060546							, 335	.431640
.040 .062500			1				.336	. 433593
.041			1		, 237	. 310546	. 337	. 435546
.042 .066406				.187500	. 240	. 312500	. 340	437500
.042 .066406		.064453	. 141	.189453	, 241	314453	.341	.439453
.043 .068359			. 142	. 191406	, 242	.316406	,342	
.044 .070312	.043	.068359	, 143	, 193359	. 243	, 318359	1	
.045 .072265 1.43 1.97265 .243 .322265 .345 .447265 .046 .074218 1.46 .199218 .246 .324218 .346 .449218 .047 .076171 1.147 .201171 .247 .326171 .347 .451171 .050 .073125 .150 .203125 .250 .328125 .350 .455078 .051 .080078 .151 .205078 .251 .330078 .351 .455078 .052 .082031 .152 .207031 .252 .332031 .352 .457031 .053 .083984 .153 .208984 .253 .333984 .353 .458984 .054 .085937 .154 .210937 .254 .335937 .354 .460937 .055 .087890 .155 .212890 .255 .337890 .355 .462890 .056 .089943 .156 .214843 .256 .339943 .356	.044	.070312	. 144	. 195312	. 244	.320312		
.046 .074218 .146 .199218 .246 .324218 .346 .449218 .047 .076171 .147 .201171 .247 .326171 .347 .451171 .050 .078125 .150 .203125 .250 .328125 .350 .453125 .051 .080078 .151 .205078 .251 .330078 .351 .455078 .052 .082031 .152 .207031 .252 .332031 .352 .457031 .053 .083984 .153 .208984 .253 .333984 .353 .458984 .054 .085937 .154 .2109937 .254 .335937 .354 .460937 .055 .087890 .155 .212890 .255 .337890 .355 .462890 .056 .089843 .156 .214843 .256 .339843 .356 .464843 .057 .091796 .157 .216796 .257 .341796 .357	. 045	.072265	. 145	.197265	. 245	. 322265	1	
.047 .076171	, 046	.074218	. 146	.199218	.246		1	
.050 .078125 .150 .203125 .250 .328125 .350 .453125 .051 .080078 .151 .205078 .251 .330078 .351 .455078 .052 .082031 .152 .207031 .252 .332031 .352 .457031 .053 .083984 .153 .208984 .253 .333984 .353 .458984 .054 .085937 .154 .210937 .254 .335937 .354 .460937 .055 .087890 .155 .212690 .255 .337890 .355 .462890 .056 .089843 .156 .214843 .256 .339843 .356 .464843 .057 .091796 .157 .216796 .257 .341796 .357 .466796 .060 .093750 .160 .218750 .260 .343750 .360 .468750 .061 .0957656 .162 .222655 .262 .347656 .362	.047	.076171	. 147	. 201171			1	
.051 .080078 .151 .205078 .251 .330078 .351 .455078 .052 .082031 .152 .207031 .252 .332031 .352 .457031 .053 .083984 .153 .208984 .253 .333984 .353 .458984 .054 .085937 .154 .210937 .254 .335937 .354 .460937 .055 .087890 .155 .212890 .255 .337890 .355 .462890 .056 .089843 .156 .214843 .256 .339843 .356 .464843 .057 .091796 .157 .216796 .257 .341796 .357 .466796 .060 .093750 .160 .218750 .260 .343750 .360 .468750 .061 .095703 .161 .220703 .261 .345703 .361 .470703 .062 .097656 .162 .222656 .262 .347656 .362 <	. 050	.078125	. 150				t .	
.052			1					
.053								
.054			1					
.055			1					
.056			1				I	
.057 .091796			!				I	
.060 .093750								
.061 .095703								
.062 .097656							1	
. 063								
.064 .101562 .164 .226562 .264 .351562 .364 .476562 .065 .103515 .165 .228515 .265 .353515 .365 .478515 .066 .105468 .166 .230468 .266 .355468 .366 .460468 .067 .107421 .167 .232421 .267 .357421 .367 .482421 .070 .109375 .170 .234375 .270 .359375 .370 .484375 .071 .111328 .171 .236328 .271 .361328 .371 .486328 .072 .113281 .172 .238281 .272 .363281 .372 .488281 .073 .115234 .173 .240234 .273 .365234 .373 .490234 .074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .19140 .175 .244140 .275 .369140 .375 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>								
.065 .103515 .165 .228515 .265 .353515 .365 .478515 .066 .105468 .166 .230468 .266 .355468 .366 .460468 .067 .107421 .167 .232421 .267 .357421 .367 .482421 .070 .109375 .170 .234375 .270 .359375 .370 .484375 .071 .111328 .171 .236328 .271 .361328 .371 .486328 .072 .13281 .172 .238281 .272 .363281 .372 .488281 .073 .115234 .173 .240234 .273 .365234 .373 .490234 .074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .119140 .175 .244140 .276 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093								
.066105468								,
.067 .107421 .167 .232421 .267 .357421 .367 .482421 .070 .109375 .170 .234375 .270 .359375 .370 .484375 .071 .111328 .171 .236328 .271 .361328 .371 .486328 .072 .113281 .172 .238281 .272 .303281 .372 .488281 .073 .115234 .173 .240234 .273 .365234 .373 .490234 .074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .119140 .175 .244140 .276 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093								
.070 .109375 .170 .234375 .270 .359375 .370 .484375 .071 .111328 .171 .236328 .271 .361328 .371 .486328 .072 .113281 .172 .238281 .272 .363281 .372 .488281 .073 .115234 .173 .240234 .273 .365234 .373 .490234 .074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .119140 .175 .244140 .275 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093								
.071 .111328							, 367	.482421
.071 .111328 .171 .236328 .271 .361328 .371 .486328 .072 .113281 .172 .238281 .272 .3053281 .372 .488281 .073 .115234 .173 .240234 .273 .365234 .373 .490234 .074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .119140 .175 .244140 .276 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093					. 270	. 359375	.370	.484375
.072 .113281 .172 .238281 .272 .363281 .372 .488281 .073 .15234 .173 .240234 .273 .365234 .373 .490234 .074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .19140 .175 .244140 .275 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093)		.271	,361328		
.073 .115234 .173 .240234 .273 .365234 .373 .490234 .074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .119140 .175 .244140 .275 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093					.272	.363281		
.074 .117187 .174 .242187 .274 .367187 .374 .492187 .075 .119140 .275 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093	. 073				.273		,	
.075 .19140 .175 .244140 .275 .369140 .375 .494140 .076 .121093 .176 .246093 .276 .371093 .376 .496093	. 074		, 174	.242187	. 274	.367187		
.076 .121093 .176 .246093 .276 .371093 .376 .496093	. 075		. 175	.244140				
077 122046 197 640046 777	.076			.246093				
	.077	, 123046	. 177	. 248046			1	
					1		1	
			L		1		<u> </u>	

OCTAL-DECIMAL FRACTION CONVERSION TABLE (continued)

Octal	Decimal	Octal	Decimal	Octal	Decimal	Octal	Decima
000000	,000000	.000100	.000244	.000200	000488	.000300	.000732
1000QQ	.000003	.000101	.000247	.000201	,000492	.000301	,000736
000002	,000007	,000102	.000251	.000202	.000495	.000302	.000740
000003	.000011	.000103	.000255	.000203	.000499	,000303	.000743
000004	,000015	.000104	. 00025 9	.000204	.000503	,000304	,000747
000005	.000019	.000105	.000263	.000205	.000507	.000305	.000751
000006	.000022	.000106	.000267	.000206	.000511	.000306	.000755
000007	.000026	.000107	. 000270	.000207	.000514	.000307	.000759
000010	.000030	,000110	.000274	.000210	,000518	.000310	.000762
000011	.000034	,000111	.000278	,000211	, D00522	.000311	.000766
000012	.000038	.000112	.000282	,000212	.000526	.000512	.000770
000013	.000041	.000113	,000286	.000213	.000530	.000313	.000774
000014	.000045	,000114	.000289	,000214	,000534	.000314	.000778
000015	.000049	.000115	.000293	,000215	.000537	.000315	.000782
000016	, 000053	.000116	,000297	.000216	.000541	.000316	.000785
600017	,000067	.000117	.000301	.000217	.000545	.000317	.000769
000020	. 000061	.000120	.000305	.000220	, 000549	.000320	.000793
000021	.000064	.000121	.000308	.000221	,000553	. 000321	,000797
000022	,00006B	.000122	.000312	.000222	.000556	,000322	.000801
000023	.000072	,000123	.000316	.000223	. 000560	.000323	.000805
000023	.000076	,000124	.000320	.000224	.000564	.000324	.000808
000025	,000080	.000125	.000324	,000225	.000568	.000325	,000812
000026	.000083	.000126	.000328	,000226	.000572	.000326	.000816
000027	.000087	.000127	.000331	.000227	,000576	.000327	.000820
		.000130	.000335	.000230	.000579	,000330	,000823
000030	.000091	.000130	,000339	,000231	.000583	.000331	000827
000031	. 000095	.000131	,000343	,000232	,000587	.000332	,000831
000032	.000099	.000132	.000347	.000233	,000591	,000333	.000835
000033	.000102	.000133	,000350	.000234	.000595	.000334	.000839
000034	.000106		.000354	.000235	,000598	.000335	.000843
000035	,000110	,000135	.000354	.000236	.000602	.000336	.000846
000036	.000114	,000136		.000237	.000606	.000337	,000850
000037	.000118	.000137	.000362		.000610	.000340	.000854
000040	,000122	.000140	.000366	.000240	,000614	.000341	.000858
000041	,000125	.000141	.000370	.000241	.000617	.000342	.000862
.0000 42	.000129	.000142	.000373	.000242	.000621	,000343	,000865
.000043	,000133	.000143	.000377	,000243	•	,000344	. 000869
.000044	,000137	.000144	.000381	.000244	.000625	.000345	,000873
.000045	.000141	.000145	.000385	,000245	.000629 .000633	.000346	.000877
,000046	.000144	.000146	.000389	.000246	.000637	.000347	,00088
.000047	.000148	.000147	.000392	,000247			
, 000050	.000152	.000150	.000396	.000250	.000640	.000350	.000888
.000051	.000156	.000151	.000400	.000251	,000644	.000351	-
, 000052	.000160	,000152	,000404	.000252	.000648	.000352	.000892
.000053	.000164	,000153	.000408	.000253	.000652	.000353	,000896
,000054	,000167	.000154	,000411	.000254	.000656	,000354	. 000900
.000055	,000171	.000155	.000415	.000255	.000659	.000355	,000904
,000056	.000175	.000156	.000419	.000256	,000863	. 000356	,00090
.000057	.000179	.000157	.000423	.000257	.000667	.0093	.00091
000060	.000183	,000160	.000427	.000260	,000671	.000360	,00091
000061	.000186	,000161	.000431	.000261	000675	.000361	.00091
000062	,000190	.000162	. 000434	,000262	. 000679	.000362	.00092
000063	000194	.000163	,000438	,000263	,000682	.000363	.00092
000064	.000198	.000164	.000442	.000264	.000686	.000364	.00093
.000065	.000202	.000165	.000446	,000265	.000690	.000365	,00093
.000066	.000205	.000166	.000450	.000266	.000694	.000366	.00093
000067	.000209	.000167	,000453	.000267	.000698	.000367	.00094
.000070	000213	.000179	.000457	.000270	.000701	.000370	,00094
.000071	.000217	.000171	.000461	.000271	.000705	.000371	.00094
000072	,000221	,000172	.000465	.000272	.000709	.000372	.00095
.000073	.000225	,000173	.000469	.000273	.000713	.000373	,00095
.000074	.000228	.000174	.000473	.000274	.000717	,000374	.00096
.000075	,000232	.000175	.000476	.000275	,000720	,000375	.00096
.000076	,000236	.000176	.000480	,000276	.000724	.000376	.00096
.000077	,000240	.000177	.000484	.000277	, p00728	.000377	.00097

OCTAL-DECIMAL FRACTION CONVERSION TABLE (continued)

Octal	Decimal	Octal	Decimal	Octal	Decimal	Octal	Decimal
.000400	.000976	.000500	.001220	.000500	.001464	.000700	.001708
.000401	.000980	.000501	.001224	.000601	.001468	.000701	,001712
.000402	.000984	,000502	,001228	.000602	.001472	.000702	.001716
, 000403	.000988	.000503	.001232	,000603	.001476	.000703	.001720
.000404	.000991	.000504	.001235	.000604	.001480	.000704	.001724
.000405	.000995	.000505	.001239	.000605	,001483	.000705	.001728
.000406	.000999	.000506	.001243	,000606	,001487	.000706	.001731
,000407	.001003	.000507	.001247	.000607	.001491	,000707	.001735
.000410	.001007	.000510	.001251	,000610	.001495	.000710	.001739
.000411	.001010	.000511	.001255	,000611	,001499	.000711	.001743
.000412	.001014	.000512	.001258	.000612	.001502	.000712	,001747
,000413	.001018	.000513	.001262	.000613	.001506	.000713	,001750
.000414	.001022	.000514	.001266	.000614	.001510	.000714	.001754
.000415	.001026	.000515	.001270	.000615	.001514	.000715	.001758
.000416	.001029	.000516	.001274	.000616	.001518	.000716	.001762
.000417	.001033	.000517	.001277	.000617	.001522	,000717	.001766
.000420	.001037	.000520	.001281	.000620	.001525	.000720	.001770
.000421	.001041	.000521	.001285	. 000621	,001529	.000721	.001773
.000422	.001045	.000522	.001289	. 000622	.001533	.000722	.001777
.000423	.001049	.000523	.001293	,000623	.001537	.000723	,001781
.000424	.001052	.000524	.001296	.000624	.001541	.000724	.001785
.000425	.001056	.000525	.001300	.000625	.001544	.000725	.001789
,000426	,001060	.000526	.001304	.000626	,001548	.000726	.001792
.000427	.001064	.000527	.001308	.000627	.001552	.000727	.001796
.000430	.001068	.000530	.001312	.000630	.001556	.000730	.001800
.000431	.001071	.000531	.001316	,000631	.001560	.000731	.001804
.000432	.001075	.000532	.001319	.000632	.001564	.000732	.001808
.000433	.001079	,000533	.001323	.000633	.001567	.000733	.001811
.000434	.001083	.000534	.001327	. 000634	.001571	.000734	.001815
.000435	.001087	,000535	.001331	, 000635	.001575	.000735	.001019
.000436	.001091	.000536	.001335	.000636	.001579	.000736	.001823
.000437	.001094	.000537	.001338	.000637	.001583	.000737	.001827
.000440	.001098	.000540	.001342	.000640	.001586	.000740	.001831
.000441	.001102	,000541	.001346	.000641	.001590	.000741	.001034
,000442	.001106	.000542	.001350	,000642	.001594	.000742	.001838
.000443	.001110	.000543	.001354	.000643	.001598	.000743	,001842
.000444	. 001113	.000544	.001358	.000644	.001602	.000744	.001846
,000445	001117	.000545	.001361	.000645	.001605	.000745	.001850
.000446	.001121	.000546	.001365	.000646	.001609	.000746	,001853
.000447	.001125	.000547	.001369	.000647	.001613	.000747	.001857
.000450	.001129	.000550	.001373	.000650	.001617	.000750	.081861
.000451	.001132	.000551	.001377	.000651	.001621	,000751	,001865
.000452	.001136	.000552	.001380	. 000652	.001625	.,000752	.001869
.000453	.001140	.000553	.001384	.000653	.001628	.000753	.001873
.000454	.001144	.000554	.001388	.000654	.001632	.000754	.001876
.000455	.001148	.000555	.001392	.000855	.001636	.000755	.001880
.000456	.001152	.000556	.001396	.000656	.001640	.000756	.001884
.000457	.001155	.000557	.001399	,000657	,001644	.000757	,001868
.000460	,001159	.000560	,001403	.000660	,001647	.000760	.001892
.000461	.001163	.000561	.001407	.000661	.001651	.000761	.001895
.000462	,001167	.000562	.001411	.000662	,001655	,000762	.001899
,000463	,001171	.000563	.001415	.000663	.001659	.000763	.001903
,000464	001174	.000564	,001419	000664	.001663	.000764	,001907
.000465	.001178	.000565	.001422	.000665	.001667	.000785	,001911
,000466	.001182	.000566	.001426	1000666	.001670	.000766	.001914
.000467	.001186	.000567	,001430	.000667	.001674	. 000767	.001918
.000470	.001190	.000570	.001434	,500670	.001678	.000770	.001922
.000471	.001194	.000571.	.001438	.000671	.001682	.000771	,001926
.000472	.001197	,000572	.001441	.000672	.001686	.000772	.001930
.000473	.001201	.000573	.001445	000673	.001689	. 000773	.001934
.000474	.001205	.090574	.001449	.000674	.001693	.000774	.001937
,000475	.001209	,000575	.001453	,000675	,001697	.000775	.001941
.000476 .000477	.001213	.000576	,001457	.000676	.001701	.000776	.001945
	.001216	.000577	,001461	.000677	.001705	.000777	.001949
,000111	-	-		i i			

APPENDIX 6

PERFORATED TAPE LOADER SEQUENCES

READIN MODE LOADER

The readin mode (RIM) loader is a minimum length, basic, perforated tape reader program for the 33 ASR. It is initially stored in memory by manual use of the operator console keys and switches. The loader is permanently stored in 18 locations on page 37.

A perforated tape to be read by the RIM loader must be in RIM format:

Tape Channel	
876545321	Format
10000.000	Leader-trailer code
01 A1. A2	Absolute address to
00 A3 . A4	contain next 4 digits
0 0 X1 . X2	Content of previous
0 0 X3 . X4	4-digit address
01 A1 . A2	
00 A3 A4	Address
0 0 X1 . X2	
0 0 X3 . X4	^
00 A3 , A4	Content
(Etc.)	(Etc.)
10000,000	Leader-trailer code

The RIM loader can only be used in conjunction with the 33 ASR reader (not the high-speed perforated tape reader). Because a tape in RIM format is, in effect, twice as long as it need be, it is suggested that the RIM loader be used only to read the binary loader when using the 33 ASR. (Note that PDP-8 diagnostic program tapes are in RIM format.)

The complete PDP-8 RIM loader (SA = 7756) is as follows:

Absolute Address	Octal Content	Tag	Instruction I Z	Comments
7756,	6032	BEG.	KCC	CLEAR AC AND FLAG
7757,	6031		KSF	/SKIP IF FLAG = 1
7760,	5357		JMP1	/LOOKING FOR CHARACTER
7761,	6036		KRB	/READ BUFFER
7762,	7106		CLL RTL	
7763,	7006		RTL	CHANNEL 8 IN ACO
7764,	7510		SPA	CHECKING FOR LEADER
7765,	5357		JMP BEG+1	/FOUND LEADER
7766,	7006		RTL	OK, CHANNEL 7 IN LINK
7767,	6031		KSF	
7770,	5367		I—. 9ML	
7771,	6034		KR\$	
7772,	7420		SNL	/READ, DO NOT CLEAR
7773,	3776		DCA I TEMP	CHECKING FOR ADDRESS
7774,	3376		DCA TEMP	STORE CONTENT
7775,	5356		JMP BEG	STORE ADDRESS
7776,	0	TEMP	0	/NEXT WORD
7777,	JMP STAR	T OF BIN LOADER	0	/TEMP STORAGE

Placing the RIM loader in core memory by way of the operator console keys and swtiches is accomplished as follows:

- 1. Set the starting address 7756 in the switch register (SR).
- 2. Press LOAD ADDRESS key.
- 3. Set the first instruction (6032) in the SR.
- 4. Press the DEPOSIT key.
- 5. Set the next instruction (6031) in the SR.
- 6. Press DEPOSIT key.
- 7. Repeat steps 5 and 6 until all 16 instructions have been deposited.

To load a tape in RIM format, place the tape in the reader, set the SR to the starting address 7756 of the RIM loader (not of the program being read), press the LOAD ADDRESS key, press the START key, and start the Teletype reader.

Refer to Digital Program Library document Digital-8-1-U for additional information on the Readin Mode Loader program.

BINARY LOADER

The binary loader (BIN) is used to read machine language tapes (in binary format) produced by the program assembly language (PAL). A tape in binary format is about one half the length of the comparable RIM format tape. It can, therefore, be read about twice as fast as a RIM tape and is, for this reason, the most desirable format to use with the 10 cps 33 ASR reader or the Type 750C High Speed Perforated Tape Reader.

The format of a binary tape is as follows:

Leader: about 2 feet of leader-trailer codes.

BODY: characters representing the absolute, machine language program in easy-to-read binary (or octal) form. The section of tape may contain characters representing instructions (channels 8 and 7 not punched) or origin resettings (channel 8 not punched, channel 7 punched) and is concluded by 2 characters (channels 8 and 7 not punched) that represent a checksum for the entire section.

Trailer: same as leader

Example of the format of a binary tape:

Tape Channel	Memory		
876545321	Location	Content	Comments
	*****		 -
10000.000			leader-trailer code
01000.010			
00000.000		0200	
00111.010			
00000.000	0200	CLA	origin setting
00001.010			
00111,111	0201		TAD 277
00011.010			
00111.110	0202	DCA 276	
00111.100			
00000.010	0203	HLT	
01000.010			· <u></u>
00111.111		0277	origin setting
00000.000	1.1	· · · · · · · · · · · · · · · · · · ·	
00101.011	0277	0053	
00001.000			
00000.111		1007	sum check
10000.000			leader-trailer code

After a BIN tape has been read in, one of the two following conditions exists:

- a. No checksum error: halt with AC = 0
- b. Checksum error: halt with AC = (computed checksum)—(tape checksum)

Operation of the BIN loader in no way depends upon or uses the RIM loader. To load a tape in BIN format place the tape in the reader, set the SR to 7777 (the starting address of the BIN loader), press the LOAD ADDRESS key, set SR switch 0 up for loading via the Teletype unit or down for loading via the high speed reader, then press the START key, and start the tape reader.

Refer to Digital Program Library document Digital-8-2-U-RIM for additional information on the Binary Loader program.

