



CARD NO. 2

CARD NO. 1

CARD NO. 3

	CARD 3	CARD 2	CARD 1	
P3A	P3B	P2A	P2B	P1
10				15VH
	R	10, L		15VH
	15, S	12, N	20, F	15VA
	16, T	13, P	27, Z	15VA
	17, U	14, R	22, E	15VL
3, K	M		A, 23, 31, K, M	ACND
	V	15, S	21, Y	LGND
			B	PWRG
				+5VH

Qume
 PRINTER INTERCONNECT
 DIAGRAM MOTHER BOARD
 NONE 1 2
 90600-XXM

PRINTER
 DISABLE
 TOGGLE SW
 COVER
 INTERLOCK

FORM
 ADVANCE
 PUSHBUTTON
 SW.

MOVE
 RIBBON
 PUSHBUTTON
 SW.

OUT OF PAPER
 SENSORS (2)

HAMMER
 COIL
 RIBBON
 LIFT
 COIL
 RIBBON
 MOTOR

PW ENCODER

EOR SENSOR

J 0657	K 0684
L 0571	H 0614
E 0539	F 0574
C 0453	D 0610
A 0420	B 0446