
P1 (1) ENCOD A FROM J11-3
P1 (19) FROM J11-4
P1 (13) CAR EOT SOURCE TO J5-1
P1 (20) ENCOD B FROM J11-5
P1 (16) FROM J11-4
P1 (5) CLEAR FROM P11-6
P1 (18) CA EOT SENSOR FROM J5-1
"POS. COMP"
POS COMPENSATION
"AMP COMP"
"ASUM"
"BSUM"
AMP. COMPENSATION
VELOCITY REFERENCE
- = RIGHT
+ = LEFT
VELOCITY
CA CLK
TO P2A-R, P3A-V
CA DIR (LEFT)
CA DIR (RIGHT)
CA LED +
TO J11-1
CA LIMIT
TO P2A-X
SCHEMATIC
BOARD 1 - PRINTER
90610-XX AA