NEXT ASSY	USED ON	REVISIONS			
		REV.	DESCRIPTION	DATE	APPR.
		—	RELEASED DCR 100142	10-11-77	—

The following modifications are required to incorporate SM1+ & WAIT+ Options to the CPU Board up to Revision D.

Modification for SM1+

1. Cut Trace from IC17-3 to IC16-7 on front of board. Sheet 2.
2. Cut trace from IC8-5 to P1-97.
3. Jumper IC17-3 to IC14-4. Sheet 4.
4. Jumper IC8-5 to P1-44. Sheet 4, 5.

   The following steps must be made to complete this Jumper.

   A. Solder to IC8-5 using #28 AWG insulated wire. Feed wire thru Feedthru hole as shown on sheet 3. Solder other end to P1-44 on component side of Board. Note: Solder to no more than the top (away from edge of card) 1/16" of the gold Tab. Gold provides an excellent surface for solder flow when hot. You must be very careful not to heat the gold Tab more than necessary or solder will coat the entire Tab (solder cannot be removed from the gold surface). Sheet 5.

Modification for WAIT+

5. Jumper IC14-24 to IC8-3. Sheet 4.
6. Jumper IC8-2 to P1-27. Sheet 4.

Notes: SWO is eliminated by this modification.

This mod. retains HLTA and INTA for use w/Extensys memory cards.

D. Sanchez	10-11-77	
CK		
R. JHH	10-11-77	

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION. IT MAY NOT BE REPRODUCED OR TRANSFERRED TO OTHER DOCUMENTS OR DISCLOSED TO OTHERS OR USED FOR MANUFACTURING OR ANY OTHER PURPOSE WITHOUT PRIOR WRITTEN PERMISSION.

PolyMorphic Systems
460 Ward Drive
Santa Barbara Ca
93111 (805) 967-2351

MODIFICATION -#2 SM1 & WAIT +

SIZE		DRAWING NUMBER	REV
A	SHEET 1 OF 5	104933	



NUMBER:
104933

PAGE 2 OF



2

NUMBER:
104435

PAGE 3 OF



NUMBER:
104433
PAGE 4 OF



NOTE: Coat Gold Tabs with white Solder Mask or masking tape showing only the top portion of the tab as shown.