

PERTEC

PRODUCT IMPROVEMENT BULLETIN

PERIPHERAL EQUIPMENT DIVISION

TITLE			NEW MANUFACTURER OF FRONT PANEL SWITCHES	PIB NO. DK3053 A
PRODUCT LINE:	TAPE DISK FORMATTER <input checked="" type="checkbox"/>	EQUIPMENT CHANGED Switch Assemblies 103663	MODEL SERIES AFFECTED D3000	EFFECTIVE DATE April 5, 1976
CLASS OF BULLETIN:		ORDER PART KIT NO.	EFFECTIVITY	
<input type="checkbox"/> IMPROVEMENT <input type="checkbox"/> RETROFIT ON FAILURE <input type="checkbox"/> RETROFIT RECOMMENDED <input checked="" type="checkbox"/> SERVICE INFORMATION ONLY		N/A	February 1976	
<p><u>PURPOSE:</u> To inform customers of new improved switch assemblies.</p> <p><u>INFORMATION:</u></p> <ol style="list-style-type: none"> Commencing in February, 1976, we have started using a new switch assembly manufactured by <u>MICROSWITCH</u>. The switch has two centered contacts for the lamp and three along the edge of the switch. The contacts are marked as normally open (NO) and normally closed (NC) with the common switch contact in the center. The internal switch contacts can be extracted for inspection. The single indicator (only) assembly used in the SAFE and READY positions, has two contacts for the lamp. The dual indicator (only) assembly, used in the PROT/PROT position, has two pairs of contacts, one pair for each lamp. <u>Lamps.</u> These assemblies use a 14 V lamp, PERTEC P/N 659-0730, commercial # 73, Wedgebase. To remove a lamp from the above assemblies, remove the cap and use the built-in lamp ejector. 				
<u>Assembly No.</u>	<u>Legend</u>	<u>Type</u>	<u>Body</u>	<u>Cap</u>
103663-27	Run/Stop	Switch	<i>DELETE</i>	
103663-28	Safe	Indicator		
103663-29	Ready	Indicator		
103663-30	Prot/Prot	Dual Indicator		

Should Additional Information Be Required — Contact

PERTEC

PERIPHERAL EQUIPMENT DIVISION

9600 Irondale Avenue, Chatsworth, California 91311

Phone (213) 882-0030 / TWX (910) 494-2093

ATTENTION: PRODUCT SUPPORT MANAGER

PERTEC 20-K012 (1)

Distribution Code - 6318