

IDENTIFICATION

PRODUCT CODE: MAINDEC-08-DIGD-D  
PRODUCT NAME: PDP-8, 81, 8S EXTENDED MEMORY CONTROL  
DATE CREATED: JULY 27, 1970  
MAINTAINER: DIAGNOSTIC PROGRAMMING GROUP  
AUTHOR: J. RICHARDSON/L. BEYERSDORFER

COPYRIGHT © 1970  
DIGITAL EQUIPMENT  
CORPORATION

M. C. N. REQUIRED  
THIS PROGRAM REQUIRES MCM(S)  
IN ORDER TO WORK PROPERLY



1. ABSTRACT  
-----

THIS PROGRAM TESTS THE EXTENDED MEMORY CONTROL LOGIC FOR PROPER OPERATION; IT MAY BE USED WITH A PDP-8, 81, OR 8S EQUIPPED WITH A MINIMUM OF 4K OF EXTENDED MEMORY. THE PROGRAM EXERCISES AND TESTS THE CONTROL IOT'S; THE ABILITY TO REFERENCE ALL FIELDS FROM 0; PROGRAM INTERRUPT AND INTERRUPT INHIBIT; AUTO-INDEXING IN EACH FIELD, AND A SPECIAL TEST FOR THE PDP-81 WHICH TESTS THE PRESENCE OF A FALSE MEMORY PULSE WHEN A NON-EXISTENT MEMORY FIELD IS REFERENCED.

ERRORS ENCOUNTERED DURING RUNNING WILL RESULT IN A PROGRAM HALT. THE HALT LOCATIONS ARE LABELED, AND THE ERROR MAY BE IDENTIFIED BY REFERENCING THE PROGRAM LISTING OR TABLE OF ERROR HALTS.

2. REQUIREMENTS  
-----

2.1 EQUIPMENT  
-----

A STANDARD PDP-8, 81 OR 8S EQUIPPED WITH AN EXTENDED MEMORY CONTROL, AND AT LEAST 4K OF EXTENDED MEMORY.

2.2 STORAGE  
-----

THE PROGRAM REQUIRES 2400(8) LOCATIONS OF CORE MEMORY. THE PROGRAM MUST RESIDE IN MEMORY FIELD 0 ONLY.

2.3 PRELIMINARY PROGRAMS  
-----

ALL PROGRAMS FOR A BASIC PDP-8, 81 OR 8S MUST HAVE BEEN PREVIOUSLY RUN SUCCESSFULLY.

3. LOADING PROCEDURE  
-----

3.1 METHOD  
-----

THE PROGRAM IS LOADED WITH THE BINARY LOADER.

4. STARTING PROCEDURE  
-----

4.1 STARTING ADDRESSES  
-----

THE STARTING ADDRESS IS 0200(8).

4.2 CONTROL SWITCH SETTINGS  
-----

SR 8 MUST BE ON A 1 IF A PDP-8I IS BEING USED. OTHERWISE, ON A 0 FOR A PDP-8 OR 8S. SR 9, 10 AND 11 MUST CONTAIN AN OCTAL VALUE EQUAL TO THE NUMBER OF EXTENDED MEMORY FIELDS AVAILABLE (1 TO 7 OCTAL). NOTE THAT FIELD 0 IS NOT TO BE INCLUDED IN THIS VALUE.

4.3 OPERATOR ACTION  
-----

WITH THE PROGRAM IN MEMORY, SET THE SWITCH REGISTER TO 0200 OCTAL. PRESS LOAD ADDRESS.

SET SR 8 TO A 1 IF A PDP-8I IS BEING USED. OTHERWISE, SET SR 8 TO A 0.

PLACE THE OCTAL NUMBER OF EXTENDED MEMORY FIELDS AVAILABLE IN SR 9, 10 AND 11. THIS VALUE MAY VARY FROM 1 TO 7 ONLY.

PRESS START.

THE PROGRAM WILL RUN UNTIL AN ERROR IS DETECTED, OR STOPPED BY THE OPERATOR. THE TTY BELL IS RUNG ONCE AFTER ONE COMPLETE PASS OF THE PROGRAM.

5. OPERATING PROCEDURE  
-----

SEE SECTION 4.2

5.1 SUBROUTINE ABSTRACTS  
-----

REFER TO THE PROGRAM LISTING FOR DESCRIPTIONS OF EACH TEST, AND THE METHOD OF TESTING.

5.2 OPERATOR ACTION  
-----

SEE SECTION 4.3

6. ERRORS  
-----

6.1 ERROR HALTS AND DESCRIPTIONS  
-----

TABLE OF ERROR HALTS

C (MA)	TAG	DESCRIPTIONS
--------	-----	--------------

-----  
CDF AND RDF TESTS  
-----

206	E1	CDF 0 OR RDF FAILED.
217	E2	CDF 7 OR RDF FAILED.
234	E3	CDF 1 OR RDF FAILED.
245	E4	CDF 2 OR RDF FAILED.
262	E5	CDF 3 OR RDF FAILED.
273	E6	CDF 4 OR RDF FAILED.
310	E7	CDF 5 OR RDF FAILED.
321	E8	CDF 6 OR RDF FAILED.

-----  
DF, IB AND SR TESTS  
-----

341	E9	RIB OR ION FAILED.
351	E10	DF NOT CLEARED, OR NO INTERRUPT.
360	E11	RIB OR SF FAILED. (DF 1)
410	E12	DF NOT CLEARED, OR NO INTERRUPT.
417	E13	RIB OR SF FAILED. (DF 2)
427	E14	DF NOT CLEARED, OR NO INTERRUPT.
436	E15	RIB OR SF FAILED. (DF 3)
452	E16	DF NOT CLEARED, OR NO INTERRUPT.
461	E17	RIM OR SF FAILED. (DF 4)
471	E18	DF NOT CLEARED, OR NO INTERRUPT.
500	E19	RIB OR SF FAILED. (DF 5)
514	E20	DF NOT CLEARED, OR NO INTERRUPT.
523	E21	RIB OR SF FAILED. (DF 6)
533	E22	DF NOT CLEARED, OR NO INTERRUPT.
542	E23	RIB OR SF FAILED. (DF 7)

-----  
DCA I AND TAD I TESTS  
-----

653	E24	DCA I OR TAD I TO AN EXTENDED FIELD FAILED; THE DF INDICATORS EQUAL THE CURRENT FIELD UNDER TEST. THE AC CONTAINS THE DATA AS READ FROM LOCATION 7000 OF THE EXTENDED FIELD. THE HALT OCCURRED DUE TO THE DATA READ AND THE CURRENT DATA FIELD NOT BEING EQUAL. EACH EXTENDED FIELD SHOULD CONTAIN ITS FIELD NUMBER IN LOCATION 7000.
-----	-----	---

C (MA)	TAG	DESCRIPTION
1132	E40	CIF OR INTERRUPT FAILED, THE DF AND IF SHOULD EQUAL AN EXTENDED FIELD, THE DF WAS NOT CLEARED AFTER THE INTERRUPT, ALL OTHER FUNCTIONS WORKED PROPERLY, RMF OR SF FAILED, THE SF REGISTER SHOULD HAVE SAVED, THE EXTENDED FIELD NUMBER AFTER INTERRUPT, THE AC=C (I.B.) AFTER AN RMF?
1203	E41	ALL FUNCTIONS WORKED, BUT THE PC DID NOT EQUAL LOCATION E40+1 AFTER THE INTERRUPT IN THE EXTENDED FIELD FAILED, THE AC=CONTENTS OF LOCATION 0, FIELD 0,
1221	E42	LOCATION 4 IN THE EXTENDED FIELD, THE INTERRUPT WENT TO THIS FIELD INSTEAD OF FIELD 0, OR THE JMP 12 AT LOCATION 7777 WAS ENABLED IN LOCATION E40 IN THE EXTENDED FIELD,
1235	E43	LOCATION 10 IN THE EXTENDED FIELD, THE JMP 12 AT LOCATION 7777 WAS NOT EXECUTED, OR INTERRUPT FAILED.
4	E44	
10	E45	

1420	E45A	NO PROGRAM INTERRUPT OCCURRED, PRESS CONTINUE TO TRY AGAIN. MEMORY FIELD 1 HALT, AN INTERRUPT IN FIELD 0 WAS FOLLOWED BY A CIF 10 IOT, AND THEN AN RMF, THE RMF SHOULD HAVE RESTORED THE IB TO FIELD 0, THE SF AND IB WERE OR'D TOGETHER RESULTING IN THE IF BEING SET TO FIELD 1, AFTER THE JMP INSTRUCTION AT LOCATION 1430, RESTART FROM 1400 TO REPEAT THE TEST.
7000	"	

(6.1 CONT'D.)

CIF TESTS (JMP AND JMS ENABLING)

PROGRAM INTERRUPT IS ENABLED FOR THESE TESTS. A CIF IS ISSUED FOLLOWED BY AN ION AND A JMP OR JMS. AN INTERRUPT SHOULD OCCUR AFTER THE JMP OR JMS AND CONTROL TRANSFERRED TO FIELD 0. THE SAVE FIELD SHOULD CONTAIN THE FIELD COMMANDED BY THE CIF. A HLT IS PLACED IN LOCATION 1 OF EACH EXTENDED FIELD IN CASE THE IF IS NOT CLEARED AT THE TIME OF THE INTERRUPT.

C (MA)	TAG	DESCRIPTION
727	E25	NO INTERRUPT OR INTERRUPT INHIBIT FAILED.
741	E26	I.B. TO I.F. TRANSFER FAILED AFTER CIF=JMP; FAILING I.F. IN AC6=8, GOOD I.F. IN AC9=11.
1024	E27	NO INTERRUPT OR INTERRUPT INHIBIT FAILED.
1036	E30	I.B. TO I.F. TRANSFER FAILED AFTER CIF=JMS; FAILING I.F. IN AC6=8, GOOD I.F. IN AC9=11.
724	E31	I.F. CHANGED AFTER CIF BUT BEFORE JMP, HALT IS IN EXTENDED FIELD.
1020	E32	I.F. CHANGED AFTER CIF BUT BEFORE JMS, HALT IS IN EXTENDED FIELD.

INTERRUPT INHIBIT TEST

A SUBROUTINE IS PLACED IN EACH EXTENDED FIELD TO INSURE THAT PROGRAM INTERRUPT IS INHIBITED AFTER A CIF IOT, AND IS ENABLED AFTER A JMP INSTRUCTION. THE ROUTINE IS IN ONE FIELD AT A TIME! THE CONTENTS OF ALL OTHER EXTENDED FIELDS WILL EQUAL 0000. THE ROUTINE IS DESCRIBED ON THE PROGRAM LISTING AS THE "EXTENDED FIELD TEST ROUTINE", AND IS TAGGED EXFLD.

THE TEST ROUTINE IS ENTERED AT LOCATION E40-1 IN THE EXTENDED FIELD. THIS LOCATION CONTAINS A CIF XX IOT, WHERE XX EQUALS THE EXTENDED FIELD NUMBER. LOCATION E40 CONTAINS AN ION IOT. LOCATIONS E40+1 THROUGH 7776 CONTAIN ALL 0'S. LOCATION 7777 CONTAINS A JMP I 12. THE ROUTINE, THEREFORE, ISSUES A CIF, ION, AND JMP I 12 SEQUENCE. PROGRAM INTERRUPT SHOULD BE INHIBITED UNTIL AFTER THE JMP I 12 AT LOCATION 7777. AN ERROR HALT OCCURS IN FIELD 0 IF AN INTERRUPT OCCURS BETWEEN LOCATIONS E40+1 AND 7777. LOCATION 12 CONTAINS THE LOCATION OF E40 AND WILL AUTO-INDEX TO E40+1.

AUTO-INDEX TEST  
-----

THE SUBROUTINE LABELED "AUTO-INDEX TEST" ON THE LISTING IS PLACED IN EACH EXTENDED FIELD, AUTO-INDEX REGISTERS 10 THROUGH 17 IN EACH FIELD ARE TESTED, ALL OF MEMORY NOT OCCUPIED BY THE SUBROUTINE IS SET TO 0, THE ERROR HALTS TAGGED E46 THROUGH E53 WILL OCCUR IN THE EXTENDED FIELD IF AN AUTO-INDEX REGISTER FAILS, THE DF AND IF INDICATORS WILL DISPLAY THE CURRENT FIELD BEING TESTED.

C (MA)	TAG	DESCRIPTION
-----	---	-----
1523	E46	INDEX REGISTER 10 FAILED.
1526	E47	INDEX REGISTER 11 FAILED.
1531	E48	INDEX REGISTER 12 FAILED.
1534	E49	INDEX REGISTER 13 FAILED.
1537	E50	INDEX REGISTER 14 FAILED.
1542	E51	INDEX REGISTER 15 FAILED.
1545	E52	INDEX REGISTER 16 FAILED.
1550	E53	INDEX REGISTER 17 FAILED.

DYNAMIC RMF TEST  
-----

THIS TEST IS PERFORMED UNCONDITIONALLY JUST PRIOR TO THE NON-EXISTENT MEMORY TEST. IT CHECKS ALL SAVE FIELD TO DATA FIELD REGISTER TRANSFERS AND THOSE SAVE FIELD TO INSTRUCTION BUFFER REGISTER TRANSFERS AS APPLICABLE TO THE NUMBER OF EXTENDED FIELDS PRESENT.

THE GENERAL METHOD IS TO INTERRUPT FROM EACH EXTENDED FIELD WITH THE DF SET FROM 0 THROUGH 7, AN RMF INSTRUCTION IS THEN ISSUED AND CONTROL IS TRANSFERRED TO AN EXTENDED FIELD. THE "RMFDY" ROUTINE IN THAT FIELD THEN CHECKS THAT THE RESTORED IF AND DF ARE CORRECT. IF NOT, THE PROGRAM HALTS WITH THE FAILING IF OR DF IN THE IF OR DF REGISTER, AND THE CORRECT FIELD NUMBER IN AC BITS 6 THROUGH 8.

1706	E60	NO INTERRUPT OCCURRED.
1716	E61	SF TO DF TRANSFER FAILED AFTER RMF. BAD DF IN DF REGISTER) CORRECT DF IN AC6=8.
1725	E62	SF TO IB TRANSFER FAILED AFTER RMF. BAD IF IN IF REGISTER) CORRECT IF IN AC6=8.

NON-EXISTENT MEMORY TEST  
-----

THIS IS THE LAST TEST PERFORMED, AND IS INCLUDED FOR PDP-8I'S ONLY. THE TEST MAKES SURE THAT A FALSE MEMORY DONE PULSE IS GENERATED WHEN THE DF IS SET TO A NON-EXISTENT MEMORY FIELD. IF THE PDP-8I BEING USED IS EQUIPPED WITH THE MAXIMUM OF 32K OF CORE MEMORY, THE PROGRAM AUTOMATICALLY SKIPS THIS TEST AND RESTARTS AT LOCATION 200. SR 8 ON A 0 WILL CAUSE THE PROGRAM TO ALWAYS SKIP THIS TEST.

THE TEST ALSO MAKES CERTAIN THAT THE CORRECT DATA IS DEPOSITED IN THE AC WHEN A NON-EXISTENT FIELD IS REFERENCED. THIS DATA MUST ALWAYS EQUAL 0000 OR 7777 OCTAL, DEPENDING ON THE NUMBER OF EXTENDED FIELDS EXISTING, FOR EXAMPLE, IF THE PDP-8I IS EQUIPPED WITH FIELDS 0,1,2 AND 3, ANY REFERENCE WITH A TAD 1 TO FIELDS 4 THROUGH 7 SHOULD RESULT WITH 7777 OCTAL IN THE AC. IF EQUIPPED WITH FIELDS 0,1, AND 2, A TAD 1 TO FIELD 3 SHOULD RESULT WITH 0000 OCTAL IN THE AC, AND REFERENCING 4 THROUGH 7 WILL RESULT WITH 7777 OCTAL IN THE AC. IN OTHER WORDS, REFERENCING THE LOWEST ORDER NON-EXISTENT FIELD, WHEN THE TOTAL NUMBER AVAILABLE IS ODD, WILL RESULT WITH 0000 IN THE AC. REFERENCING ALL OTHER NON-EXISTENT FIELDS WILL RESULT WITH 7777 IN THE AC. WHEN THE TOTAL NUMBER AVAILABLE IS EVEN, REFERENCING ANY NON-EXISTENT FIELD WILL RESULT WITH 7777 IN THE AC.

THE ONLY LEGAL HALTS IN THIS TEST, ARE AT LOCATIONS 2300 AND 2325. IF THE COMPUTER HALTS AT ANY OTHER LOCATION, THE FALSE MEMORY DONE PULSE PROBABLY WAS NOT GENERATED.

THE FALSE MEMORY DONE PULSE IS NOT GENERATED WHEN A CIF TO A NON-EXISTENT FIELD IS ATTEMPTED.

C(MA)	TAG	DESCRIPTION
2300	E54	ALL 0'S SHOULD HAVE BEEN DEPOSITED IN THE AC, OR AN EXISTING FIELD WAS REFERENCED. MAKE SURE THE PROPER VALUE IS IN SR 9-11. THE NUMBER OF EXTENDED FIELDS AVAILABLE MUST BE IN SR 9-11.
2325	E57	ALL 1'S SHOULD HAVE BEEN DEPOSITED IN THE AC, OR AN EXISTING FIELD WAS REFERENCED. MAKE SURE THE PROPER VALUE IS IN SR 9-11.

6.2 ERROR RECOVERY  
-----

PRESS CONTINUE TO REPEAT THE FAILING TEST. PLACE A NOP IN THE ERROR HALT LOCATION TO LOOP ON A FAILING TEST. RESTART FROM 1400 AFTER A HALT AT 7000 IN FIELD 1.

7. RESTRICTIONS  
-----

7.1 STARTING RESTRICTIONS  
-----

NONE

7.2 OPERATING RESTRICTIONS  
-----

THE NUMBER OF EXTENDED MEMORY FIELDS AVAILABLE MUST BE IN  
SR 9-11 BEFORE STARTING FROM LOCATION 200.

8. MISCELLANEOUS  
-----

8.1 EXECUTION TIME  
-----

RUNNING TIME IS DEPENDENT ON THE AMOUNT OF EXTENDED MEMORY FOR  
TESTING, AND ON WHETHER THE PROCESSOR BEING USED IS A PDP-8,  
OR 8S. THE TTY BELL WILL RING ONCE FOR EACH PASS OF THE PROGRAM.

9. PROGRAM DESCRIPTION  
-----

THE PROGRAM EXERCISES ALL IOT'S ASSOCIATED WITH THE EXTENDED MEMORY  
CONTROL LOGIC, PLUS THE ABILITY TO REFERENCE EXTENDED FIELDS  
FROM FIELD 0, AND VICE-VERSA. EACH TEST IS LOOPED 4096 TIMES  
BEFORE INITIATING THE NEXT TEST. A SWITCH OPTION IS PROVIDED  
TO SKIP OR EXECUTE A NON-EXISTENT MEMORY TEST FOR THE PDP-8I.

THE INDIVIDUAL TEST ROUTINES AND ERROR HALTS ARE COMMENTED  
ON THE PROGRAM LISTING AS AN AID TO TROUBLE-SHOOTING. SECTION  
6 CONTAINS A TABLE OF ERROR HALTS WHICH ALSO MAY BE REFERENCED.

10. LISTING  
-----

/PDP-8, 81, 8S EXTENDED MEMORY CONTROL TEST,  
/COPYRIGHT 1969-1970, DIGITAL EQUIPMENT CORP., MAYNARD, MASS.  
/PLACE NUMBER OF EXTENDED 4K FIELDS AVAILABLE IN SR9 TO 11: (UP TO 7)  
/IF USING AN 81, PLACE SR8 ON A 1, OTHERWISE LEAVE 0.  
/START PROGRAM AT 200

/CONSTANTS

6201 CDF=6201  
6202 CIF=6202  
6214 RDF=6214  
6224 RIF=6224  
6244 RMF=6244  
6234 RIB=6234  
\*1

0001 JMP 1  
0002  
0003

\*20

JMP10: JMP 1 0  
ISE0: 100 0  
XTFLG: TPLG  
XSTKS: NSTKS  
XRMF: TRMF  
XRANS: TRANS  
XAUTO: TAUTO  
LOOP: 0  
NDF: 0 0  
STKS: 0 0  
DAT: 0 0  
NOSTAK: 0  
NOFLD: 0  
KE40M: E40=1  
KE40: E40  
KHLT: HLT  
KCDF: 6201  
KCIF: 6202  
XFD: EXPD  
K1: 1  
K7: 7  
K10: 10  
K7777: 7777  
K7000: 7000  
K7707: 7707  
K7767: 7767  
K7757: 7757  
K7747: 7747  
K7737: 7737  
K7727: 7727  
K7717: 7717

0020 3400  
0021 2000  
0022 2342  
0023 2334  
0024 1047  
0025 1321  
0026 1432  
0027 0000  
0030 0000  
0031 0000  
0032 0000  
0033 0000  
0034 0000  
0035 1131  
0036 1132  
0037 7402  
0040 6201  
0041 6202  
0042 1316  
0043 0001  
0044 0007  
0045 0010  
0046 7777  
0047 7000  
0050 7707  
0051 7767  
0052 7757  
0053 7747  
0054 7737  
0055 7727  
0056 7717

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55

56	0057	7776	K7776,	7776
57	0060	7775	K7775,	7775
58	0061	7774	K7774,	7774
59	0062	7773	K7773,	7773
60	0063	7772	K7772,	7772
61	0064	7771	K7771,	7771
62	0065	7770	K7770,	7770
63	0066	0070	POINT,	.02

64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84

0067	0070	K78,	001
0070	7766	K7766,	7766
0071	7755		7755
0072	7744	K7744,	7744
0073	7733		7733
0074	7722		7722
0075	7711		7711
0076	7700		7700
0077	1126	XTDF,	XTDF
0100	1127	XTDF1,	XTDF+1
0101	1302	KXFLD,	KXFLD
0102	5402	KJMP,	JMP I 2
0103	1200	KNTR,	ENTER
0104	0020	K20,	20
0105	5506	JMP2,	JMP I KFLD0
0106	1427	KFLD0,	RTRN
0107	1422	KRTN,	E49A*2
0110	1400	XFI0,	SF10

```

85 /TEST CDF AND RDF
86 /
87 *200
88
89 /BEGIN, CLA LOOP /LOOP COUNTER
90 0200 7200
91 0201 3027
92
93 /DF0, CDF 00 /DF 0
94 0202 6201
95 0203 6214 RDF /SHOULD NOT SKIP
96 0204 7450 SNA DF7 /ERROR, CDF OR RDF FAILED
97 0205 5211 JMP DF7 /REPEAT
98 0206 7402 HLT
99 0207 7200 CLA
00 0210 5202 JMP DF0
01
02 /DF7, TAD K7707 /7707
03 1050 CDF 70 /DF 7
04 0212 6271 RDF
05 0213 6214 CHA
06 0214 7040 SNA
07 0215 7450 SNA OK1 /SHOULD NOT SKIP
08 0216 5222 JMP OK1 /CDF OR RDF FAILED
09 0217 7402 HLT
10 0220 7200 CLA
11 0221 5211 JMP DF7
12
13 /OK1, ISB LOOP /CHECK DONE
14 0222 2027 JMP DF0
15 0223 5202
16
17 /DF1, CLA LOOP /LOOP COUNTER
18 0224 7200
19 0225 3027
20
21 /DF1, TAD K7767 /7767
22 1051 CDF 10 /DF 10
23 0227 6211 RDF /AC=0
24 0230 6214 CHA
25 0231 7040 SNA DF2 /CDF1 OR RDF FAILED
26 0232 7450 SNA
27 0233 5237 JMP DF2
28 0234 7402 HLT
29 0235 7200 CLA
30 0236 5226 JMP DF1
31
32 /DF2, TAD K7757 /7757
33 1052 CDF 20 /DF2
34 0240 6221 RDF /AC=0
35 0241 6214 CHA
36 0242 7040 SNA
37 0243 7450 JMP OK2
38 0244 5250

```

133									
134	E4,	0245	7402	HLT					
135		0246	7200	CLA					
136		0247	5237	JMP	DF2		/CDF 2 OR RDF FAILED		
137									
138	/OK2,	0250	2027	ISE	LOOP				
139		0251	5226	JMP	DF1		/DONE IF SKIP		
140		0252	7200	CLA					
141		0253	3027	DCA	LOOP				
142									
143	/DF3,	0254	1053	TAD	K7747		/7747		
144		0255	6231	CDF	30		/DF 3		
145		0256	6214	RDF			/AC=0		
146		0257	7040	CMA					
147		0260	7450	SNA	DF4				
148		0261	5205	JMP	DF4				
149	ES,	0262	7402	HLT					
150		0263	7200	CLA			/CDF 3 OR RDF FAILED		
151		0264	5234	JMP	DF3				
152									
153	/DF4,	0265	1054	TAD	K7737		/7737		
154		0266	6241	CDF	40		/DF 4		
155		0267	6214	RDF			/AC=0		
156		0270	7040	CMA					
157		0271	7450	SNA	OK3				
158		0272	5276	JMP	OK3				
159	E6,	0273	7402	HLT					
160		0274	7200	CLA			/CDF 4 OR RDF FAILED		
161		0275	5265	JMP	DF4				
162									
163	/OK3,	0276	2027	ISE	LOOP				
164		0277	5234	JMP	DF3		/DONE IF SKIP		
165									
166	/	0300	7200	CLA					
167		0301	3027	DCA	LOOP				
168									
169	/DF5,	0302	1055	TAD	K7727		/7727		
170		0303	6251	CDF	50		/DFS		
171		0304	6214	RDF			/AC=0		
172		0305	7040	CMA					
173		0306	7450	SNA	DF6				
174		0307	5313	JMP	DF6				
175	E7,	0310	7402	HLT					
176		0311	7200	CLA			/CDF 5 OR RDF FAILED.		
177		0312	5302	JMP	DF5				
178									
179	/DF6,	0313	1056	TAD	K7717		/7717		
180		0314	6261	CDF	60		/DF 6		
181		0315	6214	RDF			/AC=0		
182		0316	7040	CMA					
183		0317	7450	SNA	OK4				
184		0320	5324	JMP	OK4				

```

185 0321 7402      HLT
186 0322 7200      CLA
187 0323 5313      JMP DF6
188
189 0324 2027      /OK4, ISE LOOP /DONE WHEN SKIP
190 0325 5302      JMP DF5
191
192 /NOW TEST INTERRUPT BUFFER (IB) BITS 9-11 WITH
193 /RIB. PI IS ENABLED. TELEPRINTER FLAG IS
194 /USED FOR INTERRUPT.
195 /
196
197 0326 6201      CDF 00 /DF0
198 0327 1020      TAD JMP10 /JMP I0=JMP I 0
199 0330 3001      DCA I /C(1)=JMP I 0
200 0331 3027      DCA LOOP
201 0332 6041      TSP /TEST TTY FLAG
202 0333 4422      JMS I XTFLG /SET FLAG
203
204 0334 6001      /ION /ENABLE PI
205 0335 7200      CLA /READ SF
206 0336 6234      RIB
207 0337 7450      SNA IB1
208 0340 5343      JMP IB1
209 0341 7402      HLT /RIB FAILED
210 0342 5334      JMP IB0
211
212 0343 6211      /ION /DF 1
213 0344 6001      CLA
214 0345 7200      RIB
215 0346 6214      RDF /DF SHOULD BE 0 AFTER A PI
216 0347 7450      SNA /+3
217 0350 5353      JMP /+3
218 0351 7402      HLT
219 0352 5343      JMP IB0 /DF NOT CLEARED, OR NO PI
220
221 0353 1057      TAD K7776
222 0354 6234      RIB /READ SF
223 0355 7040      CHA /AC00
224 0356 7450      SNA OK5
225 0357 5362      JMP OK5
226 0360 7402      HLT
227 0361 5343      JMP IB1 /RIB OR SP FAILED
228 0362 2027      /ISE LOOP /DONE WHEN SKIP
229 0363 5334      JMP IB0
230 0364 5765      JMP I ,+1
231 102-2

```

231	0400	*400			
232	0400	7200	CLA		
233	0401	3027	DCA	LOOP	
234					
235					
236	0402	6221	ODF	20	/DF 2
237	0403	6001	ION		
238	0404	7200	CLA		
239	0405	6214	ODF		/SHOULD BE 0 AFTER PI
240	0406	7450	SNA	.+3	
241	0407	5212	JMP		/DF NOT CLEARED, OR NO PI
242	0410	7402	HLT		
243	0411	5202	JMP	1B2	
244					
245	0412	1060	TAD	K7775	
246	0413	6234	RIB		/ACB7777
247	0414	7040	CMA		/B0
248	0415	7450	SNA		
249	0416	5221	JMP	1B3	/RIB OR SF FAILED
250	0417	7402	HLT		
251	0420	5202	JMP	1B2	
252					
253	0421	6231	ODF	30	/DF3
254	0422	6001	ION		
255	0423	7200	CLA		
256	0424	6214	ODF		/DF SHOULD BE CLEARED
257	0425	7450	SNA	.+3	
258	0426	5231	JMP		/DF NOT CLEARED
259	0427	7402	HLT		
260	0430	5221	JMP	1B3	
261					
262	0431	1061	TAD	K7774	
263	0432	6234	RIB		/ACB7777
264	0433	7040	CMA		/ACB0
265	0434	7450	SNA		
266	0435	5240	JMP	OK6	/RIB OR SF FAILED
267	0436	7402	HLT		
268	0437	5221	JMP	1B3	
269					
270	0440	2027	ISE	LOOP	/DONE IF SKIP
271	0441	5202	JMP	1B2	
272					
273	0442	7200	CLA		
274	0443	3027	DCA	LOOP	
275					
276	0444	6241	ODF	40	/DF 3
277	0445	6001	ION		
278	0446	7200	CLA		
279	0447	6214	ODF		/DF MUST BE 000 AFTER A PI
280	0450	7450	SNA		/ERROR IF SKIP
281	0451	5254	JMP	.+3	

282	0452	7402	E16,	HLT		/DF NOT 0 AFTER PI
283	0453	5244	/	JMP I84		
284						
285	0454	1062	/	TAD K7773	/AC=7773	
286	0455	6234		RIB	/AC=7777	
287	0456	7040		CMA	/AC=0	
288	0457	7490		SNA		
289	0460	5263		JMP I85		
290	0461	7402	E17,	HLT I84	/RIB OR SF FAILED	
291	0462	5244	/	JMP I84		
292						
293	0463	6251	/	COF 50	/DFS	
294	0464	6001	E18,	ION		
295	0465	7200	/	CLA	/DF SHOULD=000	
296	0466	6214		ROF		
297	0467	7490		SNA		
298	0470	5273		JMP I+3		
299	0471	7402	E18,	HLT I85	/DF NOT 0 AFTER PI	
300	0472	5263	/	JMP I85		
301						
302	0473	1063	/	TAD K7772	/AC= 7772	
303	0474	6234		RIB	/ 7777	
304	0475	7040		CMA	/ 0	
305	0476	7490		SNA		
306	0477	5302		JMP OK7		
307	0500	7402	E19,	HLT I85	/RIB OR SF FAILED	
308	0501	5263	/	JMP I85		
309						
310	0502	2027	/	I83 LOOP	/DONE IF 0 AND SKIP	
311	0503	5244	OK7,	JMP I84		
312			/			
313	0504	7200	/	CLA		
314	0505	3027		DCA LOOP		
315						
316	0506	6261	/	COF 60	/DF6	
317	0507	6001	E18,	ION		
318	0510	7200	/	CLA	/DF MUST=0 AFTER PI	
319	0511	6214		ROF		
320	0512	7490		SNA		
321	0513	5316		JMP I+3		
322	0514	7402	E20,	HLT I86	/DF NOT 0 AFTER PI	
323	0515	5306	/	JMP I86		
324						

325	0516	1064	TAD K7771		
326	0517	6234	RIB	/AC=7777	/.7771
327	0520	7840	CMA		
328	0521	7450	SNA		
329	0522	5325	JMP 107		
330	0523	7402	HLT	/RIB OR SF FAILED	
331	0524	5306	JMP 106		
332					
333					
334	0525	6271	COF 70	/OF 7	
335	0526	6001	ION		
336	0527	7208	CLA	/OF MUST = 0 AFTER PJ	
337	0530	6214	ROP		
338	0531	7450	SNA		
339	0532	5335	JMP 103		
340	0533	7402	HLT	/OF NOT 0	
341	0534	5325	JMP 107		
342					
343	0535	1065	TAD K7770		
344	0536	6234	RIB	/AC=7777	
345	0537	7840	CMA		
346	0540	7450	SNA		
347	0541	5344	JMP OK0		
348	0542	7402	HLT	/RIB OR SF FAILED	
349	0543	5325	JMP 107		
350					
351					
352	0544	2027	ISB LOOP	/DONE IF 0	
353	0545	5306	JMP 106		
354	0546	5747	JMP 103	/NEW PAGE	
355	0547	0600	000		





```

/CIF TEST, CHECKS THE ABILITY OF A CIF=ION=NOP=JMP OR
/CIF=ION=NOP=JMS SEQUENCE TO DO THE FOLLOWING:
/1: CIF ENABLE MB TO IB TRANSFER;
/2: INHIBIT INTERRUPT TILL JMP OR JMS EXECUTED;
/3: INTERRUPT AFTER JMP OR JMS EXECUTED;
/4: JMP OR JMS ENABLES IB TO IF TRANSFER;
/5: INTERRUPT ENABLES IF TO SP TRANSFER;

```

```

/SET UP FOR CIF=ION=NOP=JMP CHECK.
IBSF, 00 /SET LOCS 1-2 TO ISZ 0,
0656 6201 DCF TAD 1S80 /JMP I 0 RESPECTIVELY,
0657 1021 TAD DCA 1 KNOP
0660 3001 TAD DCA 2 JMPI0
0661 1352 TAD DCA 3
0662 3002 TAD
0663 1020 DCA
0664 3003

```

```

/NOW STORE HALTS IN LOC1, CIFJMP+1,
/AND CIFJMS+1 OF ALL EXTENDED FIELDS.

```

```

JMS I XSTKS
TAD KCDP
TAD K10
DCA +1
CDF 10
TAD KHLT
DCA I K1
TAD KHLT
DCA I E31
DCA I KHLT
DCA I E32
ISE STKS
SKP +3
JMP HLTS
TAD HLTS=2
CDF 00
TSP
JMS I XTELG
DCA LOOP
TAD KCIF
DCA CIFJMP
DCA CIPCK
JMS I XSTKS
TAD CIFJMP
DCA K10
DCA CIFJMP
TAD CIPJMP
DCA CIPJMP
TAD CIPCK
TAD K10
DCA CIPCK
CIFJMP: CIF

```

```

/ENSURE ITO FLAG SET.
/SET COUNTER FOR 4096 PASSES.
/INITIALIZE TO CIF 00.
/INITIALIZE I.P. CHECK TO 0.
/READ SR9=11.

```

```

/MODIFIED TO CURRENT FIELD
/UNDER TEST.

```

412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463

```

0656 6201
0657 1021
0660 3001
0661 1352
0662 3002
0663 1020
0664 3003
4423
1040
1045
3271
0211
1037
3443
1037
3790
1037
3795
2031
7410
5305
1271
5207
6201
6041
4422
3027
1041
3323
3353
4423
1323
1045
3323
1353
1045
3353
6202
0723
0720
0721
0722
0723

```

HLTS.

AGAIN1:

CIFJPL:

CIFJMP:

464	0724	6001	ION		
465	0725	7000	NOP		
466	0726	5327	JMP		
467	0727	7402	HLT		
468	0727	7402	RIB		
469	0730	6234	CIA		
470	0731	7041	TAD		
471	0732	1353	SNA	CLA	
472	0733	7650	JMP	E26+3	
473	0734	5344	TAD	CIFCK	
474	0735	1353	CLL	RAR	
475	0736	7110	RTR		
476	0737	7012	RIB		
477	0740	6234	HLT		
478	0741	7402	CLA		
479	0742	7200	JMP		
480	0743	5323	ISZ		
481	0744	2031	JMP		
482	0745	5315	ISZ		
483	0746	2027	JMP		
484	0747	5311	JMP		
485	0750	5751	JMP		
486	0751	1000	ISZ		
487	0752	7000	NOP		
488	0753	0000	0		
489	0754	0724	CIFJMP+1		
490	0755	1020	CIFJMS+1		
491					

E25, .+1

E26, .+1

KNOP: .+1  
CIFCK: .+1  
E31: .+1  
E32: .+1

/ERROR, NO PI OR INHIBIT PI.

/ERROR: I.B. TO I.F. TRANSFER  
/FAILED AFTER CIF-JMP; BAD  
/I.F. IN AC6-0; GOOD I.F. IN  
/AC9-11. REPEAT UPON CONTINUE.  
/DONE?  
/NO. DO NEXT FIELD  
/4096 TIMES?  
/NO. DO IT ALL AGAIN.  
/YES. GO TEST CIF-JMS.



```

535 /TEST INTERRUPT INHIBIT
536 /FROM EACH FIELD; REFER TO HEADING TITLED "EXTENDED
537 /FIELD TEST ROUTINE". THIS ROUTINE IS PLACED IN
538 /EACH TESTED FIELD AT THE ADDRESSES SPECIFIED. THE
539 /INDICATED ERROR HALTS WILL BE IN THE EXTENDED
540 /FIELD. PRESS CONT. TO RECOVER. ONLY 1 FIELD WILL
541 /CONTAIN IN THE ROUTINE AT ANY ONE TIME. OTHER FIELDS
542 /WILL CONTAIN ALLOIS. THE ROUTINE IS REPLACED WITH
543 /HALTS AFTER COMPLETION. THE PORTIONS OF THE FIELD
544 /WHICH DO NOT CONTAIN THE ROUTINE ARE SET TO 0000
545 /BEFOREHAND.
546
547
548
549
550

```

/SETUP FIELDS TO TEST; POINTERS, ETC.:

```

551 TRMF: JMS I XSTKS /READ SR9=11
552 TAD KODP /6201
553 DCA :+6
554 TAD :+9
555 TAD K10
556 DCA :+3
557 CMA
558 DCA 10
559 DCP 00
560 DCA I 10
561 TAD 10
562 CMA CLA
563 SZA :+4
564 JMP I 10
565 ISB STKS
566 JMP TRMF=3

```

/PLACE 0'S IN EACH FIELD FROM /LOC: 0 TO 7777.

```

1047 4423
1050 1040
1051 3257
1052 1257
1053 1045
1054 3257
1055 7040
1056 3010
1057 6201
1060 3410
1061 1010
1062 7040
1063 7040
1064 5200
1065 2031
1066 5252

```

```

567 /NOW PUT A HLT IN EACH FIELD IN THE SAME
568 /LOCATION AS E40, BELOW.
569 /
570
571
572 JMS I XSTKS /READ SR 9=11
573 TAD KCDF
574 TAD K10
575 DCA I+1
576 CDF 00
577 TAD KE40 /KE40 = ADDRESS OF E40.
578 DCA LOOP /SAVE TEMPORARILY
579 TAD KHLT /KHLT = 7402 (HLT)
580 DCA I LOOP /DONE ALL STACKS WHEN SKIP
581 ISE SYKS
582 SKP I+3
583 JMP CHDF
584 TAD CHDF
585 JMP CHDF-2
586
587 CDF 00
588 TSP /CHECK TTY FLAG
589 JMS I XTFLG /GO SET IT
590 TAD K7707
591 DCA LOOP
592 TAD POINT
593 DCA K75
594 JMS I XSTKS /POINTER FOR K7700 TO K7766
595 TAD KCDF /READ SR 9=11
596 TAD K10 /10
597 DCA STDF /0002
598 TAD KCIF /10
599 TAD K10
600 DCA STDF+1
601 TAD STDF+1
602 DCA I XPD
603 JMS I XTRANS /PUT TEST ROUTINE INTO FIELD X
604
605 CDF 10 /FIELD 1 TO START WITH
606 CIP 10
607 JMP I+1 /SHOULD ENTER EXTENDED FIELD
608 /AFTER THIS JMP. HLT IF NOT
609 NOP /ERROR: PI FAILED
610 HLT /C(I.0.)
611 JMP STDF /REPEAT SAME TEST.
612
613

```

```

1067 4423
1070 1040
1071 1045
1072 3273
1073 6201
1074 1036
1075 3027
1076 1037
1077 3427
1100 2031
1101 7410
1102 5205
1103 1273
1104 5271
1105 6201
1106 6041
1107 4422
1110 1050
1111 3027
1112 1066
1113 3067
1114 4423
1115 1040
1116 1045
1117 3326
1120 1041
1121 1045
1122 3327
1123 1327
1124 3442
1125 4425
1126 6211
1127 6212
1130 5331
1131 7000
1132 7402
1133 5326

```

```

614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666

1200
1200
1201
1202
1203
1204
1205
1206
1207
1210
1211
1212
1213
1214
1215
1216
1217
1220
1221
1222
1223
1224
1225
1226
1227
1230
1231
1232
1233
1234
1235
1236
1237
1240
1241
1242
1243
1244
1245

/ENTER HERE AFTER PI FROM EXTENDED BANK
*1200
/ENTER,
E41,
E42,
E43,

RDF
SNA
JMP +4
HLT
CLA
JMP I XTDF
CIF 10
RMP
RIB 00
CDF 00
TAD I K7S
CMA
SNA CLA
JMP CKPC
RIB
HLT

TAD KE40
IAC
CIA 0
TAD 0
SNA CLA
JMP +5
TAD 0
HLT

CLA
JMP I XTDF

ISZ STKS
JMP +5
ISZ LOOP
JMP I +2
JMP I XFI8
STRMF+4

/DF SHOULD BE 000
/ERROR IF SKIP
/CHECK C(SF)
/AC=C(DF)
/REPEAT TEST
/SET I.B. TO FIELD 1
/I.B. NOW EQUAL TO SF
/READ IB
/ERROR IF SKIP
/ERROR RMP AND PI WORKED, BUT
/I.B. NOT CORRECT AFTER RMP.
/AC=C(IB)
/BACKUP A PAGE AND REPEAT
/MAKE E40+1
/COMPARE TO C(0)
/SHOULD NOT SKIP
/FALL OK SETUP FOR NEXT FIELD
/ERROR: ALL WORKED, BUT
/CIPC) WAS NOT TO E40+1
/AFTER PI IN EXTENDED
/FIELD, C(IAC)C(0);F0.
/CHECK FOR PI NOT INHIBITED.
/FOR AUTO-INDEX REG.
/I2 FAILING IN THE EXTENDED FIELD.
/BACKUP AND REPEAT
/DONE ALL IF SKIP
/DONE LOOPING IF SKIP
/REPEAT ALL AGAIN
/EXIT TO NEXT TEST
/BACK TO LAST PAGE

```

667 /  
 668 /SET LAST TESTED FIELD TO ALL 0'S AND PUT A  
 669 /HLT IN RESPECTIVE ADDRESS OF E40  
 670 /  
 671 /

1246	7240	CLA CMA
1247	3010	DCA 10
1250	1477	TAD I XTDF /CDF X0 AT STDF
1251	3252	DCA +1 /F1 TO START WITH
1252	6211	CDF 10
1253	3410	DCA I 10
1254	1010	TAD 10
1255	7040	CMA CLA
1256	7640	SEA CLA /CLEAR IF SKIP
1257	5253	JMP #4
1260	6201	CDF 00
1261	1477	TAD I XTDF /CDF X0 AT STDF
1262	3263	DCA +1
1263	6211	CDF 10
1264	1037	TAD KHLT /E7402 (HLT)
1265	3436	DCA I KE40 /KE40=ADDRESS OF E40
1266	6201	CDF 00 /RESTORE DF

689 /INCREMENT CDF AND CIF 10T'S AT STDF, STDF+1  
 690 /TO NEXT FIELD.  
 691 /  
 692 /

1267	1477	TAD I XTDF
1270	1045	TAD K10 /CDF X0 AT STDF
1271	3477	DCA I XTDF
1272	1500	TAD I XTDF1 /CIF X0 AT STDF
1273	1045	TAD K10
1274	3900	DCA I XTDF1
1275	1500	TAD I XTDF1
1276	3216	DCA EXPD
1277	2067	ISE K7S
1300	4321	JMS TRANS /PUT ROUTINE IN NEW FIELD
1301	5477	JMP I XTDF /TEST NEW FIELD

702  
 703

```

704 /EXTENDED FIELD TEST ROUTINE
705 /
706 /THE FOLLOWING INSTRUCTIONS ARE PLACED IN
707 /EACH EXTENDED FIELD TESTED. THE NUMBERS IN THE
708 /COMMENTS FIELD CORRESPOND TO THE
709 /MEMORY LOCATIONS IN THE TESTED FIELD. LOCATIONS
710 /0 THRU 11 ARE USED FOR AN ERROR ROUTINE
711 /IN CASE FIELD 0 IS NOT ENTERED AFTER AN
712 /INTERRUPT. THE EXTENDED FIELD SHOULD BE
713 /ENTERED AT LOCATION E40+1 WHICH CORRESPONDS
714 /TO E40+1 IN FIELD 0.
715 /
716 /EXTENDED FIELD INSTRUCTIONS:
717 /
718 EXPD: 0 /0
719 TAD 0 /1
720 SNA /IF LOC. 0 NOT = 0 PI DIDN'T
721 /ENTER FIELD 0
722 JMP ,+5 /3
723 HLT /4. INTERRUPTED TO THIS FIELD
724 /INSTEAD OF FIELD 0.C(AC)5C(0)
725 /WHICH SHOULD BE E40+1
726 /IF NOT, CHECK LOC. 7777,IT
727 /MUST = 5412 (JMP I 12).
728 /5
729 CLA 0 /6
730 DCA I 20 /7. C(20) =E40
731 JMP I 20 /10. THE JMP I 12 AT LOC.
732 HLT /7777 WAS NOT EXECUTED.
733 /OR INTERRUPT FAILED. IF
734 /NO INTERRUPT, LOCATION 12
735 /NOW CONTAINS 0 INSTEAD
736 /OF ADDRESS E40.
737 JMP ,+4 /11. REPEAT IN THIS FIELD
738 E40 /12. AUTO-INDEXS TO E40+1
739 /IN F 0 IF THE JMP I 12
740 /WORKS.
741 /LOCS. 13 TO 17 ARE ALL 0'S
742 E40 /20. EQUALS E40 IN F0.
743 /
744 /LOCS. 21 TO E40-2 ARE ALL 0'S
745 /
746 EXPD: CIF 10 /FIELD 1 TO START WITH
747 ION /LOC. E40. SEE SYMBOL TABLE
748 /FOR E40.
749 /LOCS. E40+1 TO 7776 ARE ALL 0'S
750 /
751 JMP I 12 /7777; PI SHOULD OCCUR;
752 /AFTER THIS INSTRUCTION,
753 /TO FIELD 0.
754
755

```

```

756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803

/ROUTINE TO TRANSFER TEST ROUTINE TO PROPER FIELD
/TRANS, 0
1321 0000 TAD KJMP /KJMP=JMP I 2
1322 1102 DCA 1 /IN FIELD 0
1323 3001 TAD KNTR /KNTR = LOC. ENTER
1324 1103 DCA 2 /OF FIELD 0
1325 3002 TAD KXFLD /KXFLD = LOC. EXFLD
1326 1101 DCA 10
1327 3010 DCA 11
1330 3011 TAD K7766 /1=10 DECIMAL
1331 1070 DCA 0 /SAVE
1332 3000 TAD I XTDF /CDF X0 IN STDF
1333 1477 DCA 03
1334 3337 CDF 00
1335 6201 TAD I 10
1336 1410 CDF 10
1337 6211 DCA I 11 /P1 TO START WITH
1340 3411 DCA I 11 /PUT IN EXTENDED FIELD
1341 2000 ISE 0 /DONE LOC8 1 TO 12 IF SKIP
1342 5335 JMP 05
1343 1337 TAD TRFLD
1344 3347 DCA 03
1345 6201 CDF 00
1346 1410 TAD I 10
1347 6211 CDF 10
1350 3504 DCA I K20
1351 6201 CDF 00
1352 1337 TAD TRFLD
1353 3355 DCA 02
1354 1410 TAD I 10
1355 6211 CDF 10
1356 3435 DCA I KE40H
1357 6201 CDF 00
1360 1337 TAD TRFLD
1361 3363 DCA 02
1362 1410 TAD I 10
1363 6211 CDF 10
1364 3436 DCA I KE40
1365 6201 CDF 00
1366 1337 TAD TRFLD
1367 3371 DCA 02
1370 1410 TAD I 10
1371 6211 CDF 10
1372 3446 DCA I K7777
1373 6201 CDF 00
1374 5721 JMP I TRANS /EXIT

```

```

804      1400      *1400
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848

/TEST SF WITH AN RMF JOT, AN INTERRUPT IN FIELD 0 IS CREATED, AFTER
/WHICH, THE DF AND IB REGISTERS ARE SET TO FIELD 1.
/THE SF SHOULD CONTAIN FIELD 0, THE TEST
/THEN MAKES SURE THE IB IS CLEARED, THEN SET BY ISSUING AN RMF,
/FOLLOWED BY A JMP I K7000. IF THE IB IS CLEARED, THE JMP GOES TO 7000 IN FIELD 0,
/IF THE IB AND SF ARE INCLUSIVE OR'D, THE JMP GOES TO 7000 IN FIELD 1, AND
/A HALT OCCURS THERE. RESTART FROM 1400 AFTER AN ERROR, THE TEST IS LOOPED
/512 TIMES.

      TSF
      JMS I XTFLG
      TAD K7000
      DCA LOOP
      CDF IB
      TAD KHLT
      DCA I K7000
      CDF 00
      TAD JMP2
      DCA I K7000

      TAD KJMP
      DCA 1
      TAD KRTRN
      DCA 2

      ION
      NOP
      HLT
      JMP SFIB

      CLA 10
      CIP 10
      RMF I K7000
      JMP I K7000

      IS3 LOOP
      JMP E45A=2
      JMP TAUTO

      /SEE IF FLAG IS SET.
      /SET IT
      /7000
      /DF=FIELD 1
      /HLT
      /7000, FIELD 1=HLT
      /DF=0
      /JMP2=JMP I KFLD0
      /7000, FIELD 0=JMP I KFLD0
      /KFLD0=LOC, RTRN
      /KJMP=JMP I 2
      /KRTRN=LOC, E45A=2

      /ENABLE PI
      /ERROR NO PI
      /REPEAT TEST

      /RETURN HERE AFTER PI

      /BEGIN TEST

      1400 6041
      1401 4422
      1402 1047
      1403 3027
      1404 6211
      1405 1037
      1406 3047
      1407 6201
      1410 1105
      1411 3447

      1412 1102
      1413 3001
      1414 1107
      1415 3002

      1416 6001
      1417 7000
      1420 7402
      1421 5200

      1422 7200
      1423 6211
      1424 6212
      1425 6244
      1426 5447

      1427 2027
      1430 5216
      1431 5232

```

849 /  
 850 /  
 851 /TEST ALL AUTO-INDEX REGISTERS IN EACH EXTENDED FIELD.  
 852 /IDENTICAL TEST ROUTINES ARE PERFORMED FROM EACH FIELD.  
 853 /AND ERROR HALTS OCCUR IN THE FIELD CURRENTLY RUNNING  
 854 /THE ROUTINE, PRESS CONT, TO RESUME TESTING, EACH  
 855 /FIELD CONTAINS ALL 0'S EXCEPT FOR THE AREA OCCUPIED  
 856 /BY THE TEST ROUTINE. FIELD 0 IS RE-ENTERED  
 857 /AFTER EACH TEST, AND THE NEXT SEQUENTIAL FIELD  
 858 /IS THEN ENTERED. REFER TO THE HEADING "AUTO-  
 859 /INDEX TEST" FOR THE SEQUENCE OF OPERATIONS.  
 860 /

1432 6201 TAUTO, CDF 00  
 1433 1050 TAD K7707  
 1434 3027 DCA LOOP /LOOP COUNTER  
 1435 4423 JMS I XSTKS /READ SR 9=11  
 1436 1040 TAD KCDF /0201  
 1437 3246 DCA DFN  
 1440 1246 TAD DFN  
 1441 1045 TAD K10 /INCREMENT DF  
 1442 3246 DCA DFN

861 /  
 862 /CLEAR ONE FIELD TO 0  
 863 /  
 864 /  
 865 /  
 866 /  
 867 /  
 868 /  
 869 /  
 870 /  
 871 /  
 872 /  
 873 /  
 874 /  
 875 /  
 876 /  
 877 /  
 878 /  
 879 /  
 880 /  
 881 /  
 882 /

1443 7040 CMA  
 1444 3010 DCA 10  
 1445 3000 DCA 0  
 1446 6211 CDF 10 /USE LOC. 0 FOR A COUNTER  
 1447 3410 DCA I 10 /FIELD 1 TO START WITH  
 1450 2000 ISZ 0  
 1451 5247 JMP :=2  
 1452 6201 CDF 00

883 /  
 884 /NOW PUT TEST ROUTINE IN THE EXTENDED FIELD  
 885 /  
 886 /  
 887 /  
 888 /  
 889 /  
 890 /  
 891 /  
 892 /  
 893 /  
 894 /  
 895 /  
 896 /  
 897 /

1453 1317 TAD 00AUTO  
 1454 3010 DCA 10 /1ST LOC. OF ROUTINE MINUS 1  
 1455 1072 TAD K7744 /SOURCE /:=20 DECIMAL  
 1456 3000 DCA 0 /USE LOC. 0 AS COUNTER  
 1457 1317 TAD 00AUTO /DESTINATION  
 1460 3011 DCA I 1 /CDF X0  
 1461 1246 DCA :=3  
 1462 3265 CDF 00  
 1463 6201 TAD I 10 /FIELD 1 TO START  
 1464 1410 CDF 10 /MOVE WHEN SKIP  
 1465 6211 DCA I 11  
 1466 3411 ISZ 0  
 1467 2000 JMP MOVE  
 1470 5265

```

1471 1065
1472 3000
1473 1044
1474 3010
1475 7040
1476 3410
1477 2000
1500 5275
1501 7040
1502 3446
1503 6214
1504 1041
1505 3306
1506 6212
1507 4716

1510 2031
1511 5240
1512 2027
1513 5235
1514 5715
1515 1600
1516 1002

/ NOW SET AUTO=I REGS 10 TO 17 TO 7777,
/
TAD K7770
DCA 0
TAD K7
DCA 10
CMA I 10
DCA 0
ISE 0
JMP 03
CMA I K7777
DCA I K7777
RDP
TAD KCIF
DCA 01
CIP 10
JMS I FILOX

/ ENTER FIELD 0 FROM EXTENDED FIELD HERE.
/
GOTO0, ISE STKS
JMP NENDF
ISE LOOP
JMP NENDF03
JMP I LBTP
LBTP: RMTST
/ FILOX, DOAUTO=515

/PUT 7777 IN LOC. 7777 OF EXTENDED FIELD
/READ O.F. /6202

/FIELD 1 TO START
/ENTER EXTENDED FIELD
/515 OCTAL LOCS. BEFORE THE
/TAD I 10 INSTRUCTION;
/THIS IS A TEST OF THE
/DEFER BIT; 500 US DELAY

/DONE ALL WHEN SKIP
/SETUP FOR NEXT
/ALL DONE IF SKIP
/REPEAT ALL

```

```

932 /
933 /
934 /
935 /
936 /THE ROUTINE WILL BE PLACED IN THE SAME RESPECTIVE
937 /LOCATIONS IN EACH EXTENDED FIELD; ANY ERROR
938 //HALTS WILL OCCUR IN THE EXTENDED FIELD. PRESS
939 /CONTINUE TO PROCEED WITH TESTING. THE INDEX
940 /REGISTERS 10 TO 17 INITIALLY CONTAIN 7777, AND
941 /ARE AUTO-INDEXXED TO 0000 BY A TAD I INSTRUCTION.
942 /A HALT OCCURS IF THE REG. IS NOT INCREMENTED TO 0.
943 /THE TAD I WOULD HAVE THEN REFERENCED LOC. 7777.
944 /WHICH CONTAINS 7777.
945 /
946 /
947 /
948 /
949 /
950 /
951 /
952 /
953 /
954 /
955 /
956 /
957 /
958 /
959 /
960 /
961 /
962 /
963 /
964 /
965 /
966 /
967 /
968 /
969 /
970 /
971 /
972 /
973 /
974 /
975 /
976 /
977 /
978 /

```

```

1517 1517 DOAUTO, .
1520 7200 CLA
1521 1410 TAD I 10
1522 7440 SEA
1523 7402 HLT
1524 1411 TAD I 11
1525 7440 SEA
1526 7402 HLT
1527 1412 TAD I 12
1530 7440 SEA
1531 7402 HLT
1532 1413 TAD I 13
1533 7440 SEA
1534 7402 HLT
1535 1414 TAD I 14
1536 7440 SEA
1537 7402 HLT
1540 1415 TAD I 15
1541 7440 SEA
1542 7402 HLT
1543 1416 TAD I 16
1544 7440 SEA
1545 7402 HLT
1546 1417 TAD I 17
1547 7440 SEA
1550 7402 HLT
1551 6201 GDF 00
1552 6202 CIP 00
1553 5310 JMP GOTO0
/END OF TEST ROUTINE
/
/

```

```

/THIS LOC. IS NOT MOVED TO
/THE EXTENDED FIELD.

/ERROR, INDEX REG. 10 FAILED

/INDEX REG. 11 FAILED

/12 FAILED

/13 FAILED

/14 FAILED

/15 FAILED

/16 FAILED

/17 FAILED
/SET OF TO FIELD 0
/SET I.B. TO FIELD 0
/EXIT TO FIELD 0

```

```

979 /PD. 61: 8S EXTENDED MEMORY CONTROL TEST. PAL10 Y. 4 20 JUL 70 22140 PAGE 23
980 /CHECK SR 0. IF AN 81 IS BEING USED SR 8 MUST BE
981 /ON A 1. OTHERWISE, 0.
982 /
983 CSR8.
984 LAS 7604
985 AND K10
986 SZL CLA
987 JMP I XMEM /NEXT TEST
988 AND 7
989 TAD .01
990 BELL.
991 TLS /RING BELL
992 TSF
993 JMP .01
994 JMP I X8GN /START OVER AT 200
995 /
996 X8GN: 0200
997 XMEM: 2200
998
999

```

```

995 /DYNAMIC RMF TEST,
996 /TESTS ALL SF TO DF TRANSFERS AND THOSE SF TO IB TRANSFERS
997 /AS APPLICABLE TO THE NUMBER OF EXTENDED FIELDS PRESENT.
998 /THE GENERAL METHOD IS TO INTERRUPT FROM EACH EXTENDED FIELD
999 /WITH THE DF=FROM 0 THROUGH 7. AN RMF INSTRUCTION IS THEN ISSUED
1000 /AND CONTROL TRANSFERRED TO AN EXTENDED FIELD. THE RMFDY ROUTINE
1001 /IN THAT FIELD THEN CHECKS THAT THE IF AND DF ARE CORRECT. IF NOT,
1002 /THE FAILING IF OR DF IS IN THE IF OR OF REG. AND THE CORRECT FIELD
1003 /NUMBER IS IN AC BITS 6 THRU 0.
1004 /
1005 /
1006 /
1007 /
1008 /
1009 /
1010 /
1011 /
1012 /
1013 /
1014 /
1015 /
1016 /
1017 /
1018 /
1019 /
1020 /
1021 /
1022 /
1023 /
1024 /
1025 /
1026 /
1027 /
1028 /
1029 /
1030 /
1031 /
1032 /
1033 /
1034 /
1035 /
1036 /
1037 /
1038 /
1039 /
1040 /
1041 /
1042 /
1043 /
1044 /
1045 /
1046 /
1047 /
1048 /
1049 /

```

1600

```

1600 RMFTST, LAS AND K7
1601 CIA
1602 DCA
1603 JMS I XFERP
1604 0
1605 -34
1606 RMFDY=1
1607 DCA
1608 TAD
1609 DCA
1610 TAD
1611 DCA
1612 TAD
1613 DCA
1614 DCA
1615 DCA
1616 DCA
1617 DCA
1618 DCA
1619 DCA
1620 DCA
1621 DCA
1622 DCA
1623 DCA
1624 DCA
1625 DCA
1626 DCA
1627 DCA
1628 DCA
1629 DCA
1630 DCA
1631 DCA
1632 DCA
1633 DCA
1634 DCA
1635 DCA
1636 DCA
1637 DCA
1638 DCA
1639 DCA
1640 DCA
1641 DCA
1642 DCA
1643 DCA
1644 DCA
1645 DCA
1646 DCA
1647 DCA
1648 DCA
1649 DCA

```

```

/CHECK HOW MANY EXTENDED FIELDS
/ARE PRESENT
/NEGATE AND SAVE.
/TRANSFER RMFDY ROUTINE TO ALL
/EXTENDED FIELDS.
/SET RMFTST COUNTER FOR 4096 PASSES
/SET INTERRUPT LINK.
/INITIALIZE IF TO 0.
/INITIALIZE TEST COUNTER
/UPDATE CURRENT IF.
/INITIALIZE DF COUNTER TO =10.
/INITIALIZE DF TO =10.
/UPDATE DF.
/TRANSFER DF AND IF INFORMATION
/TO EXTENDED FIELDS.

```

KDFSHB=1

1050 /PD. , 81. 88 EXTENDED MEMORY CONTROL TEST, PAL10 V.L.-1 28-JUL-70 22140 PAGE 24-1

1647 6201 CDF 00



1084  
1085  
1086  
1087  
1088  
1089  
1090  
1091  
1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135

/ROUTINE TO CHECK CORRECT TRANSFERS FOR SAVE FIELD TO DATA FIELD AND  
/SAVE FIELD TO INST. BUFFER TO INSTRUCTION FIELD AFTER

/RMF.  
/STORED IN ALL EXTENDED FIELDS.

1703 6001  
1704 7000  
1705 6002  
1706 7402  
1707 5333  
1710 7200  
1711 6214  
1712 1340  
1713 7650  
1714 5320  
1715 1337  
1716 7402  
1717 5333  
1720 6224  
1721 1342  
1722 7650  
1723 5327  
1724 1341  
1725 7402  
1726 5333  
1727 6201  
1730 6202  
1731 5732  
1732 1665  
1733 6201  
1734 6202  
1735 5736  
1736 1656  
1737 0000  
1740 0000  
1741 0000  
1742 0000

RMFDY: ION /THIS IS NOT TRANSFERRED.

E60: HLT /INTERRUPT FAILURE.

JMP REPEAT

RMFDY1: CLA /CHECK FOR CORRECT DATA FIELD

ROF MDPSHB

TAD CLA

SNA CLA

JMP :\*4

TAD KDFSHB

HLT REPEAT

RIF REPEAT

TAD MIFSHB

SNA CLA

JMP :\*4

TAD KIFSHB

HLT REPEAT

JMP REPEAT

COF 00

CIF 00

JMP I :\*1

RMFE1

COF 00

CIF 00

JMP I :\*1

RMFE2

COF 00

CIF 00

JMP I :\*1

RMFE2

COF 00

CIF 00

JMP I :\*1

RMFE2

COF 00

CIF 00

JMP I :\*1

RMFE2

COF 00

CIF 00

JMP I :\*1

RMFE2

COF 00

CIF 00

JMP I :\*1

RMFE2

/ROUTINE TO TRANSFER N1 WORDS STARTING AT P IN FIELD 0 TO P IN THE

/NEXT N2 EXTENDED FIELDS.

/THE CALLING SEQUENCE IS:

/JMS I XPERP

/=N2

/=N1

/P=1

/DATA FIELD INCORRECT  
/SF TO DF TRANSFER FAILED AFTER RMF.  
/REPEAT THIS TEST.  
/CHECK FOR CORRECT INSTRUCTION FIELD.

/INSTRUCTION FIELD INCORRECT.  
/SF TO IB TRANSFER FAILED AFTER RMF  
/REPEAT THIS TEST.  
/GO BACK AND RUN NEXT TEST.

/GO BACK AND REPEAT FAILING  
/TEST.

/DATA FIELD SHOULD BE  
/TWO'S COMPLEMENT OF ABOVE.  
/INSTRUCTION FIELD SHOULD BE  
/TWO'S COMPLEMENT OF ABOVE

```

1136 2000 0000 / *2000
1137 2001 7200 / XFER,
1138 2002 1600 CLA I
1139 2003 3242 DCA XFER
1140 2004 2200 ISZ N2
1141 2005 1600 TAD I XFER
1142 2006 3243 DCA N1
1143 2007 2200 ISZ XFER
1144 2010 1600 TAD I XFER
1145 2011 3244 DCA P
1146 2012 2200 ISZ XFER
1147 2013 1040 TAD KCOF
1148 2014 3232 DCA XFERIN
1149 2015 1242 TAD N2
1150 2016 3245 DCA XFERC2
1151 2017 1244 TAD P
1152 2018 3010 DCA 10
1153 2019 1244 TAD P
1154 2022 3011 DCA 11
1155 2023 1243 TAD N1
1156 2024 3246 DCA XFERC1
1157 2025 1232 TAD XFERIN
1158 2026 1045 TAD K10
1159 2027 3232 DCA XFERIN
1160 2030 6201 XFERL1: COF 00
1161 2031 1410 TAD I 10
1162 2032 6201 XFERIN: COF 11
1163 2033 3411 DCA XFERC1
1164 2034 2246 ISZ XFERL1
1165 2035 5230 JMP XFERC2
1166 2036 2245 ISZ XFERL2
1167 2037 5217 JMP XFERL2
1168 2040 6201 COF 00
1169 2041 5600 JMP I XFER
1170 2042 0000 N2,
1171 2043 0000 N1,
1172 2044 0000 P,
1173 2045 0000 XFERC2: 0
1174 2046 0000 XFERC1: 0
1175
1176
1177
1178
1179
1180

```

```

/GET =N2
/GET =N1
/GET P=1

```

```

/UPDATE TO RETURN ADDRESS,
/INITIALIZE COF INST.

```

```

/PUT POINTER IN AUTO 10 AND 11.

```

```

/SET COUNTER 1 TO =N1
/UPDATE COF INST.

```

```

/TRANSFER

```

```

/DONE WITH CURRENT FIELD?
/NO, CONTINUE.
/DONE WITH ALL FIELDS?
/NO, DO NEXT FIELD
/ALL DONE. SET DF=0.
/EXIT.

```

```

1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219

2200
*2200
/
/REFERENCE ALL 4K FIELDS NOT PRESENT. IF 32K
/IS PRESENT, THE TEST IS BY-PASSED, AND PROGRAM IS
/RESTARTED AT 200, EACH FIELD NOT PRESENT IS
/REFERENCED BY THE PROGRAM WITH JMP, DCA AND TAD.
//THE PROGRAM MUST CONTINUE IN SEQUENCE/ THE TTY
/BELL WILL SIGNAL A SUCCESSFUL TEST, AND THE PRO-
/GRAM IS THEN RESTARTED AT 200.
/
/ NOMEM:
2200 7200 CLA
2201 1065 TAD K7770
2202 3027 DCA LOOP
2203 7004 LAS
2204 0044 AND K7
2205 7041 CIA
2206 1044 TAD K7
2207 7450 SNA
2208 5652 JMP I XBELL
2209 3033 DCA NOSTAK
2210 3651 DCA I XELL

/TEST LOOP COUNTER
/READ SR9=11
/SUBTRACT MAX. POSSIBLE
/32K PRESENT. CAN'T TEST
/SAVE NO. MISSING
/CLEAR THE TLS IOT AT
/BELL*1 TO PROHIBIT
/FALSE INDICATION: TLS
/IS RESTORED LATER WRONG
/ENTRY FROM NON-EXISTENT
/MEMORY MAY CAUSE A
/HANG-UP AT BELL*2 AND *3.
/# OF FIELDS PRESENT
/*1 TO GET 1ST MISSING
/POSITION TO AC 6=0.
/1ST MISSING
/# STACKS NOT HERE
/USED AS COUNTER

2213 7004 LAS
2214 0044 AND K7
2215 7001 IAC
2216 7100 CLL
2217 7006 RTL
2220 7004 RAL
2221 3034 DCA NOFLD
2222 1033 TAD NOSTAK
2223 7041 CIA
2224 3033 DCA NOSTAK

```

```

1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256

2225 1040
2226 1034
2227 3262
2230 1040
2231 1034
2232 3307

2233 1033
2234 7041
2235 7010
2236 7020

2237 5257
2240 4261
2241 2033
2242 5254
2243 2027
2244 5650
2245 1253
2246 3651
2247 5652

2250 2203
2251 1962
2252 1561
2253 6046

2254 1307
2255 1045
2256 3307
2257 4306
2260 5241

TAD KCDF
TAD NOFLD
DCA CDF0S
TAD KCDF
TAD NOFLD
DCA CDF1S

/6201
/MISSING STACK

/
/

/ NOW SEE IF AN ODD OR EVEN NUMBER IS MISSING
/

TAD NOSTAK
CIA
RAR
SNL CLA

JMP POS+3
JMS ALL0
ISE NOSTAK
JMP POS
ISE LOOP
JMP I XNOM
TAD TT0
DCA I XELL
JMP I XBELL

NOMEM+3
BELL+1
BELL
TTS

TAD CDF1S
TAD K10
DCA CDF1S
JMS ALL1
JMP CNSTK

CNSTK:
/

POS:
/

/DF PLUS 1
/READ ALL 1'S
/CHECK DONE

```

```

1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286

/ROUTINE TO READ ALL 0'S.
/
ALL0.
CDF00.
CLA CMA
DCA 10
CMA 11
DCA 2
CMA
DCA 1 10
ISZ 2
JMP 103
TAD I 11
SNA CLA
JMP 103
TAD 11
HLT
E94.
ISZ 2
JMP E9404
DONE0.
CDF 00
CIF 00
JMP I ALL0
/EXIT
/SET DF TO 1ST MISSING
/10 AND 11 USED FOR ADDRESS
/USE AS COUNTER
/WRITE 1'S INTO NON-EXIS-
/TENT FIELD.
/READ NON-EXIST. FIELD
/SHOULD = 0000
/ERROR. AN EXISTING FIELD
/WAS REFERENCED. C(AC)E
/ADDRESS REFERENCED
/READ NEXT

```

```

1287 /ROUTINE TO READ ALL 1'S
1288 /
1289 ALL1, CDF1S,
1290 0000 /SET DF TO MISSING FIELD
1291 2306 2307 6201 CDF 00
1292 2310 2310 7240 CLA CMA
1293 2311 2311 3010 DCA 10
1294 2312 2312 7040 CMA
1295 2313 3011 DCA 11
1296 2314 3002 DCA 2
1297 2315 3410 DCA I 10
1298 2316 2002 ISE 2
1299 2317 5315 JMP I=2
1300 2320 1411 TAD I 11
1301 2321 7040 CMA
1302 2322 7450 SNA
1303 2323 5327 JMP I=4
1304 2324 7040 CMA
1305 2325 7402 HLT
1306 E57.
1307 2326 7200 CLA
1308 2327 2002 ISE 2
1309 2330 5320 JMP E57=5
1310 2331 6201 CDF 00
1311 2332 6202 CIF 00
1312 2333 5706 JMP I ALL1
1313 /EXIT

```

/READ 1'S FROM NO MEMORY

/7777 NOT READ, C(AC)= DATA  
/READ, C(11)= ADDRESS.

```

1314 /READ SR9=11
1315 /
1316 NSTKS: 0
1317 LAS 0000
1318 AND K7 2334 0000
1319 CIA 2335 7604
1320 OCA STKS 2336 0044
1321 JMP I NSTKS 2337 7041
1322 2340 3031
1323 2341 5734
1324 /SET TTY FLAG
1325 /
1326 TFLG: 0
1327 CLA 2342 0000
1328 AND 15 2343 7200
1329 TAD :=1 2344 0015
1330 TLS 2345 1344
1331 TSF 2346 6046
1332 JMP :=1 2347 6041
1333 CLA 2350 5347
1334 JMP I TFLG 2351 7200
1335 /EXIT
S

```



4000  
4100  
4200  
4300  
4400  
4500  
4600  
4700  
  
5000  
5100  
5200  
5300  
5400  
5500  
5600  
5700  
  
6000  
6100  
6200  
6300  
6400  
6500  
6600  
6700  
  
7000  
7100  
7200  
7300  
7400  
7500  
7600  
7700

AGAIN1	0711	E24	0653	INTEP	1674	NOHEM	2200
AGAIN2	1005	E25	0727	ISEZ	0021	NOSTAK	0033
ALL0	2261	E26	0741	JMP2	0105	NSYKS	2334
ALL1	2306	E27	1024	JMPI0	0020	OK1	0222
BEGIN	0200	E3	0234	JMPI4	1702	OK2	0250
BELL	1561	E30	1036	K1	0043	OK3	0276
CDP	6201	E31	0754	K10	0045	OK4	0324
CDP0S	2262	E32	0755	K20	0104	OK5	0362
CDP1S	2307	E4	0245	K7	0044	OK6	0440
CHDF	1073	E40	1132	K7000	0047	OK7	0502
CIF	6202	E41	1203	K7707	0050	OK8	0544
CYCK	0753	E42	1221	K7717	0056	P	2044
CIPCK1	1046	E43	1235	K7727	0055	POINT	0066
CIFJMP	0723	E44	1306	K7737	0054	POS	2254
CIFJMS	1017	E45	1312	K7744	0072	RDF	6214
CIFJPL	0715	E45A	1420	K7747	0053	REPEAT	1733
CIFJSL	1011	E46	1523	K7757	0052	RIB	6234
CKPC	1226	E47	1526	K7766	0070	RIF	6224
CNSTK	2241	E48	1531	K7767	0051	RMP	6244
CSR0	1594	E49	1534	K7770	0065	RMP0N1	1676
CSR0P	1701	E5	0262	K7771	0064	RMPDY	1703
DAT	0032	E50	1537	K7772	0063	RMPDY1	1710
DCAI	0601	E51	1542	K7773	0062	RMPE1	1665
DF0	0202	E52	1545	K7774	0061	RMPE2	1656
DF1	0226	E53	1550	K7775	0060	RMP11	1660
DF2	0237	E54	2300	K7776	0057	RMP12	1661
DF3	0234	E57	2325	K7777	0046	RMPL1	1633
DF4	0265	E6	0273	K78	0067	RMPL2	1621
DF5	0302	E60	1706	K0CF	0040	RMPL3	1615
DF6	0313	E61	1716	K0CF	0041	RMPST	1600
DF7	0211	E62	1725	K0FSHB	1737	RTRN	1427
DF8	1677	E7	0310	KE40	0036	SF1B	1400
DF9	0607	E8	0321	KE00M	0035	STDF	1126
DFN	1446	E9	0341	KFLD0	0106	STKS	0031
DOAUTO	1517	ENTER	1200	KHLT	0037	STRMF	1106
DONE0	2303	EXPD	1316	K1PSHB	1741	TADI	0622
E1	0206	EXFLD	1302	KJMP	0102	TAUTO	1432
E10	0351	F1LDX	1516	KNOP	0752	TFLD	0630
E11	0360	CO700	1510	KNR	0103	TFLG	2342
E12	0410	H1TS	0671	KRYN	0107	TRANS	1321
E13	0417	I80	0334	KXFLD	0101	TRPLD	1337
E14	0427	I81	0343	L8TP	1515	TRMF	1047
E15	0436	I82	0402	L8YSG	1675	YTB	2253
E16	0452	I83	0421	LOOP	0027	XAUTO	0026
E17	0461	I84	0444	MDFSHB	1740	XBELL	2252
E18	0471	I85	0463	M1PSHB	1742	XBGN	1566
E19	0500	I86	0506	MOVE	1463	XBLL	2251
E2	0217	I87	0525	N1	2043	XFO	0042
E20	0514	I8SF	0656	N2	2042	XFER	2000
E21	0523	I8SF1	1000	NDF	0030	XFERC1	2046
E22	0533	IFCN	1605	NEWOF	1440	XFERC2	2045
E23	0542	INTE	1663	NOFLD	0034	XFERIN	2032

XFERL1 2030  
XFERL2 2017  
XPERP 1700  
XFIB 0110  
XMEM 1967  
XNOM 2250  
XRANS 0025  
XRHF 0024  
XSTKS 0023  
XTDF 0077  
XTDF1 0100  
XTFLG 0022

ERRORS DETECTED: 0

LINKS GENERATED: 0

RUN-TIME: 11 SECONDS

3K CORE USED



E20  
E21  
E22  
E23  
E24  
E25  
E26  
E27  
E3  
E30  
E31  
E32  
E4  
E40  
E41  
E42  
E43  
E44  
E45  
E49A  
E46  
E47  
E48  
E49  
E5  
E50  
E51  
E52  
E53  
E54  
E57  
E6  
E60  
E61  
E62  
E7  
E8  
E9  
ENTER  
EXFD  
EXPLD  
FILOX  
GOTO0  
HLTS  
I80  
I81  
I82  
I83  
I84  
I85  
I86  
I87  
I8SF

323#  
331#  
340#  
348#  
394  
468#  
473  
515#  
123#  
520  
440  
442  
134#  
38  
621#  
635#  
649#  
724#  
732#  
61  
951#  
954#  
957#  
960#  
149#  
963#  
966#  
969#  
972#  
1277#  
1305#  
1309#  
159#  
1893#  
1101#  
1109#  
1175#  
185#  
208#  
77  
43  
75  
916  
924#  
436#  
203#  
207  
230  
249  
276#  
290  
317#  
330  
339

407#  
478#  
525#  
490#  
491#  
39  
610#  
739  
766  
835#  
847  
1281  
1309  
618#  
700  
719#  
931#  
975  
446  
209  
211#  
236#  
253#  
284  
294#  
301  
332  
334#  
421#

748#  
447  
228  
218  
243  
260  
292  
301  
332  
341

226  
231  
268  
312  
309  
353  
349

271





