

1000 1000 1000
1000 1000 1000

IDENTIFICATION

PRODUCT CODE: MAJNDEG-8E-0808-D-101

COPYRIGHT © 1971
DIGITAL EQUIPMENT
CORPORATION

PRODUCT NAME: CMAC CLOCK8 DIAGNOSTIC

DATE CREATED: JUNE 1, 1971

MAINTAINER: DIAGNOSTIC PROGRAMMING GROUP

AUTHOR: JOHN VROBEL

1. ABSTRACT

THE DK8E CLOCKS DIAGNOSTIC IS DESIGNED TO VERIFY CORRECT OPERATION OF THE DK8-EA, DK8-EC, DK8-ES, AND DK8-EP REAL TIME CLOCK OPTIONS. THE PROGRAM UTILIZES AND TESTS IOT'S ASSOCIATED WITH THE DK8-EA LINE, DK8-EC CRYSTAL, AND THE DK8-EP/DK8-ES PROGRAMMABLE REAL TIME CLOCKS.

2. REQUIREMENTS

2.1 EQUIPMENT

A PDP-8E WITH THE DK8-EA, DK8-EC, DK8-ES, OR THE DK8-EP OPTION INSTALLED AND AN ASR-33 TELETYPE OR EQUIVALENT.

2.2 STORAGE

THE PROGRAM OCCUPIES LOCATIONS 0000-6000.

2.3 PRELIMINARY PROGRAMS

ALL PROGRAMS FOR THE BASIC PDP-8E MUST HAVE BEEN RUN SUCCESSFULLY.

3. LOADING PROCEDURE

3.1 METHOD

THE PROGRAM IS LOADED INTO BANK 0, USING THE STANDARD BINARY LOADER TECHNIQUE.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SWR0=1 FOR DK8-EP/DK8-ES REGISTER TEST
SWR1=1 FOR DK8-ES SCHMITT TRIGGER LOGIC TEST
SWR2=1 FOR INHIBIT ERROR PRINT OUT
SWR3=1 FOR INHIBIT ERROR BELL
SWR4=1 FOR INHIBIT ERROR HALT
SWR5=1 FOR ENTER SCOPE LOOP
SWR6=1 FOR LOOP ON NON-FALLING TEST
SWR7=1 FOR DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP
SWR8=1 FOR DK8-ES EXTERNAL CLOCK SCOPE LOOP

SWR9=11=0 TEST 1 CPS CRYSTAL CLOCK
SWR9=11=1 TEST 50 CPS CRYSTAL CLOCK
SWR9=11=2 TEST 50 CPS LINE CLOCK
SWR9=11=3 TEST 60 CPS LINE CLOCK
SWR9=11=4 TEST 500 CPS CRYSTAL CLOCK
SWR9=11=5 TEST 5000 CPS CRYSTAL CLOCK

4.2 STARTING ADDRESS

THE STARTING ADDRESS IS 0200 OCTAL.

4.3 OPERATOR ACTION

4.3.1 DK8-EA OR DK8-EC TEST

WITH THE PROGRAM IN BANK 0, SET SWITCH REGISTER TO 0200.

PRESS ADDRESS LOAD.

SET THE SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE FREQUENCY OF DK8-EA
OR DK8-EC CLOCK UNDER TEST.

PRESS CLEAR AND THEN PRESS CONTINUE.

THE PROGRAM SHOULD RUN UNTIL AN ERROR OCCURES OR UNTIL
STOPPED BY THE OPERATOR.

THE TTY WILL SIGNAL "DK8E PASS COMPLETE" AT
THE COMPLETION OF EVERY PASS.

4.3.2 DK8-EP/DK8-ES REGISTER TEST

WITH THE PROGRAM IN BANK 0, SET SWITCH REGISTER TO 0200.

PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE DK8-EP/DK8-ES REGISTER TEST.

PRESS CLEAR AND THEN PRESS CONTINUE.

THE PROGRAM SHOULD RUN UNTIL AN ERROR OCCURES OR UNTIL
STOPPED BY THE OPERATOR.

THE TTY WILL SIGNAL "DK8E PASS COMPLETE" AT
THE COMPLETION OF EVERY PASS.

4.3.3 DK8-ES SCHMITT TRIGGER INPUT LOGIC TEST

WITH THE PROGRAM IN BANK 0, SET THE SWITCH REGISTER TO 0200.

PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET THE SWITCH REGISTER TO INDICATE DK8-ES SCHMITT TRIGGER
INPUT LOGIC TEST.

PRESS CLEAR AND THEN CONTINUE.

THE PROGRAM SHOULD RUN UNTIL AN ERROR OCCURS OR UNTIL STOPPED BY THE OPERATOR.

THE TTY WILL SIGNAL "DK8E PASS COMPLETED" AT THE COMPLETION OF EVERY PASS.

4.3.4 DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP

WITH THE PROGRAM IN MEMORY, SET THE SWITCH REGISTER TO 0200.

PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE EXTERNAL PULSE SCOPE LOOP.

PRESS CLEAR AND THEN PRESS CONTINUE.

USE OSCILLOSCOPE TO VERIFY 40 MICRO SECOND PULSE RATE AT FJ2, FJ1, HM1, AND HM2 ON THE DK8-EP/DK8-ES MODULES.

USE OSCILLOSCOPE TO VERIFY 40 MICRO SECOND PULSE RATE AT OVERFLOW ON DK8-ES CLOCK FRONT PANEL. (DK8-ES ONLY)

4.3.5 DK8-ES EXTERNAL CLOCK SCOPE LOOP

WITH THE PROGRAM IN MEMORY, SET THE SWITCH REGISTER TO 0200.

PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE EXTERNAL CLOCK SCOPE LOOP.

PRESS CLEAR AND THEN PRESS CONTINUE.

GROUND CLOCK IN ON DK8-ES CLOCK FRONT PANEL.

THE TTY BELL WILL SIGNAL, IF AN EXTERNAL CLOCK IN WAS RECEIVED.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

NONE

5.2 SUBROUTINE ABSTRACTS

NONE

5.3 OPERATION ACTION

5.3.1 DK8-EA LINE OR DK8-EC CRYSTAL CLOCK

INSTALL DK8-EA OR DK8-EC CLOCK AND FOLLOW OPERATOR
4.3.1 .

5.3.2 DK8-EP PROGRAMMABLE CLOCK

INSTALL DK8-EP CLOCK AND FOLLOW OPERATOR ACTION 4.3.2 .

5.3.3 DK8-ES SCHMITT TRIGGER INPUT LOGIC

INSTALL DK8-ES CLOCK, RUN DK8-EP/DK8-ES REGISTER TEST,
CONNECT EXT. CPS SOURCE FREQUENCY, LOCATED AT J5 ON PDP8/E
POWER SUPPLY, TO DK8-ES CLOCK FRONT PANEL, AND FOLLOW
OPERATOR ACTION 4.3.3.

5.3.4 DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP

INSTALL DK8-EP OR DK8-ES CLOCK, RUN DK8-EP/DK8-ES REGISTER
TEST, AND FOLLOW OPERATOR ACTION 4.3.4.

5.3.5 DK8-ES EXTERNAL CLOCK SCOPE LOOP

INSTALL DK8-ES CLOCK, RUN DK8-EP/DK8-ES REGISTER TEST,
RUN DK8-ES EXTERNAL SCHMITT TRIGGER INPUT LOGIC TEST,
RUN DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP, AND FOLLOW
OPERATOR ACTION 4.3.5.

6. ERRORS

ALL RECOVERABLE ERRORS ENCOUNTERED IN THE PROGRAM WILL
RESULT IN AN ERROR HALT OR AN ERROR TYPEOUT AND THEN
AN ERROR HALT.

6.1 ERRORS AND DISCRPTION

6.1.1 ERROR HALTS

ERROR HALTS IN PROGRAM ARE AS FOLLOWS:

EHLT1: MONITOR ERROR HALT, READ ERROR TYPE OUT.

EHLT2: SKIP TRAP, CLZE

EHLT3: SKIP TRAP, CLOE

EHLT4: SKIP TRAP, CLOE

EHLT5: SKIP TRAP, CLAB

EHLT6: SKIP TRAP, CLEN

EWLT7: SKIP TRAP, CLSA

EWLT8: SKIP TRAP, CLBA

EWLT11: SKIP TRAP, CLCA

6.1.2 ERROR TYPEOUTS

ERROR TYPEOUTS IN PROGRAM ARE AS FOLLOWS:

TEST XXXX FAILED, STARTING ADDRESS XXXX

THE GOOD AC = XXXX AND BAD AC = XXXX

CLOCK BUFFER REGISTER AND AC TRANSFER FAILED

CLOCK COUNTER REGISTER AND AC TRANSFER FAILED

CLOCK ENABLE REGISTER AND AC TRANSFER FAILED

THE AC WAS CHANGED BY A CLOCK IOY

PROGRAM INTERRUPT FAILED, NO INTERRUPT EXPECTED

PROGRAM INTERRUPT FAILED, INTERRUPT EXPECTED

CLOCK SKIP FAILED, NO SKIP EXPECTED

CLOCK SKIP FAILED, SKIP EXPECTED

CLOCK OUTPUT FAILED, CLOCK FREQUENCY FAST

CLOCK OUTPUT FAILED, CLOCK FREQUENCY SLOW

6.2 ERROR RECOVERY

ALL ERRORS ENCOUNTERED MUST BE CORRECTED BEFORE PROCEEDING ON IN THE PROGRAM, IN ALL CASES ACCESS THE LISTING FOR FURTHER INFORMATION.

6.2.1 SCOPE LOOPS

A SCOPE LOOP IS AVAILABLE FOR ALL MONITOR ERROR HALTS, THE OPERATOR MAY ENTER A SCOPE LOOP AFTER A MONITOR ERROR HALT BY DOING THE FOLLOWING,

SET SWR4=1 TO INDICATE INHIBIT ERROR HALT.

SET SWR5=1 TO INDICATE ENTER SCOPE LOOP,

SET SWR6=1 TO INDICATE LOOP ON THIS TEST,

PRESS CLEAR AND THEN PRESS CONTINUE,

SET SWR2=1 TO INHIBIT ERROR TYPEOUT.

SET SWR3=1 TO INHIBIT ERROR BELL.

7. RESTRICTIONS

7.1 STARTING RESTRICTIONS

NONE

7.2 OPERATING RESTRICTIONS

THE PROGRAM MUST RESIDE IN BANK 0 .

PDP-8E WITH THE DK8-EA, DK8-EC, DK8-ES, OR THE DK8-EP
CLOCK OPTION INSTALLED.

THE EXT. CPS SOURCE USED IN THE DK8-ES EXTERNAL SCHMITT
TRIGGER INPUT LOGIC TEST MUST BE DISCONNECTED WHEN
RUNNING THE DK8-EP/DK8-ES REGISTER TEST.

THE PDP-8E MUST BE RUNNING FAST CYCLE "1.2" MICRO. SECONDS.

ALL CLOCK OUTPUTS SHOULD BE VERIFIED WITH AN OSCILLOSCOPE
TO INSURE CORRECT OPERATION.

8. MISCELLANEOUS

8.1 EXECUTION TIME

DK8-EA OR DK8-EC TEST, APPROXIMATIVELY 2.5 MINUTES.

DK8-EP/DK8-ES REGISTER TEST, APPROXIMATIVELY 3.5 MINUTES.

DK8-ES SCHMITT TRIGGER INPUT LOGIC TEST, APPROXIMATIVELY
2 MINUTES.

9. PROGRAM DISCRPTION

9.1 DK8-EA OR DK8-EC CLOCK

THE PROGRAM EXERCISES AND TESTS THE FOLLOWING IOT'S FOR CORRECT
OPERATION AND FUNCTION.

SKIP ON A CLOCK FLAG AND CLEAR THE FLAG (CLSK)

OCTAL CODE: 6133

OPERATION: SENSES THE CLOCK FLAG, WHICH IS SET WITH
EACH CLOCK PULSE. IF IT IS SET, THE NEXT
SEQUENTIAL INSTRUCTION IS SKIPPED AND THE
FLAG IS THEN CLEARED.

ENABLE CLOCK INTERRUPT (CLEI)

OCTAL CODE: 6131

OPERATION: ENABLES THE CLOCK FLAG, WHICH IS SET H
EACH CLOCK PULSE, TO CAUSE A PROGRAM

INTERRUPT REQUEST. THE FLAG WILL BE SET UNTIL CLEARED WITH CLOK.

DISABLE CLOCK INTERRUPT (CLEB)

OCTAL CODE: 6132

OPERATION: DISABLES THE CLOCK FLAG FROM CAUSING AN INTERRUPT REQUEST. THE FLAG IS NOT AFFECTED.

9.2

DK9-EP/DK9-ES CLOCK

THE PROGRAM EXERCISES AND TESTS THE FOLLOWING IOT'S FOR CORRECT OPERATION AND FUNCTION.

CLEAR THE CLOCK ENABLE REGISTER PER AC (CLZE)

OCTAL CODE: 6130

OPERATION: CLEANS THE BITS IN THE CLOCK ENABLE REGISTER CORRESPONDING TO THOSE BITS SET IN THE AC. THE AC IS NOT AFFECTED.

SKIP ON A CLOCK INTERRUPT (CLSK)

OCTAL CODE: 6131

OPERATION: SENSSES FOR INTERRUPT CONDITIONS, IF THE CONDITIONS ARE PRESENT THE NEXT SEQUENTIAL INSTRUCTION IS SKIPPED. THE CONDITIONS ARE AS FOLLOWS:
A, ENABLE EVENT INTERRUPT 1 AND INPUT 4
B, ENABLE EVENT INTERRUPT 2 AND INPUT 2
C, ENABLE EVENT INTERRUPT 3 AND INPUT 1
D, ENABLE OVERFLOW INTERRUPT AND OVERFLOW

AC TO CLOCK ENABLE REGISTER (CLOE)

OCTAL CODE: 6132

OPERATION: CAUSES THE CONTENTS OF THE AC TO BE LOADED INTO THE CLOCK ENABLE REGISTER CORRESPONDING TO THOSE BITS SET IN THE AC. THE AC IS NOT AFFECTED. CLOCK ENABLE REGISTER FUNCTIONS ARE AS FOLLOWS.

AC BIT FUNCTION

0 ENABLE CLOCK OVERFLOW

1 & 2 MODE CONTROL

00 COUNTER RUNS AT SELECTED RATE, OVERFLOW OCCURS EVERY 4096 COUNTS. OVERFLOW REMAINS SET UNTIL CLEARED BY (CLSA) IOT 6135.

01 COUNTER RUNS AT SELECTED RATE, OVERFLOW CAUSES THE CLOCK BUFFER REGISTER TO BE TRANSFERED TO THE CLOCK COUNTER REGISTER WHICH WILL CONTINUE TO RUN AFTER TRANSFER. OVERFLOW WILL REMAIN SET UNTIL CLEARED BY (CLSA) IOT 6135.

10 COUNTER RUNS AT SELECTED RATE,
AN EXTERNAL SCHMITT TRIGGER SIGNAL,
IF ENABLED, CAUSES THE CLOCK COUNTER
REGISTER TO BE TRANSFERED TO THE CLOCK
BUFFER REGISTER AND THE CLOCK COUNTER
CONTINUES TO RUN.

11 COUNTER RUNS AT SELECTED RATE,
AN EXTERNAL SCHMITT TRIGGER SIGNAL,
IF ENABLED, CAUSES THE CLOCK COUNTER
REGISTER TO BE TRANSFERED TO THE
CLOCK BUFFER REGISTER AND THE CLOCK
COUNTER WILL CONTINUE TO RUN FROM 0.

3,4 & 5

COUNT RATE

000 STOP
001 EXTERNAL CLOCK SOURCE
010 100 CPS
011 1000 CPS
100 10000 CPS
101 100000 CPS
110 1000000 CPS
111 STOP

6

WHEN SET TO A 1, OVERFLOW CAUSES
AN EXTERNAL PULSE.

7

WHEN SET TO A 1, THE CLOCK COUNTER
IS INHIBITED FROM COUNTING.

8

WHEN SET TO A 1, ENABLES EXTERNAL
SCHMITT TRIGGER SIGNALS AND THE OVERFLOW
FLOP TO CAUSE AN INTERRUPT REQUEST IF
THEY ARE ENABLED.

9,10 & 11

ENABLE SCHMITT TRIGGER EVENTS

100 INPUT 4
010 INPUT 2
001 INPUT 1

AC TO CLOCK BUFFER REGISTER (CLAB)

OCTAL CODE: 6133

OPERATION:

CAUSES THE CONTENTS OF THE AC TO BE
TRANSFERED INTO THE CLOCK BUFFER REGISTER.
THE CONTENTS OF BUFFER REGISTER IS THEN
TRANSFERED TO THE CLOCK COUNTER
REGISTER, THE AC IS NOT AFFECTED.

CLOCK ENABLE REGISTER TO AC (CLEN)

OCTAL CODE: 6134

OPERATION:

CAUSES THE CONTENTS OF THE CLOCK ENABLE
REGISTER TO BE TRANSFERRED TO THE AC,
THE ENABLE REGISTER IS NOT AFFECTED.

CLOCK STATUS TO AC (CLSA)

OCTAL CODE: 6135
OPERATION: CAUSES THE CONTENTS OF THE CLOCK STATUS REGISTER TO BE TRANSFERRED INTO THE AC. THE STATUS BITS ARE THEN CLEARED CORRESPONDING TO THOSE BITS THAT WERE SET IN THE AC. THE STATUS REGISTER FUNCTIONS ARE AS FOLLOWS.

AC BIT	STATUS CONDITION
0	OVERFLOW
1-8	NOT USED
9	INPUT 4
10	INPUT 2
11	INPUT 1

CLOCK BUFFER REGISTER TO AC (CLBA)
OCTAL CODE: 6136
OPERATION: CAUSES THE CONTENTS OF THE CLOCK BUFFER REGISTER TO BE TRANSFERRED INTO THE AC. THE BUFFER REGISTER IS NOT AFFECTED.

CLOCK COUNTER REGISTER TO AC (CLCA)
OCTAL CODE: 6137
OPERATION: CAUSES THE CONTENTS OF THE CLOCK COUNTER TO BE TRANSFERRED INTO THE CLOCK BUFFER REGISTER. THE BUFFER REGISTER IS THEN TRANSFERRED INTO THE AC. THE COUNTER REGISTER IS NOT AFFECTED.

10. LISTING

5

/
 /DK8E CLOCKS DIAGNOSTIC (PRELIMINARY VERSION)
 /
 /COPYRIGHT 1971 © DIGITAL EQUIP. CORP., MAYNARD, MASS.
 /
 /THE STARTING ADDRESS 0200 OCTAL,
 /
 /PLEASE READ DOCUMENT FOR FURTHER INFORMATION,
 /

	0000	*0000	
		/	
0000	0000	0000	
0001	5001	5001	
0002	0002	0002	
0003	0003	0003	
0004	0000		0000
0005	0000		0000
0006	0207	K0207,	0207
0007	0007	K0007,	0007
0010	0000	AUTO10,	0000
0011	0000	SAVAC,	0000
0012	7700	K7700,	7700
0013	0100	K0100,	0100
0014	4000	K4000,	4000
0015	0200	K0200,	0200
0016	2525	K2525,	2525
0017	5252	K5252,	5252
0020	5102	X10TA,	10TA
0021	5107	X10TB,	10TB
0022	5114	X10TC,	10TC
0023	5121	X10TD,	10TD
0024	5127	X10TE,	10TE
0025	5134	X10TF,	10TF
0026	5142	X10TF1,	10TF1
0027	5146	X10TG,	10TG
0030	5154	X10TH,	10TH
0031	5163	X10TI,	10TI
0032	5200	X10TJ,	10TJ
0033	5207	X10TK,	10TK
0034	5350	X10TS,	10TS
0035	5360	X10TS1,	10TS1
0036	5370	X10TS2,	10TS2
0037	5400	X10TS3,	10TS3
0040	0000	REGA,	0000
0041	0000	REGB,	0000
0042	0000	REGC,	0000
0043	0000	REGD,	0000
0044	0000	REGE,	0000
0045	0000	REGF,	0000
0046	5642	SKPWAT,	XWAIT
0047	5255	XPIG01,	PIG01
0050	5270	XPIG02,	PIG02
0051	5323	XPIG03,	PIG03
0052	5336	XPIG04,	PIG04
0053	5234	XPIG05,	PIG05

0034	5310	XISE:	ISELCP
0055	5224	HANDY,	RANDOM
0056	5216	XSNDRV:	SNDRV
0057	5302	XSYNS:	SYNS
0060	5065	XCLREG:	CLREG
0061	0215	OVER2:	OGNEAC
0062	0217	OVER2A:	OGNEAC *2
0063	0070	XKBER:	TS130
0064	3551	XMITT:	YBT002
0065	3556	XMITT1:	YBT002 *3
0066	5060	XLAS:	BLAS
0067	5746	XGTAD:	GTAD
0070	0000	SEND:	0000
0071	0000	RECEV:	0000
0072	5000	NEROR:	NERRO
0073	0020	ERR05:	ERR0
0074	5413	XLOCK:	CLOCK
0075	0000	CLCKS:	0000
0076	0000	KRE00:	0000
0077	0000	LOOP:	0000
0100	5402	JMP12:	JMP I 2
0101	5441	XPRLE:	ORLE
0102	5563	XPRE:	PRE0
0103	5471	XSNRY:	SNRY
0104	5420	XOSTEL:	OSTEL
0105	5542	XMESS:	MESS
0106	5604	XPRINT:	PRINT
0107	5056	XTYPE:	TYPE
0110	5046	XBELL:	BELL
0111	7730	KPRHTI:	7730
0112	7400	K7400:	7400
0113	0000	K71CPS:	0000
0114	6007	K6007:	6007
0115	0006	K0006:	0006
0116	0400	K0400:	0400
0117	6000	K6000:	6000
0120	3000	K3000:	3000
0121	5000	K5000:	5000
0122	7770	K7770:	7770
0123	0200	K0200:	0200
0124	4100	K4100:	4100
0125	5740	K5740:	5740
0126	0240	K0240:	0240
0127	0017	K0017:	0017
0130	7774	K7774:	7774
0131	7773	K7773:	7773
0132	7772	K7772:	7772
0133	0077	K0077:	0077
0134	0215	K0215:	0215
0135	0212	K0212:	0212
0136	0377	K0377:	0377
0137	0040	K0040:	0040
0140	0020	K0020:	0020
0141	7000	K7000:	7000
0142	0010	K0010:	0010

```

0143 2000 K2000, 2000
0144 1000 K1000, 1000
0145 0300 K0300, 0300
0146 0500 K0500, 0500
0147 0600 K0600, 0600
0150 0700 K0700, 0700
0151 2725 KTA, 2725
0152 2650 KYA1, 2650
0153 7425 KTB, 7425
0154 7350 KTB1, 7350
0155 7753 KTC, 7753
0156 0225 KTC1, 0225
0157 0150 KTC2, 0150
0160 1450 KTD, 1450
0161 1425 KTD1, 1425
0162 6575 KTE, 6575
0163 6525 KTE1, 6525
0164 5600 XSET0, SET0
0165 5450 XOPR, POPR
0166 0070 PATCH, 0070
0167 5771 XGETM, TIMCLK
0170 5740 XPASS, PASS
0171 1779 XCRS1, T122B
0172 2200 XCRS2, T127A
0173 2603 XCRS3, T150A
0174 2565 XCRS4, T150B
0175 4003 XCRS5, T215A

```

0200 *0200

```

0200 7300 BEGIN, CLA CLL /CLEAR THE AC AND LINK
0201 6007 6007 /CAP OR CLEAR THE WORLD
0202 4501 JMS I XCRLF /CRLF
0203 4506 JMS I XPRINT /PRINT DKBE CLOCKS DIAGNOSTIC
0204 6000 DKMES /MESSAGE POINTER
0205 4501 JMS I XCRLF /CRLF
0206 4460 JMS I XCLREG /CLEAR ALL MY REGISTERS
0207 4564 JMS I XSET0 /SET UP FOR PI RETURN
0210 4466 JMS I XLAS /GET HIS SWITCHES
0211 5465 JMP I XMITT1 /TEST SCHMITT
0212 5463 JMP I XDKBEP /TEST DKBEP CLOCK
0213 4474 JMS I XCLOCKS /TEST DKBEA OR DKBEC
0214 4565 JMS I XOPR /SORT AND PRINT FREQ, SELECTED
0215 4567 BGNEAC, JMS I XGETM /GET TIME LENGTH
0216 3077 DCA LOOP /SET LOOP COUNTER
0217 4460 JMS I XCLREG /CLEAR ALL REGISTERS
0220 3040 DCA REGA

```

/
/DONES IOT CLEI CHANGE AC ?
/CHECK ALL COMBINATIONS

```

0221 1040 TST0, TAD REGA /GET AC NUMBER
0222 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0223 1070 TAD SEND
0224 4420 JMS I XIOTA /IOT 6131, CLEI

```

```

0225 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
0226 3071 TAB RECEV
0227 4456 JMS I XSDRV /CHECK SEND AND RECEV REGISTERS
0230 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0231 4473 JMS I ERROR /ERROR: CLEI CHANGED AC,
0232 3000 3002 /TST0 ERROR MESSAGE,
0233 3021 TST0 /SCOPE LOOP,
0234 3040 DCA REGA

```

/
/DOES IOT CLEI CHANGE AC ?
/CHECK ALL COMBINATIONS

```

0235 1040 TST1, TAB REGA /SET AC NUMBER
0236 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0237 1070 TAB SEND
0240 4421 JMS I XICPB /IOT 6132, CLEI
0241 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
0242 1071 TAB RECEV
0243 4456 JMS I XSDRV /CHECK SEND AND RECEV REGISTERS
0244 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0245 4473 JMS I ERROR /ERROR: CLEI CHANGED AC,
0246 3001 3001 /TST1 ERROR MESSAGE,
0247 3033 TST1 /SCOPE LOOP,
0250 3040 DCA REGA

```

/
/DOES IOT CLSK CHANGE AC ?
/CHECK ALL COMBINATIONS

```

0251 1040 TST2, TAB REGA /SET AC NUMBER
0252 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0253 1070 TAB SEND
0254 4422 JMS I XICPC /IOT 6133, CLSK
0255 7000 NOP /WAIT JUST IN CASE I
0256 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
0257 1071 TAB RECEV
0260 4456 JMS I XSDRV /CHECK SEND AND RECEV REGISTERS
0261 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0262 4473 JMS I ERROR /ERROR: CLSK CHANGED AC,
0263 3002 3002 /TST2 ERROR MESSAGE,
0264 3051 TST2 /SCOPE LOOP,

```

/
/TEST FOR NO INTERRUPT RQST,

```

0265 6007 TST3, 6007 /CAF OR CLEAR THE WORLD
0266 4447 JMS I XPIGCI /GO TO PI, NO PI EXPECTED
0267 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0270 4473 JMS I ERROR /ERROR:PI OR INT, RQST, FAILED
0271 1003 1003 /TST3 ERROR MESSAGE
0272 3065 TST3 /SCOPE LOOP

```

/
/DOES CLSK SKIP ON A CLOCK FLAG

```

0273 1113 TST4, TAB KTICPS
0274 3045 DCA REGF /SET UP TIMER
0275 4422 JMS I XICPC /IOT 6133, CLSK

```

```

0276 7000      NOP
0277 4422      JMS I XIOTC      /IOT 6133, CLSK
0300 4446      JMS I SKPWAT    /GO WAIT FOR FLAG
0301 4472      JMS I NERROR    /CHECK NON-ERROR HANDLER
0302 4473      JMS I ERROR     /ERROR! CLSK OR FLAG FAILED
0303 0404      0404      /TST4 ERROR MESSAGE
0304 0273      TST4      /SCOPE LOOP

```

/DOES CLSK CLEAR THE FLAG ?

```

0305 1113      TST5, TAD KT1CPS
0306 3045      DCA REGF      /SET UP TIMER
0307 4422      JMS I XIOTC      /IOT 6133, CLSK
0310 7000      NOP
0311 4422      JMS I XIOTC      /IOT 6133, CLSK
0312 4446      JMS I SKPWAT    /GO WAIT FOR FLAG
0313 7410      SKP      /GOT THE FLAG
0314 5704      JMP I ,,-10     /GO BACK TO TEST 4
0315 4422      JMS I XIOTC      /IOT 6133, CLSK
0316 4472      JMS I NERROR    /CHECK NON-ERROR HANDLER
0317 4473      JMS I ERROR     /ERROR! CLSK CLEAR THE FLAG FAILED
0320 0005      0005      /TST5 ERROR MESSAGE
0321 0305      TST5      /SCOPE LOOP

```

/DOES CLEI ENABLE CLOCK INTERRUPT ?

```

0322 4420      TST6, JMS I XIOTA      /IOT 6131, CLEI
0323 4450      JMS I XPIG02    /GO TO PI, PI EXPECTED
0324 4472      JMS I NERROR    /CHECK NON-ERROR HANDLER,
0325 4473      JMS I ERROR     /ERROR! DID CLEI ENABLE CLOCK INTERRUPT ?
0326 1406      1406      /TST6 ERROR MESSAGE
0327 0322      TST6      /SCOPE LOOP,

```

/DOES CLED DISABLE CLOCK INTERRUPT ?

```

0330 4420      TST7, JMS I XIOTA      /IOT 6131, CLEI
0331 4421      JMS I XIOTB      /IOT 6132, CLED
0332 4447      JMS I XPIG01    /GO TO PI, NO PI EXPECTED
0333 4472      JMS I NERROR    /CHECK NON-ERROR HANDLER,
0334 4473      JMS I ERROR     /ERROR! DID CLED DISABLE CLOCK INTERRUPT?
0335 1007      1007      /TST7 ERROR MESSAGE
0336 0330      TST7      /SCOPE LOOP,

```

/DOES CAF DISABLE CLOCK INTERRUPT ?

```

0337 4420      TST10, JMS I XIOTA      /IOT 6131, CLEI
0340 6007      6007      /CAF OR CLEAR THE WORLD
0341 4447      JMS I XPIG01    /GO TO PI, NO PI EXPECTED
0342 4472      JMS I NERROR    /CHECK NON-ERROR HANDLER,
0343 4473      JMS I ERROR     /ERROR! DID CAF DISABLE CLOCK INTERRUPT ?
0344 1010      1010      /TST10 ERROR MESSAGE
0345 0337      TST10     /SCOPE LOOP,

```

/DOES CLEI ENABLE CLOCK INTERRUPT ?


```

0310 0310 03-04-87 0310 0310
0310 0400 TST10: JMS I X10YA /NOT 0100, CLEI
0317 0407 JMS I X100X /NO TO PI, PI EXPECTED
0318 0301 JMS T121
0321 0400 JMS I X10YA /NOT 0100, CLEI
0322 0400 JMS I X1000 /NO TO PI, PI EXPECTED
0323 0472 JMS I X0000 /CHECK NONERROR HANDLER,
0324 0472 T11A: JMS I ERROR /ERROR: CLEI AND CLEI NOT TOGETHER
0325 1411 0411 /ISA ERROR MESSAGE
0326 0310 /NOOP.
/
/POOR CLEI VARIABLE BLOCK INTERRUPT 1
/
0327 0420 TST10: JMS I X10YA /NOT 0101, CLEI
0328 0411 JMS I X10Y0 /NOT 0100, CLEI
0329 0400 JMS I X1000 /NO TO PI, NO PI EXPECTED
0330 0300 JMS X10A
0331 0400 JMS I X10YA /NOT 0100, CLEI
0334 0407 JMS I X1000 /NO TO PI, NO PI EXPECTED
0335 0472 JMS I NERROR /CHECK NONERROR HANDLER,
0336 0472 T11A: JMS I ERROR /ERROR: CLEI AND CLEI NOT TOGETHER
0337 1010 /TEST ERROR MESSAGE
0338 0300 /NOOP LOOP.
/
/TEST DECODER FOR 0100, NOT CLEI
/
0339 0421 TST10: JMS I X10YA /NOT 0100, CLEI
0340 0431 JMS I X10Y1 /NOT 0100, NOT AN IOT 0100
0341 0407 JMS I X1000 /NO TO PI, NO PI EXPECTED
0342 0472 JMS I NERROR /CHECK NONERROR HANDLER,
0343 0472 JMS I ERROR /ERROR: DID DECODER WORK
0344 1010 /TEST ERROR MESSAGE
0345 0300 /NOOP LOOP.
/
/TEST DECODER FOR 0100, NOT CLEI
/
0400 0420 TST10: JMS I X10YA /NOT 0101, CLEI
0401 0432 JMS I X10Y1 /NOT 0100, NOT AN IOT 0100
0402 0400 JMS I X1000 /NO TO PI, PI EXPECTED
0403 0472 JMS I NERROR /CHECK NONERROR HANDLER,
0404 0472 JMS I ERROR /ERROR: DID DECODER WORK
0405 1414 /TEST ERROR MESSAGE
0406 0400 /NOOP LOOP.
/
/TEST DECODER FOR 0107, NOT CLSK
/
0407 1113 TST15: TAD X1000
0410 3045 BCA REGF /SET UP TIMER
0411 0422 JMS I X10Y5 /NOT 0100, CLEI
0412 7000 NOP
0413 0433 JMS I X10YK /NOT 0107, NOT AN IOT 0100
0414 0444 JMS I SKPMAT /NO WAIT FOR FLAG
0415 7410 SKP /ERROR, SKIP OCCURRED
0416 0472 JMS I NERROR /CHECK NONERROR HANDLER,
0417 0472 JMS I ERROR /ERROR: DID DECODER WORK
0420 0015 TST15: /TEST ERROR MESSAGE

```

```

0421 0407          TST15          /SCOPE LOOP,
/
/DOES CLSK ENABLE CLOCK INTERRUPT ?
/
0422 4422 TST16, JMS I XI07C          /IOT 6133, CLSK
0423 7000          NOP
0424 4447          JMS I XPIG01          /GO TO PI, NO PI EXPECTED
0425 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER,
0426 4473          JMS I ERROR          /ERROR! DID CLSK CAUSE INTERRUPT
0427 1016          1016          /TST16 ERROR MESSAGE
0430 0422          TST16          /SCOPE LOOP,
/
/DOES CLSK DISABLE CLOCK INTERRUPT ?
/
0431 4420 TST17, JMS I XI07A          /IOT 6131, CLEI
0432 4422          JMS I XI07C          /IOT 6133, CLSK
0433 7000          NOP
0434 4450          JMS I XPIG02          /GO TO PI, PI EXPECTED
0435 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER,
0436 4473          JMS I ERROR          /ERROR! CLSK DISABLED CLOCK INTERRUPT
0437 1417          1417          /TST17 ERROR MESSAGE
0440 0431          TST17          /SCOPE LOOP,
/
/DOES CLEI CAUSE A SKIP ON FLAG ?
/
0441 1113 TST20, TAD KT10PS
0442 3045          DCA REGF          /SET UP TIMER
0443 4420          JMS I XI07A          /IOT 6131, CLEI
0444 4446          JMS I SKPWAT          /GO WAIT FOR FLAG
0445 7410          SKP          /ERROR, SKIP OCCURRED
0446 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER,
0447 4473          JMS I ERROR          /ERROR! DID CLEI CAUSE A SKIP
0450 0020          0020          /TST20 ERROR MESSAGE
0451 0441          TST20          /SCOPE LOOP,
/
/DOES CLEO CAUSE A SKIP ON FLAG ?
/
0452 1113 TST21, TAD KT10PS
0453 3045          DCA REGF          /SET UP TIMER
0454 4421          JMS I XI07B          /IOT 6132, CLEO
0455 4446          JMS I SKPWAT          /GO WAIT FOR FLAG
0456 7410          SKP          /ERROR, SKIP OCCURRED
0457 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER,
0460 4473          JMS I ERROR          /ERROR! DID CLEO CAUSE A SKIP ON FLAG
0461 0021          0021          /TST21 ERROR MESSAGE
0462 0452          TST21          /SCOPE LOOP,
/
/DOES INT, ROST STAY DOWN ?
/
0463 4457 TST22, JMS I XSYNC          /SYNC WITH CLOCK
0464 4420          JMS I XI07A          /IOT 6131, CLEI
0465 4447          JMS I XPIG01          /GO TO PI, PI EXPECTED
0466 5273          JMP T22A          /ERROR, PI FAILED
0467 2041          ISB REG8
0470 5267          JMP ,=1          /WAIT 15.5 MS

```

04110 04141 27-JUL-78 10:15 1-000 1-7

0471 4452 JMS I XPIG0A /GO TO PI, PI EXPECTED
0472 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0473 4473 /22A, JMS I ERROR /ERROR! DID RST, LAST J
0474 4422 1422 /TST21 ERROR MESSAGE
0475 0463 TST22 /SCOPE LOOP

/
/DOES CLSK CLEAR RST, LINE 1
/

0476 4426 TST23, JMS I XI07A /IOY 0101, CLEI
0477 4437 JMS I XSYNC /SYNC WITH CLOCK FLAG
0500 4451 JMS I XPIG03 /GO TO PI, NO PI EXPECTED
0501 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0502 4473 JMS I ERROR /ERROR! DID CLSK CLEAR RST, FLAG
2503 1000 1023 /TST23 ERROR MESSAGE
0504 0473 TST23 /SCOPE LOOP

/
/SYNC WITH CLOCK AND
/CHECK FOR FAST OUTPUT
/

0505 4467 TST21, JMS I X07AD /GET TIME CONSTANTS
0506 0000 0000 /MODIFIED BY TEST
0507 1706 TAD I ,=1
0510 3043 DCA RECD
0511 4420 JMS I XI07A /IOY 0101, CLEI
0512 4437 JMS I XSYNC /SYNC WITH CLOCK
0513 4447 JMS I XPIG01 /GO TO PI, NO PI EXPECTED
0514 4472 JMS I NERROR /CHECK NON-ERROR HANDLER!
0515 1473 JMS I ERROR /ERROR! CLOCK FREQUENCY FAST,
0516 2024 2024 /TST24 ERROR MESSAGE,
0517 0529 TST24 /SCOPE LOOP,

/
/SYNC WITH CLOCK AND
/CHECK FOR SLOW OUTPUT
/

0520 1115 TST25, TAD R0006 /SETUP FOR SLOW CLOCK
0521 4467 JMS I X07AD /GET TIME CONSTANTS
0522 0000 0000 /MODIFIED BY TEST
0523 1722 TAD I ,=1
0524 3043 DCA RECD
0525 4420 JMS I XI07A /IOY 0101, CLEI
0526 4437 JMS I XSYNC /SYNC WITH CLOCK
0527 4430 JMS I XPIG02 /GO TO PI, PI EXPECTED
0530 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0531 4473 JMS I ERROR /ERROR! CLOCK FREQUENCY SLOW,
0532 2425 2425 /TST25 ERROR MESSAGE,
0533 0520 TST25 /SCOPE LOOP,

/
/CHECK FOR FAST CLOCK AND
/BAD CLOCK FLAG WITH CLSK,
/

0534 4467 TST26, JMS I X07AD /GET TIME CONSTANTS
0535 0000 0000 /MODIFIED BY TEST
0536 1735 TAD I ,=1
0537 3043 DCA RECD
0540 4457 JMS I XSYNC /SYNC WITH CLOCK

```

0541 4454 JMS I X1S2 /WAIT
0542 4422 JMS I X107C /IOT 6133, CLSK
0543 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0544 4473 JMS I ERROR /ERROR! CLOCK FAILED
0545 2026 2026 /TST26 ERROR MESSAGE
0546 0534 TST26 /SCOPE LOOP

/
/CHECK FOR SLOW CLOCK AND
/BAD CLOCK FLAG WITH CLSK
/
0547 1113 TST27, TAD R0006 /SET UP FOR SLOW CLOCK
0550 4467 JMS I XGTAD /GET TIME CONSTANTS
0551 0000 0000 /MODIFIED BY TEST
0552 1751 TAD I ,=1
0553 3043 OCA REGD
0554 4457 JMS I XSYNC /SYNC WITH CLOCK
0555 4454 JMS I X1S2 /WAIT
0556 4422 JMS I X107C /IOT 6133, CLSK
0557 7410 NOP /ERROR, SKIP OCCURRED
0560 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0561 4473 JMS I ERROR /ERROR! CLSK OR CLOCK FLAG FAILED
0562 2427 2427 /TST27 ERROR MESSAGE
0563 0547 TST27 /SCOPE LOOP
0564 2077 ISZ LOOP
0565 5462 JMP I OVER2A /LOOP ON TEST
0566 4570 JMS I XPASS /TYPE PASS COMPLETE
0567 5461 JMP I OVER2 /RESET COUNTER AND CONTINUE TESTING

/
/DOES IOT CLE CHANGE AOT
/CHECK ALL COMBINATIONS.
/
0570 1040 TST30, TAD REGA /GET AC NUMBER
0571 4423 JMS I X107D /IOT 6130, CLE
0572 3071 OCA RECEV /SAVE INPUT FOR ERROR PRINTER
0573 1071 TAD RECEV
0574 4456 JMS I XSENDV /CHECK SEND AND RECV REGISTERS
0575 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0576 4473 JMS I ERROR /ERROR! CLE CHANGED AC
0577 3030 3030 /TST30 ERROR MESSAGE
0600 0570 TST30 /SCOPE LOOP

/
/DOES IOT CLSK CHANGE AOT
/CHECK ALL COMBINATIONS
/
0601 1040 TST31, TAD REGA /GET AC NUMBER
0602 3070 OCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0603 1070 TAD SEND
0604 4424 JMS I X107E /IOT 6101, CLSK
0605 3050 NOP
0606 3071 OCA RECV /SAVE INPUT FOR ERROR PRINTER
0607 1071 TAD RECV
0610 4456 JMS I XSENDV /CHECK SEND AND RECV REGISTERS
0611 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0612 4473 JMS I ERROR /ERROR! CLSK CHANGED AC

```

```

0612 3031          3031          /ISSUE ERROR MESSAGE
0613 0601          YST34          /SCOPE LOOP
/
/DOES IOT CLOB CHANGE AD?
/CHECK ALL COMBINATIONS
/
0615 1000          YST32,   YAD REGA          /GET AD NUMBER
0616 2420          JMS I XIOT?          /IOT 6132, CLOB
0617 3071          DSA RECV          /SAVE INPUT FOR ERROR PRINTER
0620 1071          YAD RECV
0621 4456          JMS I XERROR          /CHECK SEND AND RECV REGISTERS
0622 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
0623 6673          JMS I ERROR          /ERRORDIAG CHANGED TO
0624 3032          Y332          /ISSUE ERROR MESSAGE
0625 0601          YST33          /SCOPE LOOP
/
/DOES IOT CLAB CHANGE AD?
/CHECK ALL COMBINATIONS
/
0626 1000          YST35,   YAD REGA          /GET AD NUMBER
0627 4427          JMS I XIOT?          /IOT 6132, CLAB
0628 3071          DSA RECV          /SAVE INPUT FOR ERROR PRINTER
0631 1071          YAD RECV
0632 4456          JMS I XERROR          /CHECK SEND AND RECV REGISTERS
0633 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
0634 4473          JMS I ERROR          /ERRORDIAG CHANGED TO
0635 3033          Y333          /ISSUE ERROR MESSAGE
0636 0601          YST33          /SCOPE LOOP
/
/DOES CAF CLEAR BUFFER REGISTER?
/CHECK FOR JAM TO AD, CLBA.
/
0637 6007          YST34,   6007          /CAF OR CLEAR THE WORLD
0640 7340          CLA CLL CHA          /AD TO 7777
0641 4432          JMS I XIOT?          /IOT 6136, CLBA
0642 7650          CHA CLA          /CAF BUFFER ALL 0127
0643 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
0644 4473          JMS I ERROR          /ERRORDIAG OR CLBA FAILED
0645 3434          3434          /YST34 ERROR MESSAGE
0646 0637          YST34          /SCOPE LOOP
/
/DOES CAF CLEAR ENABLE REGISTER?
/CHECK FOR JAM TO AD, CLEN.
/
0647 6007          YST39,   6007          /CAF OR CLEAR THE WORLD
0650 7340          CLA CLL CHA          /AD TO 7777
0651 4430          JMS I XIOTH          /IOT 6134, CLEN
0652 7650          SNA CLA          /CAF ENABLE REGISTER ALL 0127
0653 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
0654 4473          JMS I ERROR          /ERRORDIAG OR CLEN FAILED
0655 4435          4435          /YST39 ERROR MESSAGE
0656 0647          YST35          /SCOPE LOOP

```

/
 /DOES CAF CLEAR STATUS REGISTER ?
 /CHECK JAM TO AC CLSA

```

/
0657 6827 TST36, 6827 /CAF OR THE CLEAR THE WORLD
0660 7340 CLA CLL CMA /AC TO 7777
0661 4431 JMS I XIOTI /IOT 6133, CLSA
0662 7650 SNA CLA /HAS STATUS REGISTER ALL 0'S ?
0663 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0664 4473 JMS I ERROR /CAF OR CLSA FAILED
0665 5036 5036 /TST36 ERROR MESSAGE
0666 0637 TST36 /SCOPE LOOP
  
```

/
 /DOES AC LOAD BUFFER REGISTER?
 /CHECK ALL 0'S TRANSFER
 /CHECK JAM TO AC, CLBA

```

/
0667 4427 TST37, JMS I XIOTG /IOT 6133, CLAB
0670 7340 CLA CLL CMA /AC TO 7777
0671 4432 JMS I XIOTJ /IOT 6136, CLBA
0672 7650 SNA CLA /HAS BUFFER ALL 0'S?
0673 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0674 4473 JMS I ERROR /ERROR:CLAB OR CLBA FAILED
0675 3437 3437 /TST37 ERROR MESSAGE
0676 0667 TST37 /SCOPE LOOP
  
```

/
 /DOES AC LOAD BUFFER REGISTER ?
 /CHECK ALL 1'S TRANSFER
 /CHECK JAM TO AC , CLBA

```

/
0677 7340 TST40, CLA CLL CMA /AC TO 7777
0700 4427 JMS I XIOTG /IOT 6133, CLAB
0701 7300 CLA CLL /CLEAR THE AC AND LINK
0702 4432 JMS I XIOTJ /IOT 6136, CLBA
0703 7040 CMA /COMPLEMENT THE AC
0704 7650 SNA CLA /HAS BUFFER ALL 1'S?
0705 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0706 4473 JMS I ERROR /ERROR:CLAB OR CLBA FAILED
0707 3440 3440 /TST40 ERROR MESSAGE
0710 0677 TST40 /SCOPE LOOP
  
```

/
 /DOES BUFFER SURVIVE PATTERN 0025 ?

```

/
0711 1010 TST41, TAD K2525 /GET LC NUMBER
0712 4427 JMS I XIOTG /IOT 6133, CLAB
0713 7040 CMA /COMPLEMENT AC
0714 4432 JMS I XIOTJ /IOT 6136, CLBA
0715 4456 JMS I KENDRY /CHECK SEND AND RECEV REGISTERS
0716 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0717 4473 JMS I ERROR /ERROR: BUFFER OR AC FAILED
0720 3441 3441 /TST41 ERROR MESSAGE
0721 0711 TST41 /SCOPE LOOP
  
```

/
 /DOES BUFFER SURVIVE PATTERN 0032 ?

```

0722 1017 TST42, TAO KBR201 /GET AC NUMBER
0723 4427 JMS I XIOTG /IOT 6133, CLAB
0724 7040 CMA /COMPLEMENT AC
0725 4432 JMS I XIOTJ /IOT 6136, CLBA
0726 4456 JMS I XNDRV /CHECK SEND AND RECEV REGISTERS
0727 4472 JMS I NERR0R /CHECK NON-ERROR HANDLER
0728 4473 JMS I ERR0R /ERROR: BUFFER OR AC FAILED
0731 3442 3442 /TST42 ERROR MESSAGE
0732 0722 TST42 /SCOPE LOOP

```

/DOES CLF REALLY CLEAR BUFFER ?

```

0733 7240 TST43, CLA CLA CMA /AC TO ALL 7777
0734 4427 JMS I XIOTG /IOT 6133, CLAB
0735 6007 6007 /CAP OR CLEAR THE WORLD
0736 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0737 7340 CLA CLL CMA
0740 4432 JMS I XIOTJ /IOT 6136, CLBA
0741 7050 SNA CLA /HAS BUFFER ALL B'S ?
0742 4472 JMS I NERR0R /CHECK NON-ERROR HANDLER
0743 4473 JMS I ERR0R /ERROR: CAP OR BUFFER FAILED
0744 3443 3443 /TST43 ERROR MESSAGE
0745 0733 TST43 /SCOPE LOOP

```

/DOES CAF REALLY CLEAR BUFFER ?
/DO ALL COMBINATIONS

```

0746 1040 TST44, TAO REGA /GET AC NUMBER
0747 4427 JMS I XIOTG /IOT 6133, CLAB
0748 6007 6007 /CAP OR CLEAR THE WORLD
0751 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0752 7340 CLA CLL CMA
0753 4432 JMS I XIOTJ /IOT 6136, CLBA
0754 7050 SNA CLA /HAS BUFFER ALL B'S ?
0755 4472 JMS I NERR0R /CHECK NON-ERROR HANDLER
0756 4473 JMS I ERR0R /ERROR: CAF OR BUFFER FAILED
0757 3444 3444 /TST44 ERROR MESSAGE
0760 0746 TST44 /SCOPE LOOP

```

/CHECK AC TO BUFFER REGISTER AND
/BUFFER REGISTER TO AC TRANSFERS.
/CHECK ALL COMBINATIONS.
/CHECK LOAD ON BUFFER REGISTER.

```

0761 7340 TST45, CLA CLL CMA
0762 3040 DCA REGA
0763 1041 T45B, TAO REGD /GET AC NUMBER
0764 4427 JMS I XIOTG /IOT 6133, CLAB
0765 7040 CMA /COMPLEMENT THE AC
0766 4432 JMS I XIOTJ /IOT 6136, CLBA
0767 4456 JMS I XNDRV /CHECK SEND RECEV REGISTERS
0770 7610 SXP CLA
0771 5375 JMP T45A
0772 2041 ISZ REGD /UPDATE AC NUMBER

```

```

0773 5363          JMP T45B
0774 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
0775 4473 T45A,    JMS I ERROR  /ERROR: AC OR BUFFER FAILED.
0776 3445          3445 /TST45 ERROR MESSAGE
0777 0761          TST45 /SCOPE LOOP

/
/DOES READING BUFFER CHANGE ITS CONTENTS ?
/
1000 7340 TST46,  CLA CLL CMA /AC TO 7777
1001 3040          DCA REGA
1002 1016          TAD K2325 /GET AC NUMBER
1003 4427          JMS I XIOTG /IOT 6133, CLAD
1004 7040          CMA /COMPLEMENT AC
1005 4432 T46B,    JMS I XIOTJ /IOT 6136, CLBA
1006 4456          JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1007 7610          SKP CLA
1010 5214          JMP T46A
1011 2041          ISZ REGB /UPDATE COUNTER
1012 5209          JMP T46B /DO 4096 TIMES
1013 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
1014 4473 T46A,    JMS I ERROR  /ERROR: BUFFER FAILED
1015 3446          3446 /TST46 ERROR MESSAGE
1016 1000          TST46 /SCOPE LOOP

/
/DOES READING BUFFER CHANGE ITS CONTENTS ?
/
1017 7340 TST47,  CLA CLL CMA /AC TO 7777
1020 3040          DCA REGA
1021 1017          TAD K5252 /GET AC NUMBER
1022 4427          JMS I XIOTG /IOT 6133, CLAD
1023 7040          CMA /COMPLEMENT AC
1024 4432 T47B,    JMS I XIOTJ /IOT 6136, CLBA
1025 4456          JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1026 7610          SKP CLA
1027 5233          JMP T47A
1030 2041          ISZ REGB /UPDATE COUNTER
1031 5224          JMP T47B /DO 4096 TIMES
1032 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
1033 4473 T47A,    JMS I ERROR  /ERROR: BUFFER FAILED
1034 3447          3447 /TST47 ERROR MESSAGE
1035 1017          TST47 /SCOPE LOOP

/
/DOES BUFFER SURVIVE RANDOM PATTERNS ?
/
1036 7340 TST82,  CLA CLL CV /AC TO 7777
1037 3040          DCA REGA
1040 4453 T120,   JMS I RANDY /GET RANDOM NUMBER
1041 4427          JMS I XIOTG /IOT 6133, CLAD
1042 7040          CMA /COMPLEMENT AC
1043 4432          JMS I XIOTJ /IOT 6136, CLBA
1044 4456          JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1045 7610          SKP CLA
1046 5252          JMP T58A
1047 2041          ISZ REGB /UPDATE COUNTER
1048 5248          JMP T58B /DO 4096 TIMES

```


LINE	ADDR	TEXT	SYMBOL	DESCRIPTION
1073	4472	JMS I NERROR	ZCHECK NON=ERROR HANDLER	
1074	4473	ZERROR	ZERROR: BUFFER FAILED	
1075	4474	4475	ZERROR: ERROR MESSAGE	
1076	4476	ZERROR	ZERROR: LOOP	
/				
/DOES BUFFER SURVIVE PAST ZERROR ?				
/				
1077	4477	ZERROR	ZERROR: BUFFER SURVIVED	
1078	4478	ZERROR	ZERROR: BUFFER SURVIVED	
1079	4479	ZERROR	ZERROR: BUFFER SURVIVED	
1080	4480	ZERROR	ZERROR: BUFFER SURVIVED	
1081	4481	ZERROR	ZERROR: BUFFER SURVIVED	
1082	4482	ZERROR	ZERROR: BUFFER SURVIVED	
1083	4483	ZERROR	ZERROR: BUFFER SURVIVED	
1084	4484	ZERROR	ZERROR: BUFFER SURVIVED	
1085	4485	ZERROR	ZERROR: BUFFER SURVIVED	
1086	4486	ZERROR	ZERROR: BUFFER SURVIVED	
1087	4487	ZERROR	ZERROR: BUFFER SURVIVED	
/				
/DOES AC SET ENABLE REGISTER?				
/CHECK ALL 819 TRANSFER,				
/CHECK JAM TO AC, CLEN				
/				
1070	7340	ZERROR	ZERROR: BUFFER SURVIVED	
1071	4425	ZERROR	ZERROR: BUFFER SURVIVED	
1072	7340	ZERROR	ZERROR: BUFFER SURVIVED	
1073	4430	ZERROR	ZERROR: BUFFER SURVIVED	
1074	7340	ZERROR	ZERROR: BUFFER SURVIVED	
1075	7650	ZERROR	ZERROR: BUFFER SURVIVED	
1076	4472	ZERROR	ZERROR: BUFFER SURVIVED	
1077	4473	ZERROR	ZERROR: BUFFER SURVIVED	
1078	4474	ZERROR	ZERROR: BUFFER SURVIVED	
1079	4475	ZERROR	ZERROR: BUFFER SURVIVED	
1080	4476	ZERROR	ZERROR: BUFFER SURVIVED	
1081	4477	ZERROR	ZERROR: BUFFER SURVIVED	
/				
/DOES AC SET ENABLE REGISTER?				
/CHECK ALL 819 TRANSFER,				
/CHECK FOR JAM TO AC , CLEN				
/				
1102	7340	ZERROR	ZERROR: BUFFER SURVIVED	
1103	4425	ZERROR	ZERROR: BUFFER SURVIVED	
1104	7340	ZERROR	ZERROR: BUFFER SURVIVED	
1105	4424	ZERROR	ZERROR: BUFFER SURVIVED	
1106	4430	ZERROR	ZERROR: BUFFER SURVIVED	
1107	7340	ZERROR	ZERROR: BUFFER SURVIVED	
1110	7650	ZERROR	ZERROR: BUFFER SURVIVED	
1111	4472	ZERROR	ZERROR: BUFFER SURVIVED	
1112	4473	ZERROR	ZERROR: BUFFER SURVIVED	
1113	4474	ZERROR	ZERROR: BUFFER SURVIVED	
1114	4475	ZERROR	ZERROR: BUFFER SURVIVED	
/				
/DOES CAF REALLY CLEAR ENABLE REGISTER?				
/				
1115	7340	ZERROR	ZERROR: BUFFER SURVIVED	
1116	4425	ZERROR	ZERROR: BUFFER SURVIVED	

```

1117 6007          6007          /CAF OR CLEAR THE WORLD
1120 3670          DCA SEND          /SAVE OUTPUT FOR XEROX PRINTER
1121 7340          CLA CLL CHA          /AC TO 7777
1122 4430          JMS I X107H          /IOT 6134, CLEN
1123 7650          SNA CLA          /WAS REGISTER ALL 0'S
1124 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
1125 4473          JMS I ERROR          /ERROR:CAF,CLE,OR CLR FAILED
1126 4454          4454          /TST54 ERROR MESSAGE
1127 1115          TST54          /SCOPE LOOP

```

/ DOES CAF REALLY CLEAR ENABLE REGISTER ?
/ DO ALL COMBINATIONS

```

1130 1040          /
TST55,  YAO REGA          /GET AC NUMBER
1131 4426          JMS I X107A          /IOT 6132, CLE
1132 6007          6007          /CAF OR CLEAR THE WORLD
1133 7340          CLA CLL CHA          /AC TO 7777
1134 4430          JMS I X107H          /IOT 6134, CLEN
1135 7650          SNA CLA          /WAS ENABLE REGISTER ALL 0'S ?
1136 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
1137 4473          JMS I ERROR          /ERROR: ENABLE REGISTER FAILED
1140 4455          4455          /TST55 ERROR MESSAGE
1141 1130          TST55          /SCOPE LOOP

```

/ DOES ENABLE REGISTER SURVIVE PATTERN 2525 ?

```

1142 1016          /
TST56,  YAO K2525          /GET AC NUMBER
1143 4425          JMS I X107F          /IOT 6132, CLE
1144 7040          CHA          /COMPLEMENT AC
1145 4430          JMS I X107H          /IOT 6134, CLEN
1146 4454          JMS I XSNDRV          /CHECK SEND AND RECV REGISTERS
1147 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
1150 4473          JMS I ERROR          /ERROR: ENABLE REGISTER FAILED
1151 4456          4456          /TST56 ERROR MESSAGE
1152 1142          TST56          /SCOPE LOOP

```

/ DOES ENABLE REGISTER SURVIVE PATTERN 5252 ?

```

1153 1017          /
TST57,  YAO K5252          /GET AC NUMBER
1154 4425          JMS I X107F          /IOT 6132, CLE
1155 7040          CHA          /COMPLEMENT AC
1156 4430          JMS I X107H          /IOT 6134, CLEN
1157 4454          JMS I XSNDRV          /CHECK SEND AND RECV REGISTERS
1160 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
1161 4473          JMS I ERROR          /ERROR: ENABLE REGISTER FAILED
1162 4457          4457          /TST57 ERROR MESSAGE
1163 1153          TST57          /SCOPE LOOP

```

/ DOES ENABLE REGISTER SURVIVE PATTERN 5525 ?

```

1164 1016          /
TST58,  YAO K5125          /GET AC NUMBER
1165 4425          JMS I X107F          /IOT 6132, CLE
1166 7340          CLA CLL          /CLEAR THE AC AND L17H
1167 4430          JMS I X107H          /IOT 6134, CLE
1168 7340          CHA CLL CHA          /AC TO 7777

```

VALUE	HEX	ADDRESS	OPERATION	DESCRIPTION
1171	4466		JMS I X1076	POINT 4466; OPEN
1172	446E		JMS I X5NDRV	CHECK SEND AND RECV REGISTERS
1173	4472		JMS I NERRDR	CHECK NON-ERROR HANDLER
1174	4478		JMS I ERROR	ERROR: ENABLE REGISTER FAILED
1175	446E	446E		POINT 446E ERROR MESSAGE
1176	1184		TS760	SCOPE LOOP

/ DOES ENABLE REGISTER SURVIVE PATTERN 0000 ?

VALUE	HEX	ADDRESS	OPERATION	DESCRIPTION
1177	1017		TS761:	POINT 1017
1200	4420		JMS I X107F	POINT 4420; OPEN
1201	7300		CLA CLL	CLEAR THE AC AND LINK
1202	4428		JMS I X107F1	POINT 4428; OPEN
1203	7300		CLA CLL CMA	AC TO 7777
1204	4430		JMS I X107F	POINT 4430; OPEN
1205	4466		JMS I X5NDRV	CHECK SEND AND RECV REGISTERS
1206	4472		JMS I NERRDR	CHECK NON-ERROR HANDLER
1207	4478		JMS I ERROR	ERROR: ENABLE REGISTER FAILED
1210	4461	4461		POINT 4461 ERROR MESSAGE
1211	1177		TS762	SCOPE LOOP

/ DOES ENABLE REGISTER SURVIVE COMPLEMENT PATTERN ?

VALUE	HEX	ADDRESS	OPERATION	DESCRIPTION
1212	7340		TS763:	AC TO 7777
1213	3070		CCA SEND	SAVE OUTPUT FOR ERROR PRINTER
1214	1016		POINT 1016	POINT 1016
1215	4426		JMS I X107F1	POINT 4426; OPEN
1216	7040		CMA	COMPLEMENT AC
1217	4426		JMS I X107F1	POINT 4426; OPEN
1220	7300		CLA CLL	CLEAR THE AC AND LINK
1221	4430		JMS I X107X	POINT 4430; OPEN
1222	4466		JMS I X5NDRV	CHECK SEND AND RECV REGISTERS
1223	4472		JMS I NERRDR	CHECK NON-ERROR HANDLER
1224	4478		JMS I ERROR	ERROR: ENABLE REGISTER FAILED
1225	4462	4462		POINT 4462 ERROR MESSAGE
1226	1212		TS764	SCOPE LOOP

/ DOES ENABLE REGISTER SURVIVE COMPLEMENT PATTERN ?

VALUE	HEX	ADDRESS	OPERATION	DESCRIPTION
1227	7340		TS765:	AC TO 7777
1230	3070		CCA SEND	SAVE OUTPUT FOR ERROR PRINTER
1231	1017		POINT 1017	POINT 1017
1232	4426		JMS I X107F1	POINT 4426; OPEN
1233	7040		CMA	COMPLEMENT AC
1234	4426		JMS I X107F1	POINT 4426; OPEN
1235	7300		CLA CLL	
1236	4430		JMS I X107X	POINT 4430; OPEN
1237	4466		JMS I X5NDRV	CHECK SEND AND RECV REGISTERS
1240	4472		JMS I NERRDR	CHECK NON-ERROR HANDLER
1241	4478		JMS I ERROR	ERROR: ENABLE REGISTER FAILED
1242	4463	4463		POINT 4463 ERROR MESSAGE
1243	1227		TS766	SCOPE LOOP

/ DO AC TO ENABLE REGISTER AND
/ ENABLE REGISTER TO AC TRANSFERS

/CHECK ALL COMBINATIONS

```

/
1244 1040 TST64, TAO RESA /GET AC NUMBER
1245 4425 JMS I XI0FP /10Y 6132, CLOS
1246 7340 CLA CLL CMA /AC TO 7777
1247 4430 JMS I XI0TH /10T 6134, CLEN
1250 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1251 4472 JMS I NERROR /CHECK NON-ERROR H. HANDLER
1252 4473 JMS I ERROR /ERROR: AC OR ENABLE REGISTER FAILED.
1253 4464 4464 /TST64 ERROR MESSAGE
1254 1244 TST64 /SCOPE LOOP
    
```

/DOES ENABLE REGISTER SURVIVE COMPLEMENT PATTERN,
/DO ALL COMBINATIONS.

```

/
1255 7340 TST65, CLA CLL CMA /AC TO 7777
1256 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1257 1040 TAO RESA /GET AC NUMBER
1260 4425 JMS I XI0FP1 /10Y 6132, CLOS
1261 7040 CMA /COMPLEMENT THE AC
1262 4425 JMS I XI0FP1 /10Y 6132, CLOS
1263 4430 JMS I XI0TH /10T 6134, CLEN
1264 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1265 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1266 4473 JMS I ERROR /ERROR: AC OR ENABLE REGISTER FAILED.
1267 4465 4465 /TST65 ERROR MESSAGE
1270 1255 TST65 /SCOPE LOOP
    
```

/DOES ENABLE REGISTER SURVIVE RANDOM PATTERN ?

```

/
1271 4459 TST66, JMS I RANDY /GET RANDOM NUMBER
1272 4425 JMS I XI0FP /10Y 6132, CLOS
1273 7300 CLA CLL /CLEAR THE AC AND LINK
1274 4430 JMS I XI0TH /10T 6134, CLEN
1275 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1276 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1277 4473 JMS I ERROR /ERROR: ENABLE REGISTER FAILED
1300 4466 4466 /TST66 ERROR MESSAGE
1301 1271 TST66 /SCOPE LOOP
    
```

/DOES ENABLE REGISTER SURVIVE RANDOM COMPLEMENT PATTERN ?

```

/
1302 7040 TST67, CLA CLL CMA /AC TO 7777
1303 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1304 4459 JMS I RANDY /GET RANDOM NUMBER
1305 4425 JMS I XI0FP1 /COMPLEMENT AC
1306 7040 CMA /AC TO 7777
1307 4425 JMS I XI0FP1 /10Y 6132, CLOS
1310 4430 JMS I XI0TH /10T 6134, CLEN
1311 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1312 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1313 4473 JMS I ERROR /ERROR: ENABLE REGISTER FAILED
1314 4467 4467 /TST67 ERROR MESSAGE
1315 1302 TST67 /SCOPE LOOP
    
```

/ DOES HEADLINE ENABLE REGISTER CHANGE THE CONTENTS ?

```

/
1313 7340 TST76, CLA CLL CMA JAC TO 7777
1317 8040 DCA REGA
1320 1010 YAD X0000 JUMP 00 NUMBER
1321 4420 JMS I X107F FIRST 0100, CLOS
1322 7340 Y700, CLA CLL CMA JAC TO 7777
1323 4430 JMS I X1000 FIRST 0100, CLOS
1324 8040 JMS I X0000 CHECK SEND AND RECV REGISTERS
1325 7610 YFF CLA
1326 8350 JAR 770A
1327 8040 ISR RECB SUPPARE COUNTER
1328 8420 JAR 7700 JCC 0000 LINE
1330 4470 JMS I X0000 CHECK NON-ERROR HANDLER
1332 4470 Y70A, JMS I X0000 CHECK ENABLE REGISTER CALLED
1333 4470 4470 ABOVE ERROR MESSAGE
1334 1314 Y8700 ESCAPE LOOP
    
```

/ DOES HEADLINE ENABLE REGISTER CHANGE THE CONTENTS ?

```

/
1335 7340 TST75, CLA CLL CMA JAC TO 7777
1336 8040 DCA REGA
1337 1010 YAD X0000 JUMP 00 NUMBER
1338 4420 JMS I X107F FIRST 0100, CLOS
1341 7300 Y700, CLA CLL CMA JAC TO 7777 AND LINA
1342 4430 JMS I X107F FIRST 0100, CLOS
1343 8040 JMS I X0000 CHECK SEND RECV REGISTERS
1344 7610 YFF CLA
1345 8350 JAR 770A
1346 8040 ISR RECB SUPPARE COUNTER
1347 8420 JAR 7700 JCC 0000 LINE
1348 4470 JMS I X0000 CHECK NON-ERROR HANDLER
1350 4470 Y70A, JMS I X0000 CHECK ENABLE REGISTER CALLED
1352 4470 4470 ABOVE ERROR MESSAGE
1353 1339 Y8700 ESCAPE LOOP
    
```

/ DOES ENABLE REGISTER SURVIVE FACT POSSIBLE ?

```

/
1354 1040 TST72, YAD REGA JUMP 00 NUMBER
1355 8070 DCA SEND SAVE OUTPUT FOR SEND REGISTER
1356 1040 YAD REGA
1357 4434 JMS I X107F FIRST 0100 AND 0104
1360 8070 DCA RECV SAVE INPUT FOR ERROR REGISTER
1361 1071 YAD RECV
1362 4436 JMS I X0000 CHECK SEND RECV REGISTERS
1363 4472 JMS I X0000 CHECK NON-ERROR HANDLER
1364 4473 JMS I X0000 CHECK ENABLE REGISTER CALLED
1365 4472 4472 ABOVE ERROR MESSAGE
1366 1354 YST72 ESCAPE LOOP
    
```

/ DOES CL2E CLEAR ENABLE REGISTER?

```

/
1367 7340 TST73, CLA CLL CMA JAC TO 7777
1370 4426 JMS I X107F FIRST 0100, CLOS
1371 7340 CLA CLL CMA
    
```

```

1372 4423 JMS I XIOTD /IOT 6130, CLEN
1373 7300 CLA CLL /CLEAR THE AC AND LTR
1374 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1375 7340 CLA CLL CMA /AC TO 7777
1376 4430 JMS I XIOTM /IOT 6134, CLEN
1377 7650 SNA CLA /NAS REGISTER ALL 0'S
1400 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1401 4473 JMS I ERROR /ERROR:CLZE OR CLEN FAILED,
1402 4473 4473 /I873 ERROR MESSAGE
1403 1367 TST73 /SCOPE LOOP

```

/

/DOES CLZE CLEAR ENABLE REGISTER?

/

```

1404 7340 TST74, CLA CLL CMA /AC TO 7777
1405 4425 JMS I XIOTF /IOT 6132, CLEN
1406 7300 CLA CLL
1407 4423 JMS I XIOTD /IOT 6130, CLEN
1410 7340 CLA CLL CMA /AC TO 7777
1411 3070 DCA SEND /SAVE OUTPUT ERROR PRINTER
1412 4430 JMS I XIOTM /IOT 6134, CLEN
1413 7040 CMA /COMPLEMENT AC
1414 7650 SNA CLA /NAS REGISTER ALL 0'S?
1415 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1416 4473 JMS I ERROR /ERROR:CLZE OR CLEN FAILED,
1417 4474 4474 /T874 ERROR MESSAGE
1420 1404 TST74 /SCOPE LOOP

```

/

/DOES CLZE CLEAR ENABLE REGISTER?

/

```

1421 1016 TST75, TAD K0035
1422 4425 JMS I XIOTF /IOT 6132, CLEN
1423 7040 CMA /COMPLEMENT THE AC
1424 4423 JMS I XIOTD /IOT 6130, CLEN
1425 7040 CMA /COMPLEMENT AC
1426 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1427 4430 JMS I XIOTM /IOT 6134, CLEN
1430 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1431 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1432 4473 JMS I ERROR /ERROR:CLZE, CLEN, OR CLEN FAILED
1433 4475 4475 /I875 ERROR MESSAGE
1434 1421 TST75 /SCOPE LOOP

```

/

/DOES CLZE CLEAR ENABLE REGISTER?

/

```

1435 1017 TST76, TAD K0252 /GET AC NUMBER
1436 4425 JMS I XIOTF /IOT 6132, CLEN
1437 7040 CMA /COMPLEMENT AC
1440 4423 JMS I XIOTD /IOT 6130, CLEN
1441 7040 CMA /COMPLEMENT AC
1442 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1443 4430 JMS I XIOTM /IOT 6134, CLEN
1444 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
1445 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1446 4473 JMS I ERROR /ERROR:ENABLE REGISTER FAILED
1447 4475 4475 /I876 ERROR MESSAGE

```

```

/
PAL10  V141  27701471  1162  1481 143-
1482  1781  TST75  SCOPE LOOP
/
/DOES CLZE CLEAR ENABLE REGISTER?
/CHECK ALL COMBINATIONS
/
1451  1840  TST77,  TAD RECA  /GET AC NUMBER
1452  4425  JMS I X10YF  /IOT 6132, CLOS
1453  4425  JMS I X10YD  /IOT 6130, CLRE
1454  7300  CLA CLL  /CLEAR THE AC AND LINK
1455  3870  DCA SEND  /SAVE OUTPUT FOR ERROR PRINTER
1456  7340  CLA CLL CHA  /AS TO ALL I'S
1457  4430  JMS I X10YF  /IOT 6134, CLEN
1458  7550  SNA CLA  /WAS REGISTER ALL OK?
1459  4472  JMS I NERROR  /CHECK NON-ERROR HANDLER
1460  4473  JMS I ERROR  /ERROR:CLRE, CLOS, OR CLEN FAILED
1461  4477  4477  /TST77 ERROR MESSAGE
1462  1451  TST77  /SCOPE LOOP

```

```

/
/DOES CLZE CLEAR ENABLE REGISTER?
/ALL COMBINATIONS
/
1465  1840  TST100, TAD MEGA  /GET AC NUMBER
1466  4424  JMS I X10YF  /IOT 6132, CLOS
1467  7040  CMA  /COMPLEMENT THE AC
1468  4425  JMS I X10YD  /IOT 6130, CLRE
1469  7240  CHA  /COMPLEMENT THE AC
1470  3870  DCA SEND  /SAVE OUTPUT FOR ERROR PRINTER
1471  4430  JMS I X10YH  /IOT 6134, CLEN
1472  4476  JMS I XNDYR  /CHECK SEND AND RECV REGISTERS
1473  4472  JMS I NERROR  /CHECK NON-ERROR HANDLER
1474  4473  JMS I ERROR  /ERROR:CLRE, CLOS, OR CLEN FAILED
1475  4500  4500  /TST100 ERROR MESSAGE
1476  1500  TST100  /SCOPE LOOP

```

```

/
/DOES CLZE SURVIVE RANDOM PATTERN ?
/
1501  4455  TST101, JMS I RANDY  /GET RANDOM NUMBER
1502  4425  JMS I YICTF  /IOT 6132, CLOS
1503  4425  JMS I X10YD  /IOT 6130, CLRE
1504  7300  CLA CLL  /CLEAR THE AC AND LINK
1505  3870  DCA SEND  /SAVE OUTPUT FOR ERROR PRINTER
1506  4430  JMS I X10YH  /IOT 6134, CLEN
1507  4456  JMS I XNDYR  /CHECK SEND AND RECV REGISTERS
1508  4472  JMS I NERROR  /CHECK NON-ERROR HANDLER
1509  4473  JMS I ERROR  /ERROR: ENABLE REGISTER FAILED
1510  4501  4501  /TST101 ERROR MESSAGE
1511  1501  TST101  /SCOPE LOOP

```

```

/
/DOES CLZE SURVIVE RANDOM COMPLEMENT PATTERN ?
/
1514  4455  TST102, JMS I RANDY  /GET RANDOM NUMBER
1515  4425  JMS I X10YF  /IOT 6132, CLOS
1516  7040  CMA  /COMPLEMENT AC

```

```

1517 4423 JMS I XIOTB /IOT 6135, CLAC
1520 7040 CMA /COMPLEMENT AC
1521 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1522 4430 JMS I XIOTM /IOT 6134, CLEN
1523 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1524 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1525 4473 JMS I ERROR /ERROR! ENABLE REGISTER FAILED
1526 4502 4502 /TSY102 ERROR MESSAGE
1527 1514 TSY102 /SCOPE LOOP

```

/ DOES CLZE SURVIVE FAST TOGGLE ?

```

1530 1040 TSY103, TAD REGA /GET AC NUMBER
1531 4423 JMS I XIOTF /IOT 6132, CLOE
1532 4437 JMS I XIOTS3 /IOT'S 6130 AND 6134
1533 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
1534 1071 TAD RECEV
1535 4456 JMS I XSNDRV /CHECK SEND RECEV REGISTERS
1536 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1537 4473 JMS I ERROR /ERROR! ENABLE REGISTER FAILED
1540 4503 4503 /TSY103 ERROR MESSAGE
1541 1530 TSY103 /SCOPE LOOP

```

/ DOES AC TRANSFER TO BUFFER THEN TO COUNTER ?

```

1542 4427 TSY104, JMS I XIOTG /IOT 6133, CLAB
1543 7040 CLA CLL CMA /AC TO ALL 1'S
1544 4433 JMS I XIOTK /IOT 6137, CLCA
1545 7050 SNA CLA /WAS COUNTER ALL 1'S?
1546 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1547 4473 JMS I ERROR /ERROR! CLAB OR CLCA FAILED
1550 4104 4104 /TSY104 ERROR MESSAGE
1551 1542 TSY104 /SCOPE LOOP

```

/ DOES AC TRANSFER TO BUFFER THEN TO COUNTER?

```

1552 7040 TSY105, CLA CLL CMA
1553 4427 JMS I XIOTG /IOT 6133, CLAB
1554 4433 JMS I XIOTK /IOT 6137, CLCA
1555 7040 CMA /COMPLEMENT THE AC
1556 7050 SNA CLA /WAS COUNTER ALL 1'S?
1557 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1560 4473 JMS I ERROR /ERROR! CLAB OR CLCA FAILED
1561 4105 4105 /TSY105 ERROR MESSAGE
1562 1552 TSY105 /SCOPE LOOP

```

/ DOES COUNTER SURVIVE PATTERN 2525 ?

```

1563 1010 TAD REGA /GET AC NUMBER
1564 4427 JMS I XIOTG /IOT 6133, CLAB
1565 7040 CLA CLL CMA /CLEAR THE AC AND LINK
1566 4433 JMS I XIOTK /IOT 6137, CLCA
1567 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1568 4472 JMS I NERROR /CHECK NON-ERROR HANDLER

```


PHASE	DATA	TEST, DL-78	TEST	SCOPE LOG
1571	4470	JMS I ERROR	TEST107	ERROR: BUFFER OVERFLOW
1572	4120	4100	TEST108	TEST108 ERROR MESSAGE
1573	4560	TEST109	TEST109	SCOPE LOOP
/				
/DOES COUNTER SURVIVE BUFFER ERROR ?				
/				
1574	1047	TEST107: TAD REGAR	TEST107	GET AD NUMBER
1575	4427	JMS I XIOYS	TEST107	ADT 4133: CLAB
1576	7040	CLA OLI OMA	TEST107	AD TO ALL 7777
1577	4433	JMS I XIOYK	TEST107	ADT 4137: OLSA
1600	4456	JMS I XSDRV	TEST107	CHECK SEND AND RECV REGISTERS
1601	4472	JMS I XERRR	TEST107	CHECK NON-ERROR HANDLER
1602	4473	JMS I XERRR	TEST107	ERROR: COUNTER FAILED
1603	4107	4107	TEST107	TEST107 ERROR MESSAGE
1604	1574	TEST107	TEST107	SCOPE LOOP
/				
/DOES AD TRANSFER TO BUFFER THEN TO COUNTER?				
/CHECK ALL COMBINATIONS				
/				
1605	1040	TEST108: TAD REGA	TEST108	GET AD NUMBER
1606	4427	JMS I XIOYS	TEST108	ADT 4133: CLAB
1607	7040	OMA	TEST108	IMPLEMENT TRK AD
1610	4433	JMS I XIOYK	TEST108	ADT 4137: OLSA
1611	4456	JMS I XSDRV	TEST108	CHECK SEND AND RECV REGISTERS
1612	4472	JMS I XERRR	TEST108	CHECK NON-ERROR HANDLER
1613	4473	JMS I XERRR	TEST108	ERROR: CLAB OR OLSA FAILED
1614	4110	4110	TEST108	TEST108 ERROR MESSAGE
1615	1605	TEST108	TEST108	SCOPE LOOP
/				
/DOES COUNTER SURVIVE PAST TOGGLE?				
/				
1616	1040	TEST111: TAD REGA	TEST111	GET AD NUMBER
1617	8070	OSA SEND	TEST111	SAVE OUTPUT FOR ERROR PRINTER
1620	1070	TAD SEND	TEST111	
1621	4436	JMS I XIOYR2	TEST111	ADT 4135 AND 4137
1622	8071	OSA RECV	TEST111	SAVE INPUT FOR ERROR PRINTER
1623	1071	TAD RECV	TEST111	
1624	4456	JMS I XSDRV	TEST111	CHECK SEND AND RECV REGISTERS
1625	4472	JMS I XERRR	TEST111	CHECK NON-ERROR HANDLER
1626	4473	JMS I XERRR	TEST111	ERROR: CLAB OR OLSA FAILED
1627	4111	4111	TEST111	TEST111 ERROR MESSAGE
1630	1616	TEST111	TEST111	SCOPE LOOP
/				
/DOES CAP AFFECT COUNTER ?				
/				
1631	1040	TEST112: TAD REGA	TEST112	GET AD NUMBER
1632	4427	JMS I XIOYS	TEST112	ADT 4133: CLAB
1633	8027	8027	TEST112	SAFE OR CLEAR THE WORLD
1634	4433	JMS I XIOYK	TEST112	ADT 4137: OLSA
1635	4456	JMS I XSDRV	TEST112	CHECK SEND AND RECV REGISTERS
1636	4472	JMS I XERRR	TEST112	CHECK NON-ERROR HANDLER
1637	4473	JMS I XERRR	TEST112	ERROR: CLAB OR OLSA FAILED
1640	4112	4112	TEST112	TEST112 ERROR MESSAGE

1641 1631 TST112 /SCOPE LOOP

/
/DOES READING COUNTER CHANGE ITS CONTENTS?
/PATTERN 2523,
/

1642 7340 TST113, CLA CLL CHA /AC TO 7777
 1643 3040 DCA REGA
 1644 1016 TAD K2525
 1645 4427 JMS I XIOTG /IOT 6133, CLAB
 1646 4433 T113B, JMS I XIOTK /IOT 6137, CLCA
 1647 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1650 7410 SKP
 1651 5255 JMP T113A
 1652 2041 ISZ REGB
 1653 5246 JMP T113B
 1654 4472 JMS I NERROR /CHECK NON=ERROR
 1655 4473 T113A, JMS I ERROR /ERROR! CLAB OR CLCA FAILED
 1656 4113 4113 /TST113 ERROR MESSAGE
 1657 1642 TST113 /SCOPE LOOP

/
/DOES READING COUNTER CHANGE ITS CONTENTS?
/PATTERN 5252
/

1660 7340 TST114, CLA CLL CHA /AC TO 7777
 1661 3040 DCA REGA
 1662 1017 TAD K5252
 1663 4427 JMS I XIOTG /IOT 6133, CLAB
 1664 4433 T114B, JMS I XIOTK /IOT 6137, CLCA
 1665 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1666 7410 SKP
 1667 5273 JMP T114A
 1670 2041 ISZ REGB
 1671 5264 JMP T114B
 1672 4472 JMS I NERROR /CHECK NON=ERROR HANDLER
 1673 4473 T114A, JMS I ERROR /ERROR! COUNTER FAILED
 1674 4114 4114 /TST114 ERROR MESSAGE
 1675 1660 TST114 /SCOPE LOOP

/
/DOES COUNTER SURVIVE RANDOM PATTERN ?
/

1676 4459 TST115, JMS I RANDY /GET RANDOM NUMBER
 1677 4427 JMS I XIOTG /IOT 6133, CLAB
 1700 7340 CLA CLL CHA
 1701 4433 JMS I XIOTK /IOT 6137, CLCA
 1702 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1703 4472 JMS I NERROR /CHECK NON=ERROR HANDLER
 1704 4473 JMS I ERROR /ERROR! COUNTER FAILED
 1705 4115 4115 /TST115 ERROR MESSAGE
 1706 1676 TST115 /SCOPE LOOP

/
/YES? FOR NO INT, STOP

1707 7340 TST116, CLA CLL CHA /AC TO 7777

```

1710 4427 JMS I X107C /IOT 6130, CLAR
1711 3040 DCA REGA
1712 1147 YAD X0010
1713 1147 YAD X0600 /GET ENABLES
1714 4425 JMS I X107F /IOT 6132, CLOE
1715 4447 JMS I X1000 /GO TO P1, NO P1 EXPECTED
1716 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1717 4473 JMS I ERROR /ERROR: INT, HOST, FAILED
1720 1116 1110 /TST110, ERROR MESSAGE
1721 1727 YS110 /SCOPE LOOP
/
/DOES CLSK SKIP ON CLOE OVERFLOW?
/SKIP EXPECTED, MODE 0, RATE 6
/
1722 7340 YST117, CLA CLL CMA /AC TO 7777
1723 4427 JMS I X107C /IOT 6133, CLAR
1724 7300 CLA CLL /CLEAR THE AD AND LINK
1725 1147 YAD X0600 /GET RATE 6
1726 4425 JMS I X107F /IOT 6132, CLOE
1727 4426 JMS I X107E /IOT 6131, CLSK
1730 7410 SKP
1731 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1732 4473 JMS I ERROR /ERROR: CLSK OR OVERFLOW FAILED
1733 0517 0517 /YST117 ERROR MESSAGE
1734 1722 YST117 /SCOPE LOOP
/
/DOES OVERFLOW REMAIN SET ?
/
1735 7340 YST120, CLA CLL CMA
1736 4427 JMS I X107C /IOT 6133, CLAR
1737 3040 DCA REGA
1740 1147 YAD X0600 /GET ENABLES
1741 4425 JMS I X107F /IOT 6132, CLOE
1742 4424 JMS I X107E /IOT 6131, CLSK
1743 5351 JMP I20A
1744 2041 ISE REGA
1745 5344 JMP ,+1 /WAIT ABOUT 10 MS
1746 4424 JMS I X107E /IOT 6131, CLSK
1747 7410 SKP
1750 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1751 4473 *I20A, JMS I ERROR /ERROR: CLSK OR OVERFLOW FAILED
1752 0520 0520 /YST120 ERROR MESSAGE
1753 1735 YST120 /SCOPE LOOP
/
/DOES CAF CLEAR THAT FLAG ?
/
1754 7340 YST121, CLA CLL CMA
1755 4427 JMS I X107C /IOT 6133, CLAR
1756 3040 DCA REGA
1757 1147 YAD X0600 /GET ENABLES
1760 4425 JMS I X107F /IOT 6132, CLOE
1761 4424 JMS I X107E /IOT 6131, CLSK
1762 5361 JMP ,+1
1763 6007 6007 /CAF OR CLEAR THE WORLD
1764 4424 JMS I X107E /IOT 6131, CLSK

```

```

1765 4472          JMS I NERROR /CHECK NON=ERROR HANDLER
1766 4473 T121A, JMS I ERROR /ERROR! CAP OR OVERFLOW FAILED
1767 0121          0121 /TST121 ERROR MESSAGE
1770 1754          TST121 /SCOPE LOOP

```

```

/
/DOES CLSK SKIP ON OVERFLOW ?
/SKIP EXPECTED, RATE 2-6, MODE 0
/

```

```

1771 1131 TST122, TAD K7773
1772 3041          DCA REGB
1773 1015          TAD K0200
1774 3044          DCA REGE
1775 7340 T122B, CLA CLL CMA /AC TO 7777
1776 4427          JMS I XIOTG /IOT 6133, CLAB
1777 3040          DCA REGA
2000 1044          TAD REGE /GET ENABLES
2001 4425          JMS I XIOTF /IOT 6132, CLOE
2002 2043          ISZ REGD
2003 5202          JMP ,~1 /WAIT
2004 4424          JMS I XIOTE /IOT 6131, CLSK
2005 5214          JMP T122A /NO OVERFLOW FOUND
2006 1013          TAD K0100
2007 3044          DCA REGE /UPDATE CLOCK RATE
2010 6007          6007 /CAP OR CLEAR THE WORLD
2011 2041          ISZ REGB
2012 5571          JMP I XCRS1
2013 4472          JMS I NERROR /CHECK NON=ERROR HANDLER
2014 4473 T122A, JMS I ERROR /ERROR! CLSK OR OVERFLOW FAILED
2015 0522          0522 /TST122 ERROR MESSAGE
2016 1771          TST122 /SCOPE LOOP

```

```

/
/DOES CLSK SKIP ON OVERFLOW ?
/SKIP EXPECTED, RATE 2-6, MODE 1
/

```

```

2017 1131 TST123, TAD K7773
2020 3041          DCA REGB
2021 1144          TAD K1000
2022 1015          TAD K0200
2023 3044          DCA REGE
2024 7340 T123B, CLA CLL CMA /AC TO 7777
2025 4427          JMS I XIOTG /IOT 6133, CLAB
2026 3040          DCA REGA
2027 1044          TAD REGE /GET ENABLES
2030 4420          JMS I XIOTF /IOT 6132, CLOE
2031 2043          ISZ REGD
2032 5201          JMP ,~1 /WAIT
2033 4420          JMS I XIOTE /IOT 6131, CLSK
2034 5240          JMP T123A /NO OVERFLOW FOUND
2035 1010          TAD K0100
2036 3044          DCA REGE /UPDATE CLOCK RATE
2037 6007          6007 /CAP OR CLEAR THE WORLD
2040 2041          ISZ REGB
2041 5220          JMP T123B /DD RATES 2-6
2042 4472          JMS I NERROR /CHECK NON=ERROR HANDLER
2043 4473 T123A, JMS I ERROR /ERROR! CLSK OR OVERFLOW FAILED

```

```

/
/AL 10  3140  27*JUL-79  15:00  PAGE 14
      2044 0523          0523          /TST123 ERROR MESSAGE
      2045 2017          TST123          /SCOPE LOOP
/
/DOES CLSK SKIP ON OVERFLOW ?
/SKIP EXPECTED; MODE 2; RATE 2-6
/
2046 1131  TST124, TAD K7773
2047 3041          DCA REGB
2050 1140          TAD K2000
2051 1015          TAD K0200          /MAKE ENABLES
2052 3044          DCA REGB
2053 7340  T124B,  CLA CLL CHA
2054 4427          JMS I X1070          /IOT 6133; CLAS
2055 3040          DCA REGB
2056 1044          TAD REGB          /GET ENABLES
2057 4420          JMS I X107F          /IOT 6132; CLOS
2060 2043          ISB REGB
2061 5040          JMP ,*1          /WAIT ABOUT 15 MS
2062 4024          JMS I X107E          /IOT 6131; CLSK
2063 5072          JMP T125A
2064 1013          TAD K0100          /UPDATE RATE
2065 3044          DCA REGB
2066 6007          6007          /CAN OR CLEAR THE WORLD
2067 2041          ISB REGB
2070 5053          JMP T124B          /DO RATES 2-6
2071 4472          JMS I NERR00          /CHECK NON-ERROR HANDLER
2072 4473  T124A,  JMS I ERR00          /ERROR! CLSK OR OVERFLOW FAILED
2073 0524          0524          /TST124 ERROR MESSAGE
2074 2046          TST124          /SCOPE LOOP
/
/DOES CLSK SKIP ON OVERFLOW ?
/SKIP EXPECTED; RATE 2-6; MODE 3
/
2075 1131  TST125, TAD K7773
2076 3041          DCA REGB
2077 1120          TAD K3000
2100 1015          TAD K0200          /MAKE ENABLES
2101 3044          DCA REGB          /SAVE ENABLES
2102 7340  T125B,  CLA CLL CHA
2103 4427          JMS I X1070          /IOT 6133; CLAS
2104 3040          DCA REGB
2105 1044          TAD REGB          /GET ENABLES
2106 4420          JMS I X107F          /IOT 6132; CLOS
2107 2043          ISB REGB
2110 5307          JMP ,*1          /WAIT ABOUT 15 MS
2111 4424          JMS I X107E          /IOT 6131; CLSK
2112 5320          JMP T125A
2113 1013          TAD K0100          /UPDATE RATE
2114 3044          DCA REGB
2115 2041          ISB REGB
2116 5302          JMP T125B          /DO RATES 2-6
2117 4472          JMS I NERR00          /CHECK NON-ERROR HANDLER
2120 4473  T125A,  JMS I ERR00          /ERROR! CLSK OR OVERFLOW FAILED
2121 0525          0525          /TST125 ERROR MESSAGE
2122 2075          TST125          /SCOPE LOOP

```

```

/
/DOES CLSK SKIP ON OVERFLOW ?
/NO SKIP EXPECTED, RATE 0=7, MODE 0, DISABLE BIT ?
/
2123 1122 TST126, TAD K7770
2124 3043 DCA REGD
2125 7340 T126B, CLA CLL CHA /TAD TO 7777
2126 4427 JMS I X1070 /IOT 6133, CLAR
2127 3040 DCA REGA
2130 1140 TAD K0020
2131 1041 TAD REGB /GET ENABLER
2132 4425 JMS I X107F /IOT 6132, CLOE
2133 2042 ISZ REGC
2134 5333 JMP ,=1 /WAIT
2135 4424 JMS I X107E /IOT 6131, CLSK
2136 7410 SKP
2137 5347 JMP T126A /OVERFLOW FOUND
2140 0150 AND K0700 /MASK BITS 3-5
2141 1013 TAD K0100
2142 3041 DCA REGB /UPDATE RATE
2143 6007 6007 /CAP OR CLEAR THE WORLD
2144 2043 ISZ REGD
2145 5325 JMP T126B /DO RATES 0=7
2146 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2147 4473 T126A, JMS I ERROR /ERROR! CLSK OR OVERFLOW FAILED
2150 0126 0126 /TST126 ERROR MESSAGE
2151 2123 TST126 /SCOPE LOOP

```

```

/
/DOES CLSK SKIP ON OVERFLOW ?
/NO SKIP EXPECTED, RATE 0,1,7 MODE 0
/
2152 7340 TST127, CLA CLL CHA
2153 4427 JMS I X1070 /IOT 6133, CLAR
2154 3040 DCA REGA
2155 4425 JMS I X107F /IOT 6132, CLOE
2156 2041 ISZ REGB
2157 5356 JMP ,=1 /WAIT ABOUT 15 MS
2160 4424 JMS I X107E /IOT 6131, CLSK
2161 7410 SKP
2162 5572 JMP I XCRS2
2163 1013 TAD K0100 /UPDATE ENABLE
2164 4426 JMS I X107F1 /IOT 6132, CLOE
2165 2042 ISZ REGC
2166 5365 JMP ,=1 /WAIT ABOUT 15 MS
2167 4424 JMS I X107E /IOT 6131, CLSK
2170 7410 SKP
2171 5572 JMP I XCRS2
2172 1147 TAD K0600 /UPDATE ENABLE
2173 4426 JMS I X107F1 /IOT 6132, CLOE
2174 2043 ISZ REGD
2175 5374 JMP ,=1 /WAIT ABOUT 15 MS
2176 4424 JMS I X107E /IOT 6131, CLSK
2177 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2180 4473 T127A, JMS I ERROR /ERROR! CLSK OR OVERFLOW FAILED
2181 0127 0127 /TST127 ERROR MESSAGE

```

```

PAL10  YC#1  27-JUL-71  17:48  PAGE 1-4
2202  2152          YST127          /SCOPE LOOP
/
/DOES CLSA READ OVERFLOW BIT ?
/
2203  7340  YST130, CLA CLL CMA
2204  4427          JMS I XIDTC          /IOT 6132, CLOS
2205  7300          CLA CLL CML RAR /AC TO 4000
2206  3070          OCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
2207  7313          CLA CLL IAC RFR /AC TO 4000
2210  1147          YAO K0000          /GET ENABLE
2211  4426          JMS I XIDTC1
2212  4424          JMS I XIDTC          /IOT 6131, CLSK
2213  5212          JMP ,=1
2214  7350          CLA CLL CMA RAR /AC TO 3777
2215  4431          JMS I XIDTC1 /IOT 6135, CLSA
2216  4450          JMS I XSNDRY /CHECK SEND AND RECV REGISTERS
2217  4472          JMS I NERROR /CHECK NON-ERROR HANDLER
2220  4473  T130a, JMS I ERROR /ERROR! CLSI OR OVERFLOW FAILED
2221  5130          S130          /YST130 ERROR MESSAGE
2222  2223          YST130          /SCOPE LOOP
/
/DOES CLSA CLEAR OVERFLOW FLOW ?
/
2223  7340  YST131, CLA CLL CMA          /AC TO 7777
2224  4427          JMS I XIDTC          /IOT 6133, CLAB
2225  7313          CLA CLL IAC RFR /AC TO 4000
2226  1147          YAO K0000          /GET ENABLE
2227  4426          JMS I XIDTC1          /IOT 6132, CLOS
2230  4424          JMS I XIDTC          /IOT 6131, CLSK
2231  5230          JMP ,=1
2232  7350          CLA CLL CMA RAR /AC TO 3777
2233  4431          JMS I XIDTC1 /IOT 6135, CLSA
2234  7300          CLA CLL          /CLEAR AC AND LINK
2235  3070          OCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
2236  7340          CLA CLL CMA          /AC TO 7777
2237  4431          JMS I XIDTC1 /IOT 6135, CLSA
2240  7650          SNA CLA          /HAS STATUS REGISTER ALL 0'S ?
2241  4472          JMS I NERROR /CHECK NON-ERROR HANDLER
2242  4473          JMS I ERROR /ERROR! CLSA OR OVERFLOW FAILED
2243  5131          S131          /YST131 ERROR MESSAGE
2244  2223          TCT131          /SCOPE LOOP
/
/DOES CLSA READ OVERFLOW BIT ?
/
2245  7340  YST132, CLA CLL CMA
2246  4427          JMS I XIDTC          /IOT 6133, CLAB
2247  7300          CLA CLL
2250  3070          OCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
2251  1147          YAO K0000          /GET ENABLES
2252  4426          JMS I XIDTC1          /IOT 6132, CLOS
2253  4424          JMS I XIDTC          /IOT 6131, CLSK
2254  5253          JMP ,=1
2255  7344          CLA CLL CMA RAR /AC TO 3777
2256  4431          JMS I XIDTC1 /IOT 6135, CLSA
2257  7650          SNA CLA          /HAS STATUS 0 ?

```

2260	4472	JMS I NERROR	/CHECK NON-ERROR HANDLER
2261	4473	JMS I ERROR	/ERROR! CLSA OR STATUS FAILED
2262	5132	5132	/TST132 ERROR MESSAGE
2263	2245	TST132	/SCOPE LOOP

/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 1, RATE 2
/

2264	7340	TST133, CLA CLL CMA	
2265	4427	JMS I XIOTG	/IOT 6133, CLAB
2266	3040	DCA REGA	
2267	7313	CLA CLL IAC RTH	/AC TO 4000
2270	1116	TAD K0400	
2271	1144	TAD K1000	/GET ENABLES
2272	4426	JMS I XIOTF1	/IOT 6132, CLOE
2273	4424	Y133B, JMS I XIOTE	/IOT 6131, CLSK
2274	5273	JMP ,=1	/WAIT FOR FLAG
2275	7300	CLA CLL	/CLEAR THE AC AND LINK
2276	4433	JMS I XIOTK	/IOT 6137, CLCA
2277	7040	CMA	/FOR TESTING
2300	7440	SZA	/HAS COUNTER ALL 1'S ?
2301	5306	JMP T133A	
2302	4431	JMS I XIOTI	/IOT 6135, CLSA
2303	2041	ISZ REGB	
2304	5273	JMP T133B	/DO TEST 4096 TIMES
2305	4472	JMS I NERROR	/CHECK NON-ERROR HANDLER
2306	4473	T133A, JMS I ERROR	/ERROR! COUNTER FAILED
2307	4133	4133	/TST133 ERROR MESSAGE
2310	2264	TST133	/SCOPE LOOP

/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 1, RATE 4
/

2311	1017	TST134, TAD K5252	/GET AC NUMBER
2312	4427	JMS I XIOTG	/IOT 6133, CLAB
2313	7340	CLA CLL CMA	/AC TO 7777
2314	3040	DCA REGA	
2315	1144	TAD K1000	
2316	1116	TAD K0400	/GET ENABLES
2317	4426	JMS I XIOTF1	/IOT 6132, CLOE
2320	4424	JMS I XIOTE	/IOT 6131, CLSK
2321	5326	JMP ,=1	/WAIT FOR FLAG
2322	7340	CLA CLL CMA	/AC TO 7777
2323	4433	JMS I XIOTK	/IOT 6137, CLCA
2324	4456	JMS I XSNOP	/CHECK SEND AND RECEV REGIST.
2325	4472	JMS I NERROR	/CHECK NON-ERROR HANDLER
2326	4473	JMS I ERROR	/ERROR! COUNTER FAILED
2327	4134	4134	/TST134 ERROR MESSAGE
2330	2311	TST134	/SCOPE LOOP

/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 1, RATE 4
/

2331	1016	TST134, TAD K5252	/GET AC NUMBER
2332	4427	JMS I XIOTG	/IOT 6133, CLAB


```

/
      PAL10  V101  17-JUL-78  11:41  PAGE 1-6

2333  7340          CLA CLL CMA          JAC TO 7777
2334  3040          DCA RECA
2335  1144          TAD K1000
2336  1116          TAD K0400          /GET ENABLES
2337  4426          JMS I X1070          /IOT 6132, CL0E
2338  4424          JMS I X107E          /IOT 6131, CL0A
2341  5376          JMP ,+1          /WAIT FOR OVERFLOW
2342  4433          JMS I X107K          /IOT 6137, CL0A
2343  4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
2344  4473          JMS I ERROR          /ERROR! COUNTER FAILED
2346  4136          4136          /TEST100 ERROR MESSAGE
2367  2351          TST155          /SCOPE LOOP

/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 1, RATE 2
/
2348  7340          TST146, CLA CLL CMA          JAC TO 7777
2351  4427          JMS I X107S          /IOT 6123, CL0A
2352  3040          DCA RECA
2353  3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
2354  1116          TAD K0400
2355  1143          TAD K0300          /GET ENABLES
2356  4426          JMS I X107FL          /IOT 6132, CL0E
2357  4424          JMS I X107E          /IOT 6131, CL0A
2360  5357          JMP ,+1          /WAIT FOR FL0C
2361  4433          JMS I X107A          /IOT 6137, CL0A
2362  7050          SNA CLA          /HAS COUNTER ALL 0'S ?
2363  4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
2364  4473          JMS I ERROR          /ERROR! COUNTER FAILED
2365  4136          4136          /TEST130 ERROR MESSAGE
2366  2350          TST130          /SCOPE LOOP

/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 3, RATE 4
/
2367  7340          TST137, CLA CLL CMA
2370  4427          JMS I X107G          /IOT 6133, CL0A
2371  3040          DCA RECA
2372  3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
2373  1116          TAD K0400
2374  1120          TAD K3000          /GET ENABLES
2375  4426          JMS I X107FL          /IOT 6132, CL0E
2376  4424          JMS I X107E          /IOT 6131, CL0A
2377  5376          JMP ,+1          /WAIT FOR OVERFLOW
2400  7340          CLA CLL CMA
2401  4433          JMS I X107K          /IOT 6137, CL0A
2402  7050          SNA CLA          /HAS COUNTER ALL 0'S ?
2403  4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
2404  4473          JMS I ERROR          /ERROR! COUNTER FAILED
2405  4137          4137          /TEST137 ERROR MESSAGE
2406  2367          TST137          /SCOPE LOOP

/
/DOES INT, WITHOUT BIT 6 ?
/

```

```

2407 7340 X TST140: CLA CLL CMA
2410 4427 JMS I X10Y6 /IOT 6133, CLAB
2411 3040 DCA REGA
2412 7313 CLA CLL IAC RTR /AC TO 4000
2413 1007 TAD K0007
2414 1147 TAD K0600 /GET ENABLES
2415 4425 JMS I X10YF /IOT 6132, CLOE
2416 4447 JMS I XPIG01 /GO TO P1, NO P1 EXPECTED
2417 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2420 4473 JMS I ERROR /ERROR! INT, RQST, OR ENA 0 FAILED
2421 1140 1140 /TST140 ERROR MESSAGE
2422 2407 TST140 /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE INT, RQST, ?
/RATE 6, MODE 0
/

```

```

2423 7340 TST141: CLA CLL CMA /AC TO 7777
2424 4427 JMS I X10Y6 /IOT 6133, CLAB
2425 7300 CLA CLL /CLEAR THE AC AND LINK
2426 1014 TAD K0000
2427 1142 TAD K0010
2430 1147 TAD K0600 /GET RATE + MODE
2431 4425 JMS I X10YF /IOT 6132, CLOE
2432 4492 JMS I XPIG04 /GO TO P1, P1 EXPECTED
2433 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2434 4473 JMS I ERROR /ERROR! OVERFLOW OR ENA 0 FAILED
2435 1541 1541 /TST141 ERROR MESSAGE
2436 2423 TST141 /SCOPE LOOP

```

```

/
/DOES INT, RQST, WITHOUT ENA 0 ?
/RATE 6, MODE 0
/

```

```

2437 7340 X TST142: CLA CLL CMA /AC TO 7777
2440 4427 JMS I X10Y6 /IOT 6133, CLAB
2441 7300 CLA CLL /CLEAR THE AC AND LINK
2442 1142 TAD K0010
2443 1147 TAD K0600 /GET RATE + MODE
2444 4425 JMS I X10YF /IOT 6132, CLOE
2445 4451 JMS I XPIG03 /GO TO P1, NO P1 EXPECTED
2446 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2447 4473 JMS I ERROR /ERROR! ENA 0 FAILED
2450 1142 1142 /TST142 ERROR MESSAGE
2451 2437 TST142 /SCOPE LOOP

```

```

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 0
/

```

```

2452 7340 TST143: CLA CLL CMA /AC TO 7777
2453 3040 DCA REGA
2454 4427 JMS I X10Y6 /IOT 6133, CLAB
2455 1014 TAD K0000
2456 1142 TAD K0010
2457 1147 TAD K0600 /GET RATE + MODE
2460 4425 JMS I X10YF /IOT 6132, CLOE
2461 4450 JMS I XPIG02 /GO TO P1

```

```

2452 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
2463 4473      JMS I ERROR  /ERROR! OVERFLOW OR COUNTER FAILED
2464 1543      1543      /TST143 ERROR MESSAGE
2465 2452      TST143      /SCOPE LOOP

```

```

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 1
/

```

```

2466 7340      TST144, CLA CMA CLL      /AC TO 7777
2467 3040      DCA REGA
2470 4427      JMS I XIOTG      /IOT 6133, CLAB
2471 1121      TAD K5000
2472 1142      TAD K0010
2473 1147      TAD K0600      /GET RATE * MODE
2474 4425      JMS I XIOTF      /IOT 6132, CLOE
2475 4450      JMS I XPIG02      /GO TO PI
2476 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
2477 4473      JMS I ERROR  /ERROR! OVERFLOW OR COUNTER FAILED
2500 1544      1544      /TST144 ERROR MESSAGE
2501 2466      TST144      /SCOPE LOOP

```

```

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 2
/

```

```

2502 7340      TST145, CLA CLL CMA      /AC TO 7777
2503 3040      DCA REGA
2504 4427      JMS I XIOTG      /IOT 6133, CLAB
2505 1117      TAD K0000
2506 1142      TAD K0010
2507 1147      TAD K0600      /GET ENABLER
2510 4425      JMS I XIOTF      /IOT 6132, CLOE
2511 4450      JMS I XPIG02      /GO TO PI, PI EXPECTED
2512 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
2513 4473      JMS I ERROR  /ERROR! OVERFLOW OR COUNTER FAILED
2514 1545      1545      /TST145 ERROR MESSAGE
2515 2502      TST145      /SCOPE LOOP

```

```

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 3
/

```

```

2516 7340      TST146, CLA CLL CMA      /AC TO 7777
2517 3040      DCA REGA
2520 4427      JMS I XIOTG      /IOT 6133, CLAB
2521 1141      TAD K7000
2522 1142      TAD K0010
2523 1147      TAD K0600      /GET ENABLER
2524 4425      JMS I XIOTF      /IOT 6132, CLOE
2525 4450      JMS I XPIG02      /GO TO PI, PI EXPECTED
2526 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
2527 4473      JMS I ERROR  /ERROR! COUNTER OR MODE 3 FAILED
2530 1546      1546      /TST146 ERROR MESSAGE
2531 2516      TST146      /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE RQST. ?
/RATE 2-6, MODE 0

```

```

2532 1131 TST147, YAD K7773
2533 3041 DCA REGB
2534 1014 YAD K4000
2535 1142 YAD K0010
2536 1015 YAD K0200
2537 3044 T147B, DCA REGE /SET UP ENABLES
2540 7340 CLA CLL CMA /AC TO 7777
2541 4427 JMS I XIOTB /IOT 6133, CLAB
2542 3040 DCA REGA
2543 1044 YAD REGE /GET ENABLES
2544 4425 JMS I XIOTF /IOT 6132, CLOC
2545 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
2546 5355 JMP T147A
2547 6007 /CAF OR CLEAR THE WORLD
2550 1013 YAD K0100
2551 1044 YAD REGE
2552 2041 ISZ REGB
2553 5337 JMP T147B /DO RATES 2-6
2554 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2555 4473 T147A, JMS I ERROR /ERROR! OVERFLOW OR MODE FAILED
2556 1547 1547 /TST147 ERROR MESSAGE
2557 2532 TST147 /SCOPE LOOP

```

```

/DOES OVERFLOW CAUSE ROST, ?
/RATE 2-6, MODE 1
/

```

```

2560 1131 TST150, YAD K7773
2561 3041 DCA REGB
2562 1121 YAD K5000
2563 1142 YAD K0010
2564 1015 YAD K0200 /MAKE ENABLES
2565 3044 T150B, DCA REGE
2566 7340 CLA CLL CMA /AC TO 7777
2567 4427 JMS I XIOTC /IOT 6133, CLAB
2570 3040 DCA REGA
2571 1044 YAD REGE /GET ENABLES
2572 4425 JMS I XIOTF /IOT 6132, CLOC
2573 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
2574 5573 JMP I XCRS3
2575 6007 /CAF OR CLEAR THE WORLD
2576 1013 YAD K0100
2577 1044 YAD REGE
2600 2041 ISZ REGB
2601 5574 JMP I XCRS4
2602 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2603 4473 T150A, JMS I ERROR /ERROR! OVERFLOW OR MODE FAILED
2604 1550 1550 /TST150 ERROR MESSAGE
2605 2560 TST150 /SCOPE LOOP

```

```

/DOES OVERFLOW CAUSE ROST, ?
/RATE 2-6, MODE 2
/

```

```

2606 1131 TST151, YAD K7773
2607 3041 DCA REGB

```

```

2610 1117 TAD K0000
2611 1142 TAD K0010
2612 1015 TAD K0200
2613 3044 T151B, DCA REGE /MAKE ENABLES
2614 7340 CLA CLL CMA /AC TO 7777
2615 4427 JMS I XIOTG /IOT 6133, CLAB
2616 3040 DCA REGA
2617 1044 TAD REGE /GET ENABLES
2620 4425 JMS I XIOTF /IOT 6132, CLCE
2621 4447 JMS I XPI001 /GO TO PI, PI EXPECTED
2622 5231 JMP T151A
2623 6007 6007 /CAF OR CLEAR THE WORLD
2624 1013 TAD K0100
2625 1044 TAD REGE
2626 2041 ISZ REGB
2627 5210 JMP T151B
2630 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2631 4473 T151A, JMS I ERROR /ERROR! OVERFLOW OR MODE FAILED
2632 1551 1551 /TST151 ERROR MESSAGE
2633 2606 TST151 /SCOPE LOOP

```

/
/DOES OVERFLOW CAUSE ROST, ?
/RATE 2-6, MODE 3
/

```

2634 1131 TST152, TAD K7773
2635 3041 DCA REGB
2636 1141 TAD K7000
2637 1142 TAD K0010
2640 1015 TAD K0200 /MAKE ENABLES
2641 3044 T152B, DCA REGE
2642 7340 CLA CLL CMA /AC TO 7777
2643 4427 JMS I XIOTG /IOT 6133, CLAB
2644 3040 DCA REGA
2645 1044 TAD REGE /GET ENABLES
2646 4425 JMS I XIOTF /IOT 6132, CLCE
2647 4447 JMS I XPI001 /GO TO PI, PI EXPECTED
2650 5257 JMP T152A
2651 6007 6007 /CAF OR CLEAR THE WORLD
2652 1013 TAD K0100
2653 1044 TAD REGE
2654 2041 ISZ REGB
2655 5241 JMP T152B /GO RATES 2-6
2656 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2657 4473 T152A, JMS I ERROR /ERROR! OVERFLOW OR MODE FAILED
2660 1552 1552 /TST152 ERROR MESSAGE
2661 2634 TST152 /SCOPE LOOP

```

/
/DOES OVERFLOW CAUSE ROST, ?
/RATE 0-7, MODE 1, DISABLE BIT 7
/

```

2662 1122 X TST153, TAD K7770
2663 3041 DCA REGB
2664 1121 TAD K5000
2665 1142 TAD K0010
2666 1140 TAD K0020

```

```

2667 3044 T153B, DCA REGE /MAKE ENABLES
2670 7340 CLA CLL CMA /AC TO 7777
2671 4427 JMS I XIOTG /IOT 6133, CLAB
2672 3040 DCA REGA
2673 1044 TAD REGE /GET ENABLES
2674 4425 JMS I XIOTF /IOT 6132, CLOE
2675 4450 JMS I XPIG02 /GO TO PI, NO PI EXPECTED
2676 5305 JMP T153A
2677 6007 /CAF OR CLEAR THE WORLD
2700 1013 TAD K0100
2701 1044 TAD REGE
2702 2041 ISZ REGB
2703 5267 JMP T153B /DO RATE 0=7
2704 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2705 4473 T153A, JMS I ERROR /ERROR! OVERFLOW OR CLK ENA FAILED
2706 1153 1153 /TST153 ERROR MESSAGE
2707 2662 TST153 /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE ROST, ?
/RATE 0=7, MODE 2, DISABLE INT, ROST, BIT
/

```

```

X
2710 1122 TST154, TAD K7770
2711 3041 DCA REGB
2712 1117 TAD K0000
2713 1142 TAD K0010
2714 1140 TAD K0020
2715 3044 T154B, DCA REGE /MAKE ENABLES
2716 7340 CLA CLL CMA /AC TO 7777
2717 4427 JMS I XIOTG /IOT 6133, CLAB
2720 3040 DCA REGA
2721 1044 TAD REGE /GET ENABLES
2722 4425 JMS I XIOTF /IOT 6132, CLOE
2723 4450 JMS I XPIG02 /GO TO PI, NO PI EXPECTED
2724 5353 JMP T154A
2725 6007 /CAF OR CLEAR THE WORLD
2726 1013 TAD K0100
2727 1044 TAD REGE
2730 2041 ISZ REGB
2731 5315 JMP T154B /DO RATE 0=7
2732 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2733 4473 T154A, JMS I ERROR /ERROR! OVERFLOW OR CLK ENA FAILED
2734 1154 1154 /TST154 ERROR MESSAGE
2735 2710 TST154 /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE INT, ROST, ?
/MODE 0, RATE 6
/

```

```

2736 7340 TST155, CLA CLL CMA /AC TO 7777
2737 4427 JMS I XIOTG /IOT 6133, CLAB
2740 7330 CLA CLL CMA /AC TO 4000
2741 1147 TAD K0000
2742 1142 TAD K0010 /GET ENABLES
2743 4425 JMS I XIOTF /IOT 6132, CLOE
2744 4452 JMS I XPIG04 /GO TO PI, PI EXPECTED
2745 4472 JMS I NERROR /CHECK NON-ERROR HANDLER

```

2746 4473 JMS I ERROR /ERROR: OVERFLOW OR COUNTER FAILED
2747 1555 1555 /TST155 ERROR MESSAGE
2750 2736 TST155 /SCOPE LOOP

/
/DOES CLK SKIP THEN INTERRUPT ?
/RATE 6, MODE 0
/

2751 7340 TST156, CLA CLL CMA /AC TO 7777
2752 4427 JMS I XIOT6 /IOT 6133, CLAB
2753 7330 CLA CLL CML RAR
2754 1142 TAD K0010
2755 1147 TAD K0000 /MAKE ENABLES
2756 4425 JMS I XIOTF /IOT 6132, CLOE
2757 4424 JMS I XIOTE /IOT 6131, CLSK
2760 5357 JMP ,=1 /WAIT FOR OVERFLOW
2761 4452 JMS I XPIG04 /GO TO PI, PI EXPECTED
2762 4472 JMS I NERRGR /CHECK NON-ERROR HANDLER
2763 4473 JMS I ERROR /ERROR: CLK OR PI FAILED
2764 1556 1556 /TST156 ERROR MESSAGE
2765 2751 TST156 /SCOPE LOOP

/
/CHECK FOR NO INT, ROST,
/MODE 0, RATE 6, DISABLE WITH CLSA
/

2766 7340 * TST157, CLA CLL CMA /AC TO 7777
2767 4427 JMS I XIOT6 /IOT 6133, CLAB
2770 7330 CLA CLL CML RAR /AC TO 4000
2771 1147 TAD K0000
2772 1142 TAD K0010
2773 4425 JMS I XIOTF /IOT 6132, CLOE
2774 4424 JMS I XIOTE /IOT 6131, CLSK
2775 5374 JMP ,=1 /WAIT FOR OVERFLOW
2776 4431 JMS I XIOTI /IOT 6130, CLSA
2777 4451 JMS I XPIG03 /GO TO PI, NO PI EXPECTED
3000 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3001 4473 JMS I ERROR /ERROR: INT, ROST, FAILED
3002 1157 1157 /TST157 ERROR MESSAGE
3003 2766 TST157 /SCOPE LOOP

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 2, MODE 0
/

3004 7340 * TST160, CLA CLL CMA /AC TO 7777
3005 3040 OCA REGA
3006 1151 TAD KYA
3007 3076 OCA KREGC
3010 4427 JMS I XIOT6 /IOT 6133, CLAB
3011 1014 TAD K4000
3012 1142 TAD K0010
3013 1015 TAD K0200 /MAKE ENABLES
3014 4425 JMS I XIOTF /IOT 6132, CLOE
3015 4453 JMS I XPIG05
3016 7610 SKP CLA
3017 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3020 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY FAST

3021 2160 2160 /TST160 ERROR MESSAGE
3022 3024 TST160 /SCOPE LOOP

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 2, MODE 0

3023 7340 TST161, CLA CLL CMA /AC TO 7777
3024 3040 DCA REGA
3025 1152 TAD KTA1
3026 3076 DCA KREGC
3027 4427 JMS I XIOTG /IOT 6133, CLAB
3030 1014 TAD K4000
3031 1142 TAD K0010
3032 1015 TAD K0200 /MAKE ENABLES
3033 4425 JMS I XIOTF /IOT 6132, CLOE
3034 4453 JMS I XPIG05
3035 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3036 4473 JMS I ERROR /ERROR! CLOCK FREQUENCY SLOW
3037 2561 2561 /TST161 ERROR MESSAGE
3040 3023 TST161 /SCOPE LOOP

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 3, MODE 0

3041 7340 X TST162, CLA CLL CMA /AC TO 7777
3042 3040 DCA REGA
3043 1153 TAD KTB
3044 3076 DCA KREGC
3045 4427 JMS I XIOTG /IOT 6133, CLAB
3046 1014 TAD K4000
3047 1142 TAD K0010
3050 1145 TAD K0300 /MAKE ENABLES
3051 4425 JMS I XIOTF /IOT 6132, CLOE
3052 4453 JMS I XPIG05
3053 7610 SKP CLA
3054 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3055 4473 JMS I ERROR /ERROR! CLOCK FREQUENCY FAST
3056 2162 2162 /TST162 ERROR MESSAGE
3057 3041 TST162 /SCOPE LOOP

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 3, MODE 0

3060 7340 TST163, CLA CLL CMA /AC TO 7777
3061 3040 DCA REGA
3062 1154 TAD KTB1
3063 3076 DCA KREGC
3064 4427 JMS I XIOTG /IOT 6133, CLAB
3065 1014 TAD K4000
3066 1142 TAD K0010
3067 1145 TAD K0300 /MAKE ENABLES
3070 4425 JMS I XIOTF /IOT 6132, CLOE
3071 4453 JMS I XPIG05
3072 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3073 4473 JMS I ERROR /ERROR! CLOCK FREQUENCY SLOW

3074 2563 2543 /TST163 ERROR MESSAGE
 3075 3068 TST163 /SCOPE LOOP

/DOES CLOCK FREQUENCY TIME OUT ?
 /RATE 4, MODE 0

3076 9340 * TST164, CLA CLL CMA /AC TO 7777
 3077 3040 DCA REGA
 3100 1153 TAD KYC
 3101 3076 DCA KREGC
 3102 1154 TAD KTC1
 3103 3043 DCA REGD /SET TIMER FOR 10000 CPS CLOCK
 3104 4427 JMS I XIOTG /IOT 6133, CLAB
 3105 1014 TAD K4000
 3106 1142 TAD K0010
 3107 1116 TAD K0400 /MAKE ENABLES
 3110 4425 JMS I XIOTF /IOT 6132, CLOC
 3111 4453 JMS I XP1005
 3112 7610 SKN CLA
 3113 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 3114 4473 JMS I ERROR /ERROR! CLOCK FREQUENCY FAST
 3115 2144 2144 /TST164 ERROR MESSAGE
 3116 3076 TST164 /SCOPE LOOP

/DOES CLOCK FREQUENCY TIME OUT ?
 /RATE 4, MODE 0

3117 9340 TST165, CLA CLL CMA /AC TO 7777
 3120 3040 DCA REGA
 3121 1153 TAD KYC
 3122 3076 DCA KREGC
 3123 1157 TAD KTC2
 3124 3043 DCA REGD /SET TIMER FOR 10000 CLOCK
 3125 4427 JMS I XIOTG /IOT 6133, CLAB
 3126 1014 TAD K4000
 3127 1142 TAD K0010
 3130 1116 TAD K0400 /MAKE ENABLES
 3131 4425 JMS I XIOTF /IOT 6132, CLOC
 3132 4453 JMS I XP1005
 3133 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 3134 4473 JMS I ERROR /ERROR! CLOCK FREQUENCY SLOW
 3135 2565 2565 /TST165 ERROR MESSAGE
 3136 3117 TST165 /SCOPE LOOP

/DOES CLOCK FREQUENCY TIME OUT ?
 /RATE 5, MODE 0

3137 9340 * TST166, CLA CLL CMA /AC TO 7777
 3140 3040 DCA REGA
 3141 7350 CLA CLL CMA RAR
 3142 4427 JMS I XIOTG /IOT 6133, CLAB
 3143 7320 CLA CLL /CLEAR THE AC AND LINK
 3144 1160 TAD KTD
 3145 3043 DCA REGD /SET TIMER FOR 10000 CPS CLOCK
 3146 1014 TAD K4000

```

3147 1142 TAD K0010
3150 1146 TAD K0000 /MAKE ENABLES
3151 4425 JMS I X107F /IOT 6132, CLOS
3152 4447 JMS I XPI001
3153 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3154 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY FAST
3155 2166 TST166 /TST166 ERROR MESSAGE
3156 3137 TST166 /SCOPE LOOP

```

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 5, MODE 0

```

/
TST167, CLA CLL CMA /AC TO 7777
3160 3040 DCA RECA
3161 7350 CLA CLL CMA RAR
3162 4427 JMS I X107B /IOT 6133, CLAB
3163 7300 CLA CLL /CLEAR THE AC AND LINK
3164 1161 TAD KTD1
3165 3043 DCA RECD /SET TIMER FOR 100000 OPS CLOCK
3166 1014 TAD K4000
3167 1142 TAD K0010
3170 1146 TAD K0000 /MAKE ENABLES
3171 4425 JMS I X107F /IOT 6132, CLOS
3172 4450 JMS I XPI002
3173 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3174 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY SLOW
3175 2567 TST167 /TST167 ERROR MESSAGE
3176 3157 TST167 /SCOPE LOOP

```

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 6, MODE 0

```

/
TST170, CLA CLL CMA /AC TO 7777
3200 3040 DCA RECA
3201 1162 TAD KTE
3202 3043 DCA RECD /SET TIMER FOR 100000 OPS CLOCK
3203 4427 JMS I X107G /IOT 6133, CLAB
3204 1014 TAD K4000
3205 1142 TAD K0010
3206 1147 TAD K0400 /MAKE ENABLES
3207 4425 JMS I X107F /IOT 6132, CLOS
3210 4447 JMS I XPI003
3211 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3212 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY FAST
3213 2170 TST170 /TST170 ERROR MESSAGE
3214 3177 TST170 /SCOPE LOOP

```

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 6, MODE 0

```

/
TST171, CLA CLL CMA /AC TO 7777
3216 3040 DCA RECA
3217 1163 TAD KTE1
3219 3043 DCA RECD /SET TIMER FOR 100000 OPS CLOCK
3221 4427 JMS I X107H /IOT 6133, CLAB

```

```

3222 1804          TAO K400X
3223 1142          TAO K0010
3224 1147          TAO K0600          /MAKE ENABLES
3225 4425          JMS I X107F          /IOT 6132, CLOE
3226 4450          JMS I XP1002
3227 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
3230 4473          JMS I ERROR          /ERROR! CLOCK FREQUENCY SLOW
3231 2571          2571          /TST171 ERROR MESSAGE
3232 3215          TST171          /SCOPE LOOP

/
/DOES COUNTER REALLY COUNT ?
/RATE 2, MODE 0
/
3233 7340          TST172, CLA CLL CMA          /AO TO 7777
3234 4427          JMS I X107G          /IOT 6133, CLAB
3235 3040          DCA REGA
3236 1015          TAO K0200          /GET RATE * MODE
3237 4426          JMS I X107F1          /IOT 6132, CLOE
3240 7300          T172B1, CLA CLL          /CLEAR THE AC AND LINK
3241 3042          DCA REGC
3242 1041          TAO REGB
3243 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
3244 4433          T172B, JMS I X107K          /IOT 6137, CLCA
3245 7041          CIA
3246 1041          TAO REGB          /COMPARE TO THIS REGISTER
3247 7650          SNA CLA          /ARE THEY THE SAME YET ?
3250 5254          JMP T172A          /YES, TEST NEXT NUMBER
3251 2042          ISZ REGC
3252 5244          JMP T172B          /WAIT ABOUT 15 MS FOR REGISTER
3253 5257          JMP T172A1          /NUMBER NOT FOUND
3254 2041          T172A, ISZ REGB          /UPDATE COMPARE REGISTER
3255 5240          JMP T172B1          /TEST FOR NEXT COUNTER PULSE
3256 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
3257 4473          T172A1, JMS I ERROR          /ERROR! COUNTER FAILED
3260 4172          4172          /TST172 ERROR MESSAGE
3261 3233          TST172          /SCOPE LOOP

/
/DOES COUNTER REALLY COUNT ?
/RATE 3, MODE 0
/
3262 7340          TST173, CLA CLL CMA          /AO TO 7777
3263 4427          JMS I X107G          /IOT 6133, CLAB
3264 3040          DCA REGA
3265 1145          TAO K0300          /GET RATE * MODE
3266 4426          JMS I X107F1          /IOT 6132, CLOE
3267 7300          T173B1, CLA CLL          /CLEAR THE AC AND LINK
3270 3042          DCA REGC
3271 1041          TAO REGB
3272 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
3273 4433          T173B, JMS I X107K          /IOT 6137, CLCA
3274 7041          CIA
3275 1041          TAO REGB          /COMPARE TO THIS REGISTER
3276 7650          SNA CLA          /ARE THEY THE SAME YET ?
3277 5303          JMP T173A          /YES, TEST NEXT NUMBER
3300 2042          ISZ REGC

```

```

3301 5273      JMP T1738      /WAIT ABOUT 15 MS FOR REGISTER
3302 5326      JMP T173A1     /NUMBER NOT FOUND
3303 2041      T173A:  ISE REGB /UPDATE COMPARE REGISTER
3304 5267      JMP T173B1     /TEST FOR NEXT COUNTER PULSE
3305 4472      JMS I NERROR  /CHECK NON-ERROR HANDLER
3306 4473      T173A1, JMS I ERROR /ERROR! COUNTER FAILED
3307 4173      4173         /TST173 ERROR MESSAGE
3310 3262      TST173       /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 2, MODE 1

```

3311 7340      TST174, CLA CLL CMA /AC TO 7777
3312 4427      JMS I XIOTG   /IOT 6133, CLAB
3313 3040      DCA REGA
3314 1015      TAO K0200
3315 1144      TAO K1000     /GET RATE * MODE
3316 4426      JMS I XIOTF1 /IOT 6132, CLCE
3317 4424      JMS I XIOTG   /IOT 6131, CLSK
3320 5317      JMP ,=1
3321 7300      CLA CLL      /CLEAR THE AC AND LINK
3322 4427      JMS I XIOTG   /IOT 6133, CLAB
3323 3042      T174B1, DCA REGC
3324 1041      TAO REGB
3325 3070      DCA SEND     /SAVE OUTPUT FOR ERROR PRINTER
3326 4433      T174B, JMS I XIOTK /IOT 6137, CLCA
3327 7041      CIA
3330 1041      TAO REGC     /COMPARE TO THIS REGISTER
3331 7650      SNA CLA     /ARE THEY THE SAME YET ?
3332 5336      JMP T174A     /YES, TEST NEXT NUMBER
3333 2042      ISE REBC
3334 5326      JMP T174B     /WAIT ABOUT 15 MS FOR REGISTER
3335 5341      JMP T174A1    /NUMBER NOT FOUND
3336 2041      T174A:  ISE REBR /UPDATE COMPARE REGISTER
3337 5323      JMP T174B1    /TEST FOR NEXT COUNTER PULSE
3340 4472      JMS I NERROR  /CHECK NON-ERROR HANDLER
3341 4473      T174A1, JMS I ERROR /ERROR! COUNTER FAILED
3342 4174      4174         /TST174 ERROR MESSAGE
3343 3311      TST174       /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 4, MODE 1

```

3344 7340      TST175, CLA CLL CMA /AC TO 7777
3345 4427      JMS I XIOTG   /IOT 6133, CLAB
3346 3040      DCA REGA
3347 1116      TAC K0400
3350 1144      TAO K1000     /GET RATE * MODE
3351 4426      JMS I XIOTF1 /IOT 6132, CLCE
3352 4424      JMS I XIOTG   /IOT 6131, CLSK
3353 5352      JMP ,=1
3354 7300      CLA CLL      /CLEAR THE AC AND LINK
3355 4427      JMS I XIOTG   /IOT 6133, CLAB
3356 3042      T175B1, DCA REGC
3357 1041      TAO REGB

```

```

3368 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
3369 4433      T1750, JMS I XI0YK          /IOT 6137, CLCA
3370 7041          CIA
3371 1041          TAD REGB          /COMPARE TO THIS REGISTER
3372 7650          SNA CLA          /ARE THEY THE SAME YET ?
3373 5371          JMP T175A          /YES, TEST NEXT NUMBER
3374 2042          ISZ RECC
3375 5361          JNP T175B          /WAIT ABOUT 15 MS FOR REGISTER
3376 9374          JMP T175A1         /NUMBER NOT FOUND
3377 2041      T175A, ISZ REGB          /UPDATE COMPARE REGISTER
3378 9358          JNP T175B1         /TEST FOR NEXT COUNTER PULSE
3379 4472          JMS I NERROR        /CHECK NON-ERROR HANDLER
3380 4473      T175A1, JMS I ERROR        /ERROR: COUNTER FAILED
3381 4175          4175                /TST175 ERROR MESSAGE
3382 3344          TST175                /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 2, MODE 2

```

3383 7340      T1751, CLA CLL CMA          /AC TO 7777
3384 4427          JMS I XI0YB          /IOT 6133, CLAB
3385 3040          DCA REGA
3386 1015          TAO K0200
3387 1143          TAD K2000          /GET RATE + MODE
3388 4426          JMS I XI0YF1         /IOT 6132, CL0E
3389 7300      T175B1, CLA CLL          /CLEAR THE AC AND LINK
3390 5042          DCA RECC
3391 1041          TAD REGB
3392 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
3393 4433      T175B, JMS I XI0YK          /IOT 6137, CLCA
3394 7041          CIA
3395 1041          TAD REGB          /COMPARE TO THIS REGISTER
3396 7650          SNA CLA          /ARE THEY THE SAME YET ?
3397 5221          JMP T175A          /YES, TEST NEXT NUMBER
3398 2042          ISZ RECC
3399 5211          JNP T175B          /WAIT ABOUT 15 MS FOR REGISTER
3400 5224          JMP T175A1         /NUMBER NOT FOUND
3401 2041      T175A, ISZ REGB          /UPDATE COMPARE REGISTER
3402 5205          JNP T175B1         /TEST FOR NEXT COUNTER PULSE
3403 4472          JMS I NERROR        /CHECK NON-ERROR HANDLER
3404 4473      T175A1, JMS I ERROR        /ERROR: COUNTER FAILED
3405 4176          4176                /TST176 ERROR MESSAGE
3406 3377          TST176                /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 4, MODE 2

```

3407 7340      TST177, CLA CLL CMA          /AC TO 7777
3408 4427          JMS I XI0YC          /IOT 6133, CLAB
3409 3040          DCA REGA
3410 1116          TAO K0400
3411 1143          TAD K2000          /GET RATE + MODE
3412 4426          JMS I XI0YF1         /IOT 6132, CL0E
3413 7300      T177B1, CLA CLL          /CLEAR THE AC AND LINK
3414 3042          DCA RECC

```

```

3437 1041 TAD REG8
3440 3070 OCA SEND /SAVE OUTPUT FOR ERROR PRINTER
3441 4433 T177B, JMS I XIOTK /IOF 6137, CLCA
3442 7041 CIA
3443 1041 TAD REG8 /COMPARE TO THIS REGISTER
3444 7650 SNA CLA /ARE THEY THE SAME YET ?
3445 5251 JMP T177A /YES, TEST NEXT NUMBER
3446 2042 ISZ REGC
3447 5241 JMP T177B /WAIT ABOUT 15 MS FOR REGISTER
3450 5254 JMP T177A1 /NUMBER NOT FOUND
3451 2041 T177A, ISZ REG8 /UPDATE COMPARE REGISTER
3452 5235 JMP T177B1 /TEST FOR NEXT COUNTER PULSE
3453 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3454 4473 T177A1, JMS I ERROR /ERROR: COUNTER FAILED
3455 4177 4177 /TST177 ERROR MESSAGE
3456 3427 TST177 /SCOPE LOOP

```

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 4, MODE 3
/

```

```

3457 7340 TST200, CLA CLL CMA /AC TO 7777
3460 4427 JMS I XIOTG /IOF 6133, CLAB
3461 3040 OCA REGA
3462 1116 TAD K0400
3463 1120 TAD K3000 /SET RATE + MODE
3464 4426 JMS I XIOTF1 /IOF 6132, CLOE
3465 7300 T200B1, CLA CLL /CLEAR THE AC AND LINK
3466 3042 OCA REGC
3467 1041 TAD REG8
3470 3070 OCA SEND /SAVE OUTPUT FOR ERROR PRINTER
3471 4433 T200B, JMS I XIOTK /IOF 6137, CLCA
3472 7041 CIA
3473 1041 TAD REG8 /COMPARE TO THIS REGISTER
3474 7650 SNA CLA /ARE THEY THE SAME YET ?
3475 5301 JMP T200A /YES, TEST NEXT NUMBER
3476 2042 ISZ REGC
3477 5271 JMP T200B /WAIT ABOUT 15 MS FOR REGISTER
3500 5304 JMP T200A1 /NUMBER NOT FOUND
3501 2041 T200A, ISZ REG8 /UPDATE COMPARE REGISTER
3502 5265 JMP T200B1 /TEST FOR NEXT COUNTER PULSE
3503 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3504 4473 T200A1, JMS I ERROR /ERROR: MODE 3, COUNTER FAILED
3505 4200 4200 /TST200 ERROR MESSAGE
3506 3457 TST200 /SCOPE LOOP

```

```

/
/DO IOF'S AFFECT AC ?
/

```

```

3507 7340 TST201, CLA CLL CMA /AC TO 7777
3510 4427 JMS I XIOTG /IOF 6133, CLAB
3511 3040 OCA REGA /PASS COUNT 1
3512 6007 6007 /CAF OR CLEAR THE WORLD
3513 1144 TAD K1000
3514 4015 TAD K0200 /DOY ENABLES
3515 4426 JMS I XIOTF1 /IOF 6132, CLOE
3516 4424 JMS I XIOTK /IOF 6133, CLCB

```

```

PAL10  V1*1  27-JUL-71  19143  PAGE 1=

3517  5316          JMP ,=0          /WAIT FOR COUNTER TO GET CLEARED
3520  7340          CLA CLL CMA
3521  4423          JMS I XIOTD          /IOT 6130, CLRE
3522  7300  T2010,  CLA CLL          /CLEAR AC AND LINK
3523  3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
3524  1041          TAD REGB          /GET AC NUMBER
3525  4432          JMS I XIOTJ          /IOT 6136, CLRA
3526  7640          SEA CLA          /WAS AC ALL 0'S ?
3527  5351          JMP T201A
3530  1041          TAD REGB          /GET AC NUMBER
3531  4433          JMS I XIOTK          /IOT 6137, CLCA
3532  7640          SEA CLA          /WAS AC ALL 0'S ?
3533  5351          JMP T201A
3534  1041          TAD REGB          /GET AC NUMBER
3535  4430          JMS I XIOTL          /IOT 6134, CLEN
3536  7640          SEA CLA          /WAS AC ALL 0'S ?
3537  5351          JMP T201A
3540  1041          TAD REGB          /GET AC NUMBER
3541  4431          JMS I XIOTI          /IOT 6135, CLSA
3542  7640          SEA CLA          /WAS AC ALL 0'S ?
3543  5351          JMP T201A
3544  4424          JMS I XIOTE          /IOT 6131, CLSK
3545  5344          JMP ,=1          /WAS FLAG STILL SET Y
3546  2041          ISZ REGB          /UPDATE PASS COUNTER
3547  5322          JMP T201B          /TEST IOT'S AGAIN
3550  4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
3551  4473  T201A,  JMS I ERROR          /ERROR! IOT FAILED
3552  3201          3201          /TST201 ERROR MESSAGE
3553  3507          TST201          /SCOPE LOOP

/
3554  4570          JMS I XPASS          /TYPE PASS COMPLETE
3555  5453          JMP I XDR0EP          /CONTINUE TESTING

/DOES INPUT 4 CAUSE INT, RQST.
/
3556  7300          CLA CLL
3557  1112          TAD K7400
3560  3077          DCA LOOP          /LOAD LOOP COUNTER
3561  7340  TST202,  CLA CLL CMA          /AC TO 7777
3562  3040          DCA REGA
3563  7307          CLA CLL IAC RTL /AC TO 0004
3564  1142          TAD K0010          /GET ENABLES
3565  4425          JMS I XIOTF          /IOT 6132, CLCE
3566  4450          JMS I XPIG02          /GO TO P1, P1 EXPECTED
3567  4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
3570  4473          JMS I ERROR          /ERROR! INPUT 4 FAILED
3571  1602          1602          /TST202 ERROR MESSAGE
3572  3561          TST202          /SCOPE LOOP

/DOES INPUT 2 CAUSE INT, RQST.
/
3573  7340  TST203,  CLA CLL CMA          /AC TO 7777
3574  3040          DCA REGA
3575  7326          CLA CLL CML RTL /AC TO 0002
3576  1142          TAD K0010          /GET ENABLES

```

```

3577 4425      JMS I XI0YF      /IOT 6132, CLOS
3600 4450      JMS I XPIG02     /GO TO PI, PI EXPECTED
3601 4472      JMS I NERROR     /CHECK NON-ERROR HANDLER
3602 4473      JMS I ERROR      /ERROR! INPUT 2 FAILED
3603 1603      1603            /TST203 ERROR MESSAGE
3604 3573      TST203          /SCOPE LOOP

```

/DOES INPUT 1 CAUSE INT. ROST,

```

3605 7340      TST204, CLA CLL CMA      /AC TO 7777
3606 3040      DCA REGA
3607 7324      CLA CLL CML RAL      /AC TO 0001
3610 1142      TAD K0010          /GET ENABLES
3611 4425      JMS I XI0YF      /IOT 6132, CLOS
3612 4450      JMS I XPIG02     /GO TO PI, PI EXPECTED
3613 4472      JMS I NERROR     /CHECK NON-ERROR HANDLER
3614 4473      JMS I ERROR      /ERROR! INPUT 1 FAILED
3615 1604      1604            /TST204 ERROR MESSAGE
3616 3605      TST204          /SCOPE LOOP

```

/DOES INPUT 4 ROST, LAST ?

```

3617 7340      TST205, CLA CLL CMA      /AC TO 7777
3620 3040      DCA REGA
3621 7307      CLA CLL IAC RTL      /AC TO 0004
3622 1142      TAD K0010          /GET ENABLES
3623 4425      JMS I XI0YF      /IOT 6132, CLOS
3624 4447      JMS I XPIG01     /GO TO PI, PI EXPECTED
3625 5232      JMP T205A          /NO ROST, FOUND
3626 2041      ISZ REGB          /UPDATE COUNTER
3627 5226      JMP ,+5          /WAIT 15 MS
3630 4450      JMS I XPIG02     /GO TO PI, PI EXPECTED
3631 4472      JMS I NERROR     /CHECK NON-ERROR HANDLER
3632 4473      JMS I ERROR      /ERROR! INPUT 4 FAILED
3633 1605      T205A, 1605          /TST205 ERROR MESSAGE
3634 3617      TST205          /SCOPE LOOP

```

/DOES INPUT 2 ROST, LAST ?

```

3635 7340      TST206, CLA CLL CMA      /AC TO 7777
3636 3040      DCA REGA
3637 7305      CLA CLL IAC RAL      /AC TO 0002
3640 1142      TAD K0010          /GET ENABLES
3641 4425      JMS I XI0YF      /IOT 6132, CLOS
3642 4447      JMS I XPIG01     /GO TO PI, PI EXPECTED
3643 5250      JMP T206A          /NO ROST, FOUND
3644 2041      ISZ REGB          /UPDATE COUNTER
3645 5244      JMP ,+1          /WAIT 15 MS
3646 4450      JMS I XPIG02     /GO TO PI, PI EXPECTED
3647 4472      JMS I NERROR     /CHECK NON-ERROR HANDLER
3650 4473      T206A, JMS I ERROR      /ERROR! INPUT 2 FAILED
3651 1606      1606            /TST206 ERROR MESSAGE
3652 3635      TST206          /SCOPE LOOP

```

/DOES INPUT 1 ROST, LAST ?


```

/
3633 7340 TST207, CLA CLL CMA /AC TO 7777
3634 3040 DCA REGA
3635 7324 CLA CLL CML RAL /AC TO 0001
3636 1142 TAD K0010 /GET ENABLER
3637 4425 JMS I X10TF /IOT 0132, CLOC
3638 4447 JMS I XPI001 /GO TO PI, PI EXPECTED
3639 5266 JMP T207A /NO ROST, FOUND
3640 2041 TSB REGH /UPDATE COUNTER
3641 5262 JMP JMS /WAIT 05 MS
3642 4450 JMS I XPI002 /GO TO PI, PI EXPECTED
3643 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3644 4473 T207A, JMS I ERROR /ERROR: INPUT 1 FAILED
3645 1607 /TST207 ERROR MESSAGE
3646 3653 TST207 /SCOPE LOOP

```

/DOES INPUTS 1,2,3 WITHOUT BIT 8 ?

```

/
3671 7340 TST210, CLA CLL CMA /AC TO 7777
3672 3040 DCA REGA
3673 7313 CLA CLL IAC RTR /AC TO 4000
3674 1007 TAD K0007
3675 1147 TAD K0000
3676 4425 JMS I X10TF /IOT 0132, CLOC
3677 4447 JMS I XPI001 /GO TO PI, NO PI EXPECTED
3678 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3679 4473 JMS I ERROR /ERROR:ENABLE BIT 8 FAILED
3680 1210 /TST210 ERROR MESSAGE
3681 3671 TST210 /SCOPE LOOP

```

/DOES INPUT 4 CAUSE SKIP ?

```

/
3704 7340 TST211, CLA CLL CMA /AC TO 7777
3705 3040 DCA REGA
3706 1113 TAD K10CP5
3707 3045 DCA REGF
3710 7307 CLA CLL IAC RYL /AC TO 0004
3711 4425 JMS I X10TF /IOT 0132, CLOC
3712 4424 JMS I X10TE /IOT 0131, CLSK
3713 4446 JMS I SKPNAT /LET'S WAIT FOR A FLAG
3714 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3715 4473 JMS I ERROR /ERROR: INPUT 4 OR SKIP FAILED
3716 0611 /TST211 ERROR MESSAGE
3717 3704 TST211 /SCOPE LOOP

```

/DOES INPUT 2 CAUSE SKIP ?

```

/
3720 7340 TST212, CLA CLL CMA /AC TO 7777
3721 3040 DCA REGA
3722 1113 TAD K10CP5
3723 3045 DCA REGF
3724 7326 CLA CLL CML RYL /AC TO 0002
3725 4425 JMS I X10TF /IOT 0132, CLOC
3726 4424 JMS I X10TE /IOT 0131, CLSK
3727 4446 JMS I SKPNAT /LET'S WAIT FOR A FLAG

```

```

3730 4472      JMS I NERROR      /CHECK NON-ERROR HANDLER
3731 4473      JMS I ERROR      /ERROR: INPUT 2 OR SKIP FAILED
3732 0612      0612      /TST212 ERROR MESSAGE
3733 3720      TST212      /SCOPE LOOP

```

/ DOES INPUT 1 CAUSE SKIP ?

```

3734 7340      TST213, CLA CLL CMA      /AC TO 7777
3735 3040      DCA REGA
3736 1113      TAD K71CPS
3737 3045      DCA REGF
3740 7301      CLA CLL IAC      /AC TO 0001
3741 4425      JMS I XIOTF      /IOT 6132, CLOS
3742 4424      JMS I XIOTE      /IOT 6131, CLSK
3743 4446      JMS I SKPWAT     /LET'S WAIT FOR FLAG
3744 4472      JMS I NERROR     /CHECK NON-ERROR HANDLER
3745 4473      JMS I ERROR     /ERROR: INPUT 1 OR SKIP FAILED
3746 0613      0613      /TST213 ERROR MESSAGE
3747 3734      TST213      /SCOPE LOOP

```

/ DOES INPUT 4 RQST, THEN SKIP AND VICE-VERSA ?

```

3750 7340      TST214, CLA CLL CMA      /AC TO 7777
3751 3040      DCA REGA
3752 7307      CLA CLL IAC RTL /AC TO 0004
3753 1142      TAD K0010      /GET ENABLES
3754 4425      JMS I XIOTF      /IOT 6132, CLOS
3755 4424      JMS I XIOTE      /IOT 6131, CLSK
3756 5355      JMP ,=-1
3757 4447      JMS I XPIG01     /GO TO PI, PI EXPECTED
3760 5364      JMP T214A
3761 4424      JMS I XIOTE      /IOT 6131, CLSK
3762 5361      JMP ,=-1
3763 4472      JMS I NERROR     /CHECK NON-ERROR HANDLER
3764 4473      T214A, JMS I ERROR /ERROR: INPUT 4 SKIP OR INT, RQST, FAILED
3765 1614      1614      /TST214 ERROR FAILED
3766 3750      TST214      /SCOPE LOOP

```

/ DOES INPUT 2 SKIP THEN INT, RQST, AND VICE-VERSA ?

```

3767 7340      TST215, CLA CLL CMA      /AC TO 7777
3770 3040      DCA REGA
3771 7305      CLA CLL IAC RAL /AC TO 0002
3772 1142      TAD K0010      /GET ENABLES
3773 4425      JMS I XIOTF      /IOT 6132, CLOS
3774 4424      JMS I XIOTE      /IOT 6131, CLSK
3775 5374      JMP ,=-1
3776 4447      JMS I XPIG01     /GO TO PI, PI EXPECTED
3777 5575      JMP I XCRSB
4000 4424      JMS I XIOTE      /IOT 6131, CLSK
4001 5200      JMP ,=-1
4002 4472      JMS I NERROR     /CHECK NON-ERROR HANDLER
4003 4473      T215A, JMS I ERROR /ERROR: INPUT 2 SKIP OR RQST, FAILED
4004 1615      1615      /TST215 ERROR MESSAGE
4005 3767      TST215      /SCOPE LOOP

```

/
 /DOES INPUT 1 SKIP WHEN INT, ROST, AND VICE-VERSA ?
 /

```

4006 7330 TST216, CLA CLL CMA /AC TO 7777
4007 3040 DCA REGA
4010 7301 CLA CLL IAC /AC TO 0001
4011 1142 YAD K0010 /GET ENABLES
4012 4425 JMS I XIOTF /IOT 6132, CLOC
4013 4424 JMS I XIOTE /IOT 6131, CLSK
4014 5213 JMP ,=1
4015 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
4016 5222 JMP T216A
4017 4424 JMS I XIOTE /IOT 6131, CLSK
4020 5217 JMP ,=1
4021 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4022 4473 T216A, JMS I ERROR /ERROR! INPUT 1 SKIP OR INT, ROST, FAILED
4023 1016 I010 /T30216 ERROR MESSAGE
4024 4006 YST216 /SCOPE LOOP
  
```

/
 /DOES CAF CLEAR INPUT 4 INT, ROST, ?
 /

```

4025 7340 TST217, CLA CLL CMA /AC TO 7777
4026 3040 DCA REGA
4027 7307 CLA CLL IAC RYL /AC TO 0004
4030 4425 JMS I XIOTF /IOT 6132, CLOC
4031 4424 JMS I XIOTE /IOT 6131, CLSK
4032 5231 JMP ,=1 /WAIT FOR FIRST FLAG
4033 6007 /CAF OR CLEAR THE WORLD
4034 7307 CLA CLL IAC RYL /AC TO 0004
4035 4425 JMS I XIOTF /IOT 6132, CLOC
4036 4424 JMS I XIOTE /IOT 6131, CLSK
4037 5236 JMP ,=1 /WAIT FOR SECOND FLAG
4040 6007 /CAF OR CLEAR THE WORLD
4041 7307 CLA CLL IAC RYL
4042 4425 JMS I XIOTF /IOT 6132, CLOC
4043 4424 JMS I XIOTE /IOT 6131, CLSK
4044 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4045 4473 JMS I ERROR /ERROR! INPUT 4 SKIP OR ROST, FAILED
4046 5217 0217 /T3T217 ERROR MESSAGE
4047 4023 TST217 /SCOPE LOOP
  
```

/
 /DOES CAF CLEAR INPUT 2 ROST, ?
 /

```

4050 7340 TST220, CLA CLL CMA /AC TO 7777
4051 3040 DCA REGA
4052 7305 CLA CLL IAC RAL /AC TO 0002
4053 4425 JMS I XIOTF /IOT 6132, CLOC
4054 4424 JMS I XIOTE /IOT 6131, CLSK
4055 5254 JMP ,=1 /WAIT FOR FIRST FLAG
4056 6007 /CAF OR CLEAR THE WORLD
4057 7325 CLA CLL IAC RAL /AC TO 0002
4060 4425 JMS I XIOTF /IOT 6132, CLOC
4061 4424 JMS I XIOTE /IOT 6131, CLSK
4062 5261 JMP ,=1 /WAIT FOR SECOND FLAG
4063 6007 /CAF OR CLEAR THE WORLD
  
```

```

4064 7305 CLA CLL IAC RAL /AC TO 0002
4065 4425 JMS I XIOTF /IOT 6132, CLOE
4066 4424 JMS I XIOTE /IOT 6131, CLSK
4067 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4070 4473 JMS I ERROR /ERROR: INPUT 2 SKIP OR ROST, FAILED
4071 0220 0220 /TST220 ERROR MESSAGE
4072 4050 TST220 /SCOPE LOOP

```

```

/DOES CAP CLEAR INPUT 3 ROST, ?
/

```

```

4073 7340 TST221, CLA CLL CMA /AC TO 0007
4074 3040 DCA REGA
4075 7301 CLA CLL IAC /AC TO 0001
4076 4425 JMS I XIOTF /IOT 6132, CLOE
4077 4424 JMS I XIOTE /IOT 6131, CLSK
4100 5277 JMP ,=1 /WAIT FOR FIRST FLAG
4101 6007 6007 /CAP OR CLEAR THE WORLD
4102 7301 CLA CLL IAC /AC TO 0001
4103 4425 JMS I XIOTF /IOT 6132, CLOE
4104 4424 JMS I XIOTE /IOT 6131, CLSK
4105 5304 JMP ,=1 /WAIT FOR SECONED FLAG
4106 6007 6007 /CAP OR CLEAR THE WORLD
4107 7301 CLA CLL IAC
4110 4425 JMS I XIOTF /IOT 6132, CLOE
4111 4424 JMS I XIOTE /IOT 6131, CLSK
4112 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4113 4473 JMS I ERROR /ERROR: INPUT 1 SKIP OR ROST, FAILED
4114 0221 0221 /TST221 ERROR MESSAGE
4115 4073 TST221 /SCOPE LOOP

```

```

/DOES CLSA READ ROST, INPUT 4 ?
/

```

```

4116 7340 TST222, CLA CLL CMA /AC TO 7777
4117 3040 DCA REGA
4120 7307 CLA CLL IAC RYL /AC TO 0004
4121 4425 JMS I XIOTF /IOT 6132, CLOE
4122 4424 JMS I XIOTE /IOT 6131, CLSK
4123 5222 JMP ,=1 /WAIT FOR FLAG
4124 7040 CMA /AC TO 7775
4125 4431 JMS I XIOTI /IOT 6133, CLSA
4126 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
4127 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4130 4473 JMS I ERROR /ERROR: CLSA OR INPUT 4 FAILED
4131 5222 5222 /TST222 ERROR MESSAGE
4132 4116 TST222 /SCOPE LOOP

```

```

/DOES CLSA READ ROST, INPUT 2 ?
/

```

```

4133 7340 TST223, CLA CLL CMA /AC TO 7777
4134 3040 DCA REGA
4135 7305 CLA CLL IAC RAL /AC TO 0002
4136 4425 JMS I XIOTF /IOT 6132, CLOE
4137 4424 JMS I XIOTE /IOT 6131, CLSK
4140 5507 JMP ,=1 /WAIT FOR FLAG
4141 7040 CMA /AC TO 7775

```

```

4142 4431 JMS I XIOTI /IOT 6135, CLSA
4143 4436 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4144 4432 JMS I NERROR /CHECK NON-ERROR HANDLER
4145 4473 JMS I ERROR /ERROR! CLSA OR INPUT 2 FAILED
4146 5223 5223 /TST223 ERROR MESSAGE
4147 4133 TST223 /SCOPE LOOP

```

/
/DOES CLSA READ RST, INPUT 1 ?
/

```

4150 7340 TST224, CLA CLL CHA /AC TO 7777
4151 3040 DCA REGA
4152 7301 CLA CLL IAC /AC TO 9991
4153 4429 JMS I XIOTI /IOT 6132, CLOC
4154 4424 JMS I XIOTE /IOT 6131, CLSK
4155 5334 JMP ,=1 /WAIT FOR FLAG
4156 7040 CHA /AC TO 7776
4157 4431 JMS I XIOTI /IOT 6135, CLSA
4158 4436 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4161 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4162 4473 JMS I ERROR /ERROR! CLSA OR INPUT 1 FAILED
4163 5224 5224 /TST224 ERROR MESSAGE
4164 4150 TST224 /SCOPE LOOP

```

/
/DOES CLSA CLEAR INPUT 4 RST, ?
/

```

4165 7340 TST225, CLA CLL CHA /AC TO 7777
4166 3040 DCA REGA
4167 7307 CLA CLL IAC RFL /AC TO 9994
4170 4426 JMS I XIOTI /IOT 6132, CLOC
4171 4424 JMS I XIOTE /IOT 6131, CLSK
4172 5371 JMP ,=2 /WAIT FOR FIRST FLAG
4173 4431 JMS I XIOTI /IOT 6135, CLSA
4174 4424 JMS I XIOTE /IOT 6131, CLSK
4175 5374 JMP ,=1 /WAIT FOR SECOND FLAG
4176 4431 JMS I XIOTI /IOT 6135, CLSA
4177 4424 JMS I XIOTE /IOT 6131, CLSK
4200 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4201 4473 JMS I ERROR /ERROR! CLSA OR INPUT 1 FAILED
4202 5225 5225 /TST225 ERROR MESSAGE
4203 4165 TST225 /SCOPE LOOP

```

/
/DOES CLSA CLEAR INPUT 2 RST, ?
/

```

4204 7340 TST226, CLA CLL CHA /AC TO 7777
4205 3040 DCA REGA
4206 7305 CLA CLL IAC RAL /AC TO 9992
4207 4425 JMS I XIOTI /IOT 6132, CLOC
4210 4424 JMS I XIOTE /IOT 6131, CLSK
4211 5210 JMP ,=1 /WAIT FOR FIRST FLAG
4212 4431 JMS I XIOTI /IOT 6135, CLSA
4213 4424 JMS I XIOTE /IOT 6131, CLSK
4214 5213 JMP ,=1 /WAIT FOR SECOND FLAG
4215 4431 JMS I XIOTI /IOT 6135, CLSA
4216 4424 JMS I XIOTE /IOT 6131, CLSK
4217 4472 JMS I NERROR /CHECK NON-ERROR HANDLER

```

```

/
PAL10  V141  27-JUL-71  13143  PAGE 1-34

4228  4473      JMS I ERROR      /ERROR! CLSA OR INPUT 2 FAILED
4221  0226      0226          /TST226 ERROR MESSAGE
4222  4264      TST226          /SCOPE LOOP

/
/DOES CLSA CLEAR INPUT 4 ROST, ?
/
4223  7340      TST227, CLA CLL CMA      /AC TO 7777
4224  3040      DCA REGA
4225  7301      CLA CLL IAC          /AC TO 0001
4226  4425      JMS I XIOTF          /IOT 6130, CLSE
4227  4424      JMS I XIOTE          /IOT 6131, CLSK
4230  5227      JMP ,=1              /WAIT FOR FIRST FLAG
4231  4431      JMS I XIOTI          /IOT 6130, CLSA
4232  4424      JMS I XIOTE          /IOT 6131, CLSK
4233  5232      JMP ,=1              /WAIT FOR SECOND FLAG
4234  4431      JMS I XIOTI          /IOT 6130, CLSA
4235  4424      JMS I XIOTE          /IOT 6131, CLSK
4236  4472      JMS I NERROR        /CHECK NON-ERROR HANDLER
4237  4473      JMS I ERROR        /ERROR! CLSA OR INPUT 2 FAILED
4240  0227      0227          /TST227 ERROR MESSAGE
4241  4223      TST227          /SCOPE LOOP

/
/DOES CLSA READ INPUT 4,2,1 ?
/
4242  7340      TST230, CLA CLL CMA      /AC TO 7777
4243  3040      DCA REGA
4244  1007      TAD K0007          /GET ENABLES
4245  4425      JMS I XIOTF          /IOT 6132, CLSE
4246  7000      NOP
4247  2041      ISB REGB
4250  5246      JMP ,=2              /WAIT FOR ALL
4251  4424      JMS I XIOTE          /IOT 6131, CLSE
4252  5251      JMP ,=1              /WAIT FOR FLAGS
4253  7340      CLA CLL CMA      /AC TO 7777
4254  4431      JMS I XIOTI          /IOT 6130, CLSA
4255  4426      JMS I XSNDRV        /CHECK SEND AND RECV REGISTERS
4256  7610      SKP CLA
4257  5265      JMP T230A          /ERROR, STATUS REGISTER
4260  3070      DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
4261  7340      CLA CLL CMA      /AC TO 7777
4262  4431      JMS I XIOTI          /IOT 6130, CLSA
4263  7650      SNA CLA          /WAS STATUS ALL BLS ?
4264  4472      JMS I NERROR        /CHECK NON-ERROR HANDLER
4265  4473      T230A, JMS I ERROR    /ERROR! CLSA OR INPUTS 1,2,3 FAILED
4266  5230      5230          /TST230 ERROR MESSAGE
4267  4242      TST230          /SCOPE LOOP

/
/DOES INPUT 4 CLEAR BIT 7 ?
/
4270  7340      TST231, CLA CLL CMA
4271  3040      DCA REGA
4272  7307      CLA CLL IAC RY, /AC TO 0004
4273  3070      DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
4274  1070      TAD SEND
4275  1140      TAD K0020          /GET ENABLES

```

```

4276 4426 JMS I XIOTF1 /IOT 6132, CLOS
4277 4424 JMS I XIOTE /IOT 6131, CLSK
4300 5277 JMP ,=1 /WAIT FOR FLAG
4301 7340 CLA CLL CMA /AC TO 7777
4302 4430 JMS I XIOTM /IOT 6134, CLEN
4303 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4304 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4305 4473 JMS I ERROR /ERRORIBIT 7 OR INPUT 4 FAILED
4306 4631 4631 /TST231 ERROR MESSAGE
4307 4270 TST231 /SCOPE LOOP

```

/DOES INPUT 2 CLEAR BIT 7 ?

```

4310 7340 TST232, CLA CLL CMA
4311 3040 OCA REGA
4312 7305 CLA CLL IAC BAL /AC TO 0002
4313 3070 OCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4314 1070 TAD SEND
4315 1140 TAD K0020
4316 4426 JMS I XIOTF1 /IOT 6132, CLOS
4317 4424 JMS I XIOTE /IOT 6131, CLSK
4320 5317 JMP ,=1 /WAIT FOR FLAG
4321 7340 CLA CLL CMA
4322 4430 JMS I XIOTM /IOT 6134, CLEN
4323 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4324 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4325 4473 JMS I ERROR /ERRORI BIT 7 OR INPUT 2 FAILED
4326 4632 4632 /TST232 ERROR MESSAGE
4327 4310 TST232 /SCOPE LOOP

```

/DOES INPUT 1 CLEAR BIT 7 ?

```

4330 7340 TST233, CLA CLL CMA /AC TO 7777
4331 3040 OCA REGA
4332 7301 CLA CLL IAC /AC TO 0001
4333 3070 OCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4334 1070 TAD SEND
4335 1140 TAD K0020
4336 4426 JMS I XIOTF1 /IOT 6132, CLOS
4337 4424 JMS I XIOTE /IOT 6131, CLSK
4340 5337 JMP ,=1 /WAIT FOR FLAG
4341 7340 CLA CLL CMA /AC TO 7777
4342 4430 JMS I XIOTM /IOT 6134, CLEN
4343 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4344 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4345 4473 JMS I ERROR /ERRORI BIT 7 OR INPUT 1 FAILED
4346 4633 4633 /TST233 ERROR MESSAGE
4347 4330 TST233 /SCOPE LOOP

```

/DOES INPUT 4,2,1 GENERATE CLR CNT ?
/MODE 3, RATE 0

```

4350 7340 TST234, CLA CLL CMA /AC TO 7777
4351 3040 OCA REGA
4352 1016 TAD K2525 /GET AC NUMBER

```

```

4353 4427 JMS I XIOTB /IOT 6133, CLAB
4354 7307 CLA CLL IAC HYL /AC TO 8004
4355 1120 TAD K3000 /GET ENABLER
4356 4426 JMS I XIOTF1 /IOT 6132, CLOE
4357 4424 JMS I XIOTF /IOT 6131, CLSK
4360 5357 JMP ,=1 /WAIT FOR FLAG
4361 7300 CLA CLL
4362 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4363 7340 CLA CLL CMA /AC TO 7777
4364 4433 JMS I XIOTK /IOT 6137, CLG4
4365 7650 SNA CLA /HAS COUNTER ALL 0'S ?
4366 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4367 4473 JMS I ERROR /ERROR! CLR CNT FAILED
4370 4234 4234 /TST234 ERROR MESSAGE
4371 4350 TST234 /SCOPE LOOP

```

/
/DOES INPUT 4,2,1 CAUSE CLR CNT ?
/MODE 3, RATE 0

```

4372 7340 TST235, CLA CLL CMA /AC TO 7777
4373 3040 DCA REGA
4374 1017 TAD K2052 /GET AC NUMBER
4375 4427 JMS I XIOTB /IOT 6133, CLAB
4376 7305 CLA CLL IAC RAL /AC TO 8002
4377 1120 TAD K3000 /GET ENABLER
4400 4426 JMS I XIOTF1 /IOT 6132, CLOE
4401 4424 JMS I XIOTE /IOT 6131, CLSK
4402 3201 JMP ,=1 /WAIT FOR FLAG
4403 7300 CLA CLL
4404 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4405 7340 CLA CLL CMA /AC TO 7777
4406 4433 JMS I XIOTK /IOT 6137, CLG4
4407 7650 SNA CLA /HAS COUNTER ALL 0'S ?
4410 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4411 4473 JMS I ERROR /ERROR! CLR CNT FAILED ?
4412 4235 4235 /TST235 ERROR MESSAGE
4413 4372 TST235 /SCOPE LOOP

```

/
/DOES INPUT 4,2,1 TRANSFER COUNTER TO BUFFER ?

```

4414 7340 TST236, CLA CLL CMA /AC TO 7777
4415 3040 DCA REGA
4416 1016 TAD K2055 /GET AC NUMBER
4417 4427 JMS I XIOTB /IOT 6133, CLAB
4420 6007 /CAF OR CLEAR THE WORLD
4421 7301 CLA CLL IAC /AC TO 8001
4422 1120 TAD K3000 /GET ENABLER
4423 4426 JMS I XIOTF1 /IOT 6132, CLOE
4424 4424 JMS I XIOTF /IOT 6131, CLSK
4425 3224 JMP ,=1 /WAIT FOR FLAG
4426 7340 CLA CLL CMA /AC TO 7777
4427 4432 JMS I XIOTK /IOT 6137, CLG4
4428 4434 JMS I XSDNDP /CHECK SEND AND RECEV REGISTERS
4431 4172 JMS I XSDNDP /CHECK NON-ERROR HANDLER
4432 4472 JMS I ERROR /ERROR! COUNTER TO BUFFER FAILED

```



```

4438 3636          3636          /TST236 ERROR MESSAGE
4434 4414          TST236          /SCOPE LOOP
/
/DOES INPUT 4,2,1 TRANSFER COUNTER TO BUFFER ?
/
TST237: CLA CLL CMA          /AC TO 7777
        DCA REGA
4436 3040          TAD R5252          /GET AC NUMBER
4437 1017          JMS I XIOTS          /IOT 6133, CLAB
4440 4427          6007          /CAF OR CLEAR THE WORLD
4441 6007
4442 7301          CLA CLL IAC          /AC TO 0001
4443 1120          TAD R3000          /GET ENABLES
4444 4426          JMS I XIOTF1          /IOT 6132, CLOE
4445 4424          JMS I XIOTE          /IOT 6131, CLSK
4446 5245          JMP ,=1          /WAIT FOR FLAG
4447 7340          CLA CLL CMA          /AC TO 7777
4450 4432          JMS I XIOTJ          /IOT 6136, CLBA
4451 4456          JMS I XSNDRV          /CHECK SEND AND RECEV REGISTERS
4452 4472          JMS I NERRON          /CHECK NON-ERROR HANDLER
4453 4473          JMS I ERROR          /ERROR! COUNTER TO BUFFER FAILED
4454 3637          3637          /TST237 ERROR MESSAGE
4455 4435          TST237          /SCOPE LOOP

```

```

/DOES INPUT 4,2,1 GENERATE CLR CNT ?
/MODE 2, RATE 0
/

```

```

4456 7340          TST240: CLA CLL CMA          /AC TO 7777
4457 3040          DCA REGA
4460 1016          TAD R2925          /GET AC NUMBER
4461 4427          JMS I XIOTS          /IOT 6133, CLAB
4462 6007          6007          /CAF OR CLEAR THE WORLD
4463 7307          CLA CLL IAC RTL          /AC TO 0004
4464 1143          TAD R2000          /GET ENABLES
4465 4426          JMS I XIOTF1          /IOT 6132, CLOE
4466 4424          JMS I XIOTE          /IOT 6131, CLSK
4467 5266          JMP ,=1          /WAIT FOR FLAG
4470 7340          CLA CLL CMA          /AC TO 7777
4471 4433          JMS I XIOTK          /IOT 6137, CLCA
4472 4456          JMS I XSNDRV          /CHECK SEND AND RECEV REGISTERS
4473 4472          JMS I NERRON          /CHECK NON-ERROR MESSAGE
4474 4473          JMS I ERROR          /ERROR! CLR CNT FAILED, MODE 2
4475 4240          4240          /TST240 ERROR MESSAGE
4476 4458          TST240          /SCOPE LOOP

```

```

/DOES INPUT 4,2,1 CAUSE CLR CNT ?
/MODE 2, RATE 0
/

```

```

4477 7340          TST241: CLA CLL CMA
4500 3040          DCA REGA
4501 1017          TAD R5252          /GET AC NUMBER
4502 4427          JMS I XIOTG          /IOT 6133, CLAB
4503 6007          6007          /CAF OR CLEAR THE WORLD
4504 7305          CLA CLL IAC RA          /AC TO 0002
4505 1143          TAD R2000          /GET ENABLES

```

```

4506 4426 JMS I XI0YF1 /IOT 6132, CL0K
4507 4424 JMS I XI0YE /IOT 6131, CL0K
4510 5327 JMP ,=1 /WAIT FOR FLAG
4511 7340 CLA CLL CMA /AC TO 7777
4512 4433 JMS I XI0YK /IOT 6137, CLCA
4513 4456 JMS I XSNDV /CHECK SEND AND RECEV REGISTERS
4514 4472 JMS I NERR0R /CHECK NON-ERROR HANDLER
4515 4473 JMS I ERROR /ERROR: CLR CNT FAILED, MODE 2
4516 4241 4241 /TST241 ERROR MESSAGE
4517 4477 TST241 /SCOPE LOOP

```

/ DOES COUNTER TRANSFER TO BUFFER ?
/MODE 2, RATE 0

```

4520 7340 TST242, CLA CLL CMA /AC TO 7777
4521 3040 OCA REGA
4522 1016 TAD K2525 /GET AC NUMBER
4523 4427 JMS I XI0Y6 /IOT 6133, CLAB
4524 6007 6007 /CAF OR CLEAR THE WORLD
4525 7307 CLA CLL IAC RTL
4526 1143 TAD K2000 /GET ENABLES
4527 4426 JMS I XI0YF1 /IOT 6132, CL0E
4530 4424 JMS I XI0YE /IOT 6131, CLSK
4531 5330 JMP ,=1 /WAIT FOR FLAG
4532 7340 CLA CLL CMA /AC TO 7777
4533 4432 JMS I XI0YJ /IOT 6136, CLBA
4534 4456 JMS I XSNDV /CHECK SEND AND RECEV REGISTERS
4535 4472 JMS I NERR0R /CHECK NON-ERROR HANDLER
4536 4473 JMS I ERROR /ERROR: COUNTER TO BUFFER FAILED
4537 3642 3642 /TST242 ERROR MESSAGE
4540 4520 TST242 /SCOPE LOOP

```

/ DOES COUNTER TRANSFER TO BUFFER ?
/MODE 2, RATE 0

```

4541 7340 TST243, CLA CLL CMA /AC TO 7777
4542 3040 OCA REGA
4543 1017 TAD K5252 /GET AC NUMBER
4544 4427 JMS I XI0Y6 /IOT 6133, CLAB
4545 6007 6007 /CAF OR CLEAR THE WORLD
4546 7305 CLA CLL IAC RAL /AC TO 0002
4547 1143 TAD K2000 /GET ENABLES
4550 4426 JMS I XI0YF1 /IOT 6132, CL0E
4551 4424 JMS I XI0YE /IOT 6131, CLSK
4552 5351 JMP ,=1 /WAIT FOR FLAG
4553 7340 CLA CLL CMA
4554 4432 JMS I XI0YJ /IOT 6136, CLBA
4555 4456 JMS I XSNDV /CHECK SEND AND RECEV REGISTERS
4556 4472 JMS I NERR0R /CHECK NON-ERROR HANDLER
4557 4473 JMS I ERROR /ERROR: COUNTER TO BUFFER FAILED
4560 3643 3643 /TST243 ERROR MESSAGE
4561 4541 TST243 /SCOPE LOOP

```

/ DOES INPUT 612:11 APPLY MODE 0 ?

```

4562 7340 TST244, CLA CLL CMA
4563 3040 DCA REGA
4564 1016 TAD K2525 /GET AC NUMBER
4565 4427 JMS I XIOTG /IOT 6133, CLAB
4566 6007 6007 /CAF OR CLEAR THE WORLD
4567 7327 CLA CLL IAC RYL /AC TO 0004
4570 4426 JMS I XIOTF1 /IOT 6132, CLOE
4571 4424 JMS I XIOTE /IOT 6131, CLSK
4572 3371 JMP ,=1 /WAIT FOR FLAG
4573 7340 CLA CLL CMA /AC TO 7777
4574 4433 JMS I XIOTM /IOT 6137, CLCA
4575 4436 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4576 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4577 4473 JMS I ERROR /ERROR! MODE 0 FAILED
4600 4244 4244 /IOT 244 ERROR MESSAGE
4601 4562 TST244 /SCOPE LOOP

```

/
/DOES INPUT 4,2,1 AFFECT MODE 0 ?
/

```

4602 7340 TST245, CLA CLL CMA /AC TO 7777
4603 3040 DCA REGA
4604 1017 TAD K2522 /GET AC NUMBER
4605 4427 JMS I XIOTG /IOT 6133, CLAB
4606 7301 CLA CLL IAC /AC TO 0001
4607 4426 JMS I XIOTF1 /IOT 6132, CLOE
4610 4424 JMS I XIOTE /IOT 6131, CLSK
4611 3210 JMP ,=1 /WAIT FOR FLAG
4612 7340 CLA CLL CMA /AC TO 7777
4613 4432 JMS I XIOTJ /IOT 6136, CLBA
4614 4436 JMS I XSNDRV /CHECK SEND RECEV REGISTERS
4615 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4616 4473 JMS I ERROR /ERROR! MODE 0 FAILED
4617 3645 3645 /TST245 ERROR MESSAGE
4620 4602 TST245 /SCOPE LOOP

```

/
/DOES INPUT 4,2,1 AFFECT MODE 1 ?
/

```

4621 7340 TST246, CLA CLL CMA /AC TO 7777
4622 3040 DCA REGA
4623 1016 TAD K2525 /GET AC NUMBER
4624 4427 JMS I XIOTG /IOT 6133, CLAB
4625 6007 6007 /CAF OR CLEAR THE WORLD
4626 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4627 7301 CLA CLL IAC /AC TO 0001
4630 1144 TAD X1000 /GET ENABLES
4631 4426 JMS I XIOTF1 /IOT 6132, CLOE
4632 4424 JMS I XIOTE /IOT 6131, CLOE
4633 5232 JMP ,=1 /WAIT FOR FLAG
4634 7340 CLA CLL CMA /AC TO 7777
4635 4432 JMS I XIOTJ /IOT 6136, CLBA
4636 7650 SVA CLA /HAS BUFFER STILL ALL 0'S ?
4637 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4640 4473 JMS I ERROR /ERROR! MODE 1 FAILED
4641 4246 4246 /TST246 ERROR MESSAGE
4642 4621 TST246 /SCOPE LOOP

```

/
/DOES INPUT 4,2,1 AFFECT MODE 1 ?
/

```

4643 7340 TST247, CLA CLL CMA /AC TO 7777
4644 3040 DCA REGA
4645 1017 TAD K5252 /GET AC NUMBER
4646 4427 JMS I XIOTG /IOT 6133, CLAB
4647 7307 CLA CLL IAC RYL /AC TO 0004
4650 1144 TAD K1000
4651 4426 JMS I XIOTF1 /IOT 6132, CLOE
4652 4424 JMS I XIOTE /IOT 6131, CLSK
4653 5252 JMP ,=1 /WAIT FOR FLAG
4654 7340 CLA CLL CMA /AC TO 7777
4655 4432 JMS I XIOTJ /IOT 6136, CLBA
4656 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4657 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4660 4473 JMS I ERROR /ERRDR1 MODE 1 FAILED
4661 3647 3647 /TST247 ERROR MESSAGE
4662 4643 TST247 /SCOPE LOOP

```

/

/DOES CLSA READ INPUTS 4,2,1 ?

```

4663 7340 TST250, CLA CLL CMA /AC TO 7777
4664 3040 DCA REGA
4665 1007 TAD K0007 /GET ENABLES
4666 4426 JMS I XIOTF1 /IOT 6132, CLOE
4667 7000 NOP
4670 2041 ISZ REGB
4671 5207 JMP ,=2 /WAIT FOR ALL
4672 4424 JMS I XIOTE /IOT 6131, CLSK
4673 5272 JMP ,=1
4674 4423 JMS I XIOTD /IOT 6130, CLZE
4675 7300 CLA CLL /CLEAR THE AC AND LINK
4676 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4677 7340 CLA CLL CMA /AC TO 7777
4700 4431 JMS I XIOTI /IOT 6135, CLSA
4701 7650 SNA CLA /WAS STATUS ALL 0'S Y
4702 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4703 4473 JMS I ERROR /ERROR:INPUT 4,2,1 OR STATUS FAILED
4704 5250 5250 /TEST250 ERROR MESSAGE
4705 4663 TST250 /SCOPE LOOP

```

/

/DOES CLSA READ STATUS REGISTER ?

```

4706 7340 TST251, CLA CLL CMA /AC TO 7777
4707 3040 DCA REGA
4710 1007 TAD K0007 /GET ENABLES
4711 4425 JMS I XIOTF /IOT 6132, CLOE
4712 7000 NOP
4713 2041 ISZ REGB
4714 5312 JMP ,=2 /WAIT FOR FLAG
4715 4424 JMS I XIOTE /IOT 6131, CLSK
4716 5315 JMP ,=1
4717 7340 CLA CLL CMA /AC TO 7777
4720 4431 JMS I XIOTI /IOT 6135, CLSA

```

```

4721 4456 JMS I XSNDRV /CHECK SEND AND RECV REGISTERS
4722 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4723 4473 JMS I ERROE /ERRORT CLSA OR STATUS REGISTER
4724 5251 /TSY251 ERROR MESSAGE
4725 4706 TSY251 /SCOPE LOOP

```

```

4726 7300 /
4727 2077 CLA CLL
4730 5464 JMP I XMITT /DO TEST 4096 TIMES
4731 4570 JMS I XPASS /TYPE PASS COMPLETE
4732 5465 JMP I XMITT1 /CONTINUE TESTING

```

/NON-ERROR HANDLER FOR PROGRAM

```

5000 5000 /
5001 6007 /5000
5002 2200 /
5003 2200 NERR0, 0000
5004 2040 6007 /CAF OR CLEAR THE WORLD
5005 5215 ISZ NERR0
5006 4460 ISZ NERR0
5007 7604 ISZ REGA
5010 0137 JMP OUT
5011 7640 JMS I XCLREG /CLEAR ALL REGISTERS
5012 5215 LAS
5013 2200 AND K0040 /IS IT LOOP ON NON-
5014 5600 SZA CLA /FAILING TEST,

```

```

5015 1600 JMP OUT
5016 3220 OUT, TAO I NERR0
5017 5620 DCA ERRO
JMP I ERRO

```

/ERROR HANDLER FOR PROGRAM

```

5020 0000 /
5021 6007 ERRO, 0000
5022 7604 6007 /CAF OR CLEAR THE WORLD
5023 7006 LAS
5024 7700 RYL
5025 4503 SMA CLA /CHECK SWR2 FOR INH, PRINT
5026 4510 JMS I XSORT /GET ERROR MESSAGE
5027 4460 JMS I XBELL /RING BELL
5030 2220 JMS I XCLREG
5031 7604 ISZ ERRO
5032 0015 LAS
5033 7650 AND K0200
5034 7402 SNA CLA /CHECK SWR4 FOR INH, HLT
EHLT1, HLT /MONITOR ERROR HALT, READ TYPEOUT
/AND REFERENCE LISTING,
5035 7604 LAS
5036 0013 AND K0100
5037 7640 SZA CLA /CHECK SWR5 FOR SCOPE LOOP
5040 5243 JMP IN
5041 2220 ISZ ERRO

```

```

5042 5620          JMP I ERRO          /CENTER SCOPE LOOP
/
5043 1620          /IN,      TAD I ERRO
5044 3200          DCA NERRO
5045 5600          JMP I NERRO
/
5046 0000          BELL,    0000
5047 7604          LAS
5050 0116          AND K0400
5051 7640          SEA CLA
5052 5646          JMP I BELL
5053 1006          TAD K0207
5054 4507          JMS I XTYPE
5055 5646          JMP I BELL
/
5056 0000          TYPE,    0000
5057 6046          TLS
5060 6041          TSF
5061 5200          JMP I,=1
5062 7200          CLA
5063 6042          TCF
5064 5656          JMP I TYPE
/
5065 0000          CLRREG,  0000
5066 7300          CLA CLL          /CLEAR THE AC AND LINK
5067 3041          DCA REGB
5070 3042          DCA REGC
5071 3043          DCA REGD
5072 3070          DCA SEND
5073 3071          DCA RECEV
5074 7604          LAS
5075 0117          AND K6000
5076 7650          SNA CLA
5077 7340          CLA CLL CHA
5100 3040          DCA REGA
5101 5665          JMP I CLRREG
/
5102 0000          IOTA,    0000
5103 6131          6131          /FIELD SERVICE CHANGE
5104 5702          JMP I IOTA
5105 2302          ISZ IOTA
5106 5702          JMP I IOTA
/
5107 0000          IOTB,    0000
5110 6132          6132          /FIELD SERVICE CHANGE
5111 5707          JMP I IOTB
5112 2307          ISZ IOTB
5113 5707          JMP I IOTB
/
5114 0000          IOTC,    0000
5115 6133          6133          /FIELD SERVICE CHANGE
5116 5714          JMP I IOTC
5117 2314          ISZ IOTC
5120 5714          JMP I IOTC
/

```

/

```

5121 0000 IOTD, 0000
5122 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
5123 1070 TAD SEND
5124 6130 6130 /FIELD SERVICE CHANGE
5125 5721 JMP I IOTD
5126 7402 EHLY2, HLT /SKIP TRAP, CLZE
/
5127 0000 IOTE, 0000
5130 6131 6131 /FIELD SERVICE CHANGE
5131 5727 JMP I IOTE
5132 2327 1S2 IOTE
5133 5727 JMP I IOTE
/
5134 0000 IOTF, 0000
5135 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
5136 1070 TAD SEND
5137 6132 6132 /FIELD SERVICE CHANGE
5140 5734 JMP I IOTF
5141 7402 EHLY3, HLT /SKIP TRAP, CLOE
/
5142 0000 IOTF1, 0000
5143 6132 6132 /FIELD SERVICE CHANGE
5144 5742 JMP I IOTF1
5145 7402 EHLY4, HLT /SKIP TRAP, CLOE
/
5146 0000 IOTG, 0000
5147 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
5150 1070 TAD SEND
5151 6133 6133 /FIELD SERVICE CHANGE
5152 5746 JMP I IOTG
5153 7402 EHLY5, HLT /SKIP TRAP, CLAB
/
5154 0000 IOTH, 0000
5155 6134 6134 /FIELD SERVICE CHANGE
5156 7410 SKP
5157 7402 EHLY6, HLT /SKIP TRAP, CLEN
5160 3071 DCA RECEV /SAVE OUTPUT FOR ERROR PRINTER
5161 1071 TAD RECEV
5162 5754 JMP I IOTH
/
5163 0000 IOTI, 0000
5164 6135 6135 /FIELD SERVICE CHANGE
5165 7410 SKP
5166 7402 EHLY7, HLT /SKIP TRAP, CLSA
5167 3071 DCA RECEV /SAVE OUTPUT FOR ERROR PRINTER
5170 1071 TAD RECEV
5171 5763 JMP I IOTI
/
5200 5200
/
5200 0000 IOTJ, 0000
5201 6136 6136 /FIELD SERVICE CHANGE
5202 7410 SKP
5203 7402 EHLY10, HLT /SKIP TRAP, CLBA
5204 3071 DCA RECEV /SAVE OUTPUT FOR ERROR PRINTER

```

```

5205 1071      TAD RECEV
5206 5600      JMP I IOTJ
/
5207 0000      IOTK,  0000
5210 6137      6137      /FIELD SERVICE CHANGE
5211 7410      SKP
5212 7402      EHLT11, HLT      /SKIP TRAP, CLCA
5213 3071      DCA RECEV      /SAVE OUTPUT FOR ERROR PRINTER
5214 1071      TAD RECEV
5215 5607      JMP I IOTK
/
5216 0000      SNDRV, 0000
5217 7041      CIA
5220 1070      TAD SEND
5221 7640      SZA CLA      /WAS SEND AND RECEV THE SAME ?
5222 2216      ISZ SNDRV
5223 5616      JMP I SNDRV
/
5224 0000      RANDOM, 0000
5225 1044      TAD REGE
5226 7004      RAL
5227 7430      SZL
5230 1410      TAD I 10
5231 3044      DCA REGE
5232 1044      TAD REGE
5233 5624      JMP I RANDOM
5234 0000      PIG05, 0000
5235 7300      CLA CLL      /CLEAR THE AC AND LINK
5236 1254      TAD PRET5
5237 3002      OCA 2      /SET FOR PI RETURN
5240 6001      ION
5241 7300      CLA CLL      /CLEAR THE AC AND LINK
5242 1076      TAD KREGC
5243 3042      DCA REGC
5244 4433      JMS I XIOTK      /READ THE COUNTER
5245 2042      ISZ REGC
5246 5245      JMP , -1
5247 2043      ISZ REGC
5250 5241      JMP , =7
5251 2234      ISZ PIG05
5252 6002      PIRET5, IOF      /DISABLE PROGRAM INTERRUPT
5253 5634      JMP I PIG05
/
5254 5252      PRET5, PIRET5
/
5255 0000      PIG01, 0000
5256 7300      CLA CLL      /CLEAR THE AC AND LINK
5257 1267      TAD PRET1
5260 3002      OCA 2      /SET FOR PI RETURN
5261 6001      ION      /ENABLE PROGRAM INTERRUPT
5262 4454      JMS I XISZ
5263 7410      SKP
5264 2255      PIRET1, ISZ PIG01
5265 6002      IOF      /DISABLE PROGRAM INTERRUPT
5266 5655      JMP I PIG01

```



```

/
5267 5264  /
          PRET1, PIRET1
/
5270 0000  PIG02, 0000
5271 7300  CLA CLL /CLEAR THE AC AND LINK
5272 1301  TAD PRET2
5273 3002  DCA 2 /SET FOR PI RETURN
5274 6001  ION
5275 4454  JMS I XISZ /WAIT
5276 2270  ISZ PIG02
5277 6002  PIRET2, IOF
5300 5670  JMP I PIG02
/
5301 5277  PRET2, PIRET2
/
5302 0000  SYNC, 0000
5303 4422  JMS I XIOTC
5304 5303  JMP ,=1
5305 4422  JMS I XIOTC
5306 5305  JMP ,=1
5307 5702  JMP I SYNC
/
5310 0000  ISZLOP, 0000
5311 7300  CLA CLL
5312 1113  TAD KTICPS
5313 3045  DCA REGF
5314 7001  IAC
5315 7000  NOP
5316 2043  ISZ REGD
5317 5314  JMP ,=3
5320 2045  ISZ REGF
5321 5314  JMP ,=5
5322 5710  JMP I ISZLOP
/
5323 0000  PIG03, 0000
5324 7300  CLA CLL /CLEAR THE AC AND LINK
5325 1335  TAD PRETC
5326 3002  DCA 2
5327 6001  ION
5330 7000  NOP
5331 7410  SKP
5332 2323  RETC, ISZ PIG03
5333 6002  IOF
5334 5723  JMP I PIG03
/
5335 5332  PRETC, RETC
/
5336 0000  PIG04, 0000
5337 7300  CLA CLL /CLEAR THE AC AND LINK
5340 1347  TAD PRETD
5341 3002  DCA 2
5342 6001  ION
5343 7000  NOP
5344 2336  ISZ PIG04
5345 6002  RETD, IOF

```

```

5346 5736          JMP I PIG04
/
5347 5345        PRETO, RETD
/
5350 0000        IOTS,  0000
5351 6132          6132
5352 6134          6134
5353 6132          6132
5354 6134          6134
5355 6132          6132
5356 6134          6134
5357 5750          JMP I IOTS
/
5360 0000        IOTS1, 0000
5361 6133          6133
5362 6136          6136
5363 6133          6133
5364 6136          6136
5365 6133          6133
5366 6136          6136
5367 5760          JMP I IOTS1
/
5370 0000        IOTS2, 0000
5371 6133          6133
5372 6137          6137
5373 6133          6133
5374 6137          6137
5375 6133          6133
5376 6137          6137
5377 5770          JMP I IOTS2
/
          5400      *5400
/
5400 0000        IOTS3, 0000
5401 6134          6134
5402 7040          CMA          /COMPLEMENT THE AC
5403 6130          6130
5404 7040          CMA          /COMPLEMENT THE AC
5405 6134          6134
5406 7040          CMA          /COMPLEMENT THE AC
5407 6130          6130
5410 7040          CMA          /COMPLEMENT THE AC
5411 6134          6134
5412 5600          JMP I IOTS3
/
5413 0000        CLOCK, 0000
5414 7604          LAS
5415 0007          AND K0007
5416 3075          DCA CLOCKS
5417 5613          JMP I CLOCK
/
/ROUTINE TO TYPE OCTAL NUMBERS
/ENTER WITH NUMBER IN AC AND LINK 2
/
5420 0000        OCTEL, 0000

```

```

5421 7006      RTL
5422 7006      RTL
5423 3041      DCA REGB      /SAVE NUMBER
5424 1130      TAD K7774
5425 3042      DCA REGC      /SET UP COUNTER
5426 1041      TAD REGB      /GET NUMBER
5427 0007      AND K0007
5430 1123      TAD K0260
5431 4507      JMS I XTYPE
5432 1041      TAD REGB      /GET NUMBER
5433 7006      RTL
5434 7024      RAL
5435 3041      DCA REGB      /SAVE THE REST
5436 2042      ISZ REGC
5437 5226      JMP ,*11
5440 5620      JMP I OCTEL

/
/ROUTINE FOR CRLF
/
5441 0000      CRLF, 0000
5442 7300      CLA CLL      /CLEAR THE AC AND LINK
5443 1134      TAD K0215
5444 4507      JMS I XTYPE
5445 1135      TAD K0212
5446 4507      JMS I XTYPE
5447 5641      JMP I CRLF

/ROUTINE TO TYPE CLOCK
/
5450 0000      POPR, 0000
5451 7300      CLA CLL      /CLEAR THE AC AND LINK
5452 1262      TAD KTADCK      /GET CLOCK TAD
5453 1075      TAD CLOCKS      /MAKE IT
5454 3255      DCA ,*1
5455 1262      TAD KTADCK      /MODIFIED BY TEST
5456 4504      JMS I XOCTEL      /PRINT NUMBER
5457 4506      JMS I XPRINT      /PRINT CLOCKS
5460 6026      FMES
5461 5650      JMP I POPR

/
5462 1263      KTADCK: TAD CLKNO
/
5463 0001      CLKNO, 0001
5464 0050      0050
5465 0050      0050
5466 0060      0060
5467 0500      0500
5470 5000      5000

/
/ROUTINE TO SORT ERROR MESSAGES
/
5471 0000      SORT, 0000
5472 7300      CLA CLL      /CLEAR THE AC AND LINK
5473 4501      JMS I XCRLF      /CRLF
5474 1473      TAD I ERROR      /GET MESSAGE POINTY
5475 3044      DCA REGE

```

```

5476 4505 JMS I XMESS /GO PRINT TEST * ADDRESS
5477 1444 TAD I REGE
5500 7012 RTR
5501 7012 RTR
5502 7012 RTR
5503 7012 RTR /MOVE IT TO BITS 8-11
5504 0127 AND K0017 /MASK 8-11
5505 3044 DCA REGE /SAVE POINTER
5506 7300 CLA CLL /CLEAR THE AC AND LINK
5507 1044 TAD REGE /GET POINTER
5510 1326 TAD KTADM
5511 3312 DCA ,+1
5512 1326 TAD KTADM /MODIFIED BY TEST
5513 3316 DCA ,+3 /STORE MESSAGE POINTER
5514 4501 JMS I XCRLF /CRLF
5515 4506 JMS I XPRINT /PRINT MESSAGE
5516 0000 0000 /MODIFIED MESSAGE POINTER
5517 7300 CLA CLL
5520 1044 TAD REGE /GET MESSAGE POINTER
5521 1132 TAD K7772 /IS IT GREATER THAN
5522 7620 SNL CLA
5523 5671 JMP I SORT
5524 4502 JMS I XREG
5525 5671 JMP I SORT

```

```

5526 1327 /
KTADM, TAD KTMX
/
KTMX, MES1
MES2
MES3
MES4
MES5
MES6
MES7
MES8
MES9
MES10
MES11

```

/ROUTINE TO PRINT TEST * ADDRESS

```

/
MESS, 0000
5542 0000
5543 7300 CLA CLL /CLEAR THE AC AND LINK
5544 4501 JMS I XCRLF /CRLF
5545 4506 JMS I XPRINT /GO PRINT TEST
5546 6046 TMS
5547 1473 TAD I ERROR /GET ERROR MESSAGE
5550 3043 DCA REGD /STORE MESSAGE POINTER
5551 1443 TAD I REGD
5552 0136 AND K0377 /MASK 4-11
5553 4504 JMS I XCTEL /GO PRINT NUMBER
5554 2043 ISZ REGD /UPDATE POINTER
5555 4506 JMS I XPRINT /GO PRINT STARTING ADDRESS
5556 6051 AMES
5557 1443 TAD I REGD

```

```

5560 4524 JMS I XCYTEL /GO PRINT NUMBER
5561 7300 CLA CLL /CLEAR THE AC AND LINK
5562 5742 JMP I MESS

```

/ROUTINE TO PRINT AC

```

5563 0000 PREG, 0000
5564 4501 JMS I XCRLF /CRLF
5565 4526 JMS I XPRINT /GO PRINT MESSAGE
5566 6067 SMES
5567 1070 TAO SEND /GET GOOD AC
5570 4504 JMS I XCYTEL /PRINT IT
5571 4526 JMS I XPRINT /PRINT BAD AC
5572 6077 SMES
5573 1071 TAO RECEV /GET BAD AC
5574 4504 JMS I XCYTEL /PRINT IT
5575 7300 CLA CLL /CLEAR THE AC AND LINK
5576 5763 JMP I PREG

```

5600 *5600

```

5600 0000 SETO, 0000
5601 1100 TAO JMP12 /GET JMP I 2
5602 3001 DCA 4 /SET FOR PI RETURN
5603 5600 JMP I SETO

```

/ROUTINE TO TYPE LISTING
/ENTER WITH JMS +1 EQUAL TO START OF LIST

```

5604 0000 PRINT, 0000
5605 7300 CLA CLL /CLEAR THE AC AND LINK
5606 1604 TAO I PRINT
5607 2204 ISZ PRINT /SET FOR RETURN +1
5610 3041 DCA REG0 /SAVE THE POINTER
5611 1441 TAO I REG0 /GET THE CHARACTER
5612 0012 AND K7700 /MASK BITS 0-5
5613 7450 SNA /END OF MESSAGE
5614 5240 JMP EXIT /YES, EXIT
5615 7500 SMA /IS AC MINUS
5616 7020 CML /NO, SET THE LINK
5617 7001 IAC
5620 7012 RTR
5621 7012 RTR
5622 7012 RTR
5623 4507 JMS I XTYPE /PRINT THE CHARACTER
5624 1441 TAO I REG0 /GET THE WORD
5625 0133 AND K0077 /MASK BITS 6-11
5626 7450 SNA /END OF MESSAGE
5627 5240 JMP EXIT /YES EXIT
5630 1125 TAO K3740 /NO, ADD A CONSTANT
5631 7500 SMA
5632 1124 TAO K4100
5633 1126 TAO K0240
5634 4507 JMS I XTYPE /TYPE THE CHARACTER
5635 2041 ISZ REG0 /UPDATE WORD LIST

```

```

5636 7300          CLA CLL          /CLEAR THE AC AND LINK
5637 5211          JMP PRINT+5
/
5640 7300  EXIT,  CLA CLL          /CLEAR THE AC AND LINK
5641 5624          JMP I PRINT      /YES EXIT
/
/ROUTINE TO WAIT FOR OVERFLOWS
/
5642 0000  XWAIT, 0000
5643 3011          DCA SAVAC          /SAVE THE AC
5644 7344          CLA CLL CMA RAL
5645 1242          TAD XWAIT
5646 3242          DCA XWAIT          /SET FOR RETURN ADDRESS
5647 2041          ISZ REGB
5650 5256          JMP RETURN
5651 2045          ISZ REGF
5652 5256          JMP RETURN
5653 7325          CLA CLL CML IAC RAL
5654 1242          TAD XWAIT
5655 3242          DCA XWAIT          /UPDATE FOR ERROR RETURN
5656 1011  RETURN, TAD SAVAC
5657 5642          JMP I XWAIT
/
5660 0000  SWLAS, 0000
5661 7604          LAS
5662 0142          AND K0010
5663 7640          SZA CLA          /CHECK FOR EXTERNAL CLOCK SCOPE LOOP
5664 5325          JMP CLKIN          /ENTER SCOPE LOOP
5665 7604          LAS
5666 0140          AND K0020          /CHECK FOR EXTERNAL PULSE SCOPE LOOP
5667 7640          SZA CLA
5670 5313          JMP EXTER          /ENTER SCOPE LOOP
5671 7340          CLA CLL CMA          /AC TO 7777
5672 3113          DCA K71CPS
5673 7604          LAS
5674 0114          AND K0007
5675 7640          SZA CLA
5676 5301          JMP ,+3
5677 1111          TAD KPRMTI
5700 3113          DCA K71CPS
5701 7604          LAS          /GET HIS SWITCHES
5702 7004          RAL          /GET BIT 1
5703 7710          SPA CLA
5704 5660          JMP I SWLAS          /TEST SCHMITT
5705 2260          ISZ SWLAS
5706 7604          LAS          /GET HIS SWITCHES
5707 7710          SPA CLA
5710 5060          JMP I SWLAS          /TEST DK8-EP
5711 2260          ISZ SWLAS
5712 5060          JMP I SWLAS          /YES? DK8-EA OR DK8-EC
/
5713 7340  EXTER,  CLA CLL CMA
5714 4427          JMS I X10TC          /IOT 6133, CLAD
5715 7300          CLA CLL
5716 1137          TAD K0040

```

```

5717 1147      TAD K0800      /GET ENABLES
5720 4425      JMS I XI0YF     /IOT 8132, CLOE
5721 4424      JMS I XI0YE     /IOT 8131, CLSK
5722 5321      JMP ,=1        /WAIT FOR OVERFLOW
5723 6007      6007         /CAF OR CLEAR THE WORLD
5724 5313      JMP EXTER      /CONTINUE WITH SCOPE LOOP

```

```

/
5725 7340      CLKIN,  CLA CLL CMA /AC TO 7777
5726 4427      JMS I XI0YB     /IOT 8133, CLAB
5727 7300      CLA CLL
5730 1013      TAD K0100      /GET ENABLES
5731 4426      JMS I XI0YF1   /IOT 8132, CLOE
5732 4424      JMS I XI0YE     /IOT 8131, CLSK
5733 5332      JMP ,=1        /WAIT FOR OPERATOR
5734 6007      6007         /CAF OR CLEAR THE WORLD
5735 1026      TAD K0207
5736 4507      JMS I XTYPE    /TTY SIGNAL
5737 5325      JMP CLKIN     /LOOP

```

```

/
5740 0000      PASS,   0000
5741 4501      JMS I XCRLF    /CRLF
5742 4506      JMS I XPRINT  /PRINT MESSAGE
5743 6014      PHES
5744 6007      6007
5745 5740      JMP I PASS

```

```

/
5746 0000      GTAD,   0000
5747 1075      TAD CLOCKS /GET SELECTED CLOCK
5750 1354      TAD CLTAD
5751 3746      DCA I GTAD
5752 2346      ISE GTAD
5753 5746      JMP I GTAD

```

```

/
5754 5755      CLTAD,  CLTAD *1
5755 6000      6000
5756 1612      1612
5757 4776      4776
5760 5367      5367
5761 7306      7306
5762 7747      7747
5763 4000      4000
5764 1527      1527
5765 4552      4552
5766 5217      5217
5767 7276      7276
5770 7741      7741

```

```

/
5771 0000      TIMCLK, 0000
5772 7604      LAS
5773 0114      AND K6007
5774 7650      SNA CLA
5775 1166      TAD PATCH
5776 1012      TAD K7700
5777 5771      JMP I TIMCLK

```

/

PAL10

V141

27-JUL-71

19143 PAGE 1469

6000	0413	OKMES, TEXT ?DK8E CLOCKS DIAGNOSTIC?
6001	7025	
6002	4003	
6003	1417	
6004	2313	
6005	2340	
6006	2411	
6007	2127	
6010	1617	
6011	2324	
6012	1123	
6013	0000	
6014	0413	PMES, TEXT ?DK8E PASS COMPLETE?
6015	7025	
6016	4020	
6017	0123	
6020	2340	
6021	0317	
6022	1520	
6023	1405	
6024	2405	
6025	0000	
6026	4003	FMES, TEXT ? CPS CLOCK SELECTED BY OPERATOR?
6027	2023	
6030	4003	
6031	1417	
6032	0313	
6033	4023	
6034	0514	
6035	0503	
6036	2405	
6037	0440	
6040	0231	
6041	4017	
6042	2005	
6043	2201	
6044	2417	
6045	2200	
6046	2405	TMES, TEXT ?TEST ?
6047	2324	
6050	4000	
6051	4026	AMES, TEXT ? FAILED, STARTING ADDRESS ?
6052	0111	
6053	1405	
6054	0454	
6055	4023	
6056	2401	
6057	2224	
6060	1116	
6061	0740	
6062	2124	
6063	2422	
6064	0523	
6065	2340	
6066	0000	

6067 2410
6070 0540
6071 0717
6072 1704
6073 4001
6074 0340
6075 7540
6076 0000
6077 4001
6100 1604
6101 4002
6102 0104
6103 4001
6104 0340
6105 7540
6106 0000
6107 0314
6110 1703
6111 1340
6112 2313
6113 1120
6114 4006
6115 0111
6116 1405
6117 0454
6120 4016
6121 1740
6122 2313
6123 1120
6124 4005
6125 3020
6126 0503
6127 2405
6130 0400
6131 0314
6132 1703
6133 1340
6134 2313
6135 1120
6136 4006
6137 0111
6140 1405
6141 0454
6142 4023
6143 1311
6144 2040
6145 0530
6146 2005
6147 0524
6150 0504
6151 0020
6152 2022
6153 1707
6154 2201
6155 1540

GMES, TEXT TYPE GOOD AC = ?

BMES, TEXT ? AND BAD AC = ?

MES1, TEXT ?CLOCK SKIP FAILED, NO SKIP EXPECTED?

MES2, TEXT ?CLOCK SKIP FAILED, SKIP EXPECTED?

MES3, TEXT ?PROGRAM INTERRUPT FAILED, NO INTERRUPT EXPECTED?

6156 1116
6157 2405
6160 2222
6161 2520
6162 2440
6163 0601
6164 1114
6165 0504
6166 5440
6167 1617
6170 4011
6171 1624
6172 0522
6173 2225
6174 2024
6175 4005
6176 3020
6177 0503
6200 2405
6201 0400
6202 2022
6203 1707
6204 2201
6205 1540
6206 1116
6207 2405
6210 2222
6211 2520
6212 2440
6213 0601
6214 1114
6215 0504
6216 5440
6217 1116
6220 2405
6221 2222
6222 2520
6223 2440
6224 0530
6225 2005
6226 0324
6227 0504
6230 0000
6231 0314
6232 1703
6233 1340
6234 1725
6235 2420
6236 2524
6237 4006
6240 0111
6241 1405
6242 0404
6243 4003
6244 1417

MES4, TEXT ?PROGRAM INTERRUPT FAILED, INTERRUPT EXPECTED?

MES5, TEXT ?CLOCK OUTPUT FAILED, CLOCK FREQUENCY FAST?

6245 0313
6246 4006
6247 2205
6250 2125
6251 0516
6252 0331
6253 4006
6254 0123
6255 2400
6256 0314
6257 1703
6260 1340
6261 1725
6262 2420
6263 2524
6264 4006
6265 0111
6266 1405
6267 0454
6270 4003
6271 1417
6272 0313
6273 4006
6274 2205
6275 2125
6276 0516
6277 0331
6300 4023
6301 1417
6302 2700
6303 2410
6304 0540
6305 0103
6306 4027
6307 0123
6310 4003
6311 1001
6312 1607
6313 0504
6314 4002
6315 3140
6316 0140
6317 0314
6320 1703
6321 1340
6322 1117
6323 2400
6324 0314
6325 1703
6326 1340
6327 0225
6330 0606
6331 0522
6332 4022
6333 0507

MES6, TEXT ?CLOCK OUTPUT FAILED, CLOCK FREQUENCY SLOW?

MES7, TEXT ?THE AC WAS CHANGED BY A CLOCK 10Y?

MES8, TEXT ?CLOCK BUFFER REGISTER AND AC TRANSFER FAILED?

6334 1123
6335 2405
6336 2240
6337 0116
6340 0440
6341 0103
6342 4024
6343 2201
6344 1623
6345 0605
6346 2240
6347 0601
6350 1114
6351 0504
6352 0000
6353 0314
6354 1703
6355 1340
6356 0317
6357 2516
6360 2405
6361 2240
6362 2205
6363 0711
6364 2324
6365 0522
6366 4001
6367 1604
6370 4001
6371 0340
6372 2422
6373 0116
6374 2306
6375 0522
6376 4006
6377 0111
6400 1405
6401 0400
6402 0314
6403 1703
6404 1340
6405 0516
6406 0102
6407 1405
6410 4022
6411 0507
6412 1123
6413 2405
6414 2240
6415 0116
6416 0440
6417 0103
6420 4024
6421 2201
6422 1623

MES9, TEXT ?CLOCK COUNTER REGISTER AND AC TRANSFER FAILED?

MES10, TEXT ?CLOCK ENABLE REGISTER AND AC TRANSFER FAILED?

6423 0625
6424 2240
6425 0621
6426 1114
6427 0504
6430 0000
6431 0314
6432 1703
6433 1340
6434 2324
6435 0124
6436 2523
6437 4022
6440 0507
6441 1123
6442 2405
6443 2240
6444 0116
6445 0440
6446 0103
6447 4024
6450 2201
6451 1623
6452 0609
6453 2240
6454 0501
6455 1114
6456 0504
6457 0000

MSG11, TEXT RELOCK STATUS REGISTER AND AC TRANSFER FAILED?

AMES	6051	K0017	0127	LOOP	0177	SE70	5500
AUTO10	0010	K0020	0140	MES1	0177	SHOPIF	5748
REGIN	0200	K0040	0137	MES10	0402	XND17	0715
BELL	5046	K0077	0133	MES11	0431	SOBT	5471
BONEAC	0215	K0100	0013	MES2	0131	BWLAS	5600
BMES	6077	K0200	0015	MES3	0152	SYNO	0302
CLKIN	5725	K0207	0006	MES4	0202	T113A	1007
CLKNO	5463	K0212	0135	MES5	0231	T113B	1148
CLOCK	5413	K0215	0134	MES6	0256	T113C	1073
CLOCKS	0075	K0240	0126	HLS7	0303	T1140	1064
CLRREG	5069	K0260	0123	PLS8	0324	T11A	0071
CLTAD	5754	K0300	0145	ML17	0353	T120A	1751
CRLF	5441	K0377	0136	MES9	0502	T121A	1706
DKMES	6000	K0400	0116	NERR0	0000	T122A	2014
ENLT1	5034	K0500	0146	NERR0R	0072	T122B	1775
ENLT10	5203	K0600	0147	OCTEL	0020	T123A	2043
ENLT11	5212	K0700	0150	OUT	0015	T123B	2024
ENLT2	5126	K1000	0144	OVER2	0021	T124A	2072
ENLT3	5141	K2000	0143	OVER2A	0002	T124B	2053
ENLT4	5145	K2525	0010	PASS	0740	T125A	2120
ENLT5	5153	K3000	0120	PATCH	0166	T125B	2102
ENLT6	5157	K3740	0125	PIG01	0255	T126A	2147
ENLT7	5106	K4000	0014	PIG02	0270	T126B	2126
ERR0	5020	K4100	0124	PIG03	0323	T127A	2000
ERROR	0073	K5000	0121	PIG04	0336	T12A	0000
EXIT	5640	K5252	0017	PIG05	0234	T130A	2020
EXTER	0713	K6000	0117	PIRET1	0264	T133A	2506
FMES	6026	K6007	0114	PIRET2	0277	T133B	2273
GMES	6067	K7000	0141	PIRETS	0252	T147A	2555
GTAD	5746	K7400	0112	PMES	0014	T147B	2037
IN	5043	K7700	0012	POPR	0450	T150A	2603
IOTA	5102	K7770	0122	PRE0	0063	T150B	2565
IOTB	5107	K7772	0132	PRE1	0007	T151A	2631
IOTC	5114	K7773	0131	PRE2	0001	T151B	2613
IOTD	5121	K7774	0130	PRE3	0004	T152A	2657
IOTE	5127	KPRMT1	0111	PRE4	0000	T152B	2641
IOTF	5134	KREGC	0076	PRE5	0047	T153A	0706
IOTF1	5142	KTICPS	0113	PRINT	0000	T153B	2667
IOTG	5146	KTA	0151	RANDOM	0224	T154A	2733
IOTH	5154	KYA1	0152	RANDY	0050	T154B	2715
IOTI	5163	KYADCK	0462	RECEV	0071	T172A	3254
IOTJ	5200	KTADM	0026	RECA	0040	T172A1	0257
IOTK	5207	KTB	0153	RECB	0041	T172B	3244
IOTS	5350	KTB1	0154	RECC	0042	T172B1	3240
IOTS1	5360	KTC	0155	RECD	0043	T175A	3303
IOTS2	5370	KYC1	0156	RECE	0044	T175A1	3300
IOTS3	5400	KYC2	0157	REGF	0045	T173B	3073
ISZLOP	5310	KTD	0160	RETC	0332	T173B1	3267
JMP12	0100	KTD1	0161	RETO	0345	T174A	3036
K0003	0115	KTE	0162	RETURN	0656	T174A1	3041
K0007	0007	KTEL	0163	SAVAC	0011	T174B	3328
K0014	0142	KTMV	0047	SENO	0070	T174B1	3323

1301
 1302
 1303
 1304
 1305
 1306
 1307
 1308
 1309
 1310
 1311
 1312
 1313
 1314
 1315
 1316
 1317
 1318
 1319
 1320
 1321
 1322
 1323
 1324
 1325
 1326
 1327
 1328
 1329
 1330
 1331
 1332
 1333
 1334
 1335
 1336
 1337
 1338
 1339
 1340
 1341
 1342
 1343
 1344
 1345
 1346
 1347
 1348
 1349
 1350
 1351
 1352
 1353
 1354
 1355
 1356
 1357
 1358
 1359
 1360
 1361
 1362
 1363
 1364
 1365
 1366
 1367
 1368
 1369
 1370
 1371
 1372
 1373
 1374
 1375
 1376
 1377
 1378
 1379
 1380
 1381
 1382
 1383
 1384
 1385
 1386
 1387
 1388
 1389
 1390
 1391
 1392
 1393
 1394
 1395
 1396
 1397
 1398
 1399
 1400

1301
 1302
 1303
 1304
 1305
 1306
 1307
 1308
 1309
 1310
 1311
 1312
 1313
 1314
 1315
 1316
 1317
 1318
 1319
 1320
 1321
 1322
 1323
 1324
 1325
 1326
 1327
 1328
 1329
 1330
 1331
 1332
 1333
 1334
 1335
 1336
 1337
 1338
 1339
 1340
 1341
 1342
 1343
 1344
 1345
 1346
 1347
 1348
 1349
 1350
 1351
 1352
 1353
 1354
 1355
 1356
 1357
 1358
 1359
 1360
 1361
 1362
 1363
 1364
 1365
 1366
 1367
 1368
 1369
 1370
 1371
 1372
 1373
 1374
 1375
 1376
 1377
 1378
 1379
 1380
 1381
 1382
 1383
 1384
 1385
 1386
 1387
 1388
 1389
 1390
 1391
 1392
 1393
 1394
 1395
 1396
 1397
 1398
 1399
 1400

1301
 1302
 1303
 1304
 1305
 1306
 1307
 1308
 1309
 1310
 1311
 1312
 1313
 1314
 1315
 1316
 1317
 1318
 1319
 1320
 1321
 1322
 1323
 1324
 1325
 1326
 1327
 1328
 1329
 1330
 1331
 1332
 1333
 1334
 1335
 1336
 1337
 1338
 1339
 1340
 1341
 1342
 1343
 1344
 1345
 1346
 1347
 1348
 1349
 1350
 1351
 1352
 1353
 1354
 1355
 1356
 1357
 1358
 1359
 1360
 1361
 1362
 1363
 1364
 1365
 1366
 1367
 1368
 1369
 1370
 1371
 1372
 1373
 1374
 1375
 1376
 1377
 1378
 1379
 1380
 1381
 1382
 1383
 1384
 1385
 1386
 1387
 1388
 1389
 1390
 1391
 1392
 1393
 1394
 1395
 1396
 1397
 1398
 1399
 1400

1301
 1302
 1303
 1304
 1305
 1306
 1307
 1308
 1309
 1310
 1311
 1312
 1313
 1314
 1315
 1316
 1317
 1318
 1319
 1320
 1321
 1322
 1323
 1324
 1325
 1326
 1327
 1328
 1329
 1330
 1331
 1332
 1333
 1334
 1335
 1336
 1337
 1338
 1339
 1340
 1341
 1342
 1343
 1344
 1345
 1346
 1347
 1348
 1349
 1350
 1351
 1352
 1353
 1354
 1355
 1356
 1357
 1358
 1359
 1360
 1361
 1362
 1363
 1364
 1365
 1366
 1367
 1368
 1369
 1370
 1371
 1372
 1373
 1374
 1375
 1376
 1377
 1378
 1379
 1380
 1381
 1382
 1383
 1384
 1385
 1386
 1387
 1388
 1389
 1390
 1391
 1392
 1393
 1394
 1395
 1396
 1397
 1398
 1399
 1400

TSY76	1439
TSY77	1451
TYPE	5056
XBELL	0110
XCLOCK	0074
XCLREG	0060
XCRLF	0101
XCRS1	0171
XCRS2	0172
XCRS3	0173
XCRS4	0174
XCRS5	0175
XDKBEP	0083
XGETM	0167
XGTAD	0067
XIOTA	0020
XIOTB	0021
XIOTC	0022
XIOTD	0023
XIOTE	0024
XIOTF	0025
XIOTF1	0026
XIOTG	0027
XIOTH	0030
XIOTI	0031
XIOTJ	0032
XIOTK	0033
XIOTS	0034
XIOTS1	0035
XIOTS2	0036
XIOTS3	0037
XISZ	0054
XLAS	0066
XMESS	0105
XMITT	0064
XMITT1	0065
XOCTEL	0104
XOPR	0165
XPASS	0170
XPIG01	0047
XPIG02	0050
XPIG03	0051
XPIG04	0052
XPIG05	0053
XPRINT	0106
XREG	0102
XSET0	0164
XSNDRV	0056
XSORT	0103
XSYNC	0057
XTYPE	0107
XWAIT	5642

CALLS: 1391 47804488 10317 1000 2

SYMBOLS GENERATED: 0

LINKS GENERATED: 7

RUN-TIME: 41 SECONDS

3X CORE USED

