

REVISION HISTORY			VARIATIONS FOR THIS ASSY,		FIRST USED ON:	DIGITAL EQUIPMENT CORPORATION MAYNARD, MASSACHUSETTS					
CHK	ECO NO	REV			M9312	TITLE					
					MADE BY: B CRAMM	DATE: 1 AUG 78	ROM LISTING BOOTSTRAP				
					CHECKED: N POLLITT	DATE: 17 AUG 78					
					DSN,ENG.: B GIST	DATE: 1 AUG 78	SIZE	CODE	DOCUMENT NUMBER	REV	
					PROD.: D PETERSON	DATE: 3 AUG 78	K	SP	M9312-0-7	A	
					RESP,ENG.: E CROCKER	DATE: 1 AUG 78	ASSY. #:			EDIT NO:	11

"THIS DRAWING AND SPECIFICATIONS HEREIN, ARE THE PROPERTY OF DIGITAL EQUIPMENT CORPORATION AND SHALL NOT BE REPRODUCED OR COPIED OR USED IN WHOLE OR IN PART AS THE BASIS FOR THE MANUFACTURE OR SALE OF ITEMS WITHOUT WRITTEN PERMISSION. COPYRIGHT 1976. DIGITAL EQUIPMENT CORPORATION"

## TABLE OF CONTENTS

PART #	MNEMON- IC	FIRST DEVICE IN ROM	MNEMON- IC	SECOND DEVICE IN ROM	PAGE #
760A9	PR	PC05	TT	LO SPD RDR	3
756A9	DK	RK03/05	DT	TU55/56	5
752A9	DM	RK06/07	NA	NA	8
751A9	DL	RL01	NA	NA	10
759A9	DS	RS03/04	NA	NA	12
753A9	DX	RX01	NA	NA	13
811A9	DY	RX02	NA	NA	15
758A9	MT	TU10/E10,TS03	NA	NA	17
757A9	MM	TU16/E16 TM02/3	NA	NA	19
761A9	CT	TU60	NA	NA	21
755A9	DP	RP02/03	DB	RP04/5/6 RM02/3	23
764A9	MS	TS04	NA	NA	25
765A9	DD	TU58	NA	NA	28
862A9	XM	COMM	NA	NA	30
863A9			NA	NA	33
864A9			NA	NA	34
865A9	XU	COMM	NA	NA	36
866A9			NA	NA	39
867A9			NA	NA	40
868A9	XW	COMM	NA	NA	43
869A9			NA	NA	46
870A9			NA	NA	47

## M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE PC11 OPTION(S)

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y34.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y36.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

.SBTTL TTY BOOT  
 .SBTTL ;PC, DL BOOT

000000	050122		HSR:	.ASCII	"RP"		;HIGH SPEED READER BOOT.
000002	000026			.WORD	<HSRE-.+2>		;OFFSET TO NEXT BOOT.
000004	000261			SEC			;ENTRY
000006	012700	000000		MOV	#0,R0		;ENTRY POINT TO NO DIAG.
000012	012701	177550	HSRM:	MOV	#HSRCR,R1		;LOAD CSR ADDR. INTO R1.
000016	010704		CFUDGE:	MOV	PC,R4		;ENTRY POINT
000020	103064			BCC	BDIAG		;GO DO DIAG.
000022	000412			BR	LOAD		
000024	173000			.WORD	MRESERVED		
000026	000340		HSRE:	.WORD	RESERVED		
000030	052124		TT:	.ASCII	"TT"		;LOW SPEED READER.
000032	000146			.WORD	<TTE-.+2>		;OFFSET TO NEXT BOOT.
000034	000261			SEC			
000036	012700	000000		MOV	#0,R0		
000042	012701	177560	TTM:	MOV	#TTCR,R1		;LOAD CSR ADDR. INTO R1.
000046	000763			BR	CFUDGE		
000050	012705	160000	LOAD:	MOV	#160000,R5		
000054	012703	000004		MOV	#4,R3		;PUT ERRVEC INTO R3
000060	010723			MOV	PC,(R3)+		;PUT RETURN ADDR IN ERRVEC
000062	005013			CLR	(R3)		
000064	012706	000502	1s:	MOV	#502,SP		
000070	010145			MOV	R1,-(R5)		;TIMES OUT UNTIL RIGHT ADDR!
000072	042705	000032		BIC	#32,R5		
000076	012725	016701		MOV	#16701,(5)+		
000102	012725	000026		MOV	#26,(5)+		
000106	012725	012702		MOV	#12702,(5)+		
000112	012725	000352		MOV	#352,(5)+		
000116	012725	005211		MOV	#5211,(5)+		
000122	012725	105711		MOV	#105711,(5)+		
000126	012725	100376		MOV	#100376,(5)+		
000132	012725	116162		MOV	#116162,(5)+		
000136	012725	000002		MOV	#2,(5)+		
000142	010515			MOV	R5,(5)		
000144	105025			CLRB	(5)+		
000146	005205			INC	R5		

```

000150 012725 005267      MOV      #5267,(5)+
000154 012725 177756      MOV      #177756,(5)+
000160 012725 000765      MOV      #765,(5)+
000164 010115      MOV      R1,(5)
000166 000165 177746      JMP      -32(R5)      ;GO DO BOOT ADDR.=X7744
000172 000137 165564      BDIAG:  JMP      @#DIAG
000176 154747      TTE:    .WORD 154747      ;CRC WORD FOR LAST 63. WORDS.
000001      .END

```

## SYMBOL TABLE

```

BDIAG  000172
CRCWD  = 000000
HSRE   000026
MRESER= 173000
RK06CR= 177440
RS03CR= 172040
R0     =%000000
R4     =%000004
SP     =%000006
TTM    000042
.      = 000200

BIT8   = 000400
DIAG   = 165564
HSRM   000012
PC     =%000007
RL01CR= 174400
RS04CR= 172040
R1     =%000001
R5     =%000005
TT     000030
TU10CR= 172522

BIT9   = 001000
HSR    000000
INITSW= 173024
RESERV= 000340
RP03CR= 176714
RX01CR= 177170
R2     =%000002
R6     =%000006
TTCR   = 177560
TU16CR= 172440

CFUDGE 000016
HSRCR  = 177550
LOAD   000050
RK05CR= 177404
RP04CR= 176700
RX02CR= 177170
R3     =%000003
R7     =%000007
TTE    000176
TU56CR= 177342

```

.TITLE M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE RK05 TU56 OPTION(S).

.SBTTL RK05 BOOT

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

.SBTTL TU56 BOOT

THIS ROM WILL BOOT THE TU56 OPTION(S).  
 TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y34.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y36.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

.SBTTL ;RK05, TU56 BOOT  
 ;CMNDS "DK", "DT"

;RK05 BOOT. THIS BOOT READS DISK ADDR. 0,0 ON ERROR I.E. DRIVE  
 ; NOT READY, NO DISK, ETC, A SYSTEM INIT. IS ISSUED AND  
 ; THE BOOT IS RETRIED UNTIL A GOOD BOOT OCCURS  
 ; OR THE BOOT IS HALTED.

;TU56 BOOT. THIS BOOT READS BLOCK 0 FROM THE DEC TAPE ON ERROR  
 ; WE ISSUE A A SYSTEM INIT. THEN TRY TO REBOOT.  
 ; THIS RETRY WILL OCCUR UNTIL WE SUCCESSFULLY BOOT,  
 ; OR THE BOOT IS HALTED.  
 ;

```

000000 042113
000002 000026
000004 000261
000006 012700 000000
000012 012701 177404
000016 010704
000020 103057
000022 000426
000024 173000
000026 000340
000030 042124
000032 000146
000034 000261
000036 012700 000000
000042 012701 177342
    
```

```

RK05:  .ASCII  "KD"           ;CMND "DK" RK05 BOOT.
        .WORD  <RK05E-.+2>    ;OFFSET TO NEXT DEVICE BOOT.
        SEC    ;UNIT 0, NO DIAG. ENTRY POINT.
RK05M: MOV    #0,R0           ;UNIT 0, RUN DIAG. ENTRY POINT
        MOV    #RK05CR,R1    ;LOAD CSR ADDR. INTO R1.
        MOV    PC,R4         ;ENTRY FROM CONSOLE EMULATOR.
        BCC   BDIAG         ;EXERCISE DIAG. IF C=0
        BR    RK05B         ;GOTO RK05 BOOT.
        .WORD  MRESERVED
RK05E: .WORD  RESERVED
TU56:  .ASCII  "TD"           ;CMND "DT" TU56 BOOT.
        .WORD  <TU56E-.+2>    ;OFFSET TO NEXT DEVICE BOOT.
        SEC    ;UNIT 0, NO DIAG. ENTRY POINT.
        MOV    #R0,R0        ;UNIT 0, RUN DIAG. ENTRY POINT.
TU56M: MOV    #TU56CR,R1    ;LOAD CSR ADDR. INTO R1
    
```

```

000046 010704          MOV    PC,R4          ;ENTRY FROM CONSOLE EMULATOR.
000050 103043          BCC    BDIAG         ;EXERCISE DIAG. IF C=0
000052 010003          MOV    R0,R3        ;FIX UNIT NUMBER IN R3
000054 000303          SWAB   R3           ;TU56 BOOT.
000056 010311          MOV    R3,(R1)      ;FIX UNIT NUMBER IN DEVICE.
000060 052711 004003    BIS    #4003,(R1)   ;SET REWIND
000064 005711          1$:  TST    (R1)      ;WAIT FOR END ZONE ERROR
000066 100376          BPL    1$
000070 005761 177776    TST    -2(R1)      ;LOOK FOR ERROR.
000074 010311          MOV    R3,(R1)      ;CLEAR DEVICE.
000076 000410          BR     CBOOT        ;GOTO COMMON BOOT.
000100 010003          RK05B: MOV    R0,R3
000102 000241          CLC
000104 006003          ROR    R3           ;FIX UNIT NUMBER FOR DEVICE.
000106 006003          ROR    R3
000110 006003          ROR    R3
000112 006003          ROR    R3
000114 010361 000006    MOV    R3,6(R1)     ;SET UNIT NUMBER IN DEVICE
000120 012761 177000 000002  CBOOT: MOV    #-512.,2(R1) ;COMMON BOOT, SET WORD COUNT.
000126 052703 000005    BIS    #5,R3       ;PICK UP READ WORD.
000132 010311          MOV    R3,(1)      ;SET INTO DEVICE CSR.
000134 105711          1$:  TSTB   (R1)      ;WAIT FOR DEVICE DONE.
000136 100376          BPL    1$
000140 005711          TST    (R1)        ;TEST FOR DEVICE ERROR
000142 100003          BPL    GBOOT
000144 000005          ERROR: RESET      ;ON ERROR, INITIALIZE SYSTEM
000146 000164 000002    JMP    2(R4)        ;RETURN TO START OF BOOT.
000152 042711 000377    GBOOT: BIC    #377,(R1) ;NO ERROR, CLEAR DEVICE
000156 005007          CLR    R7          ;GOTO SECONDARY MONITOR ADDR. OR
000160 000137 165564    BDIAG: JMP    @#DIAG   ;GOTO DIAGNOSTIC IF C=0
                                ;RETURNS BASED ON ADDR. IN R4
                                ;*****
                                ;ENTRY POINT FOR RK05 UNIT #2,NO DIAGS RUN.
                                ;*****
000164 000261          SEC
                                ;*****
                                ;ENTRY POINT FOR RK05 UNIT #2, RUN DIAGS.
                                ;*****
000166 012700 000002    RK052: MOV    #2,R0          ;ENTRY POINT FOR RK05 BOOT UNIT 2
000172 000707          BR     RK05M
                                . =176
000176 124650          TU56E: .WORD 124650      ;CRC WORD FOR LAST 63. WORDS.
                                .END
000001

```

## SYMBOL TABLE

BDIAG	000160	BIT8	= 000400	BIT9	= 001000	CBOOT	000120
CRCWD	= 000000	DIAG	= 165564	ERROR	000144	GBOOT	000152
HSRCR	= 177550	INITSW	= 173024	MRESER	= 173000	PC	= %000007
RESERV	= 000340	RK05	000000	RK05B	000100	RK05CR	= 177404
RK05E	000026	RK05M	000012	RK052	000166	RK06CR	= 177440
RL01CR	= 174400	RP03CR	= 176714	RP04CR	= 176700	RS03CR	= 172040
RS04CR	= 172040	RX01CR	= 177170	RX02CR	= 177170	R0	= %000000
R1	= %000001	R2	= %000002	R3	= %000003	R4	= %000004
R5	= %000005	R6	= %000006	R7	= %000007	SP	= %000006
TTCR	= 177560	TU10CR	= 172522	TU16CR	= 172440	TU56	000030
TU56CR	= 177342	TU56E	000176	TU56M	000042	.	= 000200

M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE RK06/RK07 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

.SBTTL RK06/RK07 BOOT

```
;RK06 BOOT.      THIS BOOT BOOTS EITHER THE RK06 OR RK07 DRIVES.
;                IT FIRST TRIES TO BOOT SELECTED DRIVE AS A RK06.
;                IF WE GET A DRIVE TYPE ERROR AS A RESULT OF THAT TRY,
;                WE SET THE RK07 DRIVE TYPE IN THE RK611 CSR. AND TRY
;                TO BOOT THE SELECTED DRIVE AS A RK07.
;
;                NOTE: DRIVE TYPE IS LEFT IN THE
;                CSR WHEN WE LEAVE THIS BOOT.
```

```
.SBTTL ;RK06/RK07
;CMND = "DM"
```

000000	042115			RK06:	.ASCII	"MD"		;ID OF RK06,RK07 BOOT.
000002	000176				.WORD	<RK06E-.+2>		;OFFSET TO NEXT DEVICE BOOT.
000004	000261				SEC			
000006	012700	000000			MOV	#0,R0		
000012	012701	177440		RK06M:	MOV	#RK06CR,R1		;LOAD DEVICE ADDR. INTO R1.
000016	010704				MOV	PC,R4		
000020	103055				BCC	BDIAG		
000022	000402				BR	RK06B		
000024	173000				.WORD	MRESERVED		
000026	000340				.WORD	RESERVED		
000030	010061	000010		RK06B:	MOV	R0,10(R1)		
000034	012711	000003			MOV	#3,(R1)		
000040	105711			1\$:	TSTB	(R1)		
000042	100376				BPL	1\$		
000044	005711				TST	(R1)		
000046	100015				BPL	3\$		;NO ERROR-THEN PROCEED.
000050	032761	000040	000014		BIT	#40,14(R1)		;THERE WAS AN ERROR,PUT DRIVE TYPE?
000056	001426				BEQ	ERROR		;NO,INIT AND TRY AGAIN.
000060	000005				RESET			;YES INIT AND TRY RK07 TYPE DRIVE.
000062	010061	000010			MOV	R0,10(R1)		;SET DRIVE NUMBER.
000066	012711	002003			MOV	#002003,(R1)		;SELECT RK07,PAC.
000072	105711			2\$:	TSTB	(R1)		;WAIT FOR READY.
000074	100376				BPL	2\$		
000076	005711				TST	(R1)		;LOOK FOR AN ERROR
000100	100415				BMI	ERROR		;IF ERROR INIT TRY AGAIN.
000102				3\$:				;REGISTER INTO ITSELF.
000102	012761	177000	000002	CBOOT:	MOV	#-512.,2(R1)		;LOAD WORD COUNT
000110	011103				MOV	(R1),R3		;READ DEVICE
000112	042703	000377			BIC	#377,R3		;STRIP.



```

000116 052703 000021          BIS      #21,R3          ;ADD READ CODE
000122 010311                MOV      R3,(R1)        ;START DEVICE
000124 105711          1$:  TSTB     (R1)          ;WAIT FOR READY
000126 100376                BPL      1$
000130 005711                TST      (1)           ;ANY ERROR?
000132 100003                BPL      GBOOT         ;NO ERROR, EXIT
000134 000005          ERROR: RESET      ;INITIALIZE SYSTEM
000136 000164 000002        JMP      2(4)          ;RETRY BOOT.
000142                GBOOT:
000142 005007          START: CLR      PC          ;STARTS LOADED CODE.

;*****
;ENTRY POINT FOR RK06,RK07 UNIT #1, NO DIAG.
;*****
000144 000261                SEC
;*****
;ENTRY POINT FOR RK06,RK07 UNIT #1, RUN DIAG.
;*****
000146 012700 000001        MOV      #1,R0
000152 000717                BR       RK06M
000154 000137 165564        BDIAG:  JMP      @#DIAG
                                . =176
000176 077161          RK06E: .WORD    077161      ;CRC WORD FOR LAST 63. WORDS.
                                .END

```

SYMBOL TABLE

BDIAG = 000154	BIT8 = 000400	BIT9 = 001000	CBOOT = 000102
CRCWD = 000000	DIAG = 165564	ERROR = 000134	GBOOT = 000142
HSRCR = 177550	INITSW= 173024	MRESER= 173000	PC = %000007
RESERV= 000340	RK05CR= 177404	RK06 = 000000	RK06B = 000030
RK06CR= 177440	RK06E = 000176	RK06M = 000012	RL01CR= 174400
RP03CR= 176714	RP04CR= 176700	RS03CR= 172040	RS04CR= 172040
RX01CR= 177170	RX02CR= 177170	R0 = %000000	R1 = %000001
R2 = %000002	R3 = %000003	R4 = %000004	R5 = %000005
R6 = %000006	R7 = %000007	SP = %000006	START = 000142
TTCR = 177560	TU10CR= 172522	TU16CR= 172440	TU56CR= 177342
. = 000200			

## M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE RL01 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

.SBTTL RL01 BOOT  
 ;CMND = "DL"

000000	042114			RL01:	.ASCII "LD"		;ID OF RL11/RL01 BOOT.
000002	000176				.WORD <RL01E-.+2>		;OFFSET TO NEXT DEVICE BOOT.
000004	000261				SEC		;UNIT 0, NO DIAG. ENTRY POINT
000006	012700	000000			MOV #0,R0		;UNIT 0, RUN DIAG. ENTRY POINT.
000012	012701	174400		RL01M:	MOV #RL01CR,R1		;LOAD CSR ADDR. INTO R1
000016	010704				MOV PC,R4		;ENTRY POINT FROM CONSOLE EMULATOR.
000020	103064				BCC BDIAG		;EXERCISE DIAG. FC=0
000022	000402				BR 1\$		
000024	173000				.WORD MRESERVED		
000026	000340				.WORD RESERVED		
000030	010003			1\$:	MOV R0,R3		
000032	000303				SWAB R3		;ASSUME SYSTEM INIT ON ENTRY.
000034	010311				MOV R3,(R1)		;SET UNIT NUMBER.
000036	012761	000013	000004		MOV #13,4(R1)		;CLEAR DRIVE ERROR.
000044	052703	000004			BIS #4,R3		
000050	010311				MOV R3,(R1)		;ISSUE GET STATUS.
000052	105711			2\$:	TSTB (R1)		;WAIT TILL DONE.
000054	100376				BPL 2\$		
000056	105003				CLRB R3		
000060	052703	000010			BIS #10,R3		;ISSUE A READ HEADER.
000064	010311				MOV R3,(R1)		
000066	105711			3\$:	TSTB (R1)		;WAIT TILL DONE.
000070	100376				BPL 3\$		
000072	016102	000006			MOV 6(R1),R2		;GET HEADER.
000076	042702	000077			BIC #77,R2		;CLEAR SECTOR.
000102	005202				INC R2		
000104	010261	000004			MOV R2,4(R1)		;SET SEEK TO ZERO.
000110	105003				CLRB R3		
000112	052703	000006			BIS #6,R3		
000116	010311				MOV R3,(R1)		;DO SEEK.
000120	105711			4\$:	TSTB (R1)		;WAIT TILL DONE.
000122	100376				BPL 4\$		
000124	005061	000004			CLR 4(R1)		;CLEAR DISK ADDR.
000130	012761	177000	000006		MOV #-512.,6(R1)		;SET WORD COUNT.
000136	105003				CLRB R3		
000140	052703	000014			BIS #14,R3		;READ DATA CMND.
000144	010311				MOV R3,(R1)		;ISSUE READ CMND.
000146	105711			5\$:	TSTB (R1)		;WAIT TILL DONE.
000150	100376				BPL 5\$		
000152	005711				TST (R1)		;LOOK FOR ERRORS.

000154	100003		BPL	GBOOT	
000156	000005		ERROR:	RESET	;SYSTEM INITIALIZE.
000160	000164	000002		JMP	2(R4)
000164	042711	000377	GBOOT:	BIC	#377,(R1)
000170	005007			CLR	R7
000172	000137	165564	BDIAG:	JMP	@#DIAG
	000176			.=176	
000176	174540		RL01E:	.WORD	174540
	000001			.END	;CRC WORD FOR LAST 63.WORDS.

SYMBOL TABLE

BDIAG	000172	BIT8	= 000400	BIT9	= 001000	CRCWD	= 000000
DIAG	= 165564	ERROR	000156	GBOOT	000164	HSRCR	= 177550
INITSW	= 173024	MRESER	= 173000	PC	=%000007	RESERV	= 000340
RK05CR	= 177404	RK06CR	= 177440	RL01	000000	RL01CR	= 174400
RL01E	000176	RL01M	000012	RP03CR	= 176714	RP04CR	= 176700
RS03CR	= 172040	RS04CR	= 172040	RX01CR	= 177170	RX02CR	= 177170
R0	=%000000	R1	=%000001	R2	=%000002	R3	=%000003
R4	=%000004	R5	=%000005	R6	=%000006	R7	=%000007
SP	=%000006	TTCR	= 177560	TU10CR	= 172522	TU16CR	= 172440
TU56CR	= 177342	.	= 000200				

M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE RS03 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

```

.SBTTL RS03 BOOT
;CMND DS

000000 042123          RS03:  .ASCII  'SD'          ;IDENTIFIER 'DS' FOR RS03 BOOT.
000002 000176          .WORD  <RS03E-.+2>      ;OFFSET TO NEXT ROM.
000004 000261          SEC                ;ENTRY FOR UNIT 0, NO CPU DIAG RUN.
000006 012700 000000   MOV      #0, R0        ;ENTRY FOR UNIT 0, RUN CPU DIAG.
000012 012701 172040   RS03M: MOV      #RS03CR, R1 ;PUT ADDR. OF CSR INTO R1.
000016 010704          MOV      PC, R4        ;GET RETURN ADDR.,
000020 103026          BCC     BDIAG         ;GOTO DIAG IF ENABLED(C=0).
000022 000402          BR      1$
000024 173000          .WORD  MRESERVED
000026 000340          .WORD  RESERVED
000030 010003          1$:    MOV      R0, R3
000032 010361 000010   RS03B: MOV      R3, 10(R1) ;SET UNIT NUMBER
000036 016161 000016 000016 MOV      16(R1), 16(R1) ;WRITE ATTENTION FLAGS.
000044 012761 177000 000002 MOV      #-512., 2(R1) ;SET WORD COUNT.
000052 012711 000071   MOV      #71., (R1)    ;SET COMMAND READ.
000056 105711          1$:    TSTB   (R1)        ;WAIT TILL READY.
000060 100376          BPL     1$
000062 005711          TST     (R1)          ;LOOK FOR ERRORS.,
000064 100401          BMI     ERROR        ;IF ERROR, TAKE CARE OF IT.
000066 005007          CLR     R7           ;ELSE EXIT TO LOADED CODE.,
000070 000005          ERROR: RESET        ;INIT SYSTEM.
000072 000164 000002   JMP     2(R4)
000076 000137 165564   BDIAG: JMP     @#DIAG    ;GOTO DIAGNOSTICS
                                ;RETURN MADE THROU ADDR. IN R4.
000176 126075          RS03E: .WORD  126075 ;CRC16 WORD FOR LAST 63. WORDS.
                                .END
000001
    
```

SYMBOL TABLE

BDIAG = 000076	BIT8 = 000400	BIT9 = 001000	CRCWD = 000000
DIAG = 165564	ERROR = 000070	HSRCR = 177550	INITSW = 173024
MRESER = 173000	PC = %000007	RESERV = 000340	RK05CR = 177404
RK06CR = 177440	RL01CR = 174400	RP03CR = 176714	RP04CR = 176700
RS03 = 000000	RS03B = 000032	RS03CR = 172040	RS03E = 000176
RS03M = 000012	RS04CR = 172040	RX01CR = 177170	RX02CR = 177170
R0 = %000000	R1 = %000001	R2 = %000002	R3 = %000003
R4 = %000004	R5 = %000005	R6 = %000006	R7 = %000007
SP = %000006	TTCH = 177560	TU10CR = 172522	TU16CR = 172440
TU56CR = 177342	. = 000200		

## M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE RX01 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

```
.SBTTL  RX01 BOOT
;CMND  "DX"
```

```
; THIS BOOT READ TRACK 1, SECTOR 1 OFF DISK. IT CAN ONLY LOOK AT
; DRIVE 0 OR DRIVE 1.
; IF ANY ERROR IS ENCONTERED I.E. DRIVE OFF LINE, NO DISK, ETC,
; A SYSTEM INIT. IS ISSUED AND WE TRY AGAIN TO REBOOT THE DISK.
```

```

000000 042130
000002 000176
000004 000261
000006 012700 000000
000012
000012 012701 177170
000016 010704
000020 103056
000022 000402
000024 173000
000026 000340
000030 000241
000032 012703 001407
000036 132700 000001
000042 001402
000044 012703 011427
000050 132711 100040

000054 001775
000056 110311
000060 111105
000062 100376
000064 112761 000001 000002
000072 106003
000074 102771
000076 032711 100040
000102 001775
000104 100412
000106 000303
000110 110311
000112 005003
000114 105711
000116 100376
000120 116123 000002

RX01:  .ASCII  "XD"          ;CMND "DX" RX01 BOOT.
      .WORD  <RX01E-.+2>    ;OFFSET TO NEXT DEVICE BOOT.
      SEC
      MOV    #0,R0          ;UNIT 0, NO DIAG
                                ;UNIT 0 RUN
RX01M:                                ;ENTRY FROM CONSOLE EMULATOR
      MOV    #RX01CR,R1     ;GET CSR ADDR TO R1
      MOV    PC,R4
      BCC   BDIAG           ;EXERCISE DIAG. IF C=D
      BR    1$
      .WORD  MRESERVED      ;
      .WORD  RESERVED      ;
1$:    CLC
RX01B: MOV    #1407,R3
      BITB  #1,R0
      BEQ   1$
      MOV   #11427,R3
1$:    BITB  #100040,(R1)   ;IS DONE BIT SET?
      ;
      BEQ   1$
      MOVB  R3,(R1)        ;LOAD READ CMND.
2$:    MOVB  (R1),R5       ;IS 'TR' BIT SET?
      BPL  2$
      MOVB  #1,2(R1)       ;LOAD TRACK, SECTOR ADDR.
      RORB  R3
      BVS  2$
3$:    BIT   #100040,(R1)   ;WAIT FOR ERROR OR DONE.
      BEQ   3$
      BMI  ERROR
      SWAB  R3
      MOVB  R3,(R1)
      CLR   R3
4$:    TSTB  (R1)
      BPL  4$
      MOVB  2(R1),(R3)+
```

```

000124 105703          TSTB   R3          ;ALL DONE READS?
000126 100372          BPL    4$          ;NO GET NEXT BYTE
000130 005007          CLR    PC          ;START CODE
000132 000005          ERROR: RESET
000134 000140 012700 000001 M1:    MOV    #1,R0 ;ENTER HERE TO BOOT
;                               ;UNIT #1 WITHOUT DIAG.
000144 000261          ;
000146 000721          BR     RX01M
000150 012700 000001 M2:    MOV    #1,R0 ;ENTER HERE TO BOOT
;                               ;UNIT #1 WITH DIAG. RUN.
000154 000716          BR     RX01M
000156 000137 165564 BDIAG: JMP    @#DIAG
000176 105572          RX01E: .WORD 105572
000001          .END

```

SYMBOL TABLE

BDIAG = 000156	BIT8 = 000400	BIT9 = 001000	CRCWD = 000000
DIAG = 165564	ERROR = 000132	HSRCR = 177550	INITSW= 173024
MRESER= 173000	M1 = 000140	M2 = 000150	PC = %000007
RESERV= 000340	RK05CR= 177404	RK06CR= 177440	RL01CR= 174400
RP03CR= 176714	RP04CR= 176700	RS03CR= 172040	RS04CR= 172040
RX01 = 000000	RX01B = 000032	RX01CR= 177170	RX01E = 000176
RX01M = 000012	RX02CR= 177170	R0 = %000000	R1 = %000001
R2 = %000002	R3 = %000003	R4 = %000004	R5 = %000005
R6 = %000006	R7 = %000007	SP = %000006	TTCR = 177560
TU10CR= 172522	TU16CR= 172440	TU56CR= 177342	. = 000200

```
.TITLE M9312 BOOTSTRAP ROM LISTING
.REM %
```

```
COPYRIGHT (C) 1977,1978
DIGITAL EQUIPMENT CORP.
MAYNARD, MASS. 01754
```

```
PROGRAM BY EDWARD C. BADGER
```

```
;THIS BOOT BOOTS THE RX02 FLOOPY DISK FORM COMMAND "DY"
;
;THE SECONDAY BOOT MUST BE IN DISK TRACK 1
;SECTORS 1,3,5, AND 7 IF ANY SECTOR IS UNSED,IT STILL WILL BE READ.
;NOTE : SINGLE DENSITY WILL BOOT 256 WORDS STARTING AT
;      LOC 0
;
;      ;DOUBLE DENSITY WILL BOOT 1000 WORDS,STARTING
;      LOC 0.
;
```

```
THIS ROM WILL BOOT THE RX02 OPTION(S).
TO BOOT UNIT 0,AND NOT RUN DIAGNOSTICS,THE START ADDR IS 173Y04.
TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS,THE START ADDR IS 173Y06.
THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.
IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX
IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.
IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.
IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.
```

```
.SBTTL RX02 BOOT
;
;
000000 042131      ;.ASCII "YD"      ;ASSCI IDENTIFIER FOR THIS BOOT "DY"
000002 000176      ;.WORD <RX02E-.+2> ;OFFFSET TO NEXT DEVICE BOOT.
000004 000261      SEC      ;ENTRY POINT FOR NOT DIAG RUN.
000006 012700 000000 MOV      #0,R0      ;ENTRY POINT TO RUN DIAG.
000012 012701 177170 MOV      #RX02CR,R1 ;PUT CSR ADDR. IN R1
000016 010704      L6: MOV      PC,R4      ;RECORD BOOT ADDR.
000020 103064      BCC      BDIAG      ;IF ENABLED ,RUN DIAG.
000022 000402      BR      1$      ;CONTINUE PAST POWER UP RESERVED LCO
000024 173000      .WORD MRESERVED ;POWER UP HERE FOR NEW PC.
000026 000340      .WORD RESERVED ;POWER UP HERE FOR NOW STATUS WORD
000030
000030 005103      1$:
000032 000005      L62: COM      R3      ;CHANGE STATE OF DENSITY BIT.
000034 012704 000401 RESET      ;SYSTEM INITAILIZE.
000040 005002      MOV      #401,R4 ;TRACK,SECTOR INFO.
000042 012705 000200 L7: CLR      R2      ;START ADDR. 0
000046 042703 177377 MOV      #200,R5 ;IF ALREADY SET,CLEAR IT.
000052 001001      BIC      #~C<BIT8>,R3 ;CLEAR OUT ALL BUT DENSITY INFORMATION.
000054 006205      BNE      LL6      ;IF SET,DOUBLE DENSITY.
000056
000056 LL6: ASR      R5      ;IF CLEAR, IT WAS SINGLE DENSITY,MUST
LL:
000056 050700      BIS      PC,R0 ;R0 WILL CONTAIN EITHER A ZERO OR A ONE.
;BY ADDING THE PC AND THE NEXT OFFSET,WE
;COME UP WITH THHE ADDRESS OF THE BYTE THAT
;CONTAINS THE START CODE FOR EITHER UNIT 0
```

```

000060 156003 000036      BISB  READ-.(R0),R3      ;OR UNIT ONE.
000064 040700          BIC   PC,R0             ;READ EITHER "007" FOR UNIT 0 OR "027" FOR UNIT 1.
000066 010706          MOV   PC,R6             ;RESTORE R0 TO UNIT NUMBER.
000070 000423          BR    WAIT             ;RECORD WHERE WE ARE FOR RETURN.
000072 000432          BR    RDDY            ;WAIT UNIT UNIT IS READY.
000074 000416          BR    WAITS           ;SET READ SECTOR
000076 000415          BR    WAITS           ;GIVE SECOTR INFORMAMATION.
000100 000425          BR    EMPTY          ;GIVE TRACK INFORMATION.
000102 000430          BR    WAITD          ;GIVE WORD COUNT
000104 000407          BR    WAITD2         ;GIVE CURRENT ADDR.
000106 060502          ADD   R5,R2           ;UPDATE CUURRENT ADDR.
000110 060502          ADD   R5,R2
000112 122424          CMPB (R4)+,(R4)+     ;UPDATE SECTOR NUMBER.
000114 120427          CMPB R4,(PC)+       ;IF THE LAST SECTOR IS #7,READ
                                     ;ONE MORE SECTOR. IF GREATOR (OCTAL 11) THEN
                                     ;THEN WE'LL EXIT.
000116      007      027      READ:  .BYTE  7,27      ;THE #7 IN LOWER BYTE FOR LAST INSTR. AND
                                     ;THESE LOCATIONS ALSO USED BY PREVIOUS
                                     ;INSTR. AS DATA FOR UNIT 1 OR UNIT 2
                                     ;READ SECTOR WITH UNIT NUMBER.
000120 003756          BLE   LL              ;READS SECTORS 1,3,5,7
000122 005007          CLR   R7              ;EXIT TO LOC ZERO
000124 010261 000002      WAITD2: MOV  R2,2(R1)     ;LOAD CURRENT ADDR.
000130 000403          BR    WAIT
000132 110461 000002      WAITS:  MOVB R4,2(R1)   ;LOAD TRACK OR SECTOR INFO.
000136 000304          SWAB R4
000140 032711 100240      WAIT:  BIT  #100240,(R1) ;LOOK FOR ERROR,T/R OR DONE.
000144 001775          BEQ   WAIT           ;IF NONE,LOOP
000146 100730          BMI  L62            ;IF ERROR,RESART.
000150 005726          TST  (6)+           ;FIX REURN ADDR.
000152 000116          JMP  (6)            ;RETURN FROM WHERE YE CAME.
000154 042703 000004      EMPTY: BIC  #4,R3
000160 010311      RDDY:  MOV  R3,(R1)
000162 000766          BR    WAIT
000164 110561 000002      WAITD: MOVB R5,2(R1)   ;STORE WORD COUNT IN DBR
000170 000763          BR    WAIT           ;WAIT TILL DONE.
000172 000137 165564      BDIAG: JMP  @#DIAG
000176 057141      RX02E: .WORD 057141 ;CRC-16 WORD FOR THIS BOOOT.
000001      .END

```

SYMBOL TABLE

BDIAG	000172	BIT8	= 000400	BIT9	= 001000	CRCWD	= 000000
DIAG	= 165564	EMPTY	000154	HSRCR	= 177550	INITSW	= 173024
LL	000056	LL6	000056	L6	000016	L62	000030
L7	000040	MRESER	= 173000	PC	= %000007	RDDY	000160
READ	000116	RESERV	= 000340	RK05CR	= 177404	RK06CR	= 177440
RL01CR	= 174400	RP03CR	= 176714	RP04CR	= 176700	RS03CR	= 172040
RS04CR	= 172040	RX01CR	= 177170	RX02CR	= 177170	RX02E	000176
R0	= %000000	R1	= %000001	R2	= %000002	R3	= %000003
R4	= %000004	R5	= %000005	R6	= %000006	R7	= %000007
SP	= %000006	TTCR	= 177560	TU10CR	= 172522	TU16CR	= 172440
TU56CR	= 177342	WAIT	000140	WAITD	000164	WAITD2	000124
WAITS	000132	.	= 000200				



## M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE TU10 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

%

```
.SBTTL ;TU10 BOOT      BOOTS UNITS 0,1,OR 2
        ;CMND = MT     WITH OR WITHOUT DIAGNOSTICS
```

```
000000 046524          TU10:  .ASCII  "TM"          ;TM11/TU10 BOOT
000002 000176          .WORD  <TU10E-.+2>      ;OFFSET TO NEXT DEVICE BOOT.
000004 000261          SEC          ;ENTRY POINT TO UNIT 0 NO DIAG.
000006 012700 000000  MOV      #0,R0          ;ENTRY POINT TO DIAGNOSTICS
000012 012701 172522  TU10M:  MOV      #TU10CR,R1    ;LOAD CSR ADDR INTO R1.
000016 010704          MOV      PC,R4          ;ENTRY POINT
000020 103054          BCC      BDIAG
000022 000411          BR       1$              ;GOTO BOOT.
000024 173000          .WORD  MRESERVED
000026 000340          .WORD  RESERVED
000030 012700 000001  MOV      #1,R0          ;START UNIT #1 DIAGNOSTICS
000034 000766          BR       TU10M
000036 012700 000001  MOV      #1,R0          ;START UNIT #1 NO DIAGNOSTICS
000042 000261          SEC
000044 000762          BR       TU10M
000046 010003          1$:   MOV      R0,R3
000050 000303          TU10B:  SWAB     R3
000052 010311          MOV      R3,(R1)        ;FIX UNIT #
000054 006061 177776  1$:   ROR      -2(R1)    ;SEE IF THE SELECTED DRIVE IS ON LINE
000060 103375          BCC      1$            ;WAIT IF NOT.
000062 052711 060017  2$:   BIS      #60017,(R1) ;REWIND, 800 BPI 9 CHANNEL
000066 105711          3$:   TSTB    (R1)      ;WAIT TILL DONE
000070 100376          BPL     3$
000072 012761 177777 000002  MOV      #-1,2(R1)    ;SET RECORD COUNTER TO SKIP ONE RECORD
000100 112711 000011  MOVB    #11,(R1)     ;SPACE FORWARD CMND.
000104 105711          4$:   TSTB    (R1)      ;WAIT FOR ERROR OR READY
000106 100376          BPL     4$
000110 005711          TST     (R1)          ;SEE IF ERROR
000112 100415          BMI     ERROR
000114 012761 177000 000002  CBOOT:  MOV      #-512.,2(R1) ;LOAD WORD COUNT
000122 011103          MOV      (R1),R3     ;SET READ
000124 042703 000377  BIC     #377,R3
000130 152703 000003  BISB    #3,R3
000134 010311          MOV      R3,(R1)
000136 105711          1$:   TSTB    (1)        ;WAIT TILL DONE
000140 100376          BPL     1$
000142 005711          TST     (R1)          ;TEST FOR ERRORS.
000144 100004          BPL     GBOOT        ;NO - ERROR - EXIT.
```

```

000146 000005          ERROR:  RESET
000150 000720          BR      TU10M
000152 000137 165564  BDIAG:  JMP      @#DIAG
000156 042711 000377  GBOOT:  BIC      #377,(R1)
000162 005007          CLR      PC
          . = 176
000176 021526  TU10E:  .WORD  021526
          .END
          ;ELSE, INITIALIZE, TRY AGAIN.
          ;CLEAR CONTROLLER.
          ;GO TO SECONDARY BOOT.

```

## SYMBOL TABLE

BDIAG	000152	BIT8	= 000400	BIT9	= 001000	CBOOT	000114
CRCWD	= 000000	DIAG	= 165564	ERROR	000146	GBOOT	000156
HSRCR	= 177550	INITSW	= 173024	MRESER	= 173000	PC	= %000007
RESERV	= 000340	RK05CR	= 177404	RK06CR	= 177440	RL01CR	= 174400
RP03CR	= 176714	RP04CR	= 176700	RS03CR	= 172040	RS04CR	= 172040
RX01CR	= 177170	RX02CR	= 177170	R0	= %000000	R1	= %000001
R2	= %000002	R3	= %000003	R4	= %000004	R5	= %000005
R6	= %000006	R7	= %000007	SP	= %000006	TTCR	= 177560
TU10	000000	TU10B	000050	TU10CR	= 172522	TU10E	000176
TU10M	000012	TU16CR	= 172440	TU56CR	= 177342	.	= 000200

## M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE TU16/TU77 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

```

&
.SBTTL ;TU16/TU77 BOOT
;CMND = "MM"

TU16: .ASCII "MM" ;TU16 BOOT.
      .WORD <TU16E-.+2> ;OFFSET TO NEXT DEVICE BOOT.
      SEC ;UNIT ZERO ENTRY
      MOV #0,R0
TU16M: MOV #TU16CR,R1 ;LOAD CSR ADDR. INTO R1
      MOV PC,R4
      BCC BDIAG
      BR TU16B
      .WORD MRESERVED
      .WORD RESERVED

TU16B:
TU16ER: RESET
      MOV R0,R3
      BIS #1300,R3 ;800 BPI AND FORMAT
      MOV R3,32(R1)
      BIT #10000,12(R1)
      BEQ 1$
      MOVB #7,(R1) ;REWIND COMMAND
      TSTB 12(R1)
      BPL 2$
      MOVB #11,(R1) ;DRIVE CLEAR CMND.
      TSTB 12(R1)
      BPL 3$
      MOV #-1,6(R1)
      MOVB #31,(R1) ;SPACE FORWARD CMND.
      TSTB 12(R1)
      BPL 4$
      MOV 16(R1),16(R1)
CMM$GO: MOV #-512.,2(R1)
      MOV (R1),R3
      BIC #377,R3
      BISB #71,R3 ;READ CMND
      MOV R3,(R1)
      TSTB (R1)
      BPL 1$
      TST (R1)
      BPL CLCRS
      CMP #1000,14(R1) ;PATTERN TO TEST FRAME ERROR BIT
      BNE TU16ER

```

000000	046515				
000002	000176				
000004	000261				
000006	012700	000000			
000012	012701	172440			
000016	010704				
000020	103064				
000022	000402				
000024	173000				
000026	000340				
000030					
000030	000005				
000032	010003				
000034	052703	001300			
000040	010361	000032			
000044	032761	010000	000012	1\$:	
000052	001774				
000054	112711	000007			
000060	105761	000012		2\$:	
000064	100375				
000066	112711	000011			
000072	105761	000012		3\$:	
000076	100375				
000100	012761	177777	000006		
000106	112711	000031			
000112	105761	000012		4\$:	
000116	100375				
000120	016161	000016	000016		
000126	012761	177000	000002		
000134	011103				
000136	042703	000377			
000142	152703	000071			
000146	010311				
000150	105711			1\$:	
000152	100376				
000154	005711				
000156	100004				
000160	022761	001000	000014		
000166	001320				

000170	005007		CLCRS:	CLR	PC
000172	000137	165564	BDIAG:	JMP	@#DIAG
	000176			.=176	
000176	162556		TU16E:	.WORD	162556
	000001			.END	

SYMBOL TABLE

BDIAG	000172	BIT8	= 000400	BIT9	= 001000	CLCRS	000170
CMM\$GO	000126	CRCWD	= 000000	DIAG	= 165564	HSRCR	= 177550
INITSW	= 173024	MRESER	= 173000	PC	= %000007	RESERV	= 000340
RK05CR	= 177404	RK06CR	= 177440	RL01CR	= 174400	RP03CR	= 176714
RP04CR	= 176700	RS03CR	= 172040	RS04CR	= 172040	RX01CR	= 177170
RX02CR	= 177170	R0	= %000000	R1	= %000001	R2	= %000002
R3	= %000003	R4	= %000004	R5	= %000005	R6	= %000006
R7	= %000007	SP	= %000006	TTCR	= 177560	TU10CR	= 172522
TU16	000000	TU16B	000030	TU16CR	= 172440	TU16E	000176
TU16ER	000030	TU16M	000012	TU56CR	= 177342	.	= 000200

## M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE TU60 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

%

.SBTTL ;THIS TA-11, TU60 CASSETTE BOOT.  
 ;CMMD = CT

000000	041524		TA11:	.ASCII "TC"	;TU60 BOOT ID "CT"
000002	000176			.WORD <TA11E-.+2>	;OFFSET TO NEXT DEVICE BOOT.
000004	000261			SEC	;UNIT #0 ENTRY, NO DIAG
000006	012700	000000		MOV #0,R0	;UNIT #0 ENTRY, RUN DIAG
000012	012701	177500	TA11M:	MOV #177500,R1	;LOAD CSR ADDR IN R1
000016	010704			MOV PC,R4	;RETURN ADDR.
000020	103042			BCC BDIAG	;GOT DIAG. IF ENABLED.
000022	000402			BR 1\$	
000024	173000			.WORD MRESERVED	
000026	000340			.WORD RESERVED	
000030	010003		1\$:	MOV R0,R3	
000032	042703	177776	TA11B:	BIC #177776,R3	;STRIP JUNK, ONLY UNIT 0 OR 1.
000036	000303			SWAB R3	;PUT IN CORRECT POS.
000040	010311			MOV R3,(R1)	;LOAD UNIT #
000042	010405			MOV R4,R5	
000044	042705	000177		BIC #177,R5	
000050	062705	000132		ADD #TABLE,R5	
000054	012702	000375		MOV #375,R2	;XFERR COUNT.
000060	112503			MOVB (R5)+,R3	;SET COMPARITOR.
000062	112511		LOOP1:	MOVB (R5)+,(R1)	;LEAD COMMAND.
000064	100407			BMI DONE	;WATCH FOR LAST COMMAND.
000066	130311		LOOP2:	BITB R3,(R1)	;LOOK FOR DONE BIT
000070	001776			BEQ LOOP2	
000072	105202			INCB R2	
000074	100772			BMI LOOP1	
000076	116112	000002		MOVB 2(R1),(R2)	
000102	000771			BR LOOP2	
000104	005711		DONE:	TST (R1)	;ANY ERRORS?
000106	100404			BMI ERROR	
000110	005002			CLR R2	
000112	120312			CMPB R3,(R2)	;CORRECT CODE IN LOC 0?
000114	001001			BNE ERROR	
000116	005007			CLR PC	
000120	000005		ERROR:	RESET	
000122	000164	000002		JMP 2(R4)	
000126	000137	165564	BDIAG:	JMP @#DIAG	
000132	240	037	015 TABLE:	.BYTE 240,37,15,5,24,224	
005	024	224			

.EVEN

000176 022763  
000001

TA11E: .WORD 022763  
.END

## SYMBOL TABLE

BDIAG	=	000126	BIT8	=	000400	BIT9	=	001000	CRCWD	=	000000
DIAG	=	165564	DONE	=	000104	ERROR	=	000120	HSRCR	=	177550
INITSW	=	173024	LOOP1	=	000062	LOOP2	=	000066	MRESER	=	173000
PC	=	%000007	RESERV	=	000340	RK05CR	=	177404	RK06CR	=	177440
RL01CR	=	174400	RP03CR	=	176714	RP04CR	=	176700	RS03CR	=	172040
RS04CR	=	172040	RX01CR	=	177170	RX02CR	=	177170	R0	=	%000000
R1	=	%000001	R2	=	%000002	R3	=	%000003	R4	=	%000004
R5	=	%000005	R6	=	%000006	R7	=	%000007	SP	=	%000006
TABLE	=	000132	TA11	=	000000	TA11B	=	000032	TA11E	=	000176
TA11M	=	000012	TTCR	=	177560	TU10CR	=	172522	TU16CR	=	172440
TU56CR	=	177342	.	=	000200						

## M9312 BOOTSTRAP ROM LISTING

THIS ROM WILL BOOT THE RP02/RP03 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y04.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y06.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

THIS ROM WILL BOOT THE RP04/RP05 OPTION(S).

TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS, THE START ADDR IS 173Y46.  
 TO BOOT UNIT 0 AND RUN CPU DIAGNOSTICS, THE START ADDR IS 173Y50.  
 THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.  
 IF THIS ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX  
 IF THIS ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.  
 IF THIS ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX.  
 IF THIS ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX.

```

.SBTTL ;BOOT FOR RP02, RP03, RP04, RP05
        ;CMND = "DP"          CMND = "DB"

RP03:  .ASCII  "PD"          ;ID OF RP02, RP03 BOOT.
        .WORD  <RP03E-.+2>  ;OFFSET TO NEXT DEVICE BOOT.
        SEC          ;UNIT 0, NO DIAG ENTRY POINT.
        MOV    #0,R0      ;UNIT 0, RUN DIAG ENTRY POINT.
RP03M: MOV    #RP03CR,R1  ;LOAD CSR ADDR. INTO R1.
        MOV    PC,R4      ;ENTRY FROM CONSOLE EMULATOR.
        BCC   BDIAG      ;EXERCISE DIAG. IF C=0.
        BR    1$
        .WORD  MRESERVED
        .WORD  RESERVED
1$:    MOV    R0,R3
        SWAB  R3
        MOV   R3,(R1)     ;LOAD UNIT #.
        MOV   #5,R2      ;CODE FOR READ.
RP03E: BR    CM$GO       ;GOTO COMMON BOOT CODE.
        ;NEW HEADER BLOCK BEGINS HERE
RP04:  .ASCII  "BD"          ;ID OF RP04, RP05 BOOT.
        .WORD  <REND-.+2>  ;OFFSET TO NEXT DEVICE BOOT.
        SEC          ;UNIT 0, NO DIAG. ENTRY POINT.
        MOV    #0,R0      ;UNIT 0, RUN DIAG. ENTRY POINT.
RP04M: MOV    #RP04CR,R1  ;LOAD CSR ADDR. INTO R1.
        MOV    PC,R4      ;ENTRY FROM CONSOLE EMULATOR.
        BCC   BDIAG      ;EXERCISE DIAG IF C=0.
        MOV   R0,10(R1)   ;SET UNIT NUMBER.
        MOV   #71,R2      ;CODE FOR READ.
        MOV   #21,(R1)    ;ISSUE READ IN PRESET CMND.
        MOV   #14000,32(R1);SET FMT22 AND ECC INHIBIT BITS
        MOV   16(R1),16(R1);WRITE ATTENTION SUMMARY REG.
        ;INTO ITSELF.
CM$GO: MOV   #-512.,2(R1) ;LOAD WORD COUNT.

```

000000	042120				
000002	000042				
000004	000261				
000006	012700	000000			
000012	012701	176714			
000016	010704				
000020	103060				
000022	000402				
000024	173000				
000026	000340				
000030	010003				
000032	000303				
000034	010311				
000036	012702	000005			
000042	000425				
000044	042102				
000046	000132				
000050	000261				
000052	012700	000000			
000056	012701	176700			
000062	010704				
000064	103036				
000066	010061	000010			
000072	012702	000071			
000076	012711	000021			
000102	012761	014000	000032		
000110	016161	000016	000016		
000116	012761	177000	000002		

```

000124 011103          MOV      (R1),R3          ;GET CSR CONTENTS.
000126 042703 000377  BIC      #377,R3
000132 050203          BIS      R2,R3          ;SET NEW COMMAND.
000134 010311          MOV      R3,(R1)
000136 105711          1$:    TSTB     (R1)          ;WAIT FOR READY.
000140 100376          BPL      1$
000142 005711          TST      (R1)          ;LOOK FOR ERRORS.
000144 100003          BPL      CLRG0         ;NONE - CONTINUE
000146 000005          ERROR: RESET        ;IF ERROR, INITIALIZE SYSTEM
000150 000164 000002  JMP      2(4)
000154 042711 000377  CLRG0:  BIC      #377,(R1)   ;CLEAR DEVICE (LOW BYTE)
000160 005007          CLR      R7          ;AWAY WE GO TO THE NEWLY LOADED CODE!
000162 000137 165564  BDIAG:  JMP      @#DIAG      ;GOTO DIAGNOSTICS.
;*****
;RP02,RP03 ENTRY FOR UNIT #1, NO DIAG
;*****
000166 000261          SEC
;*****
;RP02,RP03 ENTRY FOR UNIT #1, RUN DIAG.
;*****
000170 012700 000001  MOV      #1,R0
000174 000706          BR       RP03M
000176 000176          .=176
000176 111612          REND:   .WORD    111612
000001 000001          .END

```

SYMBOL TABLE

BDIAG	000162	BIT8	= 000400	BIT9	= 001000	CLRG0	000154
CM\$GO	000116	CRCWD	= 000000	DIAG	= 165564	ERROR	000146
HSRCR	= 177550	INITSW	= 173024	MRESER	= 173000	PC	= %000007
REND	000176	RESERV	= 000340	RK05CR	= 177404	RK06CR	= 177440
RL01CR	= 174400	RP03	000000	RP03CR	= 176714	RP03E	000042
RP03M	000012	RP04	000044	RP04CR	= 176700	RP04M	000056
RS03CR	= 172040	RS04CR	= 172040	RX01CR	= 177170	RX02CR	= 177170
R0	= %000000	R1	= %000001	R2	= %000002	R3	= %000003
R4	= %000004	R5	= %000005	R6	= %000006	R7	= %000007
SP	= %000006	TTCR	= 177560	TU10CR	= 172522	TU16CR	= 172440
TU56CR	= 177342	.	= 000200				



```

1      00100  ;<11-UTILITIES>TSBOOT.P11.145,  8-NOV-78 12:53:44, EDIT BY KINZELMAN
2      00200  .TITLE  TSBOOT - TS04 M9312 BOOTSTRAP CODE (ROM PART # 23-764A9)
3      00300  .REM    !      BY PAUL KINZELMAN
4      00400                ML1-3 E63
5      00500                3-2473
6      00600                27-JUN-78
7      00700
8      00800  THIS IS THE M9312 BOOTSTRAP CODE FOR THE TS04 MAG TAPE DRIVE, WRITTEN
9      00900  TO CONFORM TO SPEC # ECB1-77-001-00-U BY ED BADGER (10 OCT 77).
10     01000
11     01100  THIS BOOTSTRAP MUST BE LOCATED IN THE 1ST 32K AREA OF THE ADDRESS SPACE.
12     01200
13     01300  THE MAGTAPE MUST HAVE A SINGLE RECORD OR FILE MARK BEFORE THE DESIRED
14     01400  BOOTSTRAP RECORD, AND THE BOOTSTRAP RECORD MUST BE 512(10) BYTES LONG.
15     01500
16     01600  THE BOOTSTRAP DOES THE FOLLOWING OPERATIONS:
17     01700                OP                IF OK, DO                IF ERR, DO
18     01800  1          SET CHAR                2                2
19     01900  2          REWIND                3                1
20     02000  3          RD FWD (TP MK)        4                1
21     02100  4          READ FWD                EXIT                5
22     02200  5          RD PREV REV RTY EXIT                1
23     02300
24     02400  ENTER BOOT IN THE STANDARD WAY (R0 = UNIT #, R1 = TSSR BUS ADR).
25     02500  SINCE THE TS04 HAS 1 UNIT PER ADDRESS, THE UNIT # IS ROTATED LEFT 2 PLACES
26     02600  AND ADDED TO THE BUS ADR IN R1:
27     02700                MS#      TSSR ADR
28     02800                (DEFAULT) 172522
29     02900                0        172522
30     03000                1        172526
31     03100                2        172532                (ETC.)
32     03200                3        172536
33     03300
34     03400  UPON EXIT FROM THE BOOT, R1 CONTAINS THE ADDRESS OF THE TSSR REG,
35     03500  R2 CONTAINS THE TSBA REG, AND R0 LO BYTE CONTAINS THE UNIT NUMBER.
36     03600  IF YOU SUBTRACT 20 FROM R4, R4 WILL POINT TO THE ASCII ID OF THE DEVICE.
37     03700  THEREBY YOU CAN FIGURE OUT FROM WHAT MTA TYPE YOU WERE BOOTED FROM.
38     03800
39     03900  FOR THOSE OF YOU WHO KNOW NOTHING ABOUT THE TS04, HERE IS A CHEAT-SHEET.
40     04000  THE TSSR REG CONTAINS THE SSR (SUBSYSTEM RDY) BIT INDICATING THAT THE
41     04100  DRIVE IS RDY FOR THE NEXT COMMAND. THE TSSR ALSO CONTAINS THE SC (SPECIAL
42     04200  CONDITION) BIT INDICATING THAT SOMETHING ABNORMAL (USUALLY ERROR) HAPPENED
43     04300  DURING THE LAST OPERATION. TO DO AN OPERATION, WE WAIT FOR THE SSR BIT
44     04400  TO COME TRUE. WE THEN WRITE THE ADDRESS OF THE COMMAND PACKET WE WISH
45     04500  TO PERFORM INTO THE TSBA. WHEN SSR COMES TRUE AGAIN, WE CHECK
46     04600  THE SC BIT TO TELL US WHETHER ANYTHING UNUSUAL HAPPENED.
47     04700
48     04800  THE ADDRESS OF THE COMMAND PACKET MUST BE ON AN EVEN 4 WORD BOUNDARY (THE
49     04900  LO ORDER 2 BITS ARE 0). BIT 17 OF THE PACKET ADR IS MOVED TO BIT 1 OF
50     05000  THE POINTER AS WRITTEN INTO THE TSBA AND BIT 16 OF THE PACKET ADR IS
51     05100  MOVED TO BIT 0 OF THE POINTER.
52     05200  AND A FREE DINNER TO THE FIRST ONE TO COME UP WITH A SHORTER BOOTSTRAP
53     05300  THAN THIS ONE THAT DOES THE EQUIVALENT OPERATIONS!
54
55     000000  .ASECT

```

```

56          00200      .ENABL ABS
57          00300
58          172522     TS04SR= 172522      ;FIRST TS04 STATUS REG (TSBA IS PREV WD)
59          165564     DIAG= 165564
60          022000     .=22000      ;FOR NOW
61          00700
62 022000 046523     TS04:  .ASCII  "SM"      ;ASCII CODE (BACKWARDS)
63 022002 000176     .WORD  <CRCWD-.+2>    ;OFFSET TO NEXT DEVICE
64 022004 000261     SEC      ;ENTRY POINT TO UNIT 0 NO DIAG
65 022006 012700 000000  MOV     #0,R0      ;ENTRY POINT TO DIAGNOSTICS
66 022012 012701 172522  TS04M: MOV     #TS04SR,R1 ;GET THE 1ST TSSR ADR IN R1
67 022016 010704     MOV     PC,R4      ;ENTRY POINT, SAVE RTN PC
68 022020 103063     BCC     BDIAG      ;BR TO RUN DIAGNOSTICS
69 022022 000411     BR      RSTRT      ;BR OVER RESERVED WORDS
70 022024 173000     .WORD  173000     ;THE VOICE FROM ABOVE SAID THESE
71 022026 000340     .WORD  340        ;WORDS HAD TO BE HERE
72          01800     ;(XXX24 IS EXCEPTION ADDRESS)
73          01900     ;MOVE THE FOLLOWING TO 1000:
74 022030 142010     CMPRWD: 142010     ;REWIND (1 WD)
75 022032 000000     0          ;LO 16 BITS ADR
76 022034 000000     0          ;HI 2 BITS ADR
77 022036 001000     256.*2      ;SIZE OF RECORD (512(10) BYTES)
78          02400
79 022040 140004     CMPSCH: 140004     ;SET CHARACTERISTICS CMD (4 WDS)
80 022042 001012     1012        ;LO 16 BITS OF MSG BUFF POINTER (= .)
81 022044 000000     0          ;HI 2 BITS
82          02800
83          02900     ;THE FOLLOWING MUST NOT BE MOVED AWAY FROM THE END OF THE CMD LIST
84          03000     ;THE FOLLOWING IS ALSO TAKEN AS THE MSG
85          03100     ;BUFFER POINTER SIZE AND MBF SIZE:
86 022046 010003     RSTRT: MOV     R0,R3 ;COPY THE UNIT #
87          03300     ;THE FOLLOWING IS TAKEN AS THE DRV CHAR-
88          03400     ;ACTERISTICS WORD:
89 022050 010702     MOV     PC,R2      ;GET WHERE WE ARE
90 022052 012705 001022  MOV     #1022,R5    ;END OF COMMAND LST IN CORE
91 022056 014245     1$:  MOV     -(R2),-(R5) ;MOVE IN THE COMMAND LIST
92 022060 105705     TSTB    R5         ;ARE WE DONE YET?
93 022062 001375     BNE     1$        ;LOOP FOR ALL WDS (EXIT WITH R5 = 1000)
94 022064 006303     ASL     R3        ;ROTATE INTO PLACE
95 022066 006303     ASL     R3        ;SO WE CAN ADD IT TO THE ADR
96          04200     ;NOTE: THE FOLLOWING ASSUMES THE USER TYPED A REASONABLE NUMBER FOR
97          04300     ;THE UNIT. IF NOT, WE WILL PROBABLY GET A BUSS TIMEOUT.
98 022070 060301     ADD     R3,R1     ;ADD IN TO THE BUS ADR
99 022072 010102     MOV     R1,R2     ;COPY THE TS STATUS REG
100 022074 005742     TST     -(R2)     ;POINT R2 TO THE TSBA
101 022076 105711     2$:  TSTB    (R1)    ;AND CHK FOR SSR
102 022100 100376     BPL     2$        ;BR IF SSR NOT UP YET
103          04900
104          05000     ;THE FOLLOWING MAY BE REMOVED IF WE NEED THE SPACE:
105 022102 005037 000000  CLR     @#0       ;CLR OUT LOC 0 IN CASE BOOT FAILED WE'LL HALT
106          05100
107 022106 012712 001010  MOV     #1010,(R2) ;DO THE SET CHARACTERISTICS
108 022112 111103     3$:  MOVB    (R1),R3 ;TST SSR BIT (INIT R3 BYTE TO NEG WHEN RDY)
109 022114 100376     BPL     3$        ;BR IF NOT RDY YET
110          00400     ;DON'T NEED TO CHK ERRS BECAUSE IF IT FAILED,

```

```

111          00500          ;THE NEXT COMMAND WILL CERTAINLY FAIL ANYWAY
112          00600
113 022116 010512          00700 LP1:  MOV    R5,(R2)      ;DO THE REWIND OR RD FWD OVER TAPE MARK
114 022120 105711          00800 4$:  TSTB   (R1)        ;TST SSR BIT
115 022122 100376          00900      BPL    4$          ;BR IF NOT RDY YET
116 022124 032711 000012  01000      BIT    #12,(R1)    ;ALLOW TERM CLASS 0 AND 4, CHK FOR OTHERS
117 022130 001346          01100      BNE   RSTRT       ;BR IF ERROR, TRY AGN
118 022132 012715 140001  01200      MOV    #140001,(R5) ;CODE FOR RD FWD AS NEXT OPERATION
119 022136 105103          01300      COMB  R3          ;INVERT OUR FLG
120 022140 100366          01400      BPL   LP1         ;BR BACK TO DO THE RD OVER TAPE MARK
121          01500
122 022142 010512          01600 LP2:  MOV    R5,(R2)      ;DO RD FWD THE BOOT RECORD (R5=1000)
123 022144 105711          01700 6$:  TSTB   (R1)        ;TST SSR BIT
124 022146 100376          01800      BPL    6$          ;BR IF NOT RDY YET
125 022150 005711          01900      TST   (R1)        ;TST SC BIT
126 022152 100401          02000      BMI   RDBAD       ;BR IF ERROR, DO RETRY
127 022154 005007          02100      CLR   PC          ;JMP TO LOC 0
128          02200
129 022156 012715 161001  02300 RDBAD: MOV   #161001,(R5) ;CODE FOR RD PREV REV RETRY
130 022162 105103          02400      COMB  R3          ;INVERT OUR FLG
131 022164 100366          02500      BPL   LP2         ;LOOP BACK FOR RD RETRY
132 022166 000727          02600      BR    RSTRT       ;BR TO TRY WHOLE THING AGN
133          02700
134 022170 000137 165564  02800 BDIAG: JMP    @#DIAG  ;LINK TO DIAGNOSTICS
135 022174 000000          02900      HALT                    ;THIS IS A SPARE LOCATION
136          001          03000 .IF LT 176-<.&376>
137          000          03100 .ERROR .          ;BOOTSTRAP CODE OVERFLOW
138          000          03200 .ENDC
139 022176 140726          03300 CRCWD: 140726      ;CRC FOR BOOTSTRAP
140          000001          03400      .END

BDIAG 022170      CRCWD 022176      LP2 022142      TS04 022000      . = 022200
CMPRWD 022030      DIAG = 165564      RDBAD 022156      TS04M 022012
CMPSCH 022040      LP1 022116      RSTRT 022046      TS04SR= 172522
. ABS. 022200      000

```

```

1      ;M9312 BOOTSTRAP ROM LISTING
2      ;
3      ;THIS ROM WILL BOOT THE TU58 OPTION
4      ;
5      ;TO BOOT UNIT 0, AND NOT RUN DIAGNOSTICS THE START ADDR IS 173Y04
6      ;TO BOOT UNIT 0, AND RUN CPU DIAGNOSTICS THE START ADDR IS 173Y06
7      ;THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WORD
8      ;IF THE ROM IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX
9      ;IF THE ROM IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX
10     ;IF THE ROM IS IN SLOT 3 THE Y COMPONENT IS 10 ADDR. 1734XX
11     ;IF THE ROM IS IN SLOT 4 THE Y COMPONENT IS 11 ADDR. 1736XX
12
13     .SBTTL TU58 BOOT
14
15     ;*****
16     ;*** NOTE: THIS BOOTSTRAP DOES NOT RETRY IF THE BOOT FAILS.
17     ;*** THIS IS NECESSARY BECAUSE RETRIES CAN DAMAGE THE
18     ;*** TAPE CARTRIDGE IF A HARDWARE FAILURE HAS OCCURRED.
19     ;*****
20     165564      DIAG= 165564
21     173000      MRESERVED      =173000
22     000340      RESERVED      =340
23     0125025    CRC      =125025
24     176500      TI$CSR      =176500
25     176502      TI$BFR      =176502
26     176504      TO$CSR      =176504
27     176506      TO$BFR      =176506
28     000000 042104      TU58: .ASCII "DD"      ;ASCII IDENTIFIER
29     000002 000176      .WORD <TU58E-.+2>      ;OFFSET TO NEXT BOOT
30     000004 000261      SEC      ;ENTRY POINT FOR UNIT 0 NO DIAGS
31     000006 012700 000000      MOV #0,R0      ;ENTRY POINT FOR UNIT 0 WITH DIAGS
32     000012 012701 176500      TU58M: MOV #TI$CSR,R1      ;PUT DEVICE ADDRESS IN R1
33     000016 010704      MOV PC,R4      ;DIAGNOSTIC BOILER PLATE
34     000020 103054      BCC BDIAG
35     000022 000402      BR TBOOT
36     000024 173000      .WORD MRESERVED
37     000026 000340      .WORD RESERVED
38     000030 012706 002000      TBOOT: MOV #2000,SP      ;SET STACK POINTER
39     000034 005004      CLR R4
40     000036 012702 176504      MOV #TO$CSR,R2
41     000042 005212      INC @R2      ;SEND BREAK ON SERIAL LINE
42     000044 005003      CLR R3
43     000046 004767 000046      JSR PC,SEND8      ;DELAY 7 CHARACTER TIMES
44     000052 005012      CLR @R2      ;REMOVE BREAK
45     000054 005737 176502      TST @#TI$BFR      ;DUMP RECEIVE REGISTER
46     000060 012703      MOV (PC)+,R3      ;GET INIT, BOOT FLAGS
47     000062 004 010      .BYTE 4,10
48     000064 004767 000034      JSR PC,SEND2      ;SEND FLAGS
49     000070 010003      MOV R0,R3
50     000072 004767 000030      JSR PC,SEND1      ;SEND UNIT NUMBER
51     000076 005003      CLR R3      ;SET ADDRESS POINTER TO 0
52     000100 105711      RCVLOP: TSTB @R1      ;WAIT FOR CHARACTER RECEIVED

```

```

53 000102 100376          BPL      RCVLOP
54 000104 113723 176502  MOVB    @#TI$BFR,(R3)+ ;STORE CHARACTER IN MEMORY
55 000110 022703 001000  CMP     #1000,R3      ;512 BYTES RECEIVED?
56 000114 101371          BHI     RCVLOP        ;NO, LOOP
57 000116 005007          CLR     PC            ;YES, JUMP TO 0

58                          ;SUBROUTINE TO OUTPUT CHARACTERS TO THE SERIAL LINE
59
60
61 000120 004717          SEND8:  JSR     PC,@PC      ;SEND 8 CHARACTERS
62 000122 004717          JSR     PC,@PC      ;SEND 4 CHARACTERS
63 000124 004717          SEND2:  JSR     PC,@PC      ;SEND 2 CHARACTERS
64 000126 105712          SEND1:  TSTB   @R2      ;TEST TRANSMIT READY
65 000130 100376          BPL     SEND1
66 000132 110337 176506  MOVB    R3,@#TO$BFR  ;SEND CHARACTER
67 000136 000303          SWAB   R3
68 000140 000207          RTS     PC
69
70                          ;ENTRY FOR UNIT 1
71
72 000142 000261          UNIT1:  SEC
73 000144 012700 000001  UNIT1D: MOV     #1,R0    ;UNIT 1 NO DIAGS
74 000150 000720          BR     TU58M         ;UNIT 1 NO DIAGS
75
76 000152 000137 165564  BDIAG:  JMP     @#DIAG  ;LINK TO DIAGNOSTIC ADDRESS
77
78                          . = <TU58+176>
79 000176 022540          TU58E:  .WORD  CRC
80                          .END

```

SYMBOL TABLE

BDIAG	000152R	RCVLOP	000100R	SEND8	000120R	TO\$BFR=	176506	TU58M	000012R
CRC	= 022540	RESERV=	000340	TBOOT	000030R	TO\$CSR=	176504	UNIT1	000142R
DIAG	= 165564	SEND1	000126R	TI\$BFR=	176502	TU58	000000R	UNIT1D	000144R
MRESER=	173000	SEND2	000124R	TI\$CSR=	176500	TU58E	000176R		

  

. ABS.	000000	000
	000200	001

```

1          .REM      %
2
3
4
5          IDENTIFICATION
6          -----
7
8          PRODUCT CODE:      XXXXXXX-XX-XXXXX-X-X
9
10         PRODUCT NAME:      M9312 DECNET BOOT - DMC
11
12         PRODUCT DATE:      APRIL 1978
13
14         MAINTAINER:        DIAGNOSTIC ENGINEERING
15
16         THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE
17         WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT
18         BY DIGITAL EQUIPMENT CORPORATION.  DIGITAL EQUIPMENT
19         CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT
20         MAY APPEAR IN THIS MANUAL.
21
22         THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE
23         PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER
24         SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS
25         COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY
26         OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.
27
28         DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR
29         THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS
30         NOT SUPPLIED BY DIGITAL.
31
32         COPYRIGHT (C) 1978 DIGITAL EQUIPMENT CORPORATION
33         %

1          .REM      %
2          THIS ROM WILL BOOT THE DMC OPTION.
3          TO BOOT UNIT 0,AND NOT RUN DIAGNOSTICS,THE START ADDR IS 173Y04.
4          TO BOOT UNIT 0,AND RUN CPU DIAGNOSTICS,THE START ADDR IS 173Y06.
5          TO BOOT UNIT 1,AND NOT RUN DIAGNOSTICS,THE START ADDR IS 173Y30.
6          TO BOOT UNIT 1,AND RUN CPU DIAGNOSTICS,THE START ADDR IS 173Y32.
7          THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.
8          IF ROM #1 IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX
9          IF ROM #1 IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.
10         %

```

```
1          .TITLE M9312 DECNET BOOT - DMC
2          ;      BASIC DEFINITIONS
3
4          000000      R0=%0
5          000001      R1=%1
6          000002      R2=%2
7          000003      R3=%3
8          000004      R4=%4
9          000005      R5=%5
10         000006      R6=%6
11         000007      R7=%7
12         000006      SP=%6
13         000007      PC=%7
14         000340      RESERVED=340
15         165564      DIAG=165564
16         173024      INITSW=173024
17         000000      CRCWD=0
18         173000      MRESERVED=173000
19         .NLIST MC,MD
20         .LIST ME
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38 000000          .ENABL ABS
39 020000          .=20000
```

```

1
2           ;CMND           XM
3
4 020000     115         130   DMCBGN: .ASCII 'MX'           ;IDENTIFIER 'XM' FOR DMC BOOT
5 020002     000576          .WORD <DMCE-.+2>       ;OFFSET TO NEXT BOOT
6 020004     000261          SEC                   ;ENTRY FOR UNIT 0, NO CPU DIAG RUN
7 020006     012700     000000   MOV #0,R0           ;ENTRY FOR UNIT 0, RUN CPU DIAG
8 020012     012701     160010   DMCB:  MOV #160010,R1       ;PUT FLOATING BASE ADDR IN R1
9 020016     010704          MOV PC,R4           ;GET RETURN ADDR
10 020020     103015          BCC BDIAG          ;GO TO DIAG IF ENABLED (C=0)
11 020022     000416          BR SETSTK
12 020024     173000          .WORD MRESERVED
13 020026     000340          .WORD RESERVED
14 020030     000261          SEC                   ;ENTRY FOR UNIT 1, NO CPU DIAG RUN
15 020032     012700     000001   MOV #1,R0           ;ENTRY FOR UNIT 1, RUN CPU DIAG
16 020036     000765          BR DMCB
17           ;*****
18           ;* FLOATING DEVICE INTERRUPT ROUTINE
19           ;*****
20 020040     005202   NODEV: INC R2           ;UPDATE R2 TO POINT TO NEXT DEV MODULO
21 020042     005303          DEC R3           ;SUB ONE FROM R3
22 020044     100002          BPL 1$           ;IF CANT FIND DEVICE, HALT
23 020046     000000   2$:  HALT           ; *****NOTE***
24 020050     000776          BR 2$           ;REVIEW FLOATING ADDRESS ASSIGNMENTS
25 020052     000002   1$:  RTI           ;RETURN
26           ;*****
27           ;* GO TO DIAG
28           ;*****
29 020054     000137     165564   BDIAG: JMP @#DIAG          ;GO TO DIAG
30           ;RETURN MADE THROUGH ADDR IN R4
31           ;*****
32           ;* SET UP REQUEST SECONDARY BOOT MESSAGE AND STACK
33           ;*****
34 020060     012706     017776   SETSTK: MOV #17776,SP       ;SET REQ SECOND BOOT MSG POINTER
35 020064     012716     000001          MOV #1,(SP)       ;SET HIGH ORDER WORD OF MESSAGE
36 020070     012746     006010          MOV #6010,-(SP)   ;SET LOW ORDER WORD OF MESSAGE
37           ; *****NOTE***
38           ;BOOT MSG= 10,14,1,0
39           ;STACK POINTER IS SET AT 17774
40           ;*****
41           ;* FIND THE DEVICE IN FLOATING SPACE
42           ;* VERIFY THAT TWO EXTENSION ROMS ARE PROPERLY INSTALLED
43           ;*****
44 020074     010702   2$:  MOV PC,R2           ;SET UP R2 WITH
45 020076     062702     000422          ADD #DEVTAB-2$-2,R2 ;POINTER TO DEVTAB
46 020102     010704   3$:  MOV PC,R4           ;SET UP R4 WITH
47 020104     062704     177734          ADD #NODEV-3$-2,R4 ;POINTER TO TRAP ROUTINE
48           ; *****NOTE***
49           ;THE NEXT FOUR INSTRUCTIONS VERIFY THAT
50           ;THE EXTENSION ROMS ARE PROPERLY INSTALLED.
51           ;IF NOT, THE BOOT WILL HALT
52 020110     011246          MOV (R2),-(SP)       ;PUSH THE #7407 FROM ROM #3 ON THE STACK
53 020112     166416     000200          SUB 200(R4),(SP)   ;SUBTRACT FROM IT THE #2400 OFF ROM #2
54 020116     022726     005007          CMP #5007,(SP)+   ;COMP IT WITH #5007
55 020122     001402          BEQ 4$           ;IF NOT EQUAL, HALT

```



```

56 020124 000000          5$: HALT          ;      ***NOTE***
57 020126 000776          BR          5$      ;CHECK POS OF ROMS #2 AND #3
58 020130 012703 000004  4$: MOV          #4,R3 ;SET R3 TO DMC POS IN FLOAT -2
59 020134 010423          MOV          R4,(R3)+ ;SET TRAP ROUTINE ADDR IN LOC 4
60 020136 005013          CLR          (R3)    ;CLR NEW PSW. R3 NOW CONTAINS DMC POS(6)
61 020140 005711          FLOAT: TST        (R1) ;TEST FOR DEVICE, MAYBE TRAP TO NODEV
62 020142 111204          MOVB       (R2),R4   ;MODULO INCREMENT
63 020144 060401          ADD          R4,R1   ;UPDATE ADDRESS
64 020146 005201          INC          R1     ;BY MODULO
65 020150 040401          BIC          R4,R1   ;IN TABLE
66 020152 005703          TST          R3     ;IS THIS A DMC?
67 020154 001371          BNE          FLOAT  ;NOT YET
68
69 ;*****
70 ;* ADD UNIT DISPLACEMENT TO UNIT 0 CSR ADDR
71 ;*****
71 020156 042700 177760  BIC          #177760,R0 ;PREVENT TRYING TO BOOT UNIT # > 15
72 020162 010046          MOV          R0,-(SP) ;SAVE UNIT # FOR SECONDARY BOOT
73 020164 006300          ASL          R0     ;UNIT # TIMES 2
74 020166 006300          ASL          R0     ;UNIT # TIMES 4
75 020170 006300          ASL          R0     ;UNIT # TIMES 8
76 020172 060001          ADD          R0,R1   ;CSR ADDR + UNIT#8
77 020174 000402          BR          DMC     ;GO TO MAINLINE CODE
78 020176 161040          .WORD       161040  ;CRC16 WORD FOR ROM #1
79 020200 177776          .WORD       -2     ;HEADER WORD FOR ROM #2
80 ;*****
81 ;* DMC MAINLINE
82 ;*****
83 020202 012704 000010  DMC: MOV          #8.,R4 ;SET RETRY COUNT
84 020206 000005          RESET       ;MASTER CLEAR DMC
85 020210 010702          MOV          PC,R2  ;RETURN ADDR
86 020212 000461          BR          DMCIN   ;INPUT TO DMC
87 020214 000043          .WORD       43     ;RQI + BASE REQUEST
88 020216 017370          .WORD       17370  ;BASE ADDR
89 020220 000000          .WORD       0      ;NO RESUME
90 020222 000402          BR          1$
91 020224 173000          .WORD       MRESERVED
92 020226 000340          .WORD       RESERVED
93 020230 010702          1$: MOV          PC,R2 ;SET RETURN ADDRESS
94 020232 000451          BR          DMCIN   ;INPUT TO DMC
95 020234 000041          .WORD       41     ;RQI + CNTLI
96 020236 000000          .WORD       0      ;FILLER
97 020240 002400          .WORD       2400   ;MAINT MODE + HDX
98 020242 010702          DMCRCV: MOV       PC,R2 ;SET RETURN ADDR
99 020244 000444          BR          DMCIN   ;INPUT TO DMC
100 020246 000044          .WORD       44     ;RQI + BA.CC + RCV
101 020250 000000          .WORD       0      ;BUFFER ADDRESS
102 020252 007774          .WORD       4092.  ;SET SIZE TO MAX FOR CRC-16
103 020254 010705          MOV          PC,R5  ;SET NON-ZERO AS R5 FLAG (RCV PENDING)
104 020256 010702          DMCXMT: MOV       PC,R2 ;SET RETURN ADDR
105 020260 000436          BR          DMCIN   ;INPUT TO DMC
106 020262 000040          .WORD       40     ;RQI + BA/CC + XMIT
107 020264 017774          .WORD       17774  ;MESSAGE ADDR
108 020266 000004          .WORD       4      ;MESSAGE LENGTH
109 020270 012702 000017  MOV          #15.,R2 ;LARGE LOOP COUNTER

```

```

110 020274 105761 000002      1$:  TSTB    2(R1)      ;TEST RDYO SET
111 020300 100002             BPL      2$          ;NOT YET
112 020302 010703             MOV      PC,R3      ;SET RETURN ADDR
113 020304 000456             BR       DMCOUT     ;CHECK DMC REQUEST
114 020306 005705      2$:  TST      R5          ;IS RECEIVE STILL OUTSTANDING
115 020310 001754             BEQ      DMCRCV     ;NO, REISSUE ONE
116 020312 005300             DEC      R0          ;DECREMENT SHORT LOOP
117 020314 001367             BNE      1$         ;AGAIN
118 020316 005302             DEC      R2          ;DECREMENT LONG LOOP
119 020320 001365             BNE      1$         ;AGAIN
120 020322 005304             DEC      R4          ;DECREMENT RETRY COUNT
121 020324 001354             BNE      DMCXMT     ;SEND AGAIN
122 020326 010702             MOV      PC,R2      ;RETURN ADDR
123 020330 000412             BR       DMCIN      ;FORCE PROC ERR-SET BASE AGAIN-KILLS DTR
124 020332 000043             .WORD   43          ;RQI + BASE REQUEST
125 020334 017370             .WORD   17370       ;BASE ADDRESS AGAIN
126 020336 000000             .WORD   0           ;NO RESUME
127 020340 012703 000012      HNGLOP: MOV    #10.,R3 ;LONG LOOP COUNTER-HOLD DTR DOWN
128 020344 005300      1$:  DEC      R0          ;DECREMENT SHORT LOOP
129 020346 001376             BNE      1$         ;AGAIN
130 020350 005303             DEC      R3          ;DECREMENT LONG LOOP
131 020352 001374             BNE      1$         ;AGAIN
132 020354 000712             BR       DMC          ;HUNG UP LONG ENOUGH-ANSWER AGAIN
133
134 ;*****
135 ;* DMC REQUEST INPUT ROUTINE
136 ;*****
136 020356 005722      DMCIN: TST    (R2)+      ;POINT TO FIRST PARAMETER WORD
137 020360 112211             MOV      (R2)+,(R1) ;COMMAND TO DMC
138 020362 005202             INC      R2          ;TO NEXT PARAMETER WORD
139 020364 105711      DMCTST: TST   (R1)      ;IS RDYI SET?
140 020366 100411             BMI     RDYIOK       ;YES-OK
141 020370 105761 000002      TSTB   2(R1)         ;IS RDYO SET?
142
143 ;          ****NOTE****
144 ;          IF HUNG IN LOOP, IS SW7 OF SW PACK #2 ON?
144 020374 000402             BR       1$
145 020376 114076             .WORD   114076       ;CRC16 WORD FOR ROM #2
146 020400 177776             .WORD   -2          ;HEADER WORD FOR ROM #3
147 020402 100370      1$:  BPL      DMCTST     ;NO, WAIT
148 020404 010703             MOV      PC,R3      ;SET RETURN ADDR
149 020406 000415             BR       DMCOUT     ;CHECK DMC REQUEST
150 020410 000765             BR       DMCTST     ;WAIT TILL DMC IS READY
151 ;*****
152 ;* DMC LOAD INPUT ROUTINE
153 ;*****
154 020412 012261 000004      RDYIOK: MOV   (R2)+,4(R1) ;TO FIRST HALF DMC PORT
155 020416 012261 000006             MOV   (R2)+,6(R1) ;TO SECOND HALF DMC PORT
156 020422 000402             BR     2$
157 020424 173000             .WORD   MRESERVED
158 020426 000340             .WORD   RESERVED
159 020430 042711 000040      2$:  BIC     #40,(R1)   ;CLEAR RQI-GIVE TO DMC
160 020434 105711      1$:  TSTB   (R1)         ;TEST RDYI CLEAR
161 020436 100776             BMI     1$          ;NOT YET
162 020440 000112             JMP     (R2)         ;RETURN

```

```

163 ;*****
164 ;* DMC OUTPUT READY ROUTINE
165 ;*****
166 020442 132761 000003 000002 DMCOUT: BITB #3,2(R1) ;BA/CC OR CRL REQUEST
167 020450 001013 BNE 1$ ;CTL REQUEST
168 020452 132761 000004 000002 BITB #4,2(R1) ;XMIT OR RCV
169 020460 001413 BEQ 2$ ;XMIT COMPLETE
170 020462 005005 CLR R5 ;RECEIVE COMPLETE SET NON PENDING FLAG
171 020464 005715 TST (R5) ;CHECK FOR CODE 0,LOAD 0 AT LOC 0
172 020466 001010 BNE 2$ ;RECEIVED MESSAGE NO GOOD
173 020470 012600 MOV (SP)+,R0 ;RETURN UNIT # TO R0
174 020472 000005 RESET ;CLEAR DMC-11
175 020474 000137 000006 JMP @#6 ;AND JUMP TO LOADED PROGRAM
176 020500 032761 001730 000006 1$: BIT #1730,6(R1) ;FATAL ERROR?
177 020506 001314 BNE HNGLOP ;YES,START AGAIN AFTER TIME DELAY
178 020510 105061 000002 2$: CLRB 2(R1) ;CLEAR RDYO-THROW AWAY INFO
179 020514 000163 000002 JMP 2(R3) ;RETURN
180 ;*****
181 ;* FLOATING DEVICE MODULO TABLE
182 ;*****
183 020520 007 DEVTAB: .BYTE 7 ;DJ11 DEVICE MODULUS
184 020521 017 .BYTE 17 ;DH11
185 020522 007 .BYTE 7 ;DQ11
186 020523 007 .BYTE 7 ;DU11
187 020524 007 .BYTE 7 ;DUP11
188 020525 007 .BYTE 7 ;LK11-A
189 020526 007 .BYTE 7 ;DMC11
190 020527 000 .BYTE 0 ;FILLER
191 ;
; ***NOTE***
;THE NEXT 23 WORDS ARE ZERO FILLED
192 020576 060100 DMCE: .WORD 060100 ;CRC16 WORD FOR ROM #3
193 ;*****
194 ;* RELOCATION ROUTINE
195 ;*****
196 .=20600
197 020600 012702 020000 MOV #20000,R2
198 020604 012703 030000 MOV #30000,R3
199 020610 012223 2$: MOV (R2)+,(R3)+
200 020612 020227 020576 CMP R2,#20576
201 020616 001401 BEQ 1$
202 020620 000773 BR 2$
203 020622 000000 1$: HALT
204 000001 .END

```

SYMBOL TABLE

BDIAG	020054	DMCBGN	020000	DMCRCV	020242	INITSW=	173024	RESERV=	000340
CRCWD =	000000	DMCE	020576	DMCTST	020364	MRESER=	173000	R6	=000006
DEVTAB	020520	DMCIN	020356	DMCXMT	020256	NODEV	020040	R7	=000007
DIAG =	165564	DMCM	020012	FLOAT	020140	RDYIOK	020412	SETSTK	020060
DMC	020202	DMCOUT	020442	HNGLOP	020340				

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33

.REM \*

IDENTIFICATION  
-----

PRODUCT CODE:        XXXXXXXX-XX-XXXXX-X-X  
PRODUCT NAME:        M9312 DECNET BOOT - DU11  
PRODUCT DATE:        APRIL 1978  
MAINTAINER:         DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978 DIGITAL EQUIPMENT CORPORATION

\*

```

1      .REM      %
2
3      THIS ROM WILL BOOT THE DU OPTION.
4      TO BOOT UNIT 0,AND NOT RUN DIAGNOSTICS,THE START ADDR IS 173Y04.
5      TO BOOT UNIT 0,AND RUN CPU DIAGNOSTICS,THE START ADDR IS 173Y06.
6      TO BOOT UNIT 1,AND NOT RUN DIAGNOSTICS,THE START ADDR IS 173Y30.
7      TO BOOT UNIT 1,AND RUN CPU DIAGNOSTICS,THE START ADDR IS 173Y32.
8      THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.
9      IF ROM #1 IS IN SLOT 1 THE Y COMPONENT IS 00  ADDR. 1730XX
10     IF ROM #1 IS IN SLOT 2 THE Y COMPONENT IS 01  ADDR. 1732XX.
10     %

1      .TITLE  M9312 DECNET BOOT - DU11
2      ;      BASIC DEFINITIONS
3
4      000000      R0=%0
5      000001      R1=%1
6      000002      R2=%2
7      000003      R3=%3
8      000004      R4=%4
9      000005      R5=%5
10     000006      R6=%6
11     000007      R7=%7
12     000006      SP=%6
13     000007      PC=%7
14     000340      RESERVED=340
15     165564      DIAG=165564
16     173024      INITSW=173024
17     000000      CRCWD=0
18     173000      MRESERVED=173000
19     000226      SSYN=226
20     000220      DLE=220
21     000337      ASYN=337
22     000201      SOH=201
23     000005      ENQ=005
24     120001      POLY=120001
25
26     .NLIST  MC,MD
27     .LIST   ME
28
37
38
44 000000      .ENABL  ABS
45 020000      .=20000

```

```

1
2
3
4 020000      125      130
5 020002      000576
6 020004      000261
7 020006      012700      000000
8 020012      012701      160010
9 020016      010704
10 020020      103015
11 020022      000416
12 020024      173000
13 020026      000340
14 020030      000261
15 020032      012700      000001
16 020036      000765
17
18
19
20 020040      005202
21 020042      005303
22 020044      100002
23 020046      000000
24 020050      000776
25 020052      000002
26
27
28
29 020054      000137      165564
30
31
32
33
34 020060      012706      017776
35 020064      042700      177760
36 020070      010016
37 020072      010702
38 020074      062702      000466
39 020100      010704
40 020102      062704      177736
41
42
43
44
45 020106      011246
46 020110      166416      000202
47 020114      022726      005412
48 020120      001402
49 020122      000000
50 020124      000776
51 020126      012703      000006
52 020132      005013
53 020134      010443

;*****
;* CMND XW (DU11)
;*****
DUBGN: .ASCII 'UX' ;IDENTIFIER 'XU' FOR DU11 BOOT
        .WORD <ENDB00-.+2> ;OFFSET TO NEXT BOOT
        SEC ;ENTRY FOR DU11, NO CPU DIAG RUN
        MOV #0,R0 ;ENTRY FOR DU11, RUN CPU DIAG
EMDU:  MOV #160010,R1 ;PUT FLOATING BASE ADDR IN R1
        MOV PC,R4 ;GET RETURN ADDR
        BCC BDIAG ;GO TO DIAG IF ENABLED (C=0)
        BR SETSTK
        .WORD MRESERVED
        .WORD RESERVED
        SEC ;ENTRY FOR UNIT 1, NO CPU DIAG RUN
        MOV #1,R0 ;ENTRY FOR UNIT 1, RUN CPU DIAG
        BR EMDU
;*****
;* FLOATING DEVICE INTERRUPT ROUTINE
;*****
NODEV: INC R2 ;UPDATE R2 TO POINT TO NEXT DEV MODULO
        DEC R3 ;SUB ONE FROM R3
        BPL 1$ ;IF CANT FIND DEVICE, HALT
2$: HALT ;
        BR 2$ ;REVIEW FLOATING ADDRESS ASSIGNMENTS
1$: RTI ;RETURN
;*****
;* GO TO DIAG
;*****
BDIAG: JMP @#DIAG ;GO TO DIAG
        ;RETURN MADE THROUGH ADDR IN R4
;*****
;* FIND THE DEVICE IN FLOATING SPACE
;*****
SETSTK: MOV #17776,SP ;SET UP STACK
        BIC #177760,R0 ;PREVENT TRYING TO BOOT UNIT # > 15
        MOV R0,(SP) ;SAVE UNIT NUM AT 17776
2$: MOV PC,R2 ;SET UP R2 WITH
        ADD #DEVTAB-2$-2,R2 ;POINTER TO DEVTAB
3$: MOV PC,R4 ;SET UP R4 WITH
        ADD #NODEV-3$-2,R4 ;POINTER TO TRAP ROUTINE
        ;
        ; *****NOTE*****
        ;THE NEXT FOUR INSTRUCTIONS VERIFY THAT
        ;THE EXTENSION ROMS ARE PROPERLY INSTALLED.
        ;IF NOT, THE BOOT WILL HALT
        MOV (R2),-(SP) ;PUSH THE #7407 FROM ROM #3 ON THE STACK
        SUB 202(R4),(SP) ;SUBTRACT FROM IT THE #1775 OFF ROM #2
        CMP #5412,(SP)+ ;COMP IT WITH #5412
        BEQ 4$ ;IF NOT EQUAL, HALT
5$: HALT ;
        ; *****NOTE*****
        ;CHECK POS OF ROMS #2 AND #3
4$: MOV #6,R3 ;TRAP PS ADDR
        CLP (R3) ;CLR NEW PSW
        MOV R4,-(R3) ;SET TRAP ROUTINE ADDR IN LOC 4

```

```

54 020136 005303
55 020140 005711
56 020142 111204
57 020144 060401
58 020146 005201
59 020150 040401
60 020152 005703
61 020154 001371
62
63
64
65 020156 006300
66 020160 006300
67 020162 006300
68 020164 060001
69
70
71
72 020166 012706 017440
73 020172 010704
74 020174 000402
75 020176 025174
76 020200 177776
77 020202 062704 000344
78 020206 112403
79
80
81
82 020210 012711 000006
83 020214 012761 036226 000002
84 020222 000402
85 020224 173000
86 020226 000340
87 020230 032711 001000
88 020234 001775
89 020236 032711 020000
90 020242 001775
91 020244 022121
92 020246 052721 000030
93 020252 112411
94 020254 105761 177776
95 020260 100375
96 020262 005303
97 020264 001372
98
99
100
101 020266 042741 000020
102 020272 024141
103 020274 005004
104 020276 012703 000010
105 020302 004767 000052
106 020306 001327

          DEC      R3          ;R3 CONTAINS DU11 POS IN FLOAT SPACE
FLOAT:    TST      (R1)        ;TEST FOR DEVICE, MAYBE TRAP TO NODEV
          MOVVB   (R2),R4      ;MODULO INCREMENT
          ADD     R4,R1        ;UPDATE ADDRESS
          INC     R1          ;BY MODULO
          BIC     R4,R1        ;IN TABLE
          TST     R3          ;IS THIS A THE ONE?
          BNE     FLOAT       ;NOT YET
;*****
;* ADD UNIT DISPLACEMENT TO UNIT 0 CSR ADDR
;*****
          ASL     R0          ;UNIT # TIMES 2
          ASL     R0          ;UNIT # TIMES 4
          ASL     R0          ;UNIT # TIMES 8
          ADD     R0,R1        ;CSR ADDR + UNIT*8
;*****
;* SETUP TO SEND MESSAGE
;*****
SNDREQ:   MOV     #17400+<8,*4>,SP ;SET STACK ADDR-17400+8 TIMES LOOP DEC.
SNDREQ1:  MOV     PC,R4        ;SET UP R4 WITH
          BR      3$
          .WORD   025174      ;CRC16 WORD FOR ROM #1
          .WORD   -2         ;HEADER WORD FOR ROM #2
3$:       ADD     #DUREQ-SNDREQ1-2,R4 ;POINTER TO DUREQ
          MOVVB   (R4)+,R3    ;MESSAGE LENGTH + PAD
;*****
;* SEND A BLOCK ON THE LINK
;*****
          MOV     #6,(R1)     ;SET DTR AND RTS
          MOV     #36000+SSYN,2(R1) ;SET FOR DU-11 (INT SYNCHRONOUS-8 BIT)
          BR      2$
          .WORD   MRESERVED
          .WORD   RESERVED
2$:       BIT     #1000,(R1)   ;TEST FOR DSR
          BEQ     2$         ;NOT YET
1$:       BIT     #20000,(R1) ;TEST FOR CTS
          BEQ     1$         ;NOT YET
          CMP     (R1)+,(R1)+ ;SET TO XMIT CSR
          BIS     #30,(R1)+   ;HDX AND SEND ON
SEND:     MOVVB   (R4)+,(R1)  ;MOVE TO DEVICE BUFFER
STEST:    TSTB   -2(R1)      ;TEST FOR DONE
          BPL     STEST      ;NOT YET
          DEC     R3          ;DECREMENT COUNT
          BNE     SEND       ;MORE TO SEND
;*****
;* RECEIVE A MESSAGE FROM THE LINK
;*****
GETMSG:   BIC     #20,-(R1)    ;DROP SEND
          CMP     -(R1),-(R1) ;RESET TO RCV CSR AND CLR RCV BUFFER
          CLR     R4          ;BUFFER ADDR
          MOV     #8.,R3      ;HEADER LENGTH
          JSR     PC,RCV1     ;GET THE HEADER
          BNE     SNDREQ     ;NO GOOD CRC

```

```

107 020310 122527 000220      CMPB    (R5)+,#DLE      ;IS IT A DLE MESSAGE(LOC 0)
108 020314 001324              BNE     SNDREQ         ;NO
109 020316 113703 000002      MOVB   @#2,R3         ;HIGH BYTE COUNT
110 020322 042703 177700      BIC    #177700,R3     ;CLEAR FLAGS AND OTHER BYTE
111 020326 000303              SWAB   R3             ;SWAP BYTES
112 020330 152503              BISB   (R5)+,R3       ;LOW BYTE COUNT(LOC 1)
113 020332 122323              CMPB   (R3)+,(R3)+    ;ADD TWO FOR CRC
114 020334 005004              CLR    R4             ;BUFFER ADDR
115 020336 004767 000026      JSR    PC,RECV        ;GET DATA FIELD
116 020342 001311              BNE     SNDREQ         ;NO GOOD
117 020344 005715              TST    (R5)           ;CHECK FOR CODE 0, LOAD 0 AT LOC 0
118 020346 001307              BNE     SNDREQ         ;NO
119 020350 013700 017776      MOV    @#17776,R0     ;SAVE UNIT NUM FOR SECONDARY BOOT
120 020354 000137 000006      JMP    @#6            ;TRANSFER TO IT
121
122
123
124 020360 042711 000024      RECV1: BIC    #24,(R1)   ;CLEAR RTS AND SEARCH SYNC
125 020364 012711 000422      MOV    #422,(R1)     ;SET SEARCH,STRIP,DTR
126 020370 005005              RECV:  CLR    R5       ;INITIALIZE CRC
127 020372 000403              BR     RTEST
128 020374 000000              .WORD  0             ;FILLER
129 020376 056471              .WORD  056471        ;CRC16 WORD FOR ROM #2
130 020400 177776              .WORD  -2            ;HEADER WORD FOR ROM #3
131 020402 012702 000017      RTEST: MOV    #15.,R2  ;LONG LOOP VALUE
132 020406 005046              CLR    -(SP)         ;SHORT LOOP
133 020410 105711              2$:   TSTB   (R1)     ;TEST FOR DEVICE DONE
134 020412 100421              BMI    RDONE         ;ALL DONE
135 020414 005316              DEC    (SP)         ;DECREMENT SHORT LOOP
136 020416 001374              BNE    2$           ;AGAIN
137 020420 005302              DEC    R2           ;DECREMENT LONG LOOP
138 020422 000402              BR     3$
139 020424 173000              .WORD  MRESERVED
140 020426 000340              .WORD  RESERVED
141 020430 001367              3$:   BNE    2$       ;KEEP GOING
142 020432 105706              TSTB   SP           ;CHECK STACK AT OR BELOW 17400
143 020434 003256              BGT    SNDRQ1       ;LOOP ONCE MOR(8 TIMES TOTAL)
144 020436 005011              CLR    (R1)         ;DROP DTR-HANG UP
145 020440 012703 000012      HNGLOP: MOV   #10.,R3 ;LONG LOOP COUNTER
146 020444 005302              4$:   DEC    R2       ;DECREMENT SHORT LOOP
147 020446 001376              BNE    4$           ;AGAIN
148 020450 005303              DEC    R3           ;DECREMENT LONG LOOP
149 020452 001374              BNE    4$           ;AGAIN
150 020454 000644              BR     SNDREQ        ;HUNG UP LONG ENOUGH-ANSWER AGAIN
151 020456 005726              RDONE: TST    (SP)+   ;CLEAN UP STACK-LOOP CTR
152 020460 042711 000400      BIC    #400,(R1)     ;NO STRIP SYNC
153 020464 116114 000002      MOVB   2(R1),(R4)    ;STORE IT
154 020470 112446              1$:   MOVB   (R4)+,-(SP);BYTE TO ADD
155 020472 012702 000010      MOV    #8.,R2       ;NUMBER BITS PER BYTE
156 020476 000241              CRCLOP: CLC         ;CLEAR CARRY
157 020500 006005              ROR    R5           ;LOW BIT PARTIAL TO CARRY
158 020502 006016              ROR    (SP)         ;CARRY TO BYTE AND BYTE TO CARRY
159 020504 102006              BVC   1$           ;XOR OF PARTIAL AND BYTE(LOW BITS)

```



```

160 020506 012746 120001      MOV    #POLY,-(SP)      ;XOR POLY TO PARTIAL(4 INSTRUCTIONS)
161 020512 040516           BIC    R5,(SP)         ;NOT PARTIAL AND POLY
162 020514 042705 120001      BIC    #POLY,R5       ;NOT POLY AND PARTIAL
163 020520 052605           BIS    (SP)+,R5       ;POLY XOR PARTIAL
164 020522 005302 1$:      DEC    R2             ;DECREMENT BIT COUNT
165 020524 003364           BGT    CRCL0P         ;ONCE MORE
166 020526 005726           TST    (SP)+         ;CLEAN UP STACK-BYTE TO ADD
167 020530 005303           DEC    R3             ;DECREMENT BYTE COUNT
168 020532 003323           BGT    RTEST         ;ONCE MORE
169 020534 005705           TST    R5             ;SET CC
170 020536 000207           RTS    PC             ;RETURN
171                          ;*****
172                          ;* DECNET BOOT REQUEST
173                          ;*****
174 020540      024      226      226  DUREQ: .BYTE  20.,SSYN,SSYN,SSYN,DLE,4,300,0,0,1,021,120
      020543      226      220      004
      020546      300      000      000
      020551      001      021      120
175
176 020554      010      002      001      .BYTE  10,2,1,0,242,60      ;DUREQ REQUEST MESSAGE
      020557      000      242      060
177
178                          ;*****
179                          ;* FLOATING DEVICE MODULO
180                          ;*****
181 020562      007      DEVTAB: .BYTE  7      ;DJ11 DEVICE MODULUS
182 020563      017      .BYTE  17      ;DH11
183 020564      007      .BYTE  7      ;DQ11
184 020565      007      .BYTE  7      ;DU11
185
186                          ;      ***NOTE***
187 020576 075042      ENDBOO: .WORD  075042      ;THE NEXT 4 WORDS ARE ZERO FILLED
188                          ;CRC16 WORD FOR ROM #3
189                          ;*****
190                          ;* RELOCATION ROUTINE
191                          ;*****
191      020600      . =20600
192 020600 012702 020000      MOV    #20000,R2
193 020604 012703 030000      MOV    #30000,R3
194 020610 012223 2$:      MOV    (R2)+,(R3)+
195 020612 020227 020576      CMP    R2,#20576
196 020616 001401      BEQ    1$
197 020620 000773      BR     2$
198 020622 000000 1$:      HALT
199      000001      .END

```

## SYMBOL TABLE

ASYN = 000337	DUBGN 020000	HNGLOP 020440	RECV1 020360	SETSTK 020060
BDIAG 020054	DUREQ 020540	INITSW= 173024	RESERV= 000340	SNDREQ 020166
CRCLOP 020476	EMDU 020012	MRESER= 173000	RTEST 020402	SNDRQ1 020172
CRCWD = 000000	ENDBOO 020576	NODEV 020040	R6 = 0000006	SOH = 000201
DEVTAB 020562	ENQ = 000005	POLY = 120001	R7 = 0000007	SSYN = 000226
DIAG = 165564	FLOAT 020140	RDONE 020456	SEND 020252	STEST 020254
DLE = 000220	GETMSG 020266	RECV 020370		

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33

.REM %

IDENTIFICATION  
-----

PRODUCT CODE:       XXXXXXXX-XX-XXXXX-X-X  
PRODUCT NAME:        M9312 DECNET BOOT - DUP11  
PRODUCT DATE:        APRIL 1978  
MAINTAINER:           DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978 DIGITAL EQUIPMENT CORPORATION

%

```

1      .REM      %
2          THIS ROM WILL BOOT THE DUP OPTION.
3      TO BOOT UNIT 0,AND NOT RUN DIAGNOSTICS,THE START ADDR IS 173Y04.
4      TO BOOT UNIT 0,AND RUN CPU DIAGNOSTICS,THE START ADDR IS 173Y06.
5      TO BOOT UNIT 1,AND NOT RUN DIAGNOSTICS,THE START ADDR IS 173Y30.
6      TO BOOT UNIT 1,AND RUN CPU DIAGNOSTICS,THE START ADDR IS 173Y32.
7      THE Y COMPONENT OF THE ADDRESS REPRESENTS BITS 7 AND 8 OF THE WHOLE WORD.
8      IF ROM #1 IS IN SLOT 1 THE Y COMPONENT IS 00 ADDR. 1730XX
9      IF ROM #1 IS IN SLOT 2 THE Y COMPONENT IS 01 ADDR. 1732XX.
10     %

```

```

1      .TITLE  M9312 DECNET BOOT - DUP11
2      ;      BASIC DEFINITIONS
3
4      000000      R0=%0
5      000001      R1=%1
6      000002      R2=%2
7      000003      R3=%3
8      000004      R4=%4
9      000005      R5=%5
10     000006      R6=%6
11     000007      R7=%7
12     000006      SP=%6
13     000007      PC=%7
14     000340      RESERVED=340
15     165564      DIAG=165564
16     173024      INITSW=173024
17     000000      CRCWD=0
18     173000      MRESERVED=173000
19     000226      SSYN=226
20     000220      DLE=220
21     000337      ASYN=337
22     000201      SOH=201
23     000005      ENQ=005
24     120001      POLY=120001
25     .NLIST  MC,MD
26     .LIST   ME
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44     000000      .ENABL  ABS
45     020000      .=20000

```

```

1          ;*****
2          ;* CMND XW (DUP11)
3          ;*****
4 020000      127      130
5 020002      000576
6 020004      000261
7 020006      012700      000000
8 020012      012701      160010
9 020016      010704
10 020020      103015
11 020022      000416
12 020024      173000
13 020026      000340
14 020030      000261
15 020032      012700      000001
16 020036      000765
17          ;*****
18          ;* FLOATING DEVICE INTERRUPT ROUTINE
19          ;*****
20 020040      005202
21 020042      005303
22 020044      100002
23 020046      000000
24 020050      000776
25 020052      000002
26
27          ;* GO TO DIAG
28          ;*****
29 020054      000137      165564
30
31          ;*****
32          ;* FIND THE DEVICE IN FLOATING SPACE
33          ;*****
34 020060      012706      017776
35 020064      042700      177760
36 020070      010016
37 020072      010702
38 020074      062702      000474
39 020100      010704
40 020102      062704      177736
41
42          ;*****
43          ;THE NEXT FOUR INSTRUCTIONS VERIFY THAT
44          ;THE EXTENSION ROMS ARE PROPERLY INSTALLED.
45          ;IF NOT, THE BOOT WILL HALT
46 020106      011246          MOV      (R2),-(SP)      ;PUSH THE #7407 FROM ROM #3 ON THE STACK
47 020110      166416      000202      SUB      202(R4),(SP)      ;SUBTRACT FROM IT THE #1775 OFF ROM #2
48 020114      022726      005412      CMP      #5412,(SP)+      ;COMP IT WITH #5412
49 020120      001402          BEQ      4$              ;IF NOT EQUAL, HALT
50 020122      000000          5$:      HALT          ;*****
51 020124      000776          BR      5$              ;CHECK POS OF ROMS #2 AND #3
52 020126      012703      000006      4$:      MOV      #6,R3      ;TRAP PS ADDR
53 020132      005013          CLR      (R3)          ;CLR NEW PSW
          MOV      R4,-(R3)      ;SET TRAP ROUTINE ADDR IN LOC 4

```

```

54
55 020136 005711          FLOAT: TST      (R1)          ;R3 CONTAINS DUP11 POS IN FLOAT SPACE
56 020140 111204          MOVVB   (R2),R4        ;TEST FOR DEVICE, MAYBE TRAP TO NODEV
57 020142 060401          ADD     R4,R1         ;MODULO INCREMENT
58 020144 005201          INC     R1           ;UPDATE ADDRESS
59 020146 040401          BIC    R4,R1         ;BY MODULO
60 020150 005703          TST    R3            ;IN TABLE
61 020152 001371          BNE    FLOAT         ;IS THIS A THE ONE?
62                          ;*****
63                          ;* ADD UNIT DISPLACEMENT TO UNIT 0 CSR ADDR
64                          ;*****
65 020154 006300          ASL    R0            ;UNIT # TIMES 2
66 020156 006300          ASL    R0            ;UNIT # TIMES 4
67 020160 006300          ASL    R0            ;UNIT # TIMES 8
68 020162 060001          ADD    R0,R1         ;CSR ADDR + UNIT*8
69                          ;*****
70                          ;* SETUP TO SEND MESSAGE
71                          ;*****
72 020164 012706 017440  SNDREQ: MOV    #17400+<8,*4>,SP      ;SET STACK ADDR-17400+8 TIMES LOOP DEC.
73 020170 010704          SNDRQ1: MOV   PC,R4        ;SET UP R4 WITH
74 020172 000403          BR     3$              ;FILLER
75 020174 000000          .WORD  0                ;CRC16 WORD FOR ROM #1
76 020176 024572          .WORD  024572           ;HEADER WORD FOR ROM #2
77 020200 177776          .WORD  -2               ;POINTER TO DUPREQ
78 020202 062704 000354  3$:  ADD    #DUPREQ-SNDRQ1-2,R4      ;MESSAGE LENGTH + PAD
79 020206 112403          MOVVB  (R4)+,R3
80                          ;*****
81                          ;* SEND A BLOCK ON THE LINK
82                          ;*****
83 020210 012711 000006  MOV    #6,(R1)          ;SET DTR AND RTS
84 020214 012761 101226 000002  MOV    #101000+SSYN,2(R1) ;SET FOR DUP-11 (DEC MODE-CRC INH)
85 020222 000402          BR     2$              ;MRESERVED
86 020224 173000          .WORD  MRESERVED
87 020226 000340          .WORD  RESERVED
88 020230 032711 001000  2$:  BIT    #1000,(R1)      ;TEST FOR DSR
89 020234 001775          BEQ    2$              ;NOT YET
90 020236 032711 020000  1$:  BIT    #20000,(R1)     ;TEST FOR CTS
91 020242 001775          BEQ    1$              ;NOT YET
92 020244 022121          CMP    (R1)+,(R1)+    ;SET TO XMIT CSR
93 020246 052721 000030  BIS    #30,(R1)+      ;HDX AND SEND ON
94 020252 012711 000626  MOV    #400+SSYN,(R1) ;START IT UP WITH TSOM
95 020256 000401          BR     STEST          ;TEST FOR DONE
96 020260 112411          SEND: MOVVB (R4)+,(R1)  ;MOVE TO DEVICE BUFFER
97 020262 105761 177776  STEST: TSTB  -2(R1)     ;TEST FOR DONE
98 020266 100375          BPL    STEST          ;NOT YET
99 020270 005303          DEC    R3            ;DECREMENT COUNT
100 020272 001372          BNE    SEND          ;MORE TO SEND
101                          ;*****
102                          ;* RECEIVE A MESSAGE FROM THE LINK
103                          ;*****
104 020274 042741 000020  GETMSG: BIC   #20,-(R1)   ;DROP SEND
105 020300 024141          CMP    -(R1),-(R1)    ;RESET TO RCV CSR AND CLR RCV BUFFER
106 020302 005004          CLR    R4            ;BUFFER ADDR

```

```

107 020304 012703 000010      MOV      #8.,R3      ;HEADER LENGTH
108 020310 004767 000052      JSR      PC,RECV1    ;GET THE HEADER
109 020314 001323              BNE      SNDREQ      ;NO GOOD CRC
110 020316 122527 000220      CMPB    (R5)+,#DLE   ;IS IT A DLE MESSAGE(LOC 0)
111 020322 001320              BNE      SNDREQ      ;NO
112 020324 113703 000002      MOVB    @#2,R3      ;HIGH BYTE COUNT
113 020330 042703 177700      BIC     #177700,R3   ;CLEAR FLAGS AND OTHER BYTE
114 020334 000303              SWAB    R3           ;SWAP BYTES
115 020336 152503              BISB    (R5)+,R3     ;LOW BYTE COUNT(LOC 1)
116 020340 122323              CMPB    (R3)+,(R3)+ ;ADD TWO FOR CRC
117 020342 005004              CLR     R4           ;BUFFER ADDR
118 020344 004767 000036      JSR      PC,RECV    ;GET DATA FIELD
119 020350 001305              BNE      SNDREQ      ;NO GOOD
120 020352 005715              TST     (R5)         ;CHECK FOR CODE 0, LOAD 0 AT LOC 0
121 020354 001303              BNE      SNDREQ      ;NO
122 020356 013700 017776      MOV     @#17776,R0   ;SAVE UNIT NUM FOR SECONDARY BOOT
123 020362 000137 000006      JMP     @#6          ;TRANSFER TO IT
124
125
126
127 020366 042711 000024      RECV1:  BIC     #24,(R1) ;CLEAR RTS AND SEARCH SYNC
128 020372 000403              BR      1$
129 020374 000000              .WORD  0             ;FILLER
130 020376 024437              .WORD  024437        ;CRC16 WORD FOR ROM #2
131 020400 177776              .WORD  -2            ;HEADER WORD FOR ROM #3
132 020402 012711 000422      1$:    MOV     #422,(R1) ;SET SEARCH,STRIP,DTR
133 020406 005005              RECV:   CLR     R5     ;INITIALIZE CRC
134 020410 012702 000017      RTEST:  MOV     #15.,R2 ;LONG LOOP VALUE
135 020414 005046              CLR     -(SP)        ;SHORT LOOP
136 020416 105711              2$:    TSTB   (R1)     ;TEST FOR DEVICE DONE
137 020420 100421              BMI     RDONE        ;ALL DONE
138 020422 000402              BR      1$
139 020424 173000              .WORD  MRESERVED
140 020426 000340              .WORD  RESERVED
141 020430 005316              1$:    DEC     (SP)    ;DECREMENT SHORT LOOP
142 020432 001371              BNE     2$           ;AGAIN
143 020434 005302              DEC     R2           ;DECREMENT LONG LOOP
144 020436 001367              BNE     2$           ;KEEP GOING
145 020440 105706              TSTB   SP           ;CHECK STACK AT OR BELOW 17400
146 020442 003252              BGT     SNDRQ1       ;LOOP ONCE MOR(8 TIMES TOTAL)
147 020444 005011              CLR     (R1)        ;DROP DTR-HANG UP
148 020446 012703 000012      HNGLOP: MOV     #10.,R3 ;LONG LOOP COUNTER
149 020452 005302              4$:    DEC     R2     ;DECREMENT SHORT LOOP
150 020454 001376              BNE     4$           ;AGAIN
151 020456 005303              DEC     R3           ;DECREMENT LONG LOOP
152 020460 001374              BNE     4$           ;AGAIN
153 020462 000640              BR      SNDREQ       ;HUNG UP LONG ENOUGH-ANSWER AGAIN
154 020464 005726              RDONE:  TST     (SP)+ ;CLEAN UP STACK-LOOP CTR
155 020466 042711 000400              BIC     #400,(R1)    ;NO STRIP SYNC
156 020472 116114 000002              MOVB    2(R1),(R4)   ;STORE IT
157 020476 112446              1$:    MOVB    (R4)+,-(SP) ;BYTE TO ADD
158 020500 012702 000010              MOV     #8.,R2      ;NUMBER BITS PER BYTE
159 020504 000241              CRCLOP: CLC         ;CLEAR CARRY

```

```

160 020506 006005          ROR      R5          ;LOW BIT PARTIAL TO CARRY
161 020510 006016          ROR      (SP)         ;CARRY TO BYTE AND BYTE TO CARRY
162 020512 102006          BVC      1$          ;XOR OF PARTIAL AND BYTE(LOW BITS)
163 020514 012746 120001  MOV      #POLY,-(SP)  ;XOR POLY TO PARTIAL(4 INSTRUCTIONS)
164 020520 040516          BIC      R5,(SP)     ;NOT PARTIAL AND POLY
165 020522 042705 120001  BIC      #POLY,R5    ;NOT POLY AND PARTIAL
166 020526 052605          BIS      (SP)+,R5   ;POLY XOR PARTIAL
167 020530 005302 1$:    DEC      R2          ;DECREMENT BIT COUNT
168 020532 003364          BGT      CRCLOP      ;ONCE MORE
169 020534 005726          TST      (SP)+      ;CLEAN UP STACK-BYTE TO ADD
170 020536 005303          DEC      R3          ;DECREMENT BYTE COUNT
171 020540 003323          BGT      RTEST      ;ONCE MORE
172 020542 005705          TST      R5          ;SET CC
173 020544 000207          RTS      PC          ;RETURN
174
175
176
177 020546      024      226      226      DUPREQ: .BYTE 20.,SSYN,SSYN,SSYN,DLE,4,300,0,0,1,021,120
      020551      226      220      004
      020554      300      000      000
      020557      001      021      120
178
179 020562      010      012      001      .BYTE 10,10.,1,0,43,362 ;DUPREQ REQUEST MESSAGE
      020565      000      043      362
180
181
182
183
184 020570      007
185 020571      017
186 020572      007
187 020573      007
188 020574      007
189 020575      000
190
191 020576 036074          ENDBOO: .WORD 036074 ;CRC16 WORD FOR ROM #3
192
193
194
195
196 020600 012702 020000          MOV      #20000,R2
197 020604 012703 030000          MOV      #30000,R3
198 020610 012223 2$:    MOV      (R2)+,(R3)+
199 020612 020227 020576          CMP      R2,#20576
200 020616 001401          BEQ      1$
201 020620 000773          BR       2$
202 020622 000000 1$:    HALT
203 020623 000001          .END

```



## SYMBOL TABLE

ASYN = 000337	DUPBGN 020000	HNGLOP 020446	RECV1 020366	SETSTK 020060
BDIAG 020054	DUPREQ 020546	INITSW= 173024	RESERV= 000340	SNDREQ 020164
CRCLOP 020504	EMDUP 020012	MRESER= 173000	RTEST 020410	SNDRO1 020170
CRCWD = 000000	ENDBOO 020576	NODEV 020040	R6 = 0000006	SOH = 000201
DEVTAB 020570	ENQ = 000005	POLY = 120001	R7 = 0000007	SSYN = 000226
DIAG = 165564	FLOAT 020136	RDONE 020464	SEND 020260	STEST 020262
DLE = 000220	GETMSG 020274	RECV 020406		