

3 *** HBASH - HB ASSEMBLER.
 4 *
 5 * J. G. LETWIN, 09/76, FOR *WINTEK* CORP.
 6 *
 7 * COPYRIGHT 09/76, *WINTEK* CORPORATION,
 8 * LAFAYETTE, IND.

10 *** HBASH - HB RESIDENT ASSEMBLER.
 11 *
 12 * SOFTWARE ISSUE NUMBER:
 13 *
 14 * 0104.02.00. /78.10.6C/
 15 * 79/12 --.05.00

17 **** ASSEMBLY CONSTANTS.

18
 19 000.002 VER EQU 2 VERSION NUMBER
 20 000.000 LEV EQU 0 VERSION LEVEL
 21 000.101 MOD EQU 'A' MODIFICATION LEVEL
 22

23 ** ERROR FLAGS

24
 25 000.001 ERR.U EQU 0010 *U* - UNDEFINED
 26 000.002 ERR.R EQU 0020 ** - ILLEGAL REGISTER SPECIFICATION
 27 000.004 ERR.D EQU 0040 *D* - DOUBLY DEFINED SYMBOL
 28 000.010 ERR.A EQU 0100 ** - EXPRESSION ERROR
 29 000.020 ERR.V EQU 0200 *V* - VALUE TOO LARGE FOR FIELD
 30 000.040 ERR.F EQU 0400 *F* - ILLEGAL STATEMENT FORMAT
 31 000.100 ERR.O EQU 1000 *O* - OPCODE ERROR
 32 000.200 ERR.P EQU 2000 *P* - PROGRAMMER FLAGGED ERROR
 33

34 ** LIST OPTIONS.

35
 36 000.001 LST.L EQU 0010 MASTER LIST FLAG
 37 000.002 LST.I EQU 0020 LIST IF-SKIPPED LINES
 38 000.004 LST.C EQU 0040 LIST INCLUDED CODE
 39 000.200 LST.G EQU 2000 LIST ALL GENERATED BYTES
 40

41 ** SYMBOL DEFINITION TYPES.

42
 43 000.000 ST.UND EQU 0 UNDEFINED
 44 000.001 ST.LAB EQU 1 LABEL
 45 000.002 ST.EQU EQU 2 DEFINED VIA *EQU*
 46 000.003 ST.SET EQU 3 DEFINED VIA *SET*
 47 000.100 ST.REL EQU 1000 RELOCATABLE
 48 000.200 ST.DBL EQU 2000 DOUBLY DEFINED
 49

51 ** CHARACTER TYPES

52
 53 000.200 CT.ALPH EQU 10000000B ALPHA CHARACTER

```

54
55
56 **      CHANNEL NUMBERS
57
000.000 58 CN.RIN EQU 0      BINARY FILE
000.001 59 CN.LST EQU 1      LISTING FILE
000.002 60 CN.SOU EQU 2      SOURCE INPUT FILE
000.003 61 CN.XTX EQU 3      XTEXT
62
63
64 **      MACHINE INSTRUCTIONS
65
000.303 66 MI.JMP EQU 3030    JMP
000.072 67 MI.LDA EQU 0720    LDA
000.311 68 MI.RET EQU 3110    RET
000.043 69 MI.INXH EQU 430    INX H INSTRUCTIIN
000.325 70 MI.PSHD EQU 3250    PUSH D
71
000.000 72 XTEXT ASCII
73
74X **     ASCII CHARACTER EQUIVALENCES.
75X
000.015 76X CR EQU 13      CARRIAGE RETURN
000.012 77X LF EQU 10      LINE FEED
000.200 78X NULL EQU 2000    PAD CHARACTER
000.000 79X NUL2 EQU 0
000.007 80X BELL EQU 7      BELL CHARACTER
000.177 81X RUBOUT EQU 177Q
000.010 82X BKSP EQU 100     CTL-H
000.026 83X C.SYN EQU 260    SYNC
000.002 84X C.STX EQU 2      STX
000.047 85X QUOTE EQU 47Q
000.011 86X TAB EQU 11Q
000.033 87X ESC EQU 33Q
000.012 88X NL EQU 12Q      NEW LINE (HDOS SYSTEMS)
000.212 89X ENL EQU NL+200Q  NL + END-OF-LINE-FLAG
000.014 90X FF EQU 14Q     FORM FEED
000.001 91X CTLA EQU 01Q     CTL-A
000.002 92X CTLB EQU 02Q     CTL-B
000.003 93X CTLC EQU 03Q     CTL-C
000.004 94X CTLD EQU 04Q     CTL-D
000.017 95X CTLO EQU 17Q     CTL-O
000.020 96X CTLP EQU 20Q     CTL-P
000.021 97X CTLQ EQU 21Q     CTL-Q
000.023 98X CTLS EQU 23Q     CTL-S
000.032 99X CTLZ EQU 32Q     CTL-Z
000.000 100 XTEXT DIRDEF

```

HEADING

DIR

15:17:59 16-MAY-80

```

102X **      DIRECTORY ENTRY FORMAT
103X
000.000     104X      ORG      0
105X
106X
000.377     107X DF.EMP  EQU      3770      FLAGS ENTRY EMPTY
000.376     108X DF.CLR  EQU      3760      FLAGS ENTRY EMPTY; REST OF DIR ALSO CLEAR
109X
000.000     110X DIR.NAM  DS        8          NAME
000.010     111X DIR.EXT  DS        3          EXTENSION
000.013     112X DIR.PRO  DS        1          PROJECT
000.014     113X DIR.VER  DS        1          VERSION
000.015     114X DIR.IDL  EQU      *          FILE IDENTIFICATION LENGTH
115X
000.015     116X DIR.CLU  DS        1          CLUSTER FACTOR
000.016     117X DIR.FLG  DS        1          FLAGS
000.017     118X          DS        1          RESERVED
000.020     119X DIR.FGN  DS        1          FIRST GROUP NUMBER
000.021     120X DIR.LGN  DS        1          LAST GROUP NUMBER
000.022     121X DIR.LSI  DS        1          LAST SECTOR INDEX (IN LAST GROUP)
000.023     122X DIR.CRD  DS        2          CREATION DATE
000.025     123X DIR.ALD  DS        2          LAST ALTERATION DATE
124X
000.027     125X DIRELEN  EQU      *          DIRECTORY ENTRY LENGTH
000.027     126          XTEXT  DEVDEF

```

```

128X **      DEVICE TABLE ENTRIES
129X
000.000     130X      ORG      0
131X
000.000     132X DEV.NAM  DS        2          DEVICE NAME
000.000     133X DV.EL   EQU      00000000B    END OF DEVICE LIST FLAG
000.001     134X DV.NU   EQU      00000001B    DEVICE ENTRY NOT IN USE
135X
000.002     136X DEV.RES  DS        1          DRIVER RESIDENSE CODE
000.001     137X DR.IM   EQU      00000001B    DRIVER IN MEMORY
000.002     138X DR.FR   EQU      00000010B    DRIVER PERMINANTLY RESIDENT
139X
000.003     140X DEV.JMP  DS        1          JMP TO PROCESSOR
000.004     141X DEV.DPA  DS        2          DRIVER ADDRESS
000.006     142X DEV.FLG  DS        1          FLAG BYTE
000.001     143X DT.DD   EQU      00000001B    DIRECTORY DEVICE
000.002     144X DT.CR   EQU      00000010B    CAPABLE OF READ OPERATION
000.004     145X DT.CW   EQU      00000100B    CAPABLE OF WRITE OPERATION
146X
000.007     147X DEV.SPG  DS        1          SECTORS PER GROUP THIS DEVICE
000.010     148X DEV.MUM  DS        1          MOUNTED UNIT MASK
000.011     149X DEV.MNU  DS        1          MAXIMUM NUMBER OF UNITS
000.012     150X DEV.UNT  DS        2          ADDRESS OF UNIT SPECIFIC DATA TABLE
151X
000.014     152X DEV.DVL  DS        2          DRIVER BYTE LENGTH
000.016     153X DEV.DVG  DS        1          DRIVER ROUTINE GROUP ADDRESS
154X

```

```

000.017          155X DEVELEN EQU      *          DEVICE TABLE ENTRY LENGTH
................................................................
................................................................
157X **          UNIT SPECIFIC DEVICE DATA TABLE ENTRIES
158X
000.000          159X          ORG          0
160X
000.000          161X UNT.FLG DS          1          UNIT SPECIFIC *DEV.FLG*
000.001          162X UNT.GRT DS          2          ADDRESS OF GROUP RESERVATION TABLE (IF DT.DD)
000.003          163X UNT.GTS DS          2          GRT SECTOR NUMBER
000.005          164X UNT.DIS DS          2          DIRECTORY FIRST SECTOR NUMBER
165X
000.007          166X UNT.SIZ EQU      *          SIZE OF UNIT SPECIFIC DATA TABLE PER UNIT
000.007          167          XTEXT      HOSDEF
................................................................
................................................................
169X **          HOSDEF - DEFINE HOS PARAMETER.
170X *
171X
172X
000.026          173X VERS   EQU          1*16+6          VERSION 1.6
174X
000.377          175X SYSCALL EQU          3770          SYSCALL INSTRUCTION
176X
000.000          177X
178X          ORG          0
179X
180X *          RESIDENT FUNCTIONS
181X
000.000          182X .EXIT  DS          1          EXIT (MUST BE FIRST)
000.001          183X .SCIN  DS          1          SCIN
000.002          184X .SCOUT DS          1          SCOUT
000.003          185X .FRINT DS          1          PRINT
000.004          186X .READ  DS          1          READ
000.005          187X .WRITE DS          1          WRITE
000.006          188X .CONSL DS          1          SET/CLEAR CONSOLE OPTIONS
000.007          189X .CLRCD  DS          1          CLEAR CONSOLE BUFFER
000.010          190X .LOAD0  DS          1          LOAD AN OVERLAY
000.011          191X .VERS  DS          1          RETURN HDOS VERSION NUMBER
000.012          192X .SYSRES DS          1          PRECEDING FUNCTIONS ARE RESIDENT
193X
194X
000.040          195X *          *HDOSOVLO.SYS* FUNCTIONS
196X
000.040          197X          ORG          40A
198X
000.040          199X .LINK  DS          1          LINK (MUST BE FIRST)
000.041          200X .CTLC  DS          1          CTL-C
000.042          201X .OPENR DS          1          OPENR
000.043          202X .OPENW DS          1          OPENW
000.044          203X .OPENU DS          1          OPENU
000.045          204X .OPENC DS          1          OPENC
000.046          205X .CLOSE DS          1          CLOSE

```

HOSDEF

000.047	206X	.POSIT	DS	1	POSITION
000.050	207X	.DELET	DS	1	DELETE
000.051	208X	.RENAM	DS	1	RENAME
000.052	209X	.SETTP	DS	1	SETTOP
000.053	210X	.DECODE	DS	1	NAME DECODE
000.054	211X	.NAME	DS	1	GET FILE NAME FROM CHANNEL
000.055	212X	.CLEAR	DS	1	CLEAR CHAN
000.056	213X	.CLEARA	DS	1	CLEAR ALL CHANS
000.057	214X	.ERROR	DS	1	LOOKUP ERROR
000.060	215X	.CHFLG	DS	1	CHANGE FLAGS
000.061	216X	.DISMT	DS	1	FLAG SYSTEM DISK DISMOUNTED
000.062	217X	.LOADP	DS	1	LOAD DEVICE DRIVER
	218X				
	219X				
	220X	*			*HDOSQVL1.SYS* FUNCTIONS
	221X				
000.200	222X		ORG	2000	
	223X				
000.200	224X	.MOUNT	DS	1	MOUNT (MUST BE FIRST)
000.201	225X	.DMOUN	DS	1	DISMOUNT
000.202	226X	.MOMMS	DS	1	MOUNT/NO MESSAGE
000.203	227X	.DMNMS	DS	1	DISMOUNT/NO MESSAGE
000.204	228X	.RESET	DS	1	RESET = DISMOUNT/MOUNT OF UNIT
000.205	229	XTEXT		HOSERU	

231X ** HDOS SYSTEM EQUIVALENCES.

	232X	*			
	233X				
024.000	234X	S.GRT0	EQU	24000A	SYSTEM AREA FOR GRT0
025.000	235X	S.GRT1	EQU	25000A	SYSTEM AREA FOR GRT1
026.000	236X	S.GRT2	EQU	26000A	SYSTEM AREA FOR GRT2
	237X				
030.000	238X	ROMBOOT	EQU	30000A	ROM BOOT ENTRY
	239X				
040.100	240X		ORG	40100A	FREE SPACE FROM PAM-B
	241X				
040.100	242X		DS	8	JUMP TO SYSTEM EXIT
040.110	243X	D.CDN	DS	16	DISK CONSTANTS
040.130	244X	SYPD	EQU	*	SYSTEM DISK ENTRY POINT
040.130	245X	D.VEC	DS	24*3	SYSTEM ROM ENTRY VECTORS
040.240	246X	D.RAM	DS	31	SYSTEM ROM WORK AREA
040.277	247X	S.VAL	DS	36	SYSTEM VALUES
040.343	248X	S.INT	DS	115	SYSTEM INTERNAL WORK AREAS
041.126	249X		DS	16	
041.146	250X	S.SQVR	DS	2	STACK OVERFLOW WARNING
041.150	251X		DS	42200A-*	SYSTEM STACK
001.032	252X	STACKL	EQU	*-S.SQVR	STACK SIZE
	253X				
042.200	254X	STACK	EQU	*	LWA+1 SYSTEM STACK
042.200	255X	USERFWA	EQU	*	USER FWA
042.200	256	XTEXT		ESVAL	

```

258X **      S.VAL - SYSTEM VALUE DEFINITIONS.
259X *
260X *      THESE VALUES ARE SET AND MAINTAINED BY THE SYSTEM.
261X *
262X *      THE DECK HDSEQU MUST BE MODIFIED WHEN THIS IS MODIFIED.
263X
264X
040.277      265X      ORG      S.VAL
266X
040.277      267X S.DATE  DS      9      SYSTEM DATE (IN ASCII)
040.310      268X S.DATC  DS      2      CODED DATE
040.312      269X S.TIME  DS      4      TIME FROM MIDNIGHT (IN TICS)
040.316      270X S.HIEM  DS      2      HARDWARE HIGH MEMORY ADDRESS+1
271X
040.320      272X S.SYSM  DS      2      FWA RESIDENT SYSTEM
273X
040.322      274X S.USRM  DS      2      LWA USER MEMORY
275X
040.324      276X S.OMAX  DS      2      MAX OVERLAY SIZE FOR SYSTEM
277X
278X
279X **      THE FOLLOWING FIVE CELLS SHOULD BE MODIFIED/READ ONLY VIA THE .CONSL SYSCALL
280X
000.200      281X CSL.ECH  EQU      10000000B  SUPPRESS ECHO
000.002      282X CSL.WRP  EQU      00000010B  WRAP LINES AT WIDTH
000.001      283X CSL.CHR  EQU      00000001B  OPERATE IN CHARACTER MODE
284X
000.000      285X I.CSLMD  EQU      0      S.CSLMD IS FIRST BYTE
040.326      286X S.CSLMD  DS      1      CONSOLE MODE
287X
000.200      288X CTP.BKS  EQU      10000000B  TERMINAL PROCESSES BACKSPACES
000.040      289X CTP.MLI  EQU      00100000B  MAP LOWER CASE TO UPPER ON INPUT
000.020      290X CTP.MLO  EQU      00010000B  MAP LOWER CASE TO UPPER ON OUTPUT
000.010      291X CTP.2SB  EQU      00001000B  TERMINAL NEEDS TWO STOP BITS
000.002      292X CTP.BKM  EQU      00000010B  MAP BKSP (UPON INPUT) TO RUBOUT
000.001      293X CTP.TAB  EQU      00000001B  TERMINAL SUPPORTS TAB CHARACTERS
294X
000.001      295X I.CONTY  EQU      1      S.CONTY IS 2ND BYTE
000.000      296X ERRNZ   *-S.CSLMD-I.CONTY
040.327      297X S.CONTY  DS      1      CONSOLE TYPE FLAGS
000.002      298X I.CUSOR  EQU      2      S.CUSOR IS 3RD BYTE
000.000      299X ERRNZ   *-S.CSLMD-I.CUSOR
040.330      300X S.CUSOR  DS      1      CURRENT CURSOR POSITION
000.003      301X I.CONWI  EQU      3      S.CONWI IS 4TH BYTE
000.000      302X ERRNZ   *-S.CSLMD-I.CONWI
040.331      303X S.CONWI  DS      1      CONSOLE WIDTH
304X
000.001      305X CQ.FLG  EQU      00000001B  CTL-Q FLAG
000.200      306X CS.FLG  EQU      10000000B  CTL-S FLAG
307X
000.004      308X I.CONFL  EQU      4      S.CONFL IS 5TH BYTE
000.000      309X ERRNZ   *-S.CSLMD-I.CONFL
040.332      310X S.CONFL  DS      1      CONSOLE FLAGS
311X
040.333      312X S.CAADR  DS      2      ADDRESS FOR ABORT PROCESSING (>256 IF VALID)
040.335      313X S.CCTAB  DS      6      ADDR FOR CTL-A, CTL-B, CTL-C PROCESSING

```

040.343

314

XTEXT ESINT

040.343

040.343

000.000

000.001

040.344

040.346

040.350

040.352

040.354

040.356

040.360

040.362

040.364

040.365

040.366

040.370

000.001

000.002

000.014

000.200

040.371

040.372

040.374

040.376

041.000

041.002

041.004

316X ** S.INT - SYSTEM INTERNAL WORKAREA DEFINITIONS.

317X *

318X *

319X *

320X

321X

322X

323X

324X **

325X

326X

327X

328X

329X

330X *

331X

332X **

333X

334X

335X

336X

337X

338X

339X

340X **

341X

342X

343X

344X

345X

346X

347X

348X

349X

350X **

351X

352X

353X

354X

355X

356X

357X

358X

359X

360X

361X

362X

363X

364X

365X

366X *

ORG S.INT

CONSOLE STATUS FLAGS

CONSOLE DESCRIPTOR BYTE

=0 IF HB-5, =1 IF HB-4

[0-14] HB-4 BAUD RATE, =0 IF HB-5

[15] =1 IF BAUD RATE => 2 STOP BITS

TABLE ADDRESS WORDS

ADDRESS OF DATA IN HDOS CODE

FWA OVERLAY TABLE

FWA CHANNEL TABLE

FWA DEVICE TABLE

FWA RESIDENT HDOS CODE

DEVICE DRIVER DELAYED LOAD FLAGS

DRIVER LOAD ADDRESS (HIGH BYTE=0 IF NO LOAD PENDING)

CODE LENGTH IN BYTES

GROUP NUMBER FOR DRIVER

HOLD PLACE

SECTOR NUMBER FOR DRIVER (* OBSOLETE ! *)

DEVICE'S ADDRESS IN DEVLST +DEV.RES

OPEN OP-CODE PENDING

OVERLAY MANAGEMENT FLAGS

IN MEMORY

PERMANENTLY RESIDENT

OVERLAY NUMBER MASK

USER CODE SWAPPED FOR OVERLAY

OVERLAY FLAG

FWA SWAPPED USER CODE

LENGTH SWAPPED USER CODE

SIZE OF OVERLAY CODE

ENTRY POINT OF OVERLAY CODE

SWAP AREA SECTOR NUMBER

OVERLAY SECTOR NUMBER

SYSCALL PROCESSING WORK AREAS

ESINT

```

367X
041.006 368X S.CACC DS 1 (ACC) UPON SYSCALL
041.007 369X S.CODE DS 1 SYSCALL INDEX IN PROGRESS
370X
371X * JUMPS TO ROUTINES IN RESIDENT HDOS CODE
372X
041.010 373X S.JUMPS DS 0 START OF DUMP VECTORS
041.010 374X S.SDD DS 3 JUMP TO STAND-IN DEVICE DRIVER
041.013 375X S.FASER DS 3 JUMP TO FATSERK (FATAL SYSTEM ERROR)
041.016 376X S.DIREA DS 3 JUMP TO DIREAD (DISK FILE READ)
041.021 377X S.FCI DS 3 JUMP TO FCI (FETCH CHANNEL INFO)
041.024 378X S.SCI DS 3 JUMP TO SCI (STORE CHANNEL INFO)
041.027 379X S.GUP DS 3 JUMP TO GUP (GET UNIT POINTER)
380X
041.032 381X S.MOUNT DS 1 00 IF THE SYSTEM DISK IS MOUNTED
041.033 382X S.DCS DS 1 DEFAULT CLUSTER SIZE-1
383X
041.034 384X S.BOOTF DS 1 ROOT FLAGS
000.001 385X BOOT.F EQU 00000001B EXECUTE PROLOGUE UPON BOOTUP
386X
387X * STACK VALUE SAVED FOR OVERLAY SYSCALLS
388X
041.035 389X S.OVSTK DS 2 VALUE OF SP UPON SYSCALLS USING OVERLAY
390X
041.037 391X DS 1 RESERVED

393X ** ACTIVE I/O AREA.
394X *
395X * THE AIO.XXX AREA CONTAINS INFORMATION ABOUT THE I/O OPERATION
396X * CURRENTLY BEING PERFORMED. THE INFORMATION IS OBTAINED FROM
397X * THE CHANNEL TABLE, AND WILL BE RESTORED THERE WHEN DONE.
398X *
399X * NORMALLY, THE AIO.XXX INFORMATION WOULD BE OBTAINED DIRECTLY
400X * FROM VARIOUS SYSTEM TABLES VIA POINTER REGISTERS, SINCE THE
401X * BOBO HAS NO GOOD INDEXED ADDRESSING, THE DATA IS MANUALLY
402X * COPIED INTO THE AIO.XXX CELLS BEFORE PROCESSING, AND
403X * BACKDATED AFTER PROCESSING.
404X
041.040 405X AIO.VEC DS 3 JUMP INSTRUCTION
041.041 406X AIO.DPA EQU *-2 DEVICE DRIVER ADDRESS
041.043 407X AIO.FLG DS 1 FLAG BYTE
041.044 408X AIO.GRT DS 2 ADDRESS OF GROUP RESERV TABLE
041.046 409X AIO.SPG DS 1 SECTORS PER GROUP
041.047 410X AIO.CGN DS 1 CURRENT GROUP NUMBER
041.050 411X AIO.CSI DS 1 CURRENT SECTOR INDEX
041.051 412X AIO.LGN DS 1 LAST GROUP NUMBER
041.052 413X AIO.LSI DS 1 LAST SECTOR INDEX
041.053 414X AIO.DTA DS 2 DEVICE TABLE ADDRESS
041.055 415X AIO.DES DS 2 DIRECTORY SECTOR
041.057 416X AIO.DEV DS 2 DEVICE CODE
041.061 417X AIO.UNI DS 1 UNIT NUMBER (0-9)
418X
041.062 419X AIO.DIR DS DIRELEN DIRECTORY ENTRY

```


	420X				
041.111	421X AIO.CNT	DS	1	SECTOR COUNT	
041.112	422X AIO.EOM	DS	1	END OF MEDIA FLAG	
041.113	423X AIO.EOF	DS	1	END OF FILE FLAG	
041.114	424X AIO.TFF	DS	2	TEMP FILE POINTERS	
041.116	425X AIO.CHA	DS	2	ADDRESS OF CHANNEL BLOCK (IOC.DDA)	

041.120	427X S.SCR	DS	2	SYSTEM SCRATCH AREA ADDRESS	
041.122	428	XTEXT	FILDEF		

430X ** FILDEF - FILE TYPE DEFINITIONS.

	431X *				
	432X *	DB	3770,FT,XXX		
	433X				
	434X				
000.000	435X FT.ABS	EQU	0	ABSOLUTE BINARY	
000.001	436X FT.PIC	EQU	1	POSITION INDEPENDANT CODE	
000.002	437X FT.REL	EQU	2	RELOCATABLE CODE	
000.003	438X FT.BAC	EQU	3	COMPILED BASIC CODE	
041.122	439	XTEXT	ABSDEF		

441X ** ABS FORMAT EQUIVALENCES.

	442X				
000.000	443X	ORG	0		
	444X				
000.000	445X ABS.ID	DS	1	3770 = BINARY FILE FLAG	
000.001	446X	DS	1	FILE TYPE (FT.ABS)	
000.002	447X ABS.LDA	DS	2	LOAD ADDRESS	
000.004	448X ABS.LEN	DS	2	LENGTH OF ENTIRE RECORD	
000.006	449X ABS.ENT	DS	2	ENTRY POINT	
	450X				
000.010	451X ABS.COD	DS	0	CODE STARTS HERE	
000.010	452	XTEXT	PICDEF		

454X ** PIC FORMAT EQUIVALENCES.

	455X				
000.000	456X	ORG	0		
	457X				
000.000	458X PIC.ID	DS	1	3770 = BINARY FILE FLAG	
000.001	459X	DS	1	FILE TYPE (FT.PIC)	
000.002	460X PIC.LEN	DS	2	LENGTH OF ENTIRE RECORD	
000.004	461X PIC.PTR	DS	2	INDEX OF START OF PIC TABLE	
	462X				
000.006	463X PIC.COD	DS	0	CODE STARTS HERE	
000.006	464	XTEXT	PBDEF		

HEADING.

FBDEF

15:18:49 16-MAY-80

466X ** FILE BLOCK DEFINITIONS.

467X				
000.000	468X	ORG	0	
000.000	469X	FB.CHA	DS	1 CHANNEL NUMBER
000.001	470X	FB.FLG	DS	1 FLAGS
000.002	471X	FB.FWA	DS	2 BUFFER FWA
000.004	472X	FB.PTR	DS	2 BUFFER POINTER
000.006	473X	FB.LIM	DS	2 LIMIT OF DATA IN BUFFER (READ OPERATIONS)
000.010	474X	FB.LWA	DS	2 LWA OF BUFFER
000.012	475X	FB.NAM	DS	4+8+4+1 NAME OF FILE
000.021	476X	FB.NAML	EQU	*-FB.NAM
000.033	477X	FBENL	EQU	* ENTRY LENGTH
000.033	478	XTEXT	ECDEF	

480X ** ERROR CODE DEFINITIONS.

481X				
000.000	482X	ORG	0	
000.000	483X	DS	1	NO ERROR #0
000.001	484X	EC.EOF	DS	1 END OF FILE
000.002	485X	EC.EDM	DS	1 END OF MEDIA
000.003	486X	EC.ILC	DS	1 ILLEGAL SYSCALL CODE
000.004	487X	EC.CNA	DS	1 CHANNEL NOT AVAILABLE
000.005	488X	EC.DNS	DS	1 DEVICE NOT SUITABLE
000.006	489X	EC.IDN	DS	1 ILLEGAL DEVICE NAME
000.007	490X	EC.IFN	DS	1 ILLEGAL FILE NAME
000.010	491X	EC.NRD	DS	1 NO ROOM FOR DEVICE DRIVER
000.011	492X	EC.FND	DS	1 CHANNEL NOT OPEN
000.012	493X	EC.ILR	DS	1 ILLEGAL REQUEST
000.013	494X	EC.FUC	DS	1 FILE USAGE CONFLICT
000.014	495X	EC.FNF	DS	1 FILE NAME NOT FOUND
000.015	496X	EC.UND	DS	1 UNKNOWN DEVICE
000.016	497X	EC.ICN	DS	1 ILLEGAL CHANNEL NUMBER
000.017	498X	EC.DIF	DS	1 DIRECTORY FULL
000.020	499X	EC.IFC	DS	1 ILLEGAL FILE CONTENTS
000.021	500X	EC.NEM	DS	1 NOT ENOUGH MEMORY
000.022	501X	EC.RF	DS	1 READ FAILURE
000.023	502X	EC.WF	DS	1 WRITE FAILURE
000.024	503X	EC.WPV	DS	1 WRITE PROTECTION VIOLATION
000.025	504X	EC.WP	DS	1 DISK WRITE PROTECTED
000.026	505X	EC.FAP	DS	1 FILE ALREADY PRESENT
000.027	506X	EC.DDA	DS	1 DEVICE DRIVER ABORT
000.030	507X	EC.FL	DS	1 FILE LOCKED
000.031	508X	EC.FAO	DS	1 FILE ALREADY OPEN
000.032	509X	EC.IS	DS	1 ILLEGAL SWITCH
000.033	510X	EC.UUN	DS	1 UNKNOWN UNIT NUMBER
000.034	511X	EC.FNR	DS	1 FILE NAME REQUIRED
000.035	512X	EC.DIW	DS	1 DEVICE IS NOT WRITABLE (OR WRITE LOCKED)
000.036	513X	EC.UNA	DS	1 UNIT NOT AVAILABLE
000.037	514X	EC.ILV	DS	1 ILLEGAL VALUE
000.040	515X	EC.ILO	DS	1 ILLEGAL OPTION
000.041	516X	EC.VPM	DS	1 VOLUME PRESENTLY MOUNTED ON DEVICE
000.042	517X	EC.NVM	DS	1 NO VOLUME PRESENTLY MOUNTED
000.043	518X	EC.FOD	DS	1 FILE OPEN ON DEVICE
000.044	519X	EC.NPM	DS	1 NO PROVISIONS MADE FOR REMOUNTING MORE DISKS

HEADING.

ECDEF

15:18:54 14-MAY-80

000.045	520X	EC.DNI	DS	1	DISK NOT INITIALIZED
000.046	521X	EC.DNR	DS	1	DISK IS NOT READABLE
000.047	522X	EC.DSC	DS	1	DISK STRUCTURE IS CORRUPT
000.050	523X	EC.NCV	DS	1	NOT CORRECT VERSION OF HDOS
000.051	524X	EC.NOS	DS	1	NO OPERATING SYSTEM MOUNTED
000.052	525X	EC.IOI	DS	1	ILLEGAL OVERLAY INDEX
000.053	526X	EC.OTL	DS	1	OVERLAY TOO LARGE
000.054	527	XTEXT	IOCDEF		
	529X	**	I/O CHANNEL DEFINITIONS.		
	530X				
000.000	531X	ORB		0	
	532X				
000.000	533X	IOC.LNK	DS	2	ADDRESS OF NEXT CHANNEL, =0 IF LAST
000.002	534X	IOC.DDA	DS	2	THREAD JUMP TO DEVICE DRIVER (VIA DEV TABLE)
	535X				
000.004	536X	IOC.FLG	DS	1	FILE TYPE FLAGS
000.001	537X	FT.RD	EGU	00000001R	=1 IF DIRECTORY DEVICE
000.002	538X	FT.0R	EGU	00000010B	=1 IF OPEN FOR READ
000.004	539X	FT.0W	EGU	00000100B	=1 IF OPEN FOR WRITE
000.010	540X	FT.0U	EGU	00001000B	=1 IF OPEN FOR UPDATE
000.003	541X	IOC.SQL	EGU	*-IOC.DDA	LENGTH OF INFO FOR SEQUENTIAL FILE (FROM IOC)
	542X				
000.005	543X	IOC.GRT	DS	2	ADDRESS OF GROUP RESERVATION TABLE
000.007	544X	IOC.SPB	DS	1	SECTORS PER GROUP, THIS DEVICE
000.010	545X	IOC.CGN	DS	1	CURRENT GROUP NUMBER
000.011	546X	IOC.CSI	DS	1	CURRENT SECTOR INDEX (IN CURRENT GROUP)
000.012	547X	IOC.LGN	DS	1	LAST GROUP NUMBER
000.013	548X	IOC.LSI	DS	1	LAST SECTOR INDEX (IN LAST GROUP)
000.010	549X	IOC.DRL	EGU	*-IOC.FLG	LENGTH OF INFO NORMALLY COPIED BACK TO THE CHANNEL TABLE
	550X	*			
000.014	551X	IOC.ITA	DS	2	DEVICE TABLE ADDRESS FOR THIS DEVICE
000.016	552X	IOC.IES	DS	2	SECTOR NUMBER OF DIRECTORY ENTRY
000.020	553X	IOC.DEV	DS	2	DEVICE CODE
000.022	554X	IOC.UNI	DS	1	UNIT NUMBER (0-9)
000.021	555X	IOC.DIL	EGU	*-IOC.DDA	LENGTH OF INFO FOR DIRECTORY FILE (FROM IOC)
	556X				
000.023	557X	IOC.DIR	DS	DIRELEN	DIRECTORY ENTRY
	558X				
000.052	559X	IOELELEN	EGU	*	IOC ENTRY LENGTH
	560X				
000.001	561X	IOCCTD	EGU	1	INDEX OF USER CHANNEL #0 IN CHANTAB (FIRST = 0)
	562				
	563	****			

```

566
042.170          567      ORG    USERFWA-ABS.COD
042.170 377 000    568      DB     3770,FT.ABS          ABS HEADER
042.172 200 042    569      DW     USERFWA          LOAD ADDRESS
042.174 205 032    570      DW     MEML-USERFWA       SIZE
042.176 055 070    571      DW     PRS           ENTRY
                    572
042.200          573      START  EQU    *           START HERE AFTER *PRS*
                    574
042.200 315 317 052 575      CALL   RDI           BUILD DYNAMIC TABLES
042.203 332 325 042 576      JC     EXIT          PROBLEMS
042.206 076 001    577      MVI   A,1           PASS 1
042.210 315 344 042 578      CALL   ASM           ASSEMBLE PASS 1
                    579
042.213 315 366 056 580      CALL   RSF           REWIND SOURCE FILE
042.216 076 002    581      MVI   A,2
042.220 315 344 042 582      CALL   ASM           ASSEMBLE PASS 2
042.223 072 144 067 583      LDA   FTFLAG
042.226 376 001    584      CPI   FT.PIC
042.230 302 263 042 585      JNE   HBASM1        NOT PIC CODE
                    586
                    587      *       IS PIC CODE, UPDATE LENGTH POINTER IN HEADER
                    588
042.233 052 134 067 589      LHLD  ORG
042.236 353          590      XCHG          (DE) = CODE LENGTH
042.237 041 003 000 591      LXI   H,PIC.LEN+1
042.242 042 134 067 592      SHLD  ORG          SET ADDRESS FOR HEADER FIELD+1
042.245 173          593      MOV   A,E
042.246 315 070 052 594      CALL  ABV          WRITE LENGTH
042.251 041 004 000 595      LXI   H,PIC.LEN+2 (HL) = ORG+1
042.254 042 134 067 596      SHLD  ORG          WRITE 2ND BYE OF PIC.LEN
042.257 172          597      MOV   A,D
042.260 315 070 052 598      CALL  ABV          2ND HALF
042.263 072 150 067 599      HBASM1 LDA  BINFNAM
042.266 247          600      ANA   A
042.267 312 301 042 601      JZ    HBASM2        NO FILE, DONT FINISH IT
042.272 315 123 060 602      CALL  WBR          FLUSH BUFFER TO DISK
042.275 076 000    603      MVI   A,CN.BIN
042.277 377 046    604      DB     SYSCALL,.CLOSE CLOSE FILE
                    605
                    606      *       ASSEMBLY COMPLETE.
                    607
042.301 315 051 056 608      HBASM2 CALL  PAS          PRINT ASSEMBLY STATISTICS
042.304 315 104 055 609      CALL  FNF          FORCE NEW PAGE
042.307 041 226 067 610      LXI   H,LISTFR
042.312 315 052 062 611      CALL  %FCLO        CLOSE LISTING FILE
042.315 315 003 061 612      CALL  %CCO          CLEAR CTL-0
042.320 041 163 056 613      LXI   H,PASA
042.323 377 003    614      DB     SYSCALL,.PRINT PRINT FINAL MESSAGE
                    615
042.325 257          616      EXIT  XRA   A
042.326 377 000    617      DB     SYSCALL,.EXIT

```

```
619 **      CCHIT = CTL-C HIT.  
620 *  
621  
622  
042.330 315 138 031 623 CCHIT CALL $TPTYX  
042.333 136 303 624 DB 'C', 'C'+2000  
042.335 303 325 042 625 JMF EXIT  
  
627 **      RESTART - RECOVER FROM ERRORS.  
628 *  
629 *      THIS CODE IS ENTERED AFTER FILE ERRORS ARE  
630 *      DISCOVERED AND COMPLAINED ABOUT.  
631  
632  
042.340 076 001 633 RESTART MVI A+1  
042.342 377 000 634 DB SYSCALL, .EXIT EXIT WITH RESET
```

```

638 ** ASM IS CALLED TO MAKE AN ASSEMBLY PASS.
639 *
640 * IF PASS = 1, ASSEMBLE TEXT, CREATE SYMBOL TABLE, PRODUCE
641 * NO BINARY OR LISTING.
642 *
643 * IF PASS = 2, ASSEMBLE TEXT, DEFINE NO SYMBOLS, PRODUCE BINARY
644 * AND LISTING.
645 *
646 * ENTRY (A) = PASS NUMBER (1 OR 2)
647 * EXIT 'END' STATEMENT READ
648 * ERRCNT = NUMBER OF STATEMENTS WITH ERRORS
649 * STATNO = NUMBER OF STATEMENTS READ
650
651
042.344 062 122 067 652 ASM STA PASS
042.347 021 115 045 653 LXI D,NULTITL /78.10.GC/
042.352 315 031 045 654 CALL TITLE. /78.10.GC/
042.355 021 115 045 655 LXI D,NULTITL /78.10.GC/
042.360 315 104 045 656 CALL STL. /78.10.GC/
042.363 041 000 000 657 LXI H,0
042.366 042 123 067 658 SHLD ERRCNT CLEAR ERROR COUNT
042.371 042 126 067 659 SHLD STATNO
042.374 257 660 XRA A
042.375 062 347 067 661 STA CNDFLG CLEAR CONDITIONAL ASSEMBLY
043.000 062 133 067 662 STA ENDFLG CLEAR END FLAG
043.003 062 352 067 663 STA PAGNUM CLEAR PAGE NUMBER /10.04.77/
043.006 062 141 067 664 STA GRPFLG SET IN FIRST GROUP
043.011 062 146 067 665 STA CODEFLG CLEAR 'CODE' PSEUDO SEEN FLAG
043.014 062 144 067 666 STA FTFLAG CLEAR CODE GENERATION TYPE FLAG
043.017 076 001 667 MVI A,LST.L
043.021 062 130 067 668 STA LSTCTL
043.024 071 669 DAD SP (HL) = (SP)
043.025 042 352 043 670 SHLD ASMB SAVE STACK POINTER VALUE
043.030 041 200 042 671 LXI H,USERFWA DEFAULT ORG
043.033 042 134 067 672 SHLD ORG
673
674 * SET INITIAL LISTING CONTROL BITS
675
043.036 041 131 067 676 LXI H,LSTCTL
043.041 072 130 067 677 LDA LSTCTL
043.044 266 678 ORA H SET FORCED ON BITS
043.045 043 679 INX H
000.000 680 ERRNZ LSTCTL-LSTCTL-1 (HL) = #LSTCTL
043.046 246 681 ANA H CLEAR FORCED OFF BITS
043.047 062 130 067 682 STA LSTCTL
683
684 * ASSEMBLE ANOTHER LINE OF PROGRAM.
685
043.052 052 134 067 686 ASM1 LHL D ORG
043.055 042 136 067 687 SHLD SORG SAVE COPY OF ORG
043.060 315 275 056 688 CALL PBL PREPARE DISPLAY LINE
043.063 052 126 067 689 LHL D STATNO
043.066 043 690 INX H
043.067 042 126 067 691 SHLD STATNO INCREMENT STATEMENT NUMBER
043.072 315 145 057 692 CALL UNL UNPACK NEXT LINE
043.075 312 230 043 693 JZ ASM4 IS COMMENT

```

```

694
695 *      CRACK OPCODE.
696
043.100 041 174 064 697      LXI      H,OPCTAB
043.103 021 067 070 698      LXI      D,OPCODE
043.106 257 699      XRA      A
043.107 315 310 055 700      CALL     LVT          LOCATE VALUE IN TABLE
043.112 332 130 043 701      JC       ASM2        FOUND
043.115 315 003 057 702      CALL     SEF          *DX* ERROR
043.120 100 703      DB      ERR,0
043.121 001 000 000 704      LXI      B,0
043.124 120 705      MOV      D,B          GENERATE 3 00 BYTES
043.125 303 364 043 706      JMP      ASM7
707
043.130 176 708      ASM2    MOV      A,M          (A) = OPCODE INDEX
000.000 709      ERRM2   OF,CE-2000   CODE ASSUMES = 2000
043.131 027 710      RAL     CHECK FOR CONDITIONAL ELIGIBILITY
043.132 332 144 043 711      JC       ASM3        WILL PROCESS REGARDLESS OF *IF*
043.135 072 347 067 712      LDA     CNDFLG
043.140 017 713      RRC
043.141 332 237 043 714      JC       ASM5        ASM TO SKIP ASSEMBLING
043.144 176 715      ASM3    MOV      A,M          (A) = OPCODE INDEX
043.145 346 100 716      ANI     OF,LI        SEE IF TO DEFINE LABEL
043.147 345 717      PUSH   H
043.150 314 335 053 718      CZ      DLH          IF TO DEFINE LABEL
043.153 341 719      POP    H
043.154 176 720      MOV      A,M          (A) = OPCODE INDEX
043.155 346 077 721      ANI     770          CLEAR FLAG BITS
043.157 043 722      INX    H
043.160 106 723      MOV      B,M          (B) = OPCODE
043.161 345 724      PUSH   H          SAVE ADDRESS IN OPCTAB
043.162 365 725      FUSH   PSW          SAVE INDEX
043.163 376 015 726      CFI     PSIND
043.165 076 001 727      MVI     A,1          ASSUME IS MACHINE CODE, WHICH IS GROUP 2
043.167 332 173 043 728      JC      ASM3.1      IS MACHINE CODE
043.172 170 729      MOV      A,B          IS PSEUDO, USE IT'S GROUP FLAG
043.173 041 141 067 730      ASM3.1 LXI     H,GRFFLG
043.176 266 731      ORA    M          <=0 IF THIS OPERATION IN MAIN GROUP
043.177 167 732      MOV      M,A
043.200 304 076 044 733      CNZ    GCF          GENERATE 'CODE' PSEUDO, IF NECESSARY
043.203 361 734      POP    PSW          (A) = OPERATION INDEX
043.204 007 735      RLC
043.205 041 252 043 736      LXI     H,ASMA
043.210 315 101 030 737      CALL   $DADA,        (HL) = ADDRESS OF ADDRESS
043.213 315 211 030 738      CALL   $HLIHL
043.216 072 122 067 739      LDA     PASS
043.221 017 740      RRC          (C) SET IF PASS = 1
043.222 170 741      MOV      A,B          (A) = OPCODE
043.223 343 742      XTHL        (HL) = ADDRESS OF OPCTAB ENTRY
043.224 021 074 070 743      LXI     D,EXPWRK     (DE) = EXPRESSION POINTER
043.227 311 744      RET        ENTER PROCESSOR
745
746 *      HAVE COMMENT
747
043.230 072 347 067 748      ASM4    LDA     CNDFLG
043.233 017 749      RRC

```

```

043.234 322 044 044 750 JNC ASM13 LIST IF NOT CONDITIONAL ASSEMBLY
751
752 * AM SKIPPING LINE. SEE IF TO LIST.
753
043.237 072 130 067 754 ASMS LDA LSTCTL
043.242 348 002 755 ANI LST.1
043.244 312 053 044 756 JZ ASM14 IGNORE
043.247 303 044 044 757 JMP ASM13 LIST BY ITSELF
758
043.252 ASMA EQU * PROCESSOR JUMP TABLE
760
761 * MACHINE OPCODES.
762
043.252 001 044 763 DW SNG SINGLE BYTE - NO OPERAND
043.254 110 047 764 DW IMM IMMEDIATE ARITHMETIC
043.256 117 047 765 DW THR THREE-BYTE OPCODES
043.260 126 047 766 DW RAO REG ARITH - TYPE 1
043.262 135 047 767 DW RAT REG ARIT - TYPE 2
043.264 147 047 768 DW RPO REG PAIR GP 1
043.266 156 047 769 DW RPT REG PAIR GP 2
043.270 165 047 770 DW INX INX INSTRUCTION
043.272 206 047 771 DW MVI MVI INSTRUCTION
043.274 231 047 772 DW INDX LDAX, STAX INSTRUCTIONS
043.276 256 047 773 DW RST RST INSTRUCTION
043.300 303 047 774 DW LXI LXI INSTRUCTION
043.302 322 047 775 DW MOV MOV INSTRUCTION
776
777 * PSEUDO OPCODES.
778
000.015 779 PSIND EQU *-ASMA/2 INDEX OF 1ST PSEUDO OP
043.304 116 044 780 DW DB DB
043.306 220 044 781 DW DS DS
043.310 240 044 782 DW DW DW
043.312 273 044 783 DW EJECT EJECT
043.314 151 045 784 DW ELSE ELSE
043.316 007 046 785 DW END END
043.320 167 045 786 DW ENDIF ENDIF
043.322 102 046 787 DW EQU EQU
043.324 204 045 788 DW ERRXX ERRZR, ERRNZ, ERRPL, ERRMI
043.326 120 045 789 DW IF IF
043.330 271 045 790 DW LOP LOP
043.332 252 045 791 DW LON LON
043.334 354 045 792 DW ORG ORG
043.336 150 046 793 DW SET SET
043.340 311 044 794 DW SPACE SPACE
043.342 073 045 795 DW STL STL
043.344 020 045 796 DW TITLE TITLE
043.346 164 046 797 DW CODE CODE
043.350 357 046 798 DW XTEXT XTEXT
799
043.352 000 000 800 ASMB DW 0 SAVED STACKPOINTER

```


802 ** MACHINE AND PSEUDO OP CODE PROCESSORS EXIT TO
803 *
804 * THESE POINTS:

806 ** ASM6 - EXIT WITH 2 BYTES OF DATA
807 *
808 * PLACE 2 BYTES IN LINE AND LIST IT.
809 *
810 * ENTRY (R) = 1ST BYTE, (C) = 2ND
811 *
812 *

043.354 170 813 ASM6 MOV A,B
043.355 315 351 055 814 CALL ORB OUTPUT 1ST BYTE
043.360 171 815 MOV A,C
043.361 303 001 044 816 JMP ASMB

818 ** ASM7 - EXIT WITH 3 BYTES OF DATA.
819 *
820 * PLACE 3 BYTES IN LINE AND LIST IT
821 *
822 * ENTRY (D) = 1ST BYTE
823 * (C) = 2ND BYTE
824 * (B) = 3RD BYTE
825 *
826 *

043.364 172 827 ASM7 MOV A,D
043.365 315 351 055 828 CALL ORB 1ST BYTE
043.370 315 323 056 829 CALL RRI RECORD RELOCATION INFORMATION
043.373 171 830 MOV A,C
043.374 315 351 055 831 CALL ORB 2ND BYTE
043.377 257 832 XRA A

834 ** ASM8 - EXIT WITH ONE BYTE OF CODE.
835 *
836 * PLACE 1 BYTE IN LINE AND LIST IT.
837 *
838 * ENTRY (A) = VALUE
839 *
840 *

044.000 200 841 ASM8 ADD B ENTRY TO OUTPUT A+B
044.001 315 351 055 842 ASM8 CALL ORB OUTPUT BYTE
044.004 303 032 044 843 JMP ASMI1 LIST WITH ORG

845 ** ASM10 - REQUIRE STATEMENT END, THEN LIST STATEMENT
846 * WITHOUT ORG.
847 *
848 * USED BY DW AND DB
849
850
044.007 033 851 ASM10 DCX D
044.010 032 852 LDAX D (A) = LAST CHARACTER
044.011 315 031 053 853 CALL CEF CHECK FOR END OF FIELD CHARACTER
044.014 312 044 044 854 JZ ASM13 GOT A LEGAL TERMINATOR
044.017 315 003 057 855 FLGERA CALL SEF ** ERROR
044.022 010 856 DB ERR.A
044.023 303 044 044 857 JMP ASM13

859 ** ERR.O. - FLAG *D* ERROR, LIST LINE WITH ORG
860 *
861 * USED WHEN THE OPCODE IS SYNTACTICALLY VALID, JUST ILLEGAL
862 * IN THAT CONTEXT
863
864
044.026 315 003 057 865 ERR.O. CALL SEF
044.031 100 866 DB ERR.O
867 * JMP ASM11 LIST LINE WITH ORG

869 ** ASM11 - LIST LINE WITH ORG.
870 *
871
872
044.032 052 136 067 873 ASM11 LHLD SORG (HL) = SAVED ORG VALUE
044.035 104 874 MOV B,H
044.036 115 875 MOV C,L

877 ** ASM11. - LIST LINE WITH (BC) = ORG
878 *
879
880
044.037 140 881 ASM11. MOV H,B
044.040 151 882 MOV L,C

884 ** ASM12 - LIST LINE WITH (HL) AS ORG
 885 *
 886
 887
 044.041 315 121 057 888 ASM12 CALL UOL UNPACK (HL) TO LINE

890 ** ASM13 - LIST WITHOUT ORG.
 891 *
 892
 893
 044.044 315 370 053 894 ASM13 CALL DLL DISPLAY LISTING LINE
 044.047 257 895 XRA A
 044.050 062 140 067 896 STA ERRFLG CLEAR ERROR

898 ** ASM14 - NO LIST.
 899 *
 900
 901
 044.053 072 140 067 902 ASM14 LDA ERRFLG
 044.056 247 903 ANA A
 044.057 302 044 044 904 JNZ ASM13 ERROR - MUST LIST
 044.062 052 352 043 905 LHLD ASMB
 044.065 371 906 SPHL RESET STACK POINTER
 044.066 072 133 067 907 LDA ENDFLG
 044.071 247 908 ANA A
 044.072 300 909 RNZ EXIT IF *END* READ
 044.073 303 052 043 910 JMP ASM1 PROCESS ANOTHER CARD

912 ** GCP - GENERATE (CODE) PSEUDO.
 913 *
 914 * GCP IS CALLED AFTER THE GROUP CLASSIFICATION OF EVERY STATEMENT
 915 * HAS BEEN DETERMINED. IF THIS TO-BE-ASSEMBLED STATEMENT HAS
 916 * PUT US INTO GROUP 2, AND NO (CODE) PSEUDO HAS BEEN ENCOUNTERED,
 917 * THEN WE MUST FAKE UP A
 918 *
 919 * CODE ABS
 920 *
 921 * STATEMENT.
 922 *
 923 * ENTRY (A) = (GRPFLG)
 924 * EXIT NONE
 925 * USES A,F
 926
 927
 044.076 072 146 067 928 GCP LDA CODEFLG
 044.101 247 929 ANA A
 044.102 300 930 RNZ CODE PSEUDO ENCOUNTERED

ASM - MAKE ASSEMBLY PASS.

GDF

15:19:06 16-MAY-80

044.103	315 054 031	931	CALL	\$SAVALL	SAVE REGS
044.106	006 000	932	MVI	R:FT.ABS	DO ABS
044.110	315 231 046	933	CALL	CODE2	PROCESS CODE PSEUDO
044.113	303 047 031	934	JMP	\$RSTALL	RESTORE AND RETURN

```

937 ** DB - DEFINE BYTE.
938 *
939 * DB VAL,...,VAL
940 *
941 *
044.116 942 DB EQU *
044.116 315 116 057 943 CALL UOL UNPACK ORG INTO LINE
044.121 325 944 DB1 PUSH D
945 *
946 * EXAMINE NEXT ELEMENT.
947 *
044.122 032 948 LDAX D
044.123 376 047 949 CPI QUOTE
044.125 302 157 044 950 JNE DB3 NOT QUOTE
951 *
952 * HAVE QUOTED STRING. SEE IF IS PART OF EXPRESSION, OR JUST
953 * A STAND-ALONE.
954 *
044.130 023 955 INX D
044.131 315 252 055 956 DB2 CALL GSC GET STRING CHARACTER
044.134 302 131 044 957 JNZ DB2
044.137 032 958 LDAX D
044.140 247 959 ANA A
044.141 372 172 044 960 JM DB4 MARKED CHARACTER /80.02.GC/
044.144 315 031 053 961 CALL CEF CHECK FOR END OF FIELD /80.02.GC/
044.147 312 172 044 962 JZ DB4 /80.02.GC/
044.152 376 054 963 CPI ',' CHECK FOR EXPRESSION /80.02.GC/
044.154 312 172 044 964 JZ DB4 /80.02.GC/
965 *
966 * HAVE BYTE EXPRESSION
967 *
044.157 321 968 DB3 POP D
044.160 315 341 054 969 CALL EBB EVALUATE TO 8 BITS
044.163 171 970 MOV A+C (A) = VALUE
044.164 315 351 055 971 CALL OBB OUTPUT BINARY BYTE
044.167 303 206 044 972 JMP DB6
973 *
974 * HAVE QUOTED STRING
975 *
044.172 321 976 DB4 POP D
044.173 023 977 INX D
044.174 257 978 XRA A
044.175 304 351 055 979 DB5 CNZ OBB OUTPUT BINARY BYTE (SKIP 1ST TIME)
044.200 315 252 055 980 CALL GSC GET STRING CHARACTER
044.203 302 175 044 981 JNZ DB5 IF MORE
982 *
983 * END OF BYTE VALUE. SEE IF MORE FOLLOW
984 *
044.206 032 985 DB6 LDAX D
044.207 023 986 INX D
044.210 376 054 987 CPI ','
044.212 312 121 044 988 JE DB1 IF MORE
044.215 303 007 044 989 JMP ASM10 REQUIRE END AND LIST LINE

```

```
993 ** DS - DEFINE STORAGE.  
994 *  
995 * DS EXPR  
996 *  
997 *  
044.220 998 DS EQU *  
044.220 315 372 054 999 CALL EPO EVALUATE FOR PASS 1  
044.223 302 032 044 1000 JNZ ASM11 EXIT - ERROR  
044.226 052 134 067 1001 LHLD ORG  
044.231 011 1002 DAD B  
044.232 042 134 067 1003 SHLD ORG  
044.235 303 032 044 1004 JMP ASM11 LIST WITH ORG
```

```
1007 ** DW - DEFINE WORD.  
1008 *  
1009 * DW EXP1,...,EXPN  
1010  
1011  
044.240 1012 DW EQU *  
044.240 315 116 057 1013 CALL UOL UNPACK DRG INTO LINE  
1014  
1015 * DECODE NEXT ELEMENT  
1016  
044.243 315 215 051 1017 DW1 CALL EUL  
044.246 315 323 056 1018 CALL RRI RECORD RELOCATION INFORMATION  
044.251 171 1019 MOV A,C  
044.252 315 351 055 1020 CALL ORB OUTPUT BINARY BYTE  
044.255 170 1021 MOV A,B  
044.256 315 351 055 1022 CALL ORB OUTPUT 2ND HALF  
044.261 032 1023 LDAX D  
044.262 023 1024 INX D  
044.263 376 054 1025 CPI ,'  
044.265 312 243 044 1026 JE DW1 IF MORE TO GO  
044.270 303 007 044 1027 JMF ASM10 ENSURE END AND LIST
```

```

1030 ** EJECT - SET PAGE EJECT.
1031 *
1032
1033
044.273 315 041 053 1034 EJECT CALL CLE CHECK LISTING ELIGIBILITY
044.276 312 053 044 1035 JZ ASM14 NOT TO LIST
044.301 076 001 1036 MVI A;1
044.303 062 350 067 1037 STA EJEFLG FORCE PAGE EJECT
044.306 303 053 044 1038 JMP ASM14 NO LIST

1040 ** SPACE N:M
1041 *
1042 * SPACE N LINES IF < M LINES REMAIN ON THE PAGE. OTHERWISE, EJECT.
1043
1044
044.311 332 053 044 1045 SPACE JC ASM14 IGNORE IF PASS 1
044.314 315 041 053 1046 CALL CLE CHECK LISTING ELIGIBILITY
044.317 312 053 044 1047 JZ ASM14 NO LISTING
044.322 315 341 054 1048 CALL EBB EVALUATE 8 BIT EXPRESSION
044.325 305 1049 PUSH B SAVE N
044.326 032 1050 LDAX D
044.327 376 054 1051 CPI ;
044.331 302 347 044 1052 JNE SPC1 NO M
044.334 023 1053 INX D
044.335 315 341 054 1054 CALL EBB EVALUATE M
044.340 072 351 067 1055 LDA LINCNT
044.343 271 1056 CMP C
044.344 332 273 044 1057 JC EJECT IF TO FORCE EJECT
1058
044.347 301 1059 SPC1 POP B (C) = N
044.350 072 214 067 1060 LDA PAGEDF
044.353 127 1061 MOV D,A (D) = PAGESIZ
044.354 072 351 067 1062 LDA LINCNT
044.357 272 1063 CMP B
044.360 312 053 044 1064 JE ASM14 AT TOP OF PAGE, DONT SPACE
044.363 221 1065 SUB C (A) = PROPOSED NEW LINE NUMBER
044.364 332 273 044 1066 JC EJECT WILL BRING NEW PAGE
044.367 315 100 053 1067 SPC2 CALL COL COUNT OUTPUT LINE
044.372 305 1068 PUSH B SAVE COUNT
044.373 041 226 067 1069 LXI H,LISTFB
044.376 021 017 045 1070 LXI D,SPCA
045.001 001 001 000 1071 LXI B;1
045.004 315 047 063 1072 CALL $FWRIE WRITE NEW LINE
045.007 301 1073 POP B (C) = COUNT
045.010 015 1074 DCR C
045.011 302 367 044 1075 JNZ SPC2 IF NOT DONE
045.014 303 053 044 1076 JMP ASM14 EXIT WITH NO LIST
1077
045.017 012 1078 SPCA DB NL SPACE LINE

```



```

1081 **      TITLE = 'SETUP PAGE TITLE'
1082 *
1083 *      TITLE 'NEW TITLE'
1084
1085
045.020 315 031 045 1086 TITLE CALL TITLE.
045.023 332 017 044 1087 JC FLGERA
045.026 303 053 044 1088 JMP ASM14
1089
045.031 041 233 066 1090 TITLE. LXI H,TTLTXT-1 (HL) = ADDRESS FOR TEXT
045.034 066 062 1091 MVI B,TXTL (B) = MAX LENGTH
045.036 032 1092 TTL1 LDAX D
045.037 376 047 1093 CPI QUOTE
045.041 302 071 045 1094 JNE TTL4 NO TITLE
045.044 023 1095 INX D
045.045 005 1096 TTL2 DCR B
045.046 312 071 045 1097 JZ TTL4 TOO MANY CHARACTERS
045.051 043 1098 INX H
045.052 315 252 055 1099 CALL GSC GET STRING CHARACTER
045.055 167 1100 MOV M,A
045.056 302 045 045 1101 JNZ TTL2 IF MORE TO GO
1102
1103 *      FILL REMAINDER OF LINE WITH BLANKS.
1104
045.061 066 040 1105 TTL3 MVI M,' '
045.063 043 1106 INX H
045.064 005 1107 DCR B
045.065 302 061 045 1108 JNZ TTL3
045.070 311 1109 RET
1110
045.071 067 1111 TTL4 STC FLAG ERROR
045.072 311 1112 RET
    
```

```

1114 **      STL = 'SUBTITLE LINE'
1115 *
1116 *      STL 'NEW SUB-TITLE'
1117
1118
045.073 315 104 045 1119 STL CALL STL.
045.076 332 017 044 1120 JC FLGERA
045.101 303 053 044 1121 JMP ASM14
1122
045.104 006 063 1123 STL. MVI B,STXTL
045.106 041 343 066 1124 LXI H,STLTXT-1
045.111 315 036 045 1125 CALL TTL1
045.114 311 1126 RET
1127
045.115 047 040 047 1128 MULTITL DB 0470, 0470
    
```

```

1131 **      IF - INITIATE CONDITIONAL ASSEMBLY.
1132 *
1133 *      IF      EXPR
1134 *
1135 *      ASSEMBLE IF EXPR = 0
1136
1137
045.120 315 372 054 1138 IF      CALL      EPO      EVALUATE PASS 1
045.123 302 017 044 1139      JNZ      FLGERA      ERROR
045.126 041 347 067 1140      LXI      H,CNDFLG
045.131 176      1141      MOV      A,M
045.132 247      1142      ANA      A
045.133 302 017 044 1143      JNZ      FLGERA      CONDITIONAL ASSEMBLY ALREADY IN EFFECT
045.136 170      1144      MOV      A,B
045.137 261      1145      ORA      C
045.140 066 200      1146      MVI      M,2000
045.142 312 146 045 1147      JZ       IF1      AM TO ASSEMBLE
045.145 064      1148      INR      M      AM TO SKIP
045.146 303 037 044 1149 IF1     JMP      ASM11.     LIST WITH (BC) = DRG

```

```

1151 **      ELSE - TOGGLE CONDITIONAL ASSEMBLY.
1152 *
1153 *      ELSE
1154
1155
045.151 041 347 067 1156 ELSE    LXI      H,CNDFLG
045.154 176      1157      MOV      A,M
045.155 247      1158      ANA      A
045.156 362 017 044 1159      JF       FLGERA      CONDITIONAL ASSEMBLY NOT IN EFFECT
045.161 356 001      1160      XRI      1
045.163 167      1161      MOV      M,A
045.164 303 044 044 1162      JMP      ASM13      PRINT NO INFORMATION

```

```

1164 **      ENDIF - COMPLETE CONDITIONAL PROCESSING.
1165 *
1166 *      ENDIF
1167
1168
045.167 041 347 067 1169 ENDIF   LXI      H,CNDFLG
045.172 176      1170      MOV      A,M
045.173 066 000      1171      MVI      M,0
045.175 247      1172      ANA      A
045.176 312 017 044 1173      JZ       FLGERA      CONDITIONAL ASSEMBLY NOT IN EFFECT
045.201 303 044 044 1174      JMP      ASM13      LIST WITH NO INFO

```

```

1177 **      ERRXX - CONDITIONAL ERRORS.
1178 *
1179 *      ERRZR EXPR
1180 *      ERRNZ EXPR
1181 *      ERRPL EXPR
1182 *      ERRMI EXPR
1183 *
1184 *      FLAG A ** ERROR IF EXPR MATCHES CONDITION.
1185
1186
045.204 315 215 051 1187 ERRXX CALL   EVL
045.207 176          1188      MOV   A,M      (A) = TYPE INDEX
045.210 041 037 044 1189      LXI   H,ASM11. LIST WITH (BC) = ORG
045.213 315 223 045 1190      CALL  ERR1
045.216 315 003 057 1191      CALL  SEF      ** ERROR
045.221 200          1192      DB    ERR.F
045.222 351          1193      PCHL          GO TO ASM12
1194
045.223 315 076 031 1195 ERR1  CALL   $TBRA
045.226 004          1196      DB    ERRZR-*
045.227 007          1197      DB    ERRNZ-*
045.230 012          1198      DB    ERRPL-*
045.231 015          1199      DB    ERRMI-*

045.232 170          1201 ERRZR  MOV   A,B
045.233 261          1202      ORA   C
045.234 310          1203      RZ    ERR1      ** ERROR
045.235 351          1204      PCHL          LIST WITH (HL) = ORG

045.236 170          1206 ERRNZ  MOV   A,B
045.237 261          1207      ORA   C
045.240 300          1208      RNZ  ERR1      ** ERROR
045.241 351          1209      PCHL

045.242 170          1211 ERRPL  MOV   A,B
045.243 247          1212      ANA  A
045.244 360          1213      RP   ERR1      ** ERROR
045.245 351          1214      PCHL

045.246 170          1216 ERRMI  MOV   A,B
045.247 247          1217      ANA  A
045.250 370          1218      RM   ERR1      ** ERROR
045.251 351          1219      PCHL
  
```

```

1222 **      LON - LISTING ON.
1223 *
1224 *      LON      CCC
1225 *
1226 *      TURN OPTIONS ON. OPTIONS =
1227 *
1228 *      L          MASTER LISTING
1229 *      I          IF-SKIPPED LINES
1230 *      C          INCLUDED CODE
1231 *      G          GENERATED CODE
1232 *
1233 *
045,252 315 314 045 1234 LON CALL LST
045,255 312 044 044 1235 JZ   ASM13      ALL DONE
045,260 266          1236 ORA   M
045,261 041 132 067 1237 LXI  M,LSTCTL
045,264 246          1238 ANA  M          CLEAR BITS MENTIONED IN /N: SWITCH
045,265 002          1239 STAX B
045,266 303 252 045 1240 JMP  LON      PROCESSES NEXT
  
```

```

1242 **      LOF - LISTING OFF.
1243 *
1244 *      LOF      CCC
1245 *
1246 *      TURN LON OPTIONS BACK OFF.
1247 *
1248 *
045,271 315 314 045 1249 LOF CALL LST
045,274 312 044 044 1250 JZ   ASM13      DONE
045,277 365          1251 PUSH PSW      SAVE OLD VALUE
045,300 174          1252 MOV  A,M
045,301 057          1253 CMA
045,302 341          1254 POP  H          (H) = OLD (A)
045,303 244          1255 ANA  H          (A) = (.NOT.BIT).AND.LSTCTL
045,304 041 131 067 1256 LXI  M,LSTCTL
045,307 266          1257 ORA  M          SET BITS MENTIONED IN /L: SWITCH
045,310 002          1258 STAX B
045,311 303 271 045 1259 JMP  LOF
  
```

```

1261 **      LST - PERFORM LON AND LOF PRESET.
1262 *
1263 *      LST PERFORMS SOME FIXED TASKS FOR LON AND LOF.
1264 *
1265 *      ENTRY  (DE) = NEXT EXPRESSION CHARACTER
1266 *      EXIT   'Z' SET IF END OF LIST
1267 *           'Z' CLEAR IF VALID CHARACTER
1268 *           IF NOT AT END:
1269 *           (DE) UPDATED
1270 *           (BC) = #LSTCTL
1271 *           (A) = (LSTCTL)
1272 *           (HL) = ADDRESS OF OPTION BIT
  
```

```
1273
1274
045.314 032 1275 LST LDAX D
045.315 315 031 053 1276 CALL CEF CHECK FOR END OF FIELD CHARACTER
045.320 310 1277 RE END OF FIELD
045.321 023 1278 INX D
045.322 041 342 045 1279 LXI H,LSTA
045.325 315 261 061 1280 CALL $TELS TABLE SEARCH
045.330 302 017 044 1281 JNZ FLGERA NOT GOOD OPTION
045.333 366 001 1282 ORI 1 CLEAR 'Z'
045.335 001 130 067 1283 LXI B,LSTCTL
045.340 012 1284 LDAX B
045.341 311 1285 RET
1286
1287
045.342 1288 LSTA ERU * OPTION TABLE
045.342 114 001 1289 DB 'L',LST,L
045.344 107 200 1290 DB 'G',LST,G
045.346 111 002 1291 DB 'I',LST,I
045.350 103 004 1292 DB 'C',LST,C
045.352 000 000 1293 DB 0,0
```

```
1296 **   ORG - SET ORIGIN COUNTER.  
1297 *  
1298 *   ORG   EXPR  
1299 *  
1300 *   EXPRESSION MUST EVALUATE PASS 1  
1301  
1302  
045,354 072 144 067 1303 FORG   LDA   FTFLAG  
045,357 247          1304       ANA   A  
000,000          1305       ERRNZ FT,ABS  
045,360 302 026 044 1306       JNZ   ERR.O.   OP CODE ERROR  
045,363 315 372 054 1307       CALL  EPD      EVALUATE PASS 1  
045,366 302 017 044 1308       JNZ   FLGERA   BAD VALUE  
045,371 140          1309       MOV   H,B  
045,372 151          1310       MOV   L,C  
045,373 042 134 067 1311       SHLD  ORG      SET NEW ORG  
045,376 042 136 067 1312       SHLD  SORG     SET TO COME OUT ON LISTING  
046,001 315 335 053 1313       CALL  DLH      DEFINE LABEL HERE  
046,004 303 032 044 1314       JMP   ASM11    LIST WITH ORG
```

```

1317 **      END - END OF PROGRAM.
1318 *
1319 *      END
1320
1321
046.007 315 116 057 1322 END   CALL   UOL           UNPACK ORG INTO LINE
046.012 072 142 067 1323      LDA   XTXFLG
046.015 247          1324      ANA   A
046.016 302 026 044 1325      JNZ   ERR.O.       AM IN XTEXT
046.021 072 144 067 1326      LDA   FTFLAG
000.000          1327      ERRNZ FT,ABS
046.024 247          1328      ANA   A
046.025 302 047 046 1329      JNZ   END1        IS PIC, CANNOT TAKE ENTRY POINT
046.030 315 372 054 1330      CALL  EP0         EVALUATE PASS 1
046.033 151          1331      MOV   L,C
046.034 140          1332      MOV   H,B
046.035 042 201 067 1333      SHLD  ARGENT      SET PROGRAM ENTRY POINT ADDRESS
046.040 257          1334      XRA   A
046.041 315 351 055 1335      CALL  ORB        ADD 00 BYTE TO END
046.044 303 072 046 1336      JMP   END3        FLAG END AND EXIT
1337
1338 *      IS PIC, NO PASS-DEPENDANT STUFF..
1339
046.047 072 122 067 1340 END1   LDA   PASS
046.052 075          1341      BCR   A
046.053 302 067 046 1342      JNZ   END2        PASS 2
046.056 052 134 067 1343      LHLD  ORG
046.061 042 211 067 1344      SHLD  PICPTR     SET ADDRESS OF RELOCATION TABLE
046.064 303 072 046 1345      JMP   END3        FLAG END AND EXIT
1346
046.067 315 202 055 1347 END2   CALL  GRT         PIC AND PASS2 - GENERATE RELOC TABLE
1348
1349
1350 **      ENTER HERE TO FORCE END OF PASS
1351
046.072          1352 END.   EQU   *
1353
046.072 076 001     1354 END3   MVI   A,1
046.074 062 133 067 1355      STA  ENDFLG
046.077 303 044 044 1356      JMP  ASM13       LIST, ORG ALREADY DECODED

```

```

1359 **      EQU - EQUIVALENCE SYMBOL.
1360 *
1361 * LAB    EQU      EXPR
1362 *
1363 *      ASSIGN VALUE OF *EXPR* TO LABEL.
1364 *
1365 *      EXPRESSION MUST EVALUATE PASS 1
1366
1367
046.102 365      1368 EQU    PUSH    PSW      SAVE PASS FLAG
046.103 315 372 054 1369      CALL    EFG      EVALUATE PASS ONE
046.106 302 044 044 1370      JNZ     ASM13     ERROR
046.111 361      1371      POP     PSW      RESTORE PASS FLAG
046.112 322 126 046 1372      JNC     EQU1     PASS 2
1373
1374 *      PASS 1
1375
046.115 021 000 002 1376      LXI    D,ST,EQU*256+ST,UND
046.120 315 255 053 1377      CALL    DEF      DEFINE SYMBOL
046.123 303 044 044 1378      JMP     ASM13     EXIT
1379
1380 *      PASS 2
1381
046.126 021 056 070 1382 EQU1   LXI    D,LABEL
046.131 315 016 057 1383      CALL    SST
046.134 176      1384      MOV     A,M
000.000      1385      ERRNZ  ST,IBL-2000 ASSUMES = 2000
046.135 027      1386      RAL
046.136 322 037 044 1387      JNC     ASM11.    OK, LIST WITH (BC) = ORG
046.141 315 003 057 1388      CALL    SEF      ** ERROR
046.144 004      1389      DB     ERK,D
046.145 303 037 044 1390      JMP     ASM11.

```



```

1392 **      SET - SET VALUE.
1393 *
1394 * LAB    SET      EXPR
1395 *
1396 *      SET PERFORMS THE SAME FUNCTION AS EQU, BUT THE ASSIGNMENT IS MADE
1397 *      PASS 2, AND A VALUE MAY BE RE-SET.
1398
1399
046.150      1400 SET    EQU    *
046.150 315 215 051 1401      CALL    EVL      EVALUATE
046.153 021 003 003 1402      LXI    D,ST,SET*256+ST,SET
046.156 315 255 053 1403      CALL    DEF
046.161 303 037 044 1404      JMP     ASM11.    LIST WITH (BC) = ORG

```


CODE - PROCESS CODE PSEUDO

CODE

15:19:19 16-MAY-80

```

1408 ** CODE - PROCESS CODE PSEUDO.
1409 *
1410 * CODE ABS GENERATE ABS CODE
1411 * CODE PIC GENERATE PIC CODE
1412
1413
046.164 1414 CODE EDU *
046.164 315 172 046 1415 CALL CODE0 PROCESS PSEUDO
046.167 303 032 044 1416 JMP ASM11 LIST WITH ORG
1417
046.172 041 141 067 1418 CODE0 LXI H,GRFPLG
046.175 176 1419 MOV A,M
046.176 064 1420 INR M
046.177 247 1421 ANA A
046.200 312 206 046 1422 JZ CODE1 IN GROUP 1
046.203 303 026 044 1423 JMP ERR.0. *0* ERROR, NOT IN 1ST GROUP
1424
1425 * AM IN 1ST GROUP.
1426
046.206 032 1427 CODE1 LDAX D
046.207 376 101 1428 CPI 'A'
046.211 006 000 1429 MVI B,FT.ABS
046.213 312 231 046 1430 JE CODE2 GOT TYPE
046.216 004 1431 INR B (B) = FT.PIC
046.217 376 120 1432 CPI 'P'
000.000 1433 ERRNZ FT.PIC-FT.ABS-1
046.221 312 231 046 1434 JE CODE2 GOT IT
046.224 315 003 057 1435 CALL SEF
046.227 010 1436 DB ERR.A CANT UNDERSTAND OPERAND
046.230 311 1437 RET
1438
1439 * GOT A TYPE SPECIFIED
1440 *
1441 * (B) = FT.XXX
1442
046.231 170 1443 CODE2 MOV A,B
046.232 062 144 067 1444 STA FTFLAG SET TYPE
000.000 1445 ERRNZ FT.PIC*64-ST.REL
046.235 017 1446 RRC
046.236 017 1447 RRC
046.237 062 145 067 1448 STA RELFLG RELFLG = ST.REL IF FT.PIC
046.242 076 001 1449 MVI A,1
046.244 062 146 067 1450 STA CODEFLG SET CODE PSEUDO ENCOUNTERED
046.247 170 1451 MOV A,B
000.000 1452 ERRNZ FT.ABS
046.250 247 1453 ANA A
046.251 312 273 046 1454 JZ CODE2.5 IS ABS
046.254 041 000 000 1455 LXI H,0
046.257 042 175 067 1456 SHLD ABSFWA SET CODE DISPLACEMENT =0
046.262 041 006 000 1457 LXI H,PIC.COD
046.265 042 134 067 1458 SHLD ORG SET DEFAULT ORG = 0 (PIC.COD FOR 1ST USER GENERATED BYTE)
046.270 042 136 067 1459 SHLD SORG
046.273 072 122 067 1460 CODE2.5 LDA PASS
046.276 075 1461 DCR A
046.277 310 1462 RZ PASS 1
1463

```

```

1464 *      IS PASS 2. GENERATE BINARY HEADER
1465
046.300 005 1466 DCR      B
000.000 1467 ERRNZ   FT,PIC-1
046.301 312 341 046 1468 JZ      CODE3      IS PIC
1469
1470 *      IS ABSOLUTE. GENERATE
1471 *
1472 *      377Q,FT,ABS,FWA,LWA,ENTRY
1473
046.304 052 203 067 1474 LHLD    ABSLWA
046.307 353 1475 XCHG
046.310 052 175 067 1476 LHLD    ABSFWA      (HL) = FWA BENED CODE
046.313 315 224 030 1477 CALL    *CHL
046.316 031 1478 DAB     D      (HL) = LENGTH
046.317 042 177 067 1479 SHLD    ABSLEN      SET LENGTH
046.322 076 010 1480 MVI     A,ABS.COD
046.324 062 172 067 1481 STA     BINSKW      SET BINARY SKEW IN FILE
046.327 315 141 061 1482 CALL    *MOVEL
046.332 010 000 173 1483 DW     ABS.COD,ABSHDR,BINBFR  SET HEADER IN BUFFER
046.340 311 1484 RET
1485
1486 *      IS PIC, GENERATE
1487 *
1488 *      377Q,FT,PIC,LEN,POINTER
1489
046.341 257 1490 CODE3  XRA     A
046.342 062 172 067 1491 STA     BINSKW      NO BINARY SKEW DUE TO HEADER
046.345 315 141 061 1492 CALL    *MOVEL      SET HEADER IN BUFFER
046.350 006 000 205 1493 DW     PIC.COD,PICHDR,BINBFR
046.356 311 1494 RET

```

XTEXT - PROCESS XTEXT PSEUDO

XTEXT

15:19:21 16-MAY-80

```

1498 ** XTEXT - PROCESS XTEXT PSEUDO.
1499 *
1500 * XTEXT NAME
1501 *
1502 * LOOK ON SAME DISK AS SOURCE FILE, THEN LOOK ON OTHER
1503
1504
046.357 072 142 067 1505 XTEXT LDA TXFLG
046.362 247 1506 ANA A
046.363 302 026 044 1507 JNZ ERR.D. ALREADY IN XTEXT
1508
1509 * GET CURRENT DEVICE.
1510
046.366 041 326 067 1511 LXI H, TXFB+FB.NAM
046.371 315 164 061 1512 CALL $CPF COPY FILE NAME
046.374 021 074 047 1513 LXI D, XTEXTA
046.377 041 074 070 1514 LXI H, XTEXTB
047.002 325 1515 PUSH D SAVE ADDRESS OF DEFAULT BLOCK
047.003 076 002 1516 MVI A, CN.SOU
047.005 377 054 1517 DB SYSCALL, NAME GET NAME OF INPUT FILE
047.007 322 021 047 1518 JNC XTEXT0 NO ERROR
047.012 315 003 057 1519 CALL SEF
047.015 010 1520 DB ERR.A
047.016 303 032 044 1521 JMP ASM11
1522
047.021 315 141 061 1523 XTEXT0 CALL $MOVEL SET DEFAULT EXTENSION
047.024 003 000 105 1524 DW 3, XTEXTD, XTEXTA+3
047.032 321 1525 POP D (DE) = DEFAULT BLOCK ADDRESS
047.033 041 314 067 1526 LXI H, TXFB
047.036 315 337 061 1527 CALL $FOPER. OPEN WITH DEVICE AS DEFAULT
047.041 322 064 047 1528 JNC XTEXT1 GOT IT
1529
1530 * CANT OPEN ON THAT DEVICE, TRY THE OTHER
1531
047.044 021 102 047 1532 LXI D, XTEXTC
047.047 315 337 061 1533 CALL $FOPER.
047.052 322 064 047 1534 JNC XTEXT1 GOT IT
1535
1536 * CANT FIND IT ANYWHERE !
1537
047.055 315 003 057 1538 CALL SEF
047.060 001 1539 DB ERR.U
047.061 303 032 044 1540 JMP ASM11 LIST WITH ORG
1541
1542 * GOT IT OPEN
1543
047.064 076 001 1544 XTEXT1 MVI A, I
047.066 062 142 067 1545 STA TXFLG
047.071 303 032 044 1546 JMP ASM11 LIST WITH ORG
1547
047.074 1548 XTEXTA DS 6 DEFAULT BLOCK FOR FIRST TRY TO OPEN
047.102 123 131 060 1549 XTEXTC DB 'SYO' DEFAULT BLOCK FOR 2ND TRY
047.105 101 103 115 1550 XTEXTB DB 'ACM' EXTENSION FOR ANY FETCH

```

1554 ** SNG - SINGLE BYTE, NO OPERAND.
1555 *
1556
1557
044.001 1558 SNG EQU ASMB GENERATE 1 BYTE

1560 ** IMM - IMMEDIATE ARITHMETIC.
1561 *
1562 * OPC VAL
1563
1564
047.110 315 341 054 1565 IMM CALL EBB EVALUATE TO 8 BITS
047.113 106 1566 MOV B,M
047.114 303 354 043 1567 JMP ASMB GENERATE 2 BYTES

1569 ** THR - THREE BYTE OPCODES.
1570 *
1571 * OPC EXPR
1572 *
1573 * JMP, CALL, LHLD, SHLD, LDA, STA
1574
1575
047.117 315 215 051 1576 THR CALL EVL
047.122 126 1577 MOV D,M
047.123 303 364 043 1578 JMP ASMB7 GENERATE 3 BYTES

1580 ** RAO - REGISTER ARITHMETIC, TYPE 1.
1581 *
1582 * REGISTER SPECIFIED IN LOW 3 BITS.
1583
1584
047.126 315 225 054 1585 RAO CALL DRS DECODE REGISTER SPECIFICATION
047.131 276 1586 DB #DRSA GROUP 1
047.132 303 000 044 1587 JMP ASMB. GENERATE 1 BYTE

1589 ** RAT - REGISTER ARITHMETIC, TYPE 2.
1590 *
1591 * REGISTER SPECIFICATION IN MID 3 BITS
1592
1593
047.135 315 225 054 1594 RAT CALL DRS DECODE REGISTER SPECIFICATION
047.140 276 1595 DB #DRSA GROUP 1
047.141 007 1596 RLC
047.142 007 1597 RLC

047.143	007	1598	RLC				
047.144	303 000 044	1599	JMP	ASMB.	GENERATE 1 BYTE		
		1601	**	RPO - REGISTER PAIR, GROUP 1			
		1602	*				
		1603	*	B =1, D=0, H=5, S=7			
		1604					
		1605					
047.147	315 225 054	1606	RPO	CALL	DRS	DECODE REGISTER SPECIFICATION	
047.152	317	1607		DB	#DRSB	GROUP 2	
047.153	303 000 044	1608		JMP	ASMB.	GENERATE 1 BYTE	
		1610	**	RPT - REGISTER PAIR GROUP 2			
		1611	*				
		1612	*	PUSH, FDP			
		1613	*				
		1614	*	B=0, D=2, H=4, F=6			
		1615					
		1616					
047.156	315 225 054	1617	RPT	CALL	DRS	DECODE REGISTER SPECIFICATION	
047.161	330	1618		DB	#DRSC	GROUP 3	
047.162	303 000 044	1619		JMP	ASMB.	GENERATE 1 BYTE	
		1621	**	INX - PROCESS INX INSTRUCTION.			
		1622	*				
		1623					
		1624					
047.165	315 173 047	1625	INX	CALL	INX1	DECODE REGISTER SPECIFICATION	
047.170	303 000 044	1626		JMP	ASMB.	RETURN WITH CODE	
		1627					
		1628					
		1629	**	INX1 - B=00, D=20, H=40, S=60			
		1630					
047.173	315 225 054	1631	INX1	CALL	DRS		
047.176	317	1632		DB	#DRSB	GROUP 2	
047.177	075	1633		DCR	A		
047.200	027	1634		RAL			
047.201	027	1635		RAL			
047.202	027	1636		RAL			
047.203	346 070	1637		ANI	0700		
047.205	311	1638		RET			

```

1640 **      MVI - PROCESS MVI INSTRUCTIIN.
1641 *
1642 *      MVI      REG,VAL
1643
1644
047.206 315 225 054 1645 MVI  CALL  DRS      DECODE REG SPEC
047.211 276          1646      NR      #DRSA    GROUP 1
047.212 007          1647      RLC
047.213 007          1648      RLC
047.214 007          1649      RLC
047.215 200          1650      ADD  B
047.216 147          1651      MOV  H,A      (H) = OPCODE BYTE
047.217 315 066 053 1652      CALL CMA      REQUIRE COMA
047.222 315 341 054 1653      CALL ESB      EVALUTE TO 8 BITS
047.225 104          1654      MOV  B,H
047.226 303 354 043 1655      JMP  ASM6      OUTPUT 2 BYTES

```

```

1657 **      INDX - PROCESS LDAX, STAX INSTRUCTIONS
1658 *
1659 *      LDAX  B
1660 *      LDAX  D
1661 *      STAX  B
1662 *      STAX  D
1663
1664
047.231 032          1665 INDX  LDAX  D
047.232 376 102      1666      CPI  'B'
047.234 312 252 047 1667      JE   'INDX1'  IS 'B'
047.237 376 104      1668      CPI  'D'
047.241 076 020      1669      MVI  A,200
047.243 312 000 044 1670      JE   ASMB.    OUTPUT 1 BYTE
047.246 315 003 057 1671      CALL SEF      ERROR
047.251 002          1672      DB   ERR,R   BAD RESIGER SPECIFIED
047.252 170          1673 INDX1 MOV  A,B
047.253 303 001 044 1674      JMP  ASMB.    OUTPUT 1 BYTE

```

```

1676 **      RST - RESTART INSTRUCTIOIN
1677 *
1678 *      RST   EXPR
1679 *
1680 *      EXPR MUST BE 0-7
1681
1682
047.256 315 341 054 1683 RST  CALL  ESB      EVALUATE TO 8 BITS
047.261 171          1684      MOV  A,C
047.262 346 370      1685      ANI  3700
047.264 312 273 047 1686      JZ   RST1     IF OK
047.267 315 003 057 1687      CALL SEF
047.272 020          1688      DB   ERR,V
047.273 171          1689 RST1  MOV  A,C

```

RST

047.274	007		1690	RLC			
047.275	007		1691	RLC			
047.276	007		1692	RLC			
047.277	206		1693	ADD	M		
047.300	303 001 044		1694	JMP	ASMB	OUTPUT 1	

1696 ** LXI - PROCESS LXI INSTRUCTION.

1697 *

1698 * LXI REG,EXPR

1699

1700

047.303	315 173 047	1701	LXI	CALL	INX1	DECODE SPECIFICATION	
047.306	200	1702		ADD	B		
047.307	147	1703		MOV	H,A	(H) = OPCODE	
047.310	315 066 053	1704		CALL	CMA	GOBBLE COMMA	
047.313	315 215 051	1705		CALL	EVL	EVALUATE EXPRESSION	
047.316	124	1706		MOV	D,H	(D) = 3RD BYTE	
047.317	303 364 043	1707		JMP	ASM7	OUTPUT 3 BYTES	

1709 ** MOV - PROCESS MOV INSTRUCTION.

1710 *

1711 * MOV REG,REG

1712

1713

047.322	315 225 054	1714	MOV	CALL	DRS		
047.325	276	1715		DB	#DRSA	GROUP 1	
047.326	007	1716		RLC			
047.327	007	1717		RLC			
047.330	007	1718		RLC			
047.331	260	1719		ORA	B		
047.332	107	1720		MOV	B,A	(B) = OPCODE AND 1ST REG	
047.333	315 066 053	1721		CALL	CMA	READ ,	
047.336	315 225 054	1722		CALL	DRS		
047.341	276	1723		DB	#DRSA	GROUP 1	
047.342	200	1724		ADD	B		
047.343	303 001 044	1725		JMP	ASMB	SINGLE BYTE	

```

1729 **      DNT - DECODE NEXT TOKEN.
1730 *
1731 *      DNT IS CALLED TO DECODE THE NEXT TOKEN.
1732 *
1733 *      IF TOKEN = OPERATOR, (L) = INDEX
1734 *          =0 +
1735 *          =1 -
1736 *          =2 *
1737 *          =3 /
1738 *
1739 *      IF TOKEN = SYMBOL, (BC) = VALUE
1740 *
1741 *      DNT EXITS THROUGH A BRANCH TABLE.
1742 *
1743 *      CALL      DNT
1744 *      DB      ADRA-*      IF +
1745 *      DB      ADRB-*      IF -
1746 *      DB      ADRC-*      IF *
1747 *      DB      ADRD-*      IF /
1748 *      DB      ADRE-*      IF SYMBOL
1749 *      DB      ADRF-*      IF END OF EXPR
1750 *
1751 *      ENTRY    (DE) = EXPRESSION POINTER
1752 *      EXIT      (BC) = VALUE IF SYMBOL
1753 *              (L) = INDEX IF OPERATOR
1754 *              TOKREL = ST.REL IF RELOCATABLE VALUE
1755 *      USES     ALL
1756 *
047.346      1758 DNT EQU *
047.346 041 076 031 1759 LXI H,$TBRA
047.351 345 1760 PUSH H SET $TBRA EXIT VIA *RET*
047.352 257 1761 XRA A
047.353 062 354 067 1762 STA TOKREL CLEAR RELOCATION FLAG
047.356 032 1763 LDAX B
047.357 376 047 1764 CPI QUOTE
047.361 302 017 050 1765 JNE DNT2 NOT QUOTE
1766
1767 *      HAVE 'C' OR 'CC'
1768
047.364 023 1769 INX B
047.365 315 252 055 1770 CALL GSC GET STRING CHARACTER
047.370 312 353 050 1771 JZ DNT13 NULL STRING ILLEGAL
047.373 117 1772 MOV C,A
047.374 006 000 1773 MVI B,0 ASSUME ONE CHARACTER
047.376 315 252 055 1774 CALL GSC GET STRING CHARACTER
050.001 312 014 050 1775 JZ DNT1 ONLY 1 CHARACTER
050.004 101 1776 MOV B,C
050.005 117 1777 MOV C,A
050.006 315 252 055 1778 CALL GSC GET STRING CHARACTER
050.011 302 353 050 1779 JNZ DNT13 TOO MANY CHARACTERS
050.014 076 004 1780 DNT1 MVI A,4
050.016 311 1781 RET RETURN VIA $TBRA
1782
1783 *      HAVE OPERATOR OR SYMBOL OR NULL
1784

```


050.017	315	031	053	1785	DNT2	CALL	CEP	CHECK FOR END OF FIELD
050.022	076	005		1786		MVI	A,5	
050.024	310			1787		RZ		IF END OF FIELD
050.025	032			1788		LDAX	D	
050.026	376	054		1789		CPI	'','	
050.030	076	005		1790		MVI	A,5	
050.032	310			1791		RE		IF '','', FLAG AS END OF EXPRESSION
050.033	315	027	051	1792		CALL	LCT	LOOKUP CHARACTER
050.036	157			1793		MOV	L,A	
050.037	007			1794		RLC		
050.040	332	061	050	1795		JC	DNT3	IS SYMBOL
050.043	007			1796		RLC		
050.044	332	163	050	1797		JC	DNT6	IS NUMBER
050.047	007			1798		RLC		
050.050	322	353	050	1799		JNC	DNT13	ERROR
				1800				
				1801	*			HAVE OPERATOR
				1802				
050.053	175			1803		MOV	A,L	
050.054	346	003		1804		ANI	3	
050.056	157			1805		MOV	L,A	
050.057	023			1806		INX	D	
050.060	311			1807		RET		EXIT VIA \$TBRA
				1808				
				1809	*			HAVE SYMBOL, BUILD IT UP
				1810				
050.061	041	004	051	1811	DNT3	LXI	H,DNTA	(HL) = WORKAREA POINTER
050.064	006	007		1812		MVI	B,7	7 CHAR MAX
050.066	345			1813		PUSH	H	
050.067	053			1814		DCX	H	
050.070	315	027	051	1815	DNT4	CALL	LCT	LOOKUP CHARACTER TYPE
050.073	346	300		1816		ANI	3000	
050.075	312	110	050	1817		JZ	DNT5	NOT ALPHANUMERIC
050.100	032			1818		LDAX	D	
050.101	043			1819		INX	H	
050.102	167			1820		MOV	H,A	
050.103	023			1821		INX	D	
050.104	005			1822		DCR	B	
050.105	302	070	050	1823		JNZ	DNT4	IF MORE TO COPY
				1824				
				1825	*			HAVE SYMBOL, LOOKUP VALUE
				1826				
050.110	176			1827	DNT5	MOV	A,H	SET SIGN ON LAST CHARACTER
050.111	366	200		1828		ORI	2000	
050.113	167			1829		MOV	H,A	
050.114	353			1830		XCHG		
050.115	343			1831		XTHL		SAVE DE, (HL) = DNTA
050.116	353			1832		XCHG		
050.117	315	016	057	1833		CALL	SST	SEARCH SYMBOL TABLE
050.122	176			1834		MOV	A,M	(A) = TYPE
050.123	043			1835		INX	H	
000.000				1836		ERRNZ	ST,UND	CODE ASSUMES = 0
050.124	247			1837		ANA	A	
050.125	302	135	050	1838		JNZ	DNT5.5	DEFINED
050.130	315	003	057	1839		CALL	SEF	*U* ERROR
050.133	001			1840		DR	ERR,U	

```

050.134 257      1841      XRA      A      CLEAR FLAG
050.135 365      1842 DNT5.5  PUSH     PSW     SAVE CODE
050.136 346 100   1843      ANI      ST,REL
050.140 062 354 067 1844      STA      TOKREL SET RELOCATABLE FLAG
050.143 361      1845      POP      PSW     (A) = FLAG BITS
050.144 027      1846      RAL
050.145 322 154 050 1847      JNC      DNT5.7 NOT REFERENCE TO DOUBLE DEFINED
050.150 315 003 057 1848      CALL     SEF     FLAG ** FOR DOUBLE REFERENCE
050.153 200      1849      DB      ERK.P
050.154      1850 DNT5.7  EQU      *
050.154 116      1851      MOV      C,M
050.155 043      1852      INX      H
050.156 106      1853      MOV      B,M     (BC) = VALUE
050.157 321      1854      POP      D      RESTORE (DE)
050.160 076 004   1855      MVI      A,4
050.162 311      1856      RET      $TBRA  EXIT VAI $TBRA
1857
1858 *      HAVE NUMBER
1859
050.163 041 003 051 1860 DNT6   LXI      H,DNTA-1
050.166 006 022   1861      MVI      B,18   18 DIGITS MAX
050.170 315 027 051 1862 DNT7   CALL     LCT     LOOKUP TYPE
050.173 346 120   1863      ANI      120Q   SEE IF NUMBER OR POSTRADIX
050.175 312 210 050 1864      JZ      DNT8   OUT OF NUMBER
050.200 032      1865      LBAX     D
050.201 043      1866      INX      H
050.202 167      1867      MOV      M,A     COPY TO WORK AREA
050.203 023      1868      INX      D
050.204 005      1869      DCR      B
050.205 302 170 050 1870      JNZ      DNT7
1871
1872 *      HAVE ACCUMULATED NUMBER, SEE IF HAS POSTRADIX.
1873
050.210      1874 DNT8   EQU      *
050.210 257      1875      XRA      A
050.211 062 332 050 1876      STA      DNTD   FLAG NO OVERFLOW
050.214 176      1877      MOV      A,M
050.215 062 333 050 1878      STA      DNTC   SAVE POSTRADIX
050.220 315 034 051 1879      CALL     LCT.   LOOKUP CHARACTER TYPE
050.223 346 020   1880      ANI      200
050.225 302 233 050 1881      JNZ      DNT9   HAS POSTRADIX
050.230 043      1882      INX      H
050.231 066 104   1883      MVI      M,D
050.232      1884 DNT8   EQU      *-1  DEFAULT POSTRADIX
1885
1886 *      COMPUTE BASE
1887
050.233 176      1888 DNT9   MOV      A,M     (A) = POSTRADIX
050.234 066 200   1889      MVI      M,200Q FLAG END OF NUMBER
050.236 315 034 051 1890      CALL     LCT.   LOOPUP CHARACTER TYPE
050.241 346 017   1891      ANI      170
050.243 074      1892      INR      A     (A) = POSTRADIX
050.244 325      1893      PUSH     D     SAVE EXPRESSION POINTER
050.245 137      1894      MOV      E,A
050.246 026 000   1895      MVI      B,0     (DE) = BASE
1896
    
```

				1897	*	DECODE NUMBER.		
				1898				
050.250	041	000	051	1899		LXI	H,DNTA	
050.253	001	000	000	1900		LXI	B,0	PRESET ACCUMULATOR TO 0
050.256	178			1901	DNT10	MOV	A,H	
050.257	247			1902		ANA	A	
050.260	372	330	050	1903		JM	DNT11	ALL DONE
050.263	315	232	053	1904		CALL	DND	DECODE HEX DIGITS
050.266	332	352	050	1905		JC	DNT12	ERROR
050.271	043			1906		INX	H	
050.272	345			1907		PUSH	H	
050.273	325			1908		PUSH	D	
050.274	365			1909		PUSH	PSW	
050.275	315	337	030	1910		CALL	\$MU66	ACCUM = ACCUM*BASE
050.300	345			1911		PUSH	H	
050.301	041	332	050	1912		LXI	H,DNTD	ACCUMULATE OVERFLOW FLAGS
050.304	206			1913		ADD	H	
050.305	167			1914		MOV	M,A	
050.306	341			1915		POP	H	
050.307	361			1916		POP	PSW	
050.310	117			1917		MOV	C,A	
050.311	006	000		1918		MVI	R,0	(RC) = DIGIT VALUE
050.313	011			1919		DAD	B	(HL) = ACCUM*BASE + DIGIT
050.314	321			1920		POP	D	
050.315	171			1921		MOV	A,C	
050.316	273			1922		CMF	E	COMPARE DIGIT TO BASE
050.317	104			1923		MOV	B,H	
050.320	115			1924		MOV	C,L	
050.321	341			1925		POP	H	
050.322	322	352	050	1926		JNC	DNT12	ERROR
050.325	303	256	050	1927		JMP	DNT10	
				1928				
050.330	321			1929	DNT11	POP	D	NUMBER ACCUMULATED OK
050.331	041	000	000	1930		LXI	H,0	(H) = POSTRADIX, (L) = OVERFLOW
050.332				1931	DNTD	EQU	*-2	OVERFLOW FLAG
050.333				1932	DNTC	EQU	*-1	FOSTRADIX
050.334	076	101		1933		MVI	A,'A'	
050.336	274			1934		CMF	H	
050.337	314	362	050	1935		CE	DNT14	IS 'A' FOSTRADIX
050.342	175			1936		MOV	A,L	
050.343	247			1937		ANA	A	
050.344	304	377	050	1938		CNZ	DNT15	IS OVERFLOW
				1939				
050.347	076	004		1940		MVI	A,4	
050.351	311			1941		RET	\$TBRA	EXIT VIA \$TBRA
				1942				
050.352	321			1943	DNT12	POP	D	ERROR WHILE CRACKING NUMBER
				1944				
				1945	*	ERROR DETECTED		
				1946				
050.353	315	003	057	1947	DNT13	CALL	SEF	** ERROR
050.356	010			1948		DB	ERR,A	
050.357	076	005		1949		MVI	A,5	SET TYPE = NULL
050.361	311			1950		RET	\$TBRA	EXIT THROUGH \$TBRA
				1951				
050.362	175			1952	DNT14	MOV	A,L	

```

050.363 037      1953      RAR
050.364 170      1954      MOV      A,B      SHIFT HIGH BYTE RIGHT WITH CARRY
050.365 037      1955      RAR
050.366 107      1956      MOV      B,A
050.367 334 377 050 1957      CC      DNT15      BAD DIGIT
050.372 175      1958      MOV      A,L      (A) = OVERFLOW REGISTER
050.373 346 376  1959      ANI      3760     CLEAR ALLOWED OVERFLOW
050.375 157      1960      MOV      L,A      CLEAR SINGLE CARRY
050.376 311      1961      RET
                                1962
050.377 315 003 057 1963 DNT15 CALL      SEF      FLAG OVERFLOW
051.002 020      1964      DB      ERR,V
051.003 311      1965      RET
                                1966
                                1967
051.004                                1968 DNTA  DS      19      WORK AREA
    
```

```

1970 **      LCT - LOOKUP CHARACTER TYPE.
1971 *
1972 *      LCT LOOKS UP THE CHARACTER TYPE INDEX FOR A CHARACTER.
1973 *
1974 *      ENTRY (DE) = STRING POINTER
1975 *      EXIT (A) = INDEX
1976 *      1000  VALID ALPHA
1977 *      0100  VALID NUMBER
1978 *      0010  VALID OPERATOR
1979 *      0001  VALID POSTRADIX
1980 *      NNNN OFCODE INDEX IF OPERATOR, BASE IF POSTRADIX
1981 *      USES  A,F
1982 *
    
```

```

000.000      1984      ERRNZ  CT,ALPH-2000      /80.02.6C/
                                1985
051.027 032      1986 LCT  LDAX  D
051.030 247      1987      ANA  A
051.031 372 053 051 1988      JM  LCT1
051.034      1989 LCT,  EQU  *      ENTRY WITH (A) = CHARACTER
051.034 326 040  1990      SUI  ?
051.036 332 053 051 1991      JC  LCT1      TOO SMALL
051.041 345      1992      PUSH H      SAVE (HL)
051.042 041 055 051 1993      LXI H,LCTA
051.045 315 101 030 1994      CALL $DADA.
051.050 176      1995      MOV  A,M      (A) = FLAG BYTE
051.051 341      1996      POP  H
051.052 311      1997      RET
                                1998
051.053 257      1999 LCT1 XRA  A      END OF LINE
051.054 311      2000      RET
                                2001
051.055      2002 LCTA  EQU  *      CHARACTER TABLE
                                2003
051.055 000      2004      DB  00000000B  BLANK
051.056 000      2005      DB  00000000B  !
    
```

051.057	000	2006	DB	00000000E	*
051.060	000	2007	DB	00000000E	#
051.061	200	2008	DB	10000000E	\$
051.062	000	2009	DB	00000000E	PERCENT
051.063	000	2010	DB	00000000E	%
051.064	000	2011	DB	00000000E	'
051.065	000	2012	DB	00000000E	(
051.066	000	2013	DB	00000000E)
051.067	042	2014	DB	00100010E	*
051.070	040	2015	DB	00100000E	+
051.071	000	2016	DB	00000000E	,
051.072	041	2017	DB	00100001E	-
051.073	200	2018	DB	10000000E	.
051.074	043	2019	DB	00100011E	/
051.075	100	2020	DB	01000000E	0
051.076	100	2021	DB	01000000E	1
051.077	100	2022	DB	01000000E	2
051.100	100	2023	DB	01000000E	3
051.101	100	2024	DB	01000000E	4
051.102	100	2025	DB	01000000E	5
051.103	100	2026	DB	01000000E	6
051.104	100	2027	DB	01000000E	7
051.105	100	2028	DB	01000000E	8
051.106	100	2029	DB	01000000E	9
051.107	000	2030	DB	00000000E	:
051.110	000	2031	DB	00000000E	;
051.111	000	2032	DB	00000000E	<
051.112	000	2033	DB	00000000E	=
051.113	000	2034	DB	00000000E	>
051.114	000	2035	DB	00000000E	?
051.115	000	2036	DB	00000000E	@
051.116	327	2037	DB	11010111E	A
051.117	321	2038	DB	11010001E	B
051.120	300	2039	DB	11000000E	C
051.121	331	2040	DB	11011001E	D
051.122	300	2041	DB	11000000E	E
051.123	300	2042	DB	11000000E	F
051.124	200	2043	DB	10000000E	G
051.125	237	2044	DB	10011111E	H
051.126	200	2045	DB	10000000E	I
051.127	200	2046	DB	10000000E	J
051.130	200	2047	DB	10000000E	K
051.131	200	2048	DB	10000000E	L
051.132	200	2049	DB	10000000E	M
051.133	200	2050	DB	10000000E	N
051.134	227	2051	DB	10010111E	O
051.135	200	2052	DB	10000000E	P
051.136	227	2053	DB	10010111E	Q
051.137	200	2054	DB	10000000E	R
051.140	200	2055	DB	10000000E	S
051.141	200	2056	DB	10000000E	T
051.142	200	2057	DB	10000000E	U
051.143	200	2058	DB	10000000E	V
051.144	200	2059	DB	10000000E	W
051.145	200	2060	DB	10000000E	X
051.146	200	2061	DB	10000000E	Y

LCT

051.147	200	2062	DB	10000000B	Z
051.150	000	2063	DB	00000000B	[
051.151	000	2064	DB	00000000B	\
051.152	000	2065	DB	00000000B	J
051.153	000	2066	DB	00000000B	X
051.154	000	2067	DB	00000000B	-
051.155	000	2068	DB	00000000B	~
051.156	327	2069	DB	11010111B	a
051.157	321	2070	DB	11010001B	b
051.160	300	2071	DB	11000000B	c
051.161	331	2072	DB	11011001B	d
051.162	300	2073	DB	11000000B	e
051.163	300	2074	DB	11000000B	f
051.164	200	2075	DB	10000000B	g
051.165	237	2076	DB	10011111B	h
051.166	200	2077	DB	10000000B	i
051.167	200	2078	DB	10000000B	j
051.170	200	2079	DB	10000000B	k
051.171	200	2080	DB	10000000B	l
051.172	200	2081	DB	10000000B	m
051.173	200	2082	DB	10000000B	n
051.174	227	2083	DB	10010111B	o
051.175	200	2084	DB	10000000B	p
051.176	227	2085	DB	10010111B	q
051.177	200	2086	DB	10000000B	r
051.200	200	2087	DB	10000000B	s
051.201	200	2088	DB	10000000B	t
051.202	200	2089	DB	10000000B	u
051.203	200	2090	DB	10000000B	v
051.204	200	2091	DB	10000000B	w
051.205	200	2092	DB	10000000B	x
051.206	200	2093	DB	10000000B	y
051.207	200	2094	DB	10000000B	z
051.210	000	2095	DB	00000000B	_
051.211	000	2096	DB	00000000B	!
051.212	000	2097	DB	00000000B	~
051.213	000	2098	DB	00000000B	^
051.214	000	2099	DB	00000000B	DEL

2101 ** EVL - EVALUATE OPERAND EXPRESSION.
 2102 *
 2103 * EVL EVALUATES AN OPERAND EXPRESSION. IT IS PROCESSED
 2104 * LEFT TO RIGHT, WITH NO OPERATOR PRECEDENCE, AND NO PARANETHSIS.
 2105 *
 2106 * VALID OPERATORS
 2107 * +
 2108 * -
 2109 * *
 2110 * /
 2111 *
 2112 * VALID SYMBOLS
 2113 *
 2114 * LABEL

```

2115 * * LOCATION COUNTER
2116 * 'C' B BIT ASCII
2117 * 'CC' 16 BIT ASCII
2118 * NNN NUMBER, POSTRADIX =
2119 * D OCTAL
2120 * D DECIMAL
2121 * B BINARY
2122 * H HEX
2123 *
2124 * IF PASS1, UNDEFINED ERROR FLAGS WILL BE IGNORED.
2125 *
2126 * ENTRY (DE) = STRING POINTER
2127 * EXIT (BC) = VALUE
2128 * (DE) UPDATED
2129 * EXPREL = ST.REL IF RELOCATABLE
2130 * 'C' SET IF ERROR
2131 * USES A,F,B,C,D,E
2132
2133
051.215 345 2134 EVL PUSH H SAVE (HL)
051.216 001 000 000 2135 LXI B,0
051.221 257 2136 XRA A
051.222 062 353 067 2137 STA EXPREL CLEAR RELOCATABLE FLAG
051.225 305 2138 PUSH B SAVE ACCUMULATOR ON STACK
051.226 032 2139 LDAX D
051.227 376 043 2140 CPI '*'
051.231 076 377 2141 MVI A,3770 ASSUME NO #
051.233 302 240 051 2142 JNE EVL1 NO #
051.236 074 2143 INR A (A) = 0
051.237 023 2144 INX D SKIP #
051.240 062 342 051 2145 EVL1 STA EVLA SET MASK FOR RESULT
2146
2147 * HAVE NULL
2148
051.243 315 346 047 2149 CALL DNT DECODE NEXT TOKEN
051.246 032 2150 DB EVL5-* + - UNARY +
051.247 031 2151 DB EVL5-* - - UNARY -
051.250 004 2152 DB EVL2-* * - ORG
051.251 061 2153 DB EVL8-* / - ERROR
051.252 005 2154 DB EVL3-* VAL - VALUE
051.253 057 2155 DB EVL8-* NUL - ERROR
2156
051.254 315 054 052 2157 EVL2 CALL EVL20 (BC) = (ORG)
051.257 341 2158 EVL3 POP H DISCARD INITIAL VALUE
051.260 305 2159 PUSH B SET INITIAL VALUE = ORG
051.261 072 354 067 2160 LDA TOKREL
051.264 062 353 067 2161 STA EXPREL SET RELOCATABILITY OF EXPRESSION
2162
2163 * HAVE VALUE.
2164
051.267 315 346 047 2165 EVL4 CALL DNT DECODE NEXT TOKEN
051.272 006 2166 DB EVL5-* +
051.273 005 2167 DB EVL5-* -
051.274 004 2168 DB EVL5-* *
051.275 003 2169 DB EVL5-* /
051.276 034 2170 DB EVL8-* VAL - ERROR
    
```

```

2171      DB      EVL9-*      NUL - DONE
2172
2173      *      HAVE OPERATOR
2174
051.300  345      2175      EVL5      PUSH      H      SAVE OPERATOR INDEX
051.301  315 346 047 2176      CALL      BNT      DECODE NEXT TOKEN
051.304  025      2177      DB      EVL7.5-*      + - ERROR
051.305  024      2178      DB      EVL7.5-*      - - ERROR
051.306  004      2179      DB      EVL6-*      * - DRG
051.307  022      2180      DB      EVL7.5-*      / - ERROR
051.310  005      2181      DB      EVL7-*      VAL - DO OPEARTION
051.311  020      2182      DB      EVL7.5-*      NUL - ERROR
2183
051.312  315 054 052 2184      EVL6      CALL      EVL20      (BC) = (DRG)
051.315  341      2185      EVL7      POP      H
051.316  175      2186      MOV      A,L      (A) = OPERATOR INDEX
051.317  341      2187      POP      H      (HL) = OLD VALUE, (BC) = NEW
051.320  325      2188      PUSH     D
051.321  315 345 051 2189      CALL      EVL10      PERFORM OPERATION
051.324  321      2190      POP      D
051.325  345      2191      PUSH     H      SAVE RESULT
051.326  303 267 051 2192      JMP      EVL4
2193
2194      *      ERROR
2195
051.331  361      2196      EVL7.5      POP      PSW      CLEAN STACK
051.332  315 003 057 2197      EVL8      CALL      SEF      SET ERROR FLAG
051.335  010      2198      DB      ERR.A
2199
2200      *      DONE
2201
051.336  301      2202      EVL9      POP      B      (BC) = VALUE
051.337  341      2203      POP      H      RESTORE HL
051.340  170      2204      MOV      A,B
051.341  346 000      2205      ANI      0      MASK OFF IF #
051.342      2206      EVL4      EQU      *-1
051.343  107      2207      MOV      B,A
051.344  311      2208      RET
2209
2210
2211      *      PERFORM ARITHMETIC.
2212      *
2213      *      ENTRY      (L) = OPERATOR INDEX
2214      *      (BC) = Y
2215      *      (HL) = X
2216      *
2217      *      EXIT      (HL) = X OF Y
2218
051.345      2219      EVL10      EQU      *
051.345  315 076 031 2220      CALL      $TERRA
051.350  004      2221      DB      EVL11-*      +
051.351  022      2222      DB      EVL12-*      -
051.352  045      2223      DB      EVL13-*      *
051.353  053      2224      DB      EVL14-*      /
2225
051.354  011      2226      EVL11      DAD      B      +

```


051.355	345		2227		PUSH	H	SAVE SUM
051.356	041	353 067	2228		LXI	H,EXPREL	
051.361	072	354 067	2229		LDA	TOKREL	
051.364	206		2230		ADD	M	SUM RELOCATION FLAGS
000.000			2231		ERRNZ	ST.REL-1000	
051.365	167		2232		MOV	M+A	
051.366	341		2233		POP	H	RESTORE RESULT
051.367	372	047 052	2234		JM	EVL16	REL+REL IS ILLEGAL
051.372	311		2235		RET		
			2236				
051.373	175		2237	EVL12	MOV	A,L	
051.374	221		2238		SUB	C	
051.375	157		2239		MOV	L,A	
051.376	174		2240		MOV	A,H	
051.377	230		2241		SBB	B	
052.000	147		2242		MOV	H+A	
052.001	345		2243		PUSH	H	SAVE RESULT
052.002	041	353 067	2244		LXI	H,EXPREL	
052.005	072	354 067	2245		LDA	TOKREL	
052.010	226		2246		SUB	M	
052.011	167		2247		MOV	M+A	STORE RESULT
052.012	341		2248		POP	H	RESTORE RESULT
052.013	332	047 052	2249		JC	EVL16	ABS-REL ILLEGAL
052.016	311		2250		RET		
			2251				
052.017	353		2252	EVL13	XCHG		*
052.020	315	337 030	2253		CALL	\$MU66	
052.023	303	035 052	2254		JMP	EVL15	CHECK FOR RELOCATION ERROR
			2255				
052.026	120		2256	EVL14	MOV	D,B	/
052.027	131		2257		MOV	E,C	
052.030	104		2258		MOV	B,H	
052.031	115		2259		MOV	C,L	
052.032	315	106 030	2260		CALL	\$DU66	
052.035	345		2261	EVL15	PUSH	H	SAVE RESULT
052.036	041	353 067	2262		LXI	H,EXPREL	
052.041	072	354 067	2263		LDA	TOKREL	
052.044	267		2264		ORA	A	
052.045	341		2265		POP	H	RESTORE RESULT
052.046	310		2266		RZ		ABS 'OP' ABS IS OK
			2267				
			2268	*			RELOCATION ERROR
			2269				
052.047	315	003 057	2270	EVL16	CALL	SEF	
052.052	002		2271		DB	ERR,R	
052.053	311		2272		RET		

```
2274 **      EVL20 - USE ORG AS TOKEN VALUE
2275 *
2276 *      ENTRY  NONE
2277 *      EXIT   (BC) = ORG
2278 *      TOKREL SET PROPERLY
2279 *      USES  A,F,B,C,H,L
2280
2281
052,054 072 145 067 2282 EVL20  LDA  RELFLG
052,057 062 354 067 2283      STA  TOKREL          SET FLAG PROPERLY
052,062 052 134 067 2284      LHLD ORG
052,065 104      2285      MOV  B,H
052,066 115      2286      MOV  C,L          (BC) = (ORG)
052,067 311      2287      RET
```

```

2291 ** ARV - ACCUMULATE BYTE VALUE.
2292 *
2293 * ARV ADDS A BYTE TO THE BINARY BUFFER.
2294 *
2295 * THE ORG UPON ENTRY IS THE ADDRESS+1 OF THE BYTE
2296 *
2297 * ENTRY (A) = VALUE
2298 * EXIT NONE
2299 * USES NONE
2300
2301
052.070 315 054 031 2302 ARV CALL $SAVALL SAVE REGS
052.073 107 2303 MOV B,A (B) = VALUE
052.074 072 150 067 2304 LDA BINFNAM
052.077 247 2305 ANA A
052.100 312 047 031 2306 JZ $RSTALL NO BINARY FILE
052.103 072 122 067 2307 LDA PASS
052.106 374 002 2308 CPI 2
052.110 302 244 052 2309 JNE ABV2 NOT PASS 2
052.113 305 2310 PUSH R SAVE VALUE
052.114 052 175 067 2311 LHLP ABSFWA
052.117 353 2312 XCHG (DE) = ORG OF FIRST BINARY BYTE
052.120 052 134 067 2313 LHLD ORG
052.123 053 2314 ICX H (HL) = REAL ORG
052.124 175 2315 MOV A,L
052.125 223 2316 SUB E
052.126 157 2317 MOV L,A
052.127 174 2318 MOV A,H
052.130 232 2319 SRB D
052.131 147 2320 MOV H,A (HL) = INDEX OF BYTE IN BINARY FILE
052.132 072 172 067 2321 LDA BINSKW
052.135 315 101 030 2322 CALL $DADA (HL) = NUMBER OF BYTE IN BINARY FILE
052.140 072 171 067 2323 LDA BINC5N
052.143 274 2324 CMP H
052.144 312 231 052 2325 JE ABV1 CAN GO IN THIS SECTOR
2326
2327 * WILL NOT GO IN THIS SECTOR. PUT THIS SECTOR BACK, GET
2328 * THE PROPER ONE.
2329
052.147 315 123 060 2330 CALL WRR WRITE BINARY BUFFER
052.152 174 2331 MOV A,H
052.153 062 171 067 2332 STA BINC5N SET CURRENT SECTOR NUMBER
2333
2334 * NOW READ THE NEW SECTOR INTO THE BUFFER AREA. IF IT DOES NOT
2335 * YET EXIST, WRITE ENOUGH GARBAGE UNTIL IT DOES.
2336
052.156 345 2337 PUSH H
052.157 114 2338 MOV C,H (C) = SECTOR NUMBER
052.160 006 000 2339 MVI B,0
052.162 076 000 2340 MVI A,CN.BIN
052.164 377 047 2341 DB SYSCALL,POSIT POSITION TO WHERE WE WANT
052.166 322 206 052 2342 JNC ABV0 GOT THERE
052.171 101 2343 MOV B,C (B) = SECTORS TO WRITE
052.172 016 000 2344 MVI C,0
052.174 021 000 020 2345 LXI D,4096 POINT TO GARBAGE (MOSTLY 0, I THINK..)
052.177 076 000 2346 MVI A,CN.BIN

```

052,201	377	005		2347		DB	SYSCALL,,WRITE	WRITE IT
052,203	332	334	060	2348		JC	BINERR	ERROR
052,206	001	000	001	2349	ABV0	LXI	B,256	
052,211	021	237	070	2350		LXI	D,BINBFR	
052,214	076	000		2351		MVI	A,CN,BIN	
052,216	377	004		2352		DB	SYSCALL,,READ	READ IN NEW SECTOR
052,220	322	230	052	2353		JNC	ABV00	OK
052,223	374	001		2354		CFI	EC,EOF	OK IF SIMPLE EOF
052,225	302	334	060	2355		JNE	BINERR	ERROR
052,230	341			2356	ABV00	POP	H	(L) = INDEX FOR BYTE
				2357				
				2358	*			BYTE WILL GO IN THIS SECTOR
				2359				
052,231	021	237	070	2360	ABV1	LXI	D,BINBFR	
052,234	046	000		2361		MVI	H,0	
052,236	031			2362		DAD	D	(HL) = ADDRESS IN BINBFR
052,237	361			2363		POP	PSW	(A) = VALUE
052,240	167			2364		MOV	M,A	SET
052,241	303	047	031	2365		JMF	\$RSTALL	RESTORE AND EXIT
				2366				
				2367	*			IS PASS 1, IF AN ABS FILE, KEEP TRACK OF THE SMALLEST
				2368	*			AND LARGEST ADDRESS WHICH GOT DATA...
				2369				
052,244	072	144	067	2370	ABV2	LDA	FTFLAG	
052,247	247			2371		ANA	A	
052,250	302	047	031	2372		JNZ	\$RSTALL	NOT ABS
052,253	052	175	067	2373		LHLD	ABSFVA	
052,256	353			2374		XCHG		
052,257	052	134	067	2375		LHLD	ORG	COMPARE OLD LOWEST TO NOW
052,262	053			2376		DCX	H	(HL) = ORG FOR THIS BYTE
052,263	175			2377		MOV	A,L	
052,264	223			2378		SUB	E	
052,265	174			2379		MOV	A,H	
052,266	232			2380		SBB	D	
052,267	322	275	052	2381		JNC	ABV3	NOT NEW LOW
052,272	042	175	067	2382		SHLD	ABSFVA	NEW LOW
052,275	353			2383	ABV3	XCHG		
052,276	052	203	067	2384		LHLD	ABSLWA	
052,301	353			2385		XCHG		
052,302	173			2386		MOV	A,E	SEE IF NEW HIGH
052,303	225			2387		SUB	L	
052,304	172			2388		MOV	A,D	
052,305	234			2389		SBB	H	
052,306	322	047	031	2390		JNC	\$RSTALL	NOT NEW HIGH
052,311	042	203	067	2391		SHLD	ABSLWA	SET IT
052,314	303	047	031	2392		JMF	\$RSTALL	RESTORE AND RETURN

```

2394 **      BDT - BUILD DYNAMIC TABLES.
2395 *
2396 *      BDT INITIALIZES THE SYMBOL TABLE AND THE RELOCATION TABLE.
2397 *
2398 *      THE SYMBOL TABLE STARTS AT THE FIRST AVAILABLE ADDRESS,
2399 *      AND CONTINUES UP TO THE END OF THE RELOCATION TABLE.
2400 *
2401 *      THE RELOCATION TABLE STARTS IN HIGH MEMORY, AND GOES DOWN.
2402 *
2403 *      THIS ROUTINE IS USED ONE TIME ONLY, BUT CANNOT BE ENCLOSED
2404 *      WITH THE OVERLAID CODE, IN THAT THIS ROUTINE ZAPS THAT OVERLAID AREA.
2405 *
2406 *      ENTRY  NONE
2407 *      EXIT   'C' CLEAR IF OK
2408 *           'C' SET IF ERROR, ERROR MESSAGE PRINTED
2409 *      USES  ALL
2410 *
2411
052.317 052 320 040 2412 BDT  LHL D  S,SYSH      (HL) = FWA SYSTEM
052.322 072 147 067 2413  LDA  LARGE
052.325 247 2414  ANA  A
052.326 302 341 052 2415  JNZ  BDT1      WILL USEE ALL WE CAN
052.331 353 2416  XCHG
052.332 052 324 040 2417  LHL D  S,DMAX
052.335 315 224 030 2418  CALL %CHL
052.340 031 2419  DAD  D          (HL) = AMOUNT WHICH WILL NOT CAUSE OVERLAY SWAPING
052.341 021 364 377 2420 BDT1  LXI  D,-12
052.344 031 2421  DAD  D
052.345 353 2422  XCHG          (DE) = LIMIT FOR REL TABLE
052.346 041 375 300 2423  LXI  H,-SYMTAB-256
052.351 031 2424  DAD  D
052.352 322 021 053 2425  JNC  BDT4      NOT AT LEAST 256 BYTES
052.355 353 2426  XCHG          (HL) = REL LIMIT
052.356 042 223 067 2427  SHLD RELLWA   SET LIMIT FOR REL TABLE
052.361 042 224 067 2428  SHLD RELFTR   SET REL TABLE EMPTY
052.364 377 052 2429  DB   SYSCALL,SETTP  REQUEST IT
052.366 322 377 052 2430  JNC  BDT2      OK
052.371 046 007 2431  MVI  H,BELL
052.373 377 057 2432  DB   SYSCALL,ERROR  PROBLEMS
052.375 067 2433  STC          FLAG ERROR
052.376 311 2434  RET
2435
052.377 052 216 067 2436 BDT2  LHL D  SYMFWA
053.002 353 2437  XCHG
053.003 052 222 067 2438  LHL D  RELLWA
053.006 053 2439 BDT3  ICX  H
053.007 066 000 2440  MVI  M,0      CLEAR TABLE AREA
053.011 315 216 030 2441  CALL %CDEHL
053.014 302 006 053 2442  JNE  BDT3      MORE TO GO
053.017 247 2443  ANA  A
053.020 311 2444  RET          RETURN WITH 'C' CLEAR
2445
2446 *      NOT AT LEAST 256 BYTES IN SYMTAB. FORCE /LARGE
2447
053.021 076 001 2448 BDT4  MVI  A,1
053.023 062 147 067 2449  STA  LARGE     SET LARGE

```

053.026 303 317 052 2450 JMP BOT TRY AGAIN

2452 ** CEF - CHECK FOR END OF FIELD CHARACTER.
 2453 *
 2454 * CEF CHECKS A CHARACTER TO SEE IF IT IS A
 2455 *
 2456 * 00, BLANK, OR TAB
 2457 *
 2458 * ENTRY (A) = CHARACTER
 2459 * EXIT 'Z' SET IF 00, BLANK OR TAB
 2460 * 'Z' CLEAR OTHERWISE
 2461 * USES F
 2462
 2463

053.031 247 2464 CEF ANA A 00
 053.032 310 2465 RZ
 053.033 376 011 2466 CPI TAB
 053.035 310 2467 RE TAB
 053.036 376 040 2468 CPI
 053.040 311 2469 RET RETURN WITH CODE

2471 ** CLE - CHECK LISTING ELIGIBILITY.
 2472 *
 2473 * CLE IS CALLED TO SEE IF THE CURRENT LINE SHOULD BE LISTED TO
 2474 * THE OUTPUT FILE.
 2475 *
 2476 * IF LST.L = FALSE, DONT LIST
 2477 * IF XTEXT LINE AND LST.C = FALSE, DONT LIST
 2478 *
 2479 * ENTRY NONE
 2480 * EXIT 'Z' CLEAR IFF TO LIST
 2481 * USES A:F,H:L
 2482
 2483

053.041 041 130 067 2484 CLE LXI H,LSTCTL
 053.044 174 2485 MOV A,M
 053.045 346 001 2486 ANI LST.L
 053.047 310 2487 RZ DONT LIST
 053.050 072 143 067 2488 LDA XTXXLINE
 053.053 247 2489 ANA A
 053.054 302 062 053 2490 JNZ CLE1 IS XTEXT
 053.057 346 001 2491 ORI 1 LIST
 053.061 311 2492 RET
 2493
 053.062 174 2494 CLE1 MOV A,M
 053.063 346 004 2495 ANI LST.C
 053.065 311 2496 RET

```

2498 **      CMA - READ COMMA.
2499 *
2500 *      CMA IS CALLED WHEN A COMMA IS EXPECTED TO APPEAR IN THE
2501 *      EXPRESSION. IT IS CHECKED, AND ADVANCED OVER.
2502 *
2503 *      ENTRY (DE) = LINE POINTER
2504 *      EXIT (DE) ADVANCED
2505 *      USES A,F,D,E
2506
2507
053.066 032      2508 CMA      LDAX   D
053.067 023      2509      INX   D
053.070 376 054  2510      CPI   ','
053.072 310      2511      RE
053.073 315 003 057 2512      CALL  SEF          OK
053.076 010      2513      DB    ERR,A          ** ERROR
053.077 311      2514      RET

2516 **      COL - COUNT OUTPUT LINES.
2517 *
2518 *      COL IS CALLED TO COUNT AN OUTPUT LINE BEFORE IT IS WRITTEN.
2519 *
2520 *      ENTRY NONE
2521 *      EXIT NONE
2522 *      USES A,F
2523
2524
053.100 345      2525 COL      PUSH   H          SAVE (HL)
053.101 325      2526      PUSH   D
053.102 305      2527      PUSH   B          SAVE REGISTERS
2528
053.103 041 350 067 2529      LXI   H,EJFLG
053.106 176      2530      MOV   A,M          (A) = EJFLG
053.107 247      2531      ANA   A
053.110 066 000  2532      MVI   M,0          CLEAR FLAG
000.000      2533      ERRMZ LINCNT-EJFLG-1
053.112 043      2534      INX   H
053.113 176      2535      MOV   A,M          (A) = LINCNT
053.114 302 123 053 2536      JNZ  COL1          EJFLG < 0
053.117 247      2537      ANA   A
053.120 302 205 053 2538      JNZ  COL3          NOT TIME YET
2539
2540 *      FORCE NEW PAGE.
2541
053.123 345      2542 COL1    PUSH   H          /78.10.GC/
053.124 315 104 055 2543      CALL  FNF          FORCE NEW PAGE
053.127 041 352 067 2544      LXI   H,PAGNUM    /78.10.GC/
053.132 176      2545      MOV   A,M
053.133 306 001  2546      ADI   1          DECODE PAGE NUMBER
053.135 047      2547      DAA          INCREMENT
053.136 167      2548      MOV   M,A
053.137 365      2549      PUSH  PSW
053.140 037      2550      RAR
  
```

053.141	037	2551		RAR			
053.142	037	2552		RAR			
053.143	037	2553		RAR			
053.144	346 017	2554		ANI	170	(A) = HIGH DIGIT	
053.146	302 153 053	2555		JNZ	COL2.5	NON-ZERO	
053.151	076 360	2556		MVI	A, '0'		
053.153	306 060	2557	COL2.5	ADI	'0'		
053.155	062 052 067	2558		STA	HEADA		
053.160	361	2559		POP	PSW		
053.161	346 017	2560		ANI	170	2ND DIGIT	
053.163	306 060	2561		ADI	'0'		
053.165	062 053 067	2562		STA	HEADB		
053.170	001 222 000	2563		LXI	B, HEADLEN		
053.173	021 234 066	2564		LXI	D, HEADING		
053.176	041 226 067	2565		LXI	H, LISTFB		
053.201	315 047 063	2566		CALL	\$FWRIB	WRITE HEADING	
053.204	341	2567		POP	H		/78.10.GC/
		2568					
053.205	065	2569	COL3	DCR	M	COUNT LINE	/78.10.GC/
		2570					
053.206	301	2571		POP	B		
053.207	321	2572		POP	B		
053.210	341	2573		POP	H		
053.211	311	2574		RET			
		2576	**	CUS		COMPUTE UNUSED SPACE.	
		2577	*				
		2578	*	CUS		COMPUTES THE FREE SPACE LEFT TO THE ASSEMBLER.	
		2579	*				
		2580	*			IF NOT ENOUGH IS FREE TO CONTINUE, CUS RETURNS A NEGATIVE VALUE.	
		2581	*				
		2582	*	ENTRY	NONE		
		2583	*	EXIT	(HL) = BYTES FREE		
		2584	*		'C' SET IF NOT ENOUGH TO CONTINUE		
		2585	*	USES	A, E, H, L		
		2586					
		2587					
053.212	325	2588	CUS	PUSH	D		
053.213	052 220 067	2589		LHLD	SYMFTR		
053.216	353	2590		XCHG			
053.217	052 224 067	2591		LHLD	RELPTR		
053.222	175	2592		MOV	A, L		
053.223	223	2593		SUB	E		
053.224	157	2594		MOV	L, A		
053.225	174	2595		MOV	A, H		
053.226	232	2596		SBB	D		
053.227	147	2597		MOV	H, A	COMPUTE DIFFERENCE	
053.230	321	2598		POP	D	RESTORE (DE)	
053.231	311	2599		RET			


```

2601 **      DHD - DECODE HEX DIGIT.
2602 *
2603 *      DHD DECODES AN ASCII CHARACTER INTO A 4 BIT VALUE.
2604 *
2605 *      ENTRY  (A) = CHARACTER
2606 *      EXIT   (A) = VALUE
2607 *      'C' SET IF ERROR
2608 *      USES   A,F
2609
2610
053.232 326 060 2611 DHD   SUI   '0'
053.234 330      2612      RC
053.235 376 012 2613      CPI   10      ERROR
053.237 332 253 053 2614      JC    DHD1      IS 0-9
053.242 326 021 2615      SUI   'A'-'0'
053.244 330      2616      RC
053.245 376 006 2617      CPI   6      ERROR
053.247 077      2618      CMC
053.250 330      2619      RC      NOT A-F
053.251 306 012 2620
053.253 247      2621 DHD1  ANA   A      CLEAR CARRY
053.254 311      2622      RET     EXIT WITH VALUE

2624 **      DEF - DEFINE SYMBOL.
2625 *
2626 *      DEF IS CALLED TO DEFINE THE SYMBOL IN *SYMBOL*.
2627 *      THE SYMBOL IS DEFINED ABSOLUTE OR RELOCATABLE, ACCORDING TO
2628 *      (EXPREL)
2629 *
2630 *      ENTRY  (D) = NEW SYMBOL TYPE
2631 *      (E) = OLD TYPE. IF SYMBOL IS PRESET, AND ITS TYPE
2632 *      IS NOT STANDARD OR (E), FLAG 'D' ERROR.
2633 *      (BC) = VALUE
2634 *      LABEL = LINE LABEL
2635 *      EXIT  TO RET
2636 *      USES  A,F,D,E,H,L
2637
053.255 072 056 070 2638 DEF   LDA   LABEL
053.260 247      2639      ANA   A
053.261 302 271 053 2641      JNZ  DEFO   IF LABEL EXISTS
053.264 315 003 057 2642      CALL DEF   MUST HAVE LABEL
053.267 040      2643      DB   ERR.F  ** ERROR
053.270 311      2644      RET
2645
053.271 072 353 067 2646 DEF0  LDA   EXPREL
053.274 262      2647      ORA   D      SET RELOCATION FLAG, IF RELOCATABLE
053.275 127      2648      MOV  D,A
053.276 325      2649      PUSH D
053.277 021 056 070 2650      LXI  D,LABEL
053.302 315 016 057 2651      CALL SST   SEARCH SYMBOL TABLE
053.305 321      2652      POP  D
053.306 176      2653      MOV  A,M      (A) = SYMBOL TYPE
  
```

053.307	247		2654	ANA	A	
000.000			2655	ERRNZ	ST.UND	CODE ASSUMES = 0
053.310	312 327 053		2656	JZ	DEF1	UNDEFINED
053.313	273		2657	CMF	E	
053.314	312 327 053		2658	JE	DEF1	IS PROPER OLD TYPE
053.317	366 200		2659	ORI	ST.DBL	
053.321	167		2660	MOV	M,A	FLAG DOUBLE DEFINITION
053.322	315 003 057		2661	CALL	SEF	
053.325	004		2662	DB	ERR.D	*D* ERROR
053.326	311		2663	RET		DONT RE-DEFINE
			2664			
053.327	162		2665	DEF1 MOV	M,B	SET TYPE
053.330	043		2666	INX	H	
053.331	161		2667	MOV	M,C	
053.332	043		2668	INX	H	
053.333	160		2669	MOV	M,B	SET VALUE
053.334	311		2670	RET		

2672 ** DLH - DEFINE LABEL HERE.
 2673 *
 2674 * DLH IS CALLED TO DEFINE A LABEL (IF ONE EXISTS) AT THE
 2675 * CURRENT ORG.
 2676 *
 2677 * ENTRY (LABEL) = LABEL STRING
 2678 * EXIT (HL) = ORG VALUE
 2679 * 'D' SET ON LABEL IF DOUBLY DEFINED
 2680 * USES ALL
 2681

			2682			
053.335	072 056 070		2683	DLH LDA	LABEL	
053.340	247		2684	ANA	A	
053.341	310		2685	RZ		NO LABEL EXISTS
053.342	072 122 067		2686	LDA	PASS	
053.345	075		2687	DCR	A	
053.346	300		2688	RMZ		RETURN IF PASS <> 1
053.347	052 134 067		2689	LHLD	ORG	(HL) = LABEL'S VALUE
053.352	021 000 001		2690	LXI	D,ST.LAB*256+0	
053.355	072 145 067		2691	LDA	RELFLG	
053.360	062 353 067		2692	STA	EXPREL	DEFINE SYMBOL REL IF GENERATING REL CODE
053.363	104		2693	MOV	B,H	
053.364	115		2694	MOV	C,L	(BC) = VALUE
053.365	303 255 053		2695	JMP	DEF	DEFINE SYMBOL HERE

2697 ** DLL - DISPLAY LISTING LINE.
 2698 *
 2699 * DLL TYPES THE LISTING LINE IF THE 'L' LIST OPTION IS SET,
 2700 * OR IF AN ERROR IS PRESENT.
 2701 *
 2702 * ENTRY NONE
 2703 * EXIT NONE

```

2704 *      USES      ALL
2705
2706
053.370 072 122 067 2707 DLL   LDA   PASS
053.373 037       2708   RAR
053.374 330       2709   RC      DO NOTHING PASS 1
2710
2711 *      SET XTEXT FLAG
2712
053.375 072 143 067 2713   LDA   XTXLINE      /80.02.GC/
054.000 247       2714   ANA   A      /80.02.GC/
054.001 312 011 054 2715   JZ    DLLO      IS NOT CURRENTLY AN *XTEXT* /80.02.GC/
2716
054.004 076 130     2717   MVI   A,X'      /80.02.GC/
054.006 062 113 067 2718   STA   DSPLNE     FLAG THE XTEXT      /80.02.GC/
2719
054.011 072 140 067 2720 DLLO  LDA   ERRFLG
054.014 107       2721   MOV   B,A
054.015 247       2722   ANA   A
054.016 302 030 054 2723   JNZ   DLL1      HAVE ERROR
054.021 315 041 053 2724   CALL  CLE      CHECK LISTING ELIGIBILITY
054.024 310       2725   RZ          NOT IN LIST
054.025 303 130 054 2726   JMF   DLL3      DONT TRY TO INSERT ERROR MESSAGES
2727
2728 *      GENERATE ERROR CHARACTERS FOR FLAGGED ERRORS.
2729
054.030 315 003 061 2730 DLLO  CALL  %CCO      CLEAR CONTROL-O
054.033 016 003     2731   MVI   C,3      (C) = MAX NUMBER OF ERROR MESSAGES
054.035 052 123 067 2732   LHLB  ERRCNT
054.040 043       2733   INX   H
054.041 042 123 067 2734   SHLB  ERRCNT      COUNT LINES IN ERROR
054.044 041 056 067 2735   LXI   H,DSPLIN
054.047 021 203 054 2736   LXI   D,DLLB-1      (DE) = TABLE POINTER
2737
054.052 023       2738 DLLO  INX   D      LOOK UP ERROR CHARACTERS
054.053 032       2739   LDAX D
054.054 023       2740   INX   D
054.055 247       2741   ANA   A
054.056 312 074 054 2742   JZ    DLL2.5     ALL MESSAGES TYPED
054.061 240       2743   ANA   B
054.062 312 052 054 2744   JZ    DLL2      NO ERROR OF THIS TYPE
054.065 032       2745   LDAX D      (A) = CHARACTER
054.066 167       2746   MOV   M,A      STORE IN LINE
054.067 043       2747   INX   H
054.070 015       2748   DCR   C
054.071 302 052 054 2749   JNZ   DLL2      MAKE ROOM FOR ERRORS
2750
2751 *      HAVE JUST FORMATTED ERROR LINE. SEE IF TO GO TO CONSOLE
2752
054.074 072 227 067 2753 DLLO  LDA   LISTFB+FB.FLG
054.077 247       2754   ANA   A
054.100 312 112 054 2755   JZ    DLL2.7     SEND TO CONSOLE, FOR SURE
054.103 072 125 067 2756   LDA   ERRSHO
054.106 247       2757   ANA   A
054.107 312 130 054 2758   JZ    DLL3      JUST WRITE TO FILE
2759

```

```

2760 *      TYPE LINE (WITH ERROR) ON CONSOLE
2761
054.112 041 056 067 2762 DLL2.7 LXI  H,DSPLIN
054.115 377 003      2763 DB      SYSCALL, .PRINT PRINT HEADER
054.117 041 237 075 2764 LXI  H,LINE
054.122 315 051 061 2765 CALL  $TYPLZ TYPE LINE TO 00
054.125 315 226 061 2766 CALL  $CRLF END OF LINE AFTER IT
2767
2768 *      TYPE OUT LISTING LINE.
2769
054.130      2770 DLL3 EQU  *
054.130 315 100 053 2771 CALL  COL COUNT OUTPUT LINE
054.133 041 237 075 2772 LXI  H,LINE
054.136 315 342 060 2773 CALL  $DTB DELETE TRAILING BLANKS
054.141 075      2774 DCR  A
054.142 312 167 054 2775 JZ    DLL4 NO LINE TO LIST, MAYBE JUST HEADER
2776
2777 *      PRINT LINE HEADER AND BODY
2778
054.145 001 040 000 2779 LXI  B,DSPLIN
054.150 021 056 067 2780 LXI  D,DSPLIN
054.153 041 226 067 2781 LXI  H,LISTFB
054.156 315 047 063 2782 CALL  $FWRIB WRITE LINE
054.161 021 237 075 2783 LXI  D,LINE
054.164 303 002 063 2784 JMP  $FWRIL WRITE LINE AND RETURN
2785
2786 *      HAVE NO LINE BODY. SEND JUST HEADER
2787
054.167 041 056 067 2788 DLL4 LXI  H,DSPLIN
054.172 315 342 060 2789 CALL  $DTB DELETE TRAILING BLANKS
054.175 353      2790 XCHG
054.176 041 226 067 2791 LXI  H,LISTFB
054.201 303 002 063 2792 JMP  $FWRIL WRITE LINE AND RETURN
2793
054.204      2794 DLLB EQU  *
054.204 001 125      2795 DB  ERR,U, 'U'
054.206 002 122      2796 DB  ERR,R, 'R'
054.210 004 104      2797 DB  ERR,D, 'D'
054.212 010 101      2798 DB  ERR,A, 'A'
054.214 020 126      2799 DB  ERR,V, 'V'
054.216 040 106      2800 DB  ERR,F, 'F'
054.220 100 117      2801 DB  ERR,O, 'O'
054.222 200 120      2802 DB  ERR,P, 'P'
054.224 000      2803 DB  0

```

```

2805 **     DRS - DECODE REGISTER SPECIFICATION
2806 *
2807 *     DRS DECODES A REGISTER SPECIFICATION.
2808 *
2809 *     CALL  DRS
2810 *     DB  CODE
2811 *
2812 *     CODE =

```

DRS

```

2813 *      1      2      3
2814 *      B 0      B 1      B 00
2815 *      C 1      D 3      D 20
2816 *      D 2      H 5      H 40
2817 *      E 3      S 7      P 60
2818 *      H 4
2819 *      L 5
2820 *      M 6
2821 *      A 7
2822 *
2823 *      ENTRY (DE) = OPERAND POINTER
2824 *      EXIT (DE) UPDATED
2825 *      (A) = REGISTER INDEX
2826 *      ERR.R SET IF ERROR
2827 *      USES A,F,D,E
2828
2829
2830 DRS     XHLL (HL) = ADDRESS OF CODE
054,225 343 2831 MOV A,M (A) = INDEX
054,226 176 2832 INX H
054,227 043 2833 XTHL
054,230 343 2834 PUSH H SAVE (HL)
054,231 345 2835 MVI H,DRSA/256
054,232 046 054 2836 MOV L,A
054,234 157 2837 LDAX D
054,235 032 2838 INX D
054,236 023 2839 CALL $TBL5
054,237 315 261 061 2840 MOV A,M (A) = REGISTER SPECIFICATION
054,242 176 2841 POP H
054,243 341 2842 RAR
054,244 037 2843 JNZ DRS3 NO GOOD
054,245 302 270 054 2844
2845 *      HAVE VALID REGISTER, DISCARD EXTRA CHARACTERS
2846
054,250 365 2847 PUSH PSW SAVE REGISTER CODE
054,251 033 2848 DCX D
054,252 023 2849 DRS1 INX D
054,253 032 2850 LDAX D
054,254 376 101 2851 CPI 'A'
054,256 332 266 054 2852 JC DRS2 NOT ALPHA
054,261 376 133 2853 CPI 'Z'+1
054,263 332 252 054 2854 JC DRS1 IS ALPHA
054,266 361 2855 DRS2 POP PSW (A) = CODE
054,267 311 2856 RET
2857
2858 *      ILLEGAL REGISTER SPECIFICATION
2859
054,270 315 003 057 2860 DRS3 CALL SEF
054,273 002 2861 UB ERR.R *** ERROR
054,274 257 2862 XRA A
054,275 311 2863 RET

2865 **     REGISTER VALUE TABLES.
2866
054,276 2867 DRS4 EQU *     GROUP 1
  
```

```

054.276 101 017 2868 DB 'A',7*2+1
054.300 102 001 2869 DB 'B',0*2+1
054.302 103 003 2870 DB 'C',1*2+1
054.304 104 005 2871 DB 'D',2*2+1
054.306 105 007 2872 DB 'E',3*2+1
054.310 110 011 2873 DB 'H',4*2+1
054.312 114 013 2874 DB 'L',5*2+1
054.314 115 015 2875 DB 'M',6*2+1
054.316 000 2876 DB 0
2877
054.317 2878 DRSE EQU * GROUP 2
054.317 102 003 2879 DB 'B',1*2+1
054.321 104 007 2880 DB 'D',3*2+1
054.323 110 013 2881 DB 'H',5*2+1
054.325 123 017 2882 DB 'S',7*2+1
054.327 000 2883 DB 0
2884
054.330 2885 DRSC EQU * GROUP 3
054.330 102 001 2886 DB 'B',000*2+1
054.332 104 041 2887 DB 'D',200*2+1
054.334 110 101 2888 DB 'H',400*2+1
054.336 120 141 2889 DB 'P',600*2+1
054.340 000 2890 DB 0

000.054 2892 .B SET DRSC/256
000.000 2893 ERRNZ DRSA/256-.B

2895 ** EBB - EVALUATE 8 BIT EXPRESSION
2896 *
2897 * EBB IS CALLED TO EVALUATE AN EXPRESSION AND TO INSURE THAT
2898 * IS EVALUATES TO 8 BITS OR LESS. IF NOT, THE ** ERROR
2899 * IS FLAGGED.
2900 *
2901 * ENTRY (DE) = OPERAND POINTER
2902 * EXIT (C) = VALUE
2903 * (DE) UPDATED
2904 * USES A,B,C,D,E,F
2905
2906
054.341 315 215 051 2907 EBB CALL EVL EVALUATE EXPRESSION
054.344 072 353 067 2908 LDA EXPREL
054.347 247 2909 ANA A
054.350 304 365 054 2910 CNZ EBB1 RELOCATION ERROR
054.353 170 2911 MOV A,B
054.354 247 2912 ANA A
054.355 310 2913 RZ IF 0
054.356 074 2914 INR A
054.357 310 2915 RZ IF -0
054.360 315 003 057 2916 CALL SEF ** ERROR
054.363 020 2917 DB ERR.V
054.364 311 2918 RET
2919

```

```

2920 *      RELOCATION ERROR
2921
054.365 315 003 057 2922 EBB1 CALL SEF
054.370 002          2923 DB   ERR.R      FLAG ERROR
054.371 311          2924 RET

2926 **     EPO - EVALUATE FOR PASS 1.
2927 *
2928 *      EPO IS CALLED WHEN AN EVALUATION IS REQUIRED DURING PASS 1.
2929 *
2930 *      IF PASS = 1, EVALUATE THE EXPRESSION. IF IT CONTAINS UNDEFINED
2931 *      SYMBOLS, DEFINE A SYMBOL NNNNNN, WHERE NNNNNN = THE
2932 *      STATEMENT NUMBER (IN OCTAL).
2933 *
2934 *      IF PASS = 2, SEE IF NNNNNN IS DEFINED. IF SO, WAS AN ERROR
2935 *      PASS 1, FLAG 'U' THIS PASS.
2936 *
2937 *      ENTRY (DE) = EXPRESSION POINTER
2938 *      EXIT  (DE) UPDATED
2939 *      (BC) = VALUE
2940 *      'Z' SET IF NO ERROR
2941 *      USES  A,B,C,D,E,F
2942
2943
054.372 345          2944 EPO  PUSH  H
054.373 072 127 067 2945 LDA  STATNO+1
054.376 041 075 055 2946 LXI  H,EPOA
055.001 315 234 061 2947 CALL $UOD      UNPACK OCTAL DIGITS
055.004 072 126 067 2948 LDA  STATNO
055.007 315 234 061 2949 CALL $UOD      UNPACK OCTAL DIGITS
055.012 315 215 051 2950 CALL EVL      EVALUATE EXPRESSION
055.015 072 122 067 2951 LDA  PASS
055.020 017          2952 RRC
055.021 322 045 055 2953 JNC  EPO2     PASS = 2
2954
2955 *      PASS = 1
2956
055.024 072 140 067 2957 LDA  ERRFLG
000.000          2958 ERRNZ ERR.U-1   COSE ASSUMES = 1
055.027 037          2959 RAR
055.030 322 067 055 2960 JNC  EPO4     OK
2961
2962 *      HAVE 'U' ERROR, DEFINE NNNNNN
2963
055.033 325          2964 PUSH  D
055.034 021 075 055 2965 LXI  D,EPOA   (DE) = ADDRESS OF SYMBOL
055.037 315 016 057 2966 CALL  SST     SEARCH SYMBOL TABLE
055.042 303 066 055 2967 JMP  EPO3     RETURN WITH ERROR
2968
2969 *      PASS = 2
2970
055.045 325          2971 EPO2 PUSH  D
055.046 021 075 055 2972 LXI  D,EPOA

```

```

055.051 052 216 067 2973      LHL  SYMFWA
055.054 315 306 055 2974      CALL LVT.          LOCATE VALUE IN TABLE
055.057 322 066 055 2975      JNC  EPO3         NOT FOUND, OK
055.062 315 003 057 2976      CALL  SEF        *X* AND *A* ERRORS
055.065 011          2977      DB    ERR.U+ERR.A
055.066 321          2978      POP  D
055.067 341          2979      POP  H
055.070 072 140 067 2980      LDA  ERRFLG
055.073 247          2981      ANA  A          SET ERROR CODE
055.074 311          2982      RET          RETURN
                2983
055.075 060 060 060 2984      EPOA DB    '000000','X'+80H

                2986 **      FNP - FORCE NEW PAGE.
                2987 *
                2988 *      FNP CAUSES A PAGE EJECT, BY FORMFEED OR BY LINE FEED,
                2989 *      WHICHEVER IS REQUIRED.
                2990 *
                2991 *      ENTRY  NONE
                2992 *      EXIT  NONE
                2993 *      USES  ALL
                2994
                2995
055.104 072 215 067 2996      FNP  LDA  FORMDP
055.107 247          2997      ANA  A
055.110 302 132 055 2998      JNZ  FNP1         MUST LINE FEED
                2999
                3000 *      DEVICE WILL TAKE A FORM FEED
                3001
055.113 001 001 000 3002      LXI  B,1
055.114 021 200 055 3003      LXI  D,FNPA
055.121 041 226 067 3004      LXI  H,LISTFB
055.124 315 047 063 3005      CALL $FWRIB      WRITE
055.127 303 167 055 3006      JMP  FNP3         ADJUST LINE COUNT
                3007
                3008 *      MUST USE CRLF'S TO GET THERE
                3009
055.132 041 214 067 3010      FNP1 LXI  H,PAGEDP
055.135 226          3011      SUB  M          (A) = .GAP SPACE
055.136 041 351 067 3012      LXI  H,LINCNT
055.141 204          3013      ADD  M          (A) = AMOUNT NEEDED
055.142 312 167 055 3014      JZ   FNP3         IF NO LINES (IS THE CASE AT START OF ASSEMBLY)
055.145 001 001 000 3015      FNP2 LXI  B,1          (BC) = COUNT
055.150 021 201 055 3016      LXI  D,FNPR
055.153 041 226 067 3017      LXI  H,LISTFB
055.156 365          3018      PUSH PSW        SAVE COUNT
055.157 315 047 063 3019      CALL $FWRIB      WRITE BYTE
055.162 361          3020      POP  PSW
055.163 075          3021      DCR  A
055.164 302 145 055 3022      JNZ  FNP2         GO SOME MORE
                3023
                3024 *      ADJUST PAGE LINE COUNT
                3025

```



```

055.167 072 214 067 3026 FNP3 LDA PAGEDF
055.172 326 003 3027 SUI 3 (A) = SPACES ON PAGE -HEADING SIZE
055.174 062 351 067 3028 STA LINCNT SET LINES REMAINING
055.177 311 3029 RET DONE
3030
055.200 014 3031 FNFA DB FF FORM FEED
055.201 012 3032 FNFB DB NL NEW LINE

3034 ** GRT - GENERATE RELOCATION TABLE.
3035 *
3036 * GRT IS CALLED AT THE EEND OF PASS 2 TO GENERATE
3037 * ANY RELOCATION TABLES NEEDED.
3038 *
3039 * ENTRY NONE
3040 * EXIT NONE
3041 * USES ALL
3042
3043
055.202 072 144 067 3044 GRT LDA FTFLAG
000.000 3045 ERRNZ FT.PIC-1
055.205 075 3046 DCR A
055.206 300 3047 RNZ NOT PIC
055.207 052 224 067 3048 LHLD RELPTR
055.212 353 3049 XCHG
055.213 052 222 067 3050 LHLD RELLWA (DE) = LOW TABLE ADDR, (HL) = HIGH TABLE ADDR
3051
055.216 315 216 030 3052 GRT1 CALL $CDEHL
055.221 312 242 055 3053 JE GRT2 ALL DONE
3054
3055 * WRITE ELEMENT TO BINARY
3056
055.224 053 3057 DCX H
055.225 106 3058 MOV B,M
055.226 053 3059 DCX H
055.227 176 3060 MOV A,M
055.230 315 351 055 3061 CALL OBB OUTPUT
055.233 170 3062 MOV A,B
055.234 315 351 055 3063 CALL OBB OUTPUT 2ND HALF
055.237 303 216 055 3064 JMP GRT1 SEE IF MORE
3065
055.242 257 3066 GRT2 XRA A
055.243 315 351 055 3067 CALL OBB FINISH TABLE
055.246 257 3068 XRA A
055.247 303 351 055 3069 JMP OBB WRITE 2ND 00 AND EXIT
  
```

```

3071 **      GSC - GET STRING CHARACTER
3072 *
3073 *      GSC READS A CHARACTER FROM A QUOTED STRING IN THE SOURCE LINE.
3074 *
3075 *      A DOUBLE QUOTE (``) IS TAKEN AS ONE QUOTE CHARACTER.
3076 *
3077 *      ENTRY (DE) = POINTER TO NEXT CHARACTER
3078 *      EXIT (DE) UPDATED
3079 *      (A) = CHARACTER
3080 *      'Z' SET IF END OF STRING
3081 *      USES A,F,D,E
3082
3083
055.252 032 3084 GSC LDAX D (A) = NEXT LINE CHARACTER
055.253 023 3085 INX D
055.254 247 3086 ANA A SEE IF END OF LINE
055.255 312 276 055 3087 JZ GSC4 GONE PAST END
055.260 376 047 3088 CPI QUOTE
055.262 300 3089 RNE NOT END QUOTE
3090
3091 *      HAVE END-QUOTE
3092
055.263 032 3093 LDAX D
055.264 376 047 3094 CPI QUOTE
055.266 302 274 055 3095 JNE GSC3 NOT DOUBLE QUOTE, IS END QUOTE
055.271 023 3096 INX D
055.272 267 3097 ORA A CLEAR 'Z'
055.273 311 3098 RET RETURN WITH QUOTE
3099
055.274 257 3100 GSC3 XNA A SET 'Z'
055.275 311 3101 RET
3102
3103 *      GONE PAST END OF LINE WITHOUT TRAILING QUOTE
3104
055.276 315 003 057 3105 GSC4 CALL SEF
055.301 010 3106 DB ERR.A
055.302 033 3107 DCX I
055.303 033 3108 DCX D
055.304 257 3109 XRA A FLAG END OF STRING
055.305 311 3110 RET

```

```

3112 **      LVT - LOCATE VALUE IN TABLE.
3113 *
3114 *      LVT LOOKS UP A VALUE IN A TABLE.
3115 *
3116 *      ENTRY (HL) = TBL ADDRESS
3117 *      (DE) = VALUE ADDRESS
3118 *      (A) = NOP IF 2 DATA BYTES PER ENTRY, = INX H INSTRUCTION
3119 *      IF 3 DATA BYTES PER ENTRY.
3120 *      EXIT 'C' SET IF FOUND
3121 *      (HL) = ADDRESS
3122 *      'C' CLEAR IF NOT FOUND
3123 *      (HL) = ADDRESS OF NEXT EMPTY

```

```

3124 *      USES      A,F,H,L
3125
3126
055.306 076 043 3127 LVT.  MVI      A,MI,INXH  SYMTAB SEARCH ENTRY POINT
3128
055.310 3129 LVT      EQU      *
055.310 062 344 055 3130      STA      LUTA  SET INX OR NOP INSTRUCTION
055.313 176 3131 LVT0     MOV      A,M  (A) = TABLE FIRST ENTRY
055.314 247 3132      ANA      A
055.315 310 3133      RZ
055.316 325 3134      PUSH     D  TABLE EXHAUSTED
3135      SAVE (DE)
3136 *
3137      COMPARE ENTRY
3138 LVT1     LDAX     D  COMPARE CHARACTERS
3139      CMP      M
055.320 276 3140      JNE      LVT2  NO MATCH
055.321 302 334 055 3141      INX      D
055.324 023 3142      INX      H
055.325 043 3143      RAL
055.326 027 3144      JNC      LVT1  MORE TO CHECK
055.327 322 317 055 3145      POP      D
055.332 321 3146      RET
055.333 311 3147      FOUND ENTRY
3148
3149 *      NOT FOUND
3150
055.334 176 3151 LVT2     MOV      A,M
055.335 043 3152      INX      H
055.336 247 3153      ANA      A
055.337 362 334 055 3154      JP       LVT2  NOT AT END OF ENTRY
055.342 043 3155      INX      H
055.343 043 3156      INX      H
055.344 043 3157 LVT3     INX      H
055.345 321 3158      POP      D
055.346 303 313 055 3159      JMP      LVT0  LOOK AGAIN

```

```

3161 **      ORB - OUTPUT BINARY BYTE.
3162 *
3163 *      ORB IS CALLED TO OUTPUT A BINARY BYTE.
3164 *      THE BYTE IS ADDED TO THE BINARY FILE, AND IS ADDED TO THE
3165 *      LISTING (IF APPROPRIATE).
3166 *      ORG IS INCREMENTED.
3167 *
3168 *      * * NOTE * *   EVERYBODY WHO GENERATES ANY BINARY
3169 *      INFORMATION MUST DO IT VIA A CALL TO ORB! THE ONLY EXCEPTION
3170 *      IS THE TWO BYTES BACK-GENERATED INTO THE PIC HEADERS
3171 *      BY THE MAIN LOOP; ORB CALLS A&V, AND A&V (DURING PASS 1) KEEPS
3172 *      TRACK OF THE RANGE OF BINARY GENERATED.
3173 *
3174 *      IF PASS = 1, DO NOTHING
3175 *
3176 *      ENTRY (A) = VALUE

```

```

3177 *   EXIT   NONE
3178 *   USES   A,F
3179
3180
055.351 345 3181 OBB   PUSH   H
055.352 052 134 067 3182   LHLD  ORG
055.355 043 3183   INX   H
055.356 042 134 067 3184   SHLD  ORG
055.361 062 031 056 3185   STA  ORBA   SAVE VALUE
055.364 072 122 067 3186   LDA  PASS
055.367 017 3187   RRC
055.370 332 041 056 3188   JC   OBB3   PASS = 1
055.373 052 120 067 3189 OBB1  LHLD  ORBPTR
055.376 076 106 3190   MVI  A,#DSPLIM  COMPARE TO LIMIT
056.000 275 3191   CMP  L
056.001 302 030 056 3192   JNE  OBB2*   NOT 3 VALUES YET
3193
3194 *   LINE IS FULL. IF *G* SET, PRINT AND ADD ENTRY
3195
056.004 072 130 067 3196   LDA  LSTCTL
000.000 3197   ERRNZ LST.G-2000  CODE ASSUMES = 2000
056.007 027 3198   RAL
056.010 322 041 056 3199   JNC  OBB3   *G* CLEAR
056.013 325 3200   PUSH  D
056.014 305 3201   PUSH  B   PRESERVE REGISTERS
056.015 315 370 053 3202   CALL  DLL  DISPLAY LISTING LINE
056.020 315 275 056 3203   CALL  PDL  PREPARE DISPLAY LINE
056.023 301 3204   POP  B   RESTORE REGISTERS
056.024 321 3205   POP  D
056.025 303 373 055 3206   JMP  ORB1
3207
3208 *   ADD TO LINE
3209
056.030 076 000 3210 OBB2  MVI  A,0
056.031 3211 OBB2  EQU  *-1  VALUE STORED HERE
056.032 315 234 061 3212   CALL  $UGD  UNPACK OCTAL DIGITS
056.035 043 3213   INX   H
056.036 042 120 067 3214   SHLD  ORBPTR  SET NEW POINTER VALUE
056.041 072 031 056 3215 OBB3  LDA  ORBA  (A) = VALUE
056.044 315 070 052 3216   CALL  ABV  ADD BINARY VALUE
056.047 341 3217   POP  H
056.050 311 3218   RET

```

```

3220 **   PAS - PRINT ASSEMBLY STATISTICS.
3221 *
3222 *   PAS PRINTS THE FINAL ASSEMBLY STATISTICS.
3223 *
3224 *   STATEMENTS = NNN
3225 *   NO ERRORS DETECTED [OR]
3226 *   ERRORS = NN
3227 *
3228 *   ENTRY  ERRCNT = # OF ERRORS
3229 *   LINCNT = # OF LINES

```

				3230	*	EXIT	NONE	
				3231	*	USES	ALL	
				3232				
				3233				
056.051	052	126	067	3234	FAS	LHLD	STATNO	
056.054	104			3235		MOV	B,H	
056.055	115			3236		MOV	C,L	
056.056	041	165	056	3237		LXI	H,PASR	
056.061	076	005		3238		MOI	A,S	
056.063	315	157	031	3239		CALL	\$UDD	UNPACK STATEMENT COUNT
056.066	315	212	053	3240		CALL	CUS	COMPUTE UNUSED SPACE
056.071	104			3241		MOV	B,H	
056.072	115			3242		MOV	C,L	(BC) = COUNT
056.073	322	101	056	3243		JNC	PAS0	NOT ALL USED UP
056.076	001	000	000	3244		LXI	B,0	ALL USED UP
056.101	041	220	056	3245	PAS0	LXI	H,PAS0	
056.104	076	005		3246		MOI	A,S	
056.106	315	157	031	3247		CALL	\$UDD	UNPACK FREE BYTES COUNT
056.111	052	123	067	3248		LHLD	ERRCNT	
056.114	104			3249		MOV	B,H	
056.115	115			3250		MOV	C,L	(DE) = ERROR COUNT
056.116	041	241	056	3251		LXI	H,PASD	
056.121	076	005		3252		MOI	A,S	
056.123	305			3253		PUSH	B	SAVE COUNT
056.124	315	157	031	3254		CALL	\$UDD	UNPACK COUNT
056.127	301			3255		POP	B	
056.130	170			3256		MOV	A,B	
056.131	261			3257		ORA	C	
056.132	302	146	056	3258		JNZ	PAS2	HAVE ERROR COUNT
056.135	315	141	061	3259		CALL	\$MOVEL	
056.140	005	000	270	3260		DM	S,PAS0,PASD	USE 'NO' IN PLACE OF COUNT
056.146	001	104	000	3261	PAS2	LXI	B,PASAL	
056.151	021	163	056	3262		LXI	D,PASA	
056.154	041	226	067	3263		LXI	H,LISTFB	
056.157	315	047	063	3264		CALL	\$FWRIB	WRITE TO LISTING FILE
056.162	311			3265		RET		EXIT
				3266				
056.163	012	012		3267	PASA	DB	NL,NL	
056.165	060	060	060	3268	PASE	DB	'00000 Statements Assembled',NL	
056.220	060	060	060	3269	PASC	DB	'00000 Bytes Free',NL	
056.241	060	060	060	3270	PASD	DB	'00000 Errors Detected',NL	
000.104				3271	PASAL	EDU	*-PASA	
056.267	212			3272		DB	ENL	END FOR 'PRINT' STATEMENT
056.270	040	116	157	3273	PASE	DB	' No',0,0	

				3275	**	PDL	- PREPARE DISPLAY LINE	
				3276	*			
				3277	*	PDL	PRESETS THE DISPLAY LINE BY BLANKING IT OUT.	
				3278	*			
				3279	*	ENTRY	NONE	
				3280	*	EXIT	LSTLIN = BLANKS	
				3281	*	USES	A,F,R,L	
				3282				

```

3283
056.275 041 056 067 3284 PDL LXI H,DSPLIN
056.300 076 040 3285 MVI A,DSPLEN
056.302 066 040 3286 PDL1 MVI M,
056.304 043 3287 INX H
056.305 075 3288 DCR A
056.306 302 302 056 3289 JNZ PDL1
056.311 042 237 075 3290 STA LINE ZERO LINE
056.314 041 072 067 3291 LXI H,DSPLNB
056.317 042 120 067 3292 SHLD 0BBPTR SET NEW POINTER VALUE
056.322 311 3293 RET

```

```

3295 ** RRI - RECORD RELOCATION INFORMATION.
3296 *
3297 * RRI IS CALLED WHEN AN BINARY ADDRESS VALUE IS
3298 * ABOUT TO BE PRODUCED. IF IT IS RELOCATABLE (EXPREL M<> 0)
3299 * THEN ITS ADDRESS IS ENTERED IN THE RELOCATION TABLE.
3300 *

```

```

3301 * ENTRY DRG = DRG FOR VALUEE
3302 * EXPREL < 0 IF RELOCATABLE
3303 * EXIT NONE
3304 * USES A,F
3305
3306

```

```

056.323 072 353 067 3307 RRI LDA EXPREL
056.326 247 3308 ANA A
056.327 310 3309 RZ NOT RELOCATABLE
056.330 072 122 067 3310 LDA PASS
056.333 075 3311 DCR A
056.334 310 3312 RZ IS PASS 1
056.335 325 3313 PUSH D SAVE REGS
056.336 345 3314 PUSH H SAVE REGS
056.337 315 212 053 3315 CALL CUS COMPUTE UNUSED SPACE
056.342 332 036 057 3316 JC MEMOVR OVERFLOW
056.345 052 134 067 3317 LHLD DRG
056.350 353 3318 XCHG
056.351 052 224 067 3319 LHLD RELPTR
056.354 053 3320 DCX H ADD VALUE TO LIST
056.355 162 3321 MOV M,D
056.356 053 3322 DCX H
056.357 163 3323 MOV M,E
056.360 042 224 067 3324 SHLD RELPTR
056.363 341 3325 POP H
056.364 321 3326 POP D RESTORE REGS
056.365 311 3327 RET
3328
3329

```

```

3331 **      RSE - REWIND SOURCE FILE.
3332 *
3333 *      RSE IS CALLED TO REWIND THE INPUT SOURCE FILE.
3334 *
3335 *      ENTRY  RSFA = TEXT NAME
3336 *           RSFB = TEXT LENGTH
3337 *      EXIT  TAPE POSITIONED
3338 *      USES  ALL
3339 *
3340
056.366 001 000 000 3341 RSE  LXI  B,0
056.371 076 002     3342     MVI  A,CN,SOU
056.373 377 047     3343     DB   SYSCALL,,POSIT      REWIND SOURCE FILE
056.375 041 261 067 3344     LXI  H,SORCFK
057.000 303 157 062 3345     JMP  $FCLEAR      CLEAR FILE BLOCK AND EXIT

```

```

3347 **      SEF - SET ERROR FLAGS.
3348 *
3349 *      SEF SETS THE SPECIFIED ERROR IN *ERRFLG*, THEN RETURNS TO
3350 *      RET+1
3351 *
3352 *      CALL  SEF
3353 *      DB   ERRBIT
3354 *
3355 *      ENTRY  (RET) = ERROR
3356 *      EXIT  ERROR SET
3357 *           RETURN TO (RET)+1
3358 *      USES  A,F
3359 *
3360
057.003 343     3361 SEF  XTHL                (HL) = RETURN ADDRESS
057.004 072 140 067 3362     LDA  ERRFLG
057.007 266     3363     ORA  M
057.010 062 140 067 3364     STA  ERRFLG
057.013 043     3365     INX  H
057.014 343     3366     XTHL                ADVANCE EXIT
057.015 311     3367     RET                RETURN PAST CODE

```

```

3369 **      SST - SEARCH SYMBOL TABLE.
3370 *
3371 *      SST SCANS THE SYMTAB FOR A GIVEN ENTRY. IF FOUND, RETURN
3372 *      IF NOT FOUND, CREATE AS TYPE *UX*
3373 *
3374 *      ENTRY  (DE) = ADDRESS OF SYMBOL
3375 *      EXIT  (DE) UNCHANGED
3376 *           (HL) = ADDRESS OF START OF VALUE BYTES.
3377 *      USES  A,F,H,L
3378 *
3379
057.016 052 216 067 3380 SST  LHLD  SYMFMA

```

SST

057.021	315	306	055	3381	CALL	LVT.	LOCATE VALUE IN TABLE
057.024	330			3382	RC		FOUND IT
057.025	325			3383	PUSH	D	SAVE (DE)
				3384			
				3385	*		WILL CREATE NEW ENTRY. SEE IF TABLE OVERFLOW.
				3386			
057.026	345			3387	PUSH	H	
057.027	315	212	053	3388	CALL	CUS	COMPUTE UNUSED SPACE
057.032	341			3389	POP	H	
057.033	322	071	057	3390	JNC	SST1	OK
057.036	315	136	031	3391	MEMOVR CALL	\$TYPTX	
057.041	012	012	007	3392	DB	NL,NL,BELL,'Symb Overflow',NL,NL,BELL+2000	
057.066	303	072	046	3393	JMP	END.	FORCE END OF THIS PASS
				3394			
057.071	321			3395	SST1 POP	D	REFRESH (DE)
057.072	325			3396	PUSH	D	
				3397			
				3398	*		NOT FOUND. PUT IN TABLE, SET TYPE = ST,UND
				3399			
057.073	032			3400	SST2 LDAX	D	
057.074	167			3401	MOV	M,A	
057.075	023			3402	INX	D	
057.076	043			3403	INX	H	
057.077	007			3404	RLC		
057.100	322	073	057	3405	JNC	SST2	
057.103	345			3406	PUSH	H	
057.104	021	020	000	3407	LXI	D,16	
057.107	031			3408	DAD	B	
057.110	042	220	067	3409	SHLD	SYMPTR	SET SYMBOL TABLE LIMIT
057.113	341			3410	POP	H	
057.114	321			3411	POP	D	
057.115	311			3412	RET		SYMBOL CREATED IN TABLE
				3414	**		UOL - UNPACK ORG INTO LINE.
				3415	*		
				3416	*		UOL UNPACKS THE ORIGIN VALUE INTO THE LISTING LINE.
				3417	*		
				3418	*	ENTRY	NONE
				3419	*	EXIT	(HL) = SORG
				3420	*	USES	A,F,H,L
				3421			
				3422			
057.116	052	136	067	3423	UOL	LHLD	SORG
057.121	345			3424	UOL,	PUSH	H
057.122	325			3425		PUSH	D
057.123	353			3426		XCHG	(DE) = VALUE
057.124	041	061	067	3427	LXI	H,DSPLNA	
057.127	172			3428	MOV	A,D	
057.130	315	234	061	3429	CALL	\$UOD	UNPACK BANK
057.133	066	056		3430	MVI	M,' '	SET PERIOD BETWEEN BANKS
057.135	043			3431	INX	H	
057.136	173			3432	MOV	A,E	
057.137	315	234	061	3433	CALL	\$UOD	UNPACK ADDR


```

057.142 321      3434      POP    D
057.143 341      3435      POP    H
057.144 311      3436      RET

3438 **      UNL - UNPACK NEXT LINE.
3439 *
3440 *      UNL UNPACKS THE NEXT SOURCE LINE FROM THE TEXT BUFFER. IF THE
3441 *      IS NO MORE TEXT, AND *END* LINE IS GENERATED.
3442 *
3443 *      ENTRY  NONE
3444 *      EXIT   'Z' SET IF COMMENT
3445 *      USES   ALL
3446
057.145      3447
3448 UNL      EQU    *                /80.02.GC/
3449

057.145 052 126 067 3450      LHL    STATNO                /80.02.GC/
057.150 104      3451      MOV    B,H                    /80.02.GC/
057.151 115      3452      MOV    C,L                    /80.02.GC/
057.152 041 106 067 3453      LXI    H,DSPLND          HL = ADDRESS TO PAT AT /80.02.GC/
057.155 076 005 3454      MVI    A,S                A = DIGIT COUNT /80.02.GC/
057.157 315 157 031 3455      CALL   $UDD                OUTPUT THE LINE NUMBER /80.02.GC/
3456
057.162 001 144 000 3457      LXI    B,LINEMAX
057.165 021 237 075 3458      LXI    D,LINE
057.170 072 142 067 3459      LDA    TXFLG
057.173 062 143 067 3460      STA    TXLINE          TXLINE <= 0 IFF READING FROM XTEXT
057.176 247      3461      ANA    A
057.177 312 225 057 3462      JZ     UNL00            FROM MAIN SOURCE
057.202 041 314 067 3463      LXI    H,XTXFB
057.205 315 177 062 3464      CALL   $FREAL          READ LINE
057.210 322 250 057 3465      JNC    UNL0            GOT IT
3466
3467 *      EOF ON XTEXT FILE
3468
057.213 315 052 062 3469      CALL   $FCLO          CLOSE
057.216 257      3470      XRA    A
057.217 062 142 067 3471      STA    TXFLG
057.222 303 145 057 3472      JMP    UNL            TRY AGAIN
3473
057.225 041 261 067 3474 UNL00 LXI    H,SORCFB
057.230 315 177 062 3475      CALL   $FREAL          READ LINE
057.233 322 250 057 3476      JNC    UNL0            OK
3477
3478 *      EOF ON MAIN PROGRAM, FAKE AN END STATEMENT
3479
057.236 315 141 061 3480      CALL   $MOVEL
057.241 027 000 074 3481      DW    UNLAL,UNLA,LINE          USE END STATEMENT
057.247 353      3482      XCHG          (DE) = LINEE LWA
057.250 072 237 075 3483 UNL0  LDA    LINE
057.253 376 052 3484      CFI    '*'
057.255 310      3485      RE          IS COMMENT
057.256 041 237 075 3486      LXI    H,LINE          (HL) = LINE POINTER

```

UNL

```

3487
3488 * STRIP OFF LABEL.
3489
057.261 021 056 070 3490 LXI D,LABEL
057.264 006 011 3491 MVI B,B+1 8 CHARACTER MAX /80.02.GC/
057.266 315 015 060 3492 CALL UNL3 STRIP LABEL
057.271 032 3493 LDAX D CHECK FOR '?'
057.272 326 272 3494 SUI /'+2000
057.274 302 305 057 3495 JNZ UNL0.5 NOT I
057.277 022 3496 UNL0.3 STAX D CLEAR IT
057.300 033 3497 DCX D
057.301 032 3498 LDAX D
057.302 366 200 3499 ORI 2000
057.304 022 3500 STAX D
057.305 076 065 3501 UNL0.5 MVI A,#LABEL+7 FLAG LAST
057.307 223 3502 SUB E MAKE SURE 'AM NOW 7' OR LESS /80.02.GC/
057.310 302 323 057 3503 JNE UNL0.7 IS OK
057.313 315 003 057 3504 CALL SEF
057.316 040 3505 DB ERR.F
057.317 257 3506 XRA A
057.320 303 277 057 3507 JMP UNL0.3
3508
3509 * VERIFY LABEL STARTS WITH ALPHA /80.02.GC/
3510
057.323 021 056 070 3511 UNL0.7 LXI D,LABEL /80.02.GC/
057.326 032 3512 LDAX D /80.02.GC/
057.327 247 3513 ANA A /80.02.GC/
057.330 312 351 057 3514 JZ UNL0.9 NO LABEL DEFINED /80.02.GC/
057.333 346 177 3515 ANI 1770 STRIP OFF ANY *END* BIT /80.02.GC/
057.335 315 034 051 3516 CALL LCT, LOOK-UP CHARACTER TYPE /80.02.GC/
057.340 346 200 3517 ANI CT.ALPH /80.02.GC/
057.342 302 351 057 3518 JNZ UNL0.9 CHARACTER IS ALPHA /80.02.GC/
057.345 315 003 057 3519 CALL SEF /80.02.GC/
057.350 040 3520 DB ERR.F FLAG FORMAT ERROR /80.02.GC/
3521
3522 * STRIP OFF OPCODE.
3523
057.351 021 067 070 3524 UNL0.9 LXI D,OPCODE
057.354 006 006 3525 MVI B,B+1
057.356 315 015 060 3526 CALL UNL3
3527
3528 * COPY EXPRESSION TO WORKAREA.
3529
057.361 021 074 070 3530 LXI D,EXPWRK
057.364 176 3531 UNL1 MOV A,H
057.365 022 3532 STAX D
057.366 023 3533 INX D
057.367 043 3534 INX H
057.370 247 3535 ANA A
057.371 302 364 057 3536 JNZ UNL1 NOT AT END OF LINE
057.374 023 3537 INX D
057.375 022 3538 STAX D SET ZERO BYTE AT END
057.376 033 3539 DCX D
057.377 076 040 3540 MVI A, /
060.001 022 3541 STAX D GUARANTEE /',000 ENDING
3542

```

```

3543 *      SEE IF COMMENT.
3544 *
3545 *      IF NO LABEL OR OPCODE, IS COMMENT
3546
060.002 072 056 070 3547 UNL2.5 LDA LABEL
060.005 346 177 3548 ANI 1770
060.007 300 3549 RNZ NOT COMMENT
060.010 072 067 070 3550 LDA OPCODE
060.013 247 3551 ANA A
060.014 311 3552 RET

3554 **     UNL3 - PARSE LABEL OR OPCODE.
3555 *
3556 *      COPY A CHARACTER STRING FROM (HL) TO (DE)
3557 *      UNTIL TAB, SPACE, OR END OF LINE IS SEEN.
3558 *
3559 *      IF NONE COPIED, ZERO (DE)
3560 *      IF SOME COPIED, SET BOH ON LAST CHARACTER
3561 *
3562 *      ENTRY (B) = MAX CHARACTER COUNT
3563 *      EXIT (DE) = ADDRESS OF LAST CHARACTER
3564
060.015 176 3565 UNL3 MOV A,H
060.016 022 3567 STAX D
060.017 247 3568 ANA A
060.020 312 047 060 3569 JZ UNL5 IS END OF LINE
060.023 043 3570 INX H
060.024 376 040 3571 CPI ' '
060.026 312 047 060 3572 JE UNL5 IS SPACE
060.031 376 011 3573 CPI TAB
060.033 312 047 060 3574 JE UNL5 IS TAB
060.036 023 3575 INX D
060.037 005 3576 DCR B
060.040 302 015 060 3577 JNZ UNL3 MORE TO GO
3578
3579 *      TOO MANY CHARACTERS. FLAG AN ** ERROR
3580
060.043 315 003 057 3581 CALL SEF ** ERROR
060.046 040 3582 DB ERR.F
3583
3584 *      ITEM COPIED. SET SIGN BIT AND 0 NEXT BYTE
3585
060.047 257 3586 UNL5 XRA A
060.050 022 3587 STAX D CLEAR FIELD
060.051 033 3588 DCX D SET SIGN OVER LAST CHARACTER
060.052 032 3589 LDAX D
060.053 366 200 3590 ORI 80H
060.055 022 3591 STAX D
3592
3593 *      SKIP BLANKS AND TABS
3594
060.056 053 3595 DCX H

```

```

060.057 043          3596 UNL9  INX  H
060.060 176          3597 UNL10 MOV  A,M
060.061 376 040     3598      CFI  /
060.063 312 057 060 3599      JE   UNL9      IS BLANK
060.066 376 011     3600      CFI  TAB
060.070 312 057 060 3601      JE   UNL9      IS TAB
060.073 311          3602      RET  EXIT
                                3603
060.074 011 105 116 3604 UNLA  DB   /      END Statement Missing,0
000.027          3605 UNLAL  EQU  *-UNLA
  
```

```

3607 **      WBB - WRITE BINARY BUFFER.
3608 *
3609 *      WBB WRITES THE BINARY BUFFER TO THE DISK.
3610 *
3611 *      IF IT IS A REPLACEMENT FOR AN EXISIGING SECTOR, JUST WRITE IT.
3612 *
3613 *      IF NECESSARY, EXTEND THE FILE WITH GARBAGE UNTIL THE PROPER SECTOR
3614 *      IS REACHED.
3615 *
3616 *      ENTRY  NONE
3617 *      EXIT  NONE
3618 *      USES  NONE
3619 *
3620
  
```

```

060.123 315 054 031 3621 WBB  CALL  $SAVALL      SAVE REGISTERS
060.126 072 171 067 3622 WBB1  LBA  BINCSN      (A) = CURRENT SECTOR NUMBER
060.131 117          3623      MOV  C,A
060.132 006 000     3624      MVI  B,0
060.134 076 000     3625      MVI  A,CN,BIN
060.136 377 047     3626      DB   SYSCALL, .POSIT      POSITION
060.140 322 317 060 3627      JNC  WBB2      OK
060.143 376 001     3628      CFI  EC.EOF
060.145 302 334 060 3629      JNE  BINERR      NOT EOF, SERIOUS ERROR
  
```

```

3630
3631 *      SHOULD NOT OCCUR
3632 *
060.150 315 136 031 3633      CALL  $TPTX
060.153 012 007 111 3634      DB   NL,BELL,'Internal Error #1'
060.176 012 124 150 3635      DB   NL,'This should not occur.'
060.225 103 157 156 3636      DB   'Contact HEATH Technical Correspondence for Assistance.'
060.313 212          3637      DB   ENL
060.314 303 325 042 3638      JMP  EXIT
  
```

```

3639
3640 *      GOT THERE. WRITE SECTOR
3641 *
060.317 001 000 001 3642 WBB2  LXI  B,256
060.322 021 237 070 3643      LXI  D,BINBFR
060.325 076 000     3644      MVI  A,CN,BIN
060.327 377 005     3645      DB   SYSCALL, .WRITE
060.331 322 047 031 3646      JNC  $RSTALL      EXIT IF OK
0647
  
```

```

3648 *      ERROR ON BINARY FILE
  
```

SUBROUTINES.

WBB.

15:20:18 14-MAY-80

3649
060,334 041 136 067 3650 BINERR LXI H,BINFNAM-FE.NAM
060,337 303 112 064 3651 JMP \$FERROR EXPLAIN ERROR

060.342

3654

XTEXT DTB

```

3656X ** $DTB - DELETE TRAILING BLANKS.
3657X *
3658X * $DTB DELETES THE TRAILING BLANKS FROM A CODED LINE.
3659X *
3660X * ENTRY (HL) = LINE FWA
3661X * EXIT (A) = LENGTH OF RESULT (INCLUDING 00 TERMINATOR BYTE)
3662X * USES A,F
3663X
3664X
060.342 325 3665X $DTB PUSH D SAVE (DE)
060.343 124 3666X MOV D,H
060.344 135 3667X MOV E,L (DE) = FWA
060.345 033 3668X DCX D (DE) = FWA-1
060.346 176 3669X $DTB1 MOV A,M
060.347 043 3670X INX H
060.350 247 3671X ANA A FIND END OF LINE
060.351 302 346 060 3672X JNZ $DTB1
060.354 053 3673X DCX H (HL) = ADDRESS OF TERMINATING ZERO BYTE
3674X
3675X * GOT END OF LINE. DELETE TRAILING BLANKS
3676X
060.355 053 3677X $DTB2 DCX H BACKUP ONE CHARACTER
060.356 315 216 030 3678X CALL $CDEHL
060.361 312 372 060 3679X JE $DTB3 GONE PAST FRONT OF LINE; MUST BE ALL BLANKS
060.364 176 3680X MOV A,M
060.365 376 040 3681X CPI
060.367 312 355 060 3682X JE $DTB2 GOT BLANK
3683X
3684X * HAVE TRIED LINE. COMPUTE LENGTH
3685X
060.372 043 3686X $DTB3 INX H
060.373 066 000 3687X MVI M,0 TERMINATE LINE
060.375 175 3688X MOV A,L
060.376 223 3689X SUB E (A) = LENGTH +1 (FOR 00 BYTE)
060.377 353 3690X XCHG
061.000 043 3691X INX H (HL) = LINE FWA
061.001 321 3692X POP D RESTORE (DE)
061.002 311 3693X RET
061.003 3694 XTEXT CCO

```

```

3696X ** $CCO - CLEAR CONTROL-0
3697X *
3698X * $CCO IS CALLED TO CLEAR THE EFFECT OF THE CTL-0 CHARACTER.
3699X *
3700X * ENTRY NONE
3701X * EXIT NONE
3702X * USES NONE
3703X

```

```

3704X
061.003 315 054 031 3705X $CCO CALL $SAVALL SAVE REGISTERS
061.006 078 004 3706X MVI A,I,CONFL
061.010 001 001 000 3707X LXI B,CD,FLG CLEAR CD,FLG
061.013 377 008 3708X DB SYSCALL,CDNSL
061.015 303 047 031 3709X JMP $RSTALL RESTORE REGISTERS AND RETURN
061.020 3710 XTEXT MCU

```

```

3712X ** MCU -- MAP LOWER CASE TO UPPER CASE.
3713X *
3714X * MCU MAPS A LOWER CASE ALPHABETIC TO UPPER
3715X * CASE.
3716X *
3717X * ENTRY (A) = CHARACTER
3718X * EXIT (A) = CHARACTER RESULT
3719X * USES A,F

```

```

3720X
3721X
061.020 376 141 3722X $MCU CPI 'a'
061.022 330 3723X RC NOT LOWER CASE
061.023 376 173 3724X CPI 'z'+1
061.025 320 3725X RNC NOT LOWER CASE
061.026 326 040 3726X SUI 'a'-'A'
061.030 311 3727X RET
061.031 3728 XTEXT MLU

```

```

3730X ** MLU - MAP LOWER CASE LINE TO UPPER CASE.
3731X *
3732X * MLU MAPS THE LOWER CASE ALPHABETICS IN A LINE TO UPPER CASE.
3733X *
3734X * ENTRY (HL) = LINE FWA
3735X * EXIT NONE
3736X * USES NONE
3737X
3738X

```

```

061.031 365 3739X $MLU PUSH PSW SAVE (PSW)
061.032 345 3740X PUSH H SAVE FWA
061.033 053 3741X DCX H ANTICIPATE INX H
061.034 043 3742X $MLUI INX H
061.035 176 3743X MOV A,H (A)= CHARACTER
061.036 315 020 061 3744X CALL $MCU MAP CHAR TO UPPER
061.041 167 3745X MOV M,A
061.042 247 3746X ANA A
061.043 302 034 061 3747X JNZ $MLUI MORE TO GO
061.046 341 3748X POP H RESTORE (HL)
061.047 361 3749X POP PSW RESTORE (PSW)
061.050 311 3750X RET
061.051 3751 XTEXT TYPLZ

```

```

3753X ** $TYPLZ - TYPE LINE UNTIL ZERO BYTE ENCOUNTERED.
3754X *
3755X * NO NEW-LINE IS SENT.
3756X *
3757X * ENTRY (HL) = FWA OF TEXT
3758X * EXIT (HL) ADVANCED PAST ZERO BYTE
3759X * USES A,F,H,L
3760X
3761X
061.051 176 3762X $TYPLZ MOV A,M
061.052 043 3763X INX H
061.053 247 3764X ANA A
061.054 310 3765X RZ ALL DONE
061.055 315 136 061 3766X CALL $WCHAR WRITE LINE
061.060 303 051 061 3767X JMP $TYPLZ DO MORE
061.063 3768 XTEXT HLIHL

```

```

3770X ** $HLIHL - LOAD HL INDIRECT THROUGH HL.
3771X *
3772X * (HL) = ((HL))
3773X *
3774X * ENTRY NONE
3775X * EXIT NONE
3776X * USES A,H,L
3777X
030.211 3778X $HLIHL EQU 30211A IN H17 ROM
061.063 3779 XTEXT C0EHL

```

```

3781X ** $CDEHL - COMPARE (DE) TO (HL)
3782X *
3783X * $CDEHL COMPARES (DE) TO (HL) FOR EQUALITY.
3784X *
3785X * ENTRY NONE
3786X * EXIT 'Z' SET IF (DE) = (HL)
3787X * USES A,F
3788X
030.216 3789X $CDEHL EQU 30216A IN H17 ROM
061.083 3790 XTEXT CHL

```

```

3793X ** $CHL - COMPLEMENT (HL).
3794X *
3795X * (HL) = ~(HL) TWO'S COMPLEMENT
3796X *
3797X * ENTRY NONE
3798X * EXIT NONE
3799X * USES A,F,H,L

```


3800X
3801X
030.224 3802X \$CHL EQU 30224A IN H17 ROM
061.063 3803 XTEXT DADA2

3805X ** \$DADA. - ADD (0,A) TO (H,L)
3806X *
3807X * ENTRY NONE
3808X * EXIT (HL) = (HL) + (0A)
3809X * USES A,F,H,L

3810X
3811X
030.101 3812X \$DADA. EQU 30101A IN H17 ROM
061.063 3813 XTEXT SAVALL

3815X ** \$RSTALL - RESTORE ALL REGISTERS.
3816X *
3817X * \$RSTALL RESTORES ALL THE REGISTERS OFF THE STACK, AND
3818X * RETURNS TO THE PREVIOUS CALLER.
3819X *
3820X * ENTRY (SP) = PSW
3821X * (SP+2) = BC
3822X * (SP+4) = DE
3823X * (SP+6) = HL
3824X * (SP+8) = RET
3825X * EXIT TO *RET*, REGISTERS RESTORED
3826X * USES ALL

3827X
3828X
031.047 3829X \$RSTALL EQU 31047A IN H17 ROM

3831X ** \$SAVALL - SAVE ALL REGISTERS ON STACK.
3832X *
3833X * \$SAVALL SAVES ALL THE REGISTERS ON THE STACK.
3834X *
3835X * ENTRY NONE
3836X * EXIT (SP) = PSW
3837X * (SP+2) = BC
3838X * (SP+4) = DE
3839X * (SP+6) = HL
3840X * USES H,L

3841X
3842X
031.054 3843X \$SAVALL EQU 31054A IN H17 ROM
061.063 3844 XTEXT RTL

*RTL

```

3846X **      *RTL - READ TEXT LINE.
3847X *
3848X *      *RTL READS A LINE FROM THE TERMINAL.
3849X *
3850X *      CHARACTER ARE ACCEPTED FROM THE TERMINAL, RUBOUT AND BACKSPACE
3851X *      CHARACTERS ARE PROCESSED. WHEN A CARRIAGE RETURN IS ENTERED;
3852X *      *RTL RETURNS.
3853X *
3854X *      ENTRY (HL) = BUFFER FWA
3855X *      EXIT  'C' CLEAR IF OK
3856X *      DATA IN BUFFER
3857X *      (A) = TEXT LENGTH
3858X *      'C' SET IF CTL-D STRUCK
3859X *      USES  A,F
3860X
3861X
061.063 315 072 061 3862X *RTL.  CALL  *RTL          *RTL IN UPPER CASE
061.066 330          3863X      RC          CTL-D
061.067 303 031 061 3864X      JMP  *HLU          MAP LINE TO UPPER CASE
3865X
061.072          3866X *RTL  EQU    *
061.072 345          3867X      PUSH  H          SAVE FWA
061.073 315 130 061 3868X *RTL1  CALL  *RCHAR
061.076 376 004          3869X      CFI    CTLD
061.100 312 125 061 3870X      JE    *RTL2          CTL-D STRUCK
061.103 167          3871X      MOV   M,A
061.104 043          3872X      INX   H
061.105 376 012          3873X      CFI   NL
061.107 302 073 061 3874X      JNE  *RTL1
061.112 053          3875X      DCX  H
061.113 066 000          3876X      MVI  M,0
061.115 043          3877X      INX  H
3878X
3879X *      ALL DONE, COMPUTE LENGTH
3880X
061.116 353          3881X      XCHG          (DE) = LWA+1
061.117 343          3882X      XTHL          (HL) = FWA
061.120 173          3883X      MOV   A,E
061.121 225          3884X      SUB   L          (A) = LENGTH
061.122 247          3885X      ANA   A          CLEAR CARRY
061.123 321          3886X      POP   D          RESTORE (DE)
061.124 311          3887X      RET
3888X
3889X *      CTL-D STRUCK
3890X
061.125 341          3891X *RTL2  POP   H          (HL) = FWA
061.126 067          3892X      STC
061.127 311          3893X      RET
061.130          3894      XTEXT  RCHAR

```

```

3896X **      $RCHAR - READ SINGLE CHARACTER FROM CONSOLE.
3897X *
3898X *      ENTRY  NONE
3899X *      EXIT   (A) = CHARACTER
3900X *      USES  A,F
3901X
3902X
061.130 377 001 3903X $RCHAR DB      SYSCALL, SCIN
061.132 332 130 061 3904X JC      $RCHAR      NOT READY
061.135 311      3905X RET
3906X
061.136 377 002 3907X $WCHAR DB      SYSCALL, SCOUT
061.140 311      3908X RET
061.141      3909  XTEXT  UDD

```

```

3911X **      $UDD - UNPACK DECIMAL DIGITS.
3912X *
3913X *      UDD CONVERTS A 16 BIT VALUE INTO A SPECIFIED NUMBER OF
3914X *      DECIMAL DIGITS. THE RESULT IS ZERO FILLED.
3915X *
3916X *      ENTRY  (B,C) = ADDRESS VALUE
3917X *      (A) = DIGIT COUNT
3918X *      (H,L) = MEMORY ADDRESS
3919X *      EXIT   (HL) = (HL) + (A)
3920X *      USES  ALL
3921X
3922X
031.157      3923X $UDD  EQU   31157A      IN H17 ROM
061.141      3924  XTEXT  MOVEL

```

```

3926X **      $MOVEL - MOVE DATA
3927X *
3928X *      $MOVEL MOVES A BLOCK OF BYTES TO A NEW MEMORY ADDRESS.
3929X *      IF THE MOVE IS TO A LOWER ADDRESS, THE BYTES ARE MOVED FROM
3930X *      FIRST TO LAST.
3931X *
3932X *      IF THE MOVE IS TO A HIGHER ADDRESS, THE BYTES ARE MOVED FROM
3933X *      LAST TO FIRST.
3934X *
3935X *      THIS IS DONE SO THAT AN OVERLAPED MOVE WILL NOT 'RIPPLE'.
3936X *
3937X *      CALL   $MOVEL
3938X *      DW     COUNT
3939X *      DW     FROM
3940X *      DW     TO
3941X *
3942X *      ENTRY  ((SP)) = RET
3943X *      (RET+0) = COUNT (WORD VALUE)
3944X *      (RET+2) = FROM
3945X *      (RET+4) = TO

```

\$MOVEL

```

3946X *      EXIT      TO (RET+6)
3947X *      (DE) = ADDRESS OF NEXT FROM BYTE
3948X *      (HL) = ADDRESS OF NEXT *TO* BYTE
3949X *      'C' CLEAR
3950X *      USES      ALL
3951X
3952X
061.141 341 3953X $MOVEL POP      H      (HL) = RET
061.142 116 3954X      MOV      C,M
061.143 043 3955X      INX      H
061.144 106 3956X      MOV      B,M      (BC) = COUNT
061.145 043 3957X      INX      H
061.146 136 3958X      MOV      E,M
061.147 043 3959X      INX      H
061.150 126 3960X      MOV      D,M      (DE) = FROM
061.151 043 3961X      INX      H
061.152 325 3962X      PUSH     D      ((SP)) = FROM
061.153 136 3963X      MOV      E,M
061.154 043 3964X      INX      H
061.155 126 3965X      MOV      D,M      (DE) = TO
061.156 043 3966X      INX      H
061.157 343 3967X      XTHL
061.160 353 3968X      XCHG
061.161 303 252 030 3969X      JMP      $MOVE
061.164      3970      XTEXT   CPF      MOVE IT

```

```

3972X **      $CPF - COPY FILE NAME
3973X *
3974X *      $CPF COPIES A FILE NAME FROM ONE LOCATION TO ANOTHER.
3975X *
3976X *      THE CHARACTERS ARE COPIED UNTIL A DELIMITER (';', ':', '=', OR 00)
3977X *      IS FOUND.
3978X *
3979X *      THE FILENAME IS THEN TERMINATED WITH A 00 BYTE.
3980X *
3981X *      ENTRY (DE) = FROM ADDRESS
3982X *      (HL) = TO ADDRESS
3983X *      EXIT  'C' CLEAR IF OK
3984X *      (DE) = ADVANCED PAST NAME AND DELIMITER
3985X *      (HL) POINTS TO 00 BYTE OF DESTINATION
3986X *      (A) = DELIMITER
3987X *      'C' SET IF ERROR
3988X *      USES      ALL
3989X
3990X
061.164 006 022 3991X $CPF  MVI      B,FB,NAML+1      SET MAX LENGTH
061.166 032 3992X $CPF1  LDAX     D
061.167 247 3993X      ANA      A
061.170 312 223 061 3994X      JZ       $CPF2      END
061.173 023 3995X      INX      D
061.174 376 054 3996X      CPI      ','
061.176 312 223 061 3997X      JE       $CPF2
061.201 376 075 3998X      CPI      '='

```

```

061.203 312 223 061 3999X      JE      $CPF2
061.206 376 040      4000X      CFI
061.210 312 223 061 4001X      JE      $CPF2      IS BLANK
061.213 167          4002X      MOV      M,A      COPY
061.214 043          4003X      INX      H
061.215 005          4004X      DCR      B
061.216 302 166 061 4005X      JNZ     $CPF1      IF MORE GO TO
061.221 067          4006X      STC      OVERFLOW OF AREA
061.222 311          4007X      RET
                    4008X
                    4009X *      DONE.
                    4010X
061.223 066 000      4011X $CPF2  MVI      M,0      TERMINATE
061.225 311          4012X      RET
061.226              4013      XTEXT  INDL

```

```

4015X **      $INDL - INDEXED LOAD.
4016X *
4017X *      $INDL LOADS DE WITH THE TWO BYTES AT (HL)+DISPLACMENT
4018X *
4019X *      THIS ACTS AS AN INDEXED FULL WORD LOAD.
4020X *
4021X *      (DE) = ( (HL) + DSPLACEMENT )
4022X *
4023X *      ENTRY ((RET)) = DISPLACEMENT (FULL WORD)
4024X *      (HL) = TABLE ADDRESS
4025X *      EXIT TO (RET+2)
4026X *      USES A,F,D,E
4027X
4028X
030.234      4029X $INDL  EQU      30234A      IN H17 ROM
061.226      4030      XTEXT  MOVE

```

```

4032X **      $MOVE - MOVE DATA
4033X *
4034X *      $MOVE MOVES A BLOCK OF BYTES TO A NEW MEMORY ADDRESS.
4035X *      IF THE MOVE IS TO A LOWER ADDRESS, THE BYTES ARE MOVED FROM
4036X *      FIRST TO LAST.
4037X *
4038X *      IF THE MOVE IS TO A HIGHER ADDRESS, THE BYTES ARE MOVED FROM
4039X *      LAST TO FIRST.
4040X *
4041X *      THIS IS DONE SO THAT AN OVERLAPED MOVE WILL NOT 'RIPPLE'.
4042X *
4043X *      ENTRY (BC) = COUNT
4044X *      (DE) = FROM
4045X *      (HL) = TO
4046X *      EXIT MOVED
4047X *      (DE) = ADDRESS OF NEXT FROM BYTE
4048X *      (HL) = ADDRESS OF NEXT *TO* BYTE

```

```

4049X *      'C' CLEAR
4050X *      USES  ALL
4051X *
4052X *
030.252     4053X $MOVE EQU 30252A      IN H17 ROM
061.226     4054      XTEXT CRLF

```

```

4056X **     $CRLF - TYPE CARRIAGE RETURN/ LINE FEED
4057X *
4058X *     $CRLF IS USED TO GENERATE PADDED CRLF'S.
4059X *
4060X *     ENTRY  NONE
4061X *     EXIT   (A) = 0
4062X *     USES  A,F
4063X *
4064X *
061.226 076.012 4065X $CRLF MVI A,NL
061.230 377.002 4066X      DB  SYSCALL,.SCOUT
061.232 257     4067X      XRA  A
061.233 311     4068X      RET
061.234     4069      XTEXT DADA

```

```

4071X **     $DADA - PERFORM (H,L) = (H,L) + (0,A)
4072X *
4073X *     ENTRY  (H,L) = BEFORE VALUE
4074X *           (A) = BEFORE VALUE
4075X *     EXIT   (H,L) = (H,L) + (0,A)
4076X *           'C' SET IF OVERFLOW
4077X *     USES  F,H,L
4078X *
4079X *
030.072     4080X $DADA EQU 30072A      IN H17 ROM
061.234     4081      XTEXT UDD

```

```

4083X **     $UDD - UNPACK OCTAL DIGITS.
4084X *
4085X *     UDD CONVERTS A SINGLE BYTE INTO 3 OCTAL DIGITS., ZERO FILL
4086X *
4087X *     ENTRY  (A) = BYTE VALUE
4088X *           (H,L) = ADDRESS OF 3 BYTE AREA FOR DIGITS
4089X *     EXIT   (H,L) = (H,L)+3
4090X *     USES  A,H,L
4091X *
4092X *
061.234 305     4093X $UDD PUSH B
061.235 006 003 4094X      MVI B,3      (B) = LOOP COUNT
061.237 247     4095X      ANA  A      CLEAR CARRY

```

```

4096X
061.240 027 4097X UOD1 RAL
061.241 027 4098X RAL
061.242 027 4099X RAL
061.243 365 4100X PUSH PSW SAVE VALUE
061.244 346 007 4101X ANI 7
061.246 306 060 4102X ADI '0'
061.250 167 4103X MOV M+A STORE DIGIT
061.251 043 4104X INX H
061.252 361 4105X POP PSW RESTORE VALUE
061.253 005 4106X DCR B
061.254 392 340 061 4107X JNZ UOD1 IF MORE TO GO
061.257 301 4108X POP B RESTORE (B,C)
061.260 311 4109X RET EXIT
061.261 4110 XTEXT DU66

```

```

4112X ** $DU66 - UNSIGNED 16 / 16 DIVIDE.
4113X *
4114X * (HL) = (BC)/(DE)
4115X *
4116X * ENTRY (BC), (DE) PRESET
4117X * EXIT (HL) = RESULT
4118X * (DE) = REMAINDER
4119X * USES ALL
4120X
4121X
030.106 4122X $DU66 EQU 30106A IN H17 ROM
061.261 4123 XTEXT MU66

```

```

4125X ** $MU66 - UNSIGNED 16X16 MULTIPLY.
4126X *
4127X * ENTRY (BC) = MULTIPLICAND
4128X * (DE) = MULTIPLIER
4129X * EXIT (HL) = RESULT
4130X * 'Z' SET IF NOT OVERFLOW
4131X * USES ALL
4132X
4133X
030.337 4134X $MU66 EQU 30337A IN H17 ROM
061.261 4135 XTEXT TBL5

```

```

4137X **      $TBLS - TABLE SEARCH
4138X *
4139X *      TABLE FORMAT
4140X *
4141X *      DB      KEY1,VAL1,
4142X *      .
4143X *      .
4144X *      DB      KEYN,VALN
4145X *      DB      0
4146X *
4147X *      ENTRY   (A) = PATTERN
4148X *              (H,L) = TABLE FWA
4149X *      EXIT    (A) = PATTERN IF FOUND
4150X *              'Z' SET IF FOUND
4151X *              'Z' CLEAR IF NOT FOUND OR PATTERN=0      /78.10.GC/
4152X *      USES   A,F,H,L
4153X
4154X
061.261 305 4155X $TBLS  FUSH  B
061.262 376 000 4156X  CPI   0      /78.10.GC/
061.264 312 306 061 4157X  JZ   TBL2  /78.10.GC/
061.267 107 4158X  MOV  B,A
061.270 176 4159X TBL1  MOV  A,M      (A) = CHARACTER
061.271 043 4160X  INX  H
061.272 270 4161X  CMP  B
061.273 312 310 061 4162X  JZ   TBL3  IF MATCH
061.276 247 4163X  ANA  A
061.277 043 4164X  INX  H      SKIP FAST
061.300 302 270 061 4165X  JNZ  TBL1  IF NOT END OF TABLE
061.303 053 4166X  DCX  M
061.304 053 4167X  DCX  H
061.305 357 4168X  XRA  A      SET TO ZERO FOR OLD USERS
061.306 376 001 4169X TBL2  CPI   1      CLEAR ZERO      /78.10.GC/
4170X
4171X *      DONE
4172X
061.310 301 4173X TBL3  POP  B
061.311 311 4174X  RET
061.312 4175  XTEXT  TBRA

```

```

4177X **      $TBRA - BRANCH RELATIVE THROUGH TABLE.
4178X *
4179X *      $TBRA USES THE SUPPLIED INDEX TO SELECT A BYTE FROM THE
4180X *      JUMP TABLE. THE CONTENTS OF THIS BYTE ARE ADDED TO THE
4181X *      ADDRESS OF THE BYTE, YIELDING THE PROCESSOR ADDRESS.
4182X *
4183X *      CALL  $TBRA
4184X *      DB   LAB1-*      INDEX = 0 FOR LAB1
4185X *      DB   LAB2-*      INDEX = 1 FOR LAB2
4186X *      DB   LABN-*      INDEX = N-1 FOR LABN
4187X *
4188X *      ENTRY  (A) = INDEX
4189X *              (RET) = TABLE FWA

```



```

4190X *      EXIT   TO COMPUTED ADDRESS
4191X *      USES   F,H,L
4192X
4193X
031.076     4194X $TBRA EQU   31078A      IN H17 ROM
061.312     4195      XTEXT  TYPT2

4197X **      $TYPTX - TYPE TEXT.
4198X *
4199X *      $TYPTX IS CALLED TO TYPE A BLOCK OF TEXT ON THE SYSTEM CONSOLE.
4200X *
4201X *      IMBEDDED ZERO BYTES INDICATE A CARRIAGE RETURN LINE FEED.
4202X *      A BYTE WITH THE 200Q BIT SET IS THE LAST BYTE IN THE MESSAGE.
4203X *
4204X *      ENTRY   (RET) = TEXT
4205X *      EXIT    TO (RET+LENGTH)
4206X *      USES    A,F
4207X
4208X
031.136     4209X $TYPTX EQU   31136A      IN H17 ROM
4210X
031.144     4211X $TYPTX EQU   31144A      IN H17 ROM
061.312     4212      XTEXT  FOPE

4214X **      $FOPER = OPEN FILE BLOCK FOR I/O
4215X *
4216X *      $FOPER IS CALLED BEFORE ANY I/O IS DONE VIA A
4217X *      FILE BLOCK. $FOPEX SETS UP THE FILE BLOCK, AND OPENS
4218X *      THE FILE VIA *HDOS*.
4219X *
4220X *      ENTRY   (DE) = ADDRESS OF DEFAULT BLOCK
4221X *             (HL) = ADDRESS OF FILE BLOCK
4222X *      EXIT    TO $FERROR IF ERROR
4223X *             TO CALLER IF OK
4224X *      USES    A,F,B,C,D,E
4225X
4226X
061.312     4227X $FOPER CALL  $FOPER.
061.315     4228X      RNC
061.316     4229X      JMP   $FERROR      IN ERROR
4230X
061.321     4231X $FOPEW CALL  $FOPEW.
061.324     4232X      RNC
061.325     4233X      JMP   $FERROR      IN ERROR
4234X
061.330     4235X $FOPEU CALL  $FOPEU.
061.333     4236X      RNC
061.334     4237X      JMP   $FERROR      IN ERROR
4238X
4239X

```

\$FOPE

15:22:06 16-MAY-80

```

061.337 076 002 4240X $FOPER. MVI A,FT.0R FILE TYPE OF OPEN FOR READ
061.341 001 4241X DB 0010 LXI,B TO SKIP NEXT MVI
061.342 076 004 4242X $FOPEW. MVI A,FT.0W OPEN FOR WRITE
061.344 001 4243X DB 0010 LXI,B TO SKIP NEXT MVI
061.345 076 006 4244X $FOPEU. MVI A,FT.0R+FT.0W
4245X
4246X * (A) = FILE FLAGS
4247X
061.347 345 4248X PUSH H SAVE FILE BLOCK ADDRESS
061.350 365 4249X PUSH PSW SAVE NEW FLAGS
000.000 4250X ERRNZ FB,CHA
061.351 106 4251X MOV B,M (B) = CHANNEL NUMBER
061.352 305 4252X PUSH B SAVE HANNEL NUMBER
000.000 4253X ERRNZ FB,FLG-FB,CHA-1
061.353 043 4254X INX H
061.354 117 4255X MOV C,A (C) = NEW FILE FLAGS
061.355 176 4256X MOV A,M (A) = CURRENT TYPE
061.356 247 4257X ANA A
061.357 171 4258X MOV A,C (A) = NEW FLAGS TO BE SET
061.360 312 372 061 4259X JZ $FOPE1 NOT ALREADY OPEN
4260X
4261X * ALREADY OPEN. SQUACK
4262X
061.363 301 4263X POP B RESTORE (BC)
061.364 361 4264X POP PSW DISCARD NEW FLAGS
061.365 341 4265X POP H (HL) = FB ADDRESS
061.366 076 031 4266X MVI A,EC.FA0 FILE ALREADY OPEN
061.370 067 4267X STC
061.371 311 4268X RET
4269X
000.000 4270X ERRNZ FB,FWA-FB,FLG-1
061.372 043 4271X $FOPE1 INX H (HL) = $FB.FWA
061.373 116 4272X MOV C,M
061.374 043 4273X INX H
061.375 106 4274X MOV B,M (BC) = FB.FWA
061.376 043 4275X INX H
000.000 4276X ERRNZ FB,PTR-FB,FWA-2
061.377 161 4277X MOV M,C SET FB,PTR = FB.FWA
062.000 043 4278X INX H
062.001 160 4279X MOV M,B
062.002 043 4280X INX H
000.000 4281X ERRNZ FB,LIM-FB,PTR-2
062.003 161 4282X MOV M,C SET FB,LIM = FB.FWA
062.004 043 4283X INX H
062.005 160 4284X MOV M,B
062.006 043 4285X INX H
000.000 4286X ERRNZ FB,NAM-FB,LIM-4
062.007 043 4287X INX H
062.010 043 4288X INX H (HL) = $FB.NAM
4289X
4290X * FILE BLOCK POINTERS SETUP. OPEN FILE
4291X
062.011 345 4292X PUSH H SAVE NEW ADDRESS FOR NAME
062.012 041 043 062 4293X LXI H,$FOPER
062.015 247 4294X ANA A
062.016 312 025 062 4295X JZ $FOPE2
    
```

/78.10.GC/

\$FOPE

000.000		4296X	ERRNZ	.EXIT	
062.021	315 261 061	4297X	CALL	\$TBLS	FIND CODE
062.024	176	4298X	MOV	A,M	
062.025	062 033 062	4299X	\$FOPE2	STA	\$FOPEA
062.030	341	4300X	POP	H	SET SYSCALL CODE
062.031	361	4301X	POP	PSW	(HL) = \$FB.NAM
062.032	377 000	4302X	DB	SYSCALL, .EXIT	(A) = CHANNEL NUMBER
062.033		4303X	\$FOPEA	EDU	*-1
062.034	321	4304X	POP	D	SYSCALL CODE
062.035	341	4305X	POP	H	(D) = NEW FLAG
062.036	330	4306X	RC		(HL) = FILE BLOCK ADDRESS
062.037	043	4307X	INX	H	EXIT IF ERROR
000.000		4308X	ERRNZ	FB.FLG-1	
062.040	162	4309X	MOV	M,D	SET NEW FLAGS
062.041	053	4310X	DCX	H	RESTORE (HL)
062.042	311	4311X	RET		
		4312X			
062.043	002 042	4313X	\$FOPEB	DB	FT,OR, .OPENR
062.045	004 043	4314X	DB	FT,OW, .OPENW	TABLE OF SYSCALL CODES
062.047	006 044	4315X	DB	FT,OR+FT,OW, .OPENU	
062.051	000	4316X	DB	0	SHOULD NOT OCCUR
062.052		4317	XTEXT	FCLQ	
		4319X	**	\$FCLQ	- CLOSE FILE BLOCK.
		4320X	*		
		4321X	*		\$FCLQ IS CALLED TO TERMINATE PROCESSING THROUGH A FILE
		4322X	*		BLOCK.
		4323X	*		
		4324X	*	ENTRY	(HL) = FILE BLOCK ADDRESS
		4325X	*	EXIT	TO \$FERROR IF ERROR
		4326X	*		TO CALLER IF OK
		4327X	*	USES	A,F,B,C,D,E
		4328X			
		4329X			
062.052	315 061 062	4330X	\$FCLQ	CALL	\$FCLQ.
062.055	320	4331X	RNC		NO ERROR
062.056	303 112 064	4332X	JMP	\$FERROR	
		4333X			
062.061	345	4334X	\$FCLQ.	PUSH	H
000.000		4335X	ERRNZ	FB.FLG-1	SAVE FILE BLOCK ADDRESS
062.062	043	4336X	INX	H	(HL) = \$FB.FLG
062.063	176	4337X	MOV	A,M	
062.064	066 000	4338X	MVI	M,0	CLEAR FLAG
062.066	247	4339X	ANA	A	
062.067	312 155 062	4340X	JZ	\$FCLQ4	FILE NOT OPEN
062.072	346 004	4341X	ANI	FT,OW	
062.074	312 147 062	4342X	JZ	\$FCLQ3	NO WRITING, NO FLUSHING NEEDED
		4343X			
		4344X	*		WAS OPEN FOR WRITE. SEE IF NEED FLUSH THE LAST SECTOR
		4345X			
062.077	315 234 030	4346X	CALL	\$INBL	
062.102	003 000	4347X	DW	FB.PTR-FB.FLG	
062.104	325	4348X	PUSH	D	SAVE (FB.PTR)

```

062,105 315 234 030 4349X CALL $INDL (DE) = (FB.FWA)
062,110 001 000 4350X DW FB.FWA-FB.FLG
062,112 341 4351X POP H (HL) = (FB.PTR)
062,113 175 4352X MOV A,L
062,114 223 4353X SUB E
062,115 117 4354X MOV C,A
062,116 174 4355X MOV A,H
062,117 232 4356X SBB D
062,120 107 4357X MOV B,A (BC) = AMOUNT IN BLOCK
062,121 261 4358X ORA C
062,122 312 147 062 4359X JZ $FCLO3 NONE TO FLUSH
4360X
4361X * NEED TO FLUSH BUFFER
4362X *
4363X * (BC) = DATA AMOUNT
4364X * (DE) = FWA
4365X * (HL) = LWA+1
4366X
062,125 171 4367X MOV A,C
062,126 247 4368X ANA A
062,127 312 142 062 4369X JZ $FCLO2 DONT HAVE PARTIAL SECTOR
4370X
4371X * ZERO FILL PARTIAL SECTOR
4372X
062,132 066 000 4373X $FCLO1 MVI M,0
062,134 043 4374X INX H
062,135 014 4375X INR C
062,136 302 132 062 4376X JNZ $FCLO1
062,141 004 4377X INR B COUNT ANOTHER FULL SECTOR
062,142 341 4378X $FCLO2 POP H (HL) = FB.FWA
062,143 176 4379X MOV A,M (A) = CHANNEL NUMBER
000,000 4380X ERRNZ FB.CHA
062,144 345 4381X FUSH H
062,145 377 005 4382X DB SYSCALL,WRITE FLUSH
4383X
4384X * READY TO CLOSE FILE.
4385X *
4386X * C/ SET IF ERROR
4387X * (A) = ERROR CODE
4388X
062,147 341 4389X $FCLO3 POP H (HL) = FILE BLOCK ADDRESS
062,150 330 4390X RC ERROR
000,000 4391X ERRNZ FB.CHA
062,151 176 4392X MOV A,M (A) = CHANNEL NUMBER
062,152 345 4393X PUSH H
062,153 377 046 4394X DB SYSCALL,CLOSE CLOSE CHANNEL
062,155 341 4395X $FCLO4 POP H (HL) = FILE BLOCK ADDRESS
062,156 311 4396X RET
062,157 4397 XTEXT FCLEAR

```

```

4399X **      $FCLEAR - CLEAR FILE BLOCK.
4400X *
4401X *      $FCLEAR CLEARS OUT A FILE BLOCK BY SETTING THE POINTERS TO
4402X *      EMPTY, AND CLEARING ANY ERROR OR EOF FLAGS.
4403X *
4404X *      THE DISK (OR WHATEVER) FILE IS NOT POSITIONED, READ, WRITEN
4405X *      OPENED OR CLOSED.
4406X *
4407X *      ENTRY (HL) = FB ADDRESS
4408X *      EXIT NONE
4409X *      USES A,F,B,C
4410X
4411X
062.157      4412X $FCLEAR EQU *
062.157 345  4413X PUSH H SAVE FILE BLOCK ADDRESS
000.000      4414X ERRNZ FB.FLG-FB.CHA-1
062.160 043  4415X INX H
000.000      4416X ERRNZ FB.FWA-FB.FLG-1
062.161 043  4417X INX H (HL) = $FB.FWA
062.162 116  4418X MOV C,M
062.163 043  4419X INX H
062.164 106  4420X MOV B,M (BC) = FB.FWA
062.165 043  4421X INX H
000.000      4422X ERRNZ FB.PTR-FB.FWA-2
062.166 161  4423X MOV M,C SET FB.PTR = FB.FWA
062.167 043  4424X INX H
062.170 160  4425X MOV M,B
062.171 043  4426X INX H
000.000      4427X ERRNZ FB.LIM-FB.PTR-2
062.172 161  4428X MOV M,C SET FB.LIM = FB.FWA
062.173 043  4429X INX H
062.174 160  4430X MOV M,B
062.175 341  4431X POP H (HL) = FB.FWA
062.176 311  4432X RET
062.177      4433X XTEXT $FREAL

```

```

4435X **      $FREAL - READ BYTES FROM FILE BUFFER.
4436X *
4437X *      $FREAL IS CALLED TO READ A NUMBER OF BYTES FROM A FILE BUFFER.
4438X *
4439X *      ENTRY (BC) = BYTE COUNT
4440X *      (DE) = FWA FOR BYTES
4441X *      (HL) = ADDRESS OF FILE BUFFER
4442X *      EXIT TO *FERROR* IF ERROR
4443X *      TO CALLER IF OK
4444X *      (BC) = UNREAD BYTE COUNT (ONLY IF EOF)
4445X *      (DE) = ADDRESS OF FIRST UNUSED BYTE
4446X *      'C' SET IF EOF DURING READ
4447X *      USES A,F,B,C,B,E
4448X
4449X
062.177 315 212 062 4450X $FREAL CALL $FREAL,
062.202 320 4451X RNC RETURN IF OK

```

```

062.203 376 001 4452X CPI EC.EOF
062.205 302 112 064 4453X JNE $FERROR ERROR IS NOT EOF
062.210 067 4454X STC
062.211 311 4455X RET ERROR IS SIMPLY EOF
4456X
4457X
062.212 4458X $FREAL EQU *
062.212 013 4459X DCX B (BC) = COUNT NOT INCLUDING 00 BYTE
062.213 257 4460X XRA A
062.214 062 111 064 4461X STA EOFFLG CLEAR EOF FLAG
062.217 345 4462X PUSH H
062.220 315 335 063 4463X CALL CBT COPY BUFFER POINTERS TO TEMP CELLS
4464X
4465X * COPY DATA FROM BUFFER TO TARGET
4466X
062.223 325 4467X $REAL2 PUSH D SAVE TARGET ADDRESS
062.224 072 100 064 4468X LDA T,FLG
062.227 346 002 4469X ANI FT,OR
062.231 076 011 4470X MVI A,EC,FND
062.233 067 4471X STC ASSUME FILE NOT OPEN
062.234 312 370 062 4472X JZ $REAL8 ERROR
062.237 170 4473X MOV A,B
062.240 261 4474X ORA C
062.241 312 370 062 4475X JZ $REAL8 ALL DONE
4476X
4477X * COMPUTE MIN( DATA IN BUFFER, DATA REQUESTED)
4478X
062.244 052 103 064 4479X $REAL3 LHLD T,PTR
062.247 353 4480X XCHG (DE) = (FB,PTR) = ADDRESS OF DATA
062.250 052 105 064 4481X LHLD T,LIM (HL) = LIMIT ADDRESS
062.253 175 4482X MOV A,L
062.254 223 4483X SUB E
062.255 157 4484X MOV L,A
062.256 174 4485X MOV A,H
062.257 232 4486X SBB D
062.260 147 4487X MOV H,A (HL) = NUMBER OF BYTES IN BUFFER
062.261 171 4488X MOV A,C
062.262 225 4489X SUB L COMPARE TO REQUESTED COUNT
062.263 170 4490X MOV A,B
062.264 234 4491X SBB H
062.265 322 272 062 4492X JNC $REAL4 LESS THAN REQUESTED COUNT
062.270 140 4493X MOV H,B
062.271 151 4494X MOV L,C DONT TRANSFER MORE THAN LIMIT
062.272 174 4495X $REAL4 MOV A,H
062.273 265 4496X ORA L
062.274 302 310 062 4497X JNZ $REAL6 SOME IN BUFFER
4498X
4499X * BUFFER IS EMPTY, RE-FILL IT
4500X
062.277 315 015 064 4501X CALL $FFB FILL FILE BUFFER
062.302 332 370 062 4502X JC $REAL8 ERROR CONDITION
062.305 303 244 062 4503X JMF $REAL3 COUNT THE DATA
4504X
4505X * GOT THE DATA, MOVE IT FROM BUFFER TO TARGET
4506X *
4507X * (BC) = LIMIT COUNT

```

```

4508X *      (DE) = FROM
4509X *      (HL) = COUNT
4510X *      ((SP)) = TO
4511X
062.310 171 4512X #REAL6 MOV  A,C
062.311 225 4513X SUB  L
062.312 117 4514X MOV  C,A
062.313 170 4515X MOV  A,B
062.314 234 4516X SBB  H
062.315 107 4517X MOV  B,A      REMOVE BYTES ABOUT TO BE MOVED FROM REQUEST COUNT
062.316 305 4518X PUSH B
062.317 343 4519X XTHL      (HL) = REMAINING REQUEST COUNT
062.320 301 4520X POP  B      (BC) = COUNT FOR THIS COPY
062.321 343 4521X XTHL      (HL) = TARGET ADDR, ((SP)) = REMAINING REQ. COUNT
062.322 032 4522X #REAL7 LDAX D
062.323 023 4523X INX  D
062.324 167 4524X MOV  M,A
062.325 043 4525X INX  H
062.326 247 4526X ANA  A      SEE IF 00 BYTE
062.327 302 336 062 4527X JNZ  #REL7.3      NOT 00
4528X
4529X *      IS 00 BYTE. IGNORE IT.
4530X
062.332 343 4531X XTHL
062.333 043 4532X INX  H      ADD ONE TO UNREQUESTED COUNT
062.334 343 4533X XTHL
062.335 053 4534X DCX  H      BACKSPACE OVER CHARACTER
062.336 013 4535X #REL7.3 DCX  B
062.337 376 012 4536X CPI  NL
062.341 312 361 062 4537X JE   #REL7.5      IS END OF LINE
062.344 170 4538X MOV  A,B
062.345 261 4539X ORA  C
062.346 302 322 062 4540X JNZ  #REAL7      MORE TO GO
062.351 353 4541X XCHG
062.352 042 103 064 4542X SHLD T,PTR      UPDATE POINTER
062.355 301 4543X POP  B      (BC) = REMAINING COUNT
062.356 303 223 062 4544X JMP  #REAL2      SEE IF MORE IN BUFFER
4545X
4546X *      END OF CODED LINE
4547X
062.361 353 4548X #REL7.5 XCHG
062.362 033 4549X DCX  D      BACK OVER NL CHARACTER
062.363 042 103 064 4550X SHLD T,PTR      UPDATE POINTER
062.366 301 4551X POP  B      (BC) = REMAINING COUNT
062.367 325 4552X PUSH D      SAVE TARGET LWA
4553X
4554X *      READ COMPLETE.
4555X *
4556X *      (PSW) = COMPLETION FLAGS
4557X
062.370 321 4558X #REAL8 POP  D      RESTORE TARGET ADDRESS
062.371 365 4559X PUSH PSW      SAVE RETURN CODE
062.372 257 4560X XRA  A
062.373 022 4561X STAX D      FLAG END OF LINE
062.374 361 4562X POP  PSW      RESTORE RESULT FLAGS
062.375 023 4563X INX  D      POINT TO NEXT FREE

```

062.376 341 4564X *REAL9 POP H
062.377 303 363 063 4565X JMP CTR COPY TEMP POINTERS BACK TO BLOCK, EXIT
063.002 4566 XTEXT FWRIL

4568X ** \$FWRIL - WRITE LINE FROM FILE BUFFER.
4569X *
4570X * \$FWRIL IS CALLED TO WRITE A LINE TO A FILE BUFFER.
4571X *
4572X * ENTRY (DE) = PWA FOR BYTES
4573X * (HL) = ADDRESS OF FILE BUFFER
4574X * EXIT TO *FERROR* IF ERROR
4575X * TO CALLER IF OK
4576X * (DE) = ADDRESS OF FIRST UNWRITTEN BYTE
4577X * USES A,F,B,C,D,E

063.002 315 011 063 4580X \$FWRIL CALL \$FWRIL.
063.005 320 4581X RNC RETURN IF OK
063.006 303 112 064 4582X JMP \$FERROR ERROR

4583X
4584X * SCAN FOR END OF LINE
4585X

063.011 325 4586X \$FWRIL PUSH D SAVE LINE POINTER
063.012 001 377 377 4587X LXI B,1 (BC) = COUNT
063.015 032 4588X \$FWRILI LDAX D
063.016 023 4589X INX D
063.017 003 4590X INX B
063.020 247 4591X ANA A
063.021 302 015 063 4592X JNZ \$FWRILI MORE TO GO
063.024 321 4593X POP D
063.025 315 047 063 4594X CALL \$FWRIB WRITE BYTES
063.030 330 4595X RC ERROR

4596X
4597X * WRITE 'NL' CHARACTER

4598X
4599X
063.031 023 4599X INX D
063.032 325 4600X PUSH D
063.033 001 001 000 4601X LXI B,1
063.036 021 046 063 4602X LXI D,\$FWRILA
063.041 315 047 063 4603X CALL \$FWRIB
063.044 321 4604X POP D
063.045 311 4605X RET
4606X
063.046 012 4607X \$FWRILA DB NL
063.047 4608 XTEXT FWRIB


```

4610X ** $FWRIB - WRITE BYTES FROM FILE BUFFER.
4611X *
4612X * $FWRIB IS CALLED TO WRITE A NUMBER OF BYTES FROM A FILE BUFFER.
4613X *
4614X * ENTRY (BC) = BYTE COUNT
4615X * (DE) = FWA FOR BYTES
4616X * (HL) = ADDRESS OF FILE BUFFER
4617X * EXIT TO *FERROR* IF ERROR
4618X * TO CALLER IF OK
4619X * (DE) = ADDRESS OF FIRST UNWRITTEN BYTE
4620X * USES A,F,B,C,D,E
4621X
4622X
063.047 315 056 063 4623X $FWRIB CALL $FWRIB.
063.052 320 4624X RMC RETURN IF OK
063.053 303 112 064 4625X JMP $FERROR ERROR
4626X
4627X
063.056 4628X $FWRIB EQU *
063.056 345 4629X PUSH H
063.057 315 335 063 4630X CALL CRT COPY BUFFER POINTERS TO TEMP CELLS
4631X
4632X * COPY DATA FROM USER AREA TO BUFFER
4633X
063.062 325 4634X $WRIB2 PUSH D SAVE AREA ADDRESS
063.063 072 100 064 4635X LDA T,FLB
063.066 346 004 4636X ANI FT,OW SEE IF OPEN FOR WRITE
063.070 312 224 063 4637X JZ $WRIB8 FILE NOT OPEN FOR WRITE
063.073 170 4638X MOV A,B
063.074 261 4639X ORA C
063.075 312 224 063 4640X JZ $WRIB8 ALL DONE
4641X
4642X * COMPUTE MIN ROOM IN BUFFER, WRITE COUNT REQUESTED
4643X
063.100 052 103 064 4644X $WRIB3 LHLD T,PTR
063.103 353 4645X XCHG (DE) = (FB, PTR) = ADDRESS OF ROOM
063.104 052 107 064 4646X LHLD T,LWA (HL) = LIMIT ADDRESS
063.107 175 4647X MOV A,L
063.110 223 4648X SUB E
063.111 157 4649X MOV L,A
063.112 174 4650X MOV A,H
063.113 232 4651X SBB D
063.114 147 4652X MOV H,A (HL) = BYTES OF ROOM IN BUFFER
063.115 171 4653X MOV A,C COMPARE REQUESTED COUNT TO BUFFER ROOM
063.116 225 4654X SUB L
063.117 170 4655X MOV A,B
063.120 234 4656X SBB H
063.121 322 126 063 4657X JNC $WRIB4 MORE REQUESTED THEN ROOM
063.124 140 4658X MOV H,B
063.125 151 4659X MOV L,C USE REQUESTED COUNT
063.126 174 4660X $WRIB4 MOV A,H
063.127 265 4661X ORA L
063.130 302 170 063 4662X JNZ $WRIB6 SOME ROOM IN BUFFER
4663X
4664X * BUFFER IS FULL. EMPTY IT
4665X

```

```

063.133 305 4666X PUSH B SAVE COUNT
063.134 052 101 064 4667X LHLD T,FWA
063.137 042 103 064 4668X SHLD T,PTR CLEAR REMOVAL POINTER
063.142 353 4669X XCHG
063.143 052 107 064 4670X LHLD T,LWA
063.146 175 4671X MOV A,L
063.147 223 4672X SUB E
063.150 117 4673X MOV C,A
063.151 174 4674X MOV A,H
063.152 232 4675X SBB D
063.153 107 4676X MOV B,A (BC) = DATA IN BUFFER
063.154 072 077 064 4677X LDA T,CHA
063.157 377 005 4678X IE SYSCALL,WRITE WRITE BUFFER
063.161 301 4679X POP B (BC) = DESIRED COUNT
063.162 322 100 063 4680X JNC $WRIB3 GOT THE DATA
4681X
4682X * ERROR ON WRITE.
4683X
063.165 303 224 063 4684X JMP $WRIB8 HAVE ERROR
4685X
4686X * GOT THE DATA. MOVE IT FROM BUFFER TO TARGET
4687X *
4688X * (BC) = REQUEST COUNT
4689X * (DE) = TO
4690X * (HL) = COUNT
4691X * ((SP)) = FROM
4692X
063.170 171 4693X $WRIB6 MOV A,C
063.171 225 4694X SUB L
063.172 117 4695X MOV C,A
063.173 170 4696X MOV A,B
063.174 234 4697X SBB H
063.175 107 4698X MOV B,A REMOVE BYTES ABOUT TO BE MOVED FROM REQUEST COUNT
063.176 305 4699X PUSH B
063.177 343 4700X XTHL (HL) = REMAINING REQUEST COUNT
063.200 301 4701X POP B (BC) = COUNT FOR THIS COPY
063.201 343 4702X XTHL (HL) = TARGET ADDR, ((SP)) = REMAINING REQ. COUNT
063.202 176 4703X $WRIB7 MOV A,H
063.203 022 4704X STAX D
063.204 023 4705X INX D
063.205 043 4706X INX H
063.206 013 4707X DCX B
063.207 170 4708X MOV A,B
063.210 261 4709X ORA C
063.211 302 202 063 4710X JNZ $WRIB7 MORE TO GO
063.214 353 4711X XCHG
063.215 042 103 064 4712X SHLD T,PTR UPDATE POINTER
063.220 301 4713X POP B (BC) = REMAINING COUNT
063.221 303 062 063 4714X JMP $WRIB2 SEE IF MORE IN BUFFER
4715X
4716X * WRITE COMPLETE.
4717X *
4718X * (PSW) = COMPLETION FLAGS
4719X
063.224 321 4720X $WRIB8 POP D RESTORE TARGET ADDRESS
063.225 341 4721X POP H

```

063.226 303 363 063 4722X JMP CTB COPY TEMP POINTERS BACK TO BLOCK, EXIT

4724X ** \$FWBRK - BREAKOUTPUT /80.02.GC/
4725X *
4726X * \$FWBRK empties the specified buffer by filling it with NULLs
4727X * and then writing it. Note this is used to insure that block
4728X * mode I/O is output if it is not really a serial device (es.
4729X * writes to AT: from *EDIT*.
4730X *
4731X *
4732X * ENTRY: HL = FILE BLOCK POINTER
4733X *
4734X * EXIT: HL = FILE BLOCK POINTER
4735X * TO \$FERROR IF ERROR
4736X *
4737X * USES: FSW,BC,DE
4738X *
4739X *

063.231 315 240 063 4740X \$FWBRK CALL \$FWBRK,
063.234 320 4741X RNC NO ERROR

4742X
063.235 303 112 064 4743X JMP \$FERROR
4744X

063.240 345 4745X \$FWBRK PUSH H
063.241 315 335 063 4746X CALL CRT COPY BUFFER TO TEMPORARY
063.244 315 254 063 4747X CALL \$FWBRK1
063.247 341 4748X POP H
063.250 315 363 063 4749X CALL CTB COPY TEMPORARY TO BUFFER
063.253 311 4750X RET
4751X

063.254 052 107 064 4752X \$FWBRK1 LHLD T,LWA
063.257 353 4753X XCHG DE = BUFFER LWA
063.260 052 103 064 4754X LHLD T,PTR HL = BUFFER PTR
063.263 173 4755X MOV A,E
063.264 225 4756X SUR L
063.265 117 4757X MOV C,A
063.266 172 4758X MOV A,D
063.267 234 4759X SBB H
063.270 107 4760X MOV B,A BC = DE - HL
063.271 261 4761X ORA C
063.272 310 4762X RZ THE BUFFER IS ALREADY FLUSHED
4763X

4764X * FILL THE BUFFER WITH NULLS
4765X

063.273 170 4766X \$FWBRK2 MOV A,B
063.274 261 4767X ORA C
063.275 312 307 063 4768X JZ \$FWBRK3 NO MORE LEFT TO FILL
4769X

063.300 066 000 4770X MVI M,0
063.302 043 4771X INX H
063.303 013 4772X DCX B
063.304 303 273 063 4773X JMP \$FWBRK2
4774X

```

063.307 052 101 064 4775X FWBRK3 LHL D T,FWA
063.312 042 103 064 4776X SHLD T,FTR
063.315 353 4777X XCHG
063.316 052 107 064 4778X LHL D T,LWA DE = BUFFER FWA
063.321 175 4779X MOV A,L HL = BUFFER LWA
063.322 223 4780X SUB E
063.323 117 4781X MOV C,A
063.324 174 4782X MOV A,H
063.325 232 4783X SBB D
063.326 107 4784X MOV B,A BC = HL - DE ( BC = COUNT )
063.327 072 077 064 4785X LDA T,CHA
063.332 377 005 4786X DB SYSCALL,WRITE
063.334 311 4787X RET
063.335 4788 XTEXT FUTIL

4790X ** $FUTIL - UTILITY ROUTINES FOR FILE BLOCK ROUTINES.
4791X
4792X ** CBT - COPY BLOCK POINTERS TO TEMP CELLS.
4793X *
4794X * ENTRY (HL) = FILE BLOC FWA
4795X * EXIT NONE
4796X * USES A,F,H,L
4797X
063.335 325 4798X CBT PUSH D
063.336 305 4799X PUSH B SAVE REGISTERS
000.000 4800X ERKNZ TLEN-10 ASSUME 10 BYTES TO MOVE
063.337 021 077 064 4801X LXI D,T,CHA (DE) = TARGET FOR MOVE
063.342 006 005 4802X MVI B,10/2
063.344 176 4803X CBT1 MOV A,H COPY FILE BUFFER INTO WORK AREA
063.345 022 4804X STAX D
063.346 043 4805X INX H
063.347 023 4806X INX D
063.350 176 4807X MOV A,H
063.351 022 4808X STAX D
063.352 043 4809X INX H
063.353 023 4810X INX D
063.354 005 4811X DCR B
063.355 302 344 063 4812X JNZ CBT1 MORE TO GO
063.360 301 4813X POP R
063.361 321 4814X POP D (DE) = DATA TARGET ADDRESS
063.362 311 4815X RET
4816X
4817X
4818X ** CTB - COPY TEMP CELLS BACK TO FILE BLOCK.
4819X *
4820X * ENTRY (HL) = FILE BLOCK ADDRESS
4821X * EXIT NONE
4822X * USES NONE
4823X
063.363 365 4824X CTR PUSH PSW
063.364 325 4825X PUSH D
063.365 305 4826X PUSH B
063.366 345 4827X PUSH H SAVE REGISTERS

```

```

063.367 066 004 4828X MOV B,B/2
063.371 021 077 064 4829X LXI D,T,CHA
063.374 032 4830X CTRI LDAX D
063.375 167 4831X MOV M,A
063.376 023 4832X INX D
063.377 043 4833X INX H
064.000 032 4834X LDAX D
064.001 167 4835X MOV M,A
064.002 023 4836X INX D
064.003 043 4837X INX H
064.004 005 4838X DCR B
064.005 302 374 063 4839X JNZ CTB1 RESTORE FILE BUFFER VALUES
064.010 341 4840X POP H
064.011 301 4841X POP B
064.012 321 4842X POP D
064.013 361 4843X POP PSW
064.014 311 4844X RET

```

```

4846X ** $FFB - FILE FILE BUFFER.
4847X *
4848X * $FFB FILLS THE FILE BUFFER BY READING FROM THE FILE.
4849X *
4850X * ENTRY NONE
4851X * EXIT 'C' SET IF READ INCOMPLETE
4852X * (A) = ERROR CODE
4853X * 'C' CLEAR IF READ COMPLETEE
4854X * DATA IN BUFFER
4855X * USES A,F,D,E,H,L

```

```

064.015 072 111 064 4858X $FFB LDA EOFFLG
064.020 037 4859X RAR
064.021 330 4860X RC EOF
4861X
4862X * CAN READ MORE, DO SO
4863X
064.022 305 4864X PUSH B SAVE COUNT
064.023 052 101 064 4865X LHL T,FWA
064.026 042 103 064 4866X SHLD T,FTR CLEAR REMOVAL POINTER
064.031 353 4867X XCHG
064.032 052 107 064 4868X LHL T,LWA
064.035 042 105 064 4869X SHLD T,LIM SET DATA LIMIT
064.040 175 4870X MOV A,L
064.041 223 4871X SUB E
064.042 117 4872X MOV C,A
064.043 174 4873X MOV A,H
064.044 232 4874X SRR B
064.045 107 4875X MOV B,A (BC) = ROOM IN BUFFER
064.046 072 077 064 4876X LDA T,CHA
064.051 377 004 4877X DB SYSCALL, READ READ BUFFER
064.053 120 4878X MOV D,B (D) = SECTORS UNREAD
064.054 301 4879X POP B (BC) = DESIRED COUNT
064.055 320 4880X RNC GOT THE DATA

```

```

4881X
4882X *   ERROR ON READ, SEE IF EOF
4883X
064.056 027      4884X      RAL
064.057 062 111 064 4885X      STA      EOFFLG      SET EOF, WE HOPE
064.062 376 003 4886X      CPI      EC.EOF*2+1
064.064 037      4887X      RAR
064.065 300      4888X      RNE
064.066 072 106 064 4889X      LDA      T.LIN+1      IS NOT EOF, RETURN NOW!
064.071 222      4890X      SUB      D
064.072 062 106 064 4891X      STA      T.LIN+1      SET AMOUNT OF DATA WE DID GET
064.075 247      4892X      ANA      A
064.076 311      4893X      RET
4894X
4895X
4896X **   TEMP CELLS TO HOLD FILE BLOCK POINTERS DURING I/O
4897X
000.000      4898X      ERRNZ   FB.CHA
064.077 000      4899X T.CHA  DB      0      CHANNEL NUMBER
000.000      4900X      ERRNZ   *-T.CHA-FB.FLG
064.100 000      4901X T.FLG  DB      0      FLAG BYTE
000.000      4902X      ERRNZ   *-T.CHA-FB.FWA
064.101 000 000 4903X T.FWA  DW      0
000.000      4904X      ERRNZ   *-T.CHA-FB.PTR
064.103 000 000 4905X T.PTR  DW      0
000.000      4906X      ERRNZ   *-T.CHA-FB.LIM
064.105 000 000 4907X T.LIM  DW      0
000.000      4908X      ERRNZ   *-T.CHA-FB.LWA
064.107 000 000 4909X T.LWA  DW      0
000.012      4910X T.LEN  EQU     *-T.CHA      LENGTH OF TEMP CELLS
4911X
064.111 000      4912X EOFFLG DB      0
064.112      4913      XTEXT  FERROR

```

```

4915X **   $FERROR - PROCESS FILE ERRORS.
4916X *
4917X *   $FERROR IS CALLED TO COMPLAIN ABOUT AN ERROR ENCOUNTERED
4918X *   WHEN PROCESSING FILES.
4919X *
4920X *   ENTRY   (A) = ERROR CODE
4921X *           (HL) = ADDRESS OF FILE NAME - FB.NAM
4922X *   EXIT   TO RESTART
4923X *   USES   ALL
4924X
4925X
064.112 365      4926X $FERROR PUSH  PSW      SAVE CODE
064.113 315 136 031 4927X      CALL   $TYPTX
064.116 012 007 105 4928X      DB    NL,BELL,'ERROR ON FILE','+2000
064.136 021 012 000 4929X      LXI   B,FB.NAM
064.141 031      4930X      DAD   B
4931X
4932X *   PRINT FILE NAME
4933X

```

```
064.142 178      4934X $FERR1 MOV    A,H
064.143 043      4935X      INX    H          ADVANCE MESSAGE
064.144 247      4936X      ANA    A
064.145 312 156 064 4937X      JZ     $FERR2
064.150 315 136 061 4938X      CALL  $WCHAR
064.153 303 142 064 4939X      JMP   $FERR1
                   4940X
                   4941X *      TYPE ERROR MESSAGE
                   4942X
064.156 315 136 031 4943X $FERR2 CALL  $TYPTX
064.161 040 055 240 4944X      DB     ' ',' ' +200R
064.164 046 012      4945X      MVI   H,NL
064.166 361      4946X      POP   PSW          (A) = CODE
064.167 377 057      4947X      DB     SYSCALL, .ERROR
064.171 303 340 042 4948X      JMP   RESTART     EXIT
```

```

4951 **      OPCTAB - OPCODE TABLE.
4952 *
4953 *      OPCTAB CONTAINS AN ENTRY FOR EACH OPCODE.
4954 *      THE TABLE IS SEARCHED SERIALY, SO THE MOST HEAVILY
4955 *      USED OPCODES SHOULD BE PLACED TOWARDS THE FRONT.
4956 *
4957 *      THE TABLE FORMAT IS:
4958 *
4959 *      DB      'OPCDD'      CHARACTERS 1 - N-1
4960 *      DB      'E'+80H     LAST CHARACTER HAS HIGH BIT SET
4961 *      DB      F           =1 IF TO ASSEMBLE REGARDLESS OF *IFXS
4962 *      DB      F           =1 IF NOT TO AUTOMATICALLY DEFINE LABEL
4963 *      DB      'IIIIII'   = OPCODE TYPE INDEX
4964 *      DB      CODE       OPCODE, IF MACHINE OP
4965 *                          IF PSEUDO OP, =0 IF 'IN GROUP' 1
4966
000.200     4967 OF.CE EQU 200Q      CONDITIONAL ASSEMBLY EXCEPTION
000.100     4968 OF.LD EQU 100Q      DEFER LABEL DEFINITION
4969
4970
064.174     4971 OPCTAB EQU *
064.174     4972 DB      'AC', 'I'+80H,1,316Q
064.201     4973 DB      'AD', 'C'+80H,3,210Q
064.206     4974 DB      'AD', 'D'+80H,3,200Q
064.213     4975 DB      'AD', 'I'+80H,1,306Q
064.220     4976 DB      'AN', 'A'+80H,3,240Q
064.225     4977 DB      'AN', 'I'+80H,1,346Q
064.232     4978 DB      'CAL', 'L'+80H,2,315Q
064.240     4979 DB      'C', 'C'+80H,2,334Q
064.244     4980 DB      'C', 'M'+80H,2,374Q
064.250     4981 DB      'CM', 'A'+80H,0,057Q
064.255     4982 DB      'CM', 'C'+80H,0,077Q
064.262     4983 DB      'CH', 'P'+80H,3,270Q
064.267     4984 DB      'CN', 'C'+80H,2,324Q
064.274     4985 DB      'CN', 'Z'+80H,2,304Q
064.301     4986 DB      'C', 'P'+80H,2,364Q
064.305     4987 DB      'CP', 'E'+80H,2,354Q
064.312     4988 DB      'CP', 'I'+80H,1,374Q
064.317     4989 DB      'CP', 'D'+80H,2,344Q
064.324     4990 DB      'C', 'Z'+80H,2,314Q
064.330     4991 DB      'DA', 'A'+80H,0,047Q
064.335     4992 DB      'DA', 'D'+80H,7,011Q
064.342     4993 DB      'D', 'B'+80H,13,1
064.346     4994 DB      'DC', 'R'+80H,4,005Q
064.353     4995 DB      'DC', 'X'+80H,7,013Q
064.360     4996 DB      'D', 'I'+80H,0,363Q
064.364     4997 DB      'D', 'S'+80H,14,0
064.370     4998 DB      'D', 'W'+80H,15,1
064.374     4999 DB      'E', 'I'+80H,0,373Q
065.000     5000 DB      'EJEC', 'T'+80H,OF.LD+16,0
065.007     5001 DB      'ELS', 'E'+80H,OF.LD+17+OF.CE,0
065.015     5002 DB      'EN', 'D'+80H,OF.LD+18+OF.CE,1
065.022     5003 DB      'ENDI', 'F'+80H,OF.LD+19+OF.CE,0
065.031     5004 DB      'EQ', 'U'+80H,OF.LD+20,0
065.036     5005 DB      'ERRM', 'I'+80H,OF.LD+21,3
065.045     5006 DB      'ERRN', 'Z'+80H,OF.LD+21,1

```


065.054	105	122	122	5007	DB	'ERRP', 'L'+80H, OF.LD+21, 2
065.063	105	122	122	5008	DB	'ERRZ', 'R'+80H, OF.LD+21, 0
065.072	110	114	324	5009	DB	'HL', 'T'+80H, 0, 166Q
065.077	111	306	126	5010	DB	'I', 'F'+80H, OF.LD+22, 0
065.103	111	316	001	5011	DB	'I', 'N'+80H, 1, 333Q
065.107	111	116	322	5012	DB	'IN', 'R'+80H, 4, 004Q
065.114	111	116	330	5013	DB	'IN', 'X'+80H, 7, 003Q
065.121	112	303	002	5014	DB	'J', 'C'+80H, 2, 332Q
065.125	112	305	002	5015	DB	'J', 'E'+80H, 2, 312Q
065.131	112	315	002	5016	DB	'J', 'M'+80H, 2, 372Q
065.135	112	115	320	5017	DB	'JM', 'P'+80H, 2, 303Q
065.142	112	116	303	5018	DB	'JN', 'C'+80H, 2, 322Q
065.147	112	116	305	5019	DB	'JN', 'E'+80H, 2, 302Q
065.154	112	116	332	5020	DB	'JN', 'Z'+80H, 2, 302Q
065.161	112	320	002	5021	DB	'J', 'P'+80H, 2, 362Q
065.165	112	120	305	5022	DB	'JP', 'E'+80H, 2, 352Q
065.172	112	120	317	5023	DB	'JP', 'O'+80H, 2, 342Q
065.177	112	332	002	5024	DB	'J', 'Z'+80H, 2, 312Q
065.203	114	104	301	5025	DB	'LD', 'A'+80H, 2, 072Q
065.210	114	104	101	5026	DB	'LDA', 'X'+80H, 9, 012Q
065.216	114	110	114	5027	DB	'LHL', 'D'+80H, 2, 052Q
065.224	114	117	306	5028	DB	'LO', 'F'+80H, OF.LD+23, 0
065.231	114	117	316	5029	DB	'LO', 'N'+80H, OF.LD+24, 0
065.236	114	130	311	5030	DB	'LX', 'I'+80H, 11, 001Q
065.243	115	117	326	5031	DB	'MO', 'O'+80H, 12, 100Q
065.250	115	126	311	5032	DB	'MV', 'I'+80H, 8, 006Q
065.255	116	117	320	5033	DB	'NO', 'F'+80H, 0, 000Q
065.262	117	122	301	5034	DB	'OR', 'A'+80H, 3, 260Q
065.267	117	122	307	5035	DB	'OR', 'G'+80H, OF.LD+25, 0
065.274	117	122	311	5036	DB	'OR', 'I'+80H, 1, 366Q
065.301	117	125	324	5037	DB	'OU', 'T'+80H, 1, 323Q
065.306	120	103	110	5038	DB	'FCH', 'L'+80H, 0, 351Q
065.314	120	117	320	5039	DB	'FO', 'P'+80H, 6, 301Q
065.321	120	125	123	5040	DB	'FUS', 'H'+80H, 6, 305Q
065.327	122	101	314	5041	DB	'RA', 'L'+80H, 0, 027Q
065.334	122	101	322	5042	DB	'RA', 'R'+80H, 0, 037Q
065.341	122	303	000	5043	DB	'R', 'C'+80H, 0, 330Q
065.345	122	305	000	5044	DB	'R', 'E'+80H, 0, 310Q
065.351	122	105	324	5045	DB	'RE', 'T'+80H, 0, 311Q
065.356	122	114	303	5046	DB	'RL', 'C'+80H, 0, 007Q
065.363	122	315	000	5047	DB	'R', 'H'+80H, 0, 370Q
065.367	122	116	303	5048	DB	'RN', 'C'+80H, 0, 320Q
065.374	122	116	305	5049	DB	'RN', 'E'+80H, 0, 300Q
066.001	122	116	332	5050	DB	'RN', 'Z'+80H, 0, 300Q
066.006	122	320	000	5051	DB	'R', 'P'+80H, 0, 360Q
066.012	122	120	305	5052	DB	'RP', 'E'+80H, 0, 350Q
066.017	122	120	317	5053	DB	'RP', 'O'+80H, 0, 340Q
066.024	122	122	303	5054	DB	'RR', 'C'+80H, 0, 017Q
066.031	122	123	324	5055	DB	'RS', 'T'+80H, 10, 307Q
066.036	122	332	000	5056	DB	'R', 'Z'+80H, 0, 310Q
066.042	123	102	302	5057	DB	'SB', 'B'+80H, 3, 230Q
066.047	123	102	311	5058	DB	'SB', 'I'+80H, 1, 336Q
066.054	123	103	101	5059	DB	'SCAL', 'L'+80H, 1, 377Q
066.063	123	105	324	5060	DB	'SE', 'T'+80H, OF.LD+26, 0
066.070	123	110	114	5061	DB	'SHL', 'D'+80H, 2, 042Q
066.076	123	120	101	5062	DB	'SPAC', 'E'+80H, OF.LD+27, 0

066.105	123	120	110	5063	DB	'SPH', 'L'+80H,0,3710
066.113	123	124	301	5064	DB	'ST', 'A'+80H,2,0620
066.120	123	124	101	5065	DB	'STA', 'X'+80H,9,0020
066.126	123	124	303	5066	DB	'ST', 'C'+80H,0,0670
066.133	123	124	314	5067	DB	'ST', 'L'+80H,0F.LD+28,0
066.140	123	125	302	5068	DB	'SU', 'B'+80H,3,2200
066.145	123	125	311	5069	DB	'SU', 'I'+80H,1,3260
066.152	124	111	124	5070	DB	'TITL', 'E'+80H,0F.LD+29,0
066.161	130	103	110	5071	DB	'XCH', 'G'+80H,0,3530
066.167	130	122	301	5072	DB	'XR', 'A'+80H,3,2500
066.174	130	122	311	5073	DB	'XR', 'I'+80H,1,3560
066.201	130	124	110	5074	DB	'XTH', 'L'+80H,0,3430
066.207	103	117	104	5075	DB	'COD', 'E'+80H,0F.LD+30,0
066.215	105	116	103	5076	DB	'ENCL', 'U'+80H,0F.LD+31,0
066.224	130	124	105	5077	DB	'XTEX', 'T'+80H,0F.LD+31,0
				5078		
066.233	000			5079	DB	0 END OF TABLE

5082 ** THE FOLLOWING AREAS ARE ASSEMBLY AREAS FOR LISTING LINES:

5084 ** HEADING LINE.
 5085 *
 5086
 5087
 066.234 5088 HEADING EQU * START OF PAGE HEADING
 066.234 040 040 040 5089 TTLTXT DB /
 000.062 5090 TTXTL EQU *-TTLTXT LENGTH
 066.316 011 110 105 5091 DB / HEATH ASM #104.05.00' /78.10.GC/
 066.343 012 5092 DB NL NEW LINE
 5093
 066.344 040 040 040 5094 STLTXT DB /
 000.063 5095 STXTL EQU *-STLTXT LENGTH
 067.027 011 5096 DB TAB
 067.030 060 066 055 5097 HEADC DB '06-DEC-79'
 000.011 5098 HEADCL EQU *-HEADC
 067.041 040 040 040 5099 DB / Page
 067.052 000 5100 HEADA DB 0
 067.053 000 5101 HEADR DB 0
 067.054 012 012 5102 DB NL,NL 2 BLANK LINES
 000.222 5103 HEADLEN EQU *-HEADING HEADER LENGTH

5105 ** LISTING LINE WORK AREA

5106
 5107
 067.056 5108 DSPLIN DS 0
 067.056 040 040 040 5109 DB / ERROR FLAGS
 067.061 040 040 040 5110 DSPLNA DB / BANK NUMBER
 067.064 056 5111 DB /
 067.065 040 040 040 5112 DB / BANK ADDRESS
 067.070 040 040 5113 DB /
 067.072 040 040 040 5114 DSPLNB DB / BYTE 1
 067.075 040 5115 DB /
 067.076 040 040 040 5116 DB / BYTE 2
 067.101 040 5117 DB /
 067.102 040 040 040 5118 DSPLNC DB / BYTE 3
 067.105 040 5119 DB /
 067.106 5120 DSPLIM EQU * LIMIT FOR OCTAL BYTES
 067.106 060 060 060 5121 DSPLND DB '00000' LINE NUMBER /80.02.GC/
 067.113 130 5122 DSPLNE DB 'X' XTEXT FLAG /80.02.GC/
 067.114 040 040 5123 DB / /80.02.GC/
 000.040 5124 DSPLFN EQU *-DSPLIN LENGTH OF HEADER
 067.116 000 5125 DB 0 TERMINATES DSPLIN FOR \$DTE
 067.117 200 5126 DB 2000 TERMINATES DSPLIN FOR .PRINT

067.120	000 000	5129	DBRPTR	DW	0	BYTE DECODE POINTER
		5130				
067.122	000	5131	PASS	DB	0	PASS NUMBER
067.123	000 000	5132	ERRCNT	DW	0	NUMBER OF ERRORS IN PASS
067.125	000	5133	ERRSHO	DB	0	<=0 IF TO TYPE ERRORS ON CONSOLE
067.126	000 000	5134	STATNO	DW	0	STATEMENT NUMBER
067.130	000	5135	LSTCTL	DB	0	LISTING CONTROL OPTIONS
067.131	000	5136	LSTCTLS	DB	0	FORCED SET LISTING CONTROL
067.132	000	5137	LSTCTLG	DB	0	FORCED CLEAR LISTING CONTROL (INVERTED MASK)
067.133	000	5138	ENDFLG	DB	0	NON-ZERO IF END STATEMENT READ
067.134	000 000	5139	ORG	DW	0	ORIGIN POINTER
067.136	000 000	5140	SDRG	DW	0	VALUE OF *DRG* AT BEGINNING OF STATEMENT
067.140	000	5141	ERRFLG	DB	0	ERROR FLAGS FOR THIS STATEMENT
067.141	000	5142	GRPFLG	DB	0	<=0 IF HAVE ASSEMBLED 2ND GROUP INSTRUCTIONS
067.142	000	5143	XTXFLG	DB	0	<=0 IF READING FROM XTEXT
067.143	000	5144	XTXLINE	DB	0	<=0 IF CURRENT LINE FROM XTEXT
		5145				
		5146	*			CODE GENERATION FLAG
		5147				
067.144	000	5148	FTFLAG	DB	0	FILE TYPE (FT.PIC, FT.ABS)
067.145	000	5149	RELFLG	DB	0	ST.REL IF RELOCATABLE ASSEMBLY
067.146	000	5150	CODEFLG	DB	0	<=0 IF 'CODE' PSEUDO ENCOUNTERED THIS PASS
		5151				
067.147	000	5152	LARGE	DB	0	<=0 IF TO SWAP OVERLAY
		5153				
		5154				
		5155	*			BINARY OUTPUT MANAGEMENT
		5156				
067.150		5157	BINFNAM	DS	FB.NAML	BINARY FILE NAME (=0 IF NONE)
067.171	000	5158	BINCSN	DB	0	CURRENT SECTOR NUMBER IN BINBUF
067.172	000	5159	BINSKW	DB	0	BYTES OF HEADER ON FRONT OF BINARY FILE
		5160				
067.173		5161	ABSHDR	DS	0	HEADER FOR ABS BINARY FILE
067.173	377 000	5162		DB	3770+FT.ABS	
067.175	377 377	5163	ABSFVA	DW	-1	LOWEST ADDRESS GENERATED (=0 IF PIC)
067.177	000 000	5164	ABSLEN	DW	0	LENGTH
067.201	200 042	5165	ABSENT	DW	USERFVA	ENTRY POINT
		5166				
067.203	000 000	5167	ABSLWA	DW	0	MAX ADDRESS GENERATED
		5168				
067.205		5169	FICHDR	DS	0	HEADER FOR PIC BINARY FILE
067.205	377 001	5170		DB	3770+FT.PIC	
067.207	000 000	5171	PICLEN	DW	0	LENGTH OF ENTIRE THING
067.211	000 000	5172	PICPTR	DW	0	POINTER TO REL TABLE
		5173				
		5174	**			LISTING FORMAT AND CONTROL FLAGS
		5175				
067.213	000	5176	WIDE	DB	0	<=0 IF WIDE SWITCH
067.214	074	5177	PAGEFP	DB	20	DEPTH OF PAGE
067.215	000	5178	FORMFP	DB	0	FORM DEPTH (ONLY IF PRINTER WONT TAKE FORMFEED)
		5179				
		5180				
		5181	**			DYNAMIC TABLE ALLOCATION
		5182				

067.216	003 076	5183	SYMFWA	DW	SYMTAB	FWA
067.220	003 076	5184	SYMPTR	DW	SYMTAB	LWA+ (SMALL SLOP FACTOR)
067.222	000 000	5185	RELLWA	DW	0	REL TABLE END
067.224	000 000	5186	RELPTR	DW	0	REL TAB ACTIVE POINTER (IT GROWS DOWN)

5188 ** FILE BUFFERS

		5189				
067.226		5190	LISIFB	DS	0	LISTING FILE BLOCK
067.226	001	5191		DB	CN.LST	LISTING CHANNEL
067.227	000	5192		DB	0	FLAG
067.230	237 071	5193		DW	LISTBUF	
067.232	237 071	5194		DW	LISTBUF	
067.234	237 071	5195		DW	LISTBUF	
067.236	237 073	5196		DW	LISTBUF+LISTBFL	
067.240		5197		DS	FB.NAML	LISTING FILE NAME
		5198				
067.261		5199	SORCFB	DS	0	SOURCE FILE BLOCK
067.261	002	5200		DB	CN.SOU	SOURCE CHANNEL
067.262	000	5201		DB	0	FLAG
067.263	237 073	5202		DW	SORCBUF	
067.265	237 073	5203		DW	SORCBUF	
067.267	237 073	5204		DW	SORCBUF	
067.271	237 074	5205		DW	SORCBUF+SORCBFL	
067.273		5206		DS	FB.NAML	LISTING FILE NAME
		5207				
067.314		5208	XTXFB	DS	0	XTEXT FILE BLOCK
067.314	003	5209		DB	CN.XTX	XTEXT CHANNEL
067.315	000	5210		DB	0	FLAG
067.316	237 074	5211		DW	XTXBUF	
067.320	237 074	5212		DW	XTXBUF	
067.322	237 074	5213		DW	XTXBUF	
067.324	237 075	5214		DW	XTXBUF+XTXBFL	
067.326		5215		DS	FB.NAML	XTEXT FILE NAME
		5216				

5218 ** CNDIFLG - CONDITIONAL ASSEMBLY FLAG.

		5219	*			
		5220	*		=000 - NO CONDITIONS	
		5221	*		=200 - AM ASSEMBLING	
		5222	*		=201 - AM SKIPPING	
		5223				
067.347	000	5224	CNDIFLG	DB	0	CONDITIONAL ASSEMBLY FLAG
		5225				
067.350	001	5226	EJEFLG	DB	1	NON-ZERO IF TO EJECT
067.351	000	5227	LINCNT	DB	0	LINES PER LAGE
067.352	000	5228	PAGNOH	DB	0	PAGE NUMBER
		5229				
		5230	*		RELOCATION FLAGS	
		5231				
067.353	000	5232	EXPREL	DB	0	=ST.REL IF EXPRESION IS RELOCATABLE
067.354	000	5233	TOKREL	DB	0	=ST.REL IF TOKEN IS RELOCATABLE
		5234				
		5235				

067.355

5236 PATCH DS 84

PATCH AREA

```

5239 **      PRS - PRESET ASSEMBLER.
5240 *
5241 *      PRS IS THE INITIAL ENTRY POINT FOR THIS PROGRAM.
5242 *
5243 *      IT GETS THE COMMAND LINE (IF IT WASN'T PASSED ON THE STACK)
5244 *      CRACKS THE FILE NAMES AND SWITCHES, AND SETS UP THE ASSEMBLER.
5245 *
5246 *      *****
5247 *      * N O T E *
5248 *      *****      THIS CODE IS OVERLAID DURING ASSEMBLY BY BUFFERS AND
5249 *      *****      WORKAREAS. IT MAY NOT BE RE-ENTERED AFTER THE INITIAL TIME.
5250 *
5251 *      PRS PERFORMS 2 TASKS:
5252 *
5253 *      1) GET COMMAND LINE, CRACK SWITCHES, AND OPEN FILES:
5254 *          BINARY FILE
5255 *          LISTING FILE
5256 *          SOURCE FILE
5257 *      2) SETUP DYNAMIC TABLES
5258 *          SYMBOL TABLE
5259 *          RELOCATION TABLE
5260 *
5261 *      PRS IS THE ENTRY POINT FOR THIS ASSEMBLER. IF THE STACK IS NON-EMPTY
5262 *      IT IS ASSUMED TO CONTAIN THE COMMAND LINE. (1ST CHARACTER PUSHED
5263 *      ON LAST)
5264 *
5265 *      FROM THEN ON, STACK DISCIPLINE IS * * NOT MAINTAINED * *
5266 *      FOR THIS ROUTINE. ITS SUBROUTINES MAY VECTOR BACK TO IT FOR EXCEPTIONAL
5267 *      CASES, WITH THE STACK UNCLEAR, THE STACK IS KEPT 'EMPTY' ((SP) = STACK)
5268 *      WHILE IN PRS, PRS EXIT TO 'ASM' VIA A JUMP.
5269 *      ENTRY FROM SYSTEM
5270 *      EXIT TO HBASH
5271 *      USES ALL
5272 *
5273 *
5274 PRS      EQU      *
5275 *
5276 *      CHECK THE HDOS VERSION
5277 *
5278 DB      SYSCALL, VERS /79.12.GC/
5279 JC      PRSERR1      PROBABLY NO VERSION SYSTEM CALL /79.12.GC/
5280 CPI     VERS /79.12.GC/
5281 JNZ     PRSERR1      NOT THE CORRECT VERSION OF HDOS /79.12.GC/
5282 *
5283 *      SEE IF A COMMAND IS ON THE STACK
5284 *
5285 LXI     H, RHEML
5286 DB      SYSCALL, SETTP SET LIMIT (TEMPORARILY, UNTIL *BDT*)
5287 JC      PRSERR      NOT ENOUGH MEMORY
5288 LXI     H, CCHIT
5289 MVI     A, CTLC
5290 DB      SYSCALL, CTLC SETUP CTL-C PROCESSING
5291 LXI     H, 0
5292 DAD     SP      (HL) = STACK
5293 XCHG      (DE) = STACK VALUE
5294 MVI     A, #STACK

```

```

070.115 223          5295      SUB      E
070.116 117          5296      MOV      C,A
070.117 076 042      5297      MVI      A,STACK/256
070.121 232          5298      SBB      D
070.122 107          5299      MOV      B,A          (BC) = BYTES ON STACK
070.123 261          5300      ORA      C
070.124 312 142 070  5301      JZ       PRS1          READ COMMAND LINE
070.127 041 237 075  5302      LXI      H,LINE
070.132 315 252 030  5303      CALL    $MOVE          MOVE IN LINE
070.135 046 000      5304      MVI      H,0          GUARANTEE TERMINATOR
070.137 303 252 070  5305      JMP      PRS3          CRACK LINE
5306
5307 *              ANNOUNCE PRODUCT
5308
070.142 315 136 031  5309      PRS1    CALL    $TYPTX
070.145 012 110 104  5310      DB      NL,'HDS ASSEMBLER Issue #104.05.00.',ENL /78.12.GC/
5311
5312 *              GET THE CURRENT DATE
5313
070.207 315 141 061  5314      CALL    $MOVE1          /79.12.GC/
070.212 011 000      5315      DW      HEADCL          /79.12.GC/
070.214 277 040      5316      DW      S,DATE          /79.12.GC/
070.216 030 067      5317      DW      HEADC          /79.12.GC/
5318
5319 *              READ COMMAND LINE
5320
070.220 377 056      5321      PRS2    DB      SYSCALL+,CLEARA CLEAR ALL CHANNELS
070.222 257          5322      XRA      A
070.223 062 227 067  5323      STA      LISTFB+FB.FLG
070.226 062 262 067  5324      STA      SRCFB+FB.FLG  CLEAR FILE BUFFERS
070.231 061 200 042  5325      LXI      SP,STACK      CLEAN STACK
070.234 315 136 031  5326      CALL    $TYPTX
070.237 012 252      5327      DB      NL,'*'+2000
070.241 041 237 075  5328      LXI      H,LINE
070.244 315 063 061  5329      CALL    $RTL,          READ LINE /78.10.GC/
070.247 332 325 042  5330      JC      EXIT          CTL-D STRUCK
5331
5332 *              HAVE COMMAND LINE, DECODE SWITCHES
5333
070.252 315 004 072  5334      PRS3    CALL    SDV          SET DEFAULT VALUES
070.255 021 063 072  5335      LXI      B,SWITAB
070.260 041 237 075  5336      LXI      H,LINE
070.263 315 164 074  5337      CALL    $DRS          DECODE AND REMOVE SWITCHES
070.266 332 222 071  5338      JC      SW.ERR        SWITCH ERROR
5339
5340 *              HAVE CRACKED SWITCHES FROM COMMAND LINE, NOW DECODE FILE NAMES
5341
070.271 257          5342      XRA      A
070.272 062 150 067  5343      STA      BINFNAM      CLEAR BINARY FILE NAME
070.275 062 240 067  5344      STA      LISTFB+FB.NAM CLEAR LISTING FILE NAME
070.300 041 237 075  5345      LXI      H,LINE
070.303 176          5346      PRS4    MOV      A,M          CHECK FOR '='
070.304 376 075      5347      CPI      '='
070.306 043          5348      INX      H
070.307 312 324 070  5349      JE      PRS5          GOT '='
070.312 247          5350      ANA      A

```


070.313	302	303	070	5351	JNZ	PRS4	MORE TO CHECK
070.316	021	237	075	5352	LXI	D,LINE	NO LISTING OR BINARY
070.321	303	371	070	5353	JMP	PRS7	
				5354			
				5355	*	HAVE '='	HAS SPECIFIED LISTING AND/OR BINARY
				5356			
070.324	021	237	075	5357	PRS5	LXI	D,LINE
070.327	041	150	067	5358	LXI	H,BINFNAM	
070.332	315	164	061	5359	CALL	\$CPF	COPY FILE NAME
070.335	332	143	071	5360	JC	PRS10	FORMAT ERROR
070.340	376	054		5361	CPI	' '	
070.342	302	356	070	5362	JNE	PRS6	NOT LISTING FILE
070.345	041	240	067	5363	LXI	H,LISTFB+FB,NAM	
070.350	315	164	061	5364	CALL	\$CPF	COPY FILE NAME
070.353	332	143	071	5365	JC	PRS10	FNAME ERROR
070.356	376	075		5366	PRS6	CPI	'='
070.360	302	174	071	5367	JNE	PRS11	FORMAT ERROR
070.363	315	261	071	5368	CALL	ODF	OPEN OUTPUT FILES
070.366	332	220	070	5369	JC	PRS2	ERROR
				5370			
				5371	*	CRACK SOURCE FILE LIST.	
				5372			
070.371	041	273	067	5373	PRS7	LXI	H,SORCFB+FB,NAM
070.374	315	164	061	5374	CALL	\$CPF	COPY FILE NAME
070.377	041	273	067	5375	LXI	H,SORCFB+FB,NAM	
071.002	021	377	074	5376	LXI	D,DEFAULTI	
071.005	001	074	070	5377	LXI	B,EXPWRK	
071.010	377	053		5378	DB	SYSCALL, .DECODE	GET DEVICE INFO ABOUT INPUT FILE
071.012	072	074	070	5379	LDA	EXPWRK+0	(A) = DEVICE CODE
071.015	346	001		5380	ANI	DT,DD	
071.017	312	061	071	5381	JZ	PRS9	NOT DIRECTORY DEVICE
071.022	041	261	067	5382	LXI	H,SORCFB	
071.025	021	377	074	5383	LXI	D,DEFAULTI	(DE) = INPUT DEFAULT POINTER
071.030	315	337	061	5384	CALL	\$FOPER,	
071.033	322	044	071	5385	JNC	PRS8	ALL OK
071.036	315	344	071	5386	CALL	FFE	PRESET FILE ERROR
071.041	303	220	070	5387	JMP	PRS2	RE-TRY
				5388			
				5389	*	SETUP LINCNT SO THE FIRST PAGE TITLE DOES NOT EJECT ANY PAPER.	
				5390	*	(THIS HAS NO EFFECT IF AM USING FORMFEEDS TO EJECT PAPER)	
				5391			
071.044	072	214	067	5392	PRS8	LDA	PAGEDP
071.047	041	215	067	5393	LXI	H,FORMDP	
071.052	226			5394	SUB	M	(A) = FUNNY LINCNT TO CREATE 0 SKIP COUNT
071.053	062	351	067	5395	STA	LINCNT	IN *FNFX
071.056	303	200	042	5396	JMP	START	START ASSEMBLY
				5397			
				5398	*	INPUT FILE NOT ON DIRECTORY DEVICE	
				5399			
071.061	315	136	031	5400	PRS9	CALL	\$TYPTX
071.064	007	123	157	5401	DB	BELL, 'Source File Must be on SY0;, SY1;, or SY2; ,2000	
071.140	303	220	070	5402	JMP	PRS2	TRY AGAIN
				5403			
				5404	*	ERROR IN FILE NAME	
				5405			
071.143	315	136	031	5406	PRS10	CALL	\$TYPTX

```
071.146 007 111 154 5407 DB BELL,'Illegal File Name',2000  
071.171 303 220 070 5408 JMP PRS2 TRY AGAIN  
5409  
5410 * ILLEGAL SYNTAX  
5411  
071.174 315 136 031 5412 PRS11 CALL $TYPTX  
071.177 007 111 154 5413 DB BELL,'Illegal Syntax',2000  
071.217 303 220 070 5414 JMP PRS2  
5415  
5416 * SWITCH ERROR  
5417  
071.222 315 136 031 5418 SW.ERR CALL $TYPTX  
071.225 007 111 154 5419 DB BELL,'Illegal Switch',ENL  
071.245 303 220 070 5420 JMP PRS2  
5421  
071.250 076 050 5422 PRSERR1 MVI A,EC.NCV NOT CORRECT VERSION OF HDOS  
5423  
071.252 046 012 5424 PRSERR MVI H,NL  
071.254 377 057 5425 DB SYSCALL,.ERROR  
071.256 257 5426 XRA A  
071.257 377 000 5427 DB SYSCALL,.EXIT  
5428
```

```

5432 ** DOF - OPEN OUTPUT FILES.
5433 *
5434 * DOF IS CALLED TO OPEN THE BINARY AND LISTING FILES,
5435 * TO THEIR RESPECTIVE CHANNELS.
5436 *
5437 * ENTRY BINFNAM = BINARY FILE NAME (=0 IF NONE)
5438 * LISTFB+FB.NAM = LISTING FILE NAME (=0 IF NONE)
5439 * EXIT 'C' CLEAR IF OK
5440 * 'E' SET IF ERROR
5441 * ERROR IS MESSAGED BY DOF
5442 * USES A,F
5443
5444
071.261 305 5445 DOF PUSH B SAVE REGISTERS
071.262 325 5446 PUSH D
071.263 345 5447 PUSH H
071.264 041 150 067 5448 LXI H,BINFNAM
071.267 176 5449 MOV A,M
071.270 247 5450 ANA A
071.271 312 311 071 5451 JZ OOF1 NO BINARY
5452
5453 * OPEN BINARY FILE
5454
071.274 021 363 074 5455 LXI D,DEFALTB
071.277 076 000 5456 MVI A,CN.BIN
071.301 377 043 5457 DB SYSCALL,OPENW
071.303 041 136 067 5458 LXI H,BINFNAM+FB.NAM
071.306 332 334 071 5459 JC OOF3 ERROR
5460
5461 * OPEN LISTING FILE
5462
071.311 041 226 067 5463 OOF1 LXI H,LISTFB
071.314 072 240 067 5464 LDA LISTFB+FB.NAM
071.317 247 5465 ANA A
071.320 312 340 071 5466 JZ OOF4 NONE TO OPEN
071.323 021 371 074 5467 LXI D,DEFALTL
071.326 315 342 061 5468 CALL $FOPEW. OPEN FOR WRITE
071.331 322 340 071 5469 JNC OOF4 NO ERROR
5470
5471 * ERROR IN FILE
5472
071.334 315 344 071 5473 OOF3 CALL PFE PRESE1 FILE ERROR
071.337 067 5474 STC
071.340 341 5475 OOF4 POP H
071.341 321 5476 POP D
071.342 301 5477 POP B
071.343 311 5478 RET

```

```

5480 **      FFE - PRESET FILE ERROR.
5481 *
5482 *      FFE IS CALLED TO PRINT AN ERROR MESSAGE.
5483 *
5484 *      ENTRY      (A) = CODE
5485 *                (HL) = FILE BLOCK ADDRESS (ONLY USED TO GET FB.NAM)
5486 *      EXIT      NONE
5487 *      USES      ALL
5488
5489
071.344 365 5490 FFE PUSH PSW SAVE CODE
071.345 315 136 031 5491 CALL $TYPTX
071.350 007 105 162 5492 DB BELL,'Error On File:','+2000
071.367 001 012 000 5493 LXI B,FB.NAM
071.372 011 5494 DAD B
071.373 315 051 061 5495 CALL $TYPLZ TYPE FNAME
071.376 361 5496 POP PSW
071.377 046 012 5497 MVI H,NL
072.001 377 057 5498 DB SYSCALL,'ERROR PRINT ERROR MEANING
072.003 311 5499 RET
  
```

```

5501 **      SDV - SET DEFAULT SWITCH VALUES.
5502 *
5503 *      SDV IS CALLED BY PRS TO SET ALL SWITCH FLAGS TO THEIR DEFAULT
5504 *      VALUES. THEIR VALUES CANNOT BE SIMPLY ASSEMBLED IN, BECAUSE
5505 *      AN INCORRECT COMMAND LINE SWITCH MAY CHANGE THEM. BEFORE
5506 *      THE ERROR IS DETECTED. SDV RESETS THEM FOR THE
5507 *      NEXT TRY.
5508 *
5509 *      ENTRY      NONE
5510 *      EXIT      NONE
5511 *      USES      A,F,H,L
5512
5513
072.004 076 074 5514 SDV MVI A,60
072.006 062 214 067 5515 STA PAGEDP SET PAGE DEPTH
072.011 257 5516 XRA A
072.012 062 215 067 5517 STA FORMDP USE PAGE FORM CONTROL
072.015 062 213 067 5518 STA WIDE CLEAR /WIDE SWITCH
072.020 062 131 067 5519 STA LSTCWS
072.023 057 5520 CMA
072.024 062 132 067 5521 STA LSTCTL
072.027 315 141 061 5522 CALL $MOVEL
072.032 022 000 041 5523 DW 18,SDVA,DEFAULT
000.000 5524 ERNZ DEFALTI-DEFALTI-6
000.000 5525 ERNZ DEFALTI-DEFALTI-6
072.040 311 5526 RET
5527
072.041 123 131 060 5528 SDVA DB 'SYOABS' DEFAULT FOR BINARY
072.047 123 131 060 5529 DB 'SYOLST' DEFAULT FOR LISTING
072.055 123 131 060 5530 DB 'SYOASM' DEFAULT FOR INPUT
  
```

```

5533 ** SWITCH TABLE.
5534 *
5535 * THIS TABLE CONTAINS DESCRIPTIONS FOR COMMAND SWITCHES.
5536 * SEE '$DRS' FOR A DESCRIPTION OF IT'S FORMAT.
5537
5538
072.063 5539 SWITAB DS 0
5540
5541 * /PAGE:NN
5542
072.063 120 301 307 5543 DB 'P','A'+2000,'G'+2000,'E'+2000,2000
072.070 143 072 5544 DW SW.PAG
5545
5546 * /FORM:NN
5547
072.072 106 317 322 5548 DB 'F','O'+2000,'R'+2000,'M'+2000,2000
072.077 217 072 5549 DW SW.FOR
5550
5551 * /WIDE
5552
072.101 127 311 304 5553 DB 'W','I'+2000,'D'+2000,'E'+2000,2000
072.106 275 072 5554 DW SW.WID
5555
5556 * /LON:CCC
5557
072.110 114 117 116 5558 DB 'LON',2000
072.114 131 073 5559 DW SW.LON
5560
5561 * /LOF:CCC
5562
072.116 114 117 106 5563 DB 'LOF',2000
072.122 206 073 5564 DW SW.LOF
5565
5566 * /LARGE
5567
072.124 114 101 322 5568 DB 'LA','R'+2000,'G'+2000,'E'+2000,2000
072.132 361 072 5569 DW SW.LAR
5570
5571 * /ERR
5572
072.134 105 122 122 5573 DB 'ERR',2000
072.140 046 073 5574 DW SW.ERS
5575
072.142 000 5576 DB 0 END OF TABLE
    
```

```

5578 ** SW.PAG - /PAGE:NN
5579
072.143 315 107 074 5580 SW.PAG CALL $DNS DECODE NUMERIC SWITCHES
072.146 332 157 072 5581 JC SW.PAG1 ERROR
072.151 173 5582 MOV A,E (A) = VALUE
072.152 247 5583 ANA A
072.153 062 214 067 5584 STA PAGEDP
072.156 300 5585 RNZ :0 IS ILLEGAL
    
```

072.157 315 136 031 5586 SW.FAG1 CALL \$TYPTX
 072.162 042 057 120 5587 DB '/PAGE!' Value is No Good 'r' '+2000
 072.214 303 222 071 5588 JMP SW.ERR

5590 ** SW.FOR - /FORM:NN

5591
 072.217 315 107 074 5592 SW.FOR CALL \$DNS. DECODE DECIMAL SWITCH
 072.222 332 233 072 5593 JC SW.FOR1
 072.225 173 5594 MOV A,r (A) = VALUE
 072.226 042 215 067 5595 STA FORMDP
 072.231 247 5596 ANA A
 072.232 300 5597 RNZ VALUE OF 0 ILLEGAL
 072.233 315 136 031 5598 SW.FOR1 CALL \$TYPTX
 072.236 042 057 106 5599 DB '/FORM!' Value is No Good '-', '+2000
 072.272 303 222 071 5600 JMP SW.ERR

5602 ** SW.WID - /WIDE

5603
 072.275 312 306 072 5604 SW.WID JE SW.WID1 NO VALUE ALLOWED
 072.300 076 001 5605 MVI A,r
 072.302 062 213 067 5606 STA WIDE
 072.305 311 5607 RET
 5608
 072.306 315 136 031 5609 SW.WID1 CALL \$TYPTX
 072.311 111 155 160 5610 DB 'Improper Format For '/WIDE' Switch -', '+2000
 072.356 303 222 071 5611 JMP SW.ERR

5613 ** SW.LAR - /LARGE

5614
 072.361 312 372 072 5615 SW.LAR JE SW.LAR1 NO VALUE ALLOWED
 072.364 076 001 5616 MVI A,r
 072.366 042 147 047 5617 STA LARGE
 072.371 311 5618 RET
 5619
 072.372 315 136 031 5620 SW.LAR1 CALL \$TYPTX
 072.375 111 155 160 5621 DB 'Improper Format for '/LARGE' Switch -', '+2000
 073.043 303 222 071 5622 JMP SW.ERR

5624 ** SW.ERS - /ERR

5625
 073.046 312 057 073 5626 SW.ERS JE SW.ERS1 NO VALUE ALLOWED
 073.051 076 001 5627 MVI A,r
 073.053 062 125 067 5628 STA ERRSHO
 073.056 311 5629 RET
 5630
 073.057 315 136 031 5631 SW.ERS1 CALL \$TYPTX
 073.062 111 155 160 5632 DB 'Improper Format for '/ERR' Switch -', '+2000
 073.126 303 222 071 5633 JMP SW.ERR

```

5635 ** SW.LON - /LON:CC
5636
073.131 315 264 073 5637 SW.LON CALL DLS DECODE LISTING SWITCHES
073.134 332 145 073 5638 JC SW.LON1
073.137 041 131 067 5639 LXI H,LSTCTLS
073.142 266 5640 ORA M
073.143 167 5641 MOV M,A SET SWITCHES
073.144 311 5642 RET
5643
073.145 315 136 031 5644 SW.LON1 CALL $TYPTX
073.150 042 057 114 5645 DB '**/LON1: Value is No Good -',/ +2000
073.203 303 222 071 5646 JMP SW.ERR
    
```

```

5648 ** SW.LOF - /LOF:CC
5649
073.206 315 264 073 5650 SW.LOF CALL DLS DECODE LISTING SWITCHES
073.211 332 223 073 5651 JC SW.LOF1
073.214 041 132 067 5652 LXI H,LSTCTLC
073.217 057 5653 CMA
073.220 246 5654 ANA M
073.221 167 5655 MOV M,A SET 0 BITS FOR SPECIFIED OPTIONS
073.222 311 5656 RET
5657
073.223 315 136 031 5658 SW.LOF1 CALL $TYPTX
073.226 042 057 114 5659 DB '**/LOF: Value is No Good -',/ +2000
073.261 303 222 071 5660 JMP SW.ERR
    
```

```

5662 ** DLS - DECODE LISTING SWITCHES.
5663 *
5664 * DLS IS CALLED TO DECODE THE SPECIFIED LIST SUBOPTIONS FOR THE /LON
5665 * AND THE /LOF SWITCHES.
5666 *
5667 * THE OPTIONS ARE ANALYZED, AND REPLACED WITH BLANKS
5668 *
5669 * ENTRY (HL) = ADDRESS OF ':CCC'
5670 * EXIT 'C' CLEAR IF OK
5671 * (A) = BITS SET FOR EACH SPECIFIED OPTION
5672 * 'C' SET IF ERROR
5673 * USES ALL
5674
5675
073.264 176 5676 DLS MOV A,M (A) = SUPPOSED '?'
073.265 376 072 5677 CPI '!' CHECK UP ON HIM
073.267 067 5678 STC
073.270 300 5679 RNE NOT '!'
073.271 353 5680 XCHG (DE) = ADDRESS
073.272 006 000 5681 MVI B,0
5682
5683 * DECODE NEXT SWITCH
5684
073.274 076 040 5685 DLS1 MVI A,' '
    
```

073.276	022		5686	STAX	D	CLEAR THAT ONE
073.277	023		5687	INX	D	
073.300	032		5688	LDAX	D	
073.301	376	040	5689	CPI	''	
073.303	312	274 073	5690	JE	DLS1	SKIP
073.306	376	057	5691	CPI	''	
073.310	312	342 073	5692	JE	DLS2	DONE
073.313	376	054	5693	CPI	''	
073.315	312	342 073	5694	JE	DLS2	DONE
073.320	247		5695	ANA	A	
073.321	312	342 073	5696	JZ	DLS2	DONE
			5697			
			5698	*		MUST BE A SUBOPTION
			5699			
073.324	041	342 045	5700	LXI	H,LSTA	
073.327	315	261 061	5701	CALL	*IRLS	
073.332	067		5702	STC		
073.333	300		5703	RNZ		NOT A GOOD OPTION
073.334	176		5704	MOV	A,M	
073.335	260		5705	ORA	B	SET FLAGS
073.336	107		5706	MOV	B,A	
073.337	303	274 073	5707	JMP	DLS1	GET ANOTHER
			5708			
			5709	*		ALL DONE
			5710			
073.342	170		5711	DLS2	MOV	A,B
073.343	247		5712	ANA	A	
073.344	067		5713	STC		
073.345	310		5714	RZ		NONE FOUND: ERROR
073.346	247		5715	ANA	A	CLEAR CARRY
073.347	311		5716	RET		RETURN WITH OK

073.350

5719

XTEXT CVD

5721X ** \$CVD - CHECK FOR VALID DIGIT.
 5722X *
 5723X * CVD EXAMINES A DIGIT TO SEE IF IT IS A VALID DECIMAL DIGIT.
 5724X *
 5725X * ENTRY (HL) = ADDRESS OF CHARACTER
 5726X * EXIT 'C' SET IF ILLEGAL
 5727X * (A) = VALUE
 5728X * USES A,F

073.350 176
 073.351 326 060
 073.353 330
 073.354 376 012
 073.356 077
 073.357 311
 073.360

5729X
 5730X
 5731X \$CVD MOV A,H (A) = CHARACTER
 5732X \$CVD. SUI '0'
 5733X RC ILLEGAL
 5734X CFI 9+1
 5735X CMC
 5736X RET
 5737 XTEXT MUB6

5739X ** \$MUB6 - MULTIPLY 8X16 UNSIGNED.

5740X *
 5741X * \$MUB6 MULTIPLIES A 16 BIT VALUE BY A 8
 5742X * BIT VALUE.
 5743X *

5744X * ENTRY (A) = MULTIPLIER
 5745X * (DE) = MULTIPLICAND
 5746X * EXIT (HL) = RESULT
 5747X * 'Z' SET IF NOT OVERFLOW
 5748X * USES A,F,H,L
 5749X *

031.007
 073.360

5750X
 5751X \$MUB6 EDU 31007A IN H17 ROM
 5752 XTEXT DNV

5754X ** \$DNV - DECODE NUMERIC VALUE.

5755X *
 5756X * \$DNV DECODES A NUMERIC VALUE (IN THE FORM OF AN ASCII STRING)
 5757X * INTO A BINARY NUMBER. THE MAXIMUM MAGNITUDE IS
 5758X * 85535D.
 5759X *

5760X * THE NUMBER MAY CONTAIN A PREFIX OF 'B' (BINARY)
 5761X * 'O' OR 'D' (OCTAL) OR 'D' (DECIMAL)

5762X *
 5763X * ENTRY (HL) = ADDRESS OF FIRST BYTE OF NUMBER
 5764X * (A) = DEFAULT BASE ('2' FOR BINARY, '10' FOR DECIMAL, ETC.)
 5765X * EXIT 'C' CLEAR IF OK

\$DNU

```

5766X *          (HL) ADVANCED FAST NUMBER (AND POSTRADIX)
5767X *          (DE) = VALUE
5768X *          C SET IF ERROR
5769X *          USES ALL
5770X
5771X
073.360 062 075 074 5772X $DNU STA $DNVA SET DEFAULT BASE
073.363 104          5773X MOV B,H
073.364 115          5774X MOV C,L (BC) = TEXT ADDRESS
5775X
5776X *          SCAN FOR POSTRADIX
5777X
073.365 176          5778X $DNU1 MOV A,M
073.366 315 351 073 5779X CALL $CVD CHECK FOR VALID DECIMAL DIGIT
073.371 043          5780X INX H
073.372 322 365 073 5781X JNC $DNU1 MORE TO GO
073.375 053          5782X DCX H REMOVE EXTRA INCREMENT
073.376 171          5783X MOV A,C
073.377 275          5784X CMP L SEE IF THERE WERE ANY NUMBERS
074.000 067          5785X STC ASSUME NOT
074.001 310          5786X RE ERROR
5787X
5788X *          OUT OF NUMBERS. SEE IF POSTRADIX FOLLOWS
5789X
074.002 176          5790X MOV A,M (A) = PROPOSED POSTRADIX
074.003 345          5791X PUSH H SAVE END ADDRESS
074.004 041 076 074 5792X LXI H,$DNUB
074.007 247          5793X ANA A
074.010 312 030 074 5794X JZ $DNU2 NO POSTRADIX
074.013 315 261 061 5795X CALL $TBLS
074.016 176          5796X MOV A,M
074.017 302 030 074 5797X JNE $DNU2 NOT POSTRADIX
074.022 341          5798X POP H
074.023 043          5799X INX H SKIP POSTRADIX
074.024 345          5800X PUSH H
074.025 062 075 074 5801X STA $DNVA SET NEW POSTRADIX
074.030 021 000 000 5802X $DNU2 LXI B,0 (DE) = ACCUMULATOR
5803X
5804X *          BUILD NUMBER
5805X
074.033 072 075 074 5806X $DNU3 LDA $DNVA (A) = BASE
074.036 365          5807X PUSH PSW SAVE BASE
074.037 315 007 031 5808X CALL $MUB6 MULTIPLY
074.042 321          5809X POP D (D) = BASE
074.043 332 073 074 5810X JC $DNVA OVERFLOW
074.046 012          5811X LBAX B (A) = DIGIT
074.047 326 060          5812X SUI '0'
074.051 003          5813X INX B
074.052 272          5814X CMP D COMPARE TO BASE
074.053 077          5815X CMC
074.054 332 073 074 5816X JC $DNVA TOO LARGE A DIGIT
074.057 315 101 030 5817X CALL $DADA ADD TO VALUE
074.062 353          5818X XCHG (DE) = VALUE
074.063 012          5819X LBAX B
074.064 315 351 073 5820X CALL $CVD
074.067 322 033 074 5821X JNC $DNU3 MORE TO GO

```

\$DNV

074.072	247	5822X	ANA	A	CLEAR CARRY
074.073	341	5823X \$DNV4	POP	H	RESTORE POINTER
074.074	311	5824X	RET		EXIT
		5825X			
074.075	000	5826X \$DNVA	DB	0	DEFAULT BASE
074.076	102 002	5827X \$DNVB	DB	'B',2	POSTRADIX TABLE
074.100	117 010	5828X	DB	'0',8	
074.102	121 010	5829X	DB	'Q',8	
074.104	104 012	5830X	DB	'D',10	
074.106	000	5831X	DB	0	
074.107		5832	XTEXT	DNS	
		5834X **	\$DNS - DECODE NUMERIC SWITCH.		
		5835X *			
		5836X *	\$DNS DECODES A NUMERIC SWITCH OF THE FORM:		
		5837X *			
		5838X *	:ANN		
		5839X *			
		5840X *	A POSTRADIX OF D, Q, O, OR B IS ALLOWED, IF THE VALUE		
		5841X *	IS SYNTACTICALLY VALID, IT IS REPLACED WITH BLANKS.		
		5842X *			
		5843X *	ENTRY (HL) = ADDRESS IF ':'		
		5844X *	(A) = DEFAULT BASE (2, 8 OR 10)		
		5845X *	EXIT 'C' CLEAR IF OK		
		5846X *	(HL) ADVANCED PAST VALUE		
		5847X *	VALUE BLANKED		
		5848X *	(DE) = VALUE		
		5849X *	'C' SET IF ERROR		
		5850X *	USES ALL		
		5851X			
		5852X			
074.107	076 012	5853X \$DNS.	MVI	A,10	BASE 10 DEFAULT
074.111	107	5854X \$DNS	MOV	B,A	(B) = DEFAULT BASE
074.112	176	5855X	MOV	A,M	
074.113	376 072	5856X	CPI	::'	
074.115	067	5857X	STC		
074.116	300	5858X	RNE		NOT ::'
074.117	345	5859X	PUSH	H	SAVE ADDRESS OF SWITCH START
074.120	043	5860X	INX	H	
074.121	170	5861X	MOV	A,B	
074.122	315 360 073	5862X	CALL	\$DNV	DECODE NUMERIC VALUE
074.125	301	5863X	POP	B	(BC) = ADDRESS OF ':'
074.126	330	5864X	RC		ERROR
074.127	076 040	5865X \$DNS1	MVI	A,'	
074.131	002	5866X	STAX	B	BLANK LINE
074.132	003	5867X	INX	B	INCREMENT ADDRESS
074.133	175	5868X	MOV	A,L	
074.134	271	5869X	CMF	C	
074.135	302 127 074	5870X	JNE	\$DNS1	
074.140	170	5871X	MOV	A,B	
074.141	274	5872X	CMF	H	SEE IF IN RIGHT BANK
074.142	302 127 074	5873X	JNE	\$DNS1	
074.145	311	5874X	RET		RETURN WITH 'C' CLEAR AND VALUE

074.146

5875

XTEXT SOB

074.146 053
 074.147 043
 074.150 176
 074.151 376 040
 074.153 312 147 074
 074.156 376 011
 074.160 312 147 074
 074.163 311
 074.164

5877X ** \$SOB - SKIP OVER BLANKS.
 5878X *
 5879X * \$SOB IS CALLED TO SKIP AN ARBITRARILY LONG STRING OF BLANKS AND TABS.
 5880X *
 5881X * ENTRY (HL) = FWA OF (POSSIBLE) BLANK STRING
 5882X * EXIT (HL) = LWA+1 OF BLANK STRING (UNCHANGED IF NO BLANKS)
 5883X * (A) = FIRST NON-BLANK, NON-TAB CHARACTER EEN
 5884X * USES A,F,H,L
 5885X
 5886X
 5887X \$SOB DCX H PRE-DECREMENT
 5888X \$SOB1 INX H
 5889X MOV A,M
 5890X CPI ''
 5891X JE \$SOB1 GOT BLANK
 5892X CPI TAB
 5893X JE \$SOB1 GOT TAB
 5894X RET
 5895 XTEXT DRS

5897X ** \$DRS - DECODE AND REMOVE SWITCHES.
 5898X *
 5899X * \$DRS IS CALLED TO DECODE COMMAND SWITCHES FROM A LINE
 5900X * OF TEXT. SWITCHES TAKE THE FORM:
 5901X *
 5902X * /XXXXX
 5903X *
 5904X * AFTER A SWITCH HAS BEEN LOCATED, IT (AND THE PRECEDING '/')
 5905X * ARE REPLACED WITH BLANKS.
 5906X *
 5907X * VALID SWITCH DESCRIPTIONS ARE ENCODED INTO A TABLE
 5908X * SUPPLIED BY THE CALLER, IN THE FORMAT:
 5909X *
 5910X * DB 'X...X' REQUIRED SWITCH CHARACTERS
 5911X * DB 'C'+2000,...,'C'+2000 OPTIONAL CHARACTERS
 5912X * DB 2000 END OF CHARACTERS
 5913X * DW ADDR PROCESSOR ADDRESS (CALLED WHEN SWITCH DETECTED)
 5914X *
 5915X * DB 'Y...Y' NEXT SWITCH
 5916X *
 5917X *
 5918X *
 5919X *
 5920X * DB 0 FLAGS END OF TABLE
 5921X *
 5922X * SWITCHES MUST BE FOLLOWED BY A ':', A '/' (ANOTHER SWITCH)
 5923X * A ',', OR A 00 BYTE.
 5924X *

```

5925X *      UPON DETECTION OF A VALID SWITCH, $DRS CALLS THE USER PROCESS
5926X *      ROUTINE. UPON ENTRY,
5927X *      (HL) = ADDRESS OF THE FIRST BYTE FOLLOWING THE SWITCH
5928X *      'Z' CLEAR IF CHARACTER = '///', ' ', OR 00
5929X *      'Z' SET IF CHARACTER = '?'
5930X *
5931X *      THE USER ROUTINE CAN DECIDE SWITCH SUB-OPTIONS, IF DESIRED.
5932X *      THE USER ROUTINE MAY USE ALL REGISTERS.
5933X *
5934X *      ENTRY (DE) = SWITCH TABLE FWA
5935X *      (HL) = LINE FWA
5936X *      EXIT 'C' CLEAR IF OK
5937X *      'C' SET IF ERROR
5938X *      (HL) = ADDRESS OF START OF BAD SWITCH
5939X *      (A) = ERROR CODE
5940X *      USES ALL
5941X
5942X
074.164     5943X $DRS EQU *
5944X
5945X *      LOOK FOR SWITCHES
5946X
074.164 176 5947X $DRS1 MOV A,M
074.165 247 5948X ANA A
074.166 310 5949X RZ                               END OF LINE
074.167 043 5950X INX H
074.170 376 057 5951X CPI '///'
074.172 302 164 074 5952X JNE $DRS1 NOT A SWITCH
074.175 042 361 074 5953X SHLD $DRSB ($DRSB) = SWITCH FWA (AFTER '///')
5954X
5955X *      GOT A SWITCH. LOOK FOR A MATCH IN THE CALLER'S TABLE
5956X
074.200 325 5957X PUSH D SAVE TABLE FWA
074.201 052 361 074 5958X $DRS2 LHLD $DRSB (HL) = SWITCH FWA
074.204 032 5959X $DRS3 LDAX D (A) = TABLE ENTRY
074.205 346 177 5960X ANI 1770
074.207 312 257 074 5961X JZ $DRS6 GOT A MATCH
074.212 276 5962X CMP M
074.213 302 223 074 5963X JNE $DRS4 NO MATCH
074.216 023 5964X INX D
074.217 043 5965X INX H
074.220 303 204 074 5966X JMP $DRS3 SEE IF MORE MATCH
5967X
5968X *      HAVE MIS-MATCH. SEE IF THE MISSING CHARACTER IS SIGNIFICANT
5969X
074.223 176 5970X $DRS4 MOV A,M (A) = LINE CHARACTER WE COULDN'T MATCH
074.224 315 330 074 5971X CALL $DRS15 SEE IF 'OK' TERMINATOR
074.227 302 237 074 5972X JNE $DRS4.5 NO MATCH ON THIS SWITCH
074.232 032 5973X LDAX D (A) = NEXT CHARACTER IN SWITCH PATTERN
074.233 247 5974X ANA A
074.234 372 257 074 5975X JR $DRS6 HAVE SUFFICIENT MATCH
074.237 315 343 074 5976X $DRS4.5 CALL $DRS20 SKIP TABLE ENTRY
074.242 032 5977X LDAX D
074.243 247 5978X ANA A
074.244 302 201 074 5979X JNZ $DRS2 MORE SWITCHES IN TABLE TO CHECK
5980X

```

```

5981X *      BAD SWITCH
5982X
074.247 321 5983X $DRS5 POP      D      RESTORE STACK
074.250 052 361 074 5984X      LHL D $DRS6 POINT TO BAD SWITCH
074.253 067 5985X      STC
074.254 076 032 5986X      MVI  A,EC.IS  ILLEGAL SWITCH
074.256 311 5987X      RET
5988X
5989X *      HAVE SWITCH. CHECK IT'S FOLLOWING CHARACTER
5990X
074.257 315 146 074 5991X $DRS6 CALL   $SDB      SKIP OVER BLANKS
074.262 176 5992X      MOV   A,M
074.263 315 330 074 5993X      CALL  $DRS15 CHECK CHARACTER
074.266 302 247 074 5994X      JNE  $DRS5  IN ERROR
074.271 315 343 074 5995X      CALL  $DRS20 GET PROCESSOR ADDRESS
074.274 021 306 074 5996X      LXI  D,$DRS7
074.277 345 5997X      PUSH H      SAVE (HL)
074.300 325 5998X      PUSH D      SET RETURN ADDRESS FOR TABLE CODE
074.301 305 5999X      PUSH B      SAVE PROCESSOR ADDRESS
074.302 176 6000X      MOV   A,M      (A) = NEXT CHARACTER
074.303 376 072 6001X      CFI  '/'      SET CONDITION CODES
074.305 311 6002X      RET      CALL USER PROCESS
6003X
6004X *      USER PROCESS RETURNS HERE
6005X
074.306 321 6006X $DRS7 POP      D      (DE) = LAST CHARACTER OF SWITCH+1
074.307 052 361 074 6007X      LHL D $DRS6 (HL) = FIRST CHARACTER OF SWITCH AFTER /
074.312 053 6008X      DCX  H      (HL) = ADDRESS OF '/'
6009X
6010X *      REPLACE SWITCH WITH BLANKS
6011X
074.313 066 040 6012X $DRS8 MVI  M,' '
074.315 043 6013X      INX  H
074.316 315 216 030 6014X      CALL $CDEHL
074.321 302 313 074 6015X      JNE  $DRS8  NOT THERE YET
074.324 321 6016X      POP  D      (DE) = SWITCH TABLE FWA
074.325 303 164 074 6017X      JMP  $DRS1  LOOK FOR MORE SWITCHES

6019X **     $DRS15 - CHECK FOR VALID DELIMITER CHARACTER.
6020X *
6021X *      $DRS15 CHECKS THE NEXT TEXT CHARACTER TO SEE IF IT IS
6022X *
6023X *      00, '/', ',', '.', '!'
6024X *
6025X *      ENTRY (A) = CHARACTER
6026X *      EXIT 'Z' SET IFF CHARACTER IS ONE OF THE ABOVE
6027X *      USES F
6028X
074.330 247 6029X $DRS15 ANA  A
074.331 310 6030X      RZ      IS '00'
074.332 376 057 6031X      CPI  '/'
074.334 310 6032X      RE
074.335 376 054 6033X      CPI  ','
074.337 310 6034X      RE
074.340 376 072 6035X      CPI  '.'

```

```

074.342 311      6036X      RET
.....................................................................
6038X **        $DRS20 - GET PROCESSOR ADDRESS.
6039X *
6040X *        $DRS20 IS CALLED TO GET THE PROCESSOR ADDRESS FIELD OUT OF
6041X *        AN ENTRY IN THE SWITCH TABLE. THE CALLER SUPPLIES A POINTER
6042X *        TO SOMEWHERE IN THE TEXT PART OF THE SWITCH DESCRIPTION.
6043X *        $DRS20 ADVANCES THE POINTER TO THE PROCESSOR ADDRESS.
6044X *
6045X *        ENTRY (DE) = POINTER TO TEXT PART OF SWITCH ENTRY
6046X *        EXIT (DE) = POINTER TO 1ST BYTE OF NEXT SWITCH TABLE ENTRY
6047X *        (BC) = PROCESSOR ADDRESS FROM TABLE
6048X *        USES A:F,B:C,D,E.
6049X
6050X
074.343 032      6051X $DRS20 LDAX  D
074.344 023      6052X      INX  D
074.345 376 200  6053X      CPI  2000
074.347 302 343 079 6054X      JNE  $DRS20
074.352 032      6055X      LDAX  D          (A) = LOW BYTE OF PROCESSOR ADDRESS
074.353 117      6056X      MOV  C:A
074.354 023      6057X      INX  D
074.355 032      6058X      LDAX  D
074.356 107      6059X      MOV  B:A          (BC) = PROCESSOR ADDRESS
074.357 023      6060X      INX  D
074.360 311      6061X      RET
6062X
074.361 000 000  6063X $DRSB  DW   0          POINTER TO SWITCH BEING PROCESSED
6064
074.363          6065  DEFALTB DS   6          DEFAULTS FOR BINARY FILE NAME
074.371          6066  DEFALTL DS   6          DEFAULTS FOR LISTING FILE NAME
074.377          6067  DEFALTI DS   6          DEFAULTS FIR INPUT FILE NAME
6068
075.005          6069  MEML   EQU   *          LWA LOADED MEMORY
6070

```

	6073				
070.055	6074	ORG	PRS		THESE BUFFERS OVERLAY PRS
	6075				
	6076	**			STATEMENT UNPACK FIELDS, SETUP BY *UNL*.
	6077				
070.055	6078	DS	1		SMASHED IF NO LABEL
070.056	6079	LABEL DS	8		LABEL FIELD
070.066	6080	DS	1		SMASHED IF NO OPCODE
070.067	6081	OPCODE DS	5		OPCODE VALUE
070.074	6082	EXPWRK DS	99		EXPRESSION WORK-AREA /80.02.GC/
000.000	6083	ERRNZ	*-EXPWRK+1-LINEMAX		/80.02.GC/
070.074	6084	XTEXTB EQU	EXPWRK		XTEXTB SCRATCH BUFFER
	6085				
070.237	6086	BINBFR DS	256		BINARY BUFFER
002.000	6087	LISTBFL EQU	512		LISTING BUFFER SIZE
001.000	6088	SORCBFL EQU	256		SOURCE BUFFER SIZE
001.000	6089	XTXBFL EQU	256		XTEXT BUFFER SIZE
	6090				
071.237	6091	LISTBUF DS	LISTBFL		
073.237	6092	SORCBUF DS	SORCBFL		
074.237	6093	XTXBUF DS	XTXBFL		
	6094				
	6095				
	6096	*			BUFFERS USED BY PRESET
	6097				
377.146	6098	ERRPL	MEML-*		MUST NOT OVERLAY PRESET CODE
075.237	6099	LINE DS	100		LINE BUFFER
000.144	6100	LINEMAX EQU	*-LINE		MAX LENGTH
	6101				
076.003	6102	RMEML EQU	*		MEM LIMIT WHEN RUNNING *PRS*
	6103				
076.003	6104	SYNTAB EQU	*		START OF SYMBOL TABLE
	6105				
	6106				
076.003	6107	END			
ASSEMBLY COMPLETE					
6107 STATEMENTS					
0 ERRORS DETECTED					
8916 BYTES FREE					

CROSS REFERENCE TABLE

.CLEARA	000056	213L	5321				
.CLOSE	000046	205L	604	4394			
.CLRCD	000007	189L					
.CONSL	000006	188L	3708				
.CTLG	000041	200L	5290				
.DECODE	000053	210L	5378				
.DELET	000050	207L					
.DISHT	000061	216L					
.DMNMS	000203	227L					
.DMOUN	000201	225L					
.ERROR	000057	214L	2432	4947	5425	5498	
.EXIT	000000	182L	617	634	4296	4302	5427
.LINK	000040	189L					
.LOADD	000062	217L					
.LOADD	000010	190L					
.MONMS	000202	226L					
.MOUNT	000200	224L					
.NAME	000054	211L	1517				
.OFENC	000045	204L					
.OPENR	000042	201L	4313				
.OPENU	000044	203L	4315				
.OPENW	000043	202L	4314	5457			
.POSIT	000047	206L	2341	3343	3424		
.PRINT	000003	185L	614	2763			
.READ	000004	186L	2352	4877			
.RENAM	000051	208L					
.RESET	000204	228L					
.SCIN	000001	183L	3903				
.SCOUT	000002	184L	3907	4068			
.SETTP	000052	209L	2429	5286			
.SYSRES	000012	192L					
.VERS	000011	191L	5278				
.WRITE	000005	187L	2347	3645	4382	4678	4786
ABS.COD	000010	451L	567	1480	1483		
ABS.ENT	000006	449L					
ABS.IF	000000	445L					
ABS.LDA	000002	447L					
ABS.LEN	000004	448L					
ABSENT	047201	1333	5165L				
ABSFWA	047175	1456	1476	2311	2373	2382	5163L
ABSHDR	047173	1483	5161L				
ABSLN	047177	1479	5164L				
ABSLWA	047203	1474	2384	2391	5167L		
ABV	052070	594	598	2302L	3214		
ABVQ	052206	2342	2349L				
ABV00	052230	2353	2356L				
ABV1	052231	2325	2360L				
ABV2	052244	2309	2370L				
ABV3	052275	2381	2383L				
AIO.CGN	041047	410L					
AIO.CHA	041116	425L					
AIO.CNT	041111	421L					
AIO.CSI	041050	411L					
AIO.DDA	041041	406E					
AIO.DES	041055	415L					
AIO.DEV	041057	416L					
AIO.DIR	041062	419L					
AIO.DTA	041053	414L					

CNDFLG	067347	661	712	748	1140	1156	1169	5224L
CO.FLG	000001	305E	3707					
CODE	046164	797	1414E					
CODE0	046172	1415	1418L					
CODE1	046206	1422	1427L					
CODE2	046231	933	1430	1434	1443L			
CODE2.5	046273	1454	1460L					
CODE3	046341	1468	1490L					
CODEFLG	067146	665	928	1450	5150L			
COL	053100	1067	2525L	2771				
COL1	053123	2534	2542L					
COL2.5	053153	2555	2557L					
COL3	053205	2538	2569L					
CR	000015	76E						
CS.FLG	000200	306E						
CSL.CHR	000001	283E						
CSL.ECH	000200	281E						
CSL.WRF	000002	282E						
CT.ALPH	000200	53E	1984	3517				
CTB	063363	4565	4722	4749	4824L			
CTB1	063374	4830L	4839					
CTLA	000001	91E						
CTLB	000002	92E						
CTLC	000003	93E	5289					
CTLD	000004	94E	3869					
CTLO	000017	95E						
CTLP	000020	96E						
CTLQ	000021	97E						
CTLS	000023	98E						
CTLZ	000032	99E						
CTP.2SB	000010	291E						
CTP.BKM	000002	292E						
CTP.BNS	000200	288E						
CTP.MLI	000040	289E						
CTP.MLD	000020	290E						
CTP.TAB	000001	293E						
CUS	053212	2588L	3240	3315	3388			
D.CON	040110	243L						
D.RAM	040240	246L						
D.VEC	040130	245L						
DB	044116	780	942E					
DB1	044121	944L	988					
DB2	044131	956L	957					
DB3	044157	950	968L					
DB4	044172	960	962	964	976L			
DB5	044175	979L	981					
DB6	044206	972	985L					
DEF	053255	1377	1403	2639L	2695			
DEF0	053271	2641	2646L					
DEF1	053327	2656	2658	2665L				
DEFALTB	074363	5455	5523	5524	6065L			
DEFALTI	074377	5376	5383	5525	6067L			
DEFALTL	074371	5467	5524	5525	6066L			
DEV.DDA	000004	141L						
DEV.IVG	000016	153L						
DEV.DVL	000014	152L						
DEV.FLS	000006	142L						
DEV.JMP	000003	140L						

CROSS REFERENCE TABLE

DEV.MNU	000011	149L			
DEV.MUM	000010	148L			
DEV.NAM	000000	132L			
DEV.RES	000002	136L			
DEV.SPG	000007	147L			
DEV.UNT	000012	150L			
DEVELEN	000000	155E			
DF CLR	000376	108E			
D: MP	000377	107E			
DHD	053232	1904	2611L		
DHD1	053253	2614	2621L		
DIR.ALD	000025	123L			
DIR.CLU	000015	116L			
DIR.CRD	000023	122L			
DIR.EXT	000010	111L			
DIR.FGN	000020	119L			
DIR.FLG	000016	117L			
DIR.LGN	000021	120L			
DIR.LSI	000022	121L			
DIR.NAM	000000	110L			
DIR.PRO	000013	112L			
DIR.VER	000014	113L			
DIRELEN	000027	125E	419	557	
DIRIDL	000015	114E			
DLL	053335	718	1313	2683L	
DLL	053370	894	2707L	3202	
DLL0	054011	2715	2720L		
DLL1	054030	2723	2730L		
DLL2	054052	2738L	2744	2749	
DLL2.5	054074	2742	2753L		
DLL2.7	054112	2755	2762L		
DLL3	054130	2726	2758	2770E	
DLL4	054167	2775	2788L		
DLLB	054204	2736	2794E		
DLS	073264	5637	5650	5676L	
DLS1	073274	5685L	5690	5707	
DLS2	073342	5692	5694	5696	5711L
DNT	047346	1758E	2149	2165	2176
DNT1	050014	1775	1780L		
DNT10	050256	1901L	1927		
DNT11	050330	1903	1929L		
DNT12	050352	1905	1926	1943L	
DNT13	050353	1771	1779	1799	1947L
DNT14	050362	1935	1952L		
DNT15	050377	1938	1957	1963L	
DNT2	050017	1765	1785L		
DNT3	050061	1795	1811L		
DNT4	050070	1815L	1823		
DNT5	050110	1817	1827L		
DNT5.5	050135	1838	1842L		
DNT5.7	050154	1847	1850E		
DNT6	050163	1797	1860L		
DNT7	050170	1862L	1870		
DNT8	050210	1864	1874E		
DNT9	050233	1861	1888L		
DNTA	051004	1811	1860	1899	1968L
DNTB	050232	1884E			
DNTC	050333	1878	1932E		

TLLTXT	066234	1090	5089L	5090				
TTXTL	000062	1091	5090E					
UNL	057145	692	3448E	3472				
UNLO	057250	3465	3476	3483L				
UNLO.3	057277	3496L	3507					
UNLO.5	057305	3495	3501L					
UNLO.7	057323	3503	3511L					
UNLO.9	057351	3514	3518	3524L				
UNLOO	057225	3462	3474L					
UNL1	057364	3531L	3536					
UNL10	060060	3597L						
UNL2.5	060002	3547L						
UNL3	060015	3492	3526	3566L	3577			
UNL5	060047	3569	3572	3574	3586L			
UNL9	060057	3596L	3599	3601				
UNLA	060074	3481	3604L	3605				
UNLAL	000027	3481	3605E					
UNT.DIS	000005	164L						
UNT.FLG	000000	161L						
UNT.GRT	000001	162L						
UNT.GTS	000003	163L						
UNT.SIZ	000007	166E						
UDD1	061240	4077L	4107					
UOL	057116	943	1013	1322	3423L			
UOL	057121	888	3424L					
USERFWA	042200	255E	567	569	570	671	5165	
VER	000002	19E						
VER5	000026	173E	5280					
WBR	060123	602	2330	3621L				
WBR1	060126	3622L						
WBR2	060317	3627	3642L					
WIDE	067213	5176L	5518	5606				
XTEXT	046357	798	1505L					
XTEXT0	047021	1518	1523L					
XTEXT1	047064	1528	1534	1544L				
XTEXTA	047074	1513	1524	1548L				
XTEXTB	070074	1514	6084E					
XTEXTC	047102	1532	1549L					
XTEXTD	047105	1524	1550L					
XTXBFL	001000	5214	6089E	6093				
XTXBUF	074237	5211	5212	5213	5214	6093L		
XTXFB	067314	1511	1526	3463	5208L			
XTXFLB	067142	1323	1505	1545	3459	3471	5143L	
XTXLINE	067143	2488	2713	3460	5144L			

10064 BYTES FREE
