

4 *** BASIC - *WINTEK* BASIC INTERPRETER.
5 *
6 * J. G. LETWIN, 09/76, FOR *WINTEK* CORPORATION.
7 *
8 * H. W. SCHULTZ, 12/77, FOR HEATH CO.
9 *
10 * J. G. LETWIN, 1/78, FOR HEATH COMPANY
11 *
12 * G. Chandler, 78/10, for Heath Co.
13 * 79/12
14 * 80/02
15 *
16 *
17 *
18 * Issues:
19 *
20 * 110.01.00
21 * 110.02.00 /79.05.sc/
22 * 110.05.00 /79.12.GC/
23 * /80.02.GC/

25 *** COPYRIGHT 09/1976, *WINTEK* CORPORATION, LAFAYETTE, IND.
26 *
27 * COPYRIGHT 12/1977, 05/1979 HEATH CO.
28 *
29 * HEATH CO.
30 * BENTON HARBOR, MI
31 * 49022
32 *

36 **** ASSEMBLY CONSTANTS.
37
000.005 38 CHANMAX EQU 5 MAXIMUM CHANNEL # = 5

40 ** RUN MODE FLAGS.
41 *
42 * THESE ARE SET IN *RUNMODE*.
43
000.000 44 RM.IMM EQU 0 IMMEDIATE MODE
000.001 45 RM.STE EQU 01Q STEP MODE
000.004 46 RM.CON EQU 04Q CONTINUOUS MODE
000.200 47 RM.HLT EQU 200Q HALT EXECUTION

49 ** MACHINE INSTRUCTIONS.
50 *
51
000.200 52 MI.ADDB EQU 200Q ADD B
000.303 53 MI.JMP EQU 303Q JMP
000.077 54 MI.CMC EQU 077Q CMC
000.072 55 MI.LDA EQU 072Q LDA
000.076 56 MI.MVIA EQU 076Q MVI A
000.323 57 MI.OUT EQU 323Q OUT
000.220 58 MI.SUBB EQU 220Q SUB B
000.000 59 MI.NOP EQU 0 NOP
000.311 60 MI.RET EQU 311Q RET
000.333 61 MI.IN EQU 333Q IN
000.041 62 MI.LXIH EQU 041Q LXI H
000.021 63 MI.LXID EQU 021Q LXI D
000.001 64 MI.LXIB EQU 001Q LXI B

66 ** THE CT. SYMBOLS DEFINE INDEXED OF TOKENS.
67 *
68
69

70 ** CHARACTER TYPES.
71
000.000 72 ORG 0
73
000.000 74 CT.FIN DS 1 OO OR :
000.001 75 CT.ALP DS 1 ALPHABETIC
000.002 76 CT.NUM DS 1 NUMERIC
000.003 77 CT.SEP DS 1 UNSPECIFIED SEPERATOR
78

79 * THE FOLLOWING ARE NOT COMPRESSED IN THE TEXT INTO THESE TOKENS,
80 * BUT THE VARIOUS SCANNER ROUTINES RETURN THESE VALUES.
81
000.004 82 ERRMI 10Q-*
000.004 83 DS 10Q-*
000.010 84 DS 1 PLACE HOLDER TO POSITION CT.EQ
000.000 85 ERRNZ *-011Q REQUIRED FOR COMPARE PROCESSING

000.011	86	CT.ER	DS	1	=	1
000.012	87	CT.GT	DS	1	>	2
000.013	88	CT.GE	DS	1	>=	3
000.014	89	CT.LT	DS	1	<	4
000.015	90	CT.LE	DS	1	<=	5
000.016	91	CT.NE	DS	1	<>	6
	92					
000.017	93	CT.PAL	DS	1	(
000.020	94	CT.PAR	DS	1)	
000.021	95	CT.PL	DS	1	+	
000.022	96	CT.MI	DS	1	-	
000.023	97	CT.MU	DS	1	*	
000.024	98	CT.DI	DS	1	/	
000.025	99	CT.EX	DS	1	^	
000.026	100	CT.CMA	DS	1	,	
000.027	101	CT.SEM	DS	1	;	
000.030	102	CT.QUO	DS	1	"	
000.031	103	CT.PS	DS	1	#	
	104					
	105					
	106	**	BASIC VERBS AND KEYWORDS.			
	107					
	108					
000.200	109		ORG	2000		
000.200	110	CT.BLD	DS	1	BUILD	(MUST BE FIRST)
000.201	111	CT.BYE	DS	1	BYE	
000.202	112	CT.CNT	DS	1	CONTINUE	
000.203	113	CT.DEL	DS	1	DELETE	
000.204	114	CT.LIS	DS	1	LIST	
000.205	115	CT.REP	DS	1	REPLACE	
000.206	116	CT.RUN	DS	1	RUN	
000.207	117	CT.SAV	DS	1	SAVE	
000.210	118	CT.SCR	DS	1	SCRATCH	
000.211	119	CT.STE	DS	1	STEP	
	120					
000.212	121	CT.RUA	EGU	*	FOLLOWING COMMANDS 'RUN USAGE ALLOWED'	
	122					
000.212	123	CT.SYE	DS	1	SYNTAX ERROR	
000.213	124	CT.CHA	DS	1	CHAIN	
000.214	125	CT.CLR	DS	1	CLEAR	
000.215	126	CT.CLO	DS	1	CLOSE	
000.216	127	CT.CTL	DS	1	CTRL	
000.217	128	CT.DIM	DS	1	DIM	
000.220	129	CT.FN	DS	1	FN	
000.221	130	CT.FOR	DS	1	FOR	
000.222	131	CT.FRE	DS	1	FREE	
000.223	132	CT.FRZ	DS	1	FREEZE	
000.224	133	CT.GOS	DS	1	GOSUB	
000.225	134	CT.GOT	DS	1	GOTO	
000.226	135	CT.IF	DS	1	IF	
000.227	136	CT.LET	DS	1	LET	
000.230	137	CT.LCK	DS	1	LOCK	
000.231	138	CT.NXT	DS	1	NEXT	
000.232	139	CT.OLD	DS	1	OLD	
000.233	140	CT.ON	DS	1	ON	
000.234	141	CT.OPE	DS	1	OPEN	

000.235	142	CT.OUT	DS	1		OUT
000.236	143	CT.PAU	DS	1		PAUSE
000.237	144	CT.POK	DS	1		POKE
000.240	145	CT.PRT	DS	1		PRINT
000.241	146	CT.REA	DS	1		READ
000.242	147	CT.REM	DS	1		REMARK
000.243	148	CT.RES	DS	1		RESTORE
000.244	149	CT.RET	DS	1		RETURN
000.245	150	CT.UNF	DS	1		UNFREEZE
000.246	151	CT.UNL	DS	1		UNLOCK
000.247	152	CT.UNS	DS	1		UNSAVE
	153					
000.250	154	CT.IUA	EQU	*		PREVIOUS COMMANDS 'IMMEDIATE USAGE ALLOWED'
	155					
000.250	156	CT.LIN	DS	1		LINE
000.251	157	CT.DAT	DS	1		DATA
000.252	158	CT.DEF	DS	1		DEF
000.253	159	CT.END	DS	1		END
000.254	160	CT.INP	DS	1		INPUT
000.255	161	CT.STP	DS	1		STOP
	162					
000.256	163	CT.CMD	EQU	*		PREVIOUS ARE VALID COMMANDS
	164					
	165					
	166	**				BASIC PRE-DEFINED FUNCTIONS.
	167					
	168					
000.022	169	ERRMI	DS	3000-*		CHECK FOR OVERLAP
000.256	170		DS	3000-*		
	171					
	172	*				THE FOLLOWING BITS ARE DESCRIBED IN THE SYMTAB DOCUMENTATION.
	173	*				THEY ARE USED TO DECLARE VARIABLE TYPE.
	174					
000.001	175	CF.STR	EQU	00000001B		IS STRING (NOT NUMERIC)
000.002	176	CF.VEC	EQU	00000010B		IS VECTOR (NOT SCALAR)
000.004	177	CF.FCN	EQU	00000100B		IS FUNCTION (NOT VALUE)
	178					
	179					
	180					
	181	**				SYMBOL TYPE DECLARATIONS.
	182	*				
	183	*				USED IN SYMBOL TABLE AND BY LEXICAL.
	184					
	185					
000.300	186	CT.SNV	ORG	3000+0		
000.304	187	CT.SNF	ORG	3000+CF.FCN		SCALAR NUMERIC FUNCTION
000.301	188	CT.SSV	ORG	3000+CF.STR		SCALAR STRING VARIABLE
000.305	189	CT.SSF	ORG	3000+CF.STR+CF.FCN		SCALAR STRING FUNCTION
000.302	190	CT.VNV	ORG	3000+CF.VEC		VECTOR NUMERIC VARIABLE
000.303	191	CT.VSV	ORG	3000+CF.VEC+CF.STR		VECTOR STRING VALUE
000.300	192	CT.VARL	EQU	CT.SNV		LEAST VARIABLE INDEX
000.307	193	CT.VARH	EQU	3000+CF.VEC+CF.STR+CF.FCN		HIGH VARIABLE INDEX
000.310	194		ORG	3000+CF.VEC+CF.STR+CF.FCN+1		
	195					
	196					
	197	*				VARIOUS NON-FUNCTION KEYWORDS.

CTFLAG

	198				
000.310	199	CT.AND	DS	1	AND
000.311	200	CT.AS	DS	1	AS
000.312	201	CT.FIL	DS	1	FILE
000.313	202	CT.WRI	DS	1	WRITE
000.314	203	CT.NOT	DS	1	NOT
000.315	204	CT.OR	DS	1	OR
000.316	205	CT.THEN	DS	1	THEN
000.317	206	CT.TO	DS	1	TO
	207				
	208	*			FUNCTION DEFINITIONS
	209				
000.320	210	CT.FCN	EQU	*	ALL FUNCTIONS FOLLOW
	211				
000.320	212	CT.ABS	DS	1	ABS(
000.321	213	CT.ATN	DS	1	ATN(
000.322	214	CT.CHR	DS	1	CHR\$(
000.323	215	CT.CIN	DS	1	CIN(
000.324	216	CT.COS	DS	1	COS(
000.325	217	CT.EXP	DS	1	EXP(
000.326	218	CT.INT	DS	1	INT(
000.327	219	CT.LND	DS	1	LND(
000.330	220	CT.LOG	DS	1	LOG(
000.331	221	CT.MAX	DS	1	MAX(
000.332	222	CT.MIN	DS	1	MIN(
000.333	223	CT.PAD	DS	1	PAD(
000.334	224	CT.PEK	DS	1	PEEK(
000.335	225	CT.PIN	DS	1	PIN(
000.336	226	CT.POS	DS	1	POS(
000.337	227	CT.RND	DS	1	RND(
000.340	228	CT.SEG	DS	1	SEG(
000.341	229	CT.SGN	DS	1	SGN(
000.342	230	CT.SIN	DS	1	SIN(
000.343	231	CT.SPC	DS	1	SPC(
000.344	232	CT.SQR	DS	1	SQR(
000.345	233	CT.STR	DS	1	STR\$(
000.346	234	CT.TAB	DS	1	TAB(
000.347	235	CT.TAN	DS	1	TAN(
	236				
	237	*			THE FOLLOWING FUNCTIONS REQUIRE STRING ARGUMENTS.
	238				
000.350	239	CT.SRA	EQU	*	REQUIRE STRING ARGUMENTS
000.350	240	CT.ASC	DS	1	ASC(
000.351	241	CT.LEF	DS	1	LEFT\$(
000.352	242	CT.LEN	DS	1	LEN(
000.353	243	CT.MAT	DS	1	MATCH\$(
000.354	244	CT.MID	DS	1	MID\$(
000.355	245	CT.RIG	DS	1	RIGHT\$(
000.356	246	CT.VAL	DS	1	VAL(
000.357	247	CT.FNM	DS	0	MAX FUNCTION VALUE

000.357

249

XTEXT MTR

252X ** MTR - PAM/8 EQUIVALENCES.

253X *

254X *

255X *

THIS DECK CONTAINS SYMBOLIC DEFINITIONS USED TO
MAKE USE OF THE PAM/8 CODE AND CONTROL BYTES.

257X ** IO PORTS

258X

000.360

259X IP.FAD EQU

360R

PAD INPUT PORT

000.360

260X OP.CTL EQU

360R

CONTROL OUTPUT PORT

000.360

261X OP.DIG EQU

360R

DIGIT SELECT OUTPUT PORT

000.361

262X OP.SEG EQU

361R

SEGMENT SELECT OUTPUT PORT

264X ** FRONT PANEL CONTROL BITS.

265X

000.020

266X CB.SSI EQU

00010000B

SINGLE STEP INTERRUPT

000.040

267X CB.MTL EQU

00100000B

MONITOR LIGHT

000.100

268X CB.CLI EQU

01000000B

CLOCK INTERRUPT ENABLE

000.200

269X CB.SPK EQU

10000000B

SPEAKER ENABLE

271X ** MONITOR MODE FLAGS.

272X

000.000

273X DM.MR EQU

0

MEMORY READ

000.001

274X DM.MW EQU

1

MEMORY WRITE

000.002

275X DM.RR EQU

2

REGISTER READ

000.003

276X DM.RW EQU

3

REGISTER WRITE

278X ** USER OPTION BITS.

279X *

280X *

THESE BITS ARE SET IN CELL .MFLAG.

281X

000.200

282X UO.HLT EQU

10000000B

DISABLE HALT PROCESSING

000.100

283X UO.NFR EQU

CB.CLI

NO REFRESH OF FRONT PANEL

000.002

284X UO.DDU EQU

00000010B

DISABLE DISPLAY UPDATE

000.001

285X UO.CLK EQU

00000001B

ALLOW PRIVATE INTERRUPT PROCESSING

287X ** MONITOR IDENTIFICATION FLAGS

288X *

289X *

290X *

THESE BYTES IDENTIFY THE ROM MONITOR.
THEY ARE THE VARIOUS VALUES OF LOCATION .IDENT

291X

000.021

292X M.PAMB EQU

021Q

'LXI' INSTRUCTION AT 000.000 IN PAM-B

000.303

293X M.FOX EQU

303Q

'JMP' INSTRUCTION AT 000.000 IN FOX ROM

ENTRY

295X ** ROUTINE ENTRY POINTS.

296X *

297X

000.000	298X .IDENT	EQU	0000A	IDENTIFICATION LOCATION
000.053	299X .ILY	EQU	0053A	DELAY
001.267	300X .LOAD	EQU	1267A	TAPE LOAD
001.374	301X .DUMP	EQU	1374A	TAPE DUMP
002.136	302X .ALARM	EQU	2136A	ALARM ROUTINE
002.140	303X .HORN	EQU	2140A	HORN
002.172	304X .CTC	EQU	2172A	CHECK TAPE CHECKSUM
002.205	305X .TPERR	EQU	2205A	TAPE ERROR ROUTINE
002.264	306X .PCHL	EQU	2264A	PCHL INSTRUCTION
002.265	307X .SRS	EQU	2265A	SCAN RECORD START
002.325	308X .RNP	EQU	2325A	READ NEXT PAIR
002.331	309X .RNB	EQU	2331A	READ NEXT BYTE
002.347	310X .CRC	EQU	2347A	CRC-16 CALCULATOR
003.017	311X .WNP	EQU	3017A	WRITE NEXT PAIR
003.024	312X .WNB	EQU	3024A	WRITE NEXT BYTE
003.122	313X .DOD	EQU	3122A	DECODE FOR OCTAL DISPLAY
003.260	314X .RCK	EQU	3260A	READ CONSOLE KEYS
003.356	315X .DODA	EQU	3356A	SEGMENT CODE TABLE

317X ** RAM CELLS USED BY HBMTX.

318X *

319X

040.000	320X .START	EQU	40000A	START DUMP ADDRESS
040.002	321X .IOWRK	EQU	40002A	IN OR OUT INSTRUCTION
040.005	322X .REGI	EQU	40005A	DISPLAYED REGISTER INDEX
040.006	323X .DISPROT	EQU	40006A	PERIOD FLAG BYTE
040.007	324X .DISPMOD	EQU	40007A	DISPLAY MODE
040.010	325X .MFLAG	EQU	40010A	USER OPTION BYTE
040.011	326X .CTLFLG	EQU	40011A	PANEL CONTROL BYTE
040.013	327X .ALEDS	EQU	40013A	ABUSS LEDS
040.021	328X .DLEDS	EQU	40021A	DBUSS LEDS
040.024	329X .ABUSS	EQU	40024A	ABUSS REGISTER
040.027	330X .CRCSUM	EQU	40027A	CRCSUM WORD
040.031	331X .TPERRX	EQU	40031A	TAPE ERROR EXIT VECTOR
040.033	332X .TICCNT	EQU	40033A	CLOCK TICK COUNTER
040.035	333X .REGPTR	EQU	40035A	REGISTER POINTER
040.037	334X .UIVEC	EQU	40037A	USER INTERRUPT VECTORS
000.357	335	XTEXT	ASCII	

337X ** ASCII CHARACTER EQUIVALENCES.

338X

000.015	339X CR	EQU	13	CARRIAGE RETURN
000.012	340X LF	EQU	10	LINE FEED
000.200	341X NULL	EQU	2000	PAD CHARACTER
000.000	342X NUL2	EQU	0	
000.007	343X BELL	EQU	7	BELL CHARACTER
000.177	344X RUBOUT	EQU	1770	
000.010	345X BKSP	EQU	100	CTL-H
000.026	346X C.SYN	EQU	260	SYNC
000.002	347X C.STX	EQU	2	STX

000.047	348X QUOTE	EQU	470	
000.011	349X TAB	EQU	110	
000.033	350X ESC	EQU	330	
000.012	351X NL	EQU	120	NEW LINE (HDOS SYSTEMS)
000.212	352X ENL	EQU	NL+2000	NL + END-OF-LINE-FLAG
000.014	353X FF	EQU	140	FORM FEED
000.001	354X CTLA	EQU	010	CTL-A
000.002	355X CTLB	EQU	020	CTL-B
000.003	356X CTLC	EQU	030	CTL-C
000.004	357X CTLD	EQU	040	CTL-D
000.017	358X CTLO	EQU	170	CTL-O
000.020	359X CTLP	EQU	200	CTL-P
000.021	360X CTLQ	EQU	210	CTL-Q
000.023	361X CTLS	EQU	230	CTL-S
000.032	362X CTLZ	EQU	320	CTL-Z
000.357	363	XTEXT	BECDEF	

365X ** BASIC ERROR CODE DEFINITIONS.

000.200	368X	ORG	128	USE 128 AND ABOVE
000.200	369X BEC.CC	DS	1	CONTROL-C HIT
000.201	370X BEC.CB	DS	1	CONTROL-B HIT
000.202	371X BEC.DE	DS	1	DATA EXHAUSTED
000.203	372X BEC.DO	DS	1	/O
000.204	373X BEC.IN	DS	1	ILLEGAL NUMBER
000.205	374X BEC.IU	DS	1	ILLEGAL USAGE
000.206	375X BEC.LK	DS	1	DATA LOCK ENGAGED
000.207	376X BEC.NV	DS	1	NEXT VARIABLE MISSING
000.210	377X BEC.OV	DS	1	NUMERIC OVERFLOW
000.211	378X BEC.RE	DS	1	RETURN ERROR
000.212	379X BEC.SL	DS	1	STRING LENGTH
000.213	380X BEC.SN	DS	1	STATEMENT NUMBER
000.214	381X BEC.SY	DS	1	SYNTAX ERROR
000.215	382X BEC.TC	DS	1	TYPE CONFLICT
000.216	383X BEC.TO	DS	1	TABLE OVERFLOW
000.217	384X BEC.SR	DS	1	SUBSCRIPT RANGE
000.220	385X BEC.SC	DS	1	SUBSCRIPT COUNT
000.221	386X BEC.ND	DS	1	NOT DIMENSIONED
000.222	387X BEC.IC	DS	1	ILLEGAL CHARACTER
000.223	388X BEC.UD	DS	1	UNDEFINED FUNCTION
000.224	389X BEC.EN	DS	1	END
000.225	390X BEC.ST	DS	1	STOP
000.226	391X BEC.FAE	DS	1	FILE ALREADY EXISTS
000.227	392X BEC.ILF	DS	1	ILLEGAL FILE NAME
000.230	393X BEC.AC	DS	1	ILLEGAL ARGUMENT COUNT
000.231	394X BEC.FNO	DS	1	FILE NOT OPEN
000.232	395X BEC.LTL	DS	1	LINE TOO LONG
000.233	396X BEC.CIU	DS	1	CHANNEL IN USE
000.234	397	XTEXT	ECDEF	

	399X **	ERROR CODE DEFINITIONS.		
	400X			
000.000	401X	ORG	0	
000.000	402X	DS	1	NO ERROR #0
000.001	403X	EC.EOF	DS 1	END OF FILE
000.002	404X	EC.EOM	DS 1	END OF MEDIA
000.003	405X	EC.ILC	DS 1	ILLEGAL SYSCALL CODE
000.004	406X	EC.CNA	DS 1	CHANNEL NOT AVAILABLE
000.005	407X	EC.DNS	DS 1	DEVICE NOT SUITABLE
000.006	408X	EC.IDN	DS 1	ILLEGAL DEVICE NAME
000.007	409X	EC.IFN	DS 1	ILLEGAL FILE NAME
000.010	410X	EC.NRD	DS 1	NO ROOM FOR DEVICE DRIVER
000.011	411X	EC.FNO	DS 1	CHANNEL NOT OPEN
000.012	412X	EC.ILR	DS 1	ILLEGAL REQUEST
000.013	413X	EC.FUC	DS 1	FILE USAGE CONFLICT
000.014	414X	EC.FNF	DS 1	FILE NAME NOT FOUND
000.015	415X	EC.UND	DS 1	UNKNOWN DEVICE
000.016	416X	EC.ICN	DS 1	ILLEGAL CHANNEL NUMBER
000.017	417X	EC.DIF	DS 1	DIRECTORY FULL
000.020	418X	EC.IFC	DS 1	ILLEGAL FILE CONTENTS
000.021	419X	EC.NEM	DS 1	NOT ENOUGH MEMORY
000.022	420X	EC.RF	DS 1	READ FAILURE
000.023	421X	EC.WF	DS 1	WRITE FAILURE
000.024	422X	EC.WPV	DS 1	WRITE PROTECTION VIOLATION
000.025	423X	EC.WP	DS 1	DISK WRITE PROTECTED
000.026	424X	EC.FAP	DS 1	FILE ALREADY PRESENT
000.027	425X	EC.IDA	DS 1	DEVICE DRIVER ABORT
000.030	426X	EC.FL	DS 1	FILE LOCKED
000.031	427X	EC.FAO	DS 1	FILE ALREADY OPEN
000.032	428X	EC.IS	DS 1	ILLEGAL SWITCH
000.033	429X	EC.UUN	DS 1	UNKNOWN UNIT NUMBER
000.034	430X	EC.FNR	DS 1	FILE NAME REQUIRED
000.035	431X	EC.DIW	DS 1	DEVICE IS NOT WRITABLE (OR WRITE LOCKED)
000.036	432X	EC.UNA	DS 1	UNIT NOT AVAILABLE
000.037	433X	EC.ILV	DS 1	ILLEGAL VALUE
000.040	434X	EC.ILO	DS 1	ILLEGAL OPTION
000.041	435X	EC.VPM	DS 1	VOLUME PRESENTLY MOUNTED ON DEVICE
000.042	436X	EC.NVM	DS 1	NO VOLUME PRESENTLY MOUNTED
000.043	437X	EC.FOD	DS 1	FILE OPEN ON DEVICE
000.044	438X	EC.NPM	DS 1	NO PROVISIONS MADE FOR REMOUNTING MORE DISKS
000.045	439X	EC.DNI	DS 1	DISK NOT INITIALIZED
000.046	440X	EC.DNR	DS 1	DISK IS NOT READABLE
000.047	441X	EC.DSC	DS 1	DISK STRUCTURE IS CORRUPT
000.050	442X	EC.NCV	DS 1	NOT CORRECT VERSION OF HDOS
000.051	443X	EC.NDS	DS 1	NO OPERATING SYSTEM MOUNTED
000.052	444X	EC.IOI	DS 1	ILLEGAL OVERLAY INDEX
000.053	445X	EC.OTL	DS 1	OVERLAY TOO LARGE
000.054	446	XTEXT	FRDEF	

```

448X **      FILE BLOCK DEFINITIONS.
449X
000.000     450X      ORG      0
000.000     451X FB.CHA  DS      1      CHANNEL NUMBER
000.001     452X FB.FLG  DS      1      FLAGS
000.002     453X FB.FWA  DS      2      BUFFER FWA
000.004     454X FB.PTR  DS      2      BUFFER POINTER
000.006     455X FB.LIM  DS      2      LIMIT OF DATA IN BUFFER (READ OPERATIONS)
000.010     456X FB.LWA  DS      2      LWA OF BUFFER
000.012     457X FB.NAM  DS      4+8+4+1  NAME OF FILE
000.021     458X FB.NAML EQU     *-FB.NAM
000.033     459X FBENL  EQU     *      ENTRY LENGTH
000.033     460      XTEXT  DIRDEF
    
```

```

462X **      DIRECTORY ENTRY FORMAT.
463X
000.000     464X      ORG      0
465X
466X
000.377     467X DF.EMP  EQU     3770     FLAGS ENTRY EMPTY
000.376     468X DF.CLR  EQU     3760     FLAGS ENTRY EMPTY, REST OF DIR ALSO CLEAR
469X
000.000     470X DIR.NAM  DS      8      NAME
000.010     471X DIR.EXT  DS      3      EXTENSION
000.013     472X DIR.PROD DS      1      PROJECT
000.014     473X DIR.VER  DS      1      VERSION
000.015     474X DIRIDL  EQU     *      FILE IDENTIFICATION LENGTH
475X
000.015     476X DIR.CLU  DS      1      CLUSTER FACTOR
000.016     477X DIR.FLG  DS      1      FLAGS
000.017     478X      DS      1      RESERVED
000.020     479X DIR.FGN  DS      1      FIRST GROUP NUMBER
000.021     480X DIR.LGN  DS      1      LAST GROUP NUMBER
000.022     481X DIR.LSI  DS      1      LAST SECTOR INDEX (IN LAST GROUP)
000.023     482X DIR.CRD  DS      2      CREATION DATE
000.025     483X DIR.ALD  DS      2      LAST ALTERATION DATE
484X
000.027     485X DIRELEN EQU     *      DIRECTORY ENTRY LENGTH
000.027     486      XTEXT  IOCDEF
    
```

```

488X **      I/O CHANNEL DEFINITIONS.
489X
000.000     490X      ORG      0
491X
000.000     492X IOC.LNK  DS      2      ADDRESS OF NEXT CHANNEL, =0 IF LAST
000.002     493X IOC.DDA  DS      2      THREAD JUMP TO DEVICE DRIVER (VIA DEV TABLE)
494X
000.004     495X IOC.FLG  DS      1      FILE TYPE FLAGS
000.001     496X FT.DD  EQU     00000001B  =1 IF DIRECTORY DEVICE
000.002     497X FT.OR  EQU     00000010B  =1 IF OPEN FOR READ
000.004     498X FT.OW  EQU     00000100B  =1 IF OPEN FOR WRITE
000.010     499X FT.OU  EQU     00001000B  =1 IF OPEN FOR UPDATE
    
```

000.003	500X	IOC.SQL	ERU	*-IOC.DDA	LENGTH OF INFO FOR SEQUENTIAL FILE (FROM IOC)
	501X				
000.005	502X	IOC.GRT	DS	2	ADDRESS OF GROUP RESERVATION TABLE
000.007	503X	IOC.SPG	DS	1	SECTORS PER GROUP, THIS DEVICE
000.010	504X	IOC.CGN	DS	1	CURRENT GROUP NUMBER
000.011	505X	IOC.CSI	DS	1	CURRENT SECTOR INDEX (IN CURRENT GROUP)
000.012	506X	IOC.LGN	DS	1	LAST GROUP NUMBER
000.013	507X	IOC.LSI	DS	1	LAST SECTOR INDEX (IN LAST GROUP)
000.010	508X	IOC.DRL	ERU	*-IOC.FLG	LENGTH OF INFO NORMALLY COPIED BACK TO
	509X	*			THE CHANNEL TABLE
000.014	510X	IOC.BTA	DS	2	DEVICE TABLE ADDRESS FOR THIS DEVICE
000.016	511X	IOC.DES	DS	2	SECTOR NUMBER OF DIRECTORY ENTRY
000.020	512X	IOC.DEV	DS	2	DEVICE CODE
000.022	513X	IOC.UNI	DS	1	UNIT NUMBER (0-9)
000.021	514X	IOC.DIL	ERU	*-IOC.DDA	LENGTH OF INFO FOR DIRECTORY FILE (FROM IOC)
	515X				
000.023	516X	IOC.DIR	DS	DIRELEN	DIRECTORY ENTRY
	517X				
000.052	518X	IOCELEN	ERU	*	IOC ENTRY LENGTH
	519X				
000.001	520X	IOCCTD	ERU	1	INDEX OF USER CHANNEL #0 IN CHANTAB (FIRST = 0)
000.052	521	XTEXT		HOSDEF	

523X ** HOSDEF - DEFINE HOS PARAMETER,

524X *

525X

526X

000.026 527X VERS EQU 1*16+6 VERSION:1,6

528X

000.377 529X SYSCALL EQU 3770 SYSCALL INSTRUCTION

530X

531X

000.000 532X ORG 0

533X

534X * RESIDENT FUNCTIONS

535X

000.000 536X .EXIT DS 1 EXIT (MUST BE FIRST)

000.001 537X .SCIN DS 1 SCIN

000.002 538X .SCOUT DS 1 SCOUT

000.003 539X .PRINT DS 1 PRINT

000.004 540X .READ DS 1 READ

000.005 541X .WRITE DS 1 WRITE

000.006 542X .CONSL DS 1 SET/CLEAR CONSOLE OPTIONS

000.007 543X .CLRCO DS 1 CLEAR CONSOLE BUFFER

000.010 544X .LDADO DS 1 LOAD AN OVERLAY

000.011 545X .VERS DS 1 RETURN HDOS VERSION NUMBER

000.012 546X .SYSRES DS 1 PRECEDING FUNCTIONS ARE RESIDENT

547X

548X

549X * *HDOSVLO.SYS* FUNCTIONS

550X

000.040 551X ORG 40A

552X

000.040 553X .LINK DS 1 LINK (MUST BE FIRST)

000.041	554X	.CTLG	DS	1	CTL=C
000.042	555X	.OPENR	DS	1	OPENR
000.043	556X	.OPENW	DS	1	OPENW
000.044	557X	.OPENU	DS	1	OPENU
000.045	558X	.OPENC	DS	1	OPENC
000.046	559X	.CLOSE	DS	1	CLOSE
000.047	560X	.POSIT	DS	1	POSITION
000.050	561X	.DELET	DS	1	DELETE
000.051	562X	.RENAM	DS	1	RENAME
000.052	563X	.SETTP	DS	1	SETTOP
000.053	564X	.DECODE	DS	1	NAME DECODE
000.054	565X	.NAME	DS	1	GET FILE NAME FROM CHANNEL
000.055	566X	.CLEAR	DS	1	CLEAR CHAN
000.056	567X	.CLEARA	DS	1	CLEAR ALL CHANS
000.057	568X	.ERROR	DS	1	LOOKUP ERROR
000.060	569X	.CHFLG	DS	1	CHANGE FLAGS
000.061	570X	.DISMT	DS	1	FLAG SYSTEM DISK DISMOUNTED
000.062	571X	.LOADD	DS	1	LOAD DEVICE DRIVER
	572X				
	573X				
	574X	*	*HDSOVL1.SYS*	FUNCTIONS	
	575X				
000.200	576X		ORG	2000	
	577X				
000.200	578X	.MOUNT	DS	1	MOUNT (MUST BE FIRST)
000.201	579X	.DMOUN	DS	1	DISMOUNT
000.202	580X	.MONMS	DS	1	MOUNT/NO MESSAGE
000.203	581X	.DMNMS	DS	1	DISMOUNT/NO MESSAGE
000.204	582X	.RESET	DS	1	RESET = DISMOUNT/MOUNT OF UNIT
000.205	583	.XTEXT		OVLDEF	

585X ** OVERLAY TABLE ENTRYS.

	586X				
000.000	587X		ORG	0	
	588X				
000.000	589X	OVL.COD	DS	2	FIRST SECTOR OF OVERLAY CODE
000.002	590X	OVL.SIZ	DS	2	OVERLAY SIZE
000.004	591X	OVL.ENT	DS	2	OVERLAY ENTRY POINT
000.006	592X	OVL.FLB	DS	1	OVERLAY FLAG BYTE
000.007	593X		DS	1	DUMMY BYTE TO ROUND TABLE SIZE UP TO 8
000.010	594X	OVL.ENS	EQU	*	OVERLAY ENTRY SIZE
	595X				
	596X	*	OVERLAY INDICES		
	597X				
000.000	598X		ORG	0	
	599X				
000.000	600X	OVL0	DS	1	
000.001	601X	OVL1	DS	1	
000.002	602	.XTEXT		HOSSEQU	

```

604X **      HDOS SYSTEM EQUIVALENCES.
605X *
606X
024.000      607X S.GRT0 EQU    24000A      SYSTEM AREA FOR GRT0
025.000      608X S.GRT1 EQU    25000A      SYSTEM AREA FOR GRT1
026.000      609X S.GRT2 EQU    26000A      SYSTEM AREA FOR GRT2
610X
030.000      611X ROMBOOT EQU    30000A      ROM BOOT ENTRY
612X
040.100      613X          ORG    40100A      FREE SPACE FROM PAM-8
614X
040.100      615X          DS     8          JUMP TO SYSTEM EXIT
040.110      616X D.CON  DS     16         DISK CONSTANTS
040.130      617X SYDD   EQU    *          SYSTEM DISK ENTRY POINT
040.130      618X D.VEC  DS    24*3       SYSTEM ROM ENTRY VECTORS
040.240      619X D.RAM  DS     31         SYSTEM ROM WORK AREA
040.277      620X S.VAL  DS     36         SYSTEM VALUES
040.343      621X S.INT  DS    115        SYSTEM INTERNAL WORK AREAS
041.126      622X          DS     16
041.146      623X S.SQVR DS     2          STACK OVERFLOW WARNING
041.150      624X          DS   42200A-*   SYSTEM STACK
001.032      625X STACKL EQU    *-S,SQVR   STACK SIZE
626X
042.200      627X STACK  EQU    *          LWA+1 SYSTEM STACK
042.200      628X USERFWA EQU    *          USER FWA
042.200      629          XTEXT  ESWAL

```

```

631X **      S.VAL - SYSTEM VALUE DEFINITIONS.
632X *
633X *      THESE VALUES ARE SET AND MAINTAINED BY THE SYSTEM.
634X *
635X *      THE DECK HOSEQU MUST BE MODIFIED WHEN THIS IS MODIFIED.
636X
637X
040.277      638X          ORG    S.VAL
639X
040.277      640X S.DATE  DS     9          SYSTEM DATE (IN ASCII)
040.310      641X S.DATC  DS     2          CODED DATE
040.312      642X S.TIME  DS     4          TIME FROM MIDNIGHT (IN TICS)
040.316      643X S.HIMEM DS     2          HARDWARE HIGH MEMORY ADDRESS+1
644X
040.320      645X S.SYSM  DS     2          FWA RESIDENT SYSTEM
646X
040.322      647X S.USRM  DS     2          LWA USER MEMORY
648X
040.324      649X S.OMAX  DS     2          MAX OVERLAY SIZE FOR SYSTEM
650X
651X
652X **      THE FOLLOWING FIVE CELLS SHOULD BE MODIFIED/READ ONLY VIA THE ,CONSL SYSCALL
653X
000.200      654X CSL.ECH EQU    10000000B      SUPPRESS ECHO
000.002      655X CSL.WRP EQU    00000010B      WRAP LINES AT WIDTH
000.001      656X CSL.CHR EQU    00000001B      OPERATE IN CHARACTER MODE

```

```

657X
000.000 658X I.CSLMD EQU 0 S.CSLMD IS FIRST BYTE
040.326 659X S.CSLMD DS 1 CONSOLE MODE
660X
000.200 661X CTF.BKS EQU 10000000B TERMINAL PROCESSES BACKSPACES
000.040 662X CTF.MLI EQU 00100000B MAP LOWER CASE TO UPPER ON INPUT
000.020 663X CTF.MLO EQU 00010000B MAP LOWER CASE TO UPPER ON OUTPUT
000.010 664X CTF.2SB EQU 00001000B TERMINAL NEEDS TWO STOP BITS
000.002 665X CTF.BKM EQU 00000010B MAP BKSP (UPON INPUT) TO RUBOUT
000.001 666X CTF.TAB EQU 00000001B TERMINAL SUPPORTS TAB CHARACTERS
667X
000.001 668X I.CONTY EQU 1 S.CONTY IS 2ND BYTE
000.000 669X ERRNZ *-S.CSLMD-I.CONTY
040.327 670X S.CONTY DS 1 CONSOLE TYPE FLAGS
000.002 671X I.CUSOR EQU 2 S.CUSOR IS 3RD BYTE
000.000 672X ERRNZ *-S.CSLMD-I.CUSOR
040.330 673X S.CUSOR DS 1 CURRENT CURSOR POSITION
000.003 674X I.CONWI EQU 3 S.CONWI IS 4TH BYTE
000.000 675X ERRNZ *-S.CSLMD-I.CONWI
040.331 676X S.CONWI DS 1 CONSOLE WIDTH
677X
000.001 678X CO.FLG EQU 00000001B CTL-O FLAG
000.200 679X CS.FLG EQU 10000000B CTL-S FLAG
680X
000.004 681X I.CONFL EQU 4 S.CONFL IS 5TH BYTE
000.000 682X ERRNZ *-S.CSLMD-I.CONFL
040.332 683X S.CONFL DS 1 CONSOLE FLAGS
684X
040.333 685X S.CAADR DS 2 ADDRESS FOR ABORT PROCESSING (>256 IF VALID)
040.335 686X S.CCTAB DS 6 ADDR FOR CTL-A, CTL-B, CTL-C PROCESSING
040.343 687 XTEXT ESINT

```

689X ** S.INT - SYSTEM INTERNAL WORKAREA DEFINITIONS.

690X *

691X * THESE CELLS ARE REFERENCED BY OVERLAYS AND MAIN CODE, AND
692X * MUST THEREFORE RESIDE IN FIXED LOW MEMORY.

693X

694X

040.343

695X ORG S.INT

696X

697X ** CONSOLE STATUS FLAGS

698X

040.343

699X S.CDR DS 1 CONSOLE DESCRIPTOR BYTE

000.000

700X CDR.H85 EQU 00000000B

000.001

701X CDR.H84 EQU 00000001B =0 IF H8-5, =1 IF H8-4

040.344

702X S.BAUD DS 2 [0-14] H8-4 BAUD RATE, =0 IF H8-5

703X * [15] =1 IF BAUD RATE => 2 STOP BITS

704X

705X ** TABLE ADDRESS WORDS

706X

040.346

707X S.DLINK DS 2 ADDRESS OF DATA IN HDOS CODE

040.350

708X S.OFWA DS 2 FWA OVERLAY TABLE

040.352

709X S.CFWA DS 2 FWA CHANNEL TABLE

ESINT

040.354	710X	S.DFWA	DS	2	FWA DEVICE TABLE
040.356	711X	S.RFWA	DS	2	FWA RESIDENT HDOS CODE
	712X				
	713X	**			DEVICE DRIVER DELAYED LOAD FLAGS
	714X				
040.360	715X	S.DDLDA	DS	2	DRIVER LOAD ADDRESS (HIGH BYTE=0 IF NO LOAD PENDING)
040.362	716X	S.IDLEN	DS	2	CODE LENGTH IN BYTES
040.364	717X	S.DGRP	DS	1	GROUP NUMBER FOR DRIVER
040.365	718X		DS	1	HOLD PLACE
	719X	*S.DDSEC	DS	2	SECTOR NUMBER FOR DRIVER (* OBSOLETE ! *)
040.366	720X	S.DDDTA	DS	2	DEVICE'S ADDRESS IN DEVLST +DEV.RES
040.370	721X	S.DDOPC	DS	1	OPEN OP CODE PENDING
	722X				
	723X	**			OVERLAY MANAGEMENT FLAGS
	724X				
000.001	725X	OVL.IN	EGU	00000001B	IN MEMORY
000.002	726X	OVL.RES	EGU	00000010B	PERMINANTLY RESIDENT
000.014	727X	OVL.NUM	EGU	00001100B	OVERLAY NUMBER MASK
000.200	728X	OVL.UCS	EGU	10000000B	USER CODE SWAPPED FOR OVERLAY
	729X				
040.371	730X	S.OVLFL	DS	1	OVERLAY FLAG
040.372	731X	S.UCSF	DS	2	FWA SWAPPED USER CODE
040.374	732X	S.UCSL	DS	2	LENGTH SWAPPED USER CODE
040.376	733X	S.OVLS	DS	2	SIZE OF OVERLAY CODE
041.000	734X	S.OVLE	DS	2	ENTRY POINT OF OVERLAY CODE
	735X				
041.002	736X	S.SSN	DS	2	SWAP AREA SECTOR NUMBER
041.004	737X	S.OSN	DS	2	OVERLAY SECTOR NUMBER
	738X				
	739X	*			SYSCALL PROCESSING WORK AREAS
	740X				
041.006	741X	S.CACC	DS	1	(ACC) UPON SYSCALL
041.007	742X	S.CODE	DS	1	SYSCALL INDEX IN PROGRESS
	743X				
	744X	*			JUMPS TO ROUTINES IN RESIDENT HDOS CODE
	745X				
041.010	746X	S.JUMPS	DS	0	START OF DUMP VECTORS
041.010	747X	S.SDD	DS	3	JUMP TO STAND-IN DEVICE DRIVER
041.013	748X	S.FASER	DS	3	JUMP TO FATSERR (FATAL SYSTEM ERROR)
041.016	749X	S.DIREA	DS	3	JUMP TO DIREAD (DISK FILE READ)
041.021	750X	S.FCI	DS	3	JUMP TO FCI (FETCH CHANNEL INFO)
041.024	751X	S.SCI	DS	3	JUMP TO SCI (STORE CHANNEL INFO)
041.027	752X	S.GUP	DS	3	JUMP TO GUP (GET UNIT POINTER)
	753X				
041.032	754X	S.MOUNT	DS	1	<>0 IF THE SYSTEM DISK IS MOUNTED
041.033	755X	S.DCS	DS	1	DEFAULT CLUSTER SIZE-1
	756X				
041.034	757X	S.BOOTF	DS	1	BOOT FLAGS
000.001	758X	BOOT.P	EGU	00000001B	EXECUTE PROLOGUE UPON BOOTUP
	759X				
	760X	*			STACK VALUE SAVED FOR OVERLAY SYSCALLS
	761X				
041.035	762X	S.OVSTK	DS	2	VALUE OF SP UPON SYSCALLS USING OVERLAY
	763X				
041.037	764X		DS	1	RESERVED


```

766X ** ACTIVE I/O AREA.
767X *
768X * THE AIO,XXX AREA CONTAINS INFORMATION ABOUT THE I/O OPERATION
769X * CURRENTLY BEING PERFORMED. THE INFORMATION IS OBTAINED FROM
770X * THE CHANNEL TABLE, AND WILL BE RESTORED THERE WHEN DONE.
771X *
772X * NORMALLY, THE AIO,XXX INFORMATION WOULD BE OBTAINED DIRECTLY
773X * FROM VARIOUS SYSTEM TABLES VIA POINTER REGISTERS. SINCE THE
774X * 8080 HAS NO GOOD INDEXED ADDRESSING, THE DATA IS MANUALLY
775X * COPIED INTO THE AIO,XXX CELLS BEFORE PROCESSING, AND
776X * BACKDATED AFTER PROCESSING.
777X *
041.040 778X AIO.VEC DS 3 JUMP INSTRUCTION
041.041 779X AIO.DDA EQU *-2 DEVICE DRIVER ADDRESS
041.043 780X AIO.FLG DS 1 FLAG BYTE
041.044 781X AIO.GRT DS 2 ADDRESS OF GROUP RESERV TABLE
041.046 782X AIO.SPG DS 1 SECTORS PER GROUP
041.047 783X AIO.CGN DS 1 CURRENT GROUP NUMBER
041.050 784X AIO.CSI DS 1 CURRENT SECTOR INDEX
041.051 785X AIO.LGN DS 1 LAST GROUP NUMBER
041.052 786X AIO.LSI DS 1 LAST SECTOR INDEX
041.053 787X AIO.DTA DS 2 DEVICE TABLE ADDRESS
041.055 788X AIO.DES DS 2 DIRECTORY SECTOR
041.057 789X AIO.DEV DS 2 DEVICE CODE
041.061 790X AIO.UNI DS 1 UNIT NUMBER (0-9)
791X *
041.062 792X AIO.DIR DS DIRELEN DIRECTORY ENTRY
793X *
041.111 794X AIO.CNT DS 1 SECTOR COUNT
041.112 795X AIO.EDM DS 1 END OF MEDIA FLAG
041.113 796X AIO.EOF DS 1 END OF FILE FLAG
041.114 797X AIO.TFP DS 2 TEMP FILE POINTERS
041.116 798X AIO.CHA DS 2 ADDRESS OF CHANNEL BLOCK (IOC,DDA)
  
```

```

041.120 800X S.SCR DS 2 SYSTEM SCRATCH AREA ADDRESS
041.122 801 XTEXT MYRDEF
  
```

```

803X ** HDOS MONITOR PRIVATE RAM AREA DEFINITIONS.
804X *
000.000 805X ORG 0
000.000 806X M.SYSM DS 1 SYSCALL ITERATION COUNT
000.001 807X M.SALO DS 1 STAND-ALONE FLAG
000.002 808X M.CSLC DS 1 LINES IN CONSOLE BUFFER
000.003 809X M.CPRE DS 1 CONSOLE PREVIOUS CHARACTER
000.004 810X M.CRUB DS 1 CONSOLE RUBOUT FLAG
000.005 811X M.CINT DS 1 CONSOLE INTERRUPT FLAG
000.006 812X M.CIN DS 2 CONSOLE CB IN POINTER
000.010 813X M.COUT DS 2 CONSOLE CB OUT POINTER
000.012 814X M.CFWA DS 2 CONSOLE CB FWA POINTER
000.014 815X M.CLWA DS 2 CONSOLE CB LWA POINTER
  
```

000.016	816X	M.CDLY	DS	1	CONSOLE PAD CHARACTER COUNT
000.017	817X	M.CDCA	DS	2	ADDRESS OF CHARACTER BEING PADDED
000.021	818	XTEXT	FILDEF		

820X ** FILDEF - FILE TYPE DEFINITIONS.

	821X	*			
	822X	*	DB	3770,FT,XXX	
	823X				
	824X				
000.000	825X	FT,ABS	EQU	0	ABSOLUTE BINARY
000.001	826X	FT,FIC	EQU	1	POSITION INDEPENDANT CODE
000.002	827X	FT,REL	EQU	2	RELOCATABLE CODE
000.003	828X	FT,BAC	EQU	3	COMPILED BASIC CODE
000.021	829	XTEXT	ABSDEF		

831X ** ABS FORMAT EQUIVALENCES.

	832X				
000.000	833X		ORG	0	
	834X				
000.000	835X	ABS.ID	DS	1	3770 = BINARY FILE FLAG
000.001	836X		DS	1	FILE TYPE (FT,ABS)
000.002	837X	ABS.LDA	DS	2	LOAD ADDRESS
000.004	838X	ABS.LEN	DS	2	LENGTH OF ENTIRE RECORD
000.006	839X	ABS.ENT	DS	2	ENTRY POINT
	840X				
000.010	841X	ABS.COD	DS	0	CODE STARTS HERE

			844			
042.170			845	ORG	USERFWA-ABS.COD	
042.170	377	000	846	DB	3770.FT.ABS	ABS FILE
042.172	200	042	847	DW	USERFWA	LOAD ADDRESS
042.174	225	050	848	DW	LOADL-USERFWA	SIZE
042.176	210	112	849	DW	PRS	ENTRY
			850			
			852	**	LOW-MEMORY CELLS USED BY BASIC	
			853			
042.200			854	DS	2	ACCX TYPE
042.202			855	ACCX DS	4	
042.206			856	DS	2	ACCY TYPE
042.210			857	ACCY DS	4	
			858			
			859	**	SPECIAL LEXICAL VARIABLE AREA.	
			860	*		
			861	*	VARIABLES ARE STORED HERE SO THAT BASIC CAN QUICKLY TELL THAT	
			862	*	THEY DONT RESIDE IN THE SYMBOL TABLE BY SIMPLY CHECKING THE	
			863	*	BANK ADDRESS.	
			864			
042.214	000		865	DB	0	TYPE OF LEXC
042.215	000	000 000	866	LEXC DB	0,0,0,0	SPECIAL LEXICAL UNDEFINED VARIABLE VALUE
			867			
042.221	000		868	DB	0	TYPE OF LEXB
042.222	000	000 000	869	LEXB DB	0,0,0,0	SPECIAL LEXICAL CELL FOR NUMERIC LITERALS
			870			
042.226			871	LEXLIM EQU	*	ALL SYMTAB VARIABLES OCCUR IN HIGHER MEM
			873	**	FBLIST - FILE BLOCK LIST.	/80.02.sc/
			874	*		
			875	*	FBLIST CONTAINS THE FILE BLOCK FOR ALL POSSIBLE USER	
			876	*	CHANNELS, IN ORDER #1 TO #N.	
			877	*		
			878	*	THE FIRST ENTRY IN FBLIST IS NOT A USER ACCESSABLE FILE, BUT IS	
			879	*	THE SYSTEM'S INTERNAL WORK FILE.	
			880	*	THE 2ND ENTRY IS CHANNEL #2, THE 3RD CHANNEL #3, ETC.	
			881	*		
			882	*	NOTE: These tables were moved to the front to avoid problems	
			883	*	when overlays are loaded, etc.	/80.02.sc/
			884			
042.226	351	114	885	FBUFAD DW	MTAREA+3	CURRENT CONTENTS OF FILTAB+MT.FWA
			886			
042.230			887	FBLIST DS	0	
			888			
042.230	000	000	889	FBSR DB	0,0	CHANNEL AND STATUS
042.232	000	000 000	890	DW	0,0,0,0+512	USE *HDOS* SCRATCH RAM (PRS INITIALIZES IT)
042.242			891	DS	FB.NAML	
			892			
			893	*	CHANNEL #1	
			894			
042.263	001	000	895	DB	1,0	CHANNEL AND STATUS

042.265	351	114	351	896	DW	MTAREA+3,MTAREA+3,MTAREA+3,MTAREA+3+256
042.275				897	DS	FB.NAML
				898		
				899	*	CHANNEL #2
				900		
042.316	002.000			901	DB	2,0 CHANNEL AND STATUS
042.320	351	115	351	902	DW	MTAREA+3+256,MTAREA+3+256,MTAREA+3+256,MTAREA+3+256+256
042.330				903	DS	FB.NAML
				904		
				905	*	CHANNEL #3
				906		
042.351	003.000			907	DB	3,0 CHANNEL AND STATUS
042.353	351	116	351	908	DW	MTAREA+3+512,MTAREA+3+512,MTAREA+3+512,MTAREA+3+512+256
042.363				909	DS	FB.NAML
				910		
				911	*	CHANNEL #4
				912		
043.004	004.000			913	DB	4,0 CHANNEL AND STATUS
043.006	351	117	351	914	DW	MTAREA+3+768,MTAREA+3+768,MTAREA+3+768,MTAREA+3+768+256
043.016				915	DS	FB.NAML
				916		
				917	*	CHANNEL #5
				918		
043.037	005.000			919	DB	5,0 CHANNEL AND STATUS
043.041	351	120	351	920	DW	MTAREA+3+1024,MTAREA+3+1024,MTAREA+3+1024,MTAREA+3+1024+256
043.051				921	DS	FB.NAML

043.072	123	131	060	923	DEFAULT	DB	'SYOBAS'	PROGRAM FILE DEFAULTS	/80.02.GC/
043.100	123	131	060	924	DEFAULT	DB	'SYODAT'	DATA FILE DEFAULTS	/80.02.GC/

```

926 *** BASIC - MAIN EXEC LOOP.
927 *
928
043.106 929 START EQU *
043.106 041 370 100 930 LXI H,CBINT
043.111 076 002 931 MVI A,CTLB
043.113 377 041 932 DB SYSCALL,.CYLC SETUP CTL-B HANDLER
043.115 041 363 100 933 LXI H,CCINT
043.120 076 003 934 MVI A,CTLC
043.122 377 041 935 DB SYSCALL,.CTLC SETUP CTL-C HANDLER
936
937 ** ACCEPT COMMAND OR TEXT.
938
043.124 939 RESTART EQU * RESTART ADDRESS
940
941 * AM IN COMMAND MODE. RESTORE SYSTEM TO COMMAND MODE.
942
043.124 061 200 042 943 LXI SP,STACK RESTORE STACK POINTER
043.127 041 124 043 944 LXI H,RESTART
043.132 345 945 PUSH H SET *RETURN ADDRESS*
043.133 257 946 XRA A
000.000 947 ERRNZ MI,NOP
043.134 062 111 076 948 STA PNTC CLEAR TOKEN PIPELINE
043.137 062 142 112 949 STA CTLFLAG CLEAR CTL-C AND CTL-B FLAGS
043.142 062 326 040 950 STA S.CSLMD
000.000 951 ERRNZ RM,IMM
043.145 062 301 114 952 STA RUNMOD SET IMMEDIATE MODE
043.150 315 115 074 953 CALL FOC FILE OPEN CLEANUP
043.153 076 001 954 MVI A,1
043.155 062 253 112 955 STA COLCNTS+0 SET COLUMN NUMBER FOR CONSOLE (*PRINT* CMD)
043.160 315 354 111 956 CALL $CC0 CLEAR CTL-D
043.163 315 031 112 957 CALL $GNL GUARANTEE NEW LINE
043.166 315 136 031 958 CALL $TYPTX
043.171 252 959 DB '*+2000 PROMPT
043.172 315 364 065 960 CALL ICL INPUT COMMAND LINE
043.175 322 203 043 961 JNC BAS1 NO CTL-C HIT
962
963 * CTL-C HIT. CLEAR CONSOLE AND RESTART
964
043.200 377 007 965 DB SYSCALL,.CLRCO
043.202 311 966 RET RESTART START AGAIN
967
043.203 302 152 070 968 BAS1 JNZ ERR.SY SYNTAX ERROR IN STATEMENT /80.01.GC/
043.206 001 265 112 969 LXI B,LINE
043.211 315 230 072 970 CALL CNC CLASSIFY NEXT CHARACTER /80.01.GC/
043.214 247 971 ANA A SEE IF KEYWORD
043.215 372 233 043 972 JH BAS3 IS KEYWORD
043.220 376 002 973 CPI CT.NUM /80.01.GC/
043.222 302 240 043 974 JNZ BAS2 IS NOT A NUMBER /80.01.GC/
975
976 * HAVE STATEMENT WITH NUMBER.
977
043.225 315 021 045 978 CALL CLR1 CLEAR REFERENCES TO TEXT
043.230 303 270 070 979 JMP MTL INSERT TEXT LINE
980
981 * IS KEYWORD. SEE IF ALLOWED IMMEDIATE USAGE

```

			982						
043.233	376	250	983	BAS3	CPI	CT.IUA		IMMEDIATE USAGE ALLOWED?	
043.235	322	125	984		JNC	ERR.IU		ILLEGAL USAGE	
			985						
043.240	257		986	BAS2	XRA	A			
000.000			987		ERRNZ	RM.IMM		SET IMMEDIATE MODE	
			988	*	JMP	EXEC		EXECUTE IN IMMEDIATE MODE	

```

991 ** EXEC - EXECUTE BASIC STATEMENTS.
992 *
993 * EXEC CAUSES ONE OR MORE BASIC STATEMENTS TO BE EXECUTED.
994 *
995 * ENTRY (CURNUM) = CURRENT LINE NUMBER
996 * (CURADR) = CURRENT LINE ADDRESS
997 * (A) = RUN MODE CONTROL
998 * (BC) = TEXT START ADDRESS
999 * (STEP, IMMEDIATE, CONTINUOUS)
1000 * EXIT WHEN MODE CONTROL IS CLEARED, OR AT END OF LINE
1001 * FOR STEP AND IMMEDIATE MODES.
1002 * USES ALL
1003
1004
043.241 1005 EXEC EQU *
043.241 062 301 114 1006 STA RUNMOD SET RUN MODE
1007
1008 * PERFORM THE NEXT COMMAND.
1009
043.244 041 124 043 1010 EXEC1 LXI H,RESTART SET ABNORMAL EXIT ADDRESS
043.247 042 077 075 1011 SHLD ILMA
043.252 257 1012 XRA A
043.253 062 140 112 1013 STA IOCHAN SET OUTPUT TO CONSOLE
043.256 315 072 076 1014 CALL PNT PREVIEW NEXT TOKEN
000.000 1015 ERRNZ CT.FIN
043.261 247 1016 ANA A
043.262 302 372 043 1017 JNE EXEC3
043.265 315 056 071 1018 CALL ANT CLEAR 'PNT' PIPELINE
1019
1020 * END OF STATEMENT.
1021
043.270 1022 EXEC2 EQU *
043.270 315 201 044 1023 CALL EXEC7 SAVE CURRENT TEXT ADDRESS
1024
1025 * CHECK FOR CONTROL CHARACTERS.
1026
043.273 041 142 112 1027 LXI H,CTLFLAG
043.276 176 1028 MOV A,M
043.277 037 1029 RAR
043.300 332 106 070 1030 JC ERR.CC CONTROL-C HIT
043.303 037 1031 RAR
043.304 334 215 044 1032 CC EXEC8 USER INTERRUPT
1033
1034 * CHECK FOR HALT
1035
043.307 072 301 114 1036 LDA RUNMOD
043.312 147 1037 MOV H,A
043.313 247 1038 ANA A
000.000 1039 ERRNZ RM.HLT-2000
043.314 370 1040 RM AM TO HALT
1041
1042 * SETUP CORRECT DISPLAY MODE FOR FPLED5.
1043
043.315 076 000 1044 MVI A,0 (A) = MODE INDEX
043.316 1045 FPMODE EQU *-1
043.317 021 244 044 1046 LXI D,EXECA

```

043.322	203	1047	ADD	E	
043.323	137	1048	MOV	E,A	
043.324	032	1049	LDAX	D	(A) = FLAG VALUE
043.325	062 010 040	1050	STA	,MFLAG	SET TYPE OF DISPLAY
		1051			
		1052	*		CHECK TO SEE IF ANOTHER STATEMENT ON THIS LINE
		1053			
043.330	012	1054	LDAX	B	
043.331	003	1055	INX	B	
043.332	247	1056	ANA	A	
043.333	302 244 043	1057	JNZ	EXEC1	DO NEXT STATEMENT
043.336	174	1058	MOV	A,H	(A) = RUNMODE
043.337	247	1059	ANA	A	
000.000		1060	ERRNZ	RM.HLT-2000	REMOVE HALT FLAG
043.340	310	1061	RZ		IMMEDIATE MODE
		1062			
		1063	*		ADVANCE TO NEXT PROGRAM LINE.
		1064			
043.341	012	1065	LDAX	B	
043.342	003	1066	INX	B	
043.343	157	1067	MOV	L,A	SET LINE NUMBER
043.344	012	1068	LDAX	B	
043.345	003	1069	INX	B	
043.346	147	1070	MOV	H,A	
043.347	042 133 112	1071	SHLD	CURNUM	
043.352	245	1072	ANA	L	(A) = PRODUCT OF LINE NUMBER BYTES
043.353	074	1073	INR	A	
043.354	076 253	1074	MVI	A,CT,ENB	
043.356	312 040 044	1075	JZ	EXEC6	END OF TEXT - GENERATE 'END'
043.361	315 201 044	1076	CALL	EXEC7	
043.364	376 001	1077	CPI	RM,STE	
043.366	310	1078	RE		DONE STEPPING.
043.367	303 244 043	1079	JMP	EXEC1	PROCESS NEXT STATEMENT
		1080			
		1081	*		PROCESS LINE.
		1082			
043.372	315 007 044	1083	EXEC3	CALL	EXEC4
		1084			
		1085	*		RETURN FROM STATEMENT PROCESSOR. MUST HAVE END OF STATEMENT.
		1086			
043.375	315 305 077	1087	EXEC3.5	CALL	RNT
044.000	000	1088	DB	CT,FIN	REQUIRE CT,FIN
044.001	315 357 073	1089	CALL	DTS	DELETE TEMP STRINGS
044.004	303 270 043	1090	JMP	EXEC2	
		1091			
		1092			
044.007	376 200	1093	EXEC4	CPI	CT,BLD
044.011	332 125 070	1094	JC	ERR,IU	ILLEGAL USAGE
		1095			
044.014	376 256	1096	CPI	CT,CMD	
044.016	322 374 050	1097	JNC	LET	MUST BE 'LET', IS NOT COMMAND
		1098			
044.021	376 212	1099	CPI	CT,RUA	
044.023	322 035 044	1100	JNC	EXEC5	RUN USAGE ALLOWED
		1101			
044.026	072 301 114	1102	LDA	RUNMOD	

000.000			1103		ERRNZ	RM IMM	
044.031	247		1104		ANA	A	
044.032	302	125	070	1105	JNE	ERR.IU	ILLEGAL USAGE FOR IMMEDIATE MODE
			1106				
044.035	315	056	071	1107	EXEC5	CALL	ANT
044.040	326	200		1108	EXEC6	SUI	2000
044.042	315	061	031	1109		CALL	%TJMP
			1110				
044.045	247	044		1111	DW	BUILD	
044.047	337	044		1112	DW	BYE	
044.051	163	045		1113	DW	CONT	CONTINUE
044.053	162	046		1114	DW	DELETE	
044.055	020	051		1115	DW	LIST	
044.057	233	053		1116	DW	REPLACE	
044.061	155	045		1117	DW	RUN	
044.063	302	053		1118	DW	SAVE	
044.065	351	044		1119	DW	SCRATCH	
044.067	356	053		1120	DW	STEP	
			1121				
044.071	152	070		1122	DW	ERR.SY	LEXICAL SYNTAX ERROR FOUND
044.073	205	045		1123	DW	CHAIN	
044.075	363	044		1124	DW	CLEAR	
044.077	260	045		1125	DW	CLOSE	
044.101	320	045		1126	DW	CNTRL	CNTRL
044.103	236	046		1127	DW	DIM	DIMENSION
044.105	152	070		1128	DW	ERR.SY	FN
044.107	060	047		1129	DW	FOR	
044.111	213	047		1130	DW	FREE	
044.113	336	047		1131	DW	FREEZE	
044.115	026	050		1132	DW	GOSUB	
044.117	031	050		1133	DW	GOTO	
044.121	051	050		1134	DW	IF	
044.123	374	050		1135	DW	LET	
044.125	175	051		1136	DW	LOCK	
044.127	203	051		1137	DW	NEXT	
044.131	332	051		1138	DW	OLD	
044.133	355	051		1139	DW	ON	
044.135	036	052		1140	DW	OPEN	
044.137	220	052		1141	DW	OUT	
044.141	251	052		1142	DW	PAUSE	
044.143	336	052		1143	DW	POKE	
044.145	343	052		1144	DW	PRINT	
044.147	171	053		1145	DW	READ	
044.151	121	050		1146	DW	IF2	REM
044.153	053	045		1147	DW	RESTORE	
044.155	242	053		1148	DW	RETURN	
044.157	041	054		1149	DW	UNFREZ	UNFREEZE
044.161	176	051		1150	DW	UNLOCK	
044.163	065	054		1151	DW	UNSAVE	
			1152				
044.165	137	050		1153	DW	LINPUT	
044.167	342	077		1154	DW	SES	DATA
044.171	133	046		1155	DW	DEF	
044.173	044	047		1156	DW	END	
044.175	150	050		1157	DW	INPUT	
044.177	030	054		1158	DW	STOP	

```

1160 *      END OF EXEC SEQUENCE. SAVE TEXT POINTER.
1161
044.201 072 301 114 1162 EXEC7 LDA      RUNMOD
044.204 346 177 1163 ANI      377Q-RM,HLT
000.000 1164 ERRNZ  RM,IMM
044.206 310 1165 RZ
044.207 140 1166 MOV      H,B          AM IN IMMEDIATE MODE
044.210 151 1167 MOV      L,C          (HL) = TEXT ADDRESS
044.211 042 135 112 1168 SHLD   CURADR
044.214 311 1169 RET

1171 **     CTL-B (USER INTERRUPT) HIT
1172
044.215 021 000 000 1173 EXEC8 LXI      B,0          (DE) = INTERRUPT EXIT ADDRESS
044.216 1174 ACTLB EQU      *-2
044.220 172 1175 MOV      A,D
044.221 263 1176 ORA      E
044.222 312 111 070 1177 JZ      ERR,CB          NO USER PROCESSING
1178
1179 *      USER PROGRAM PROCESSING SPECIFIED.
1180
044.225 176 1181 EXEC9 MOV      A,M
044.226 346 375 1182 ANI      377R-CFCTLB
044.230 167 1183 MOV      M,A          CLEAR FLAG
044.231 341 1184 EXEC10 POP     H          DISCARD 'RETURN ADDRESS'
044.232 353 1185 XCHG
044.233 315 143 100 1186 CALL   SRA          (HL) = TEXT ADDRESS
044.236 315 042 050 1187 CALL   GOT02        SAVE TEXT RETURN ADDRESS
044.241 303 375 043 1188 JMP     EXEC3,5      PROCESS AS GOTO
1189 EXIT FROM GOSUB
1190 **     TABLE OF .MFLAG VALUES FOR DISPLAY CONTROL.
1191
044.244 301 1192 EXECA DB      U0.NFR+U0.HLT+U0.CLK  NO DISPLAY
044.245 203 1193 DB      U0.DDU+U0.HLT+U0.CLK  DISABLE UPDATE
044.246 201 1194 DB      U0.HLT+U0.CLK        LEAVE ON AND UPDATING
1195
000.044 1196 .      SET      */256
000.000 1197 ERRNZ  EXECA/256-,    ASSUME IN SAME BANK
1198

1201 **     BUILD - PROCESS BUILD COMMAND.
1202 *
1203 *      BUILD N,M
1204 *
1205 *      STARTING AT LINE N, INCREMENT BY M
1206
1207
044.247 1208 BUILD EQU      *
044.247 315 313 075 1209 CALL   LFC          CHECK FOR DATA LOCK
044.252 315 235 052 1210 CALL   OUT1         (DE) = INC, (HL) = VAL

```

```

044.255 325      1211 BLD1  PUSH  D      SAVE INC
044.256 345      1212      PUSH  H      SAVE NUMBER
044.257 353      1213      XCHG
044.260 315 206 072 1214      CALL  CLN      CHECK FOR LEGAL NUMBER
044.263 315 206 100 1215      CALL  TDI      TYPE LINE NUMBER
044.266 315 364 065 1216      CALL  ICL      ACCEPT NEW LINE
044.271 332 124 043 1217      JC    RESTART  CTL-C HIT
044.274 302 320 044 1218      JNZ   BLD2     ERROR IN LINE
044.277 041 265 112 1219      LXI   H,LINE
044.302 321      1220      POP   D
044.303 325      1221      PUSH  D      (DE) = NUMBER
044.304 315 304 070 1222      CALL  MTLO     INSERT TEXT LINE
044.307 341      1223      POP   H      (HL) = NUMBER
044.310 321      1224      POP   D      (DE) = INC
044.311 031      1225      DAD   D
044.312 332 122 070 1226      JC    ERR.IN  OVERFLOW
044.315 303 255 044 1227      JMP   BLD1
1228
1229 *          ERROR IN LINE
1230
044.320 315 136 031 1231 BLD2  CALL  $TYPTX
044.323 207      1232      DB    BELL+2000
044.324 076 214  1233      MVI   A,BEC.SY
044.326 046 012  1234      MVI   H,NL
044.330 377 057  1235      DB    SYSCALL,.ERROR SHOW ERROR
044.332 341      1236      POP   H
044.333 321      1237      POP   D
044.334 303 255 044 1238      JMP   BLD1  RE-TRY LINE ENTRY
  
```

```

1240 ***      BYE - RETURN TO HDOS.
1241 *
1242 *          BYE
1243
1244
044.337      1245 BYE  EQU   *
044.337 315 313 075 1246      CALL  LFC      CHECK FOR DATA LOCK
044.342 315 146 071 1247      CALL  AYS      ARE YOU SURE?
044.345 300      1248      RNE
044.346 257      1249      XRA   A      NOT SURE
044.347 377 000  1250      DB    SYSCALL,.EXIT  EXIT
  
```

```

1252 **      SCRAT - SCRATCH SYSTEM.
1253 *
1254 *          DESTROY TEXT, CLEAR VARIABLES.
1255
1256
044.351      1257 SCRATCH EQU *
044.351 315 313 075 1258      CALL  LFC      CHECK FOR DATA LOCK
044.354 315 146 071 1259      CALL  AYS      ARE YOU SURE?
044.357 300      1260      RNE
  
```

044.360 315 320 077 1261 SCR. CALL SCRA INSERT DUMMY LAST LINE INTO TEXT TABLE
 1262 * JMP CLEAR

1264 ** CLEAR - MASTER CLEAR.

1265 *

1266 *

CLEAR RESETS ALL CONTROL STRUCTURES:

1267 *

1268 *

1) GOSUB STACK

1269 *

2) 'FOR' STACK

1270 *

3) NEXT STATEMENT INDEX

1271 *

4) CLEAR VARIABLE LIST

1272 *

5) DATA POINTER

1273

1274

044.363

1275

CLEAR EQU *

044.363 315 313 075

1276

CALL LFC

CHECK FOR DATA LOCK

044.366 315 056 071

1277

CALL ANT

000.000

1278

ERRNZ CT,FIN

044.371 247

1279

ANA A

044.372 302 062 045

1280

JNZ CLR2

HAVE VARIABLE

044.375 315 357 073

1281

CLEAR CALL DTS

045.000 041 000 000

1282

LXI H,0

045.003 042 112 112

1283

SHLD STARTAB+MT,LEN

045.006 042 066 112

1284

SHLD SYMTAB+MT,LEN

045.011 056 200

1285

MVI L,2000

045.013 042 143 112

1286

SHLD STRVI

CLEAR STRING INDEX

045.016 315 171 072

1287

CALL CLF

CLEAR FILE STRUCTURES

1288

1289

1290 *

ENTRY POINT FOR ROUTINES TO CLEAR REFERENCES TO TXTTAB.

1291

045.021 041 000 000

1292

CLR1 LXI H,0

ENTRY TO JUST CLEAR TXTTAB REFERENCES

045.024 042 073 112

1293

SHLD FORTAB+MT,LEN

045.027 042 100 112

1294

SHLD GOSTAB+MT,LEN

045.032 042 105 112

1295

SHLD WRKTAB+MT,LEN

045.035 042 216 044

1296

SHLD ACTLB

045.040 056 300

1297

MVI L,3000

045.042 042 366 073

1298

SHLD DTSA

CLEAR TEMP ONDEX

045.045 041 345 114

1299

LXI H,MTAREA-1

045.050 042 135 112

1300

SHLD CURADR

CLEAR ADDRESS

1301

1302 **

RESTORE - RESTORE DATA POINTER

1303 *

1304 *

RESTORE

1305

1306

045.053 041 345 114

1307

RESTORE LXI H,MTAREA-1

045.056 042 303 114

1308

SHLD DATPTR

045.061 311

1309

RET

1310

```

1311 * CLEAR VARIABLE
1312
045.062 376 300 1313 CLR2 CFI CT,VARL
045.064 332 152 070 1314 JC ERR,SY NOT VARIABLE
045.067 376 306 1315 CFI CT,SSF+1
045.071 322 152 070 1316 JNC ERR,SY NOT VARIABLE
045.074 147 1317 MOV H,A SAVE (A) IN H
045.075 076 042 1318 MVI A,LEXLIM/256
045.077 272 1319 CMP D
045.100 320 1320 RNC IS NOT IN SYMBOL TABLE
045.101 174 1321 MOV A,H (A) = VARIABLE TYPE
045.102 041 006 000 1322 LXI H,6 (HL) = SIZE TO CLEAR
045.105 346 002 1323 ANI CF,VEC
045.107 312 132 045 1324 JZ CLR3 NOT VECTOR
045.112 032 1325 LDAX D
045.113 247 1326 ANA A
045.114 372 132 045 1327 JH CLR3 IS FUNCTION
045.117 325 1328 PUSH D SAVE ADDR OF AREA+2
045.120 345 1329 PUSH H SAVE #6
045.121 023 1330 INX D
045.122 023 1331 INX D
045.123 353 1332 XCHG
045.124 136 1333 MOV E,H
045.125 043 1334 INX H
045.126 126 1335 MOV D,H (DE) = SIZE OF ARRAY
045.127 341 1336 POP H (HL) = 6
045.130 031 1337 DAD D (HL) = TOTAL SIZE
045.131 321 1338 POP D (DE) = VARIABLE AREA+2
045.132 033 1339 CLR3 DCX D
045.133 033 1340 DCX D (DE) = VARIABLE FWA
045.134 345 1341 PUSH H SAVE COUNT TO REMOVE
045.135 052 064 112 1342 LMLD SYMTAB+MT,FWA
045.140 173 1343 MOV A,E COMPUTE INDEX INTO SYMTAB
045.141 225 1344 SUB L
045.142 157 1345 MOV L,A
045.143 172 1346 MOV A,D
045.144 234 1347 SBB H
045.145 147 1348 MOV H,A (HL) = INDEX
045.146 321 1349 POP D (DE) = DELETE COUNT
045.147 315 203 104 1350 CALL $DBT DELETE FROM SYMTAB
045.152 064 112 1351 DW SYMTAB+1
045.154 311 1352 RET DONE
  
```

1354 ** RUN - BEGIN EXECUTION.

1355 *

1356 * RUN IS THE SAME AS

1357 *

1358 * CLEAR; CONTINUE

1359

1360

```

045.155 315 313 075 1361 RUN CALL LFC CHECK FOR DATA LOCK
045.160 315 375 044 1362 CALL CLEAR,
  
```

```

1364 ** CONT - RESUME EXECUTION.
1365 *
1366
1367
045.163 076 004 1368 CONT MVI A,RN.CON (A) = NEW RUN MODE
045.165 052 135 112 1369 CONT1 LHLD CURADR
045.170 104 1370 MOV B,H
045.171 115 1371 MOV C,L (BC) = CURRENT TEXT ADDRESS
045.172 315 241 043 1372 CALL EXEC EXECUTE WITH REQUESTED MODE
045.175 001 345 114 1373 LXI B,ZERO POINT TO ZERO BYTE
000.000 1374 ERRNZ RM,IMM
045.200 257 1375 XRA A
045.201 062 301 114 1376 STA RUNMOD RESTORE IMMEDIATE MODE
045.204 311 1377 RET

1379 *** CHAIN - CHAIN TO NEW PROGRAM.
1380 *
1381 * CHAIN <STRING> [<LINE NUMBER>]
1382 *
1383 * LEAVE DATA, VARIABLES, AND CHANNELS INTACT
1384
1385
045.205 1386 CHAIN EQU *
045.205 341 1387 POP H ** KLUDGE ** TO CLEAN STACK FOR RECURSIVE CALL TO *CONT*
045.206 341 1388 POP H
045.207 315 053 072 1389 CALL CFN COPY FILE NAME
045.212 315 072 076 1390 CALL PNT SEE IF LINE # FOLLOWS
045.215 247 1391 ANA A
000.000 1392 ERRNZ CT,FIN
045.216 312 231 045 1393 JZ CHAIN1 NO LINE NUMBER
045.221 315 223 072 1394 CALL CHA GOBBLE COMMA
045.224 315 033 074 1395 CALL ELN EVAL LINE NUMBER
045.227 366 001 1396 ORI 1 CLEAR 'Z'
045.231 325 1397 CHAIN1 PUSH D SAVE LINE NUMBER (GARBAGE IF NO NUMBER)
045.232 365 1398 PUSH PSW 'Z' SET IF NO LINE NUMBER
045.233 315 206 077 1399 CALL RNF READ NEW PROGRAM
045.236 361 1400 POP PSW 'Z' SET IF NO NUMBER
045.237 321 1401 POP D (DE) = NUMBER
045.240 312 163 045 1402 JZ CONT JUST CONTINUE
1403
1404 * HAD LINE NUMBER. NOW FIND IT
1405
045.243 315 242 074 1406 CALL FLN FIND LINE BY NUMBER
045.246 332 147 070 1407 JC ERR.SN
045.251 053 1408 DCX H POINT TO TERMINATOR OF PREVIOUS LINE
045.252 042 135 112 1409 SHLD CURADR
045.255 303 163 045 1410 JMP CONT PROCESS AS CONTINUE

```

```

1412 *** CLOSE - CLOSE FILE.
1413 *
1414 * CLOSE #I [,#J,...,#N]
1415 *
1416 * CLOSE FILES #I THROUGH #N
1417 *
1418 * NO ERROR MESSAGE IF FILE ALREADY CLOSED.
1419 *
1420
045.260 1421 CLOSE EQU *
045.260 315 273 073 1422 CALL BCN. DECODE CHANNEL NUMBER
045.263 305 1423 PUSH B SAVE TEXT POINTER
045.264 072 140 112 1424 LBA IOCHAN
045.267 075 1425 BCR A
045.270 315 005 072 1426 CALL CFA COMPUTE FILE BLOCK ADDRESS
045.273 332 304 045 1427 JC CLOSE1 CHANNEL DOESNT EXIST
045.276 315 335 102 1428 CALL #FCLO CLOSE IT
045.301 315 326 073 1429 CALL INF DELETE NON-OPEN FILE BLOCKS
045.304 301 1430 CLOSE1 POF B
045.305 315 072 076 1431 CALL PNT CHECK NEXT TOKEN
000.000 1432 ERKNZ CT.FIN
045.310 247 1433 ANA A
045.311 310 1434 RZ
045.312 315 223 072 1435 CALL CMA REQUIRE COMMA
045.315 303 260 045 1436 JMP CLOSE CRACK ANOTHER
  
```

```

1438 ** CNTRL - CONTROL COMMAND.
1439 *
1440 * CNTRL I,J
1441 *
1442 * I=0 SET CTL-R PROCESSOR LINE
1443 * J=N LINE NUMBER
1444 *
1445 * I=1 SET PRINTING MODE
1446 * J=N SET SCIENTIFIC THRESHOLD
1447 *
1448 * I=2 SET DISPLAY MODE
1449 * J=0 DISPLAYS OFF
1450 * J=1 DISPLAYS REFRESHED, NOT UPDATED
1451 * J=2 DISPLAYS REFRESHED AND UPDATED
1452 *
1453 * I=3 SET TAB SIZE
1454 * J=NN WIDTH OF TAB FIELD
1455 *
1456 * I=4 SET OVERLAY FLAG
1457 * J=0 USE MAXIMUM AMOUNT OF MEMORY
1458 * J=1 ALLOW OVERLAY TO REMAIN RESIDENT
1459 *
1460
  
```

```

045.320 1461 CNTRL EQU *
045.320 315 235 052 1462 CALL OUT1 (L) = I, (E) = J
045.323 175 1463 MOV A,L
045.324 376 005 1464 CFI CNTLMX
  
```

```

045.326 322 122 070 1465 JNC ERR.IN TOO BIG A NUMBER
045.331 315 076 031 1466 CALL *TBRA
045.334 005 1467 CNTLA DB CNTL1-*
045.335 016 1468 DB CNTL2-*
045.336 033 1469 DB CNTL3-*
045.337 044 1470 DB CNTL4-*
045.340 101 1471 DB CNTL5-*
000.005 1472 CNTLMX EQU *-CNTLA MAX NUMBER OF FUNCTIONS - 1
1473
1474
1475 * SET CTL-B PROCESSOR.
1476
045.341 315 242 074 1477 CNTL1 CALL FLN FIND LINE BY NUMBER
045.344 332 147 070 1478 JC ERR.SN NOT FOUND
045.347 042 216 044 1479 SHLD ACTLB SET ADDRESS
045.352 311 1480 RET
1481
1482 * SET SCIENTIFIC THRESHOLD
1483
045.353 173 1484 CNTL2 MOV A,E SET THRESHOLD
045.354 074 1485 INR A
045.355 376 010 1486 CFI 7+1 /78.10.GC/
045.357 322 122 070 1487 JNC ERR.IN LIM SIZE DUE TO ACC. OF FLT. PT./78.10.GC/
045.362 062 360 110 1488 STA FTAC
045.365 062 370 110 1489 STA FTAD /78.10.GC/
045.370 311 1490 RET
1491
1492 * SET DISPLAY MODE.
1493
045.371 173 1494 CNTL3 MOV A,E
045.372 376 003 1495 CFI 3
045.374 322 122 070 1496 JNC ERR.IN IF ILLEGAL VALUE
045.377 062 316 043 1497 STA FPMODE SET DISPLAY MODE
046.002 311 1498 RET
1499
1500 * SET TAB SIZE
1501
046.003 173 1502 CNTL4 MOV A,E
046.004 247 1503 ANA A
046.005 312 122 070 1504 JZ ERR.IN BAD VALUE
046.010 062 062 053 1505 STA PRIC
1506
046.013 257 1507 XRA A /80.01.GC/
046.014 041 331 040 1508 LXI H,S.CONWI /80.01.GC/
046.017 203 1509 CNTL43 ADD E /80.01.GC/
046.020 332 033 046 1510 JC CNTL46 /80.01.GC/
046.023 276 1511 CMP M /80.01.GC/
046.024 332 017 046 1512 JC CNTL43 NOT >= CONSOLE WIDTH /80.01.GC/
046.027 312 033 046 1513 JZ CNTL46 IS AN INTEGRAL MULTIPLE /80.01.GC/
046.032 223 1514 SUB E /80.01.GC/
046.033 223 1515 CNTL46 SUB E /80.01.GC/
046.034 074 1516 INR A ADJUST AT THE LIMIT POINTS /80.01.GC/
1517
046.035 062 050 053 1518 STA PRIB SET TAB-FIELD WRAP WIDTH
046.040 311 1519 RET
1520

```



```

1521 *      SET OVERLAY LOAD OPTIONS
1522
046.041 172      1523 CNTLS MOV A,D
046.042 247      1524 ANA A
046.043 302 122 070 1525 JNZ ERR,IN BAD VALUE /78.10.6C/
046.046 263      1526 ORA E /78.10.6C/
046.047 376 002 1527 CPI I+I /78.10.6C/
046.051 322 122 070 1528 JNC ERR,IN /78.10.6C/
046.054 062 141 112 1529 STA OVL,MAN SET OVERLAY MANAGE FLAGS
046.057 247      1530 ANA A /78.10.6C/
046.060 312 115 074 1531 JZ FOC OPEN TABLES /78.10.6C/
1532
1533 *      GET THE NEW OVERLAY MEMORY /80.01.6C/
1534
046.063 315 054 031 1535 CALL $SAVALL /80.01.6C/
046.066 315 230 074 1536 CALL FOP, SQUEEZE TABLES /80.01.6C/
046.071 345      1537 PUSH H SAVE LWA /80.01.6C/
1538
046.072 052 350 040 1539 LHLD S,OFWA /80.01.6C/
000.000      1540 ERRNZ OVLO /80.01.6C/
046.075 021 006 000 1541 LXI D,OVL,FLB /80.01.6C/
046.100 031      1542 DAD D
046.101 176      1543 MOV A,M HL = ADDR. OF FLAG BYTE /80.01.6C/
046.102 346 001 1544 ANI OVL,IN A = FLAG BYTE /80.01.6C/
046.104 052 320 040 1545 LHLD S,SYSM /80.01.6C/
046.107 021 360 377 1546 LXI D,-16 /80.01.6C/
046.112 031      1547 DAD D LEAVE SOME SLOP /80.01.6C/
046.113 302 126 046 1548 JNZ CNTL52 ALREADY IN MEMORY /80.01.6C/
1549
1550 *      LEAVE ROOM FOR THE OVERLAY /80.01.6C/
1551
046.116 353      1552 XCHG
046.117 052 324 040 1553 LHLD S,OMAX /80.01.6C/
046.122 315 224 030 1554 CALL $CHL HL = -HL /80.01.6C/
046.125 031      1555 DAD D /80.01.6C/
1556
046.126 321      1557 CNTL52 POP D /80.01.6C/
046.127 353      1558 XCHG DE = PROSPECTUS, HL = LIMIT /80.01.6C/
046.130 303 152 074 1559 JMP FOC1.3 /80.01.6C/

1561 **     DEF - DEFINE FUNCTION.
1562 *
1563 *      1 LINE FUNCTIONS:
1564 *
1565 *      DEF FN X(F1,...,PN) = EXPR
1566
046.133      1567 DEF
046.133 315 305 077 1568 EQU *
046.136 220      1569 CALL RNT
046.137 315 263 075 1570 DB CT, FN REQUIRE 'FN'
046.142 032      1571 CALL IVT INSERT VECTOR IN TABLE
046.143 075      1572 LDAX D
1573 DCR A

```

```

046.144 362 152 070 1574      JP      ERR.SY      IS DIMENSIONED
                                1575
                                1576 *      IS SINGLE LINE DEFINITION.
                                1577
046.147 076 201   1578      MVI     A,201R
046.151 022      1579      STAX   D
046.152 023      1580      INX   D
046.153 353      1581      XCHG
046.154 161      1582      MOV   M,C
046.155 043      1583      INX   H
046.156 160      1584      MOV   M,B      SET FUNCTION ADDRESS
046.157 303 342 077 1585      JMP   SES      SKIP TO STATEMENT END AND EXIT
  
```

```

1587 **      DELETE - DELETE LINES.
  
```

```

1588 *
1589 *      DELETE NNN,MMM
1590
1591
  
```

```

046.162      1592      DELETE EQU *
046.162 315 313 075 1593      CALL   LFC      CHECK FOR DATA LOCK
046.165 315 036 057 1594      CALL   EVALI    (DE) = 1ST LINE NUMBER
046.170 315 223 072 1595      CALL   CMA      REQUIRE ', '
046.173 315 242 074 1596      CALL   FLN      FIND LINE BY NUMBER
046.176 345      1597      PUSH  H      SAVE ADDRESS
046.177 315 036 057 1598      CALL   EVALI
046.202 023      1599      INX   D
046.203 315 242 074 1600      CALL   FLN      FIND LAST
046.206 353      1601      XCHG
046.207 341      1602      POP   H      (HL) = FMA, (DE) = LWA
046.210 175      1603      MOV   A,L
046.211 223      1604      SUB   E
046.212 137      1605      MOV   E,A
046.213 174      1606      MOV   A,H
046.214 232      1607      SBB   D
046.215 127      1608      MOV   D,A      (DE) = BYTE COUNT TO DELETE
046.216 322 152 070 1609      JNC   ERR.SY    FIRST > LAST
046.221 325      1610      PUSH  D      SAVE COUNT
046.222 021 032 263 1611      LXI   D,-MTAREA
046.225 031      1612      DAD   D      (HL) = TABLE INDEX OF 1ST LINE TO DELETE
046.226 321      1613      POP   D      (DE) = COUNT
046.227 067      1614      STC
046.230 315 213 104 1615      CALL  #IBT     NUMBER IS NEG, SET 17TH BIT OF NUMBER
046.233 057 112 1616      DW   TTTAB+1  REMOVE BYTES
046.235 311      1617      RET
  
```

```

1619 ** DIM - PROCESS DIMENSION DECLARATION.
1620 *
1621 * DIM ITEM(X1,...,XN),...,ITEMN(X1,...,XP)
1622
1623
046.236 1624 DIM EQU *
046.236 052 086 112 1625 LHL D SYMTAB+MT.LEN
046.241 042 034 047 1626 SHLD DIMA SET BEFORE SYMTAB LEN
046.244 041 033 047 1627 LXI H,DIMS
046.247 042 077 075 1628 SHLD ILMA SET ABORT PROCESSOR
046.252 315 263 075 1629 CALL IVT INSERT VECTOR IN SYMBOL TABLE
1630
046.255 315 000 073 1631 CALL CSI (DE) = INDEX INTO SYMTAB
046.260 325 1632 PUSH D SAVE INDEX INTO SYMTAB
1633
1634 * DECODE AND STORE DIMENSION BOUNDS IN VECTAB.
1635
046.261 041 001 000 1636 LXI H,1 (HL) = ARRAY SIZE ACCUMULATOR
046.264 134 1637 MOV E,H (E) = 0 = DIMENSION COUNT
046.265 034 1638 DIM2 INR E INCREMENT DIMENSION COUNT
046.266 325 1639 PUSH D
046.267 315 036 057 1640 CALL EVALI EVALUATE NUMERIC EXPRESSION
046.272 023 1641 INX D (DE) = BOUND+1
046.273 325 1642 PUSH D SAVE BOUND
046.274 305 1643 PUSH B SAVE (BC)
046.275 104 1644 MOV B,H (BC) = CURRENT ARRAY SIZE
046.276 115 1645 MOV C,L
046.277 315 337 030 1646 CALL $MU66 (HL) = NEW ARRAY SIZE
046.302 302 160 070 1647 JNZ ERR.TO OVERFLOW
046.305 301 1648 POP B
046.306 343 1649 XTHL PUSH SIZE UNDER DIMENSION BOUND
046.307 345 1650 PUSH H
046.310 041 002 000 1651 LXI H,2
046.313 021 064 112 1652 LXI D,SYMTAB+1
046.316 315 026 071 1653 CALL AMB ALLOCATE 2 BYTES TO STORE BOUND
046.321 321 1654 POP D (DE) = DIMENSION BOUND
046.322 163 1655 MOV H,E
046.323 043 1656 INX H
046.324 162 1657 MOV M,D STORE IN TABLE
046.325 315 056 071 1658 CALL ANT ACCEPT NEXT TOKEN
046.330 341 1659 POP H (HL) = ARRAY SIZE
046.331 321 1660 POP D (E) = DIMENSION COUNT
046.332 376 026 1661 CPI CT,CMA
046.334 312 265 046 1662 JE DIM2 GET ANOTHER
046.337 376 020 1663 CPI CT,FAR
046.341 302 152 070 1664 JNE ERR.SY REQUIRE )
1665
1666 * READ ALL BOUNDS. SET SUBSCRIPT COUNT IN SYMTAB.
1667
046.344 173 1668 MOV A,E (A) = SUBSCRIPT COUNT
046.345 321 1669 POP D (DE) = INDEX INTO SYMBOL
1670
046.346 315 366 072 1671 CALL CSA (DE) = ABSOLUTE ADDRESS IN SYMTAB
1672
046.351 325 1673 PUSH D
046.352 022 1674 STAX D SET DIMENSION COUNT

```

```

046.353 051 1675 DAD H (HL) = 2*(HL)
046.354 332 122 070 1676 JC ERR.IN TOO LARGE
046.357 051 1677 DAD H (HL) = 4*HL
046.360 332 122 070 1678 JC ERR.IN TOO LARGE
1679
1680 * INSERT LENGTH OF AREA IN HEADER, (HL) = STORAGE NEEDED
1681
046.363 207 1682 ADD A (A) = NUMBER OF DIMENSIONS *2
046.364 353 1683 XCHG
046.365 046 000 1684 MVI H,0
046.367 157 1685 MOV L,A (HL) = LENGTH OF BOUNDS
046.370 031 1686 DAD D (HL) = TOTAL LENGTH
046.371 353 1687 XCHG
046.372 343 1688 XTHL (HL) = ADDRESS OF HEADER+(SP) = STORAGE NEEDED
046.373 043 1689 INX H
046.374 043 1690 INX H
1691
046.375 163 1692 MOV M,E
046.376 043 1693 INX H
046.377 162 1694 MOV M,D SET TOTAL LENGTH
047.000 341 1695 POP H (HL) = LENGTH OF VALUE STORE AREA
047.001 021 064 112 1696 LXI D,SYMTAB+1
047.004 345 1697 PUSH H SAVE COUNT
047.005 315 026 071 1698 CALL AMB ALLOCATE MEMORY
047.010 321 1699 POP D (DE) = COUNT
1700
1701 * ZERO NEWLY CREATED VALUES.
1702
047.011 066 000 1703 DIM3 MVI M,0
047.013 033 1704 DCX D ZERO ENTRIES
047.014 043 1705 INX H
047.015 172 1706 MOV A,D
047.016 263 1707 ORA E
047.017 302 011 047 1708 JNZ DIM3
1709
1710 * DONE WITH DECLARATION, SEE IF ANOTHER FOLLOWS.
1711
047.022 315 056 071 1712 CALL ANT GET NEXT TOKEN
047.025 376 026 1713 CPI CT.CMA
047.027 300 1714 RNE NOT COMMA
047.030 303 236 046 1715 JMP DIM PROCESS ANOTHER
1716
1717 * ERROR OCCURED, PUT SYMBOL TABLE BACK.
1718
047.033 041 000 000 1719 DIM5 LXI H,0
047.034 1720 DIMA EQU *-2 PREVIOUS LENGTH
047.036 042 066 112 1721 SHLD SYMTAB+NT.LEN
047.041 303 124 043 1722 JMP RESTART EXIT: RESTART RESTORES ABORT ADDRESS
  
```

END.

```

1724 **      END - END PROGRAM.
1725 *
1726 *
1727 *
047.044 041 345 114 1728 END LXI      H,MYAREA-1
047.047 042 135 112 1729 SHLD     CURADR      SET EXECUTION ADDRESS TO TOP
047.052 076 224      1730 MVI      A,BEC:EN
047.054 365          1731 PUSH     PSW          SAVE CODE
047.055 303 063 075 1732 JMP      ILM          ISSUE LINE MESSAGE

1734 **      FOR - PERFORM 'FOR' LOOP.
1735 *
1736 *      FOR VAR = VAL1 TO VAL2 (STEP VAL3)
1737 *
1738 *      KEPT ON 'FOR' STACK:
1739 *
1740 *      1) INDEX VARIABLE ADDRESS (2BYTES)
1741 *      2) STEP VALUE (4 BYTES)
1742 *      3) FINAL VALUE (4 BYTES)
1743 *      4) LOOP ADDRESS (2 BYTES)
1744 *
1745 *      IF THE 'FOR' VARIABLE IS ALREADY PRESENT IN THE 'FOR' STACK,
1746 *      REMOVE IT AND THEN ADD IT TO THE END.
1747 *
1748 *
047.060          1749 FOR     EQU      *
047.060 315 362 077 1750 CALL     SFS          SEARCH 'FOR' STACK
047.063 315 000 073 1751 CALL     CSI          CONVERT TO INDEX /80.01.GC/
047.066 325          1752 PUSH     D
047.067 302 104 047 1753 JNZ     FOR1          NONE PRE-EXISTING
047.072 053          1754 DCX     H
047.073 053          1755 DCX     H
047.074 021 014 000 1756 LXI     D,12
047.077 315 203 104 1757 CALL     $DBT          REMOVE FROM TABLE
047.102 071 112      1758 DW      FORTAB+1
1759 *
1760 *      ALLOCATE SPACE FOR ENTRY.
1761 *
047.104          1762 FOR1   EQU      *
047.104 041 014 000 1763 LXI     H,12
047.107 021 071 112 1764 LXI     D,FORTAB+1
047.112 315 026 071 1765 CALL     AMB          ALLOCATE 12 BYTES
047.115 321          1766 POP     D              (DE) = FOR INDEX
047.116 315 366 072 1767 CALL     CSA          CONVERT BACK TO ABS. AFTER DEL /80.01.GC/
1768 *
1769 *      STORE THE KEY ENTRY
1770 *
047.121 033          1771 DCX     D              /80.01.GC/
047.122 033          1772 DCX     D              /80.01.GC/
047.123 032          1773 LDAX    D              /80.01.GC/
047.124 167          1774 MOV     M,A           /80.01.GC/
047.125 023          1775 INX     D              /80.01.GC/
047.126 043          1776 INX     H              /80.01.GC/

```

```

047.127 032      1777      LDAX  D      /80.01.GC/
047.130 167      1778      MOV   M,A    /80.01.GC/
047.131 023      1779      INX   D      /80.01.GC/
047.132 043      1780      INX   H      /80.01.GC/
047.133 315 000 073 1781      CALL  CSI    CONVERT IT TO AN INDEX /80.01.GC/
                                1782
047.136 076 300    1783      MVI   A,CT,SNU
047.140 315 377 050 1784      CALL  LET,   ASSIGN VALUE
047.143 315 305 077 1785      CALL  RNT
047.146 317      1786      DB   CT,TD   REQUIRE *TO*
047.147 315 022 057 1787      CALL  EVALN
047.152 043      1788      INX   H      GO PAST 'STEP' VALUE
047.153 043      1789      INX   H
047.154 043      1790      INX   H
047.155 043      1791      INX   H
047.156 315 051 076 1792      CALL  MOV4   STORE LIMIT
047.161 021 370 377 1793      LXI   D,-8
047.164 031      1794      DAD  D      (HL) = ADDRESS FOR STEP
047.165 315 056 071 1795      CALL  ANT    ACCEPT NEXT TOKEN
047.170 021 147 112 1796      LXI   D,FP1,0
047.173 376 211    1797      CPI   CT,STE
047.175 314 022 057 1798      CE   EVALN   EVALUATE STEP VALUE
047.200 315 051 076 1799      CALL  MOV4   STORE STEP
047.203 043      1800      INX   H      SKIP 'LIMIT'
047.204 043      1801      INX   H
047.205 043      1802      INX   H
047.206 043      1803      INX   H
047.207 161      1804      MOV  M,C
047.210 043      1805      INX   H
047.211 160      1806      MOV  M,B    STORE STATEMENT RETURN ADDRESS
047.212 311      1807      RET

```

1809 ** FREE - TYPE FREE SPACE.

1810 *

1811 * FREE

1812

1813

```

047.213      1814 FREE EQU *
047.213 305    1815 PUSH B      SAVE (BC)
047.214 041 061 112 1816 LXI H,MTABIND+MT.LEN
047.217 345    1817 PUSH H      SAVE TABLE INDEX ON STACK
047.220 006 021 1818 MVI B,MTABL*2+1 (B) = NUMBER OF TABLES * 2 + 1
047.222 041 272 047 1819 LXI H,FREEA (HL) = HEADER MESSAGES
                                1820
047.225 377 003 1821 FREE1 DB SYSCALL,,PRINT PRINT HEADER
047.227 315 136 031 1822 CALL $TYPTX
047.232 040 075 240 1823 DB ' ',' '+200G
047.235 343    1824 XTHL (HL) = ADDRESS OF INDEX
047.236 136    1825 MOV  E,M
047.237 043    1826 INX  H
047.240 126    1827 MOV  D,M
047.241 043    1828 INX  H
047.242 043    1829 INX  H

```

```

047.243 043 1830 INX H
047.244 043 1831 INX H
047.245 343 1832 XTHL
047.246 005 1833 DCR B
047.247 304 264 047 1834 CNZ TDI. TYPE VALUE IF NOT LAST ONE
047.252 005 1835 DCR B
047.253 362 225 047 1836 JF FREE1 MORE TO GO
047.256 341 1837 POP H DISCARD TABLE ADDRESS
047.257 315 127 072 1838 CALL %CFS COMPUTE FREE SPACE
047.262 353 1839 XCHG
047.263 301 1840 POP B RESTORE (BC)
1841
1842 ** TDI. - TYPE DECIMAL INTEGER FOLLOWED BY %CRLF
1843
047.264 315 206 100 1844 TDI. CALL TDI
047.267 303 312 111 1845 JMP %CRLF
1846
047.272 1847 FREEA EQU * TABLE OF TABLE NAMES
047.272 124 145 170 1848 DB 'Tex', 't' +2000
047.276 123 171 155 1849 DB 'Sym', 'b' +2000
047.302 106 157 162 1850 DB 'For', 'l' +2000
047.306 107 163 165 1851 DB 'Gsu', 'b' +2000
047.312 127 157 162 1852 DB 'Wor', 'k' +2000
047.316 123 164 162 1853 DB 'Str', 'n' +2000
047.322 124 123 164 1854 DB 'TSt', 'r' +2000
047.326 106 151 154 1855 DB 'Fil', 'e' +2000
047.332 106 162 145 1856 DB 'Fre', 'e' +2000

1858 *** FREEZE - FREEZE PROGRAM AND BASIC.
1859 *
1860 * FREEZE <STRING>
1861 *
1862 * FREEZE THE BASIC PROGRAM, BASIC, AND ALL MEMORY ONTO
1863 * FILE 'STRING'
1864
1865
047.336 1866 FREEZE EQU *
047.336 315 041 072 1867 CALL CFN. COPY FILE NAME, DO FILE OPEN PRESET
047.341 257 1868 XRA A
047.342 315 005 072 1869 CALL CFA PRESET FOR I/O OPERATION
047.345 021 057 054 1870 LXI D, UNFREZA (DE) = DEFAULTS
047.350 315 030 101 1871 CALL %FOPEW OPEN FOR WRITE
047.353 345 1872 PUSH H SAVE FB ADDRESS
047.354 052 127 112 1873 LHLD MEML
047.357 021 200 335 1874 LXI D, -USERFWA
047.362 031 1875 DAD D (HL) = LENGTH
047.363 042 022 050 1876 SHLD FREEZ
047.366 021 016 050 1877 LXI D, FREEZA (DE) = HEADER ADDRESS
047.371 343 1878 XTHL (HL) = FB ADDRESS, ((SP)) = LEN
047.372 001 010 060 1879 LXI B, FREEZAL
047.375 315 047 102 1880 CALL %FWRIE WRITE HEADER
050.000 301 1881 POP B (BC) = LEN OF PROGRAM
050.001 021 200 042 1882 LXI D, USERFWA

```

```

050.004 315 047 102 1883      CALL  $FWRIB  WRITE IT
050.007 315 335 102 1884      CALL  $FCLO  CLOSE FILE
050.012 001 345 114 1885      LXI   B,ZERO  NO MORE TEXT LINE
050.015 311                1886      RET      LET HIM KEEP RUNNING
                1887
050.016 377 000            1888  FREZEA DB  3770,FT,ABS  ABS HEADER FOR IMAGE
050.020 200 042            1889      DW   USERFWA
050.022 000 000            1890  FREZEB DW  0          LENGTH
050.024 106 043            1891      DW   START    ENTRY ADDRESS
000.010                1892  FREZEAL EQU  *-FREZEA  LENGTH OF HEADER
  
```

```

                1894  **      GOSUB - CALL SUBROUTINE.
                1895  *
                1896  *      GOSUB EXIR
                1897
                1898
050.026                1899  GOSUB  EQU   *
050.026 315 143 100      1900      CALL  SRA      STACK RETURN ADDRESS
                1901  *      JMP   GOTO    PROCESS AS GOTO
  
```

```

                1903  **      GOTO - GO TO STATEMENT.
                1904  *
                1905  *      GOTO EXPR
                1906
                1907
050.031                1908  GOTO  EQU   *
050.031 315 033 074      1909      CALL  ELN      EVAL LINE NUMBER
050.034 315 242 074      1910  GOTO1 CALL  FLN      FIND LINE BY NUMBER
050.037 332 147 070      1911      JC   ERR.SN   CANT FIND IT
                1912
050.042                1913  GOTO2 EQU   *
050.042 053                1914      DCX  H          (HL) # PREVIOUS LINE TERMINATOR
050.043 104                1915      MOV  B,H
050.044 115                1916      MOV  C,L
050.045 042 135 112      1917      SHLD CURADR   SAVE CURRENT TEXT ADDRESS
050.050 311                1918      RET      LET EXEC 'FIND' NEW LINE
  
```

```

                1920  **      IF - PROCESS IF STATEMENT.
                1921  *
                1922  *      IF EXPR THEN <STATEMENT>
                1923  *      IF EXPR THEN <STATEMENT NUMBER>
                1924
                1925
050.051                1926  IF    EQU   *
050.051 315 034 057      1927      CALL  EVALI   EVALUATE EXPRESSION
                1928
                1929  *      WILL EXECUTE, REQUIRE 'THEN'
  
```


IF

```

1930
050.054 315 056 071 1931 CALL ANT GET NEXT TOKEN
050.057 376 225 1932 CPI CT.GOT
050.061 312 127 050 1933 JE IF3 IS IF <EXPR> GOTO <EXPR>
050.064 376 316 1934 CPI CT.THN
050.066 302 152 070 1935 JNE ERR.SY NOT *THEN*
050.071 173 1936 MOV A,E (A) = TEST CODE
050.072 037 1937 RAR
050.073 322 121 050 1938 JNC IF2 FALSE - WILL SKIP
050.076 315 126 100 1939 CALL SOB SKIP OVER BLANKS
050.101 012 1940 LDAX B
050.102 376 060 1941 CPI '0'
050.104 332 114 050 1942 JC IF0 NOT DIGIT - MUST BE STATEMENT
050.107 376 072 1943 CPI '0'+1
050.111 332 031 050 1944 JC GOTO IS DIGIT - MUST BE GOTO
050.114 341 1945 IF0 POP H
050.115 303 244 043 1946 JMP EXEC1 PROCESS AS STATEMENT
1947
1948 * SKIP REST OF LINE.
1949
050.120 003 1950 IF1 INX B
050.121 012 1951 IF2 LDAX B
050.122 247 1952 ANA A
050.123 302 120 050 1953 JNZ IF1 SKIP STATEMENT
050.126 311 1954 RET DONE
1955
1956 * IF <EXPR> GOTO <EXPR>
1957
050.127 173 1958 IF3 MOV A,E
050.130 037 1959 RAR
050.131 322 121 050 1960 JNC IF2 IF TO SKIP
050.134 303 031 050 1961 JMP GOTO PROCESS GOTO

```

1963 ** LINE INPUT - INPUT ONE LINE FROM CONSOLE.

1964 *
 1965 * SAME AS *INPUT*, EXCEPT THAT THE FIRST VARIABLE MUST
 1966 * BE A STRING VARIABLE, AND THE FIRST LINE IS
 1967 * TAKEN AS THE VALUE.

```

1968
1969
050.137 1970 LINPUT EQU *
050.137 315 305 077 1971 CALL RNT
050.142 254 1972 DB CT.INP REQUIRE *INPUT*
050.143 076 001 1973 MVI A+1
050.145 303 151 050 1974 JMP INP1 PROCESS AS INPUT

```

INPUT

```

1976 ** INPUT - INPUT FROM CONSOLE.
1977 *
1978 * INPUT *PROMPT*#V1,...,VN
1979
1980
050.150 257 1981 INPUT XRA A
050.151 062 370 050 1982 INP1 STA INPUTA SAVE FLAG FOR LINE INPUT
050.154 315 253 073 1983 CALL DCN DECODE CHANNEL NUMBER
050.157 305 1984 PUSH B SAVE (BC)
050.160 315 354 111 1985 CALL $CCO CLEAR CTL-0
050.163 301 1986 POP B
050.164 315 072 076 1987 CALL PNT PEEK AT NEXT TOKE
050.167 041 371 050 1988 LXI H,INPUTB ASSUME '?' PROMPT
050.172 376 027 1989 CPI CT,SEM
050.174 302 205 050 1990 JNE INP2 MAY HAVE PROMPT
050.177 315 056 071 1991 CALL ANT NO PROMPT, GOBBLE ;
050.202 303 233 050 1992 JMP INP4 PROVIDE DEFAULT PROMPT
1993
050.205 376 301 1994 INP2 CPI CT,SSV SCALAR STRING VALUE
050.207 302 233 050 1995 JNE INP4 NO PROMPT
1996
1997 * HAVE PROMPT
1998
050.212 072 140 112 1999 LDA IOCHAN
050.215 247 2000 ANA A
050.216 314 200 100 2001 CZ TCS TYPE CHARACTER STRING IFF CONSOLE INPUT
050.221 315 056 071 2002 CALL ANT ACCEPT ALREADY PROCESSED STRING
050.224 315 305 077 2003 CALL RNT
050.227 027 2004 DB CT,SEM REQUIRE ;
050.230 041 373 050 2005 LXI H,INPUTC SUPPRESS OUR PROMPT
2006
2007 * READY TO INPUT VALUES
2008
050.233 072 140 112 2009 INP4 LDA IOCHAN
050.236 247 2010 ANA A SEE IF OUTPUT TO CONSOLE
050.237 302 244 050 2011 JNZ INP4.5 DISK I/O, NO PROMPT
050.242 377 003 2012 DB SYSCALL,.PRINT PRINT PROMPT
050.244 2013 INP4.5 EQU * /80.01.6C/
2014
2015 * MAKE SURE WE HAVE VARIABLES
2016
050.244 315 072 076 2017 CALL PNT /80.01.6C/
050.247 376 300 2018 CPI CT,VARL LOWEST VARIABLE /80.01.6C/
050.251 332 152 070 2019 JC ERR,SY < LOWEST VARIABLE /80.01.6C/
050.254 376 310 2020 CPI CT,VARH+1 /80.01.6C/
050.256 322 152 070 2021 JNC ERR,SY > HIGHEST VARIABLE /80.01.6C/
2022
050.261 041 266 112 2023 LXI H,LINE+1 /80.01.6C/
050.264 315 141 077 2024 CALL RLF READ LINE FROM FILE
050.267 332 106 070 2025 JC ERR,CC IF CTL-C HIT
050.272 072 370 050 2026 LDA INPUTA
050.275 247 2027 ANA A
050.276 041 266 112 2028 LXI H,LINE+1 ASSUME START LINE AT FIRST CHARACTER
050.301 312 356 050 2029 JZ INP6 IS REGULAR INPUT
2030
2031 * IS LINE INPUT, ENCLOSE LINE IN QUOTES

```

```

2032
050.304 315 072 076 2033 INF5 CALL PNT CHECK INPUT VARIABLE
050.307 346 375 2034 ANI 3770-CF.VEC ALLOW VECTORS, TOO
050.311 376 301 2035 CPI CT.SSV
050.313 302 152 070 2036 JNE ERR.SY MUST BE SCALAR STRING VALUE
050.316 345 2037 PUSH H SAVE DATA POINTER
050.317 315 136 075 2038 CALL IST INSERT SYMBOL IN TABLE
050.322 341 2039 POP H (HL) = DATA POINTER
050.323 325 2040 PUSH D SAVE TARGET VARIABLE INDEX
050.324 305 2041 PUSH B SAVE TEXT POINTER
050.325 104 2042 MOV B,H
050.326 115 2043 MOV C,L (BC) = INPUT TEXT ADDRESS
050.327 315 012 055 2044 CALL LEX11.5 BUILD INTO STRING
050.332 001 005 000 2045 LXI B,5
050.335 033 2046 DCX D
050.336 041 201 042 2047 LXI H,ACCX-1
050.341 315 252 030 2048 CALL $MOVE MOVE TEMP DESCRIPTOR INTO ACCX
050.344 301 2049 POP B
050.345 321 2050 POP D
050.346 315 366 072 2051 CALL CSA CONVERT INDEX TO ABSOLUTE
050.351 076 301 2052 MVI A,CT.SSV IS STRING ASSIGNMENT
050.353 303 202 071 2053 JMP AVU ASSIGN VALUE TO VARIABLE, EXIT 'INPUT' PROCESSING
2054
2055 * ASSIGN VALUES
2056
050.356 315 135 076 2057 INF6 CALL PVI PERFORM VALUE INPUT
050.361 310 2058 RE DONE
050.362 041 371 050 2059 LXI H,INPUTB USE '?' PROMPT
050.365 303 233 050 2060 JMP INF4 INPUT MORE
2061
050.370 000 2062 INPUTA DB 0 <>0 IF LINE INPUT
050.371 077 240 2063 INPUTB DB '?','+2000 DEFAULT PROMPT
050.373 200 2064 INPUTC DB 2000 NULL PROMPT
2066 ** LET - ASSIGN VALUE.
2067 *
2068 * LET VAL = EXPR
2069
2070
050.374 315 136 075 2071 LET CALL IST PREPARE VALUE FOR ASSIGNMENT
2072
050.377 365 2073 LET. PUSH PSW SAVE TYPE
2074
051.000 325 2075 PUSH D SAVE INDEX
051.001 315 305 077 2076 CALL RNT
051.004 011 2077 DB CT.EQ REQUIRE =
051.005 315 244 055 2078 CALL EVAL (ACCX) = VALUE
051.010 321 2079 POP D (DE) = VALUE INDEX
051.011 315 366 072 2080 CALL CSA (DE) = ABSOLUTE ADDRESS INTO SYMTAB
051.014 361 2081 POP PSW (A) = TYPE
051.015 303 202 071 2082 JMP AVU ASSIGN VALUE TO VARIABLE
  
```

```

2084 ** LIST - PROCESS LIST COMMAND.
2085 *
2086 * LIST LIST ALL
2087 * LIST NNN LIST NNN
2088 * LIST NNN,MMM LIST NNN TO MMM
2089 *
2090 * LIST [#CHANIC,NNNC,MMMJJ] ETC. /78.10.GC/
2091
051.020 2092 LIST EQU *
2093
051.020 315 253 073 2094 CALL DCN DECODE CHANNEL NUMBER /78.10.GC/
2095
2096 * DECODE RANGE.
2097
051.023 021 000 000 2098 LIST. LXI D,0
051.026 325 2099 PUSH D SET DEFAULT NN
051.027 033 2100 DCX D
051.030 033 2101 DCX D (DE) = 377376A
051.031 315 072 076 2102 CALL PNT PEEK AT NEXT TOKEN
000.000 2103 ERRNZ CT,FIN
051.034 247 2104 ANA A
051.035 312 065 051 2105 JZ LIST1 IS LIST 0,377376A
051.040 315 036 057 2106 CALL EVALI (DE) = NNN
051.043 341 2107 * POP H DISABD DEFAULT FIRST
051.044 325 2108 PUSH D SET 1ST = LAST = NNN
051.045 315 072 076 2109 CALL PNT PEEK AT NEXT TOKEN
000.000 2110 ERRNZ CT,FIN
051.050 247 2111 ANA A
051.051 312 065 051 2112 JZ LIST1 IS NNN
051.054 315 223 072 2113 CALL CMA REQUIRE '/'
051.057 315 036 057 2114 CALL EVALI IS NNN,MMM
051.062 315 242 074 2115 CALL FLN CHECK VALIDITY OF LAST LINE NUMBER /78.10.GC/
2116
2117 * LIST TEXT
2118
051.065 341 2119 LIST1 POP H (HL) = START
051.066 325 2120 PUSH D SAVE END
051.067 353 2121 XCHG (DE) = 1ST, ((BP)) = LAST
051.070 315 242 074 2122 CALL FLN FIND LINE BY NUMBER
2123
2124 * SEE IF OFF THE END
2125
051.073 116 2126 LIST2 MOV C,H
051.074 043 2127 INX H
051.075 106 2128 MOV B,H (BC) = LINE NUMBER OF NEXT LINE
051.076 043 2129 INX H
051.077 343 2130 XTHL (HL) = LIMIT
051.100 175 2131 MOV A,L
051.101 221 2132 SUB C COMPARE TO CURRENT
051.102 174 2133 MOV A,H
051.103 230 2134 SBB B
051.104 332 170 051 2135 JC LIST6 ALL DONE
051.107 343 2136 XTHL RESTORE LIMIT
051.110 345 2137 PUSH H SAVE LINE ADDRESS
051.111 041 273 113 2138 LXI H,LINE2
051.114 076 095 2139 MVI A,5

```

```

051.118 315 157 031 2140 CALL $000 UNPACK DECIMAL DIGITS
051.121 066 040 2141 MVI M, ' ' ADD BLANK
051.123 043 2142 INX H
051.124 353 2143 XCHG (DE) = LINE ADDRESS
051.125 341 2144 POP H (HL) = PROGRAM TEXT ADDRESS
051.126 176 2145 LIST3 MOV A,M (A) = NEXT CHARACTER
051.127 043 2146 INX H
051.130 247 2147 ANA A
051.131 374 374 073 2148 CM EKA EXPAND KEYWORD TO ASCII
051.134 022 2149 STAX D STORE IN LISTING LINE
051.135 023 2150 INX D
051.136 247 2151 ANA A
051.137 302 126 051 2152 JNZ LIST3 MORE TO GO
2153
2154 * SEE IF TO WRITE TO FILE, OR TO CONSOLE
2155
051.142 345 2156 PUSH H SAVE PROGRAM TEXT ADDRESS
051.143 353 2157 XCHG (HL) = LINE NEXT ADDRESS
051.144 053 2158 DCX H BACKUP OVER END OF LINE
051.145 066 012 2159 MVI M,NL
051.147 043 2160 INX H
051.150 066 000 2161 MVI M,0 ADD END OF LINE
051.152 315 242 100 2162 CALL WLF WRITE LINE TO FILE
051.155 341 2163 POP H (HL) = TEXT FWA
051.156 072 142 112 2164 LDA CTLFLAG
000.000 2165 ERRNZ CFCTLC-1
051.161 037 2166 RAR
051.162 332 106 070 2167 JC ERR.CC CTL-C STRUCK
051.165 303 073 051 2168 JMP LIST2 DO NEXT
2169
2170 * ALL DONE.
2171
051.170 341 2172 LIST6 POP H
051.171 001 345 114 2173 LXI R,ZERO END OF COMMAND LINE
051.174 311 2174 RET
  
```

```

2176 ** LOCK - LOCK OUT DATA CHANGE
2177 *
2178 * LOCK PREVENTS ANY DATA OR LINES OF TEXT TO BE
2179 * CHANGED
2180 *
2181 *
2182 ** UNLOCK - ENABLE DATA CHANGE
2183 *
2184 * UNLOCK CLEARS THE LOCK FLAG ENABLING
2185 * DATA CHANGES
2186 *
2187 * UNLOCK
2188 * LOCK
2189 *
2190 *
2191 *****
2192 * *
  
```

```

2193 * LOCK USES THE XRA A OPCODE (257) AS THE VALUE TO PUT IN *
2194 * LCKFLG THROUGH THE USE OF THE MVI INSTRUCTION IMPLEMENTED *
2195 * TO USE THE XRA A OPCODE AS THE SECOND BYTE OF THE MVI *
2196 * INSTRUCTION. *
2197 * *
2198 *****
2199 *****
2200
2201
051.175 076 2202 LOCK DB MI,MVIA MVI OPCODE
2203
051.176 257 2204 UNLOCK XRA A
051.177 062 137 112 2205 STA LCKFLG STORE EITHER 0 OR 257 (FROM XRA OPCODE)
051.202 311 2206 RET EXIT

2208 ** NEXT - PROCESS NEXT.
2209 *
2210 * NEXT VAR
2211 *
2212 * PERFORM LOOPING FOR REQUESTED VARIABLE. IF NOT THE MOST
2213 * RECENT, DISCARD 'FORTAB' ENTRIES UNTIL IS FOUND.
2214
2215
051.203 2216 NEXT EQU *
051.203 315 352 077 2217 CALL SFS SEARCH 'FOR' STACK
051.206 302 133 070 2218 JNZ ERR.NV NEXT MISSING VARIABLE
051.211 345 2219 PUSH H SAVE FORTAB INDEX
2220 ** CALL CSA (DE) = ABS. ADDR. OF VARIABLE /80.01.GC/
051.212 315 210 073 2221 CALL CVX COPY VALUE TO ACCX
051.215 315 000 073 2222 CALL CSI (DE) = INDEX INTO SYMTAB OF VARIABLE
051.220 341 2223 POP H (HL) = FORTAB INDEX
051.221 325 2224 PUSH D SAVE INDEX ADDRESS
051.222 353 2225 XCHG
051.223 041 012 000 2226 LXI H,12-2
051.226 031 2227 DAD D (HL) = NEW TABLE LENGTH
051.227 042 073 112 2228 SHLD FORTAB+MT.LEN DISCARD ANY MORE INNER ENTRIES
051.232 052 071 112 2229 LHLD FORTAB+MT.FWA
051.235 031 2230 DAD D (HL) = TABLE ADDRESS
051.236 353 2231 XCHG
051.237 315 352 104 2232 CALL FPADD ADD STEP TO INDEX
051.242 353 2233 XCHG (HL) = ADDRESS OF STEP VALUE
051.243 321 2234 POP D (DE) = ADDRESS OF INDEX
051.244 315 366 072 2235 CALL CSA (DE) = ABS. ADDR. OF VARIABLE
051.247 315 237 073 2236 CALL CXV COPY ACCX TO VALUE
2237
2238 * COMPARE RESULT TO LIMIT.
2239 *
2240 * IF INC >= 0, VAL-LIM>0 => TERMINATE
2241 * IF INC < 0, LIM-VAL>0 => TERMINATE
2242
051.252 043 2243 INX H
051.253 043 2244 INX H
051.254 176 2245 MOV A,M (A) = SIGN OF INCREMENT
  
```

```

051.255 043 2246 INX H
051.256 043 2247 INX H
051.257 345 2248 PUSH H SAVE ADDRESS OF LIMIT
051.260 247 2249 ANA A
051.261 353 2250 XCHG (DE) = ADDRESS OF LIMIT
051.262 372 271 051 2251 JH NXT1 IS < 0
2252
2253 * COMPUTE VALUE-LIMIT
2254
051.265 315 210 073 2255 CALL CVX (ACCX) = LIMIT
051.270 353 2256 XCHG (DE) = ADDRESS OF VALUE
2257
2258 * COMPUTE LIMIT-VALUE
2259
051.271 315 166 105 2260 NXT1 CALL FPSUB COMPARE
051.274 341 2261 POP H (HL) = ADDRESS OF LIMIT
051.275 072 204 042 2262 LDA ACCX+2
051.300 247 2263 ANA A
051.301 312 307 051 2264 JZ NXT1.5 IS MATCH
051.304 362 317 051 2265 JP NXT2 ALL DONE
2266
2267 * LOOP TO AFTER 'FOR' STATEMENT
2268
051.307 043 2269 NXT1.5 INX H
051.310 043 2270 INX H
051.311 043 2271 INX H
051.312 043 2272 INX H
051.313 116 2273 MOV C,M
051.314 043 2274 INX H
051.315 106 2275 MOV B,M
051.316 311 2276 RET
2277
2278 * DONE. COLLAPSE 'FOR' OUT OF TABLE.
2279
051.317 052 073 112 2280 NXT2 LHLD FORTAB+MT.LEN
051.322 021 364 377 2281 LXI D,-12
051.325 031 2282 DAD D
051.326 042 073 112 2283 SHLD FORTAB+MT.LEN
051.331 311 2284 RET

2286 *** OLD - GET NEW PROGRAM.
2287 *
2288 * OLD <STRING>
2289 *
2290 * OLD CLEARS ALL THE TABLE, THEN LOADS A PROGRAM.
2291
2292
051.332 2293 OLD EQU *
051.332 315 053 072 2294 CALL CFN COPY FILE NAME
051.335 041 141 112 2295 LXI H,DVLMAN
051.340 176 2296 MOV A,M (A) = CURRENT VALUE
051.341 064 2297 INR H MAKE NON-ZERO
051.342 345 2298 PUSH H
  
```

051.343	365		2299		PUSH	PSW	
051.344	315	360	044	2300	CALL	SCR,	CLEAR PROGRAM
051.347	361			2301	PDP	PSW	
051.350	341			2302	PDP	H	
051.351	167			2303	MOV	M.A	RESTORE FLAG
051.352	303	206	077	2304	JMP	RNP	READ NEW PROGRAM AND RETURN

2306 ** ON - PROCESS 'ON' STATEMENT.

2307 *

2308 * ON EXPR GOTO EXP1,...,EXPN

2309 * ON EXPR GOSUB EXP1,...,EXPN

2310 *

2311 * IF EXPR < 0, FLAG ERROR

2312 * IF EXPR = 1,...,N TAKE EXP1,...,EXPN

2313 * IF EXPR>N TAKE EXPN

2314 * IF EXPR=0 TAKE EXPN

2315

2316

051.355	315	036	057	2317	ON	CALL	EVALI	EVALUATE INTEGER
---------	-----	-----	-----	------	----	------	-------	------------------

051.360	353			2318		XCHG		(HL) = INDEX
---------	-----	--	--	------	--	------	--	--------------

051.361	315	056	071	2319		CALL	ANT	ACCEPT NEXT TOKEN
---------	-----	-----	-----	------	--	------	-----	-------------------

051.364	376	225		2320		CPI	CT.GOT	
---------	-----	-----	--	------	--	-----	--------	--

051.366	312	001	052	2321		JE	ON1	GOTO
---------	-----	-----	-----	------	--	----	-----	------

051.371	376	224		2322		CPI	CT.GOS	
---------	-----	-----	--	------	--	-----	--------	--

051.373	302	152	070	2323		JNE	ERR.SY	NOT GOSUB
---------	-----	-----	-----	------	--	-----	--------	-----------

051.376	315	143	100	2324		CALL	SRA	SET RETURN ADDRESS
---------	-----	-----	-----	------	--	------	-----	--------------------

052.001				2325	ON1	EGU	*	
---------	--	--	--	------	-----	-----	---	--

2326

2327 * SKIP DOWN LIST UNTIL INDEX FOUND.

2328

052.001	315	033	074	2329	ON2	CALL	ELN	EVALUATE LINE NUMBER
---------	-----	-----	-----	------	-----	------	-----	----------------------

052.004	315	056	071	2330		CALL	ANT	GET DELIMITER
---------	-----	-----	-----	------	--	------	-----	---------------

052.007	062	035	052	2331		STA	ONA	SAVE FOR LATER EXAM
---------	-----	-----	-----	------	--	-----	-----	---------------------

052.012	053			2332		DCX	H	
---------	-----	--	--	------	--	-----	---	--

052.013	174			2333		MOV	A,H	
---------	-----	--	--	------	--	-----	-----	--

052.014	265			2334		ORA	L	
---------	-----	--	--	------	--	-----	---	--

052.015	312	034	050	2335		JZ	GOTO1	HAVE PROPER LABEL
---------	-----	-----	-----	------	--	----	-------	-------------------

052.020	072	035	052	2336		LDA	ONA	
---------	-----	-----	-----	------	--	-----	-----	--

052.023	247			2337		ANA	A	
---------	-----	--	--	------	--	-----	---	--

000.000				2338		ERRNZ	CT.FIN	
---------	--	--	--	------	--	-------	--------	--

052.024	310			2339		RZ		END OF LINE
---------	-----	--	--	------	--	----	--	-------------

052.025	376	026		2340		CFI	CT.CMA	
---------	-----	-----	--	------	--	-----	--------	--

052.027	302	152	070	2341		JNE	ERR.SY	
---------	-----	-----	-----	------	--	-----	--------	--

052.032	303	001	052	2342		JMP	ON2	
---------	-----	-----	-----	------	--	-----	-----	--

2343

052.035	000			2344	ONA	DB	0	TEMP AREA
---------	-----	--	--	------	-----	----	---	-----------

OPEN

```

2346 *** OPEN - OPEN FILE
2347 *
2348 * OPEN <STRING> FOR <VERB> AS FILE #N
2349 *
2350 * <STRING> = STRING CONTAINING FILE NAME
2351 *
2352 * <VERB> = READ OPEN FILE FOR READ ACCESS
2353 * <VERB> = WRITE OPEN FILE FOR WRITE ACCESS
2354
2355
052.036 2356 OPEN EQU *
052.036 315 053 072 2357 CALL CFN CRACK FILE NAME
052.041 315 305 077 2358 CALL RNT
052.044 221 2359 DB CT.FOR REQUIRE FOR
052.045 315 056 071 2360 CALL ANT
052.050 376 241 2361 CPI CT.REA
052.052 312 082 052 2362 JE OPEN1 VERB IS OK
052.055 376 313 2363 CPI CT.WRI
052.057 302 152 070 2364 JNE ERR.SY NOT A GOOD VERB
052.062 365 2365 OPEN1 PUSH PSW SAVE VERB TOKEN
052.063 315 305 077 2366 CALL RNT
052.066 311 2367 DB CT.AS
052.067 315 305 077 2368 CALL RNT
052.072 312 2369 DB CT.FIL FILE
052.073 315 273 073 2370 CALL DCN. DECODE CHANNEL NUMBER, NO COMMA
052.076 315 302 075 2371 CALL LCC LOCATE CHANNEL COLUMN NUMBER
052.101 066 001 2372 MVI M,1 SET AT FRONT OF LINE
052.103 361 2373 POP PSW (A) = FUNCTION KEYWORD
052.104 305 2374 PUSH B SAVE TEXT POINTER
052.105 365 2375 PUSH PSW SAVE FUNCTION KEYWORD
052.106 072 140 112 2376 LDA IOCHAN
052.111 075 2377 DCR A (A) = CHANNEL NUMBER
2378
2379 * FIND THE FILE BLOCK, CREATE IT IF NECESSARY
2380
052.112 365 2381 OPEN2 PUSH PSW SAVE CHANNEL/BLOCK NUMBER
052.113 315 005 072 2382 CALL CFA COMPUTE FILEBLOCK ADDRESS
052.116 322 144 052 2383 JNC OPEN3 GOTIT
2384
052.121 315 374 071 2385 CALL CEF CREATE EMPTY FILE BLOCK
052.124 072 125 112 2386 LDA FILTAB+MT.LEN+1 A = BUFFER JUST ADDED /80.01.GC/
052.127 315 005 072 2387 CALL CFA HL = FILE-BLOCK ADDRESS /80.01.GC/
052.132 332 160 070 2388 JC ERR.T0 SHOULD NOT HAPPEN ! (NOT FOUND) /80.01.GC/
052.135 043 2389 INX H /80.01.GC/
000.000 2390 ERRNZ FB.FLG-1 /80.01.GC/
052.136 066 000 2391 MVI M,0 ZERO THE FLAG /80.01.GC/
052.140 361 2392 POP PSW
052.141 303 112 052 2393 JMP OPEN2 SEE IF WE'VE CREATED ENOUGH
2394
2395 * GOT THE FILE BLOCK.
2396 * (HL) = FB FWA (ABS)
2397
052.144 043 2398 OPEN3 INX H (HL) = #FB.FLG
000.000 2399 ERRNZ FB.FLG-1
052.145 176 2400 MOV A,M /80.01.GC/
052.146 247 2401 ANA A /80.01.GC/

```

```

052.147 302 221 070 2402 JNZ ERR.CIU CHANNEL ALREADY IN USE /80.01.6C/
                2403
052.152 001 011 000 2404 LXI B,FB.NAM-FB.FLG
052.155 011 2405 DAD B (HL) = ADDRESS FOR NAME IN FILE BLOCK
052.156 021 242 042 2406 LXI D,FBLIST+FB.NAM (DE) = ADDRESS OF NAME IN SYSTEM FILE BLOCK
377.012 2407 ERRPL FB.NAM-256 CODE ASSUMES 1 BYTE VALUE
377.021 2408 ERRPL FB.NAML-256 CODE ASSUMES 1 BYTE VALUE
052.161 016 021 2409 MVI C,FB.NAML (BC) = #FB.NAML
052.163 315 252 030 2410 CALL $MOVE MOVE NAME TO PROPER BLOCK
052.166 315 217 074 2411 CALL FOP FILE OPEN PRESET
052.171 361 2412 POP PSW (A) = CHANNEL NUMBER
052.172 315 005 072 2413 CALL CFA COMPUTE FILE BLOCK ADDRESS
052.175 361 2414 POP PSW (A) = CT.REA OR CT.WRI
052.176 021 100 043 2415 LXI D,DEFALTD USE DATA DEFAULTS
052.201 315 210 052 2416 CALL OPEN4 CALL OPEN ROUTINE
052.204 301 2417 POP B RESTORE TEXT POINTER
052.205 303 115 074 2418 JMP FOC FILE OPEN CLEANUP AND EXIT
                2419
052.210 376 241 OPEN4 CPI CT.REA
052.212 312 021 101 2421 JE $FOPER
052.215 303 030 101 2422 JMP $FOPEW OPEN FOR READ OR WRITE
  
```

2424 ** OUT - OUTPUT TO PORT.

2425 *

2426 * OUT PORT,VALUE

2427

2428

```

052.220 315 235 052 2429 OUT CALL OUT1 EVALUATE PORT AND VALUE
052.223 145 2430 MOV M,L (H) = PORT
052.224 056 323 2431 MVI L,MI.OUT
052.226 042 002 040 2432 SHLD ,IOWRK SET VALUE
052.231 173 2433 MOV A,E (A) = VALUE
052.232 303 002 040 2434 JMP ,IOWRK OUTPUT AND RETURN
                2435
  
```

2436

2437 **

2438

2439 ** OUT1 - EVALUATE ADDRESS,VALUE

```

052.235 315 036 057 2439 OUT1 CALL EVALI
052.240 325 2440 PUSH D SAVE ADDRESS
052.241 315 223 072 2441 CALL CMA REQUIRE ' '
052.244 315 036 057 2442 CALL EVALI (E) = VALUE
052.247 341 2443 POP H (HL) = ADDRESS
052.250 311 2444 RET
  
```

```

2446 ** PAUSE - PAUSE FOR TIME INTERVAL.
2447 *
2448 * PAUSE <IEXP>
2449 *
2450 * PAUSE FOR <IEXP>*2 MILLISECONDS. IF NO TIME IS
2451 * SPECIFIED, PAUSE UNTIL A KEY IS STRUCK.
2452 *
2453 * METHOD OF CALCULATION: (IF IEXP GIVEN)
2454 *
2455 * AT EXAMINE TIME:
2456 *
2457 * IF TARGET => TICCNT
2458 * THEN
2459 * IF TAR. - TIC <> 0
2460 * OR
2461 * IF TAR. - TIC. < 377 000A TIME UP
2462 * ELSE WAIT
2463 *
2464 * IF TARGET < TICCNT
2465 * THEN
2466 * IF TIC. - TAR. < 000 377A , TIME UP
2467 * ELSE WAIT
2468 *
2469 *
052.251 2470 PAUSE EQU *
052.251 315 072 076 2471 CALL PNT CHECK NEXT TOKEN
000.000 2472 ERRNZ CT.FIN
052.254 247 2473 ANA A
052.255 312 233 103 2474 JZ $RCHAR NO PARAMETERS, JUST WAIT
2475
052.260 315 036 057 2476 CALL EVALI DECODE PAUSE INTERVAL
052.263 172 2477 MOV A,D (A) = HIGH ORDER BYTE OF IEXP
052.264 074 2478 INR A
052.265 312 122 070 2479 JZ ERR.IN NUMBER TOO LARGE
052.270 052 033 040 2480 LHLD .TICCNT
052.273 031 2481 DAD D (HL) = TICCNT FINAL VALUE
052.274 353 2482 XCHG
052.275 052 033 040 2483 PAUSE1 LHLD .TICCNT (HL) = TIC COUNTER
052.300 315 224 030 2484 CALL $CHL INVERT IT
052.303 031 2485 DAD D TAR. - TIC.
052.304 332 320 052 2486 JC PAUSE2 TAR. - TIC. => 0
2487
2488 * TAR. < TIC.
2489 *
052.307 315 224 030 2490 CALL $CHL (HL) = TIC. - TAR.
052.312 174 2491 MOV A,H
052.313 247 2492 ANA A
052.314 310 2493 RZ DONE
052.315 303 326 052 2494 JMP PAUSE3 WAIT
2495
2496 * TAR. => TIC.
2497 *
052.320 174 2498 PAUSE2 MOV A,H CHECK FOR TAR. = TIC.
052.321 265 2499 ORA L
052.322 310 2500 RZ DONE
2501

```

```

052.323 174      2502      MOV    A,H
052.324 074      2503      INR    A
052.325 310      2504      RZ          DONE
                2505
052.326 072 142 112 2506 PAUSE3 LDA    CTLFLAG
052.331 247      2507      ANA    A          SEE IF ANY CTL CHARACTERS HIT
052.332 300      2508      RNZ          CONTROL CHARACTER HIT
052.333 303 275 052 2509      JMP    PAUSE1     CONTINUE WAITING
  
```

```

                2511      **      POKE - WRITE VALUE INTO MEMORY.
                2512      *
                2513      *      POKE ADDR,VALUE
                2514
                2515
052.336      2516      POKE    EQU    *
052.336 315 235 052 2517      CALL   OUT1     READ ADDRESS AND VALUE
052.341 143      2518      MOV    M,E       SET VALUE
052.342 311      2519      RET
  
```

```

                2521      ***      POSITION - SET FILE POSITION.
                2522      *
                2523      *      POSITION #N, IEXP.
                2524      *
                2525      *      POSITION FILE #N AT BLOCK IEXP. FILE MUST BE OPEN FOR READ.
                2526
                2527
  
```

```

                2529      **      PRINT - PROCESS PRINT STATEMENT.
                2530      *
                2531      *      PRINT VARLIST
                2532      *
                2533      *      IF VARIABLE SEPERATOR IS ', ', TAB TO NEXT FIELD.
                2534      *      IF SEPERATOR IS '; ', DONT TAB.
                2535      *      IF THE LAST TOKEN IN THE STATEMNET IS ', ' OR '; ', DONT
                2536      *      CR LF AFTER LINE.
                2537
                2538
052.343      2539      PRINT   EQU    *
052.343 257      2540      XRA    A
052.344 062 144 053 2541      STA    PRIA     CLEAR ', OR ;' FLAG
052.347 315 253 073 2542      CALL   DCN     DECODE CHANNEL NUMBER
052.352 041 352 052 2543      PRIi   LXI    H,PRIi
052.355 345      2544      PUSH   H          SET 'RETURN ADDRESS'
052.356 315 072 076 2545      CALL   PNT     PREVIEW NEXT TOKEN
000.000      2546      ERRNZ  CT,FIN
052.361 247      2547      ANA    A
052.362 312 142 053 2548      JZ     PRI7     END OF STATEMENT
  
```

052.365	062	144	053	2549	STA	PRI1	SAVE TYPE	
052.370	376	346		2550	CPI	CT.TAB		
052.372	312	105	053	2551	JE	PRI6	TAB FUNCTION	
052.375	376	343		2552	CPI	CT.SPC		
052.377	312	105	053	2553	JE	PRI6	SPC FUNCTION	
053.002	376	027		2554	CPI	CT.SEM		
053.004	312	056	071	2555	JE	ANT	ACCEPT ' AND GO TO PRI1	
053.007	376	026		2556	CPI	CT.CMA		
053.011	312	040	053	2557	JE	PRI3		
				2558				
				2559	*	MUST BE EXPRESSION.		
				2560				
053.014	315	244	055	2561	CALL	EVAL	EVALUTE EXPRESSION	
053.017	033			2562	DCX	D		
053.020	032			2563	LBAX	D	(A) = TYPE	
053.021	023			2564	INX	D		
053.022	346	001		2565	ANI	CF.STR		
053.024	302	200	100	2566	JNZ	TCS	IS STRING: TYPE CHARACTER STRING	
				2567				
				2568	*	HAVE NUMERIC VALUE.		
				2569				
053.027	041	273	113	2570	PRI2	LXI	H,LINE2	USE SCRATCH AREA
053.032	315	237	110	2571	CALL	FTA	CONVERT FLOATING TO ASCII	
053.035	303	251	100	2572	JMP	WLF.	WRITE LINE TO FILE AND RETURN TO PRI1	
				2573				
				2574	*	HAVE COMMA - SKIP TO NEXT FIELD		
				2575				
053.040	315	056	071	2576	PRI3	CALL	ANT	ACCEPT ,
053.043	315	302	075	2577	CALL	LCC	LOCATE CHANNEL COLUMN COUNTER	
053.046	176			2578	MOV	A,M	(A) = COLUMN COUNTER	
053.047	376	072		2579	CPI	58		
053.050				2580	PRI8	EQU	*-1	TAB LIMITS
053.051	322	225	100	2581	JNC	WEL	OVERFLOW - A NEW LINE	
				2582				
				2583	*	COMPUTE REQUIRED SPACES		
				2584				
053.054	305			2585	PUSH	B		/80.01.GC/
				2586				
053.055	117			2587	MOV	C,A		/80.01.GC/
053.056	006	000		2588	MVI	B,0	BC = COLUMN COUNTER	/80.01.GC/
053.060	013			2589	DCX	B	ON RANGE [O,N]	/80.01.GC/
053.061	021	016	000	2590	LXI	D,14	DE = FIELD SIZE	/80.01.GC/
053.062				2591	PRI3	EQU	*-2	/80.01.GC/
053.064	315	106	030	2592	CALL	\$DU66	DE = REMAINDER	/80.01.GC/
053.067	301			2593	POP	B		/80.01.GC/
053.070	072	062	053	2594	LDA	PRI3	A = FIELD SIZE	/80.01.GC/
053.073	223			2595	SUB	E	A = NUMBER OF SPACES REQUIRED	/80.01.GC/
				2596				
053.074	247			2597	PRI5	ANA	A	
053.075	310			2598	RZ		NO MORE SPACES	/80.01.GC/
053.076	315	156	053	2599	CALL	PRI8	OUTPUT A SPACE	/80.01.GC/
053.101	075			2600	DCR	A		
053.102	303	074	053	2601	JMP	PRI5		
				2602				
				2603	*	HAVE TAB OR SPC FUNCTION		
				2604				

```

053.105 315 056 071 2605 PRI6 CALL ANT ACCEPT TAB OR SPC
053.110 365 2606 PUSH PSW SAVE FUNCTION TYPE
053.111 315 044 057 2607 CALL EVALI8 EVALUTE COUNT
053.114 315 305 077 2608 CALL RNT
053.117 020 2609 DB CT,PAR REQUIRE ')'
053.120 361 2610 POP PSW
053.121 376 343 2611 CPI CT,SPC
053.123 173 2612 MOV A,E (A) = COUNT IF SPACE
053.124 312 074 053 2613 JE PR15 IS SPC
053.127 315 302 075 2614 CALL LCC LOCATE CHANNEL COLUMN COUNTER /80.01.GC/
053.132 176 2615 MOV A,M (A) = COLUMN
053.133 223 2616 SUB E
053.134 057 2617 CMA
053.135 074 2618 INR A
053.136 362 074 053 2619 JP PR15 NOT PAST IT /78.10.GC/
053.141 311 2620 RET ALREADY PAST - DO NOTHING
2621
2622 * HAVE END OF LINE
2623
053.142 341 2624 PRI7 POP H DISCARD 'RETURN' ADDRESS
053.143 076 000 2625 MVI A,0
053.144 2626 PRIA EQU *-1
053.145 376 026 2627 CPI CT,CMA CHECK TEYP OF LAST TOKEN
053.147 310 2628 RE COMMA
053.150 376 027 2629 CPI CT,SEM
053.152 310 2630 RE
053.153 303 225 100 2631 JMP WEL END LINE
2632
2633 * OUTPUT A SPACE
2634 /80.01.GC/
053.156 365 2635 PRI8 PUSH PSW
053.157 041 207 112 2636 LXI H,SPACE /80.01.GC/
053.162 076 001 2637 MVI A,1 /80.01.GC/
053.164 315 251 100 2638 CALL WLF, COUNT = 1 /80.01.GC/
053.167 361 2639 POP PSW WRITE CHARACTER TO THE FILE /80.01.GC/
053.170 311 2640 RET

```

```

2642 ** READ - READ FROM DATA STATEMENT.
2643 *
2644 * READ PERFORMS READS FROM DATA STATEMENTS.
2645 *
2646 * THE 1ST DATA STATEMENT IS FOUND AND USED, THEN THE 2ND,
2647 * ETC.
2648
2649
053.171 2650 READ EQU *
053.171 052 303 114 2651 LHL DATPTR (HL) = DATA STATEMENT POINTER
053.174 315 135 076 2652 REA1 CALL PVI PERFORM VALUE INPUT
053.177 042 303 114 2653 SHLD DATPTR SAVE FOR NEXT TIME
053.202 310 2654 RE NO MORE DATA NEEDED
2655
2656 * SCAN FOR NEXT DATA STATEMENT
2657

```

READ

```

053.203 176      2658 REA2  MOV  A,H
053.204 043      2659      INX  H
053.205 247      2660      ANA  A
053.206 302 203 053 2661      JNZ  REA2      NOT AT END OF STATEMENT
053.211 176      2662      MOV  A,H
053.212 043      2663      INX  H
053.213 246      2664      ANA  H
053.214 043      2665      INX  H
053.215 074      2666      INR  A
053.216 312 114 070 2667      JZ   ERR.DE    DATA EXHAUSED AT LINE 377377A
053.221 176      2668      MOV  A,H
053.222 376 251      2669      CPI  CT,DAT
053.224 302 203 053 2670      JNE  REA2      NOT DATA
053.227 043      2671      INX  H
053.230 303 174 053 2672      JMP  REA1      READ NEW DATA STATEMENT
  
```

```

2674 **      REPLACE - SAVE PROGRAM OVERTOP ANY EXISTING PROGRAM.
2675 *
2676 *      REPLACE <STRING>
2677 *
2678 *      SAME AS SAVE, BUT DOESNT SQUAK IF ALREADY EXISTS.
2679
2680
  
```

```

053.233      2681 REPLACE EQU  *
053.233 315 041 072 2682      CALL  CFN,    COPY FILE NAME AND FILE OPEN PRESET
053.236 305      2683      PUSH B        SAVE (BC)
053.237 303 324 053 2684      JMP  SAVE1    SAVE IT
  
```

```

2686 **      RETURN - RETURN FROM GOSUB.
2687 *
2688
2689
  
```

```

053.242 052 076 112 2690 RETURN  LHLD  GOSTAB+MT.FWA
053.245 353      2691      XCHG      (DE) = FWA
053.246 052 100 112 2692      LHLD  GOSTAB+MT.LEN
053.251 174      2693      MOV  A,H
053.252 265      2694      ORA  L
053.253 312 141 070 2695      JZ   ERR.RE    RETURN ERROR
053.256 053      2696      DCX  H
053.257 053      2697      DCX  H
053.260 053      2698      DCX  H
053.261 053      2699      DCX  H
053.262 042 100 112 2700      SHLD GOSTAB+MT.LEN  SET REDUCED SIZE
053.265 031      2701      DAD  D        (HL) = ABS ADDRESS OF ENTRY
053.266 116      2702      MOV  C,H
053.267 043      2703      INX  H
053.270 106      2704      MOV  B,H      (BC) = RETURN ADDRESS
053.271 043      2705      INX  H
053.272 176      2706      MOV  A,H
053.273 043      2707      INX  H
  
```

053.274	146		2708	MOV	H,M	
053.275	157		2709	MOV	L,A	
053.276	042	133 112	2710	SNLD	CURNUM	(HL) = OLD LINE NUMBER
053.301	311		2711	RET		
			2713	***	SAVE - SAVE PROGRAM ON DISK.	
			2714	*		
			2715	*	SAVE <FNAME>	
			2716	*		
			2717	*	WILL COMPLAIN IF FILE ALREADY EXISTS.	
			2718			
			2719			
053.302			2720	SAVE	EQU	*
053.302	315	041 072	2721	CALL	CFN,	COPY FILE NAME AND FILE OPEN PRESET
053.305	305		2722	PUSH	B	SAVE (BC)
053.306	021	072 043	2723	LXI	D,DEFALTP	PROGRAM DEFAULT
053.311	315	046 101	2724	CALL	\$FOPER,	OPEN FILE
053.314	322	177 070	2725	JNC	ERR,FAE	FILE ALREADY EXISTS
053.317	376	014	2726	CPI	EC,FNF	
053.321	302	223 070	2727	JNE	\$FERROR	NON-EXPECTED ERROR
			2728			
			2729	*	ENTERED HERE FROM 'REPLACE' TO SAVE FILE REGARDLESS	
			2730			
053.324	021	072 043	2731	SAVE1	LXI	D,DEFALTP (DE) = DEFAULTS FOR SAVE
053.327	315	030 101	2732	CALL	\$FOPEW	OPEN FOR WRITE, THEN
053.332	301		2733	POP	B	RESTORE TEXT POINTER
			2734			
			2735	*	FILE IS OPEN, LIST PROGRAM TO IT	
			2736			
053.333	076	001	2737	MVI	A,1	
053.335	062	140 112	2738	STA	IOCHAN	SET I/O CHANNEL
053.340	345		2739	PUSH	H	SAVE ADDRESS OF BUFFER
053.341	315	023 051	2740	CALL	LIST,	LIST TO FILE /78.10.GC/
053.344	341		2741	POP	H	
053.345	315	335 102	2742	CALL	\$FCLO	CLOSE IT
053.350	001	345 114	2743	LXI	B,ZERO	
053.353	303	115 074	2744	JMP	FOC	FILE OPEN CLEANUP, AND EXIT
			2746	**	STEP - PERFORM SINGLE STEPPING.	
			2747	*		
			2748	*	STEP I	
			2749	*		
			2750			
			2751			
053.356	315	072 076	2752	STEP	CALL	PNT PREVIEW NEXT TOKEN
053.361	127		2753	MOV	D,A	
053.362	137		2754	MOV	E,A	
000.000			2755	ERRNZ	CT,FIN	
053.363	247		2756	ANA	A	
053.364	304	036 057	2757	CNZ	EVALI	EVALUATE COUNT

ADDRESS	PC	SP	BP	STEP	OPCODE	OPERANDS	COMMENT
053.367	315	305	077		CALL	RNT	FLUSH TOKEN PIPELINE
053.372	000				DB	CT.FIN	
053.373	033				DCX	D	
							2760
							2761
053.374	325			STEP1	PUSH	D	SAVE COUNT
053.375	076	001			MVI	A,RM.STE	
053.377	315	165	045		CALL	CONT1	STEP 1
054.002	321				POP	D	
054.003	033				DCX	D	
054.004	172				MOV	A,D	
054.005	247				ANA	A	
054.006	362	374	053		JP	STEP1	MORE TO GO
054.011	315	136	031		CALL	\$TYPTX	
054.014	116	145	170		DB	'Next',''+2000	
054.021	052	133	112		LHLD	CURNUM	
054.024	353				XCHG		
054.025	303	264	047		JMP	TBI.	TYPE AS DECIMAL INTEGER

2774 ** STOP - STOP EXECUTION.

2777 *
 2778 *
 2779 *

054.030	315	201	044	STOP	CALL	EXEC7	STORE RC
054.033	076	225			MVI	A,BEC.ST	
054.035	365				PUSH	PSW	
054.036	303	063	075		JMP	ILM	ISSUE LINE MESSAGE

2785 *** UNFREEZE - UNFREEZE FROZEN PROGRAM.

2786 *
 2787 * UNFREEZE <FNAME>
 2788 *
 2789 * SAME AS *RUN SY0:FNAME.BAF*
 2790 *
 2791 *

054.041				UNFREZ	EQU	*	
054.041	315	313	075		CALL	LFC	CHECK FOR DATA LOCK
054.044	315	103	054		CALL	UNSAVE1	PRESET
054.047	021	057	054		LXI	D,UNFREZA	
054.052	377	040			DB	SYSCALL,.LINK	LINK IT
054.054	303	223	070		JMP	\$FERROR	GOT PROBLEMS
							2798
054.057	123	131	060	UNFREZA	DB	'SYOBAF'	DEFAULT BLOCK

```

2801 *** UNSAVE - DELETE PROGRAM.
2802 *
2803 * UNSAVE <FNAME>
2804
2805
2806
054.065 2807 UNSAVE EQU *
054.065 315 103 054 2808 CALL UNSAVE1 PRESET
054.070 021 072 043 2809 LXI D,DEFAULT PROGRAM DEFAULTS
054.073 305 2810 PUSH B
054.074 377 050 2811 DB SYSCALL,DELET DELETE IT
054.076 301 2812 POP B (BC) = TEXT POINTER
054.077 320 2813 RNC NO ERROR
054.100 303 223 070 2814 JMP $FERROR FLAG ERROR
2815
2816
2817 ** GET READY FOR OPERATION
2818
054.103 315 053 072 2819 UNSAVE1 CALL CFN CRACK FILE NAME
054.106 021 012 000 2820 LXI D,FB.NAM
054.111 031 2821 DAD D
054.112 353 2822 XCHG
054.113 041 273 113 2823 LXI H,LINE2
054.116 305 2824 PUSH B
054.117 001 021 000 2825 LXI B,FB.NAML
054.122 345 2826 PUSH H SAVE #FOPWRK
054.123 315 252 030 2827 CALL $MOVE MOVE IN NAME
054.126 341 2828 POP H
054.127 301 2829 POP B
054.130 311 2830 RET
  
```

```

2834 **      LEXCAL - PERFORM LEXICAL ANALYSIS.
2835 *
2836 *      LEXCAL PARSSES THE NEXT TOKEN FROM THE SOURCE LINE.
2837 *
2838 *      IF THE VARIABLE HAS NOT BEEN DEFINED, A SPECIAL ADDRESS,
2839 *      *LEXC* IS RETURNED, THIS ADDRESS CONTAINS A 0 OR A NULL STRING,
2840 *      DEPENDING UPON THE VARIABLE TYPE.
2841 *
2842 *      ENTRY (BC) = SOURCE TEXT POINTER
2843 *      EXIT (A) = TYPE (CT, CODE)
2844 *      (DE) = SYMTAB ENTRY ADDRESS+2 (IF SYMBOL)
2845 *      'C' SET IF VARIABLE AND NOT DEFINED
2846 *      (DE) = LEXC
2847 *      LEXA = VARIABLE NAM
2848 *      USES  A,F,B,C,D,E
2849 *
2850
054.131      2851 LEXCAL EQU *
054.131 315 126 100 2852 CALL SOB          SKIP OVER BLANKS
054.134 315 230 072 2853 CALL CMC          CLASSIFY NEXT CHARACTER
000.000      2854 ERRNZ CT,FIN
054.137 247      2855 ANA A
054.140 310      2856 RZ              IS CT,FIN
054.141 003      2857 INX B          ACCEPT CHARACTER
054.142 370      2858 RM              IS KEYWORD
054.143 376 030  2859 CPI CT,QUO
054.145 312 015 055 2860 JE LEX12       HAVE STRING
054.150 376 014  2861 CFI CT,LT
054.152 314 354 054 2862 CE LEX10       IS <
054.155 376 012  2863 CFI CT,GT
054.157 314 377 054 2864 CE LEX11       HAVE >
054.162 376 001  2865 CFI CT,ALP
054.164 312 231 054 2866 JE LEX1        IS ALPHARETIC
054.167 376 002  2867 CFI CT,NUM
054.171 312 202 054 2868 JE LEX0        IS NUMERIC VALUE
054.174 376 003  2869 CPI CT,SEP
054.176 300      2870 RNE            IS SOME KNOWN CHARACTER
054.177 303 174 070 2871 JMP ERR,IC     ILLEGAL CHARACTER
2872
2873 *      IS NUMERIC VALUE, FLOAT IT.
2874
054.202 013      2875 LEX0 DCX B     (BC) = ADDRESS OF FIRST DIGIT
054.203 353      2876 XCHG          SAVE (HL) IN (DE)
054.204 140      2877 MOV H,B
054.205 151      2878 MOV L,C
054.206 315 323 107 2879 CALL ATF       ASCII TO FLOATING
054.211 104      2880 MOV B,H
054.212 115      2881 MOV C,L
054.213 353      2882 XCHG          RESTORE (HL)
054.214 021 222 042 2883 LXI D,LEXB
054.217 315 237 073 2884 CALL CXV       COPY NUMBER INTO 'LEXB' HOLD AREA
054.222 076 300  2885 MVI A,3000    SET TYPE
054.224 247      2886 ANA A         CLEAR CARRY
054.225 062 221 042 2887 STA LEXB-1    SET TYPE
054.230 311      2888 RET
2889

```

```

2890 * IS ALPHABETIC. MUST BE VARIABLE.
2891
054.231 2892 LEX1 EQU X
054.231 013 2893 DCX B POINT TO 1ST CHAR OF NAME
054.232 012 2894 LDAX B (A) = 1ST CHARACTER OF NAME
054.233 315 045 112 2895 CALL $MCU MAP CHARACTER TO UPPER CASE
054.236 127 2896 MOV D,A
054.237 036 000 2897 MVI E,0 (DE) = VARIABLE NAME
054.241 003 2898 INX B
054.242 012 2899 LDAX B
054.243 326 060 2900 SUI '0'
054.245 332 264 054 2901 JC LEX2 NOT NUMBER
054.250 376 012 2902 CPI 9+1
054.252 322 264 054 2903 JNC LEX2 NOT NUMBER
054.255 074 2904 INR A DIFFERENTIATE BETWEEN X AND X0
054.256 007 2905 RLC
054.257 007 2906 RLC
054.260 007 2907 RLC
054.261 007 2908 RLC
054.262 137 2909 MOV E,A (E) = NUMBER INDEX
054.263 003 2910 INX B ADVANCE PAST NUMBER
2911
2912 * HAVE VARIABLE NAME IN (DE), CHECK FOR $ AND (
2913
054.264 012 2914 LEX2 LDAX B
054.265 376 044 2915 CPI '$'
054.267 302 274 054 2916 JNE LEX3 NOT $
054.272 003 2917 INX B
000.000 2918 ERRNZ CF,STR-1
054.273 034 2919 INR E SET CF,STR
054.274 315 126 100 2920 LEX3 CALL SOB SKIP OVER BLANKS
054.277 012 2921 LDAX B
054.300 376 050 2922 CPI '('
054.302 302 312 054 2923 JNE LEX3.5
054.305 003 2924 INX B
054.306 076 002 2925 MVI A,CF,VEC SET VECTOR TYPE
054.310 263 2926 ORA E SET VECTOR TYPE
054.311 137 2927 MOV E,A
2928
2929 * (DE) = VARIABLE NAME AND TYPE. FIND IN SYMTAB
2930
054.312 345 2931 LEX3.5 PUSH H /80.01.GC/
054.313 325 2932 PUSH D /80.01.GC/
054.314 315 323 075 2933 CALL LVS DE = SYMTAB ADDRESS
054.317 341 2934 POP H HL = SAVED TYPE
054.320 023 2935 INX D /80.01.GC/
054.321 302 334 054 2936 JNZ LEX7 /80.01.GC/
2937
2938 * HAVE FOUND MATCH.
2939
054.324 032 2940 LDAX D /80.01.GC/
054.325 023 2941 INX D /80.01.GC/
054.326 346 007 2942 ANI 7 (A) = TYPE CODE
054.330 366 300 2943 ORI 3000
054.332 341 2944 POP H RESTORE (HL)
054.333 311 2945 RET
  
```

```

2946
2947 * ITEM NOT IN TABLE.
2948 *
2949 * RETURN NULL OR ZERO VALUE.
2950
054.334 042 236 075 2951 LEX7 SHLD LEXA SAVE
054.337 175 2952 MOV A,L (A) = FLAG FIELD OF NAME
054.340 021 214 042 2953 LXI D,LEXC-1 (DE) = RESULT POINTER-1
054.343 346 007 2954 ANI 7 STRIP FLAGS
054.345 366 300 2955 ORI 3000 SET VARIABLE TYPE
054.347 022 2956 STAX D SET TYPE
054.350 023 2957 INX D SET RESULT POINTER
054.351 341 2958 POP H RESTORE (HL)
054.352 067 2959 STC FLAG UNDEFINED
054.353 311 2960 RET
2961
2962 * HAVE <, SEE IF <= OR <>
2963
054.354 012 2964 LEX10 LDAX B
054.355 003 2965 INX B ASSUME IS <= OR <>
054.356 376 075 2966 CPI '='
054.360 076 015 2967 MVI A,CT,LE ASSUME <=
054.362 310 2968 RE
054.363 013 2969 DCX B GET TESTING CHARACTER
054.364 012 2970 LDAX B
054.365 003 2971 INX B RESTORE (BC)
054.366 376 076 2972 CPI '>'
054.370 076 016 2973 MVI A,CT,NE ASSUME <>
054.372 310 2974 RE IS <>
054.373 076 014 2975 MVI A,CT,LT IS JUST <
054.375 013 2976 DCX B
054.376 311 2977 RET
2978
2979 * HAVE >, SEE IF >=
2980
054.377 012 2981 LEX11 LDAX B
055.000 003 2982 INX B ASSUME IS >=
055.001 376 075 2983 CPI '='
055.003 076 013 2984 MVI A,CT,GE
055.005 310 2985 RE IS <=
055.006 076 012 2986 MVI A,CT,GT IS >
055.010 013 2987 DCX B
055.011 311 2988 RET
2989
2990
2991 ** LEX12 - PUT TEXT STRING INTO STRINGTABLE AS TEMP STRING.
2992 *
2993 * ENTRY (BC) = ADDRESS OF 1ST CHARACTER
2994 * EXIT LEXB = STRING HEADER
2995 * (DE) = #LEXB
2996 * USES A,F,B,C,D,E
2997
055.012 076 000 2998 LEX11.5 MVI A,0
2999
055.014 021 3000 DB HI,LEXID USE 'LXI,D' TO GOBBLE NEXT MVI
055.015 076 042 3001 LEX12 MVI A,' '

```

LEXCAL

				3002				
055.017	062	033	055	3003	STA	LEXD		SET END OF STRING MATCH CHARACTER
055.022	345			3004	PUSH	H		SAVE (HL)
055.023	305			3005	PUSH	B		SAVE TEXT POINTER
055.024	041	377	377	3006	LXI	H,-1		(HL) = CHARACTER COUNTER
055.027	012			3007	LEX13	LDAX	B	
055.030	003			3008		INX	B	
055.031	043			3009		INX	H	
055.032	376	042		3010		CPI	??	
055.033				3011	LEXD	EQU	*-1	END OF STRING MATCH
055.034	312	044	055	3012		JE	LEX14	GOT END QUOTE
055.037	247			3013		ANA	A	
055.040	302	027	055	3014		JNZ	LEX13	NOT AT END OF LINE
055.043	053			3015		DCX	H	RAN OFF END OF LINE, DONT COUNT 00 BYTE
				3016				
055.044	174			3017	LEX14	MOV	A,H	
055.045	247			3018		ANA	A	
055.046	302	144	070	3019		JNZ	ERR,SL	STRING LENGTH ERROR
055.051	345			3020		PUSH	H	SAVE LENGTH IN (L)
055.052	042	222	042	3021		SHLD	LEXB	SET IN DESCRIPTOR
055.055	021	222	042	3022		LXI	D,LEXB	
055.060	315	033	073	3023		CALL	CSE,	CREATE TEMP STRING TAB ENTRY
055.063	301			3024		POP	B	(BC) = COUNT
055.064	321			3025		POP	D	(DE) = FROM ADDRESS
055.065	315	252	030	3026		CALL	#MOVE	COPY STRING INTO TEMP
055.070	102			3027		MOV	B,D	
055.071	113			3028		MOV	C,E	
055.072	003			3029		INX	B	
055.073	076	301		3030		MVI	A,CT,SSV	SCALAR STRING VALUE
055.075	021	221	042	3031		LXI	D,LEXB-1	
055.100	022			3032		STAX	D	SET TYPE
055.101	023			3033		INX	D	(DE) = DESCRIPTOR POINTER
055.102	341			3034		POP	H	RESTORE (HL)
055.103	311			3035		RET		

```

3039 ** VARIAB - DECODE VARIABLE.
3040 *
3041 * VARIAB IS CALLED TO EVALUATE A VARIABLE SPECIFICATION.
3042 * VARIAB RESOLVES SUBSCRIPTS.
3043 *
3044 * ENTRY (BC) = TEXT POINTER
3045 * EXIT (BC) UPDATED
3046 * (DE) = VARIABLE POINTER
3047 * USES A,F,B,C,D,E
3048
3049
055.104 3050 VARIAB EQU *
055.104 315 056 071 3051 CALL ANT ACCEPT NEXT TOKEN
055.107 365 3052 VARIAB PUSH PSW SAVE TYPE
055.110 346 002 3053 ANI CF,VEC
055.112 302 117 055 3054 JNZ VAR2 IS VECTOR
055.115 361 3055 POP PSW
055.116 311 3056 RET IS SIMPLE VARIABLE
3057
3058 * HAVE SUBSCRIPT.
3059
055.117 345 3060 VAR2 PUSH H
055.120 032 3061 LDAX D (A) = DIMENSION COUNT
055.121 247 3062 ANA A
055.122 372 152 070 3063 JM ERR.SY IS FUNCTION
055.125 312 171 070 3064 JZ ERR.ND NOT DECLARED
3065
3066 * EVALUATE SUBSCRIPT.
3067
055.130 353 3068 XCHG (HL) = SUBSCRIPT LIST-2
055.131 043 3069 INX H
055.132 043 3070 INX H
055.133 021 000 000 3071 LXI D,0 (DE) = INDEX
3072
055.136 365 3073 VAR4 PUSH PSW
055.137 043 3074 INX H
055.140 043 3075 INX H POINT TO NEXT SUBSCRIPT LIMIT
055.141 345 3076 PUSH H SAVE VECTOR POINTER
055.142 305 3077 PUSH B SAVE (BC)
055.143 116 3078 MOV C,M
055.144 043 3079 INX H
055.145 106 3080 MOV B,M (BC) = LIMIT
055.146 305 3081 PUSH B SAVE LIMIT
055.147 315 337 030 3082 CALL $MU66 (HL) = NEW INDEX
055.152 321 3083 POP D (DE) = NEW LIMIT
055.153 301 3084 POP B (BC) = TEXT POINTER
055.154 345 3085 PUSH H SAVE INDEX
055.155 325 3086 PUSH D SAVE LIM
055.156 315 036 057 3087 CALL EVALI EVALUATE SUBSCRIPT
055.161 341 3088 POP H (HL) = LIM
055.162 053 3089 DCX H
055.163 175 3090 MOV A,L
055.164 223 3091 SUB E
055.165 174 3092 MOV A,H
055.166 232 3093 SBB D
055.167 332 163 070 3094 JC ERR.SR SUBSCRIPT RANGE
  
```

VARIAB - DECODE VARIABLE.

VARIAB

15:45:28 16-MAY-80

055.172	341		3095	POP	H	(HL) = INDEX
055.173	031		3096	DAD	D	(HL) = NEW INDEX
055.174	353		3097	XCHG		
055.175	341		3098	POP	H	(HL) = SYMTAB POINTER
055.176	361		3099	POP	PSW	
055.177	075		3100	DCR	A	
055.200	312	220	055	JZ	VAR5	NO MORE SUBSCRIPTS
			3101			
			3102			
			3103	*	EXPECT ,	
			3104			
055.203	365		3105	PUSH	PSW	
055.204	315	056	071	CALL	ANT	ACCEPT NEXT TOKEN
055.207	376	026		CPI	CT.CMA	
055.211	302	166	070	JNE	ERR.SC	NOT ENOUGH SUBSCRIPTS
055.214	361		3109	POP	PSW	(A) = REMAINING SUBSCRIPT COUNT
055.215	303	136	055	JMP	VAR4	READ NEXT
			3110			
			3111			
			3112	*	EXPECT .)	
			3113			
055.220	315	056	071	VAR5	CALL	ANT
055.223	376	020		CPI	CT.PAR	ACCEPT NEXT TOKEN
055.225	302	166	070	JNE	ERR.SC	TOO MANY SUBSCRIPTS
			3116			
			3117			
			3118	*	SUBSCRIPT EVALUATED. (DE) = INDEX	
			3119			
055.230	043		3120	INX	H	
055.231	043		3121	INX	H	
055.232	353		3122	XCHG		
055.233	051		3123	DAD	H	
055.234	051		3124	DAD	H	
055.235	031		3125	DAD	D	
055.236	353		3126	XCHG		(DE) = ADDRESS OF ENTRY IN SYMTAB
055.237	341		3127	POP	H	
055.240	361		3128	POP	PSW	
055.241	346	375	3129	ANI	3770-CF.VEC	CLEAR VECTOR TYPE
055.243	311		3130	RET		


```

3133 ** EVAL - EVALUATES AN EXPRESSION.
3134 *
3135 * EVAL EVALUATES EXPRESSIONS MADE UP OF OPERATORS AND
3136 * SYMBOLS.
3137 *
3138 * VALID OPERATORS ARE (IN ORDER OF PRECEDENCE)
3139 *
3140 * - NOT (UNARY MINUS, NOT)
3141 * (EXPONENTIATION)
3142 * */,
3143 * +,-
3144 * < <= = <> >= >
3145 * AND
3146 * OR
3147 *
3148 * EVAL PROCESSES EXPRESSIONS UNTIL AN INAPPROPRIATE TOKEN IS
3149 * ENCOUNTERED.
3150 *
3151 *
3152 * ENTRY (BC) = TEXT POINTER
3153 * EXIT (BC) UPDATED
3154 * (DE) = VALUE POINTER
3155 * USES A,F,B,C,D,E
3156 *
3157 *
055.244 3158 EVAL EQU *
055.244 345 3159 PUSH H SAVE (HL)
055.245 315 255 055 3160 CALL LEV1
055.250 341 3161 POP H RESTORE (HL)
055.251 021 202 042 3162 LXI D,ACCX (DE) = RESULT ADDRESS
055.254 311 3163 RET

3165
3166 ** LEV1 - OR
3167 *
055.255 315 304 055 3168 LEV1 CALL LEV2
055.260 376 315 3169 LEV11 CPI CT,OR
055.262 300 3170 RNE NOT 'OR'
055.263 315 030 077 3171 CALL PSHX. ACCEPT '-' AND SAVE ACCX
055.266 315 304 055 3172 CALL LEV2
055.271 315 365 076 3173 CALL POPY
055.274 365 3174 PUSH PSW SAVE TYPE
055.275 315 323 061 3175 CALL P,OR PREFORM 'OR'
055.300 361 3176 POP PSW
055.301 303 260 055 3177 JMP LEV11
3178
3179 * LEV2 - AND
3180 *
055.304 315 333 055 3181 LEV2 CALL LEV3
055.307 376 310 3182 LEV21 CPI CT,AND
055.311 300 3183 RNE
055.312 315 030 077 3184 CALL PSHX. ACCEPT 'AND' AND SAVE ACCX
055.315 315 333 055 3185 CALL LEV3
055.320 315 365 076 3186 CALL POPY
    
```

055.323	365			3187		PUSH	PSW	
055.324	315	336	061	3188		CALL	P.AND	PERFORM AND
055.327	361			3189		POP	PSW	
055.330	303	307	055	3190		JMP	LEV21	
055.333				3191	LEV3	EQU	*	NOT USED
				3192				
				3193	*	LEV4	-	COMPARE OPERATORS.
				3194				
055.333	315	367	055	3195	LEV4	CALL	LEV5	
055.336	376	011		3196	LEV41	CPI	CT.EQ	
055.340	330			3197		RC		NOT COMPARE
055.341	376	017		3198		CPI	CT.NE+1	
055.343	320			3199		RNC		NOT COMPARE
055.344	365			3200		PUSH	PSW	SAVE TYPE
055.345	315	030	077	3201		CALL	PSHX.	ACCEPT OPERATOR AND SAVE ACCX
055.350	315	367	055	3202		CALL	LEV5	
055.353	315	365	076	3203		CALL	POPY	
055.356	341			3204		POP	H	(H) = COMPARE TYPE
055.357	365			3205		PUSH	PSW	SAVE NEXT TYPE
055.360	315	375	061	3206		CALL	P.CMP	BO BOOLEAN
055.363	361			3207		POP	PSW	
055.364	303	336	055	3208		JMP	LEV41	
				3209				
				3210	*	LEV5	- +, -	
				3211				
055.367	315	025	056	3212	LEV5	CALL	LEV6	
055.372	376	021		3213	LEV51	CPI	CT.PL	
055.374	312	002	056	3214		JE	LEV52	IS +
055.377	376	022		3215		CPI	CT.MI	
056.001	300			3216		RNE		NOT + OR -
056.002	365			3217	LEV52	PUSH	PSW	SAVE TYPE
056.003	315	030	077	3218		CALL	PSHX.	ACCEPT OPERATOR AND SAVE ACCX
056.006	315	025	056	3219		CALL	LEV6	
056.011	315	365	076	3220		CALL	POPY	
056.014	341			3221		POP	H	(H) = TYPE
056.015	365			3222		PUSH	PSW	
056.016	315	134	062	3223		CALL	P.ADD	
056.021	361			3224		POP	PSW	
056.022	303	372	055	3225		JMP	LEV51	
				3226				
				3227	*	LEV6	- * /	
				3228				
056.025	315	063	056	3229	LEV6	CALL	LEV7	
056.030	376	023		3230	LEV61	CPI	CT.MU	
056.032	312	040	056	3231		JE	LEV62	IS *
056.035	376	024		3232		CPI	CT.DI	
056.037	300			3233		RNE		NOT * /
056.040	365			3234	LEV62	PUSH	PSW	
056.041	315	030	077	3235		CALL	PSHX.	ACCEPT OPERATOR AND SAVE ACCX
056.044	315	063	056	3236		CALL	LEV7	
056.047	315	365	076	3237		CALL	POPY	
056.052	341			3238		POP	H	(HL) = TYPE
056.053	365			3239		PUSH	PSW	
056.054	315	247	062	3240		CALL	P.MUL	
056.057	361			3241		POP	PSW	
056.060	303	030	056	3242		JMP	LEV61	

```

3243
3244 *      LEV7 -
3245
056.063 315 112 056 3246 LEV7 CALL LEV8
056.066 376 028 3247 LEV71 CPI CT.EX
056.070 300 3248 RNE
056.071 315 030 077 3249 CALL PSHX. NOT EXPONENTIAL
                                ACCEPT * AND SAVE ACCX
056.074 315 112 056 3250 CALL LEV8
056.077 315 365 076 3251 CALL POPY
056.102 365 3252 PUSH PSW
056.103 315 270 062 3253 CALL P.EXP
056.106 361 3254 POP PSW
056.107 303 066 056 3255 JMP LEV71
3256
3257 *      LEV8 - UNARY - NOT
3258
056.112 315 072 076 3259 LEV8 CALL PNT FEEL AT NEXT TOKEN
056.115 376 022 3260 CPI CT.MI
056.117 312 127 056 3261 JE LEV81 IS MINUS
056.122 376 314 3262 CPI CT.NOT
056.124 302 170 056 3263 JNE LEV9 NOT - OR NOT
056.127 315 056 071 3264 LEV81 CALL ANT READ '-' OR 'NOT'
056.132 365 3265 PUSH PSW SAVE TYPE
056.133 315 170 056 3266 CALL LEV9 PROCESS OPERAND
056.136 341 3267 POP H (H) = TYPE
056.137 365 3268 PUSH PSW SAVE NEXT TOKEN CODE
056.140 072 201 042 3269 LDA ACCX-1
056.143 346 001 3270 ANI CF.STR
056.145 302 155 070 3271 JNZ ERR.TC MUST BE NUMERIC
056.150 174 3272 MOV A,H
056.151 376 022 3273 CPI CT.MI
056.153 302 163 056 3274 JNE LEV82 IS NOT
3275
3276 *      IS -
3277
056.156 315 302 105 3278 CALL FPNEG
056.161 361 3279 POP PSW (A) = CODE FOR NEXT TOKEN
056.162 311 3280 RET
3281
3282 *      IS NOT
3283
056.163 315 351 061 3284 LEV82 CALL P.NOT
056.166 361 3285 POP PSW
056.167 311 3286 RET
3287
3288 *      LEV9 - TOKEN
3289
056.170 315 072 076 3290 LEV9 CALL PNT PREVIEW NEXT TOKEN
056.173 376 300 3291 CFI CT.VARL
056.175 332 234 056 3292 JC LEV92 NOT VARIABLE
056.200 376 310 3293 CFI CT.VARH+1
056.202 322 234 056 3294 JNC LEV92 NOT VARIABLE
3295
3296 *      IS VARIABLE.
3297
056.205 315 104 055 3298 CALL VARIAB DECODE
    
```

```

056.210 041 201 042 3299 LXI H,ACCX-1
056.213 167 3300 MOV M,A
056.214 043 3301 INX H
056.215 305 3302 PUSH B SAVE (BC)
056.216 006 004 3303 MVI B,4 (B) = LOOP COUNT
056.220 032 3304 LEV95 LDAX D
056.221 167 3305 MOV M,A COPY VALUE INTO ACCX
056.222 023 3306 INX D
056.223 043 3307 INX H
056.224 005 3308 DCR B
056.225 302 220 056 3309 JNZ LEV95
056.230 301 3310 POP B RESTORE (BC)
056.231 303 072 076 3311 JMP PNT PREVIEW NEXT TOKEN AND EXIT
3312
056.234 315 056 071 3313 LEV92 CALL ANT ACCEPT TOKEN
056.237 376 017 3314 CPI CT,FAL
056.241 302 256 056 3315 JNE LEV93 NOT (
056.244 315 244 055 3316 CALL EVAL IS PARENTHESISED EXPRESSION
3317
3318 * FUNCTION COMPLETE, REQUIRE ')'
3319
056.247 315 305 077 3320 LEV94 CALL RNT
056.252 020 3321 DB CT,PAR REQUIRE ')'
056.253 303 072 076 3322 JMP PNT READ NEXT TOKEN AND EXIT
3323
056.256 376 220 3324 LEV93 CPI CT,FCN
056.260 312 340 062 3325 JE TXTFN TEXT FUNCTION
3326
3327 * IS NOT SIMPLE STRING OR VALUE, MUST BE FUNCTION
3328
056.263 326 320 3329 SUI CT,FCN
056.265 332 152 070 3330 JC ERR,SY NOT FUNCTION
056.270 365 3331 PUSH PSW
056.271 315 244 055 3332 CALL EVAL EVALUATE INWARDS
056.274 361 3333 POP PSW
056.275 365 3334 PUSH PSW (A) = FUNCTION INDEX
056.276 376 030 3335 CPI CT,SRA-CT,FCN
056.300 072 201 042 3336 LDA ACCX-1 (A) = PARAMETER TYPE
056.303 332 307 056 3337 JC LEV90 REQUIRE NUMERIC ARGUMENT
056.306 057 3338 CMA
056.307 346 001 3339 LEV90 ANI CF,STR
056.311 302 155 070 3340 JNZ ERR,TC TYPE CONFLICT
056.314 361 3341 POP PSW (A) = FUNCTION CODE
056.315 041 247 056 3342 LXI H,LEV94
056.320 345 3343 PUSH H SAVE 'LEV94' AS RETURN
3344
3345 * IS SYSTEM FUNCTION
3346
056.321 315 061 031 3347 CALL $TJMP ENTER PROCESSOR
056.324 055 057 3348 DW ARS
056.326 026 045 3349 DW ATN
056.330 103 057 3350 DW CHR$
056.332 140 057 3351 DW CIN
056.334 125 064 3352 DW COS
056.336 075 063 3353 DW EXP
056.340 216 057 3354 DW INT

```

056.342	064	057	3355	DW	LNO		
056.344	225	063	3356	DW	LOG		
056.346	317	060	3357	DW	MAX		
056.350	320	060	3358	DW	MIN		
056.352	006	061	3359	DW	PAD		
056.354	014	061	3360	DW	PEEK		
056.356	034	061	3361	DW	PIN		
056.360	053	061	3362	DW	POS		
056.362	074	061	3363	DW	RND		
056.364	170	061	3364	DW	SEG		
056.366	205	061	3365	DW	SGN		
056.370	117	064	3366	DW	SIN		
056.372	152	070	3367	DW	ERR.SY	SPC	
056.374	360	063	3368	DW	SQR		
056.376	231	061	3369	DW	STR#		
057.000	152	070	3370	DW	ERR.SY	TAB	
057.002	243	064	3371	DW	TAN		

3372
 3373 * THESE FUNCTIONS REQUIRE STRING ARGUMENTS.
 3374

057.004	065	057	3375	DW	ASC		
057.006	314	057	3376	DW	LEFT#		
057.010	306	057	3377	DW	LEN		
057.012	111	060	3378	DW	MATCH		
057.014	314	057	3379	DW	MID#		
057.016	314	057	3380	DW	RIGHT#		
057.020	270	061	3381	DW	VAL		

3383 ** EVALN - EVALUATE NUMERIC EXPRESSION.
 3384 *

3385 * ENTRY SAME AS EVAL.
 3386 * EXIT SAME AS EVAL
 3387 * USES A,F,B,C,D,E
 3388

057.022	315	244	055	3390	EVALN	CALL	EVAL		
057.025	072	201	042	3391		LDA	ACCX-1		
057.030	346	001		3392		ANI	CF.STR		
057.032	302	155	070	3393		JNZ	ERR.TC	TYPE CONFLICT	
057.035	311			3394		RET		OK	

3396 ** EVALI - EVALUATE INTEGER EXPRESSION.
 3397 *

3398 * ENTRY SAME AS EVAL
 3399 * EXIT (DE) = INTEGER VALUE
 3400 * (BC) UPDATED
 3401 * USES A,F,B,C,D,E
 3402
 3403

057.036	315	022	057	3404	EVALI	CALL	EVALN		
---------	-----	-----	-----	------	-------	------	-------	--	--

EVALI

057.041 303 002 075 3405 JMP IFIX FIX IT

3407 ** EVALI8 - EVALUATE 8 BIT INTEGER EXPRESSION.
3408 *
3409 * ENTRY SAME AS EVAL
3410 * EXIT (BC) UPDATED
3411 * (E) = VALUE
3412 * USES A,F,B,C,D,E
3413
3414

057.044 315 036 057 3415 EVALI8 CALL EVALI
057.047 172 3416 MOV A,D
057.050 247 3417 ANA A
057.051 310 3418 RZ
057.052 303 122 070 3419 JMP ERR.IN OK
TOO LARGE

```

3423 ** ABS - ABSOLUTE VALUE.
3424 *
3425 * Y=ABS(X)
3426
3427
057.055 072 204 042 3428 ABS LDA ACCX+2
057.060 247 3429 ANA A
057.061 374 302 105 3430 CM FPNEG
3431
3432 * IDENTIFY FUNCTION
3433
057.064 311 3434 LND RET

3436 ** ASC - DECODE ASCII VALUE
3437 *
3438 * X=ASC(*C*)
3439
3440
057.065 021 202 042 3441 ASC LXI D,ACCX
057.070 315 315 074 3442 CALL FSE FIND STRING TABLE ENTRY
057.073 247 3443 ANA A
057.074 312 020 061 3444 JZ PEEK1 NULL STRING YIELDS 0
057.077 176 3445 MOV A,M GIVE VALUE
057.100 303 020 061 3446 JMP PEEK1

3448 ** CHR$ - CONVERT VALUE INTO ASCII CHARACTER.
3449 *
3450 * C*=CHR$(X)
3451
3452
057.103 315 002 075 3453 CHR$ CALL IFIX MAKE INTEGER
057.106 325 3454 PUSH D SAVE VALUE
057.107 041 001 000 3455 LXI H,1
057.112 042 202 042 3456 SHLD ACCX SET LENGTH
057.115 021 202 042 3457 LXI D,ACCX
057.120 315 033 073 3458 CALL CSE CREATE TEMP STRINGTAB ENTRY
057.123 315 262 061 3459 CALL FRC SET FUNCTION RETURNS CHARACTER
057.124 321 3460 POP D (DE) = VALUE
057.127 173 3461 MOV A,E
057.130 346 177 3462 ANI 177H CLEAR BIT
057.132 167 3463 MOV M,A STORE
057.133 300 3464 RNZ IF NOT NULL
057.134 062 202 042 3465 STA ACCX NULL STRING IF 00
057.137 311 3466 RET

```

```

3468 **      CIN - CHARACTER INPUT FUNCTION.
3469 *
3470 *      I=CIN<CHAN>
3471 *
3472 *      INPUT SINGLE CHARACTER, NO MAPPING OR PARITY ADJUSTMENT.
3473 *      I=-1 IF NO CHARACTER AVAILABLE
3474 *
3475
057.140      3476 CIN      EQU      *
057.140      3477      CALL      IFIX      GET CHANNEL NUMBER
057.143      3478      PUSH      B      SAVE TEXT POINTER
057.144      3479      MOV      A,D
057.145      3480      ANA      A
057.146      3481      JNZ      ERR.IN      TOO LARGE A NUMBER
057.151      3482      MOV      A,E      (A) = CHANNEL NUMBER
057.152      3483      ANA      A
057.153      3484      JNZ      CIN2      FROM FILE
3485
3486 *      IS INPUT FROM CONSOLE
3487
057.156      3488      IB      SYSCALL, .SCIN      READ CHARACTER
057.160      3489 CIN0     MOV      E,A
057.161      3490      MVI      D,0
057.163      3491      JNC      CIN1      GOT CHARACTER
057.166      3492      MVI      E,1
057.170      3493 CIN1     PUSH     PSW
057.171      3494      CALL     IFLT      FLOAT IT
057.174      3495      POP      PSW
057.175      3496      CC      FFNEG      NEGATE IT, IF NO CHARACTER
057.200      3497      POP      B      RESTORE TEXT POINTER
057.201      3498      RET      EXIT
3499
3500 *      READ CHARACTER FROM FILE
3501
057.202      3502 CIN2     CALL     CFA      COMPUTE FILE ADDRESS
057.205      3503      JC      ERR.FND      FILE NOT OPEN
057.210      3504      CALL     $FREAD      READ CHARACTER
057.213      3505      JMP      CIN0      PROCESS VALUE ('C' SET IF EOF)

3507 **      INT - TRUNCATE TO NEAREST INTEGER.
3508 *
3509 *      Y=INT(X)
3510 *
3511
057.216      3512 INT     EQU      *
057.216      3513      LXI      H,ACCX+2
057.221      3514      MOV      A,M      (A) = SIGN
057.222      3515      ANA      A
057.223      3516      PUSH     PSW      SAVE TEST RESULTS
057.224      3517      CM      FFNEG      MAKE POSITIVE
057.227      3518      LXI      D,INTA
057.232      3519      CALL     FPADD      ROUND UP
057.235      3520      INX      H      (HL) = #ACCX+3

```



```

057.236 305          3521      PUSH      B          SAVE (BC)
057.237 106          3522      MOV       B,M        (B) = EXPONENT
057.240 004          3523      INR      B
057.241 021 000 000  3524      LXI     D,0
057.244 112          3525      MOV     C,D        (C,D,E) = MASK
          3526
          3527 *      SHIFT IN ONE BITS TO CORRESPOND TO NON-FRACTIONAL BITS.
          3528
057.245 005          3529 INT1     DCR      B
057.246 362 260 057  3530      JP       INT2      NO MORE
057.251 067          3531      STC
057.252 315 233 107  3532      CALL    SRS,,     SHIFT (BCD) RIGHT THROUGH CARRY
057.255 303 245 057  3533      JMP     INT1
          3534
057.260 053          3535 INT2     DCX      H
057.261 176          3536      MOV     A,M        MASK OFF VALUE
057.262 241          3537      ANA     C
057.263 167          3538      MOV     M,A
057.264 053          3539      DCX     H
057.265 176          3540      MOV     A,M
057.266 242          3541      ANA     D
057.267 167          3542      MOV     M,A
057.270 053          3543      DCX     H
057.271 176          3544      MOV     A,M
057.272 243          3545      ANA     E
057.273 167          3546      MOV     M,A
057.274 301          3547      POP     B          RESTORE (BC)
057.275 361          3548      POP     PSW       (A) = ORIGINAL SIGN TEST RESULTS
057.276 374 302 105  3549      CH      FPNEG     RE-INVERT IF NECESSARY
057.301 311          3550      RET
          3551
057.302 000 000 101  3552 INTA     DB      0000,0000,1010,1570

```

```

          3554 **      LEN - LENGTH OF STRING.

```

```

          3555 *
          3556 *      X=LEN(S$)
          3557 *
          3558 *

```

```

057.306 072 202 042  3559 LEN     LDA     ACCX      (A) = LENGTH
057.311 303 020 061  3560      JMP     PEEK1     FLOAT INTO ACCX

```

```

          3562 **      LEFT$ - GET LEFTMOST CHARACTERS.

```

```

          3563 *
          3564 *      Y$=LEFT$(X$,CNT)
          3565 *
          3566 *

```

```

          3567 **      RIGHT$ - GET RIGHTMOST CHARACTERS.

```

```

          3568 *
          3569 *      Y$=RIGHT$(X$,CNT)
          3570 *

```

LEFT\$

```

3571
3572
3573
3574 **      MID$ - GET SEGMENT OF CHARACTER STRING.
3575 *
3576 *      Y$=MID$(X$,POS,LEN)
3577
3578
057.314      3579 LEFT$ EQU *
057.314      3580 RIGHT$ EQU *
057.314      3581 MID$ EQU *
057.314 365      3582 PUSH PSW SAVE TYPE CODE
057.315 315 223 072 3583 CALL CMA REQUIRE ',,'
057.320 315 033 077 3584 CALL PSHX SAVE X$ POINTER
057.323 315 044 057 3585 CALL EVALIS EVALUATE 8 BIT RESULT
057.326 123      3586 MOV D,E (D) = LEN
057.327 036 001 3587 MVI E,1 (E) = POS
057.331 315 370 076 3588 CALL POPY, (Y) = X$ POINTER
057.334 361      3589 POP PSW
000.003      3590 ERRMI CT,MID-CT,LEF
057.335 376 070 3591 CPI CT,MID-CT,FCN*2
057.337 312 365 057 3592 JE MID$1 IS MID$
057.342 332 032 060 3593 JC LEFT$1 IS LEFT$
377.377      3594 ERRPL CT,MID-CT,RIG
3595
3596 *      IS RIGHT$
3597 *
3598 *      GENERATE MID$(X$,LENX$-MIN(LENX$,CNT),MIN(LENX$,CNT))
3599
057.345 072 210 042 3600 LDA ACCY
057.350 137      3601 MOV E,A (E) = LENX$
057.351 272      3602 CMP D
057.352 322 356 057 3603 JNC RIGHT$1
057.355 127      3604 MOV D,A (D) = MIN(LENX$,CNT)
057.356 173      3605 RIGHT$1 MOV A,E (A) = LENX$
057.357 222      3606 SUB D (A) = LENX$-MIN(LENX$,CNT)
057.360 137      3607 MOV E,A (E) = LENX$-MIN(LENX$,CNT)
057.361 034      3608 INR E
057.362 303 032 060 3609 JMP MID$2 MOVE
3610
3611 *      IS MID$
3612 *
3613 *      EVALUATE CNT
3614
057.365      3615 MID$1 EQU *
057.365 132      3616 MOV E,D (E) = POS
057.366 172      3617 MOV A,D
057.367 247      3618 ANA A
057.370 312 122 070 3619 JZ ERR,IN 0 ILLEGAL
057.373 026 377 3620 MVI D,255 ASSUME NULL (LEN=255)
057.375 315 072 076 3621 CALL PNT PREVIEW NEXT TOKEN
060.000 376 020 3622 CPI CT,PAR
060.002 312 032 060 3623 JE MID$2 IS NULL
060.005 315 056 071 3624 CALL ANT ACCEPT ,
060.010 376 026 3625 CPI CT,CMA
060.012 302 152 070 3626 JNE ERR,SY

```

LEFT\$

```

060.015 325      3627      PUSH      D      SAVE CURRENT POS
060.016 315 041 077 3628      CALL      PSHY     SAVE STRING
060.021 315 044 057 3629      CALL      EVALIS  EVALUATE LEN
060.024 315 370 076 3630      CALL      POPY.   (ACCY) = X$ POINTER
060.027 353      3631      XCHG
060.030 321      3632      POP       D
060.031 125      3633      MOV       D,L     SET NEW LEN
                   3634
                   3635 *      (ACCX) = X$ POINTER
                   3636 *      (D) = LEN
                   3637 *      (E) = POS
                   3638 *
                   3639 *      COMPUTE Y$ = MID$(X$,POS,LEN)
                   3640
060.032      3641      LEFT$1  EQU      *
060.032      3642      MID$2   EQU      *
                   3643
                   3644 *      COMPUTE LEN' = MIN(LEN,MAX(LENX$-POS+1,0))
                   3645
060.032 072 210 042 3646      LDA      ACCY     (A) = LENX$
060.035 223      3647      SUB      E
060.036 074      3648      INR      A      (A) = LENX$-POS+1
060.037 322 043 060 3649      JNC      MID$3   IS >= 0
060.042 257      3650      XRA      A      USE 0
060.043 272      3651      MID$3   CMP      B
060.044 322 050 060 3652      JNC      MID$4   (D) = MIN VALUE
060.047 127      3653      MOV      B,A     (D) = MIN VALUE
060.050 046 000   3654      MID$4   MVI      H,0
060.052 152      3655      MOV      L,D     (HL) = LEN
060.053 042 202 042 3656      SHLD   ACCX     SET IN BLOCK
060.056 325      3657      PUSH   D      SAVE LENGTH
060.057 021 202 042 3658      LXI    D,ACCX
060.062 315 033 073 3659      CALL   CSE.    CREATE TEMP STRINGTAB ENTRY
060.065 343      3660      XTHL
060.066 345      3661      PUSH   H      SAVE LEN, POS
060.067 021 210 042 3662      LXI    D,ACCY
060.072 315 315 074 3663      CALL   FSE     FIND STRING ENTRY
060.075 321      3664      POP    D      (E) = POS
060.076 173      3665      MOV    A,E
060.077 075      3666      DCR   A
060.100 315 072 030 3667      CALL   $DADA   (HL) = FROM ADDRESS
060.103 172      3668      MOV    A,D     (A) = LEN
060.104 353      3669      XCHG
060.105 341      3670      POP    H      (HL) = TO ADDRESS
060.106 303 257 061 3671      JMP    STR$1   MOVE, EXIT WITH TYPE = CT,SSU

3673 ***      MATCH - FIND SUBSTRING IN STRING.
3674 *
3675 *      I=MATCH$(S1$,S2$,J)
3676 *
3677 *      SCAN S1$ FOR OCCURANCE OF S2$, STARTING AT CHARACTER J
3678 *
3679 *      I=0 IF NOT FOUND

```

3680 * I = CHARACTER NUMBER OF START OF MATCH IF FOUND

3681

3682

060.111 3683 MATCH EQU *
 060.111 041 307 060 3684 LXI H,MATCHA
 060.114 315 051 076 3685 CALL MOV4 SAVE S1 DESCRIPTOR
 060.117 315 223 072 3686 CALL CMA GOBBLE CMA

060.122 315 244 055 3688 CALL EVAL /80.01:GC/
 060.125 072 201 042 3689 LBA ACX-1 /80.01:GC/
 060.130 346 001 3690 ANI CF,STR /80.01:GC/
 060.132 312 155 070 3691 JZ ERR,TC REQUIRE A STRING /80.01:GC/
 060.135 041 313 060 3692 LXI H,MATCHC

060.140 315 051 076 3693 CALL MOV4 SAVE S2 DESCRIPTION
 060.143 315 223 072 3694 CALL CMA GOBBLE ','
 3695

060.146 315 044 057 3696 CALL EVALIB EVALUATE INDEX
 060.151 305 3697 PUSH B SAVE TEXT POINTER
 060.152 103 3698 MOV R,E (B) = J

060.153 021 313 060 3699 LXI D,MATCHC
 060.156 315 315 074 3700 CALL FSE FIND S2
 060.161 345 3701 PUSH H SAVE S2 ADDRESS

060.162 365 3702 PUSH PSW SAVE S2 COUNT
 060.163 021 307 060 3703 LXI D,MATCHA
 060.166 315 315 074 3704 CALL FSE FIND S1

060.171 365 3705 PUSH PSW SAVE S1 LENGTH
 060.172 175 3706 MOV A,L
 060.173 062 276 060 3707 STA MATCHB SAVE ADDRESS (IN PAGE) OF START

060.176 170 3708 MOV A,B
 060.177 247 3709 ANA A
 060.200 312 122 070 3710 JZ ERR,IN ILLEGAL NUMBER

060.203 075 3711 DCR A
 060.204 315 101 030 3712 CALL \$DATA (HL) = START OF SEARCH AREA
 060.207 361 3713 POP PSW

060.210 220 3714 SUB B (A) = LEN(S1)-J
 060.211 332 257 060 3715 JC MATCH2,3 NOT ANYWHERE
 060.214 074 3716 INR A

060.215 301 3717 POP B (B) = S2 LENGTH
 060.216 220 3718 SUB B (A) = # OF TRYS -1
 060.217 332 260 060 3719 JC MATCH2,5 NONE

060.222 321 3720 POP D (DE) = S2 ADDRESS
 060.223 074 3721 INR A
 060.224 365 3722 PUSH PSW SAVE TRY COUNT

3723

3724

3725 * SEE IF MATCH

060.225 032 3726 MATCH1 LDAX D
 060.226 276 3727 CMP M
 060.227 302 247 060 3728 JNE MATCH2 NOT THIS ONE

060.232 325 3729 PUSH D
 060.233 345 3730 PUSH H
 060.234 305 3731 PUSH B SAVE ALL REGS

060.235 110 3732 MOV C,B (C) = S2 LENGTH = COMPARE COUNT
 060.236 315 060 030 3733 CALL \$COMP COMPARE THE REST
 060.241 301 3734 POP B

060.242 341 3735 POP H

```

060.243 321 3736 POP D
060.244 312 273 060 3737 JE MATCH3 GOT IT
3738
3739 * NO MATCH AT THIS ONE
3740
060.247 043 3741 MATCH2 INX H
060.250 361 3742 POP PSW
060.251 075 3743 DCR A
060.252 365 3744 PUSH PSW COUNT IT
060.253 302 225 060 3745 JNZ MATCH1 MORE TO TRY
060.256 365 3746 PUSH PSW SET STACK PROPERLY
060.257 361 3747 MATC2.3 POP PSW
060.260 361 3748 MATC2.5 POP PSW
060.261 041 202 042 3749 LXI H,ACCX
060.264 006 004 3750 MVI B,4
060.266 315 212 031 3751 CALL $ZERO RETURN ZERO FOR ANSWER
060.271 301 3752 POP B RESTORE (BC)
060.272 311 3753 RET
3754
3755 * GOT ONE
3756
060.273 361 3757 MATCH3 POP PSW
060.274 175 3758 MOV A,L (A) = FWA OF STRING
060.275 326 000 3759 SUI 0 SUBTRACT START ADDRESS
060.276 3760 MATCHB EQU *-1 INDEX OF START OF S1
060.277 137 3761 MOV E,A
060.300 026 000 3762 MVI D,0
060.302 023 3763 INX D BIAS INTO 1 TO 256
060.303 301 3764 POP B RESTORE TEXT POINTER
060.304 303 040 075 3765 JMP IFLT FLOAT RESULT, AND EXIT
3766
060.307 3767 MATCHA DS 4 HOLD AREA FOR STRING DESCRIPTOR
060.313 3768 MATCHC DS 4 HOLD AREA FOR S2 DESCRIPTOR

```

3770 ** MAX - COMPUTE 'MAXIMUM' FUNCTION.

3771 *
3772 * Y=MAX(X1,...,XN)

3773
3774
3775 ** MIN - COMPUTE 'MINIMUM' FUNCTION.

3776 *
3777 * Y=MIN(X1,...,XN)

```

060.317 076 3780 MAX DB MI,MVIA
060.320 257 3781 MIN XRA A (A) = MI,MVI IF MAX, 0 IF MIN
060.321 365 3782 PUSH PSW SAVE CODE
060.322 315 317 100 3783 CALL XCY (ACCY) = CURRENT CANDIDATE
3784
3785 * (ACCY) = CURRENT CANDIDATE
3786
060.325 315 072 076 3787 MAX1 CALL PNT PEEK AT NEXT TOKEN
060.330 376 020 3788 CPI CT,PAR

```

```

060.332 312 002 061 3789 JE MAX2 IS )
060.335 315 223 072 3790 CALL CMA REQUIRE ', '
060.340 315 041 077 3791 CALL PSHY SAVE CURRENT BEST
060.343 315 022 057 3792 CALL EVALN EVALUATE NUMBER
060.346 315 365 076 3793 CALL POPY RESTORE CURRENT BEST
060.351 315 033 077 3794 CALL PSHX SAVE LATEST
060.354 021 210 042 3795 LXI D,ACCY
060.357 315 166 105 3796 CALL FPSUB COMPUTE (CANDIDATE-LATEST)
060.362 072 204 042 3797 LDA ACCX+2
060.365 127 3798 MOV D,A
060.366 315 357 076 3799 CALL POPX RESTORE LATEST TRY
060.371 361 3800 POP PSW
060.372 365 3801 PUSH PSW (A) = MIN/MAX FLAG
060.373 252 3802 XRA D (A) = CODE
060.374 364 317 100 3803 CP XCY LATEST IS SUPERIOR
060.377 303 325 060 3804 JMP MAX1

```

```

3805
3806 * AT END OF LIST.
3807

```

```

061.002 361 3808 MAX2 POP PSW
061.003 303 317 100 3809 JMP XCY (ACCX) = BEST FOUND

```

```

3811 ** PAD - READ KEYPAD.
3812 *
3813 * Y=PAD(0)
3814
3815

```

```

061.006 315 260 003 3816 PAD CALL RCK READ VALUE
061.011 303 020 061 3817 JMP PEEK1 RETURN VALUE

```

```

3819 ** PEEK - PEEK AT MEMORY.
3820 *
3821 * X=PEEK(ADDR)
3822
3823

```

```

061.014 315 002 075 3824 PEEK CALL IFIX EVAL TO 16 BITS
061.017 032 3825 LDAX D
061.020 137 3826 PEEK1 MOV E,A
061.021 026 000 3827 MVI D,0 (DE) = VALUE
061.023 315 040 075 3828 PEEK1.5 CALL IFLT FLOAT INTO ACCX
061.026 076 300 3829 PEEK2 MVI A,CT,SNU SCALAR NUMERIC VALUE
061.030 062 201 042 3830 STA ACCX-1
061.033 311 3831 RET

```

```

3833 ** PIN - PORT INPUT.
3834 *
3835 * Y=PIN(PORT)
3836
3837
061.034 315 002 075 3838 PIN CALL IFIX
061.037 143 3839 MOV H,E
061.040 056 333 3840 MVI L,MI,IN
061.042 042 002 040 3841 SHLD ,IOWRK
061.045 315 002 040 3842 CALL ,IOWRK INPUT
061.050 303 020 061 3843 JMP PEEK1 FLOAT AND EXIT
    
```

```

3845 ** POS - RETURN PRINT HEAD POSITION.
3846 *
3847 * X=POS(PORT)
3848
3849
061.053 315 002 075 3850 POS CALL IFIX
061.056 041 253 112 3851 LXI M,COLCNTS
061.061 173 3852 MOV A,E
061.062 247 3853 ANA A
061.063 312 067 061 3854 JZ POS1 IS CHANNEL 0
061.066 023 3855 INX D (DE) = INDEX INTO COLCNTS
061.067 031 3856 POS1 DAD D
061.070 176 3857 MOV A,M (A) = POSITION
061.071 303 020 061 3858 JMP PEEK1 FLOAT
    
```

```

3860 ** RND - COMPUTE TAUSWORTH 15 BIT RANDOM NUMBER.
3861 *
3862 * X=RND(Y)
3863 *
3864 * Y = 0, GIVE LAST RANDOM NUMBER
3865 * Y > 0, GIVE NEXT RANDOM NUMBER
3866 * Y < 0, SEED WITH Y
3867
3868
061.074 3869 RND EQU *
061.074 072 204 042 3870 LDA ACCX+2 EXAMINE SIGN
061.077 247 3871 ANA A
061.100 041 114 107 3872 LXI H,'GL' (HL) = SEED
061.101 3873 RND EQU *-2 SEED
061.103 026 017 3874 MVI B,15 (B) = BIT COUNT
061.105 312 150 061 3875 JZ RND2 JUST RETURN SEED
061.110 362 116 061 3876 JP RND1 GENERATE NEW NUMBER
061.113 052 203 042 3877 LHLD ACCX+1 USE NEW SEED
061.116 174 3878 RND1 MOV A,H SHIFT RIGHT ONE
061.117 247 3879 ANA A
061.120 037 3880 RAR
061.121 147 3881 MOV H,A
061.122 175 3882 MOV A,L
    
```

RND

```

061.123 037      3883      RAR
061.124 157      3884      MOV      L,A
061.125 027      3885      RAL
061.126 027      3886      RAL      'C' = 1
061.127 027      3887      RAL
061.130 027      3888      RAL
061.131 255      3889      XRA      L      'C' = 100
061.132 027      3890      RAL      XOR WITH VALUE
061.133 027      3891      RAL
061.134 027      3892      RAL
061.135 346 100   3893      ANI      100Q
061.137 264      3894      ORA      H      INSERT IN LEFT
061.140 147      3895      MOV      H,A
061.141 025      3896      DCR      D
061.142 302 116 061 3897      JNZ      RND1      MORE TO GO
061.145 042 101 061 3898      SHLD     RNDA      SAVE SEED
061.150 353      3899
061.151 041 202 042 3900 RND2  XCHG      (DE) = VALUE
061.154 066 000   3901      LXI      H,ACCX
061.156 043      3902      MVI      M,0      ZERO LOW B
061.157 163      3903      INX      H
061.160 043      3904      MOV      M,E
061.161 162      3905      INX      H
061.162 043      3906      MOV      M,D
061.163 066 200   3907      INX      H
061.165 303 202 105 3908      MVI      M,200Q   EXPONENT
061.165 303 202 105 3909      JMP      FPNRM    NORMALIZE AND EXIT

```

```

3911 **      SEG - DECODE SEGMENT VALUE,
3912 *
3913 *      Y=SEG(NUM)
3914 *
3915 *      DECODE VALUES 0-9.
3916 *      NUM = 10 GIVES BLANK.
3917
3918

```

```

061.170 315 002 075 3919 SEG  CALL     IFIX
061.173 041 356 003 3920      LXI      H,.DDBA
061.176 031      3921      DAD      D
061.177 176      3922      MOV      A,M
061.200 366 200   3923      ORI      200Q    CLEAR DECIMAL
061.202 303 020 061 3924      JHP      PEEK1   DECODE VALUE

```

```

3926 **      SGN - RETURN SIGN OF NUMBER.
3927 *
3928 *      Y=SGN(X)
3929 *
3930 *      I = -1 IF X<0, =0 IF X=0, =1 IF X > 0
3931
3932

```



```

061.205 021 000 000 3933 SGN LXI D:0
061.210 072 204 042 3934 LDA ACCX+2
061.213 247 3935 ANA A
061.214 312 040 075 3936 JZ IFLT IS 0
061.217 023 3937 INX D
061.220 362 040 075 3938 JP IFLT IS POSITIVE
061.223 315 040 075 3939 CALL IFLT
061.226 303 302 105 3940 JMP FPNEG MAKE -1

3942 ** STR* - CONVERT FLOATING TO ASCII.
3943 *
3944 * Y*=STR*(X)
3945
061.231 041 273 113 3947 STR* LXI H,LINE2
061.234 315 237 110 3948 CALL FTA FLOATING TO ASCII
061.237 345 3949 PUSH H SAVE 'FROM'
061.240 157 3950 MOV L,A
061.241 046 000 3951 MVI H,0
061.243 365 3952 PUSH PSW SAVE LENTRN
061.244 042 202 042 3953 SHLD ACCX SET LENGTH
061.247 021 202 042 3954 LXI D,ACCX
061.252 315 033 073 3955 CALL CSE. CREATE TEMP ENTRY
061.255 361 3956 POP PSW (A) = COUNT
061.256 321 3957 POP D
061.257 315 015 071 3958 STR*1 CALL MOV MOVE IT
3959
3960 ** FRC - FUNCTION RETURNS CHARACTER VALUE.
3961
061.262 076 301 3962 FRC MVI A,CT.SSV SCALAR STRING VALUE
061.264 062 201 042 3963 STA ACCX-1
061.267 311 3964 RET

3966 ** VAL - CONVERT ASCII TO FLOATING POINT.
3967 *
3968 * Y=VAL(X*)
3969
061.270 021 202 042 3971 VAL LXI D,ACCX
061.273 315 315 074 3972 CALL FSE FIND STRINGTAB ENTRY
061.276 353 3973 XCHG
061.277 041 273 113 3974 LXI H,LINE2
061.302 315 015 071 3975 CALL MOV MOVE TO *LINE*
061.305 066 000 3976 MVI H,0 MAKE SURE TERMINATES
061.307 041 273 113 3977 LXI H,LINE2
061.312 315 330 111 3978 CALL *SOB SKIP OVER BLANKS
061.315 315 323 107 3979 CALL ATF ASCII TO FLOATING
061.320 303 026 061 3980 JMP PEEK2

```

```

3982 ** P. OR - PROCESS BOOLEAN 'OR'.
3983 *
3984 * ENTRY (ACCX) = 1ST VALUE
3985 * (ACCY) = 1ND VALUE
3986 * EXIT (ACCX) = 1ST 'OR' 2ND
3987
3988
061.323 315 345 076 3989 P. OR CALL PBO PROCESS BOOLEAN OPERATOR
061.326 172 3990 MOV A,D
061.327 264 3991 ORA H
061.330 127 3992 MOV D,A
061.331 173 3993 MOV A,E
061.332 265 3994 ORA L
061.333 303 371 061 3995 JMP P.NOT1
    
```

```

3997 ** P. AND - PROCESS BOOLEAN AND.
3998 *
3999 * ENTRY NONE
4000 * EXIT (ACCX) = IFLT(IFIX(ACCX).AND.IFIX(ACCY))
4001
4002
061.336 315 345 076 4003 P. AND CALL PBO PREPARE BOOLEAN
061.341 172 4004 MOV A,D
061.342 244 4005 ANA H
061.343 127 4006 MOV D,A
061.344 173 4007 MOV A,E
061.345 245 4008 ANA L
061.346 303 371 061 4009 JMP P.NOT1
    
```

```

4011 ** P. NOT - PROCESS BOOLEAN 'NOT'.
4012 *
4013 * ENTRY NONE
4014 * EXIT (ACCX) = IFLT(.NOT.IFIX(ACCX))
4015
4016
061.351 072 201 042 4017 P. NOT LDA ACCX-1 (A) = TYPE OF ARGUMENT
061.354 376 300 4018 CPI CT,SNU
061.356 302 155 070 4019 JNE ERR.TC WRONG TYPE
061.361 315 377 074 4020 CALL IFIX. (DE) = IFIX(ACCX)
061.364 172 4021 MOV A,D
061.365 057 4022 CHA
061.366 127 4023 MOV D,A
061.367 173 4024 MOV A,E
061.370 057 4025 CHA
061.371 137 4026 P. NOT1 MOV E,A (DE) = RESULT
061.372 303 040 075 4027 JMP IFLT FLOAT AND EXIT
    
```

```

4029 **      P.CMP - PROCESS COMPARES.
4030 *
4031 *      Y= 'X1' 'OP' 'X2'
4032 *
4033 *      OP = '<' '<=' '= <>' '>' '>'
4034 *
4035 *      THE TWO OPERANDS ARE COMPARED, AND THE RESULT GENERATES
4036 *      A BIT PATTERN:
4037 *
4038 *      001      EQUAL
4039 *      010      POSITIVE
4040 *      100      NEGATIVE
4041 *
4042 *      THIS PATTERN IS THEN MASKED WITH THE PATTERNS GENERATED BY THE
4043 *      OPERATORS:
4044 *
4045 *      = 001
4046 *      > 010
4047 *      >= 011
4048 *      < 100
4049 *      <= 101
4050 *      <> 110
4051 *
4052 *      ENTRY  (ACCX) = X2
4053 *             (ACCY) = X1
4054 *             (L) = OPERATOR 'CT.' CODE
4055 *      USES   A,F,D,E,H,L
4056 *
4057 *
061.375 345      4058 P.CMP PUSH H          SAVE (H)
061.376 315 347 072 4059          CALL CDT          CHECK OPERAND TYPE
062.001 302 047 062 4060          JNZ P.CMP2     IS STRING
4061 *
4062 *      IS NUMERIC COMPARE.
4063 *
062.004 315 166 105 4064          CALL FPSUB     (ACCX) = X1-X2
062.007 072 204 042 4065          LDA ACCX+2   (A) = SIGN OF RESULT
062.012 247      4066          ANA A           SET FLAGS
062.013 341      4067 P.CMP1 POP H
062.014 067      4068          STC
062.015 077      4069          CMC          CLEAR CARRY
062.016 076 001 4070          MVI A,1     ASSUME IS ZERO
062.020 312 030 062 4071          JZ P.CMP13    IS ZERO
062.023 027      4072          RAL
062.024 362 030 062 4073          JF P.CMP13    IS POSITIVE
062.027 027      4074          RAL          IS NEGATIVE
062.030 157      4075 P.CMP13 MOV L,A         (L) = RESULTS OF TEST
062.031 174      4076          MOV A,H         (A) = TYPE
062.032 326 010 4077          SUI CT.EQ-1   (A) = CODE FOR DCONDITIONS
062.034 245      4078          ANA L
062.035 021 000 000 4079          LXI D,0     ASSUME FALSE
062.040 312 023 061 4080          JZ PEEK1.5  IS FALSE
062.043 033      4081          DCX D
062.044 303 023 061 4082          JMP PEEK1.5  IS TRUE

```

```

4084 **      STRING COMPARES.
4085 *
4086 *      COMPARE CHARACTER FOR CHARACTER. IF A STRING RUNS OUT, ITS
4087 *      NEXT CHARACTER IS CONSIDERED TO BE '00'
4088
4089
062.047 305      4090 P.CMP2  PUSH  B          SAVE (BC)
062.050 021 202 042 4091      LXI   D,ACCX
062.053 315 315 074 4092      CALL  FSE          FIND STRING ENTRY
062.056 107      4093      MOV   B,A          (B) = LEN(X2)
062.057 345      4094      PUSH  H          SAVE ADDRESS OF X2
062.060 021 210 042 4095      LXI   D,ACCY
062.063 315 315 074 4096      CALL  FSE          FIND ENTRY
062.066 117      4097      MOV   C,A          (C) = LEN(X1)
062.067 321      4098      POP   D          (DE) = ADR(X2), (HL) = ADR(X1)
062.070 353      4099      XCHG
062.071 004      4100      INR   B          (B) = LEN(X2)+1
062.072 014      4101      INR   C          (C) = LEN(X1)+1
4102
4103 *      COMPARE STRINGS.
4104
062.073 005      4105 P.CMP3  DCR   B
062.074 312 121 062 4106      JZ    P.CMP5      OUT OF X2
062.077 015      4107      DCR   C
062.100 312 115 062 4108      JZ    P.CMP4      OUT OF X1, BUT NOT X2
062.103 032      4109      LBAX  D
062.104 226      4110      SUB   M
062.105 302 130 062 4111      JNZ  P.CMP6      HAVE RESULT
062.110 023      4112      INX  D
062.111 043      4113      INX  H
062.112 303 073 062 4114      JMP   P.CMP3      TOO EARLY TO TELL
4115
4116 *      RAN OUT OF X1, BUT NOT X2. RESULT IS X1 < X2
4117
062.115 015      4118 P.CMP4  DCR   C          SET 'M' FLAG
062.116 303 130 062 4119      JMP   P.CMP6
4120
4121 *      RAN OUT OF X2, DONT KNOW ABOUT X1
4122
062.121 015      4123 P.CMP5  DCR   C
062.122 312 130 062 4124      JZ    P.CMP6      OUT OF BOTH
062.125 076 001      4125      MVI  A,1
062.127 247      4126      ANA  A          X2 > X1
4127
4128 *      HAVE COMPARE RESULT IN PSW
4129
062.130 301      4130 P.CMP6  POP   B          RESTORE (BC)
062.131 303 013 062 4131      JMP   P.CMP1

```

```

4133 ** P.ADD - PROCESS ADD AND SUBTRACT.
4134 *
4135
4136
062.134 078 021 4137 P.ADD MVI A,CT,PL
062.136 274 4138 CMP H
062.137 302 241 082 4139 JNE P,SUB IS -
062.142 315 347 072 4140 CALL COT CHECK OPERAND TYPE
062.145 312 352 104 4141 JZ FPADD IS NUMERIC ADD
4142
4143 * IS STRING CONCATINATE.
4144
062.150 072 202 042 4145 LDA ACCX
062.153 157 4146 MOV L,A (L) = LEN(X2)
062.154 072 210 042 4147 LDA ACCY
062.157 205 4148 ADD L (A) = RESULTANT LENGTH
062.160 332 144 070 4149 JC ERR,SL STRING LENGTH ERROR
062.163 157 4150 MOV L,A (HL) = LEN
062.164 046 000 4151 MVI H,0
062.166 042 235 062 4152 SHLD P,ADDA SAVE INDEX IN BUILD BLOCK AREA
062.171 021 235 062 4153 LXI D,P,ADDA
062.174 315 033 073 4154 CALL CSE, CREATE TEMP STRINGTAB ENTRY
062.177 345 4155 PUSH H SAVE 'TO'
062.200 021 210 042 4156 LXI D,ACCY
062.203 315 315 074 4157 CALL FSE FIND ENTRY
062.206 353 4158 XCHG (DE) = FROM
062.207 341 4159 POP H (HL) = TO
062.210 315 015 071 4160 CALL MOV COPY 1ST
062.213 345 4161 PUSH H SAVE TO
062.214 021 202 042 4162 LXI D,ACCX
062.217 315 315 074 4163 CALL FSE
062.222 353 4164 XCHG (DE) = FROM
062.223 341 4165 POP H (HL) = TO
062.224 315 015 071 4166 CALL MOV
062.227 021 235 062 4167 LXI D,P,ADDA
062.232 303 210 073 4168 JMP CVX COPY BLOCK TO ACCX
4169
062.235 4170 P,ADDA DS 4

```

```

4172 *
4173 * (ACCX) = (ACCY-ACCX)
4174
4175
062.241 315 177 077 4176 P,SUB CALL RND REQUIRE NUMERIC OPERANDS
062.244 303 166 105 4177 JMP FFSUB

```

```

4179 **      M.MUL - PROCESS MULTIPLICATION AND DIVISION.
4180 *
4181 *      (ACCX) = (ACCX)*(ACCY)
4182 *
4183 *      ENTRY (DE) = #ACCY
4184
4185
062.247 076 024 4186 P.MUL MVI A,CT,DI
062.251 274 4187 CMP H SEE IF /
062.252 365 4188 PUSH PSW SAVE RESULT
062.253 315 177 077 4189 CALL RNO REQUIRE NUMERIC OPERANDS
062.254 361 4190 POP PSW
062.257 302 323 105 4191 JNE FPMUL IS *
062.262 315 317 100 4192 CALL XCY INVERT
062.265 303 260 106 4193 JMP FPDIV DIVIDE

```

```

4195 **      P.EXP - EXPONENTIATION.
4196 *
4197 *      (ACCX) = (VAL)^(POWR)
4198 *
4199 *      IF (ACCY)>0, COMPUTE RSLT=EXP(X*LOG(Y))
4200 *
4201 *      ENTRY (ACCY) = VAL
4202 *      (ACCX) = POWER
4203 *      EXIT (ACCX) = RESULT
4204
4205
062.270 4206 P.EXP EQU *
062.270 315 317 100 4207 CALL XCY (ACCX) = VAL
062.273 072 205 042 4208 LDA ACCX+3 CHECK IF VAL IS 0
062.274 247 4209 ANA A
062.277 302 321 062 4210 JNZ P.EXP1 VAL NON - ZERO
4211
4212 *      CHECK FOR 0^0
4213
062.302 072 213 042 4214 LDA ACCY+3 CHECK IF POWER IS 0
062.305 247 4215 ANA A
062.306 300 4216 RNZ EXIT; POWER NON - ZERO, VAL = 0
4217
062.307 021 147 112 4218 LXI D,FP1,0 POWER = ZERO; RETURN RESULT OF 1
062.312 041 202 042 4219 LXI H,ACCX
062.315 315 051 076 4220 CALL MOV4 (ACCX) = 1
062.320 311 4221 RET EXIT
4222
062.321 315 041 077 4223 P.EXP1 CALL PSHY SAVE EXPONENT
062.324 315 225 063 4224 CALL LOG (ACCX) = LOG(Y)
062.327 315 365 076 4225 CALL POPY
062.332 315 323 105 4226 CALL FPMUL
062.335 303 075 063 4227 JMP EXP (ACCX) = EXP(X*LOG(Y))

```

TXTFN

```

4231 **   TXTFN - PERFORM TEXT DEFINED FUNCTIONS.
4232 *
4233 *
4234
062.340 4235 TXTFN EQU *
062.340 315 056 071 4236 CALL ANT ACCEPT NEXT TOKEN
062.343 346 002 4237 ANI CF,VEC
062.345 312 152 070 4238 JZ ERR.SY NOT VECTOR TYPE
062.350 032 4239 LDAX B
062.351 247 4240 ANA A
062.352 362 216 070 4241 JP ERR.UD NOT DECLARED AS FUNCTION
062.355 023 4242 INX D
062.356 353 4243 XCHG
062.357 136 4244 MOV E,M
062.360 043 4245 INX H
062.361 126 4246 MOV D,M (DE) = ADDRESS OF FUNCTION DEFINITION
062.362 353 4247 XCHG
062.363 305 4248 TXTF1 PUSH B
062.364 343 4249 XTHL
062.365 301 4250 POP B (BC) = ADDRESS OF PARAMETER LIST
4251
4252 *   ASSIGN VALUES TO PARAMETER LIST.
4253
062.366 345 4254 TXTF2 PUSH H SAVE (HL)
062.367 315 136 075 4255 CALL IST INSERT SYMBOL IN TABLE
062.372 341 4256 POP H
062.373 325 4257 PUSH D SAVE INDEX
062.374 365 4258 PUSH PSW
062.375 315 056 071 4259 CALL ANT EXAMINE NEXT TOKEN
063.000 365 4260 PUSH PSW SAVE FOR LATER
063.001 376 026 4261 CPI CT,CHA
063.003 312 013 063 4262 JE TXTF3 IS ,
063.006 376 020 4263 CPI CT,PAR
063.010 302 152 070 4264 JNE ERR.SY BAD SYNTAX
4265
4266 *   SWAP (BC) (HL) TO DECODE VALUE FOR VARIABLE
4267
063.013 305 4268 TXTF3 PUSH B
063.014 343 4269 XTHL
063.015 301 4270 POP B
063.016 315 244 055 4271 CALL EVAL EVALUATE PARAMETER VALUE
063.021 361 4272 POP PSW (A) = NEXT CHARACTER FROM *ANT*
063.022 062 041 063 4273 STA TXTFNA SAVE FOR COMPARISON
063.025 361 4274 POP PSW RESTORE TYPE
063.026 321 4275 POP D RESTORE PARAM ADDRESS
063.027 315 366 072 4276 CALL CSA (DE) = ABS. ADDR. INTO SYMBOL
063.032 315 202 071 4277 CALL AVU ASSIGN VALUE TO VARIABLE
063.035 315 056 071 4278 CALL ANT CHECK SEPERATOR
063.040 376 000 4279 CPI 0 MUST BE SAME AS FUNCTION LIST
063.041 4280 TXTFNA EQU *-1
063.042 302 205 070 4281 JNE ERR.AC ARG COUNT ERROR
063.045 376 020 4282 CPI CT,PAR
063.047 302 363 062 4283 JNE TXTF1 MORE TO ASSIGN
063.052 305 4284 PUSH B EXCHANGE POINTERS
063.053 343 4285 XTHL
063.054 301 4286 POP B

```

063.055	345	4287	PUSH	H	SAVE CALLER POINTER
063.056	315 305 077	4288	CALL	RNT	
063.061	011	4289	DB	CT.EQ	REQUIRE =
063.062	315 244 055	4290	CALL	EVAL	EVALUATE FUNCTION
063.065	315 305 077	4291	CALL	RNT	
063.070	000	4292	DB	CT.FIN	REQUIRE STATEMENT END
063.071	301	4293	POP	B	
063.072	303 072 076	4294	JMP	PNT	EXIT WITH NEXT TOKEN PEKED


```

4298 **      EXP - CALCULATE EXP(X).
4299 *
4300 *      Y=EXP(X)
4301 *
4302 *      VIA:
4303 *
4304 *      X1 = X * LN(2)^-1
4305 *
4306 *      Y = 2^(INT(X1)) * 2^(FRACT(X1))
4307 *
4308 *      FRACT(X) [0,1) = P5(X)
4309
4310
063.075      4311 EXP EQU *
063.075 305 4312 PUSH B SAVE TEXT POINTER
063.076 072 204 042 4313 LDA ACCX+2 (A) = SIGN
063.101 247 4314 ANA A
063.102 365 4315 PUSH PSW SAVE RESULTS
063.103 374 305 105 4316 CM NEG INSURE POSITIVE
063.106 041 221 063 4317 LXI H,EXPA
063.111 315 327 105 4318 CALL MUL (ACCX) = X * LN(2)^-1
063.114 315 223 073 4319 CALL CXY SAVE IN ACCY
063.117 315 377 074 4320 CALL IFIX. (DE) = INT(X1)
063.122 172 4321 MOV A,D
063.123 247 4322 ANA A
063.124 312 133 063 4323 JZ EXP1 EXPONENT NOT TOO BIG
063.127 074 4324 INR A
063.130 302 136 070 4325 JNZ ERR.OV EXPONENT TOO BIG
063.133 325 4326 EXP1 PUSH D SAVE EXP
063.134 315 040 075 4327 CALL IFLT FLOAT INTO ACCX
063.137 041 210 042 4328 LXI H,ACCY
063.142 315 172 105 4329 CALL SUB (ACCX) = FRACT(X1)
063.145 315 177 065 4330 CALL POLY EVALUATE P5(X)
063.150 006 4331 BB 6
063.151 202 014 173 4332 DB 2020,0140,1730,1670 .001877576677
063.155 003 244 111 4333 DB 0030,2440,1110,1720 .008989340083
063.161 021 125 162 4334 DB 0210,1250,1620,1740 .05582631808
063.165 152 365 172 4335 DB 1520,3650,1720,1760 .2401536170
063.171 075 271 130 4336 DB 0750,2710,1300,2000 .6931530732
063.175 377 377 177 4337 DB 3770,3770,1770,2000 .9999999250
4338
063.201 321 4339 POP D (DE) = EXP OF 2^(INT(X1))
063.202 173 4340 MOV A,E (A) = EXPONENT ADJUSTMENT
063.203 041 205 042 4341 LXI H,ACCX+3
063.206 206 4342 ADD H ADJUST EXPONENT
063.207 167 4343 MOV M,A
063.210 332 136 070 4344 JC ERR.OV OVERFLOW
063.213 361 4345 POP PSW (A) = RESULTS OF INITIAL SIGN TEST
063.214 374 312 065 4346 CM RCX EXP(X) = 1/EXP(-X)
063.217 301 4347 POP B RESTORE BC
063.220 311 4348 RET
4349
063.221 035 125 134 4350 EXPA DB 0350,1250,1340,2010 1/LN(2)
    
```

```

4352 **      LOG - CALCULATE LOG BASE E
4353 *
4354 *      Y=LOG(X)
4355 *
4356 *      VIA:
4357 *
4358 *      LOGE(X) = LOGE(2)* LOG2(X)
4359 *
4360 *      LOG2(X) = EXPONENT(X) + LOG2(MANTISSA)
4361 *
4362 *      LOG2(N) [1.5,1) = P3(X)/P2(X)
4363 *
4364 *
063.225      4365 LOG EQU *
063.225 305      4366 PUSH B SAVE TEXT POINTER
063.226 041 204 042 4367 LXI H,ACCX+2
063.231 176      4368 MOV A,H (A) = SIGN
063.232 247      4369 ANA A
063.233 372 122 070 4370 JM ERR.IN MUST BE > 0 /80.01.6C/
063.236 312 136 070 4371 JZ ERR.OV
063.241 043      4372 INX H
063.242 136      4373 MOV E,M
063.243 026 000      4374 MVI D,0 (DE) = EXPONENT
063.245 325      4375 PUSH D SAVE
063.246 066 200      4376 MVI H,2000 (ACCX) = MANTISSA
063.250 315 153 065 4377 CALL POLYQ COMPUTE P3(X)/P2(X)
063.253 004      4378 DB 4
063.254 000 000 100 4379 DB 0000,0000,1000,2010 1.0
063.260 160 330 146 4380 DB 1600,3300,1460,2030 6.4278 42090
063.264 005 271 110 4381 DB 0050,2710,1100,2030 4.5451 70876
063.270 172 202 132 4382 DB 1720,2020,1320,1770 .35355 34252
063.274 004      4383 DB 4
063.275 314 373 114 4384 DB 3140,3730,1140,2030 4.8114 74609
063.301 221 261 141 4385 DB 2210,2610,1410,2030 6.1058 51990
063.305 106 031 271 4386 DB 1060,0310,2710,2040 -8.8628 59939
063.311 054 100 276 4387 DB 0540,1000,2760,2020 -2.0546 66719
063.315 315 223 073 4388 CALL CXY (ACCY) = LOG2(MANTISSA)
063.320 321      4389 POP D (DE) = EXPONENT
063.321 315 040 075 4390 CALL IFLT
063.324 041 350 063 4391 LXI H,LOGA
063.327 315 356 104 4392 CALL ADD REMOVE EXPONENT BIAS
063.332 041 210 042 4393 LXI H,ACCY
063.335 315 356 104 4394 CALL ADD (ACCX) = EXPONENT+LOG2(MANTISSA)
063.340 041 354 063 4395 LXI H,LOGB
063.343 315 327 105 4396 CALL MUL (ACCX) = LOGE(2)*LOG2(X)
063.346 301      4397 POP B
063.347 311      4398 RET
4399 *
063.350 000 000 200 4400 LOGA DB 0000,0000,2000,2070 -128.
063.354 014 271 130 4401 LOGB DB 0140,2710,1300,2000 LOGE(2)
    
```

```

4403 ** SQRT - SQUARE ROOT.
4404 *
4405 * Y=SQRT(X)
4406 *
4407 * VIA:
4408 *
4409 * SQRT(X) = 2^B * SQRT(X*2^(-2*B))
4410 *
4411 * SQRT(X1) [.25;1] = P2(X)/P2(X)
4412 *
4413
063.360 4414 SQR EQU *
063.360 305 4415 PUSH B
063.361 315 033 077 4416 CALL PSHX SAVE X
063.364 041 204 042 4417 LXI H,ACCX+2
063.367 176 4418 MOV A,M (A) = SIGN
063.370 247 4419 ANA A
063.371 372 122 070 4420 JM ERR.IN MUST BE >= 0
063.374 312 112 064 4421 JZ SQRT3 IS ZERO
063.377 043 4422 INX H
064.000 176 4423 MOV A,M (A) = EXPONENT
4424
4425 * EXPONENT >= 2000. SCALE TO 177 OR 200
4426
064.001 326 177 4427 SUI 1770
064.003 037 4428 RAR (A) = B (SCALE FACTOR)
064.004 365 4429 PUSH PSW SAVE FACTOR
064.005 077 4430 CMC
064.006 303 015 064 4431 JMF SQRT2
4432
4433 * EXPONENT < 2000. SCALE TO 177 OR 200
4434
064.011 326 177 4435 SQRT1 SUI 1770
064.013 037 4436 RAR (A) = B (SCALE FACTOR)
064.014 365 4437 PUSH PSW SAVE SCALE FACTOR
064.015 076 200 4438 SQRT2 MVI A,2000
064.017 336 000 4439 SBI 0 (A) = 2000 OR 1770
064.021 167 4440 MOV M,A (ACCX) = SCALED VALUE
064.022 315 177 065 4441 CALL POLY EVALUTE POLY
064.025 005 4442 DB 5
064.026 053 017 255 4443 DB 0530,0170,2550,1770 -.32398 73450
064.032 327 005 104 4444 DB 3270,0050,1040,2010 1.062856525
064.036 153 213 241 4445 DB 1530,2130,2410,2010 -1.4758 65807
064.042 170 366 142 4446 DB 1700,3660,1420,2010 1.546293465
064.046 362 202 141 4447 DB 3620,2020,1410,1760 .19045 21794
4448
064.052 361 4449 POP PSW (A) = EXPONENT ADJUST
064.053 041 205 042 4450 LXI H,ACCX+3
064.056 206 4451 ADD M ADJUST EXPONENT
064.057 167 4452 MOV M,A
4453
4454 * APPLY HERON'S ITERATION ONCE.
4455
064.060 315 223 073 4456 CALL CXY ACCY = GUESS
064.063 315 357 076 4457 CALL POPX ACCX = X
064.066 041 210 042 4458 LXI H,ACCY
    
```

SORT

```

064.071 345          4459      PUSH      H
064.072 315 264 106 4460      CALL      DIV
064.075 341          4461      POP       H
064.076 315 356 104 4462      CALL      ADD          (HL) = #ACCY
064.101 041 205 042 4463      LXI      H,ACCX+3      (ACCX) = GUESS+X/GUESS
064.104 176          4464      MOV      A,M
064.105 326 001      4465      SUI      1          DIVIDE BY 2
064.107 167          4466      MOV      M,A
064.110 301          4467      POP      B          RESTORE (BC)
064.111 311          4468      RET
064.112 315 357 076 4470 SORT3 CALL      POPX      RESTORE STACK
064.115 301          4471      POP      B          RESTORE (BC)
064.116 311          4472      RET          EXIT

4474 **      SINCOS = SIN AND COSIN.
4475 *
4476 *      Y=SIN(X)
4477 *      Y=COS(X)
4478 *
4479 *      REDUCE RANGE FROM 0 TO PI/2 APPROXIMATE WITH
4480 *
4481 *      COS(X) = P4(X)
4482
4483
064.117          4484 SIN      EQU      *
064.117 021 163 112 4485      LXI      D,NPI,2
064.122 315 352 104 4486      CALL      FPADD      SIN(X) = COS(X-PI/2)
4487
064.125          4488 COS      EQU      *
064.125 305          4489      PUSH     B
064.126 315 252 065 4490      CALL      PTS          PERFORM TRIG SCALING
064.131 072 204 042 4491      LDA      ACCX+2
064.134 247          4492      ANA      A
064.135 374 305 105 4493      CM       NEG          COS(-X) = COS(X)
4494
4495 *      REDUCE RANGE TO 0<=X<=2*PI
4496
064.140 041 167 112 4497      LXI      H,NPI2      POINT TO -2PI
064.143 315 331 065 4498      CALL      RAR          REDUCE ARGUMENT RANGE
4499
4500 *      REDUCE RANGE TO 0<=X<=PI/2
4501
064.146 041 163 112 4502      LXI      H,NPI,2
064.151 315 331 065 4503      CALL      RAR
064.154 074          4504      INR      A
064.155 037          4505      RAR
064.156 062 234 064 4506      STA      COSA      (COSA) = ODD IF TO INVERT SIGN
064.161 332 175 064 4507      JC       COS1      IF < PI/2
064.164 041 163 112 4508      LXI      H,NPI,2      (X) = -(X-PI/2)
064.167 315 356 104 4509      CALL      ADD
064.172 315 305 105 4510      CALL      NEG
064.175 041 202 042 4511 COS1  LXI      H,ACCX
    
```

```

064.200 315 327 105 4512 CALL MUL (ACCX) = X**
064.203 315 177 065 4513 CALL POLY
064.206 005 4514 DB S
064.207 130 035 141 4515 DB 130Q,035Q,141Q,161Q .00002315393167
064.213 130 065 245 4516 DB 130Q,065Q,245Q,167Q -.00138 53704 276
064.217 267 123 125 4517 DB 267Q,123Q,125Q,174Q .04166358467
064.223 020 000 200 4518 DB 020Q,000Q,200Q,177Q -.49999 90534
064.227 000 000 100 4519 DB 000Q,000Q,100Q,201Q .9999999534
    
```

4520
 4521 * NEGATE SIGN OF RESULT, IF NECESSARY
 4522

```

064.233 076 000 4523 COS2 MUT A,0
064.234 4524 COSA EQU *-1 ODD IF TO TOGGLE SIGN
064.235 037 4525 RAR
064.236 334 305 105 4526 CC NEG
064.241 301 4527 POP B
064.242 311 4528 RET
    
```

4530 ** TAN - COMPUTE TANGENT FUNCTION.
 4531 *

```

4532
4533
064.243 4534 TAN EQU *
064.243 315 252 065 4535 CALL PTS PERFORM TRIG SCALING
064.246 072 204 042 4536 LDA ACCX+2
064.251 247 4537 ANA A
064.252 310 4538 RZ TAN(0) = 0
064.253 305 4539 PUSH B
064.254 007 4540 RLC
064.255 062 234 064 4541 STA COSA SET NEGATION FLAG
064.260 334 305 105 4542 CC NEG TAN(-X) = -TAN(X)
064.263 041 173 112 4543 LXI H,NPI REDUCE RANGE BY PI
064.266 315 331 065 4544 CALL RAR REDUCE ARGUMENT RANGE
    
```

4545
 4546 * REDUCE IT BY PI/2
 4547

```

064.271 041 163 112 4548 LXI H,NPI.2
064.274 315 331 065 4549 CALL RAR
064.277 247 4550 ANA A
064.300 312 321 064 4551 JZ TAN1 WAS IN RANGE 0 - PI/2
064.303 041 234 064 4552 LXI H,COSA
064.306 256 4553 XRA M
064.307 167 4554 MOV M,A TAN(X) = -TAN(PI-X)
064.310 041 163 112 4555 LXI H,NPI.2
064.313 315 356 104 4556 CALL ADD
064.316 315 305 105 4557 CALL NEG ACCX = -(X-PI)
    
```

4558
 4559 * SCALE TO PI/4
 4560

```

064.321 041 177 112 4561 TAN1 LXI H,NPI.4
064.324 315 331 065 4562 CALL RAR REDUCE ARGUMENT RANGE
064.327 062 016 065 4563 STA TANA SAVE COUNT
064.332 247 4564 ANA A
    
```

TAN

```

064.333 312 347 064 4565 JZ TAN2
4566
4567 * TAN(X) = 1/TAN(PI/2-X)
4568
064.336 041 177 112 4569 LXI H,PI.4
064.341 315 356 104 4570 CALL ADD
064.344 315 305 105 4571 CALL NEG (ACCX) = -(X-PI/2)
4572
064.347 041 203 112 4573 TAN2 LXI H,PI.4
064.352 315 264 106 4574 CALL DIV (ACCX) = X/(PI/4)
064.355 315 142 065 4575 CALL XPOLYQ COMPUTE P1(X^2)/P2(X^2)
064.360 003 4576 DB 3
064.361 000 000 100 4577 DB 000Q,000Q,100Q,201Q 1.
064.365 151 147 270 4578 DB 151Q,147Q,270Q,207Q 71.59606050
064.371 346 235 103 4579 DB 346Q,235Q,103Q,211Q 270.4672235
064.375 002 4580 DB 2
064.376 331 222 233 4581 DB 331Q,222Q,233Q,204Q -12.55329742
065.002 124 066 152 4582 DB 124Q,066Q,152Q,210Q 212.42445758
4583
065.006 315 365 076 4584 CALL POPY (ACCY) = X
065.011 353 4585 XCHG
065.012 315 327 105 4586 CALL MUL X*PI/P2
065.015 076 000 4587 MVI A,0
065.016 4588 TANA ERU *-1
065.017 037 4589 RAR
065.020 334 312 065 4590 CC RCX TAKE RECIPRICAL OF ACCX
065.023 303 233 064 4591 JMP COS2 NEGATE RESULT, IF NECESSARY
    
```

```

4593 ** ATAN = ATAN(X)
4594 *
4595
4596
065.026 4597 ATN EQU *
065.026 305 4598 PUSH B
065.027 072 204 042 4599 LDA ACCX+2
065.032 007 4600 RLC
065.033 062 234 064 4601 STA COSA SET NEGATE FLAG
065.036 334 305 105 4602 CC NEG ATAN(-X) = -ATAN(X)
065.041 072 205 042 4603 LDA ACCX+3
065.044 326 201 4604 SUI 201Q
065.046 365 4605 PUSH PSW SAVE RANGE
065.047 324 312 065 4606 CNC RCX IF VALUE > 1, TAKE RECIPROCAL
4607
065.052 315 142 065 4608 ATAN1 CALL XPOLYQ =X*P3(X^2)/P2(X^2)
065.055 003 4609 DB 3
065.056 000 000 100 4610 DB 000Q,000Q,100Q,201Q 1.
065.062 156 132 103 4611 DB 156Q,132Q,103Q,203Q 4.2095 84416
065.066 332 176 164 4612 DB 332Q,176Q,164Q,202Q 3.640485264
065.072 004 4613 DB 4
065.073 156 000 252 4614 DB 156Q,000Q,252Q,172Q -.01049 78419 9
065.077 104 042 123 4615 DB 104Q,042Q,123Q,177Q .32474 16032
065.103 013 340 137 4616 DB 013Q,340Q,137Q,202Q 2.996099356
065.107 332 176 164 4617 DB 332Q,176Q,164Q,202Q 3.640485163
    
```

```

4618
065.113 315 365 076 4619 CALL POPY
065.116 353 4620 XCHG
065.117 315 327 105 4621 CALL MUL MULTIPLY RESULT BY X
065.122 361 4622 POP PSW RESTORE INVERT CODE
065.123 332 137 065 4623 JC ATAN2 NOT INVERTED
065.126 041 163 112 4624 LXI H, NPI.2 PI/2-ATAN(1/X)= ATAN(X)
065.131 315 356 104 4625 CALL ADD
065.134 315 305 105 4626 CALL NEG ACCX = -(X-PI/2)
065.137 303 233 064 4627 ATAN2 JMP COS2 NEGATE IF NECESSARY
    
```

```

4629 ** XPOLYQ - EVALUATE X*(X^2)/Q(X^2)
4630 *
4631 * ENTRY (ACCX) = VALUE
4632 * (RET) = QUOTIENT LIST, NUMERATOR FIRST
4633 * EXIT TO AFTER LIST
4634 * USES ALL
4635 *
4636 *
    
```

```

065.142 315 033 077 4637 XPOLYQ CALL PSHX SAVE X
065.145 041 202 042 4638 LXI H, ACCX
065.150 315 327 105 4639 CALL MUL X=X^2
    
```

```

4641 ** POLYQ - EVALUATE P(X)/Q(X)
4642 *
4643 * ENTRY (ACCX) = X
4644 * (RET) = QUOTIENT LIST, NUMERATOR FIRST
4645 * EXIT TO AFTER LIST
4646 * USES ALL
4647 *
4648 *
    
```

```

065.153 341 4649 POLYQ POP H (HL) = LIST ADDRESS
065.154 315 204 065 4650 CALL PLY COMPUTE DENOMINATOR
065.157 345 4651 PUSH H SAVE (HL)
065.160 315 033 077 4652 CALL PSHX SAVE QUOTIENT
065.163 341 4653 POP H RESTORE (HL)
065.164 315 207 065 4654 CALL FLYO COMPUTE NUMERATOR
065.167 345 4655 PUSH H SAVE RETURN ADDRESS
065.170 315 365 076 4656 CALL POPY (ACCY) = DENOMINATOR
065.173 353 4657 XCHG (HL) = #ACCY
065.174 303 264 106 4658 JMP DIV DIVIDE AND RETURN
    
```

```

4660 ** POLY - EVALUATE POLYNOMIAL.
4661 *
4662 * ENTRY ACCX = X
4663 * (RET) = COEFFICIENT LIST
4664 * EXIT TO AFTER LIST
4665 * USES ALL
4666
4667
065.177 341 4668 POLY POP H (HL) = RETURN ADDRESS
065.200 315 204 065 4669 CALL PLY COMPUTE
065.203 351 4670 PCHL

```

```

4672 ** PLY - COMPUTE POLYNOMIAL.
4673 *
4674 * ACCX = PN(X)
4675 *
4676 * COMPUTE A + X(B + X(C + X(D...)))
4677
4678
065.204 315 223 073 4679 PLY CALL CXY (ACCY) = ACCX VALUE
065.207 176 4680 PLY0 MOV A,M (A) = COUNT
065.210 365 4681 PUSH PSW
065.211 043 4682 INX H
065.212 353 4683 XCHG (DE) = ADDRESS
065.213 315 210 073 4684 CALL CVX (ACCX) = D
065.216 353 4685 XCHG (HL) = ADDRESS OF D
065.217 303 240 065 4686 JMP PLY2
4687
065.222 365 4688 PLY1 PUSH PSW SAVE COUNT
065.223 345 4689 PUSH H SAVE ADDRESS
065.224 041 210 042 4690 LXI H,ACCY
065.227 315 327 105 4691 CALL MUL COMPUTE X(...)
065.232 341 4692 POP H
065.233 345 4693 PUSH H
065.234 315 356 104 4694 CALL ADD COMPUTE A + X(...)
065.237 341 4695 POP H
065.240 361 4696 PLY2 POP PSW
065.241 043 4697 INX H
065.242 043 4698 INX H
065.243 043 4699 INX H
065.244 043 4700 INX H
065.245 075 4701 POLY2 DCR A
065.246 302 222 065 4702 JNZ PLY1 IF MORE TO GO
065.251 311 4703 RET DONE

```



```

4705 **   PTS - PERFORM TRIG SCALING.
4706 *
4707 *   PTS SCALES A VALUE INTO THE RANGE -2*PI <= X <= 2*PI
4708 *   ONLY IF -10*PI <= X <= 10*PI.
4709 *
4710 *   FOR VALUES WITHIN THIS RANGE, THE ADDITIVE SCALING OF THE
4711 *   FUNCTIONS THEMSELVES IS MORE EFFICIENT.
4712 *
4713 *   ENTRY (ACCX) = X
4714 *   EXIT (ACCX) = SCALED VALUE
4715 *   USES  A;F;D;E;H;L
4716 *
4717 *
065.252 072 205 042 4718 PTS LDA ACCX+3 (A) = EXPONENT
065.255 376 206 4719 CPI 2060
065.257 330 4720 RC DOSENT NEED IT.
065.260 305 4721 PUSH B SAVE (BC)
4722 *
4723 *   COMPUTE SCALED = X - INT(X/2*PI) * 2*PI
4724 *
065.261 315 223 073 4725 CALL CXY (ACCY) = X
065.264 041 167 112 4726 LXI H,NPI2
065.267 345 4727 PUSH H SAVE ADDRESS OF NPI2
065.270 315 264 106 4728 CALL DIV
065.273 315 216 057 4729 CALL INT FIX
065.276 341 4730 POP H
065.277 315 327 105 4731 CALL MUL
065.302 041 210 042 4732 LXI H,ACCY
065.305 315 172 105 4733 CALL SUB TAKE DIFFERENCE
065.310 301 4734 POP B
065.311 311 4735 RET

4737 **   RCX - TAKE RECIPROCAL OF (ACCX).
4738 *
4739 *   (ACCX) = 1/(ACCX)
4740 *
4741 *   ENTRY NONE
4742 *   EXIT NONE
4743 *   USES ALL
4744 *
4745 *
065.312 315 223 073 4746 RCX CALL CXY (ACCY) = X
065.315 021 147 112 4747 LXI D,FP1.0
065.320 315 210 073 4748 CALL CUX COPY VALUE INTO ACCX
065.323 041 210 042 4749 LXI H,ACCY
065.326 303 264 106 4750 JMP DIV ACCX = 1/(ACCX)
    
```

```

4752 **   RAR - REDUCE ARGUMENT RANGE.
4753 *
4754 *   RAR REDUCES THE ARGUMENT RANGE OF A VALUE BY REPEATED
4755 *   ADDITION WITH A NEGATIVE CONSTANT, UNTIL THE NUMBER IS
4756 *   SMALLER THAN ABS(CONSTANT)
4757 *
4758 *   ENTRY (HL) = CONSTANT
4759 *   EXIT (A) = ADDITION COUNT
4760 *   (HL) UNCHANGED
4761 *   USES A,F,B,C,D,E
4762
4763
065.331 257 4764 RAR   XRA   A
4765
065.332 365 4766 RAR1  PUSH  PSW   SAVE COUNT
065.333 315 223 073 4767   CALL  CXY   SAVE VALUE IN ACCY
065.336 345 4768   PUSH  H
065.337 315 356 104 4769   CALL  ADD   SUBTRACE
065.342 341 4770   POP   H
065.343 072 204 042 4771   LDA   ACCX+2
065.346 247 4772   ANA   A
065.347 372 357 065 4773   JM    RAR2  DONE
065.352 361 4774   POP  PSW
065.353 074 4775   INR  A
065.354 303 332 065 4776   JMP  RAR1
4777
065.357 315 317 100 4778 RAR2  CALL  XCY   COPY LAST VALUE INTO ACCX
065.362 361 4779   POP  PSW
065.363 311 4780   RET

```

```

4784 ** ICL - INPUT COMMAND LINE.
4785 *
4786 * ICL INPUTS A COMMAND INTO *LINE*.
4787 *
4788 * KEYWORDS ARE EXPANDED UNLESS
4789 * 1) THEY FOLLOW A 'REM' KEYWORD
4790 * 2) THEY APPEAR IN QUOTES
4791 *
4792 * ICL MAKES (AND ENFORCES) CERTAIN ASSUMPTIONS ABOUT
4793 * LEXICAL SYNTAX
4794 * 1) A PAIR OF ALPHA CHARACTERS MAY ONLY APPEAR IN A
4795 * KEYWORD, OR WITHIN A 'REM' OR QUOTED STRING.
4796 * 2) ALL KEYWORDS ARE UNIQUE WITHIN THE 1ST 3 CHARACTERS.
4797 *
4798 * IF A CTL-C IS ENTERED, ICL EXITS WITH NO TEXT.
4799 *
4800 * ENTRY (A) = PROMPT CHARACTER
4801 * EXIT LINE READ
4802 * 'C' SET IF CTL-C ENTERED, NO TEXT.
4803 * 'C' CLEAR IF HAVE LINE
4804 * 'Z' SET IF NO ERROR IN LINE
4805 * USES ALL
4806
4807
065.364 4808 ICL EQU *
065.364 041 266 112 4809 LXI H,LINE+1
065.367 315 075 077 4810 CALL RIL READ INPUT LINE
065.372 330 4811 RC CTL-C
4812
4813 ** ICL. - ENTRY FOR PRE-READ LINE
4814 *
4815 * (HL) = LINE FWA (BUFFER ADDRESS +1)
4816
065.373 053 4817 ICL. DCX H PRE-DECREMENT H
065.374 345 4818 PUSH H SAVE BUFFER FWA
065.375 104 4819 MOV B,H
065.376 115 4820 MOV C,L (BC) = TO, (HL) = FROM
065.377 013 4821 DCX B PREDECREMENT (BC)
4822
4823 * COPY ANOTHER CHARACTER
4824
066.000 003 4825 ICL1 INX B
066.001 043 4826 ICL1.5 INX H
066.002 176 4827 MOV A,M
066.003 002 4828 STAX B COPY CHARACTER
066.004 127 4829 MOV D,A (D) = 0 IFF END OF LINE
066.005 247 4830 ANA A
066.006 312 234 066 4831 JZ ICL10 ALL DONE
066.011 315 045 112 4832 CALL $MCU MAP CHARACTER TO UPPER CASE
066.014 376 042 4833 CPI ''
066.016 312 176 066 4834 JE ICL7 GOT QUOTES
066.021 376 101 4835 CPI 'A'
066.023 332 000 066 4836 JC ICL1 NOT ALPHA
066.026 376 133 4837 CPI 'Z'+1
066.030 322 000 066 4838 JNC ICL1 NOT ALPHA
4839

```

```

4840 *      HAVE AN ALPHA CHARACTER.  SEE IF WE HAVE 2 IN A ROW
4841
066.033 043 4842      INX      H
066.034 176 4843      MOV      A,M
066.035 053 4844      DCX      H
066.036 315 045 112 4845      CALL    $MCU      MAP CHARACTER TO UPPER CASE
066.041 376 101 4846      CPI      'A'
066.043 332 000 066 4847      JC      ICL1      NOT TWO ALPHA
066.046 376 133 4848      CPI      'Z'+1
066.050 322 000 066 4849      JNC     ICL1      NOT TWO ALPHA
4850
4851 *      HAVE TWO ALPHA IN A ROW.  MUST BE A KEYWORD.  FIND IT IN LIST
4852
066.053 021 240 066 4853      LXI      D,KEYTAB
066.056 345 4854      ICL2   PUSH     H      SAVE *FROM* ADDRESS
066.057 032 4855      LDAX   D
066.060 002 4856      STAX   B      ASSUME IS THIS KEYWORD
066.061 023 4857      INX      D
066.062 032 4858      ICL3   LDAX   D      COMPARE LINE AGAINST TABLE ENTRY
066.063 247 4859      ANA      A
066.064 372 122 066 4860      JM      ICL5      GOT MATCH
066.067 353 4861      XCHG   (DE) = LINE, (HL) = KEYTAB ADDR
066.070 032 4862      LDAX   D      (A) = CHARACTER
066.071 315 045 112 4863      CALL    $MCU      MAP TO UPPER
066.074 276 4864      CMP      H
066.075 353 4865      XCHG   RESTORE (DE) AND (HL)
066.076 023 4866      D
066.077 043 4867      INX      H
066.100 312 062 066 4868      JE      ICL3      STILL MATCHING
066.103 033 4869      DCX      D      PRE-DECREMENT KEYTAB POINTER
4870
4871 *      NOT THIS KEYWORD.  SCAN TO NEXT ONE AND RETRY.
4872
066.104 023 4873      ICL4   INX      D
066.105 032 4874      LDAX   D
066.106 247 4875      ANA      A
066.107 362 104 066 4876      JP      ICL4      NOT AT START OF NEXT
066.112 341 4877      POP     H      (HL) = FWA OF UNKNOWN KEYWORD
066.113 074 4878      INR      A      SEE IF AT END OF LIST
066.114 302 056 066 4879      JNZ     ICL2      NOT AT END OF LIST
066.117 303 216 066 4880      JMP     ICL8      INVALID KEYWORD
4881
4882 *      HAVE FOUND THE KEYWORD.  SEE IF ((') FOLLOWS
4883 *
4884 *      (HL) POINTS JUST PAST THE KEYWORD ON THE LINE
4885
066.122 321 4886      ICL5   POP     D      DISCARD KEYWORD FWA
066.123 012 4887      LDAX   B      (A) = KEYWORD VALUE
066.124 003 4888      INX      B
066.125 376 320 4889      CPI      CT,FCN
066.127 322 163 066 4890      JNC     ICL6      IS FUNCTION
066.132 365 4891      PUSH   PSW      SAVE CODE
066.133 176 4892      MOV      A,M
066.134 376 040 4893      CPI      ' '
066.136 302 142 066 4894      JNE     ICL5.5    NO BLANK FOLLOWING
066.141 043 4895      INX      H

```

```

.....
066.142 361          4896 ICL5.5 POP    PSW          (A) = KEYWORD CODE
066.143 026 000     4897          MVI    D,0          NO ERROR WHEN REACH END OF LINE
066.145 378 242     4898          CPI    CT.REM
066.147 312 223 066 4899          JE     ICL9          COPY REST OF LINE
066.152 378 251     4900          CPI    CT.DAT
066.154 312 223 066 4901          JE     ICL9          COPY REST OF LINE
066.157 053         4902          DCX   H             PRESET (HL) FOR INCREMENT
066.160 303 001 066 4903          JMP   ICL1.5
.....
4904
4905 *             IS FUNCTION, REQUIRE '('
4906
066.163 315 330 111 4907 ICL6   CALL   $SOB          SKIP OVER BLANKS
066.166 376 050     4908          CPI    '('
066.170 312 001 066 4909          JE     ICL1.5       OK, GOBBLE '('
066.173 303 216 066 4910          JMP   ICL8          ERROR
.....
4911
4912 *             GOT QUOTE, SCAN TO CLOSE QUOTE
4913
066.176 003         4914 ICL7   INX    B
.....
066.177 043         4915          INX    H
066.200 176         4916          MOV   A,M
066.201 002         4917          STAX  B             STORE CHARACTER
066.202 247         4918          ANA   A
066.203 312 216 066 4919          JZ    ICL8          ERROR
066.206 376 042     4920          CPI    '?'
066.210 302 176 066 4921          JNE   ICL7          NOT CLOSE QUOTE
066.213 303 000 066 4922          JMP   ICL1          GOT CLOSE
.....
4923
4924 *             ERROR IN LINE, FLAG IT, AND COPY THE REST VERBATIM
4925 *             (A) = 0
4926
066.216 076 212     4927 ICL8   MVI    A,CT.SYE
066.220 002         4928          STAX  B             SET ERROR
066.221 003         4929          INX   B
066.222 127         4930          MOV   D,A          (D) <> 0 INDICATING ERROR
.....
4931
4932 *             COPY REST OF LINE VERBATIM
4933 *             (D) <> 0 IF ERROR
4934
066.223 176         4935 ICL9   MOV   A,M
066.224 002         4936          STAX  B
066.225 043         4937          INX   H
066.226 003         4938          INX   B
066.227 247         4939          ANA   A
066.230 302 223 066 4940          JNZ   ICL9          NOT DONE
066.233 013         4941          DCX   B
.....
4942
4943 *             ALL DONE.
4944 *
4945 *             (BC) = LINE LWA
4946 *             (D) <> 0 IFF ERROR
4947
066.234 341         4948 ICL10 POP    H             (HL) = FWA
066.235 172         4949          MOV   A,D          (A) = ERROR FLAG
066.236 247         4950          ANA   A
066.237 311         4951          RET
.....

```

4953 ** KEYTAB - KEYWORD TABLE.

4954 *

4955

Address	Line 1	Line 2	Line 3	Line 4	Address	Code	Keyword	Keyword
066.240					4956	KEYTAB	EQU	*
066.240	320	101	102	4957	DB	CT.ABS,	'ABS'	
066.244	310	101	116	4958	DB	CT.AND,	'AND'	
066.250	350	101	123	4959	DB	CT.ASC,	'ASC'	
066.254	311	101	123	4960	DB	CT.AS,	'AS'	
066.257	321	101	124	4961	DB	CT.ATN,	'ATN'	
066.263	200	102	125	4962	DB	CT.BLD,	'BUILD'	
066.271	201	102	131	4963	DB	CT.BYE,	'BYE'	
066.275	213	103	110	4964	DB	CT.CHA,	'CHAIN'	
066.303	322	103	110	4965	DB	CT.CHR,	'CHR\$'	
066.310	323	103	111	4966	DB	CT.CIN,	'CIN'	
066.314	214	103	114	4967	DB	CT.CLR,	'CLEAR'	
066.322	215	103	114	4968	DB	CT.CLO,	'CLOSE'	
066.330	216	103	116	4969	DB	CT.CTL,	'CNTRL'	
066.336	202	103	117	4970	DB	CT.CNT,	'CONTINUE'	
066.347	324	103	117	4971	DB	CT.COS,	'COS'	
066.353	251	104	101	4972	DB	CT.DAT,	'DATA'	
066.360	252	104	105	4973	DB	CT.DEF,	'DEF'	
066.364	203	104	105	4974	DB	CT.DEL,	'DELETE'	
066.373	217	104	111	4975	DB	CT.DIM,	'DIM'	
066.377	253	105	116	4976	DB	CT.END,	'END'	
067.003	325	105	130	4977	DB	CT.EXP,	'EXP'	
067.007	312	106	111	4978	DB	CT.FIL,	'FILE'	
067.014	220	106	116	4979	DB	CT.FN,	'FN'	
067.017	221	106	117	4980	DB	CT.FOR,	'FOR'	
067.023	223	106	122	4981	DB	CT.FRZ,	'FREEZE'	MUST APPEAR BEFORE 'FREE'
067.032	222	106	122	4982	DB	CT.FRE,	'FREE'	
067.037	224	107	117	4983	DB	CT.GOS,	'GOSUB'	
067.045	225	107	117	4984	DB	CT.GOT,	'GOTO'	
067.052	226	111	106	4985	DB	CT.IF,	'IF'	
067.055	254	111	116	4986	DB	CT.INP,	'INPUT'	
067.063	326	111	116	4987	DB	CT.INT,	'INT'	
067.067	352	114	105	4988	DB	CT.LEN,	'LEN'	
067.073	351	114	105	4989	DB	CT.LEF,	'LEFT\$'	
067.101	227	114	105	4990	DB	CT.LET,	'LET'	
067.105	250	114	111	4991	DB	CT.LIN,	'LINE'	
067.112	204	114	111	4992	DB	CT.LIS,	'LIST'	
067.117	230	114	117	4993	DB	CT.LCK,	'LOCK'	
067.124	327	114	116	4994	DB	CT.LND,	'LNO'	
067.130	330	114	117	4995	DB	CT.LOG,	'LOG'	
067.134	353	115	101	4996	DB	CT.MAT,	'MATCH'	
067.142	331	115	101	4997	DB	CT.MAX,	'MAX'	
067.146	354	115	111	4998	DB	CT.MID,	'MID\$'	
067.153	332	115	111	4999	DB	CT.MIN,	'MIN'	
067.157	231	116	105	5000	DB	CT.NXT,	'NEXT'	
067.164	314	116	117	5001	DB	CT.NOT,	'NOT'	
067.170	232	117	114	5002	DB	CT.OLD,	'OLD'	
067.174	233	117	116	5003	DB	CT.ON,	'ON'	
067.177	234	117	120	5004	DB	CT.OPE,	'OPEN'	
067.204	315	117	122	5005	DB	CT.OR,	'OR'	
067.207	235	117	125	5006	DB	CT.OUT,	'OUT'	
067.213	333	120	101	5007	DB	CT.PAD,	'PAD'	
067.217	236	120	101	5008	DB	CT.PAU,	'PAUSE'	

ICL - INPUT COMMAND LINE.

KEYTAB

15:46:31 16-MAY-80

067.225	334	120	105	5009	DB	CT.PEK,'PEEK'
067.232	335	120	111	5010	DB	CT.PIN,'PIN'
067.236	237	120	117	5011	DB	CT.POK,'POKE'
067.243	336	120	117	5012	DB	CT.POS,'POS'
067.247	240	120	122	5013	DB	CT.PRT,'PRINT'
067.255	241	122	105	5014	DB	CT.REA,'READ'
067.262	242	122	105	5015	DB	CT.REM,'REM'
067.266	205	122	105	5016	DB	CT.REP,'REPLACE'
067.276	243	122	105	5017	DB	CT.RES,'RESTORE'
067.306	244	122	105	5018	DB	CT.RET,'RETURN'
067.315	355	122	111	5019	DB	CT.RIG,'RIGHT*
067.324	337	122	116	5020	DB	CT.RND,'RND'
067.330	206	122	125	5021	DB	CT.RUN,'RUN'
067.334	207	123	101	5022	DB	CT.SAV,'SAVE'
067.341	210	123	103	5023	DB	CT.SCR,'SCRATCH'
067.351	340	123	105	5024	DB	CT.SEG,'SEG'
067.355	341	123	107	5025	DB	CT.SGN,'SGN'
067.361	342	123	111	5026	DB	CT.SIN,'SIN'
067.365	343	123	120	5027	DB	CT.SPC,'SPC'
067.371	344	123	121	5028	DB	CT.SQR,'SQR'
067.375	345	123	124	5029	DB	CT.STR,'STR*
070.002	211	123	124	5030	DB	CT.STE,'STEP'
070.007	255	123	124	5031	DB	CT.STP,'STOP'
070.014	346	124	101	5032	DB	CT.TAB,'TAB'
070.020	347	124	101	5033	DB	CT.TAN,'TAN'
070.024	316	124	110	5034	DB	CT.THN,'THEN'
070.031	317	124	117	5035	DB	CT.TO,'TO'
070.034	245	125	116	5036	DB	CT.UNF,'UNFREEZE'
070.045	246	125	116	5037	DB	CT.UNL,'UNLOCK'
070.054	247	125	116	5038	DB	CT.UNS,'UNSAVE'
070.063	356	126	101	5039	DB	CT.VAL,'VAL'
070.067	313	127	122	5040	DB	CT.WRI,'WRITE'
070.075	212	007	052	5041	DB	CT.SYE,BELL,'*ERR*' HERE FOR LISTING VIA *EKA*, CANNOT BE MATCHED
070.105	377		5042	DB	377Q 377Q = END OF TABLE	

```

5046 **      ERROR PROCESSING.
5047 *
5048 *      THESE ERROR PROCESSORS ARE ENTERED WHEN AN ERROR IS DETECTED.
5049 *
5050 *      SINCE ALL TRACK OF CONTROL HAS BEEN LOST, EXECUTING CANNOT
5051 *      BE RESUMED.
5052 *
5053 *      THE USER MAY DISPLAY VARIABLES WHEN AN ERROR OCCURS, BUT MAY
5054 *      NOT 'CONTINUE'.
5055
5056
5057
5058
5059
070.106 076 200 5060 ERR.DC MVI  A,BEC.DC      CONTROL-C
070.110 001      5061      DB      MI.LXIB
5062
070.111 076 201 5063 ERR.CB MVI  A,BEC.CB      CTL-R
070.113 001      5064      DB      MI.LXIB
5065
070.114 076 202 5066 ERR.DE MVI  A,BEC.DE      DATA EXHAUSTED
070.116 001      5067      DB      MI.LXIB
5068
070.117 076 203 5069 ERR.DO MVI  A,BEC.DO      /O
070.121 001      5070      DB      MI.LXIB
5071
070.122 076 204 5072 ERR.IN MVI  A,BEC.IN      ILLEGAL NUMBER
070.124 001      5073      DB      MI.LXIB
5074
070.125 076 205 5075 ERR.IU MVI  A,BEC.IU      ILLEGAL USAGE
070.127 001      5076      DB      MI.LXIB
5077
070.130 076 206 5078 ERR.LK MVI  A,BEC.LK      DATA LOCK ENGAGED
070.132 001      5079      DB      MI.LXIB
5080
070.133 076 207 5081 ERR.NV MVI  A,BEC.NV      NEXT VARIABLE MISSING
070.135 001      5082      DB      MI.LXIB
5083
070.136 076 210 5084 ERR.OV MVI  A,BEC.OV      OVERFLOW
070.140 001      5085      DB      MI.LXIB
5086
070.141 076 211 5087 ERR.RE MVI  A,BEC.RE      RETURN ERROR
070.143 001      5088      DB      MI.LXIB
5089
070.144 076 212 5090 ERR.SL MVI  A,BEC.SL      STRING LENGTH
070.146 001      5091      DB      MI.LXIB
5092
070.147 076 213 5093 ERR.SN MVI  A,BEC.SN      STATEMENT NUMBER
070.151 001      5094      DB      MI.LXIB
5095
070.152 076 214 5096 ERR.SY MVI  A,BEC.SY      SYNTAX ERROR
070.154 001      5097      DB      MI.LXIB
5098
070.155 076 215 5099 ERR.TC MVI  A,BEC.TC      TYPE CONFLICH
070.157 001      5100      DB      MI.LXIB
5101

```


ERROR

070.160	076 216	5102	ERR.TO	MVI	A,BEC.TO	TABLE OVERFLOW	
070.162	001	5103		DB	MI.LXIB		
		5104					
070.163	076 217	5105	ERR.SR	MVI	A,BEC.SR	SUBSCRIPT RANGE	
070.165	001	5106		DB	MI.LXIB		
		5107					
070.166	076 220	5108	ERR.SC	MVI	A,BEC.SC	SUBSCRIPT COUNT	
070.170	001	5109		DB	MI.LXIB		
		5110					
070.171	076 221	5111	ERR.ND	MVI	A,BEC.ND	NOT DIMENSIONED	
070.173	001	5112		DB	MI.LXIB		
		5113					
070.174	076 222	5114	ERR.IC	MVI	A,BEC.IC	ILLEGAL CHARACTER	
070.176	001	5115		DB	MI.LXIB		
		5116					
070.177	076 226	5117	ERR.FAE	MVI	A,BEC.FAE	FILE ALREADY EXISTS	
070.201	001	5118		DB	MI.LXIB		
		5119					
070.202	076 227	5120	ERR.ILF	MVI	A,BEC.ILF	ILLEGAL FILE NAME	
070.204	001	5121		DB	MI.LXIB		
		5122					
070.205	076 230	5123	ERR.AC	MVI	A,BEC.AC	ARG COUNT	
070.207	001	5124		DB	MI.LXIB		
		5125					
070.210	076 231	5126	ERR.FND	MVI	A,BEC.FND	FILE NOT OPEN	
070.212	001	5127		DB	MI.LXIB		
		5128					
070.213	076 001	5129	ERR.EOF	MVI	A,EC.EOF	END OF FILE	
070.215	001	5130		DB	MI.LXIB		
		5131					
070.216	076 223	5132	ERR.UD	MVI	A,BEC.UD	UNDEFINED FUNCTION	
070.220	001	5133		DB	MI.LXIB		
		5134					
070.221	076 233	5135	ERR.CIU	MVI	A,BEC.CIU	CHANNEL IN USE	/80.01.GC/
		5136					
070.223		5137	SERROR	EQU	*		
070.223		5138	\$FERROR	EQU	*		
		5139					
070.223	365	5140		PUSH	PSW	SAVE ERROR CODE	
070.224	041 061 112	5141		LXI	H,MTABIND+MT.LEN	(HL) = #LENGTH OF TXXTAB	
070.227	136	5142		MOV	E,M		
070.230	043	5143		INX	H		
070.231	176	5144		MOV	A,M	(AE) = LENGTH OF TABLE	
070.232	247	5145		ANA	A		
070.233	302 244 070	5146		JNZ	ERROR1	TABLE LENGTH > 3	
070.236	173	5147		MOV	A,E		
070.237	376 004	5148		CPI	4		
070.241	334 320 077	5149		CC	SCRA	TABLE LENGTH < 3	
		5150					
070.244		5151	ERROR1	EQU	*		
		5152	*	CALL	FOP	MAKE OVL RESIDENT	
		5153	*	CALL	CLF	CLEAR FILE OPERATIONS	
070.244	377 007	5154		DB	SYSCALL,CLRCO	CLEAR CONSOLE	
070.246	315 136 031	5155		CALL	\$TYPTX		
070.251	012 007 041	5156		DB	NL,BELL,? ERROR ??,??+2000		
		5157					

		S158 *	TYPE MESSAGE	
		S159		
070.265	303	063	075	S160
		JMP	ILM	ISSUE LINE MESSAGE

```

5163 ** MTL - MANAGE TEXT LINE.
5164 *
5165 * MTL IS CALLED TO INSERT/REPLACE/DELETE A TEXT LINE FROM
5166 * THE TEXT BUFFER.
5167 *
5168 * ENTRY *LINE* = TEXT LINE
5169 * EXIT LINE INSERTED/DELETED/REPLACED
5170 * 'CI' FLAG SET
5171 * USES ALL
5172
5173
070.270 5174 MTL EQU *
070.270 315 313 075 5175 CALL LFC CHECK FOR DATA LOCK
070.273 041 265 112 5176 LXI H,LINE CRACK NUMBER FROM LINE
070.276 315 171 111 5177 CALL DDN DECODE DECIMAL NUMBER
070.301 315 206 072 5178 CALL CLN CHECK FOR LEGAL NUMBER
5179
5180 * DELETE LEADING BLANKS.
5181
070.304 053 5182 MTL0 DCX H
070.305 076 040 5183 MVI A, ' '
070.307 043 5184 MTL1 INX H SKIP LEADING BLANKS
070.310 276 5185 CMP H
070.311 312 307 070 5186 JE MTL1 STILL BLANKS
070.314 315 273 111 5187 CALL $CLL COMPUTE LINE LENGTH
070.317 075 5188 DCR A REMOVE END COUNT
070.320 312 325 070 5189 JZ MTL1.5 AM TO DELETE
070.323 306 003 5190 ADI 3 LINE NUMBER + END-OF-LINE
070.325 117 5191 MTL1.5 MOV C,A (C) = NEW LENGTH
070.326 053 5192 DCX H
070.327 162 5193 MOV H,D
070.330 053 5194 DCX H
070.331 163 5195 MOV M,E
070.332 345 5196 PUSH H SAVE (FROM) ADDRESS
070.333 052 057 112 5197 LHLD TTTTAB+MT.FWA
070.336 345 5198 PUSH H
070.337 315 242 074 5199 CALL FLN FIND LINE BY NUMBER
070.342 006 000 5200 MVI B,0 (B) = OLD LENGTH
070.344 332 361 070 5201 JC MTL2 IS INSERT
070.347 043 5202 INX H
070.350 043 5203 INX H
070.351 315 273 111 5204 CALL $CLL
070.354 306 002 5205 ADI 2
070.356 107 5206 MOV B,A (B) = OLD LENGTH
070.357 053 5207 DCX H
070.360 053 5208 DCX H (HL) = ADDRESS TO INSERT
070.361 321 5209 MTL2 POP B (DE) = TABLE FWA
070.362 175 5210 MOV A,L
070.363 223 5211 SUB E
070.364 157 5212 MOV L,A
070.365 174 5213 MOV A,H
070.366 232 5214 SBB D
070.367 147 5215 MOV H,A (HL) = INDEX
070.370 171 5216 MOV A,C (A) = LEW LENGTH
070.371 220 5217 SUB B (A) = NEW LENGTH - OLD
070.372 137 5218 MOV E,A

```

070.373	237		5219	SBB	A	
070.374	127		5220	MOV	D,A	(DE) = NEEDED BYTES COUNT
070.375	315	213 104	5221	CALL	\$IBT	MAKE OR DESTROY ROOM
071.000	057	112	5222	DW	TXITAB+1	TABLE POINTER
071.002	353		5223	XCHG		
071.003	052	057 112	5224	LHLD	TXITAB+MT.FWA	
071.006	031		5225	DAD	D	(HL) = *TO* ADDRESS
071.007	321		5226	POP	D	(DE) = *FROM* ADDRESS
071.010	006	000	5227	MVI	B,0	(BC) = NEW LENGTH
071.012	303	252 030	5228	JMP	\$MOVE	COPY TEXT INTO BUFFER AND RETURN

5230 ** MOV - MOVE A BLOCK OF DATA.

5231 *

5232 * MOV MOVES A BLOCK OF DATA IN MEMORY.

5233 *

5234 * ENTRY (DE) = FROM

5235 * (HL) = TO

5236 * (A) = COUNT

5237 * EXIT MOVED

5238 * (DE) = FROM + COUNT

5239 * (HL) = TO + COUNT

5240 * USES A,F

5241

5242

071.015	305		5243	MOV	PUSH	B
071.016	117		5244	MOV	C,A	
071.017	006	000	5245	MVI	B,0	
071.021	315	252 030	5246	CALL	\$MOVE	
071.024	301		5247	POP	B	
071.025	311		5248	RET		

```

5252 **      AMB - ALLOCATE MEMORY BYTES.
5253 *
5254 *      AMB ALLOCATES A BLOCK OF MEMORY TO THE END OF A TABLE.
5255 *      AND RETURNS THE FWA OF THE BLOCK.
5256 *
5257 *      ENTRY  (DE) = TABLE ADDRESS+1
5258 *             (HL) = BYTES WANTED
5259 *      EXIT   (DE) = TABLE ADDRESS+1
5260 *             (HL) = FWA (ABS) OF BLOCK
5261 *      USES   A,F,H,L
5262
5263
5264 AMB      EQU      *
071.026    5265      PUSH      H          SAVE COUNT
071.026 345 5266      PUSH      D          SAVE TABLE ADDRESS
071.027 325
071.030 023 5267      INX       D
071.031 023 5268      INX       D
071.032 032 5269      LDAX     D
071.033 157 5270      MOV      L,A          (HL) = TABLE LENGTH
071.034 023 5271      INX       D
071.035 032 5272      LDAX     D
071.036 321 5273      POP      D
071.037 147 5274      MOV      H,A
071.040 343 5275      XTHL     (HL) = COUNT
071.041 315 244 103 5276      CALL    $ATS      ALLOCATE SPACE
071.044 341 5277      POP      H          (HL) = ORIGINAL LENGTH
071.045 032 5278      LDAX     D
071.046 205 5279      ADD      L
071.047 157 5280      MOV      L,A
071.050 023 5281      INX       D
071.051 032 5282      LDAX     D
071.052 214 5283      ADC      H
071.053 147 5284      MOV      H,A
071.054 033 5285      DCX     D          (HL) = FWA OF BLOCK
071.055 311 5286      RET

```

```

5288 **      ANT - ACCEPT NEXT TOKEN.
5289 *
5290 *      ANT ACCEPTS THE NEXT TEXT TOKEN.
5291 *
5292 *      ENTRY  (BC) = TEXT POINTER
5293 *      EXIT   (A) = TYPE
5294 *             (DE) = INDEX (IF VARIABLE)
5295 *      USES   A,F, (D,E IF VARIABLE)
5296
5297
071.056 315 072.076 5298 ANT      CALL    PNT          PEEK AT NEXT TOKEN
071.061 365 5299      PUSH     PSW          SAVE TYPE
000.000    5300      ERRNZ   MI,NOP
071.062 297 5301      XRA     A
071.063 062 073.076 5302      STA     PNTA          CLEAR TYPE
071.066 303 130.076 5303      JMP     PNT1          CLEAR 'TOKEN ALREADY READ' FLAG

```

```

5305 **      ATP - ADJUST TABLE POINTERS.
5306 *
5307 *      $ATP IS CALLED BY THE MANAGED TABLE PACKAGE WHENEVER THE TABLES
5308 *      HAVE BEEN SHUFFLED. $ATP IS TO ADJUST ANY ABS POINTERS THAT MAY
5309 *      EXIST.
5310 *
5311 *      THE ONLY ABS POINTERS ARE THE ONES IN THE FILE BUFFERS IN
5312 *      THE FILTAB TABLE.
5313 *
5314 *      SINCE THE FILE BUFFER IMMEDIATELY FOLLOWS THE FILE BLOCK, THE
5315 *      DISPLACEMENT FOR THE TABLE CAN BE COMPUTED BY SUBTRACTING THE
5316 *      OLD BUFFER FWA (IN FB.FWA) FROM THE NEW ONE (FILTAB ENTRY + FB.NAM +
5317 *      FB.NAML)
5318 *
5319 *      NOTE THAT THE LAST BUFFER IN THE TABLE MAY NOT HAVE IT'S POINTERS SETUP
5320 *      CORRECTLY, IN WHICH CASE THE GARBAGE THERE JUST GETS STIRED UP A LITTLE.
5321 *
5322 *      ENTRY  NONE
5323 *      EXIT   NONE
5324 *      USES  ALL
5325
5326
071.071 052 226 042 5327 $ATP  LHLD  FBUFAD      (HL) = OLD FILTAB MT.FWA
071.074 353      5328      XCHG
071.075 052 122 112 5329      LHLD  FILTAB+MT.FWA (HL) = NEW FILTAB MT.FWA
071.100 042 226 042 5330      SHLD  FBUFAD      SAVE FOR NEXT TIME
071.103 175      5331      MOV   A,L
071.104 223      5332      SUB   E
071.105 137      5333      MOV   E,A      (DE) = TABLE DISPLACEMENT
071.106 174      5334      MOV   A,H
071.107 232      5335      SBB   D
071.110 127      5336      MOV   D,A
071.111 006 005 5337      MVI   B,CHANMAX (B) = TABLES TO ADJUST
071.113 041 265 042 5338      LXI   H,FBLIST+FBENL+FB.FWA START AT FIRST USER BLOCK
071.116 016 004 5339 ATP1  MVI   C,4      4 ADDRESSES IN EACH BLOCK
071.120 176      5340 ATP2  MOV   A,M      RELOCATE ADDRESS
071.121 203      5341      ADD   E
071.122 167      5342      MOV   M,A
071.123 043      5343      INX   H
071.124 176      5344      MOV   A,H
071.125 212      5345      ADC   D
071.126 167      5346      MOV   M,A
071.127 043      5347      INX   H
071.130 015      5348      DCR   C
071.131 302 120 071 5349      JNZ   ATP2      RELOCATE ALL 4 ADDRESSES
071.134 076 023 5350      MVI   A,FBENL-8
071.136 315 101 030 5351      CALL $DADA. POINT TO NEXT BLOCK
071.141 005      5352      DCR   B
071.142 302 116 071 5353      JNZ   ATP1      RELOCATE ALL BLOCKS
071.145 311      5354      RET      EXIT

```

```

5356 ** AYS - ASK 'ARE YOU SURE?'
5357 *
5358 * AYS ASKS THE USER IF HE IS SURE. A LINE LINE ANSWER IS
5359 * RECEIVED, AND ITS FIRST CHARACTER IS CHECKED.
5360 *
5361 * ENTRY NONE
5362 * EXIT 'Z' SET IF REPLY STARTED WITH 'Y'
5363 * (BC) = #ZERO
5364 * USES ALL
5365
071.146 315 136 031 5367 AYS CALL $TYPTX
071.151 007 123 165 5368 DB BELL,'Sure','?'*2000
071.157 041 265 112 5369 LXI H,LINE
071.162 315 075 077 5370 CALL RIL
071.165 332 106 070 5371 JC ERR,CC CTL-C STRUCK
071.170 178 5372 MOV A,H (A) = REPLY
071.171 315 045 112 5373 CALL $MCU
071.174 376 131 5374 CPI 'Y'
071.176 001 345 114 5375 LXI B,ZERO POINT TO END OF LINE
071.201 311 5376 RET

5378 ** AVV - ASSIGN VALUE TO VARIABLE.
5379 *
5380 * AVV ASSIGNS THE VALUE IN (ACCX) TO A VARIABLE POINTED TO
5381 * BY (DE).
5382 *
5383 * IF THE TYPES DO NOT MATCH, FLAG AN ERROR.
5384 *
5385 *
5386 * ENTRY (ACCX) = VALUE
5387 * (A) = TARGET TYPE
5388 * (DE) = TARGET POINTER
5389 * EXIT TO 'RET' IF OK
5390 * TO ERR,TC IF MISMATCH.
5391 * USES A,F,D,E
5392
071.202 345 5394 AVV PUSH H SAVE (HL)
071.203 147 5395 MOV H,A
5396
5397 * DETERMINE ABSOLUTE ADDRESS OF TARGET.
5398
071.204 072 201 042 5399 LDA ACCX-1
071.207 057 5400 CMA
071.210 254 5401 XRA H
071.211 346 001 5402 ANI CF,STR
071.213 312 155 070 5403 JZ ERR,TC MISMATCH
071.216 244 5404 ANA H
071.217 312 240 073 5405 JZ CXU.
5406
5407 * HAVE STRING
5408 * (DE) = ADDRESS OF BLOCK

```

```

5409
071.222 315 000 073 5410 AVV1 CALL CSI (DE) = INDEX INTO SYMBOL
071.225 325 5411 PUSH D SAVE 'TO' DESCRIPTOR ADDRESS
071.226 315 366 072 5412 CALL CSA (DE) = ABS. ADDR. INTO SYMBOL
071.231 315 315 074 5413 CALL FSE (HL) = TO ABS, (A) = TO LEN
071.234 127 5414 MOV D,A
071.235 072 202 042 5415 LDA ACCX
071.240 222 5416 SUB D (A) = NEWLEN-OLDLEN
071.241 137 5417 MOV E,A
071.242 237 5418 SBB A
071.243 127 5419 MOV D,A (DE) = COUNT CHANGE
071.244 325 5420 PUSH D SAVE TABLE DELTA
071.245 353 5421 XCHG (DE) = 'TO' ABS ADDRESS
071.246 052 110 112 5422 LHLD STRTAB+MT,FWA
071.251 173 5423 MOV A,E COMPUTE INDEX OF 'TO'
071.252 225 5424 SUB L
071.253 157 5425 MOV L,A
071.254 172 5426 MOV A,D
071.255 234 5427 SBB H
071.256 147 5428 MOV H,A
071.257 321 5429 POP D
071.260 172 5430 MOV A,D
071.261 027 5431 RAL MOVE SIGN BIT INTO CARRY
071.262 315 213 104 5432 CALL $IBT
071.265 110 112 5433 DW STRTAB+1
071.267 325 5434 PUSH D SAVE COUNT
071.270 353 5435 XCHG
071.271 052 110 112 5436 LHLD STRTAB+MT,FWA
071.274 031 5437 DAD D (HL) = ABS ADDRESS OF ADDITION
071.275 321 5438 POP D (DE) = COUNT
071.276 172 5439 MOV A,D
071.277 247 5440 ANA A
071.300 364 351 100 5441 CP ZRO CLEAR IF WAS ADDITION
071.303 321 5442 POP D (DE) = 'TO' DESCRIPTOR ADDRESS(INDEX)
071.304 315 366 072 5443 CALL CSA (DE) = 'TO' DESCRIPTOR ADDRESS(ABS.)
071.307 072 202 042 5444 LDA ACCX
071.312 022 5445 STAX D SET NEW COUNT
071.313 315 315 074 5446 CALL FSE
071.316 345 5447 PUSH H
071.317 021 202 042 5448 LXI D,ACCX
071.322 315 315 074 5449 CALL FSE
071.325 353 5450 XCHG FIND 'FROM'
071.326 341 5451 POP H (DE) = 'FROM' ADDRESS
071.327 315 015 071 5452 CALL MOV (HL) = 'TO' ADDRESS
071.332 341 5453 POP H MOVE STRING
071.333 311 5454 RET RESTORE (HL)

```



```

5456 ** CAS - CALCULATE ARRAY SIZE.
5457 *
5458 * CAS COMPUTES THE NUMBER OF ENTRIES IN AN ARRAY.
5459 *
5460 * ENTRY (DE) = HEADER POINTER
5461 * EXIT (HL) = COUNT
5462 * USES A;F;D;E;H;L
5463
5464
071.334 305 5465 CAS PUSH B SAVE (BC)
071.335 032 5466 LDAX D (A) = SUBSCRIPT COUNT
071.336 023 5467 INX D
071.337 023 5468 INX D
071.340 023 5469 INX D
071.341 023 5470 INX D
071.342 325 5471 PUSH D SAVE SYMTAB ADDRESS
071.343 041 001 000 5472 LXI H,1 (HL) = ACCUMULATOR
5473
071.346 5474 CAS1 EQU *
071.346 343 5475 XTHL (HL) = ADDRESS
071.347 136 5476 MOV E,H
071.350 043 5477 INX H
071.351 126 5478 MOV D,H (DE) = BOUND
071.352 043 5479 INX H
071.353 301 5480 POP B (BC) = ACCUMULATOR
071.354 345 5481 PUSH H SAVE ADDRESS
071.355 365 5482 PUSH PSW SAVE COUNT
071.356 315 337 030 5483 CALL $MU66 (HL) = ACCUMULATION
071.361 302 122 070 5484 JNZ ERR.IN OVERFLOW
071.364 361 5485 POP PSW
071.365 075 5486 DCR A DECREMENT COUNT
071.366 302 346 071 5487 JNZ CAS1 IF MORE
071.371 321 5488 POP D DISCARD ADDRESS
071.372 301 5489 POP B RESTORE BC
071.373 311 5490 RET

```

```

5492 ** CEF - CREATE EMPTY FILE BUFFER.
5493 *
5494 * CEF CREATES AN EMPTY FILE BUFFER
5495 * ON THE END OF FILTAB.
5496 *
5497 * ENTRY NONE
5498 * EXIT NONE
5499 * USES ALL
5500
5501

```

```

071.374 021 122 112 5502 CEF LXI D,FILTAB+1
071.377 041 000 001 5503 LXI H,256
072.002 303 244 103 5504 JMP $ATS ALLOCATE TABLE SPACE /80.01.GC/

```

```

5506 **      CFA - COMPUTE FILE BLOCK ADDRESS.
5507 *
5508 *      CFA COMPUTES THE ABS ADDRESS OF A FILE BLOCK.
5509 *
5510 *      ENTRY (A) = FILE BLOCK NUMBER (IOCHAN-1)
5511 *      EXIT  TO ERR.SY IF NUMBER TOO LARGE
5512 *          'C' CLEAR IF OK
5513 *          (HL) = ABS ADDRESS OF FILE BLOCK
5514 *          'C' SET IF NOT THERE
5515 *      USES  A,F,D,E,H,L
5516
5517
072.005 376 007 5518 CFA  CPI  CHANMAX+2      +1 FOR TEST; +1 FOR SKEWED ENTRY
072.007 322 122 070 5519  JNC  ERR.IN      TOO LARGE
072.012 127 5520  MOV  D,A        (D) = CHANNEL NUMBER
072.013 036 000 5521  MVI  E,0        (DE) = 256*CHANNEL
5522 *      ANA  A
5523 *      JNZ  CFA1      IS USER CHANNEL
5524
5525 *      IS SYSTEM BUFFER, SETUP WRITE-ACCESS TO PROTECTED H17 RAM
5526
5527 *      ERRNZ M.SYSM
5528 *      LHL  S.DLINK
5529 *      MVI  M,1      SET M.SYSM NON-ZERO
5530 *      CALL $WER      WRITE ENABLE RAM
072.015 052 124 112 5531 CFA1 LHL  FILTAB+MT,LEN
072.020 175 5532  MOV  A,L      SEE IF WE HAVE THAT MANY
072.021 223 5533  SUR  E
072.022 174 5534  MOV  A,H
072.023 232 5535  SBB  D
072.024 330 5536  RC
072.025 172 5537  MOV  A,D      (A) = CHANNEL NUMBER
072.026 021 033 000 5538  LXI  D,FRENL
072.031 315 007 031 5539  CALL $MUS6
072.034 021 230 042 5540  LXI  D,FBLIST
072.037 031 5541  DAD  D      (HL) = ABS ADDRESS OF BLOCK
072.040 311 5542  RET

```

```

5544 **      CFN - CRACK FILE NAME.
5545 *
5546 *      CFN DECODES A STRING FROM THE TEXT LINE INTO THE FILE
5547 *      NAME AREA OF THE SYSTEM FILE BLOCK.
5548 *
5549 *      ENTRY (BC) = LINE POINTER
5550 *      EXIT  (BC) ADVANCED
5551 *          (HL) = FWA OF FILE BLOCK
5552 *      USES  ALL
5553
5554
072.041 315 053 072 5555 CFN.  CALL  CFN      CFN WITH FOP
072.044 315 217 074 5556  CALL  FOP      FILE OPEN PRESET
072.047 041 230 042 5557  LXI  H,FBLIST
072.052 311 5558  RET

```

```

5559
072.053 315 244 055 5560 CFN CALL EVAL /78.10.GC/
072.056 033 5561 DCX D /78.10.GC/
072.057 032 5562 LDAX D (A) = TYPE /78.10.GC/
072.060 023 5563 INX D /78.10.GC/
072.061 346 001 5564 ANI CF,STR /78.10.GC/
072.063 312 152 070 5565 JZ ERR,SY /78.10.GC/
072.066 315 315 074 5566 CALL FSE FIND STRING TABLE ENTRY
072.071 247 5567 ANA A
072.072 312 202 070 5568 JZ ERR,ILF ILLEGAL FILE NAME
072.075 353 5569 XCHG (DE) = STRING ADDRESS
072.076 376 021 5570 CPI FB,NAML
072.100 322 202 070 5571 JNC ERR,ILF TOO LONG A NAME
072.103 305 5572 PUSH B SAVE (BC)
072.104 041 242 042 5573 LXI H,FBLIST+FB,NAM
072.107 117 5574 MOV C,A
072.110 006 000 5575 MVI B,0 (BC) = LEN
072.112 315 252 030 5576 CALL $MOVE MOVE IN NAME
072.115 257 5577 XRA A
072.116 167 5578 MOV M,A TERMINATE NAME
072.117 062 231 042 5579 STA FBLIST+FB,FLG CLEAR STATUS
072.122 041 230 042 5580 LXI H,FBLIST
072.125 301 5581 POP B RESTORE REGS
072.126 311 5582 RET EXIT

```

```

5584 ** *CFS - CALCULATE FREE SPACE.
5585 *
5586 * *CFS COUNTS THE FREE SPACE AVAILABLE TO MANAGED TABLES.
5587 *
5588 * ENTRY NONE
5589 * EXIT (HL) = COUNT
5590 * USES A,F,D,E,H,L
5591
5592
072.127 041 061 112 5593 *CFS LXI H,MTABIND+MT,LEN
072.132 345 5594 PUSH H SAVE POINTER ON STACK
072.133 041 346 114 5595 LXI H,MTAREA (HL) = ACCUMULATOR
072.136 076 010 5596 MVI A,MTABL (A) = NUMBER OF TABLES
072.140 343 5597 CFS1 XTHL (HL) = ADDRESS OF NEXT TABLE
072.141 136 5598 MOV E,M
072.142 043 5599 INX H
072.143 126 5600 MOV D,M
072.144 043 5601 INX H
072.145 043 5602 INX H
072.146 043 5603 INX H
072.147 043 5604 INX H
072.150 343 5605 XTHL
072.151 031 5606 DAD D (HL) = LENGTH
072.152 075 5607 DCR A
072.153 302 140 072 5608 JNZ CFS1 MORE TABLES TO ADD
5609
5610 * (HL) = TABLE BYTE COUNT + TABLE FWA
5611

```

072.156	321	5612	POP	D	(DE) = ADDRESS OF MEM12
072.157	033	5613	DCX	D	
072.160	033	5614	DCX	D	
072.161	032	5615	LDAX	D	
072.162	225	5616	SUB	L	
072.163	157	5617	MOV	L,A	
072.164	023	5618	INX	D	
072.165	032	5619	LDAX	D	
072.166	234	5620	SBB	H	
072.167	147	5621	MOV	H,A	
072.170	311	5622	RET		

5624 ** CLF - CLEAR FILE OPERATIONS.

5625 *

5626 * CLF IS CALLED TO CLEAR FILE JUNK.

5627

5628

072.171		5629	CLF	EQU	*
072.171	041 000 000	5630		LXI	H,0
072.174	042 124 112	5631		SHLD	FILTAB+MT.LEN EMPTY ALL BUT ONE FILE
072.177	377 056	5632		DB	SYSCALL,CLEARA CLEAR ALL CHANNELS (BUT OVERLAY CHANNEL)
072.201	257	5633		XRA	A
072.202	042 231 042	5634		STA	FBLIST+FB.FLG CLEAR STATUS OF INTERNAL BUFFER
072.205	311	5635		RET	

5637 ** CLN - CHECK FOR LEGAL NUMBER.

5638 *

5639 * CLN EXAMINES A LINE NUMBER TO SEE IF IT OCCURS IN THE
5640 * LEGAL RANGE.

5641 *

5642 * ENTRY (DE) = LINE NUMBER

5643 * EXIT TO *RET* IF BAD

5644 * TO ERR.SR IF BAD

5645 * USES A,F

5646

5647

072.206	172	5648	CLN	MOV	A,D
072.207	243	5649		ORA	E
072.210	312 122 070	5650		JZ	ERR.IN IS 0
072.213	023	5651		INX	D
072.214	172	5652		MOV	A,D
072.215	243	5653		ORA	E
072.216	033	5654		DCX	D
072.217	312 122 070	5655		JZ	ERR.IN IS 377377A
072.222	311	5656		RET	IS OK

```

5658 **      CMA - CHECK FOR COMMA.
5659 *
5660 *      CMA REQUIRES A COMMA IN THE TEXT STREAM.
5661 *
5662 *      ENTRY  NONE
5663 *      EXIT   (BC) ADVANCED
5664 *      USES   A,F,B,C,D,E
5665
5666
072,223 315 305 077 5667 CMA  CALL  RNT
072,226 026          5668      DB   CT,CMA
072,227 311          5669      RET

5671 **      CNC - CLASSIFY NEXT CHARACTER.
5672 *
5673 *      CNC CLASSIFYS THE NEXT TEXT CHARACTER.
5674 *
5675 *      ENTRY  (BC) = TEXT POINTER
5676 *      EXIT   (A) = 'CT,' CODE
5677 *      USES   A,F
5678
5679
072,230 012          5680 CNC  LDAX  B          (A) = CODE
072,231 247          5681      ANA  A
072,232 370          5682      RM   IS KEYWORD
000,000          5683      ERRNZ CT,FIN
072,233 310          5684      RZ   IS FIN
072,234 376 060      5685      CPI  '0'
072,236 332 265 072 5686      JC   CNC1      NOT NUMERIC OR ALPHA
072,241 376 072      5687      CPI  '9'+1
072,243 076 002      5688      MVI  A,CT,NUM
072,245 330          5689      RC   IS NUMERIC
072,246 012          5690      LDAX  B
072,247 315 045 112 5691      CALL  $MCU      MAP CHARACTER TO UPPER CASE
072,252 376 101      5692      CPI  'A'
072,254 332 265 072 5693      JC   CNC1      NOT ALPHA
072,257 376 133      5694      CPI  'Z'+1
072,261 076 001      5695      MVI  A,CT,ALP
072,263 330          5696      RC   IS ALPHABETIC
072,264 012          5697      LDAX  B
5698
5699 *      NOT ALPHABETIC OR NUMERIC. FIND IN TABLE.
5700
072,265 345          5701 CNC1 PUSH  H
072,266 041 302 072 5702      LXI  H,CNCA
072,271 315 371 111 5703      CALL  $TBLS      SEARCH TABLE
072,274 176          5704      MOV  A,M          (A) = INDEX
072,275 341          5705      POP  H          RESOTRE (HL)
072,276 310          5706      RZ   FOUND
072,277 076 003      5707      MVI  A,CT,SEP      SEPERATOR
072,301 311          5708      RET
5709
5710 **      TABLE OF SPECIAL TERMINATORS.

```

```

5711
072.302          5712 CNCA EQU *
072.302 053 021 5713 DB '+',CT,PL
072.304 055 022 5714 DB '-',CT,MI
072.306 050 017 5715 DB '(',CT,PAL
072.310 051 020 5716 DB ')',CT,PAR
072.312 052 023 5717 DB '*',CT,MU
072.314 057 024 5718 DB '/',CT,DI
072.316 136 025 5719 DB '^',CT,EX
072.320 072 000 5720 DB '|',CT,FIN
072.322 056 002 5721 DB '&',CT,NUM
072.324 054 026 5722 DB '>',CT,CMA
072.326 074 014 5723 DB '<',CT,LT
072.330 075 011 5724 DB '=',CT,EQ
072.332 076 012 5725 DB '>',CT,GT
072.334 073 027 5726 DB '<',CT,SEM
072.336 042 030 5727 DB '*',CT,QUO
072.340 133 017 5728 DB '|',CT,PAL
072.342 135 020 5729 DB '|',CT,PAR
072.344 043 031 5730 DB '*',CT,PS
072.346 000          5731 DB 0

```

END OF TABLE

```

5733 ** COT - CHECK OPERAND TYPES.
5734 *
5735 * COT CHECKS THE OPERANDS TO SEE IF THE TYPE IS CONSISTANT.
5736 *
5737 * EXIT (ACCX); (ACCY) = 2 OPERANDS
5738 * EXIT TO *RET* IF BOTH SAME TYPE
5739 * 'Z' SET IF NUMERIC
5740 * TO ERR,TE IF OF DIFFERING TYPES
5741 * USES A,F,H,L
5742
5743
072.347 072 201 042 5744 COT LDA ACCX-1
072.352 041 207 042 5745 LXI H,ACCY-1
072.355 057          5746 CMA
072.356 254          5747 XRA M
072.357 346 001     5748 ANI CF,STR
072.361 312 155 070 5749 JZ ERR,TC DIFFERENT TYPES
072.364 246          5750 ANA M (A) = CODE
072.365 311          5751 RET RETURN WITH CODE

```

```

5753 ** CSA - CALCULATE SYMTAB ABSOLUTE ADDR.
5754 *
5755 * CSA CALCULATES AN ABSOLUTE ADDRESS FOR A GIVEN
5756 * INDEX
5757 *
5758 * ENTRY (DE) = INDEX INTO SYMTAB
5759 * EXIT (DE) = ABSOLUTE ADDRESS
5760 * USES D,E

```

```

5761
5762
072.366 5763 CSA EQU *
5764
072.366 365 5765 PUSH PSW SAVE (A)
072.367 345 5766 PUSH H SAVE (HL)
072.370 052 064 112 5767 LHL D SYMTAB+MT,FWA (HL) = #FWA OF SYMTAB
072.373 031 5768 DAD D /80.01.GC/
072.374 353 5769 XCHG DE = ABSOLUTE ADDRESS IN SYMTAB /80.01.GC/
072.375 341 5770 POP H RESTORE (HL)
072.376 361 5771 POP PSW
072.377 311 5772 RET EXIT

```

```

5774 ** CSI - CALCULATE SYMTAB INDEX
5775 *
5776 * CSI CALCULATES AN INDEX INTO THE SYMTAB
5777 * FROM A GIVEN ABSOLUTE ADDRESS.
5778 *
5779 * ENTRY (DE) = ABSOLUTE ADDRESS INTO SYMBOL
5780 * EXIT (DE) = INDEX INTO SYMTAB
5781 * USES D,E

```

```

5782
5783
073.000 5784 CSI EQU *
5785
073.000 365 5786 PUSH PSW SAVE (A)
073.001 345 5787 PUSH H SAVE (HL)
073.002 052 064 112 5788 LHL D SYMTAB+MT,FWA
073.005 173 5789 MOV A,E
073.006 225 5790 SUB L
073.007 137 5791 MOV E,A
073.010 172 5792 MOV A,D
073.011 234 5793 SBB H
073.012 127 5794 MOV D,A (DE) = INDEX INTO SYMBOL TABLE
073.013 341 5795 POP H RESTORE (HL)
073.014 361 5796 POP PSW RESTORE (A)
073.015 311 5797 RET EXIT

```

```

5799 ** CSE - CREATE STRING TABLE ENTRY.
5800 *
5801 * CSE CREATES A STRING TABLE ENTRY.
5802 *
5803 * ENTRY (DE) = POINTER BLOCK ADDRESS.
5804 * EXIT DESCRIPTOR SET IN BLOCK
5805 * (DE) = POINTER BLOCK ADDRESS
5806 * (HL) = ABS STRING ADDRESS
5807 * USES A,F,D,E,H,L
5808
5809

```

```

073.016 305 5810 CSE PUSH B

```

CSE

```

073.017 041 143 112 5811 LXI H,STRVI
073.022 315 056 073 5812 CALL CSE,,
073.025 021 110 112 5813 LXI D,STRTAB+1
073.030 303 045 073 5814 JMP CSE1
                    5815
073.033 305          5816 CSE, PUSH B
073.034 041 143 112 5817 LXI H,STRTI
073.037 315 056 073 5818 CALL CSE,,
073.042 021 115 112 5819 LXI D,TSTTAB+1
                    5820
073.045 315 026 071 5821 CSE1 CALL AMB MAKE ROOM
073.050 160          5822 MOV M,B
073.051 043          5823 INX H
073.052 161          5824 MOV M,C SET NUMBER IN STRING
073.053 043          5825 INX H (HL) = ABS ADDRESS
073.054 301          5826 POP B
073.055 311          5827 RET
                    5828
073.056 043          5829 CSE,, INX H
073.057 064          5830 INR M INCREMENT INDEX
073.060 053          5831 DCX H
073.061 302 065 073 5832 JNZ CSE2 NOT OVERFLOW
073.064 064          5833 INR M
073.065 106          5834 CSE2 MOV B,M
073.066 043          5835 INX H
073.067 116          5836 MOV C,M (BC) = STRING NAME
073.070 353          5837 XCHG (HL) = BLOCK ADDRESS + 2
073.071 136          5838 MOV E,M
073.072 043          5839 INX H
073.073 126          5840 MOV D,M (DE) = STRING LENGTH
073.074 043          5841 INX H
073.075 160          5842 MOV M,B
073.076 043          5843 INX H
073.077 161          5844 MOV M,C STORE IN HEADER
073.100 023          5845 INX D
073.101 023          5846 INX D +2 FOR HEADER
073.102 353          5847 XCHG
073.103 311          5848 RET

```

```

5850 ** CUF -- CLEAR USER FUNCTION
5851 *
5852 * CUF CLEARS THE USER-DEFINED FUNCTIONS FROM THE FUNCTION TABLE
5853 * BY REMOVING THE ENTRIES FROM *SYMTAB*.
5854 *
5855 * ENTRY: NONE
5856 *
5857 * EXIT: USER-DEFINED FUNCTIONS OUT OF THE SYMBOL TABLE ENTRY
5858 *
5859 * USES: ALL
5860 *
5861
073.104 5861 CUF ERU *
5862
5863

```



```

073.104 021 000 000 5864 LXI D,0 SET THE INDEX TO ZERO
                    5865
073.107 052 066 112 5866 CUF1 LHL D SYMTAB+HT.LEN
073.112 023 5867 INX D
073.113 315 346 111 5868 CALL HLCFDE
073.116 033 5869 DCX D
073.117 330 5870 RC ALL FINISHED (LENGTH <= INDEX+1)
                    5871
073.120 315 126 073 5872 CALL CUF2 PROCESS THE ENTRY
                    5873
073.123 303 107 073 5874 JMP CUF1
                    5875
                    5876 * PROCESS A SYMBOL TABLE ENTRY
                    5877
073.126 5878 CUF2 EQU *
                    5879
073.126 052 064 112 5880 LHL D SYMTAB+HT.FWA
073.131 031 5881 DAD D HL = FWA OF SYMBOL TABLE ENTRY
073.132 043 5882 INX H
073.133 176 5883 MOV A,M A FLAG BYTE
073.134 043 5884 INX H
073.135 346 002 5885 ANI CF,VEC
073.137 312 163 073 5886 JZ CUF3 NOT A VECTOR
                    5887
073.142 176 5888 MOV A,M
073.143 247 5889 ANA A
073.144 362 172 073 5890 JP CUF4 IS A VECTOR
                    5891
                    5892 * DELETE A FUNCTION
                    5893
073.147 325 5894 PUSH D
073.150 353 5895 XCHG HL = INDEX INTO TABLE
073.151 021 006 000 5896 LXI D,6 COUNT = 6
073.154 315 203 104 5897 CALL $DBT DELETE THE BYTES FROM THE TABLE
073.157 064 112 5898 DW SYMTAB+1
073.161 321 5899 POP B
073.162 311 5900 RET
                    5901
                    5902 * PASS OVER A SCALAR
                    5903
073.163 001 006 000 5904 CUF3 LXI B,6
073.166 353 5905 XCHG
073.167 011 5906 DAD B
073.170 353 5907 XCHG INDEX = INDEX + 6
073.171 311 5908 RET
                    5909
                    5910 * PASS OVER A VECTOR
                    5911
073.172 043 5912 CUF4 INX H
073.173 043 5913 INX H SKIP 'DIM' AND '0' BYTES
                    5914
073.174 116 5915 MOV C,M
073.175 043 5916 INX H
073.176 106 5917 MOV B,M
073.177 043 5918 INX H BC = ARRAY SIZE FOR VECTOR ENTRIES
                    5919

```

073.200	353	5920	XCHG		
073.201	011	5921	DAD	B	INDEX = INDEX + SIZE
073.202	001 006 000	5922	LXI	B,6	
073.205	011	5923	DAD	B	INDEX = INDEX + 6 (BYTES SKIPPED AT START)
073.206	353	5924	XCHG		
073.207	311	5925	RET		

5927	**	CVX - COPY VALUE INTO 'X' ACCUMULATOR.
5928	*	
5929	*	CVX COPIES A 4 BYTE VALUE INTO THE X ACCUMULATOR.
5930	*	
5931	*	ENTRY (DE) = ADDRESS OF VALUE
5932	*	EXIT COPIED
5933	*	USES A,F
5934		
5935		

073.210	345	5936	CVX	PUSH	H	
073.211	325	5937		PUSH	D	
073.212	041 202 042	5938		LXI	H,ACCX	
073.215	315 051 076	5939		CALL	MOV4	MOVE
073.220	321	5940		POP	D	
073.221	341	5941		POP	H	
073.222	311	5942		RET		

5944	**	CXY - COPY (ACCX) INTO (ACCY)
5945	*	
5946	*	ENTRY NONE
5947	*	EXIT NONE
5948	*	USES A,F,D,E
5949		
5950		

073.223		5951	CXY	EQU	*	
073.223	345	5952		PUSH	H	SAVE (HL)
073.224	021 201 042	5953		LXI	D,ACCX-1	SOURCE
073.227	041 207 042	5954		LXI	H,ACCY-1	DESTINATION
073.232	315 045 076	5955		CALL	MOV5	MOVE (ACCX) TO (ACCY)
073.235	341	5956		POP	H	RESTORE (HL)
073.236	311	5957		RET		EXIT

5959	**	CVV - COPY X TO VALUE.
5960	*	
5961	*	CVV COPIES THE CONTENTS OF THE 'X' ACCUMULATOR INTO A MEMORY
5962	*	LOCATION.
5963	*	
5964	*	ENTRY (DE) = TARGET ADDRESS
5965	*	EXIT COPIED
5966	*	USES A,F

			5967					
			5968					
073.237	345		5969	CXV	PUSH	H		
073.240	325		5970	CXV.	PUSH	D		
073.241	353		5971		XCHG			
073.242	021	202 042	5972		LXI	D,ACCX		
073.245	315	051 076	5973		CALL	MOV4	MOVE	
073.250	321		5974		POP	D	RESTORE DE	
073.251	341		5975		POP	H		
073.252	311		5976		RET			

			5978	**	DCN - DECODE CHANNEL NUMBER.			
			5979	*				
			5980	*	DCN DECODES A CHANNEL SPECIFICATION OF THE FORM:			
			5981	*				
			5982	*	#N	OR		
			5983	*	#LND(EXPR) ARCHAIC (THIS IS TACKY!)		/BO.01.GC/	
			5984	*				
			5985	*	IF THE CHANNEL EXPRESSION IS OMITTED, IOCHAN IS SETUP TO INDICATE THE			
			5986	*	SYSTEM CONSOLE.			
			5987	*				
			5988	*	ENTRY	(BC) = TEXT POINTER		
			5989	*	EXIT	(BC) ADVANCED		
			5990	*	IOCHAN = 0 IF CONSOLE, = N+1 IF FILE			
			5991	*	(A) = (IOCHAN)			
			5992	*	USES	ALL		
			5993	*				
			5994	*				
073.253	257		5995	DCN	XRA	A		
073.254	062	140 112	5996		STA	IOCHAN	ASSUME NONE	
073.257	315	072 076	5997		CALL	PNT		
073.262	376	031	5998		CPI	CT.PS		
073.264	300		5999		RNE		NONE	
073.265	315	273 073	6000		CALL	DCN.	DECODE CHANNEL NUMBER	
073.270	303	223 072	6001		JMP	CMA	REQUIRE COMMA AND EXIT	

			6002					
			6003	**	DCN. - DECODE CHANNEL NUMBER.			
			6004	*				
			6005	*	SAME AS DCN, BUT REQUIRES CHANNEL			
			6006	*	AND DOESNT CHECK FOR TRAILING COMMA			
			6007	*				
			6008	*				
073.273	315	305 077	6009	DCN.	CALL	RNT		
073.276	031		6010		DB	CT.PS		
073.277	315	036 057	6011		CALL	EVALI	EVALUATE AN EXPRESSION	/BO.01.GC/
			6012					
			6013	**	DCN.. - CHECK CHANNEL NUMBER.			
			6014	*				
			6015	*	CHECK (DE) FOR VALID CHANNEL NUMBER			
			6016	*	EXIT	(A) = CHANNEL VALUE		
			6017	*				
			6018	*				
073.302	172		6019	DCN..	MOV	A:D		

073.303	267	6020	ORA	A	
073.304	302 122 070	6021	JNZ	ERR.IN	TOO LARGE
073.307	173	6022	MOV	A,E	
073.310	376 004	6023	CPI	CHANMAX+1	/78.10.BC/
073.312	322 122 070	6024	JNC	ERR.IN	TOO LARGE
073.315	247	6025	ANA	A	
073.316	312 322 073	6026	JZ	DCN1	
073.321	074	6027	INR	A	(A) = 2+N
073.322	062 140 112	6028	STA	IOCHAN	
073.325	311	6029	RET		EXIT

6031 ** DNF - DELETE NON-OPEN FILE BLOCKS.

6032 *

6033 *

6034 *

6035 *

6036 *

6037 *

6038 *

6039 *

6040 *

6041 *

6042

6043

073.324	072 125 112	6044	DNF	LDA	FILTAB+MT.LEN+1 (A) = # OF BUFFERS
073.331	247	6045		ANA	A
073.332	310	6046		RZ	NONE ELIGIBLE
073.333	021 033 000	6047		LXI	D,FBENL
073.336	315 007 031	6048		CALL	\$MUB6
073.341	021 231 042	6049		LXI	D,FRLIST+FB.FLG
073.344	031	6050		BAD	D (HL) = ADDRESS OF FB, STA FOR LAST BLOCK, W/BUFFER
073.345	176	6051		MOV	A,M
073.346	247	6052		ANA	A
073.347	300	6053		RNZ	IS OPEN
073.350	041 125 112	6054		LXI	H,FILTAB+MT.LEN+1
073.353	065	6055		DCR	M SHORTEN TABLE
073.354	303 326 073	6056		JMP	DNF TRY AGAIN

6058 ** DTS - DELETE TEMP STRINGS.

6059 *

6060 *

6061 *

6062 *

6063 *

6064 *

6065 *

6066

6067

073.357	041 000 000	6068	DTS	LXI	H,0
073.362	042 117 112	6069		SHLD	TSTTAB+MT.LEN

```

073.365 041 300 000 6070 LXI H,3000
073.366 6071 DTSA EQU *-2
073.370 042 145 112 6072 SHLD STRTI RESET STRING TEMP INDEX
073.373 311 6073 RET
    
```

```

6075 ** EKA - EXPAND KEYWORD INTO ASCII EQUIVALENT.
6076 *
6077 * EKA EXPANDS A KEYWORD BYTE INTO THE ASCII EQUIVALENT.
6078 *
6079 * ENTRY (A) = TOKEN
6080 * (DE) = ADDRESS FOR STRING
6081 * EXIT (A) = LAST CHARACTER OF ASCII
6082 * (DE) = ADDRESS FOR LAST CHARACTER OF ASCII
6083 * USES A,F,B,C,D,E
6084
6085
    
```

```

073.374 001 240 066 6086 EKA LXI B,KEYTAB
073.377 325 6087 PUSH D SAVE ADDRESS
074.000 127 6088 MOV B,A (D) = PATTERN
074.001 012 6089 EKA1 LDAX B
074.002 272 6090 CMP D
074.003 003 6091 INX B
074.004 302 001 074 6092 JNE EKA1 NOT THERE, YET
074.007 321 6093 POP D (DE) = ADDRESS
074.010 365 6094 PUSH PSW SAVE KEYWORD BYTE
6095
    
```

```

6096 * EXPAND IT.
6097
    
```

```

074.011 012 6098 EKA2 LDAX B
074.012 022 6099 STAX D
074.013 003 6100 INX B
074.014 023 6101 INX D
074.015 247 6102 ANA A
074.016 362 011 074 6103 JF EKA2 MORE TO GO
074.021 033 6104 DCX D REPLACE EXTRA BYTE WITH ' ' OR '( '
074.022 361 6105 POP PSW
074.023 376 320 6106 CFI CT,FCN
074.025 076 040 6107 MVI A,' ' ASSUME NOT FUNCTION
074.027 330 6108 RC NOT FUNCTION
074.030 076 050 6109 MVI A,' (' IS FUNCTION
074.032 311 6110 RET
    
```

```

6112 ** ELN - EVALUATE LINE NUMBER.
6113 *
6114 * ELN IS CALLED WHEN A LINE NUMBER IS TO BE EVALUATED.
6115 *
6116 * THE LINE NUMBER CAN EITHER BE A DECIMAL INTEGER, OR
6117 * THE EXPRESSION LNO(EXPR)
6118 *
6119 * ENTRY (BC) = LINE POINTER
    
```

```

6120 *      EXIT      (BC) UPDATED
6121 *      (DE) = LINE NUMBER
6122 *      USES      A,F,B,C,D,E
6123
6124
074.033 315 126 100 6125 ELN  CALL  SOB      SKIP BLANKS
6126
6127 *      MUST HAVE DECIMAL INTEGER, OR LNO(
6128
074.036 012      6129      LDAX   B
074.037 376 327 6130      CPI   CT,LNO
074.041 312 102 074 6131      JE    ELN2      IS LNO(EXPR)
074.044 315 321 111 6132      CALL  $CVD.     SEE IF DIGIT
074.047 332 152 070 6133      JC    ERR.SY
074.052 021 000 000 6134      LXI   D,0      (DE) =ACCUM
6135
6136 *      HAVE DECIMAL INTERGER
6137
074.055 012      6138 ELN1  LDAX   B
074.056 315 321 111 6139      CALL  $CVD.
074.061 330      6140      RC      END OF NUMBER
074.062 345      6141      PUSH  H      SAVE (HL)
074.063 315 324 030 6142      CALL  $MU10    (HL) = 10*ACCUM
074.066 315 072 030 6143      CALL  $DADA    (HL) = 10*ACCUM+DIGIT
074.071 353      6144      XCHG
074.072 003      6145      INX   B
074.073 341      6146      POP   H      RESTORE (HL)
074.074 332 122 070 6147      JC    ERR.IN   ILLEGAL NUMBER IF OVERFLOW
074.077 303 055 074 6148      JMP   ELN1     TRY FOR MORE
6149
6150 *      IS LNO(EXPR)
6151
074.102 003      6152 ELN2  INX   B      SKIP LNO( KEYWORD
074.103 315 036 057 6153      CALL  EVALI
074.106 325      6154      PUSH  D      SAVE VALUE
074.107 315 305 077 6155      CALL  RNT
074.112 020      6156      BB    CT,FAR   REQUIRE ')'
074.113 321      6157      POP   D
074.114 311      6158      RET

6160 **     FDC - FILE OPEN CLEANUP.
6161 *
6162 *      FDC IS CALLED TO CLEANUP AFTER FDP. FDC RESTORES AS MUCH
6163 *      MEMORY AS THE SYSTEM IS NOT USING (ALSO DEPENDS UPON CNTRL OPTION)
6164 *
6165 *      ENTRY  NONE
6166 *      EXIT  NONE
6167 *      USES  NONE
6168
6169
074.115 315 054 031 6170 FDC  CALL  $SAVALL  SAVE ALL
6171 *      LHL  S,DLINK
6172 *      ERNZ M,SYSM
/80,02,GC/
/80,02,GC/

```



```

6226
074.230 315 127 104 6227 POP CALL MTD MOVE TABLES DOWN
074.233 325 6228 PUSH D SAVE LWA
074.234 315 071 071 6229 CALL $ATF ADJUST TABLE POINTERS
074.237 341 6230 POP H (HL) = LWA
074.240 043 6231 INX H
074.241 311 6232 RET
/80,01,6C/

```

```

6234 ** FLN - FIND LINE BY NUMBER.
6235 *
6236 * FLN SEARCHES THE TEXT BUFFER FOR THE SPECIFIED LINE.
6237 *
6238 * ENTRY (DE) = LINE NUMBER
6239 * EXIT TO ERR.SN IF LINE NUMBER = 65535
6240 * 'C' SET IF NOT FOUND
6241 * (HL) = ADDRESS OF LINE IF FOUND, ADDRESS IF LINE+1 IF NOT
6242 * USES A,F,H,L
6243
6244
074.242 305 6245 FLN PUSH B
074.243 091 346 114 6246 LXX H:MTAREA
6247
6248 * CHECK IF LINE NUMBER = 65535
6249
074.246 172 6250 MOV A,D
074.247 074 6251 INR A
074.250 302 240 074 6252 JNZ FLN1 HIGH ORDER BYTE < 377
074.253 173 6253 MOV A,E
074.254 074 6254 INR A
074.255 312 147 070 6255 JZ ERR.SN LINE NUMBER = 65535; ERROR
6256
074.260 173 6257 FLN1 MOV A,E
074.261 226 6258 SUB M
074.262 107 6259 MOV B,A (B) = LOW LETTER
074.263 172 6260 MOV A,D
074.264 043 6261 INX H
074.265 236 6262 SBB M
074.266 332 312 074 6263 JC FLN3 RAN PAST
074.271 302 300 074 6264 JNZ FLN1.5 NOT THERE YET
074.274 260 6265 ORA B
074.275 312 312 074 6266 JZ FLN3 FOUND IT
074.300 043 6267 FLN1.5 INX H
074.301 176 6268 FLN2 MOV A,M SKIP THIS LINE
074.302 043 6269 INX H
074.303 247 6270 ANA A
074.304 302 301 074 6271 JNZ FLN2 NOT END OF LINE
074.307 303 260 074 6272 JMP FLN1
6273
6274 * FOUND LINE. 'C' CLEAR IF FOUND
6275
074.312 093 6276 FLN3 DCX H
074.313 301 6277 POP B
074.314 311 6278 RET

```



```

6280 ** FSE - FIND STRINGTAB ENTRY.
6281 *
6282 * FSE FINDS A SPECIFIED STRING IN THE TABLE.
6283 *
6284 * ENTRY (DE) = DESCRIPTOR ADDRESS
6285 * EXIT (HL) = ABS ADDRESS
6286 * (A) = LENGTH
6287 * USES A,F,D,E,H,L
6288
6289
074.315 032 6290 FSE LDAX D (A) = LENGTH
074.316 365 6291 PUSH PSW
074.317 023 6292 INX D
074.320 023 6293 INX D
074.321 353 6294 XCHG
074.322 126 6295 MOV B,M
074.323 043 6296 INX H
074.324 136 6297 MOV E,M (DE) = INDEX
6298
6299 * CHECK FOR WHICH STRING TABLE
6300
074.325 172 6301 MOV A,D
074.326 346 100 6302 ANI 1000
074.330 312 341 074 6303 JZ FSE0
074.333 052 115 112 6304 LHLD TSTTAB+MT.FWA
074.336 303 344 074 6305 JMP FSE1
6306
074.341 052 110 112 6307 FSE0 LHLD STRTAB+MT.FWA
000.000 6308 ERRNZ *-FSE1
6309
6310 * SEE IF WE HAVE IT YET
6311
074.344 172 6312 FSE1 MOV A,D
074.345 247 6313 ANA A
074.346 362 374 074 6314 JP FSE3 NOT LOOKING FOR A VALID STRING ID
074.351 276 6315 CMP M
074.352 043 6316 INX H
074.353 302 363 074 6317 JNE FSE2 NO MATCH
074.356 173 6318 MOV A,E
074.357 276 6319 CMP M
074.360 312 374 074 6320 JE FSE3 FOUND
074.363 043 6321 FSE2 INX H NOT FOUND
074.364 176 6322 MOV A,M
074.365 247 6323 ANA A
074.366 362 363 074 6324 JP FSE2 SKIP TO NEXT INDEX
074.371 303 344 074 6325 JMP FSE1 TRY AGAIN
6326
6327 * FOUND IT.
6328
074.374 043 6329 FSE3 INX H
074.375 361 6330 POP PSW (A) = LEN
074.376 311 6331 RET

```

```

6333 **      IFIX - SPLIT NUMBER INTO INTEGER AND FRACTION.
6334 *
6335 *      IFIX FIXES ((DE)) INTO AN INTEGER.
6336 *
6337 *      ENTRY  (DE) = ADDRESS OF NUMBER
6338 *      EXIT   (DE) = INTEGRAL PART OF 0<=N<=65535
6339 *      TO ERR:IN OTHERWISE
6340
6341
074.377 021 202 042 6342 IFIX. LXI  D,ACCX      USE ACCX
075.002 305          6343 IFIX  PUSH  B
075.003 345          6344      PUSH  H
075.004 353          6345      XCHG
075.005 315 250 107 6346      CALL  LDD      (BCDE) = NUMBER
075.010 171          6347      MOV   A,C
075.011 247          6348      ANA   A
075.012 372 122 070 6349      JH   ERR:IN    TOO LARGE
075.015 076 220     6350      MVI  A,2200
075.017 220          6351      SUB  B
075.020 332 122 070 6352      JC   ERR:IN    TOO LARGE
075.023 306 007     6353      ADI  7      (A) = SHIFT COUNT
075.025 107          6354      MOV  B,A
075.026 315 231 107 6355 IFIX1 CALL  SRS
075.031 005          6356      DCR  B
075.032 302 026 075 6357      JNZ  IFIX1    NOT DONE YET
075.035 341          6358      POP  H
075.036 301          6359      POP  B
075.037 311          6360      RET

```

```

6362 **      IFLT - FLOAT NUMBER.
6363 *
6364 *      ENTRY  (DE) = VALUE
6365 *      EXIT   (ACCX) = NUMBER VALUE
6366 *      (DE) = #ACCX-1
6367
6368
075.040 305          6369 IFLT PUSH  B
075.041 345          6370      PUSH H
075.042 001 000 227 6371      LXI  B,2000+23*256
075.045 315 213 105 6372      CALL NRM      NORMALIZE
075.050 315 245 106 6373      CALL STX      STORE IN ACCX
075.053 076 300     6374      MVI  A,CT,SNO  SCALAR NUMERIC VALUE
075.055 062 201 042 6375      STA  ACCX-1    SET TYPE
075.060 341          6376      POP  H
075.061 301          6377      POP  B
075.062 311          6378      RET

```

```

6380 **      ILM - ISSUE LINE MESSAGE.
6381 *
6382 *      ILM ISSUES A MESSAGE OF THE FORM
6383 *
6384 *      XXXXXX AT LINE NNNNN
6385 *
6386 *      WHERE XXXXXX = SUPPLIED TEXT,
6387 *             NNNNN = (CURNUM)
6388 *
6389 *      NOTE THAT ILM ALSO CLEARS THE BASIC WORKING CHANNEL
6390 *      (CHANNEL 0). THIS IS A KLUDGE SO THAT THE CHANNEL DOESNT REMAIN
6391 *      OPEN IF AN ERROR OCCURS WHILE USING IT.
6392 *
6393 *      ENTRY  (SF+0) = ERROR CODE
6394 *      EXIT   NONE
6395 *      USES   A,F,H,L
6396 *
075.063 315 217 074 6398 ILM  CALL  FOP          ALLOW OVERLAY TO RESIDE
075.066 257          6399      XRA   A
075.067 377 055     6400      DB   SYSCALL,CLEAR
075.071 361          6401      POP  PSW          (A) = CODE
075.072 046 040     6402      MVI  H, ' '
075.074 377 057     6403      DB   SYSCALL,ERROR LOOKUP ERROR
6404
075.076 041 124 043 6405      LXI  H,RESTART  (HL) = EXIT PROCESSOR ADDRESS
075.077          6406  ILMA  EQU   *-2          SET BY CALLER
075.101 345          6407      PUSH H          SET AS 'RETURN ADDRESS'
075.102 041 301 114 6408      LXI  H,RUNMOD
075.105 176          6409      MOV  A,M          (A) = OLD RUN MODE
075.106 366 200     6410      ORI  RM,HLT      SET HALT FLAG
075.110 167          6411      MOV  M,A
075.111 376 200     6412      CPI  RM,IMM+RM,HLT
075.113 310          6413      RE
075.114 315 136 031 6414      CALL $TYPTX
075.117 101 144 040 6415      DB   'At Line',t, '+2000'
075.127 052 133 112 6416      LHL  CURNUM
075.132 353          6417      XCHG
075.133 303 206 100 6418      JMP  TDI          TYPE LINE NUMBER

6420 **      IST - INSERT IN SYMBOL TABLE.
6421 *
6422 *      IST LOOKS UP THE ADDRESS HOLDING THE VALUE FOR
6423 *      A VARIABLE. IF THE VARIABLE IS A MATRIX OR VECTOR,
6424 *      THE SUBSCRIPT IS EVALUATED AND THE PARTICULAR ENTRY
6425 *      IS RETURNED AS A SCALAR VALUE.
6426 *
6427 *      IF THE VARIABLE IS NOT YET DEFINED, AND IT IS NOT A
6428 *      VECTOR, IT IS DEFINED WITH A VALUE OF 0 (OR A NULL STRING)
6429 *
6430 *      ENTRY  (BC) = TEXT POINTER
6431 *      EXIT   (BC) UPDATED
6432 *             (DE) = INDEX OF SYMBOL ADDRESS

```

IST

```

6433 * (A) = TYPE
6434 * USES ALL
6435
6436
075.136 315 172 075 6437 IST CALL IST0 INSERT SYMBOL IN TABLE
075.141 365 6438 PUSH PSW SAVE TYPE
075.142 315 000 073 6439 CALL CSI (DE) = INDEX INTO SYMBOL TABLE
075.145 346 001 6440 ANI CF,STR
075.147 312 170 075 6441 JZ IST00 IS NOT STRING TYPE
075.152 325 6442 PUSH D SAVE INDEX
075.153 315 366 072 6443 CALL CSA (DE) = ABS. ADDR. INTO SYMBOL
075.156 325 6444 PUSH D
075.157 023 6445 INX D
075.160 023 6446 INX D
075.161 032 6447 LDAX D (A) = STRING ID
075.162 321 6448 POP D RESTORE DE
075.163 247 6449 ANA A
075.164 314 016 073 6450 CZ CSE CREATE STRING TABLE ENTRY IF NOT THERE
075.167 321 6451 POP D
075.170 361 6452 IST00 POP PSW RESTORE TYPE
075.171 311 6453 RET
6454
075.172 6455 IST0 EQU *
075.172 315 056 071 6456 CALL ANI ACCEPT NEXT TOKEN
075.175 376 300 6457 CFI CT,VARL SEE IF HAVE VARIABLE
075.177 332 152 070 6458 JC ERR,SY NOT VARIABLE
075.202 376 310 6459 CFI CT,VARH+1
075.204 322 152 070 6460 JNC ERR,SY NOT VARIABLE
075.207 041 151 335 6461 LXI H,-LEXLIM-1
075.212 031 6462 DAD D
075.213 332 257 075 6463 JC IST2 IS PRE-DEFINED
075.216 365 6464 IST1 PUSH PSW SAVE TYPE
6465
6466 * NEVER BEFORE DEFINED.
6467
075.217 346 002 6468 ANI CF,VEC
075.221 302 171 070 6469 JNZ ERR,ND NOT DECLARED
075.224 021 064 112 6470 LXI D,SYMTAB+1
075.227 041 006 000 6471 LXI H,6
075.232 315 026 071 6472 CALL AMB ALLOCATE 6 BYTES
075.235 021 000 000 6473 LXI D,0 (DE) = NAME
075.236 6474 LEXA EQU *-2 UNDEFINED NAME
075.240 162 6475 MOV M,D
075.241 043 6476 INX H
075.242 163 6477 MOV M,E STORE NAME
075.243 043 6478 INX H
075.244 124 6479 MOV D,H
075.245 135 6480 MOV E,L (DE) = ADDRESS OF VALUE
075.246 257 6481 XRA A (A) = 0
075.247 167 6482 MOV M,A CLEAR VALUE
075.250 043 6483 INX H
075.251 167 6484 MOV M,A
075.252 043 6485 INX H
075.253 167 6486 MOV M,A
075.254 043 6487 INX H
075.255 167 6488 MOV M,A 000 000 000 000

```

```

075.256 361          6489      POP      PSW          RESTORE TYPE
                   6490
                   6491 *      IS NOW DEFINED.
                   6492
075.257 334 107 055 6493  IST2   CC      VARIAB.      PROCESS VARIABLE IF NOT JUST DEFINED
075.262 311          6494      RET

```

```

6496 **      IVT - INSERT VECTOR IN TABLE.
6497 *
6498 *      IVT INSERTS A SYMBOL OF TYPE VECTOR IN THE SYMBOL TABLE.
6499 *      THE SYMBOL MUST NOT BE PREVIOUSLY DEFINED.
6500 *
6501 *      ENTRY (BC) = TEXT POINTER
6502 *      EXIT (BC) UPDATED
6503 *      (DE) = SYMBOL ADDRESS
6504 *      (A) = TYPE - CF,VEC
6505 *      USES A,F,B,C,D,E
6506
6507

```

```

075.263 315 056 071 6508  IVT   CALL   ANT          ACCEPT NEXT TOKEN
075.266 041 151 335 6509      LXI   H,-LEXLIM-1
075.271 031          6510      DAD   D
075.272 332 125 070 6511      JC    ERR,IU          ALREADY DEFINED
075.275 356 002     6512      XRI   CF,VEC          TOGGLE VECTOR FLAG
075.277 303 216 075 6513      JMP   IST1          PROCESS AS IST

```

```

6515 **      LCC - LOCATE CHANNEL COLUMN COUNTER.
6516 *
6517 *      LCC IS CALLED TO LOCATE THE BYTE CONTAINING THE COLUMN COUNTER
6518 *      FOR THIS CHANNEL ((IOCHAN)). SINCE PRINTING
6519 *      CAN BE IN PROGRESS ON SEVERAL CHANNELS AT ONCE, A SEPERATE COLUNE
6520 *      COUNTER IS KEPT FOR EACH ONE.
6521 *
6522 *      ENTRY NONE
6523 *      EXIT (HL) = ADDRESS OF RIGHT ENTRY IN *COLCNTS*
6524 *      USES A,F,H,L
6525
6526

```

```

075.302 041 253 112 6527  LCC   LXI   H,COLCNTS
075.305 072 140 112 6528      LDA   IOCHAN
075.310 303 101 030 6529      JMP   $DATA.          (HL) = ADDRESS

```

```

6531 **      LFC - LOCK FLAG CHECK
6532 *
6533 *      LFC CHECKS IF THE DATA LOCK IS INVOKED
6534 *
6535 *      ENTRY  NONE
6536 *      EXIT   TO ERR,LK IF DATA LOCK IN FORCE
6537 *           TO (RET) IF NORMAL
6538 *      USES  A,F
6539
6540
075.313 072 137 112 6541 LFC  LDA  LCKFLG      (A) = DATA LOCK FLAG
075.316 247      6542  ANA  A
075.317 302 130 070 6543  JNZ  ERR,LK      DATA LOCK IN FORCE
075.322 311      6544  RET  EXIT

```

```

6546 **      LVS - LOOK-UP VARIABLE IN SYMBOL TABLE
6547 *
6548 *      LVS LOOKS UP THE SPECIFIED VARIABLE IN THE SYMBOL TABLE.
6549 *      THE VARIABLE IS SPECIFIED BY THE VARIABLE NAME AND TYPE
6550 *      IN THE *DE* REGISTER PAIR AS PER THE *SYMTAB* FORMAT.
6551 *
6552 *      ENTRY: DE = SYMTAB KEY
6553 *
6554 *      EXIT: PSW = 'Z' CLEAR IF NOT FOUND
6555 *           = 'Z' SET IF FOUND
6556 *           DE = SYMTAB ADDRESS
6557 *
6558 *      USES: PSW,DE
6559 *
075.323      6560
075.323      6561 LVS  EQU  *
075.323 345      6562
075.324 305      6563  PUSH H
075.325 052 064 112 6564  PUSH B
075.330 104      6565  LHL  SYMTAB+MT,LEN
075.331 115      6566  MOV  B>H
075.332 052 064 112 6567  MOV  C>L      BC = SYMTAB LENGTH
075.332 052 064 112 6568  LML  SYMTAB+MT,FWA HL = SYMTAB FWA
075.332 052 064 112 6569
075.335 170      6570 LVS1 MOV  A>B
075.336 241      6571  ORA  C
075.337 312 040 076 6572  JZ   LVS4      NOT FOUND
075.337 312 040 076 6573
075.342 176      6574  MOV  A>H
075.343 043      6575  INX  H
075.344 272      6576  CMP  B
075.345 176      6577  MOV  A>H
075.346 302 363 075 6578  JNE  LVS2      NO MATCH
075.351 273      6579  CMP  E
075.352 302 363 075 6580  JNE  LVS2      NO MATCH
075.352 302 363 075 6581
075.352 302 363 075 6582 *      HAVE A MATCH
075.352 302 363 075 6583

```

```

075.355 053      6584      DCX      H
075.356 353      6585      XCHG
075.357 257      6586      XRA      A      DE = SYNTAB ADDRESS
075.360 301      6587      POP      B      SET THE ZERO FLAG
075.361 341      6588      POP      H
075.362 311      6589      RET
6590
6591 *          HAVE NO MATCH
6592
075.363 013      6593 LVS2     DCX      B
075.364 013      6594      DCX      B
075.365 013      6595      DCX      B
075.366 013      6596      DCX      B
075.367 013      6597      DCX      B
075.370 013      6598      DCX      B      BC = BC - 6
6599
075.371 176      6600      MOV      A,M
075.372 043      6601      INX      H
075.373 346 002  6602      ANI      CF,VEC
075.375 312 027 076 6603      JZ       LVS3     IS NOT A VECTOR
6604
076.000 176      6605      MOV      A,M
076.001 247      6606      ANA      A
076.002 372 027 076 6607      JM       LVS3     IS JUST A FUNCTION
6608
6609 *          PROCESS A VECTOR
6610
076.005 043      6611      INX      H
076.006 043      6612      INX      H      SKIP 'DIM' AND '0' BYTES
6613
076.007 325      6614      PUSH     D
076.010 136      6615      MOV      E,M
076.011 043      6616      INX      H
076.012 126      6617      MOV      D,M
076.013 043      6618      INX      H      DE = ARRAY SIZE
6619
076.014 171      6620      MOV      A,C
076.015 223      6621      SUB      E
076.016 117      6622      MOV      C,A
076.017 170      6623      MOV      A,B
076.020 232      6624      SBB      D
076.021 107      6625      MOV      B,A      BC = BC - SIZE
6626
076.022 031      6627      DAD      D      HL = HL + ARRAY SIZE
076.023 321      6628      POP      B
6629
076.024 503 335 075 6630      JMP      LVS1
6631
6632 *          PROCESS A NORMAL SCALAR
6633
076.027 305      6634 LVS3     PUSH     B
076.030 001 004 000 6635      LXI      B,6-2
076.033 011      6636      DAD      B      HL = HL + 6-2
076.034 301      6637      POP      B
6638
076.035 303 335 075 6639      JMP      LVS1      DO IT AGAIN

```

```

6640
6641 * PROCESS AN UNFOUND VARIABLE
6642
076.040 366 001 6643 LVS4 ORI 1 CLEAR ZERO FLAG
076.042 301 6644 POP B
076.043 341 6645 POP H
076.044 311 6646 RET

6648 ** MOVX - MOVE X BYTES OF DATA
6649 *
6650 * MOVX CONSISTS OF TWO ROUTINES
6651 *
6652 * MOV4 MOVES 4 BYTES OF DATA
6653 *
6654 * MOV5 MOVES 5 BYTES OF DATA
6655 *
6656 * ENTRY (HL) = DESTINATION ADDRESS
6657 * (DE) = SOURCE ADDRESS
6658 * EXIT (HL) = (HL) + COUNT
6659 * (DE) = (DE) + COUNT
6660 * USES AxF, D, E, H, L
6661
6662
076.045 6663 MOV5 EQU * ENTRY POINT TO MOVE 4 BYTES
076.045 032 6664 LDAX D
076.046 167 6665 MOV M,A
076.047 023 6666 INX D
076.050 043 6667 INX H
076.051 032 6668 MOV4 LDAX D
076.052 167 6669 MOV M,A
076.053 023 6670 INX D
076.054 043 6671 INX H
076.055 032 6672 LDAX D
076.056 167 6673 MOV M,A
076.057 023 6674 INX D
076.060 043 6675 INX H
076.061 032 6676 LDAX D
076.062 167 6677 MOV M,A
076.063 023 6678 INX D
076.064 043 6679 INX H
076.065 032 6680 LDAX D
076.066 167 6681 MOV M,A
076.067 023 6682 INX D
076.070 043 6683 INX H
076.071 311 6684 RET

```



```

6686 **      PNT - PREVIEW NEXT TOKEN.
6687 *
6688 *      PNT READS THE NEXT TEXT TOKEN. HOWEVER, THE TOKEN POINTER
6689 *      IS NOT ADVANCED, SO THAT IT CAN BE PREVIEWED OVER
6690 *      AND OVER, (AND ACCEPTED ONCE).
6691 *
6692 *      ENTRY (BC) = TEXT POINTER
6693 *      EXIT (BC) UPDATED
6694 *      (A) = TYPE
6695 *      (DE) = CODE (IF VARIABLE)
6696 *      USES A,F (D,E IF VARIABLE)
6697
6698
076.072 076 000 6699 PNT MVI A,0 (A) = TYPE
076.073 6700 PNTA EQU *-1 TYPE OF CURRENT TOKEN
076.074 376 300 6701 CPI CT,UARL
076.076 332 111 076 6702 JC PNT2 IS NOT VARIABLE
076.101 376 310 6703 CPI CT,UARH+1
076.103 322 111 076 6704 JNC PNT2 IS NOT VARIABLE
076.106 021 000 000 6705 LXI D,0 (DE) = INDEX
076.107 6706 PNTB EQU *-2
076.111 6707 PNT2 EQU *
076.111 000 6708 PNTC NOP 'RET' IF VALUE IN PNTA, PNTB
076.112 315 131 054 6709 CALL LEXCAL
076.115 353 6710 XCHG
076.116 042 107 076 6711 SHLD PNTB SET INDEX
076.121 353 6712 XCHG
076.122 062 073 076 6713 STA PNTA SET TYPE
076.125 365 6714 PUSH PSW
076.126 076 311 6715 MVI A,MI,RET VALUE IS IN PNTA, PNTB
076.130 062 111 076 6716 PNT1 STA PNTC SET FLAG
076.133 361 6717 POP PSW
076.134 311 6718 RET

```

```

6720 **      PVI - PERFORM VALUE INPUT.
6721 *
6722 *      PVI READS A LIST OF VARIABLES FROM THE TEXT AT (BC), AND
6723 *      ASSIGNS THEM THE VALUES OF THE EXPRESSIONS AT (HL).
6724 *
6725 *      ENTRY (BC) = VARIABLE LIST
6726 *      (HL) = TEXT LIST
6727 *      EXIT (BC) UPDATED
6728 *      (HL) UPDATED
6729 *      'Z' SET IF VARIABLE LIST SATISFIED
6730 *      USES ALL
6731
6732
076.135 315 072 076 6733 PVI CALL PNT PEEK AT NEXT TOKEN
000.000 6734 ERRNZ CT,FIN
076.140 247 6735 ANA A
076.141 310 6736 RZ NO MORE VARIABLES
076.142 326 020 6737 SUI CT,PAR SEE IF }
076.144 310 6738 RZ NO MORE VARIABLES

```

PVI

076.145	315 330 111	6739	CALL	\$SOB	SKIP BLANKS
076.150	176	6740	MOV	A,M	(A) = NEXT NON-BLANK
076.151	247	6741	ANA	A	
076.152	312 236 076	6742	JZ	PVI3	NO DATA
		6743			
		6744	*		WE KNOW WE HAVE DATA (OR A SPECIFIED NULL VALUE)
		6745			
076.155	345	6746	PUSH	H	
076.156	315 136 075	6747	CALL	IST	INSERT SYMBOL IN TABLE
076.161	341	6748	POP	H	
076.162	365	6749	PUSH	FSW	SAVE TYPE
076.163	315 062 077	6750	CALL	RCE	REQUIRE DELIMITER, CLEAR RNT
076.166	361	6751	POP	FSW	(A) = TYPE OF VARIABLE
076.167	305	6752	PUSH	B	
076.170	325	6753	PUSH	D	SAVE INDEX
076.171	365	6754	PUSH	FSW	SAVE TYPE
076.172	104	6755	MOV	B,H	
076.173	115	6756	MOV	C,L	(BC) = VALUE LIST ADDRESS
076.174	012	6757	LDAX	R	
076.175	376 054	6758	CPI	','	
076.177	302 210 076	6759	JNE	PVI1	IS NOT NULL VALUE
076.202	321	6760	POP	D	
076.203	361	6761	POP	FSW	SKIP ASSIGNING VALUE
076.204	003	6762	INX	B	
076.205	303 230 076	6763	JMP	PVI2	
		6764			
		6765	*		STORE VALUE.
		6766			
076.210	361	6767	PVI1	POP	FSW (A) = TYPE
076.211	365	6768		PUSH	FSW
076.212	315 240 076	6769	CALL	PVI5	EVALUATE VALUE
076.215	315 062 077	6770	CALL	RCE	REQUIRE COMMA OR END
076.220	361	6771	POP	FSW	RESTORE TYPE
076.221	321	6772	POP	D	(DE) = VARIABLE POINTER
076.222	315 366 072	6773	CALL	CSA	(DE) = ABS. ADDR. INTO SYMBOL TABLE
076.225	315 202 071	6774	CALL	AVV	ASSIGN VALUE TO VARIABLE
076.230		6775	PVI2	EQU	*
076.230	140	6776		MOV	H,B
076.231	151	6777		MOV	L,C
076.232	301	6778		POP	B
076.233	303 135 076	6779		JMP	PVI
		6780			
		6781	*		RAN OUT OF VALUES.
		6782			
076.236	264	6783	PVI3	ORA	H CLEAR 'Z'
076.237	311	6784		RET	
		6785			
		6786	*		CRACK VALUE.
		6787	*		
		6788	*		(A) = TYPE OF INPUT VARIABLE
		6789			
000.000		6790		ERRNZ	CF,STR-1 ASSUME 1 BIT FOR STRING
076.240	037	6791	PVI5	RAR	
076.241	332 261 076	6792		JC	PVI7 IS STRING VARIABLE
		6793			
		6794	*		REQUIRE NUMBER.

FVI

```

6795 * IF NOT VALID NUMBER, *ATF* WONT LEAVE POINTER AT DELIMITER
6796
076.244 140 6797 FVI6 MOV H,B
076.245 151 6798 MOV L,C
076.246 315 323 107 6799 CALL ATF ASCII TO FLOATING
076.251 076 300 6800 MVI A,CT,SNU
076.253 062 201 042 6801 STA ACCX-1 SET SCALAR NUMERIC VALUE
076.256 104 6802 MOV B,H
076.257 115 6803 MOV C,L UPDATE (BC)
076.260 311 6804 RET
6805
6806 * MUST BE STRING. IF QUOTES, GOBBLE IT ALL. IF NONE, GO TO COMMA
6807
076.261 012 6808 FVI7 LDAX B (A) = FIRST DATA CHARACTER
076.262 376 042 6809 CPI ','
076.264 003 6810 INX B ASSUME HAVE QUOTE
076.265 312 325 076 6811 JE FVI10 INPUT AS STRING
6812
6813 * DOESNT HAVE QUOTES. COPY INTO LINE2, AND ADD THE QUOTES
6814
076.270 041 273 113 6815 LXI H,LINE2
076.273 013 6816 DCX B POINT TO 1ST CHARACTER
076.274 012 6817 FVI8 LDAX B
076.275 167 6818 MOV M,A
076.276 003 6819 INX B
076.277 043 6820 INX H
076.300 012 6821 LDAX B CHECK NEXT CHARACTER
076.301 376 054 6822 CPI ','
076.303 312 312 076 6823 JE FVI9 GOT THE END
000.000 6824 ERRNZ CT,FIN
076.306 247 6825 ANA A
076.307 302 274 076 6826 JNZ FVI8 NOT AT END OF LINE
6827
6828 * ALL DONE COPYING STRING. ADD CLOSE QUOTE
6829
076.312 066 042 6830 FVI9 MVI M,','
076.314 305 6831 PUSH B SAVE (BC)
076.315 001 273 113 6832 LXI B,LINE2
076.320 315 325 076 6833 CALL FVI10 BUILD STRING
076.323 301 6834 POP B RESTORE (BC)
076.324 311 6835 RET
6836
076.325 315 015 055 6837 FVI10 CALL LEX12 READ STRING TYPE
076.330 305 6838 PUSH B
076.331 001 005 000 6839 LXI B,5
076.334 033 6840 DCX D POINT TO VALUE-1
076.335 041 201 042 6841 LXI H,ACCX-1
076.340 315 252 030 6842 CALL $MOVE MOVE DESCRIPTOR INTO ACCX
076.343 301 6843 POP B
076.344 311 6844 RET

```

```

6846 **      PBO - PRESET BOOLEAN OPERATORS
6847 *
6848 *      PBO INSURES THAT BOTH VALUES ARE NUMERIC, AND THEN
6849 *      FIXES BOTH TO INTEGERS.
6850 *
6851 *      ENTRY  (ACCX) = VALUE 1
6852 *             (ACCY) = VALUE 2
6853 *      EXIT  (HL) = IFIX(ACCX)
6854 *             (DE) = IFIX(ACCY)
6855 *      USES  A,F,D,E,H,L
6856 *
6857
076.345 315 177 077 6858 FBO  CALL  RNO          REQUIRE NUMERIC OPERANDS
076.350 315 002 075 6859      CALL  IFIX          (DE) = IFIX(ACCX)
076.353 353                6860      XCHG
076.354 303 377 074 6861      JMP   IFIX,          (DE) = IFIX(ACCX)

```

```

6863 **      POPX - POP VALUE INTO ** ACCUMULATOR.
6864 *
6865 *      ENTRY  NONE
6866 *      EXIT  NONE
6867 *      USES  H,L
6868
076.357 041 201 042 6870 POPX  LXI   H,ACCX-1
076.362 303 373 076 6871      JMP   POP

```

```

6873 **      POPY - POP VALUE INTO *Y* ACCUMULATOR.
6874 *
6875 *      ENTRY  NONE
6876 *      EXIT  (DE) = #ACCY
6877 *      USES  A,F,D,E,H,L
6878
6879
6880 **      POPY. - POP VALUE INTO *Y* ACCUMULATOR.
6881 *
6882 *      ENTRY  NONE
6883 *      EXIT  NONE
6884 *      USES  D,E,H,L
6885
6886
076.365 021 210 042 6887 POPY  LXI   D,ACCY
076.370 041 207 042 6888 POPY, LXI   H,ACCY-1      STORE AREA

```

```

6890 ** POP - POP VALUE FROM WRKTAB.
6891 *
6892 * ENTRY (HL) = ADDRESS OF 5 BYTE AREA
6893 * EXIT DATA IN AREA
6894 * USES H,L
6895
6896
076.373 365 6897 POP PUSH PSW SAVE PSW
076.374 325 6898 PUSH D
076.375 345 6899 PUSH H
076.376 052 105 112 6900 LHLD WRKTAB+MT.LEN
077.001 021 373 377 6901 LXI D,-5
077.004 031 6902 DAD D
077.005 042 105 112 6903 SHLD WRKTAB+MT.LEN DECREASE SIZE
077.010 322 117 070 6904 JNC ERR.DO SHOULD NOT OCCUR
077.013 353 6905 XCHG
077.014 052 103 112 6906 LHLD WRKTAB+MT.FWA
077.017 031 6907 DAD D (HL) = ABS ADDRESS OF 5 BYTES
077.020 353 6908 XCHG
077.021 341 6909 POP H (HL) = TO
077.022 315 045 076 6910 CALL MOVE MOVE DATA
077.025 321 6911 POP D
077.026 361 6912 POP PSW
077.027 311 6913 RET
  
```

```

6915 ** PSHX - PUSH (ACCX) ONTO STACK.
6916 *
6917 * ENTRY NONE
6918 * USES A,F,D,E,H,L
6919
6920
077.030 315 056 071 6921 PSHX. CALL ANT ACCEPT OPERATION
077.033 041 201 042 6922 PSHX LXI H,ACCX-1
077.036 303 044 077 6923 JMP PSW PUSH ACCX
6924
6925
6926 ** PSHY - PUSH (ACCY) ONTO WORK STACK.
6927 *
6928 * ENTRY NONE
6929 * EXIT (ACCY) ON STACK
6930 * USES A,F,D,E,H,L
6931
6932
077.041 041 207 042 6933 PSHY LXI H,ACCY-1
6934
6935
6936 ** PSH - PUSH MEMORY VALUE INTO WORK STAC.
6937 *
6938 * ENTRY (HL) = ADDRESS OF 5 BYTES
6939 * EXIT ON WRKTAB
6940 * USES A,F,D,E,H,L
6941
6942
  
```

077.044	345	6943	PSH	PUSH	H	
077.045	041 005 000	6944		LXI	H,5	
077.050	021 103 112	6945		LXI	D,WKRTAB+1	
077.053	315 026 071	6946		CALL	AMB	ALLOCATE 5 BYTES
077.056	321	6947		POP	B	(DE) = FROM
077.057	303 045 076	6948		JMP	MOV5	COPY AND EXIT

6950 ** RCE - REQUIRE COMMA OR END.
6951 *
6952 * RCE REQUIRES EITHER A COMMA, OR END OF STATEMENT.
6953 *
6954 * ENTRY (BC) = TEXT POINTER
6955 * EXIT TO *RET* IF OK
6956 * (BC) UPDATED
6957 * (A) = TYPE CODE
6958 * TO ERR.SY IF NOT ', ' OR CT.FIN
6959 * USES A,F,B,C
6960
6961

077.062	315 056 071	6962	RCE	CALL	ANT	ACCEPT NEXT TOKEN
077.065	247	6963		ANA	A	
000.000		6964		ERRNZ	CT.FIN	
077.066	310	6965		RZ		IS FIN
077.067	376 026	6966		CPI	CT.CMA	
077.071	310	6967		RE		COMMA
077.072	303 152 070	6968		JMP	ERR.SY	SYNTAX ERROR

6970 ** RIL - READ INPUT LINE.
6971 *
6972 * RIL READS A LINE FROM THE SYSTEM CONSOLE.
6973 *
6974 * ENTRY (HL) = LINE FWA
6975 * EXIT 'C' SETE IF CTL-C STRUCK
6976 * 'C' CLEAR IF GOT LINE
6977 * (A) = LINE LENGTH
6978 * USES A,F,D,E
6979
6980

077.075	345	6981	RIL	PUSH	H	SAVE START ADDRESS
077.076	072 142 112	6982	RIL1	LDA	CTLFLAG	
000.000		6983		ERRNZ	CFCTL-C-1	
077.101	037	6984		RAR		
077.102	332 137 077	6985		JC	RIL3	CTL-C
077.105	377 001	6986		DB	SYSCALL, .SCIN	
077.107	332 076 077	6987		JC	RIL1	
077.112	376 012	6988		CPI	NL	
077.114	302 120 077	6989		JNE	RIL2	NOT END OF LINE
077.117	257	6990		XRA	A	USE 00 AS END OF LINE
077.120	167	6991	RIL2	MOV	M,A	
077.121	043	6992		INX	H	

Address	Line 1	Line 2	Line 3	Line 4	Op	Reg	Comment
077.122	302	076	077	6993	JNZ	RIL1	MORE TO GO
077.125	074			6994	INR	A	(A) = 1
077.126	062	253	112	6995	STA	COLCNTS	SET CONSOLE COLUMN AT FRONT OF LINE
077.131	321			6996	POP	D	(DE) = LINE FWA
077.132	175			6997	MOV	A,L	(A) = LENGTH OF LINE
077.133	223			6998	SUB	E	
077.134	247			6999	ANA	A	CLEAR CARRY
077.135	353			7000	XCHG		(HL) = LINE FWA
077.136	311			7001	RET		
				7002			
				7003	*	CTL-C HIT	
				7004			
077.137	341			7005	RIL3	POP	H
077.140	311			7006	RET		
				7008	**	RLF - READ LINE FROM FILE.	
				7009	*		
				7010	*	RLF READS A LINE FROM THE FILE NUMBER SPECIFIED IN IOCHAN.	
				7011	*	THIS MAY BE THE CONSOLE, OR IT MAY BE A FILE BLOCK.	
				7012	*		
				7013	*	ENTRY (HL) = LINE ADDRESS	
				7014	*	EXIT 'C' SET IF CTL-C (WAS CONSOLE INPUT)	
				7015	*	USES A,F,D,E	
				7016			
				7017			
077.141	072	140	112	7018	RLF	LDA	IOCHAN
077.144	247			7019		ANA	A
077.145	312	075	077	7020	JZ	RIL	IS CONSOLE, READ LINE
				7021			
				7022	*	IS FROM FILE	
				7023			
077.150	345			7024	PUSH	H	SAVE TEXT FWA
077.151	075			7025	DCR	A	
077.152	315	005	072	7026	CALL	CFA	COMPUTE FILE BLOCK ADDRESS
077.155	332	210	070	7027	JC	ERR.FNO	FILE NOT OPEN
077.160	321			7028	POP	D	(DE) = LINE FWA
077.161	305			7029	PUSH	B	SAVE BC
077.162	001	005	001	7030	LXI	B,LINEL+6	MAX.CHAR.TO.READ+6 FOR LINE # /78.10.GC/
077.165	325			7031	PUSH	D	SAVE LINE FWA
077.166	315	161	101	7032	CALL	\$FREAL	READ LINE
077.171	332	213	070	7033	JC	ERR.EOF	EOF ON DEVICE
077.174	341			7034	POP	H	(HL) = LINE FWA
077.175	301			7035	POP	B	RESTORE (BC)
077.176	311			7036	RET		

```

7038 **      RND - REQUIRE NUMERIC OPERANDS.
7039 *
7040 *      RND REQUIRES THAT (ACCX) AND (ACCY) ARE BOTH NUMERIC.
7041 *
7042 *      ENTRY  NONE
7043 *      EXIT   TO *RET* IF NUMERIC
7044 *           TO ERR.TC IF NOT
7045 *      USES   A,F,H,L
7046 *
7047 *
077.177 315 347 072 7048 RND  CALL  COT
077.202 310          7049      RZ          NUMERIC
077.203 303 155 070 7050      JMP   ERR.TC      TYPE ERROR

7052 **      RNP - READ NEW PROGRAM.
7053 *
7054 *      RNP IS CALLED TO READ A NEW SOURCE PROGRAM INTO THE TEXT TABLE (TXTAB).
7055 *
7056 *      ALL TXTAB DEPENDANT TABLES ARE CLEARED.
7057 *
7058 *      RNP EXPECTS THAT THE PROPER FILE NAME IS ALREADY INSTALLED
7059 *      IN THE FIRST FILE BLOCK IN FILTAB. NOTE THAT AS THE PROGRAM TEXT
7060 *      IS INSERTED, FILTAB MAY MOVE BETWEEN LINES.  THUS, RNP RE-LOADS
7061 *      THIS ADDRESS BEFORE EVERY OPERATION.
7062 *
7063 *      ENTRY  NONE
7064 *      EXIT   (BC) = #ZERO
7065 *      USES   ALL
7066 *
077.206 315 320 077 7068 RNP  CALL  SCRA      CLEAR TEXT TABLE
077.211 315 104 073 7069      CALL  CUF        CLEAR USER-DEFINED FUNCTIONS FROM SYMTAB
077.214 315 021 045 7070      CALL  CLR1       CLEAR TEXT TABLE REFERENCES
077.217 315 217 074 7071      CALL  FOP        FILE OPEN PRESET
077.222 041 230 042 7072      LXI  H,FBLIST   (HL) = TABLE FWA
077.225 021 072 043 7073      LXI  D,DEFALTP
077.230 315 021 101 7074      CALL  $FOPER     OPEN FOR READ
077.233 315 115 074 7075      CALL  FOC        RESTORE MEMORY SPACE
077.236 001 005 001 7076 RNP1  LXI  B,LINEL+6
077.241 021 266 112 7077      LXI  D,LINE+1
077.244 041 230 042 7078      LXI  H,FBLIST   (HL) = FB FWA
077.247 325          7079      PUSH  0          SAVE ADDRESS
077.250 315 161 101 7080      CALL  $FREAL     READ LINE INTO BUFFER+1
077.253 341          7081      POP   H          (HL) = #BUFFER+1
077.254 332 273 077 7082      JC   RNP2       ALL DONE
077.257 315 373 065 7083      CALL  ICL        COMPRESS LINE INTO BUFFER+0
077.262 332 273 077 7084      JC   RNP2       CTL-C HIT
077.265 315 270 070 7085      CALL  MTL        MERGE TEXT LINEE
077.270 303 236 077 7086      JMP   RNP1     GET NEXT
7087 *
7088 *      END OF TEXT
7089 *
077.273 041 230 042 7090 RNP2  LXI  H,FBLIST   (HL) = FB FWA

```



```

077.276 315 335 102 7091 CALL *FCLO CLOSE INPUT FILE
077.301 001 345 114 7092 LXI B,ZERO (BC) = TEXT POINTER = NO MORE
077.304 311 7093 RET EXIT

```

```

7095 ** RNT - REQUIRE NEXT TOKEN.
7096 *
7097 * RNT CHECKS TO SEE IF THE NEXT TOKEN IS THE REQUIRED VALUE.
7098 * AND FLAGS A SYNTAX ERROR IF NOTL
7099 *
7100 * ENTRY (RET) = REQUIRED TOKEN
7101 * EXIT TO (RET)+1 IF MATCH
7102 * (DE) = SYMBOL POINTER (IF VARIABLE)
7103 * (A) = VARIABLE TYPE
7104 * TO ERR.SY IF NOT
7105 * USES A,F, (DE, IF VARIABLE)
7106 *
7107 *

```

```

077.305 315 056 071 7108 RNT CALL ANT ACCEPT NEXT TOKEN
077.310 343 7109 XTHL
077.311 276 7110 CMP H
077.312 043 7111 INY H
077.313 343 7112 XTHL
077.314 310 7113 RE OK
077.315 303 152 070 7114 JMP ERR.SY NO GOOD

```

```

7116 ** SCRA - SCRATCH TEXT BUFFER
7117 *
7118 * SCRA INSERTS THE DUMMY LAST LINE
7119 * AT THE BEGINNING OF THE BUFFER
7120 *
7121 * ENTRY NONE
7122 * EXIT (BC) = #0 BYTE
7123 * USES A,F,B,C,H,L
7124 *
7125 *

```

```

077.320 041 003 000 7126 SCRA LXI H,3 SCRATCH STORE
077.323 042 061 112 7127 SHLD TXTTAB+MT.LEN LENGTH = 3
077.326 041 377 377 7128 LXI H,377377A
077.331 042 346 114 7129 SHLD MTAREA
077.334 001 350 114 7130 LXI B,MTAREA+2
077.337 257 7131 XRA A
077.340 002 7132 STAX B CLEAR TEXT, SET ((BC)) = 0
7133 *
077.341 311 7134 RET EXIT

```

```

7136 ** SES - SKIP TO END OF STATEMENT.
7137 *
7138 * SES SKIPS OVER TEXT UNTIL AN END-OF-LINE IS DETECTED
7139 *
7140 * ENTRY (BC) = TEXT POINTER
7141 * EXIT (BC) UPATED
7142 * USES A,F,B,C
7143
7144
077.342 315 056 071 7145 SES CALL ANT ACCEPT NEXT TOKEN
000.000 7146 ERRNZ CT,FIN
077.345 247 7147 ANA A
077.346 302 342 077 7148 JNZ SES NOT YET
077.351 311 7149 RET

7151 ** SFS - SEARCH 'FOR' STACK.
7152 *
7153 * SFS SEARCHES A FOR STACK FOR AN ENTRY MATCHEDING A
7154 * SUPPLIED ONE.
7155 *
7156 *
7157 * ENTRY (DE) = INDEX VARIABLE INDEX
7158 *
7159 * EXIT 'Z' SET IF FOUND
7160 * (HL) = INDEX OF IND+2 (IF ANY)
7161 * (DE) = ABS. ADDRESS OF INDEX IN SYMTAB
7162 *
7163 * USES A,F,H,L
7164 *
7165
077.352 315 072 076 7166 SFS. CALL FNT ALLOW NULL AS THE LAST IN STACK
000.000 7167 ERRNZ CT,FIN
077.355 127 7168 MOV D,A ASSUME (A) = 0 = CT,FIN
077.356 137 7169 MOV E,A
077.357 312 375 077 7170 JZ SFS0 (DE) = 0 = INDEX
7171

077.362 315 136 075 7172 SFS CALL IST INSERT SYMBOL IN TABLE
077.365 376 300 7173 CPI CT,SNV
077.367 302 152 070 7174 JNE ERR,SY MUST BE SCALAR NUMERIC VARIABLE
077.372 315 366 072 7175 CALL CSA DE = ABS. SYMTAB ADDRESS /80.01.GC/
7176

077.375 305 7177 SFS0 PUSH B SAVE TEXT POINTER
077.376 052 073 112 7178 LHLD FORTAB+MT.LEN
100.001 104 7179 MOV B,H
100.002 115 7180 MOV C,L
100.003 052 071 112 7181 LHLD FORTAB+MT.FWA (HL) = TABLE FWA
100.004 345 7182 PUSH H
100.007 011 7183 DAD B (HL) = LWAY1
7184

100.010 172 7185 MOV A,D /80.01.GC/
100.011 263 7186 ORA E /80.01.GC/
100.012 312 025 100 7187 JZ SFS1 /80.01.GC/
7188

```

100.015	353	7189	XCHG			/80.01.6C/
100.016	053	7190	DCX	H		/80.01.6C/
100.017	053	7191	DCX	H		/80.01.6C/
100.020	176	7192	MOV	A,M		/80.01.6C/
100.021	043	7193	INX	H		/80.01.6C/
100.022	156	7194	MOV	L,M		/80.01.6C/
100.023	147	7195	MOV	H,A		/80.01.6C/
100.024	353	7196	XCHG		DE = SYMBOL KEY	/80.01.6C/
		7197				
100.025	170	7198	SFS1	MOV	A,B	
100.026	261	7199		ORA	C	CHECK COUNT
100.027	312 073 100	7200		JZ	SFS3	NOT FOUND
100.032	305	7201		PUSH	B	
100.033	001 365 377	7202		LXI	B,-11	
100.036	011	7203		DAD	B	(HL) = ADDRESS OF LAST ELEMENT
100.037	301	7204		POP	B	
100.040	172	7205		MOV	A,D	
100.041	263	7206		ORA	E	
100.042	176	7207		MOV	A,M	
100.043	053	7208		DCX	H	
100.044	312 120 100	7209		JZ	SFS6	WILL TAKE THE LAST
100.047	273	7210		CMF	E	SEE IF FOUND
100.050	302 060 100	7211		JNE	SFS2	NOT FOUND
100.053	176	7212		MOV	A,M	
100.054	272	7213		CMF	D	/80.01.6C/
100.055	312 074 100	7214		JE	SFS4	FOUND
100.060	171	7215	SFS2	MOV	A,C	
100.061	326 014	7216		SUI	12	
100.063	117	7217		MOV	C,A	
100.064	170	7218		MOV	A,B	COUNT = COUNT-12
100.065	336 000	7219		SRI	0	
100.067	107	7220		MOV	B,A	
100.070	303 025 100	7221		JMP	SFS1	TRY AGAIN
		7222				
		7223	*		NOT FOUND.	
		7224				
100.073	264	7225	SFS3	ORA	H	
		7226				
		7227	*		FOUND. COMPUTE FORTAB INDEX FROM ABS.	
		7228				
100.074	043	7229	SFS4	INX	H	
100.075	043	7230	SFS5	INX	H	
100.076	104	7231		MOV	B,H	
100.077	115	7232		MOV	C,L	(BC) = ABS ADDRESS
100.100	341	7233		POP	H	(HL) = FORTAB FWA
100.101	365	7234		PUSH	PSW	SAVE CODE
100.102	171	7235		MOV	A,C	
100.103	225	7236		SUB	L	
100.104	157	7237		MOV	L,A	
100.105	170	7238		MOV	A,B	
100.106	234	7239		SBB	H	
100.107	147	7240		MOV	H,A	
100.110	315 323 075	7241		CALL	LVS	GET AN ABS. ADDRESS
100.113	023	7242		INX	D	/80.01.6C/
100.114	023	7243		INX	D	/80.01.6C/
100.115	361	7244		POP	PSW	RESTORE CODE

```

100.116 301      7245 POP      B          RESTORE (BC)
100.117 311      7246 RET
              7247
              7248 *      NO VARIABLE SUPPLIED, JUST TAKE THE LAST ONE.
              7249
100.120 124      7250 SFS6  MOV     D,M          /80.01.GC/
100.121 043      7251      INX     H
100.122 136      7252      MOV     E,M          (DE) = VARIABLE INDEX /80.01.GC/
100.123 303 075 100 7253      JMP     SFS5

              7255 **      SOB - SKIP OVER BLANKS.
              7256 *
              7257 *      ENTRY (BC) = TEXT POINTER
              7258 *      EXIT (BC) = ADDRESS OF NEXT NON-BLANK CHARACTER
              7259 *      USES  A,F,B,C
              7260
              7261
100.126 012      7262 SOB     LDAX   B
100.127 376 040  7263      CPI     ' '
100.131 312 137 100 7264      JE      SOB1      IS BLANK
100.134 376 011  7265      CPI     TAB
100.136 300      7266      RNE     NOT TAB, EITHER
100.137 003      7267 SOB1  INX     B
100.140 303 126 100 7268      JMP     SOB

              7270 **      SRA - STACK RETURN ADDRESS.
              7271 *
              7272 *      SRA STACKS THE TEXT RETURN ADDRESS (END OF CURRENT STATEMENT)
              7273 *      AND THE CURRENT LINE NUMBER ON STACK 'GOSTAB'.
              7274 *
              7275 *      ENTRY (BC) = TEXT POINTER
              7276 *      EXIT (BC) UNCHANGED.
              7277 *      USES  A,F,D,E
              7278
              7279
100.143 305      7280 SRA    PUSH   B          SAVE TEXT ADDRESS
100.144 345      7281      PUSH   H          SAVE (HL)
100.145 315 342 077 7282      CALL  SES          SKIP TO END OF STATEMENT
100.150 041 004 000 7283      LXI   H,A
100.153 021 076 112 7284      LXI   D,GOSTAB+1
100.156 315 026 071 7285      CALL  AMB          ALLOCATE ROOM
100.161 353      7286      XCHG
100.162 052 133 112 7287      LHLD  CURNUM      (HL) = CURRENT LINE NUMBER
100.165 353      7288      XCHG
100.166 161      7289      MOV   M,C          SAVE RETURN ADDRESS
100.167 043      7290      INX   H
100.170 160      7291      MOV   M,B
100.171 043      7292      INX   H
100.172 163      7293      MOV   M,E          SET CURNUM
100.173 043      7294      INX   H

```

100.174	162	7295	MOV	M,D	
100.175	341	7296	POP	H	
100.176	301	7297	POP	B	RESTORE (BC)
100.177	311	7298	RET		

		7300	**	TCS - TYPE CHARACTER STRING.	
		7301	*		
		7302	*	TCS TYPES A CHARACTER STRING ON THE CONSOLE.	
		7303	*		
		7304	*	ENTRY (DE) = STRING DESCRIPTOR	
		7305	*	EXIT TYPED	
		7306	*	USES A,F,D,E,H,L	
		7307			
		7308			
100.200		7309	TCS	EQU *	
100.200	315 315 074	7310	CALL	FSE	FIND STRINGTAB ENTRY
100.203	303 251 100	7311	JMP	WLF,	WRITE LINE TO FILE

		7313	**	TDI - TYPE DECIMAL INTEGER.	
		7314	*		
		7315	*	TDI TYPES AN INTEGER AS A 5 PLACE NUMBER. LEADING ZEROS ARE	
		7316	*	SUPPRESSED.	
		7317	*		
		7318	*	ENTRY (DE) = NUMBER	
		7319	*	EXIT TYPED	
		7320	*	USES A,F,D,E	
		7321			
		7322			
100.206	345	7323	TDI	PUSH H	
100.207	315 040 075	7324	CALL	IFLT	FLOAT IT
100.212	041 273 113	7325	LXI	H,LINE2	
100.215	315 237 110	7326	CALL	FTA	FLOATING TO ASCII
100.220	315 217 103	7327	CALL	\$TYPCC	TYPE NUMBER MINUS .
100.223	341	7328	POP	H	
100.224	311	7329	RET		

		7331	**	WEL - WRITE END OF LINE.	
		7332	*		
		7333	*	WEL WRITES AN END OF LINE CHARACTER TO THE CURRENT OUTPUT FILE.	
		7334	*		
		7335	*	ENTRY NONE	
		7336	*	EXIT NONE	
		7337	*	USES A,F,D,E,H,L	
		7338			
		7339			
100.225	315 302 075	7340	WEL	CALL LCC	
100.230	257	7341	XRA	A	

```

100.231 167      7342      MOV      M,A          SET COLUMN # = 1(-1 FOR THE NL CHARACTER)
100.232 041 241 100 7343      LXI      H,WELA
100.235 074      7344      INR      A          (A) = 1
100.236 303 251 100 7345      JMP      WLF,        WRITE CHARACTER AND EXIT
                        7346
100.241 012      7347 WELA  DB      NL
  
```

```

7349 **      WLF - WRITE LINE TO FILE.
7350 *
7351 *      WLF WRITES A LINE IN 'LINE2' TO THE INDICATED (IOCHAN) FILE.
7352 *      THIS MAY BE THE SYSTEM CONSOLE, AND THE 'LINE' MAY NOT
7353 *      BE A COMPLETE LINE (I.E., HAVE NO NL CHARACTER)
7354 *
7355 *      ENTRY (LINE2) = TEXT
7356 *      EXIT  NONE
7357 *      USES  A,F,D,E,H,L
7358
7359
  
```

```

100.242 041 273 113 7360 WLF  LXI      H,LINE2
100.245 315 273 111 7361      CALL   #CILL        COMPUTE LINE LENGTH
100.250 075      7362      DCR      A          REMOVE 00 BYTE COUNT
                        7363
  
```

```

7364 **      WLF, - WRITE LINE TO FILE,
7365 *
7366 *      ENTRY (A) = LINE LENGTH
7367 *      (HL) = LINE FWA
7368 *      EXIT  NONE
7369 *      USES  A,F,D,E,H,L
7370
7371
  
```

```

100.251 305      7372 WLF,  PUSH     B          SAVE (BC)
100.252 117      7373      MOV      C,A
100.253 006 000  7374      MVI      B,0          (BC) = COUNT
100.255 353      7375      XCHG                     (DE) = TEXT ADDRESS
100.256 315 302 075 7376      CALL   LCC          LOCATE COLCNT FOR THIS CHANNEL
100.261 176      7377      MOV      A,M
100.262 201      7378      ADD      C
100.263 167      7379      MOV      M,A          UPDATE COLUME NUMBER
100.264 353      7380      XCHG                     (HL) = TEXT ADDRESS
100.265 072 140 112 7381      LDA      IOCHAN
100.270 247      7382      ANA      A
100.271 302 301 100 7383      JNZ      WLF2        WRITE TO DISK
                        7384
  
```

```

7385 *      TO CONSOLE
7386
7387      MOV      A,C
7388      POP      B          RESTORE (BC)
7389      JMP      $TYPCC     WRITE TO CONSOLE AND EXIT
7390
  
```

```

7391 *      WRITE TO DISK BUFFER, LOCATE FILE BLOCK
7392
  
```

```

100.301 345      7393 WLF2  PUSH     H          SAVE TEXT FWA
100.302 075      7394      DCR      A          (A) = FILE BLOCK NUMBER
  
```

100.303	315	005	072	7395	CALL	CFA	COMPUTE FILE BLOCK ADDRESS
100.306	332	210	070	7396	JC	ERR,FNO	FILE NOT OPEN
100.311	321			7397	POP	D	(DE) = DATA FWA
100.312	315	047	102	7398	CALL	\$FWRIB	WRITE DATA TO BUFFER
100.315	301			7399	POP	B	RESTORE (BC)
100.316	311			7400	RET		

7402 ** XCY - EXCHANGE (ACCX) WITH (ACCY)

7403 *
7404 * ENTRY NONE
7405 * EXIT NONE
7406 * USES A,F

				7407			
				7408			
100.317	305			7409	XCY	PUSH	B
100.320	325			7410		PUSH	D
100.321	345			7411		PUSH	H
100.322	021	201	042	7412		LXI	D,ACCX-1
100.325	041	207	042	7413		LXI	H,ACCY-1
100.330	016	005		7414		MVI	C,5 (C) = BYTE COUNT
100.332	032			7415	XCY1	LDAX	D
100.333	106			7416		MOV	B,M
100.334	167			7417		MOV	H,A (A) = NEXT BYTE IN LIST
100.335	170			7418		MOV	A,B
100.336	022			7419		STAX	D
100.337	023			7420		INX	D
100.340	043			7421		INX	H
100.341	015			7422		DCR	C
100.342	302	332	100	7423		JNZ	XCY1 MORE TO GO
100.345	341			7424		POP	H
100.346	321			7425		POP	D
100.347	301			7426		POP	B
100.350	311			7427		RET	

7429 ** ZRO - ZERO MEMORY.
7430 *
7431 * ZRO ZEROS A FIELD OF MEMORY.
7432 *
7433 * ENTRY (HL) = ADDRESS
7434 * (DE) = COUNT
7435 * EXIT NONE
7436 * USES A,F,D,E,H,L

				7437			
				7438			
100.351	172			7439	ZRO	MOV	A,D
100.352	263			7440		ORA	E
100.353	310			7441		RZ	DONE
100.354	066	000		7442		MVI	M,0
100.356	043			7443		INX	H
100.357	033			7444		DCX	D

SUBROUTINES.

ZRO

15:47:26 16-MAY-80

100.360 303 351 100 7445

JMP ZRO

7448 *** THE FOLLOWING SUBROUTINES ARE ENVOCKED BY INTERRUPTS.
 7449 *
 7450 *

7452 ** CCINT - PROCESS CTL-C INTERRUPT.
 7453 *
 7454 * ENTRY NONE
 7455 * EXIT TO CALLER (INTERRUPT)
 7456 * USES A,F
 7457
 7458

100.363 076 001 7459 CCINT MVI A,CFCTLC
 100.365 303 372 100 7460 JMP CBINT1 PROCESS AS CTL-B

7462 ** CBINT - CONTROL-B INTERRUPT.
 7463 *
 7464 * ENTRY NONE
 7465 * EXIT NONE
 7466 * USES A,F
 7467
 7468

100.370 076 002 7469 CBINT MVI A,CFCTLB
 100.372 345 7470 CBINT1 PUSH H
 100.373 365 7471 PUSH PSW SAVE FLAG BIT
 100.374 315 136 031 7472 CALL \$TYP TX
 100.377 336 7473 DB /C'+2000
 101.000 361 7474 POP PSW
 101.001 365 7475 PUSH PSW (A) = CODE
 000.000 7476 ERRNZ CFCTLB-2 02 IF CTL-B
 000.000 7477 ERRNZ CFCTLC-1 01 IF CTL-C
 101.002 366 002 7478 ORI 2 =3 IF CTLC, =2 IF CTL-B
 101.004 306 100 7479 ADI 'e'
 101.006 315 241 103 7480 CALL \$UCHAR ECHO CHARACTER
 101.011 361 7481 POP PSW (A) = CODE
 101.012 041 142 112 7482 LXI H,CTLFLAG
 101.015 266 7483 ORA H
 101.016 167 7484 MOV M,A
 101.017 341 7485 POP H
 101.020 311 7486 RET RETURN

```

101.021          7489          XTEXT  FOPE
.....
7491X **          $FOPEX - OPEN FILE BLOCK FOR I/O
7492X *
7493X *          $FOPEX IS CALLED BEFORE ANY I/O IS DONE VIA A
7494X *          FILE BLOCK. $FOPEX SETS UP THE FILE BLOCK, AND OPENS
7495X *          THE FILE VIA *HDOS*.
7496X *
7497X *          ENTRY (DE) = ADDRESS OF DEFAULT BLOCK
7498X *          (HL) = ADDRESS OF FILE BLOCK
7499X *          EXIT TO $FERROR IF ERROR
7500X *          TO CALLER IF OK
7501X *          USES A,F,B,C,D,E
7502X
7503X
101.021 315 046 101 7504X $FOPER CALL $FOPER.
101.024 320          7505X RNC
101.025 303 223 070 7506X JMP $FERROR IN ERROR
7507X
101.030 315 051 101 7508X $FOPEW CALL $FOPEW.
101.033 320          7509X RNC
101.034 303 223 070 7510X JMP $FERROR IN ERROR
7511X
101.037 315 054 101 7512X $FOPEU CALL $FOPEU.
101.042 320          7513X RNC
101.043 303 223 070 7514X JMP $FERROR IN ERROR
7515X
7516X
101.046 076 002 7517X $FOPER. MVI A,FT,OR FILE TYPE OF OPEN FOR READ
101.050 001 7518X DB 001Q LXI,B TO SKIP NEXT MVI
101.051 076 004 7519X $FOPEW. MVI A,FT,OW OPEN FOR WRITE
101.053 001 7520X DB 001Q LXI,B TO SKIP NEXT MIV
101.054 076 006 7521X $FOPEU. MVI A,FT,OR+FT,OW
7522X
7523X *          (A) = FILE FLAGS
7524X
101.056 345 7525X PUSH H SAVE FILE BLOCK ADDRESS
101.057 345 7526X PUSH PSW SAVE NEW FLAGS
000.000 7527X ERRNZ FB,CHA
101.060 106 7528X MOV B,H (B) = CHANNEL NUMBER
101.061 305 7529X PUSH B SAVE HANNEL NUMBER
000.000 7530X ERRNZ FB,FLG-FB,CHA-1
101.062 043 7531X INX H
101.063 117 7532X MOV C,A (C) = NEW FILE FLAGS
101.064 176 7533X MOV A,M (A) = CURRENT TYPE
101.065 247 7534X ANA A
101.066 171 7535X MOV A,C (A) = NEW FLAGS TO BE SET
101.067 312 101 101 7536X JZ $FOPE1 NOT ALREADY OPEN
7537X
7538X *          ALREADY OPEN. SQUACK
7539X
101.072 301 7540X POP B RESTORE (BC)
101.073 361 7541X POP PSW DISCARD NEW FLAGS

```

\$FOPE

```

101.074 341      7542X      POP      H      (HL) = FB ADDRESS
101.075 076 031 7543X      MVI      A,EC,FAO  FILE ALREADY OPEN
101.077 067      7544X      STC
101.100 311      7545X      RET
                7546X
000.000      7547X      ERRNZ   FB,FWA-FB,FLG-1
101.101 043      7548X $FOPE1 INX      H      (HL) = #FB,FWA
101.102 116      7549X      MOV      C,M
101.103 043      7550X      INX      H
101.104 106      7551X      MOV      B,M      (BC) = FB,FWA
101.105 043      7552X      INX      H
000.000      7553X      ERRNZ   FB,PTR-FB,FWA-2
101.106 161      7554X      MOV      M,C      SET FB,PTR = FB,FWA
101.107 043      7555X      INX      H
101.110 160      7556X      MOV      M,B
101.111 043      7557X      INX      H
000.000      7558X      ERKNZ   FB,LIM-FB,PTR-2
101.112 161      7559X      MOV      M,C      SET FB,LIM = FB,FWA
101.113 043      7560X      INX      H
101.114 160      7561X      MOV      M,B
101.115 043      7562X      INX      H
000.000      7563X      ERKNZ   FB,NAM-FB,LIM-4
101.116 043      7564X      INX      H
101.117 043      7565X      INX      H      (HL) = #FB,NAM
                7566X
                7567X *      FILE BLOCK POINTERS SETUP, OPEN FILE
                7568X
101.120 345      7569X      PUSH    H      SAVE NEW ADDRESS FOR NAME
101.121 041 152 101 7570X      LXI    H,$FOPE
101.124 247      7571X      ANA    A
                /78.10,6C/
101.125 312 134 101 7572X      JZ     $FOPE2
000.000      7573X      ERKNZ   .EXIT
101.130 315 371 111 7574X      CALL  $TBLS      FIND CODE
101.133 176      7575X      MOV    A,M
101.134 062 142 101 7576X $FOPE2 STA    $FOPEA      SET SYSCALL CODE
101.137 341      7577X      POP    H      (HL) = #FB,NAM
101.140 361      7578X      POP    PSW      (A) = CHANNEL NUMBER
101.141 377 000      7579X      DB     SYSCALL,.EXIT
101.142      7580X $FOPEA EQU    *-1      SYSCALL CODE
101.143 321      7581X      POP    D      (D) = NEW FLAG
101.144 341      7582X      POP    H      (HL) = FILE BLOCK ADDRESS
101.145 330      7583X      RC     EXIT IF ERROR
101.146 043      7584X      INX    H
000.000      7585X      ERKNZ   FR,FLG-1
101.147 162      7586X      MOV    M,D      SET NEW FLAGS
101.150 053      7587X      DCX    H      RESTORE (HL)
101.151 311      7588X      RET
                7589X
101.152 002 042      7590X $FOPEB DB     FT,OR,.OPENR  TABLE OF SYSCALL CODES
101.154 004 043      7591X      DB     FT,OW,.OPENW
101.156 006 044      7592X      DB     FT,OR+FT,OW,.OPENU
101.160 000      7593X      DB     0      SHOULD NOT OCCUR
101.161      7594      XTEXT  FREAL

```

```

7596X **      $FREAL - READ BYTES FROM FILE BUFFER,
7597X *
7598X *      $FREAL IS CALLED TO READ A NUMBER OF BYTES FROM A FILE BUFFER.
7599X *
7600X *      ENTRY      (BC) = BYTE COUNT
7601X *                (DE) = FWA FOR BYTES
7602X *                (HL) = ADDRESS OF FILE BUFFER
7603X *      EXIT      TO *FEERROR* IF ERROR
7604X *                TO CALLER IF OK
7605X *                (BC) = UNREAD BYTE COUNT (ONLY IF EOF)
7606X *                (DE) = ADDRESS OF FIRST UNUSED BYTE
7607X *                'C' SET IF EOF DURING READ
7608X *      USES      A,F,B,C,D,E
7609X
7610X
101.161 315 174 101 7611X $FREAL CALL $FREAL
101.164 320          7612X RNC          RETURN IF OK
101.165 376 001     7613X CFI          EC,EOF
101.167 302 223 070 7614X JNE          $FEERROR  ERROR IS NOT EOF
101.172 067        7615X STC
101.173 311        7616X RET          ERROR IS SIMPLY EOF
7617X
7618X
101.174          7619X $FREAL EQU *
101.174 013       7620X DCX      B          (BC) = COUNT NOT INCLUDING 00 BYTE
101.175 257       7621X XRA      A
101.176 042 214 103 7622X STA      EOFFLB  CLEAR EOF FLAG
101.201 345       7623X PUSH     H
101.202 315 042 103 7624X CALL     CBT      COPY BUFFER POINTERS TO TEMP CELLS
7625X
7626X *          COPY DATA FROM BUFFER TO TARGET
7627X
101.205 325       7628X $REAL2 PUSH    D          SAVE TARGET ADDRESS
101.206 072 205 103 7629X LDA      T,FLG
101.211 346 002     7630X ANI      FT,DR
101.213 076 011     7631X MVI      A,EC,FND
101.215 067        7632X STC          ASSUME FILE NOT OPEN
101.216 312 352 101 7633X JZ      $REALB  ERROR
101.221 170        7634X MOV      A,B
101.222 261        7635X ORA      C
101.223 312 352 101 7636X JZ      $REALB  ALL DONE
7637X
7638X *          COMPUTE MIN( DATA IN BUFFER, DATA REQUESTED)
7639X
101.226 052 210 103 7640X $REAL3 LHLD   T,PTR
101.231 353        7641X XCHG
101.232 052 212 103 7642X LHLB   T,LIM  (DE) = (FB,PTR) = ADDRESS OF DATA
101.235 175        7643X MOV     A,L    (HL) = LIMIT ADDRESS
101.236 223        7644X SUB     E
101.237 157        7645X MOV     L,A
101.240 174        7646X MOV     A,H
101.241 232        7647X SBB     D
101.242 147        7648X MOV     H,A
101.243 171        7649X MOV     A,C  (HL) = NUMBER OF BYTES IN BUFFER
101.244 225        7650X SUB     L    COMPARE TO REQUESTED COUNT
101.245 170        7651X MOV     A,B

```

\$FREAL

```

101.246 234      7652X      SBB      H
101.247 322 254 101 7653X      JNC      $REAL4      LESS THAN REQUESTED COUNT
101.252 140      7654X      MOV      H,B
101.253 151      7655X      MOV      L,C      DONT TRANSFER MORE THAN LIMIT
101.254 174      7656X $REAL4  MOV      A,H
101.255 265      7657X      ORA      L
101.256 302 272 101 7658X      JNZ      $REAL6      SOME IN BUFFER
7659X
7660X *      BUFFER IS EMPTY. RE-FILL IT
7661X
101.261 315 122 103 7662X      CALL     $FFB      FILL FILE BUFFER
101.264 332 352 101 7663X      JC       $REAL8      ERROR CONDITION
101.267 303 226 101 7664X      JMP      $REAL3      COUNT THE DATA
7665X
7666X *      GOT THE DATA. MOVE IT FROM BUFFER TO TARGET
7667X *
7668X *      (BC) = LIMIT COUNT
7669X *      (DE) = FROM
7670X *      (HL) = COUNT
7671X *      ((SP)) = TO
7672X
101.272 171      7673X $REAL6  MOV      A,C
101.273 225      7674X      SUB      L
101.274 117      7675X      MOV      C,A
101.275 170      7676X      MOV      A,B
101.276 234      7677X      SBB      H
101.277 107      7678X      MOV      B,A
101.300 305      7679X      PUSH    B      REMOVE BYTES ABOUT TO BE MOVED FROM REQUEST COUNT
101.301 343      7680X      XTHL
101.302 301      7681X      POP      B      (HL) = REMAINING REQUEST COUNT
101.303 343      7682X      XTHL      (BC) = COUNT FOR THIS COPY
101.304 032      7683X $REAL7  LDAX    D      (HL) = TARGET ADDR, ((SP)) = REMAINING REQ. COUNT
101.305 023      7684X      INX      D
101.306 167      7685X      MOV      M,A
101.307 043      7686X      INX      H
101.310 247      7687X      ANA      A
101.311 302 320 101 7688X      JNZ      $REL7.3      SEE IF 00 BYTE NOT 00
7689X
7690X *      IS 00 BYTE. IGNORE IT
7691X
101.314 343      7692X      XTHL
101.315 043      7693X      INX      H      ADD ONE TO UNREQUESTED COUNT
101.316 343      7694X      XTHL
101.317 053      7695X      DCX     H      BACKSPACE OVER CHARACTER
101.320 013      7696X $REL7.3  DCX     B
101.321 376 012      7697X      CPI     NL
101.323 312 343 101 7698X      JE       $REL7.5      IS END OF LINE
101.326 170      7699X      MOV      A,B
101.327 261      7700X      ORA      C
101.330 302 304 101 7701X      JNZ      $REAL7      MORE TO GO
101.333 353      7702X      XCHG
101.334 042 210 103 7703X      SHLD   T,PTR      UPDATE POINTER
101.337 301      7704X      POP      B      (BC) = REMAINING COUNT
101.340 303 205 101 7705X      JMP      $REAL2      SEE IF MORE IN BUFFER
7706X
7707X *      END OF CODED LINE

```

```

7708X
101.343 353 7709X $REL7.5 XCHG
101.344 033 7710X DCX D BACK OVER NL CHARACTER
101.345 042 210 103 7711X SHLD T.PTR UPDATE POINTER
101.350 301 7712X POP B (BC) = REMAINING COUNT
101.351 325 7713X PUSH D SAVE TARGET LWA
7714X
7715X * READ COMPLETE.
7716X *
7717X * (PSW) = COMPLETION FLAGS
7718X
101.352 321 7719X $REALR POP D RESTORE TARGET ADDRESS
101.353 365 7720X PUSH PSW SAVE RETURN CODE
101.354 257 7721X XRA A
101.355 022 7722X STAX D FLAG END OF LINE
101.354 341 7723X POP PSW RESTORE RESULT FLAGS
101.357 023 7724X INX D POINT TO NEXT FREE
101.360 341 7725X $REAL9 POP H
101.361 303 070 103 7726X JMP CTB COPY TEMP POINTERS BACK TO BLOCK, EXIT
101.364 7727X XTEXT FREAD

```

```

7729X ** $FREAD - READ ONE BYTE FROM FILE BUFFER.
7730X *
7731X * $FREAD IS CALLED TO READ ONE BYTE FROM A FILE BUFFER.
7732X *
7733X * ENTRY (HL) = ADDRESS OF FILE BUFFER
7734X * EXIT TO $FERROR* IF ERROR
7735X * TO CALLER IF OK
7736X * (A) = CHARACTER
7737X * 'C' SET IF EOF DURING READ
7738X * USES A,F,B,C,D,E
7739X
7740X

```

```

101.364 315 377 101 7741X $FREAD CALL $FREAD.
101.367 320 7742X RNC RETURN IF OK
101.370 376 001 7743X CPI EC,EOF
101.372 302 223 070 7744X JNE $FERROR ERROR IS NOT EOF
101.375 067 7745X STC
101.376 311 7746X RET ERROR IS SIMPLY EOF
7747X
7748X
101.377 7749X $FREAD EQU *
101.377 257 7750X XRA A
102.000 062 216 103 7751X STA EOF,FLG CLEAR EOF FLAG
102.003 345 7752X PUSH H
102.004 315 042 103 7753X CALL CBT COPY BUFFER POINTERS TO TEMP CELLS
102.007 052 212 103 7754X $READ1 LHL D T,LIM
102.012 353 7755X XCHG
102.013 052 210 103 7756X LHL D T,PTR
102.016 315 216 030 7757X CALL $CDEHL SEE IF ANY TO READ
102.021 302 035 102 7758X JNE $READ2 GOT DATA
102.024 315 122 103 7759X CALL $FFB FILL FILE BUFFER
102.027 332 043 102 7760X JC $READ3 ERROR CONDITION

```

COMMON DECKS

#FREAO

15:47:49 16-MAY-80

```

102.032 303 007 102 7761X JMP #REAO1 TRY AGAIN
7762X
102.035 176 7763X #READ2 MOV A,H (A) = CHARACTER
102.036 247 7764X ANA A CLEAR CARRY
102.037 043 7765X INX H
102.040 042 210 103 7766X SHLD T, PTR
7767X
7768X * READ COMPLETE
7769X *
7770X * (FSW) = COMPLETION FLAGS
7771X
102.043 341 7772X #REAO8 POP H
102.044 303 070 103 7773X JMP CTB COPY TEMP POINTERS BACK TO BLOCK, EXIT
102.047 7774X XTEXT FWRIB

7776X ** #FWRIB - WRITE BYTES FROM FILE BUFFER.
7777X *
7778X * #FWRIB IS CALLED TO WRITE A NUMBER OF BYTES FROM A FILE BUFFER.
7779X *
7780X * ENTRY (BC) = BYTE COUNT
7781X * (DE) = FWA FOR BYTES
7782X * (HL) = ADDRESS OF FILE BUFFER
7783X * EXIT TO *FERROR* IF ERROR
7784X * TO CALLER IF OK
7785X * (DE) = ADDRESS OF FIRST UNWRITTEN BYTE
7786X * USES A,F,B,C,D,E
7787X
7788X
102.047 315 056 102 7789X #FWRIB CALL #FWRIB.
102.052 320 7790X RNC RETURN IF OK
102.053 303 223 070 7791X JMP #FERROR ERROR
7792X
7793X
102.056 7794X #FWRIB. EQU *
102.056 345 7795X PUSH H
102.057 315 042 103 7796X CALL CRT COPY BUFFER POINTERS TO TEMP CELLS
7797X
7798X * COPY DATA FROM USER AREA TO BUFFER
7799X
102.062 325 7800X #WRIB2 PUSH D SAVE AREA ADDRESS
102.063 072 205 103 7801X LDA T, FLG
102.066 346 004 7802X ANI FT, OW SEE IF OPEN FOR WRITE
102.070 312 224 102 7803X JZ #WRIBB FILE NOT OPEN FOR WRITE
102.073 170 7804X MOV A, B
102.074 241 7805X ORA C
102.075 312 224 102 7806X JZ #WRIBB ALL DONE
7807X
7808X * COMPUTE MIN( ROOM IN BUFFER, WRITE COUNT REQUESTED)
7809X
102.100 052 210 103 7810X #WRIB3 LHLD T, PTR
102.103 353 7811X XCHG (DE) = (FB, PTR) = ADDRESS OF ROOM
102.104 052 214 103 7812X LHLD T, LWA (HL) = LIMIT ADDRESS
102.107 175 7813X MOV A, L

```

COMMON DECKS.

\$FWRIB

15:47:51 16-MAY-80

```

102.110 223 7814X SUB E
102.111 157 7815X MOV L,A
102.112 174 7816X MOV A,H
102.113 232 7817X SBB B
102.114 147 7818X MOV H,A (HL) = BYTES OF ROOM IN BUFFER
102.115 171 7819X MOV A,C COMPARE REQUESTED COUNT TO BUFFER ROOM
102.116 225 7820X SUB L
102.117 170 7821X MOV A,B
102.120 234 7822X SBB H
102.121 322 126 102 7823X JNC $WRIB4 MORE REQUESTED THEN ROOM
102.124 140 7824X MOV H,B
102.125 151 7825X MOV L,C USE REQUESTED COUNT
102.126 174 7826X $WRIB4 MOV A,H
102.127 265 7827X ORA L
102.130 302 170 102 7828X JNZ $WRIB6 SOME ROOM IN BUFFER
7829X
7830X * BUFFER IS FULL, EMPTY IT
7831X
7832X
102.133 305 7832X PUSH B SAVE COUNT
102.134 052 206 103 7833X LHLD T,FWA
102.137 042 210 103 7834X SHLD T,PTR CLEAR REMOVAL POINTER
102.142 353 7835X XCHG
102.143 052 214 103 7836X LHLD T,LWA
102.146 175 7837X MOV A,L
102.147 223 7838X SUB E
102.150 117 7839X MOV C,A
102.151 174 7840X MOV A,H
102.152 232 7841X SBB R
102.153 107 7842X MOV B,A (BC) = DATA IN BUFFER
102.154 072 20A 103 7843X LDA T,CHA
102.157 377 005 7844X DB SYSCALL,WRITE WRITE BUFFER
102.161 301 7845X POP R (BC) = DESIRED COUNT
102.162 322 100 102 7846X JNC $WRIB3 GOT THE DATA
7847X
7848X * ERROR ON WRITE.
7849X
102.165 303 224 102 7850X JMP $WRIB8 HAVE ERROR
7851X
7852X * GOT THE DATA, MOVE IT FROM BUFFER TO TARGET
7853X *
7854X * (BC) = REQUEST COUNT
7855X * (DE) = TO
7856X * (HL) = COUNT
7857X * ((SP)) = FROM
7858X
102.170 171 7859X $WRIB6 MOV A,C
102.171 225 7860X SUB L
102.172 117 7861X MOV C,A
102.173 170 7862X MOV A,B
102.174 234 7863X SBB H
102.175 107 7864X MOV B,A REMOVE BYTES ABOUT TO BE MOVED FROM REQUEST COUNT
102.176 305 7865X PUSH B
102.177 343 7866X XTHL (HL) = REMAINING REQUEST COUNT
102.200 301 7867X POP R (BC) = COUNT FOR THIS COPY
102.201 343 7868X XTHL (HL) = TARGET ADDR, ((SP)) = REMAINING REQ. COUNT
102.202 176 7869X $WRIB7 MOV A,H

```


COMMON DECKS:

*FWRIB

15:47:53 16-MAY-80

```

102.203 022      7870X      STAX  D
102.204 023      7871X      INX   D
102.205 043      7872X      INX   H
102.206 013      7873X      DCX   B
102.207 170      7874X      MOV   A,E
102.210 261      7875X      ORA   C
102.211 302 202 102 7876X      JNZ   $WRIB7      MORE TO GO
102.214 353      7877X      XCHG
102.215 042 210 103 7878X      SHLD  T,PTR      UPDATE POINTER
102.220 301      7879X      POP   B           (BC) = REMAINING COUNT
102.221 303 062 102 7880X      JMP   $WRIB2      SEE IF MORE IN BUFFER
7881X
7882X *          WRITE COMPLETE.
7883X *
7884X *          (PSW) = COMPLETION FLAGS
7885X
102.224 321      7886X $WRIB8 POP   D           RESTORE TARGET ADDRESS
102.225 341      7887X      POP   H
102.226 303 070 103 7888X      JMP   CTR        COPY TEMP POINTERS BACK TO BLOCK, EXIT
    
```

```

7890X **        $FWBRK - BREAKOUTPUT                               /80.02.GC/
7891X *
7892X *          $FWBRK empties the specified buffer by filling it with NULLs
7893X *          and then writing it. Note this is used to insure that block
7894X *          mode I/O is output if it is not really a serial device (eg.
7895X *          writing to AT: from *EDIT*).
7896X *
7897X *
7898X *          ENTRY: HL      = FILE BLOCK POINTER
7899X *
7900X *          EXIT:  HL      = FILE BLOCK POINTER
7901X *          TO $FERROR IF ERROR
7902X *
7903X *          USES:  PSW,BC,DE
7904X *
7905X
102.231 315 240 102 7906X $FWBRK CALL  $FWBRK.
102.234 320      7907X      RNC           NO ERROR
7908X
102.235 303 223 070 7909X      JMP   $FERROR
7910X
102.240 345      7911X $FWBRK. PUSH  H
102.241 315 042 103 7912X      CALL  CBT      COPY BUFFER TO TEMPORARY
102.244 315 254 102 7913X      CALL  $FWBRK1
102.247 341      7914X      POP   H
102.250 315 070 103 7915X      CALL  CTR      COPY TEMPORARY TO BUFFER
102.253 311      7916X      RET
7917X
102.254 052 214 103 7918X $FWBRK1 LHLD  T,LWA
102.257 353      7919X      XCHG          DE = BUFFER LWA
102.260 052 210 103 7920X      LHLD  T,PTR   HL = BUFFER PTR
102.263 173      7921X      MOV   A,E
102.264 225      7922X      SUB   L
    
```

```

102.265 117      7923X      MOV      C,A
102.266 172      7924X      MOV      A,B
102.267 234      7925X      SBB      H
102.270 107      7926X      MOV      B,A      BC = DE - HL
102.271 261      7927X      ORA      C
102.272 310      7928X      RZ          THE BUFFER IS ALREADY FLUSHED
              7929X
              7930X *      FILL THE BUFFER WITH NULLS
              7931X
102.273 170      7932X FWBRK2 MOV      A,B
102.274 261      7933X      ORA      C
102.275 312 307 102 7934X      JZ          FWBRK3      NO MORE LEFT TO FILL
              7935X
102.300 066 000 7936X      MVI      M,0
102.302 043      7937X      INX      H
102.303 013      7938X      DCX      B
102.304 303 273 102 7939X      JMP      FWBRK2
              7940X
102.307 052 206 103 7941X FWBRK3 LHL     T,FWA
102.312 042 210 103 7942X      SHLD    T,PTR
102.315 353      7943X      XCHG
              DE = BUFFER FWA
              HL = BUFFER LWA
102.316 052 214 103 7944X      LHL     T,LWA
102.321 175      7945X      MOV      A,L
102.322 223      7946X      SUB      E
102.323 117      7947X      MOV      C,A
102.324 174      7948X      MOV      A,H
102.325 232      7949X      SBB      D
102.326 107      7950X      MOV      B,A      BC = HL - DE ( BC = COUNT )
102.327 072 204 103 7951X      LDA      T,CHA
102.332 377 005 7952X      DB      SYSCALL,WRITE
102.334 311      7953X      RET
102.335      7954      XTEXT   FCLO

```

```

7956X **      %FCLO - CLOSE FILE BLOCK.
7957X *
7958X *      %FCLO IS CALLED TO TERMINATE PROCESSING THROUGH A FILE
7959X *      BLOCK.
7960X *
7961X *      ENTRY (HL) = FILE BLOCK ADDRESS
7962X *      EXIT TO %FERROR IF ERROR
7963X *           TO CALLER IF OK
7964X *      USES A,F,B,C,D,E
7965X
7966X
102.335 315 344 102 7967X %FCLO CALL  %FCLO.
102.340 320      7968X      RNC          NO ERROR
102.341 303 223 070 7969X      JMP      %FERROR
              7970X
102.344 345      7971X %FCLO, PUSH  H          SAVE FILE BLOCK ADDRESS
000.000      7972X      ERRNZ  FB,FLG-1
102.345 043      7973X      INX      H          (HL) = %FB,FLG
102.346 176      7974X      MOV      A,M
102.347 066 000 7975X      MVI      M,0      CLEAR FLAG

```

COMMON DECKS:

*FCLO

15:48:00 16-MAY-80

```

102.351 247 7976X ANA A
102.352 312 040 103 7977X JZ $FCLO4 FILE NOT OPEN
102.355 346 004 7978X ANI FT.0W
102.357 312 032 103 7979X JZ $FCLO3 NO WRITING, NO FLUSHING NEEDED
7980X
7981X * WAS OPEN FOR WRITE, SEE IF NEED FLUSH THE LAST SECTOR
7982X
102.362 315 234 030 7983X CALL $INDL
102.365 003 000 7984X DW FB.PTR-FB.FLG
102.367 325 7985X PUSH D SAVE (FB.FTR)
102.370 315 234 030 7986X CALL $INDL (DE) = (FB.FWA)
102.373 001 000 7987X DW FB.FWA-FB.FLG
102.375 341 7988X POP H (HL) = (FB.PTR)
102.376 175 7989X MOV A,L
102.377 223 7990X SUB E
103.000 117 7991X MOV C,A
103.001 174 7992X MOV A,H
103.002 232 7993X SBB D
103.003 107 7994X MOV B,A (BC) = AMOUNT IN BLOCK
103.004 261 7995X ORA C
103.005 312 032 103 7996X JZ $FCLO3 NONE TO FLUSH
7997X
7998X * NEED TO FLUSH BUFFER
7999X *
8000X * (BC) = DATA AMOUNT
8001X * (DE) = FWA
8002X * (HL) = LWA+1
8003X
103.010 171 8004X MOV A,C
103.011 247 8005X ANA A
103.012 312 025 103 8006X JZ $FCLO2 DONT HAVE PARTIAL SECTOR
8007X
8008X * ZERO FILL PARTIAL SECTOR
8009X
103.015 066 000 8010X $FCLO1 MVI M,0
103.017 043 8011X INX H
103.020 014 8012X INR C
103.021 302 015 103 8013X JNZ $FCLO1
103.024 004 8014X INR B COUNT ANOTHER FULL SECTOR
103.025 341 8015X $FCLO2 POP H (HL) = FB.FWA
103.026 176 8016X MOV A,M (A) = CHANNEL NUMBER
000.000 8017X ERRNZ FB.CHA
103.027 345 8018X PUSH H
103.030 377 005 8019X DB SYSCALL,WRITE FLUSH
8020X
8021X * READY TO CLOSE FILE.
8022X *
8023X * 'C' SET IF ERROR
8024X * (A) = ERROR CODE
8025X
103.032 341 8026X $FCLO3 POP H (HL) = FILE BLOCK ADDRESS
103.033 330 8027X RC ERROR
000.000 8028X ERRNZ FB.CHA
103.034 176 8029X MOV A,M (A) = CHANNEL NUMBER
103.035 345 8030X PUSH H
103.036 377 046 8031X DB SYSCALL,CLOSE CLOSE CHANNEL

```

103.040 341 8032X \$FCLO4 POP H (HL) = FILE BLOCK ADDRESS
103.041 311 8033X RET
103.042 8034 XTEXT FUTIL

8036X ** \$FUTIL - UTILITY ROUTINES FOR FILE BLOCK ROUTINES.

8037X

8038X ** CBT - COPY BLOCK POINTERS TO TEMP CELLS.

8039X *

8040X * ENTRY (HL) = FILE BLOK FWA

8041X * EXIT NONE

8042X * USES A,F,H,L

8043X

103.042 325 8044X CBT PUSH D

103.043 305 8045X PUSH B SAVE REGISTERS

000.000 8046X ERRNZ ILEN-10 ASSUME 10 BYTES TO MOVE

103.044 021 204 103 8047X LXI D,T,CHA (DE) = TARGET FOR MOVE

103.047 006 005 8048X MVI B,10/2

103.051 176 8049X CBT1 MOV A,M COPY FILE BUFFER INTO WORK AREA

103.052 022 8050X STAX D

103.053 043 8051X INX H

103.054 023 8052X INX D

103.055 176 8053X MOV A,M

103.056 022 8054X STAX D

103.057 043 8055X INX H

103.060 023 8056X INX D

103.061 005 8057X DCR B

103.062 302 051 103 8058X JNZ CBT1 MORE TO GO

103.065 301 8059X POP B

103.066 321 8060X POP D (DE) = DATA TARGET ADDRESS

103.067 311 8061X RET

8062X

8063X

8064X ** CTR - COPY TEMP CELLS BACK TO FILE BLOCK,

8065X *

8066X * ENTRY (HL) = FILE BLOCK ADDRESS

8067X * EXIT NONE

8068X * USES NONE

8069X

103.070 365 8070X CTR PUSH PSW

103.071 325 8071X PUSH D

103.072 305 8072X PUSH B

103.073 345 8073X PUSH H SAVE REGISTERS

103.074 006 004 8074X MVI B,8/2

103.076 021 204 103 8075X LXI D,T,CHA

103.101 032 8076X CTR1 LDAX D

103.102 167 8077X MOV M,A

103.103 023 8078X INX D

103.104 043 8079X INX H

103.105 032 8080X LDAX D

103.106 167 8081X MOV M,A

103.107 023 8082X INX D

103.110 043 8083X INX H

103.111 005 8084X DCR B

```

103.112 302 101 103 8085X      JNZ      CTBI      RESTORE FILE BUFFER VALUES
103.115 341          8086X      POP      H
103.116 301          8087X      POP      R
103.117 321          8088X      POP      B
103.120 361          8089X      POP      PSW
103.121 311          8090X      RET

```

```

8092X **      $FFB - FILE FILE BUFFER.
8093X *
8094X *      $FFB FILLS THE FILE BUFFER BY READING FROM THE FILE.
8095X *
8096X *      ENTRY  NONE
8097X *      EXIT   'C' SET IF READ INCOMPLETE
8098X *              (A) = ERROR CODE
8099X *              'C' CLEAR IF READ COMPLETEE
8100X *      DATA IN BUFFER
8101X *      USES   A>F,D>E>H>L
8102X
8103X

```

```

103.122 072 216 103 8104X $FFB LDA      EOFFLG
103.125 037          8105X      RAR
103.126 330          8106X      RC          EOF
8107X
8108X *      CAN READ MORE. DO SO
8109X
103.127 305          8110X      PUSH     B          SAVE COUNT
103.130 052 206 103 8111X      LHL     T,FWA
103.133 042 210 103 8112X      SHLD   T,FTR      CLEAR REMOVAL POINTER
103.136 353          8113X      XCHG
103.137 052 214 103 8114X      LHL     T,LWA
103.142 042 212 103 8115X      SHLD   T,LIM      SET DATA LIMIT
103.145 175          8116X      MOV     A>L
103.146 223          8117X      SUB     E
103.147 117          8118X      MOV     C>A
103.150 174          8119X      MOV     A>H
103.151 232          8120X      SBB     D
103.152 107          8121X      MOV     B>A      (BC) = ROOM IN BUFFER
103.153 072 204 103 8122X      LDA     T,CHA
103.156 377 004      8123X      DR      SYSCALL,READ READ BUFFER
103.160 120          8124X      MOV     D>B      (D) = SECTORS UNREAD
103.161 301          8125X      POP     B      (BC) = DESIRED COUNT
103.162 320          8126X      RNC          GOT THE DATA
8127X

```

```

8128X *      ERROR ON READ. SEE IF EOF
8129X

```

```

103.163 027          8130X      RAL
103.164 062 216 103 8131X      STA     EOFFLG      SET EOF, WE HOPE
103.167 376 003      8132X      CPI     EC:EOF*2+1
103.171 037          8133X      RAR
103.172 300          8134X      RNE          IS NOT EOF, RETURN NOW!
103.173 072 213 103 8135X      LDA     T,LIM+1
103.176 222          8136X      SUB     D
103.177 062 213 103 8137X      STA     T,LIM+1      SET AMOUNT OF DATA WE DID GET

```

```

103.203 247      8138X      ANA      A
103.203 311      8139X      RET              EXIT WITH DATA
                  8140X
                  8141X
103.204 000      8142X **      TEMP CELLS TO HOLD FILE BLOCK POINTERS DURING I/O
                  8143X
000.000          8144X      ERRNZ      FB.CHA
103.204 000      8145X T.CHA      DB              CHANNEL NUMBER
000.000          8146X      ERRNZ      *-T.CHA-FB.FLG
103.205 000      8147X T.FLG      DB              FLAG BYTE
000.000          8148X      ERRNZ      *-T.CHA-FB.FWA
103.206 000 000  8149X T.FWA      DW              0
000.000          8150X      ERRNZ      *-T.CHA-FB.FTR
103.210 000 000  8151X T.PTR      DW              0
000.000          8152X      ERRNZ      *-T.CHA-FB.LIM
103.212 000 000  8153X T.LIM      DW              0
000.000          8154X      ERRNZ      *-T.CHA-FB.LWA
103.214 000 000  8155X T.LWA      DW              0
000.012          8156X TLEN      EQU          *-T.CHA          LENGTH OF TEMP CELLS
                  8157X
103.216 000      8158X EOFFL6   DB              0
103.217          8159X XTEXT      TYPCC

```

```

8161X **          $TYPCC - TYPE A CHARACTER STRING BY COUNT.
8162X *
8163X *          $TYPCC TYPES A STRING OF CHARACTERS. THE CALLER SUPPLIES
8164X *          THE CHARACTER ADDRESS AND COUNT.
8165X *
8166X *          ENTRY (HL) = ADDRESS
8167X *          (A) = COUNT
8168X *          EXIT (HL) = LAST CHARACTER ADDRESS+1
8169X *          USES A,F,H,L
8170X
8171X
103.217          8172X $TYPCC EQU          *
103.217 247      8173X ANA          A
103.220 310      8174X RZ              NOTHING TO TYPE
103.221 365      8175X PUSH      PSW          SAVE COUNT
103.222 176      8176X MOV        A,M          (A) = CHARACTER
103.223 043      8177X INX              H
103.224 377 002  8178X DB          SYSCALL, SCAUT
103.226 361      8179X POP        PSW
103.227 075      8180X ICR          A
103.230 303 217 103 8181X JMP          $TYPCC
103.233          8182 XTEXT      RCHAR

```

\$RCHAR

15:48:18 16-MAY-80

```

.....
      8184X **      $RCHAR - READ SINGLE CHARACTER FROM CONSOLE.
      8185X *
      8186X *      ENTRY NONE
      8187X *      EXIT (A) = CHARACTER
      8188X *      USES A,F
      8189X
      8190X
103,233 377 001      8191X $RCHAR DB      SYSCALL, SCIN
103,235 332 233 103 8192X      JC      $RCHAR      NOT READY
103,240 311      8193X      RET
      8194X
103,241 377 002      8195X $WCHAR DB      SYSCALL, SCOUT
103,243 311      8196X      RET
      8197      LON      C
103,244      8198      XTEXT  ATS
.....

      8200X **      $ATS - ALLOCATE TABLE SPACE.
      8201X *
      8202X *      ATS IS CALLED TO ALLOCATE ADDITIONAL SPACE TO A MANAGED TABLE.
      8203X *
      8204X *      IF NO MOVING IS REQUIRED, $ATS REQUIRES ABOUT 150 MICROSECONDS.
      8205X *
      8206X *      ENTRY (HL) = BYTES TO ALLOCATE
      8207X *      (DE) = ADDRESS OF TABLE INDEX+1
      8208X *      EXIT      SPACE ALLOCATED (IF ENOUGH ROOM)
      8209X *      TO *ERR,TO* IF NO MORE ROOM
      8210X *      USES      A,F,H,L
      8211X
      8212X
103,244      8213X $ATS  EQU      *      ENTRY POINT
103,244 305      8214X      PUSH  B      SAVE REGISTERS
103,245 325      8215X      PUSH  D
103,246 345      8216X      PUSH  H
103,247 353      8217X      XCHG
      8218X      SHLD  ATSA      (DE) = BN (BYTES NEEDED)
103,250 042 356 103 8219X      MOV   C,M      SAVE FOR LATER
103,253 116      8220X      INX   H
103,254 043      8221X      MOV   B,M      (BC) = TFWA (TABLE FWA)
103,255 106      8222X      INX   H
103,256 043      8223X      PUSH  B      SAVE TFWA
103,257 305      8224X      MOV   C,M
103,260 116      8225X      INX   H
103,261 043      8226X      MOV   B,M      (BC) = TL (TABLE LENGTH)
103,262 106      8227X      INX   H
103,263 043      8228X      XCHG      (HL) = BN
103,264 353      8229X      DAD   B      (HL) = NEW TABLE LENGTH
103,265 011      8230X      MOV   B,H
103,266 104      8231X      MOV   C,L      (BC) = NEW TABLE LENGTH
103,267 115      8232X      POP   H
103,270 341      8233X      DAD   B      (HL) = NEW TABLE LWA
103,271 011      8234X      JC      ATSI
103,272 332 321 103 8235X      XCHG      (DE) = NEW LWA, (HL) = INDEX ENTRY ADDRESS
103,275 353      8236X      INX   H      SPACE OVER ALLOCATION FACTOR
.....

```

*ATS

```

103.277 173      8237X      MOV      A,E
103.300 226      8238X      SUB      M          COMPARE NEW LWA WITH NEXT TABLE FWA
103.301 043      8239X      INX      H
103.302 172      8240X      MOV      A,D
103.303 236      8241X      SBB     M
103.304 322 321 103 8242X      JNC     AT51      OVERFLOW
103.304 322 321 103 8243X
103.304 322 321 103 8244X *      HAVE ENOUGH ROOM WITHOUT TABLE MOVES. UPDATE INDEX
103.304 322 321 103 8245X
103.307 053      8246X      DCX     H
103.310 053      8247X      DCX     H
103.311 053      8248X      DCX     H
103.312 160      8249X      MOV     M,B      SET NEW LENGTH
103.313 053      8250X      DCX     H
103.314 161      8251X      MOV     M,C
103.315 341      8252X      POP     H          RESTORE REGISTERS
103.316 321      8253X      POP     D
103.317 301      8254X      POP     B
103.320 311      8255X      RET

8257X **      THE TABLE OVERFLOWED IT'S FREE SPACE. REALLOCATE FREE SPACE
8258X *      AMONG STACKS.
8259X *
8260X *      (ATSA) = TABLE INDEX FWA
8261X *      (STACK TOP) = BN (BYTES NEEDED)
8262X
103.321 315 127 104 8263X AT51  CALL    MTD      MOVE TABLES DOWN
103.324 041 012 000 8264X      LXI     H,10
103.327 031      8265X      DAD     D
103.330 321      8266X      POP     D
103.331 325      8267X      PUSH    D          (DE) = BN
103.332 031      8268X      DAD     D
103.333 332 160 070 8269X      JC      ERR.TO    TABLE OVERFLOW
103.336 353      8270X      XCHG
103.337 052 127 112 8271X      LHLD   MEML      (HL) = MEMORY LIMIT ADDRESS
103.342 173      8272X      MOV     A,E
103.343 225      8273X      SUB     L
103.344 157      8274X      MOV     L,A
103.345 172      8275X      MOV     A,I
103.346 234      8276X      SBB     H
103.347 147      8277X      MOV     H,A      (HL) = -SPACE LEFT
103.350 322 160 070 8278X      JNC     ERR.TO    TABLE OVERFLOW
103.350 322 160 070 8279X
103.350 322 160 070 8280X *      THE ROOM EXISTS. ADD REQUESTED SPACE TO PROPER TABLE.
103.350 322 160 070 8281X
103.353 301      8282X      POP     B          (BC) = BN (BYTES NEEDED)
103.354 345      8283X      PUSH    H          SAVE -(SPACE LEFT)
103.355 041 000 000 8284X      LXI     H,0      (HL) = TABLE INDEX FWA
103.356 043      8285X      EQU     *-2
103.360 043      8286X      INX     H
103.361 043      8287X      INX     H
103.362 136      8288X      MOV     E,M
103.363 043      8289X      INX     H
103.364 126      8290X      MOV     D,M      (DE) = CURRENT SIZE
103.365 353      8291X      XCHG

```



```

103.366 011      8292X      DAD      B
103.367 353      8293X      XCHG
103.370 162      8294X      MOV      M,D      (DE) = NEW SIZE
103.371 053      8295X      DCX      H
103.372 163      8296X      MOV      M,E      SET NEW SIZE
8297X
8298X *
8299X *
8300X *
8301X *
8302X *
103.373 301      8303X      POP      B      (B) = -(SPACE LEFT)
103.374 046 003  8304X      MOV      H,3      DIVIDE BY 8
8305X
8306X *
8307X
8308X AT52
103.376 067      8309X      MOV      A,B
103.377 170      8310X      RAR
104.000 037      8311X      MOV      B,A      SHIFT RIGHT WITH SIGN EXTEND
104.001 107      8312X      MOV      A,C
104.002 171      8313X      RAR
104.003 037      8314X      MOV      C,A
104.004 117      8315X      DCR      H
104.005 045      8316X      JNZ      AT52
104.006 302 378 103 8317X      INX      B
104.011 003      8318X      MOV      A,B      (BC) = 1/8 FREE SPACE
104.012 170      8319X      ANA      A
104.013 247      8320X      JP       ERR.TO   TABLE OVERFLOW
104.014 362 160 070 8321X
8322X *
8323X *
8324X *
8325X
104.017 072 124 104 8326X      LDA      AT5B      (A) = TABLE COUNT-1
104.022 041 130 112 8327X      LXI      H,MEML+1
104.025 126      8328X      MOV      D,M
104.026 053      8329X      DCX      H
104.027 136      8330X      MOV      E,M      (DE) = (MEML)
104.030 053      8331X      DCX      H
8332X
104.031 365      8333X AT53
104.032 305      8334X      PUSH     PSW      SAVE COUNT
8335X
104.033 053      8336X      DCX      B
104.034 106      8337X      MOV      B,M
104.035 053      8338X      DCX      H
104.036 116      8339X      MOV      C,M      (BC) = TABLE LENGTH
104.037 053      8340X      DCX      H
104.040 173      8341X      MOV      A,E
104.041 221      8342X      SUB      C
104.042 137      8343X      MOV      E,A
104.043 172      8344X      MOV      A,D
104.044 230      8345X      SBB      B
104.045 127      8346X      MOV      D,A      (DE) = MEM TOP - TABLE SIZE
104.046 053      8347X      DCX      H
104.047 053      8347X      DCX      H

```

```

104.050 176      8348X      MOV      A,M      (A) = NUMBER OF 1/8'S TO GIVE THIS TABLE
104.051 343      8349X      XTHL                      (HL) = 1/8TH -SPACE
104.052 353      8350X      XCHG                      (HL) = MEM ADDRESS
104.053 247      8351X      ANA      A
104.054 312 064 104 8352X      JZ       AT55      NO SPACE FOR THIS TABLE
104.057 031      8353X      IAD      D         DECREMENT BY FREE SPACE AMOUNT
104.060 075      8354X      DCR      A
104.061 302 057 104 8355X      JNZ      AT54      GIVE SPECIFIED NUMBER OF 1/8THS
104.064 353      8356X      XCHG      AT55      (DE) = TARGET ADDRESS
104.065 343      8357X      XTHL                      (HL) = TABLE ENTRY ADDRESS
104.066 345      8358X      PUSH     H
104.067 043      8359X      INX      H
104.070 176      8360X      MOV      A,M
104.071 163      8361X      MOV      M,E      SET NEW ADDRESS
104.072 365      8362X      PUSH     PSW
104.073 043      8363X      INX      H
104.074 176      8364X      MOV      A,M
104.075 162      8365X      MOV      M,D
104.076 147      8366X      MOV      H,A
104.077 361      8367X      POP      PSW
104.100 157      8368X      MOV      L,A
104.101 353      8369X      XCHG                      (BC) = COUNT, (DE) = FROM, (HL) = TO
104.102 345      8370X      PUSH     H
104.103 315 252 030 8371X      CALL    $MOVE      MOVE TABLE
104.106 321      8372X      POP      D         (DE) = NEW MEMORY LIMIT
104.107 341      8373X      POP      H
104.110 301      8374X      POP      B
104.111 361      8375X      POP      PSW
104.112 075      8376X      DCR      A
104.113 302 031 104 8377X      JNZ      AT53      IF MORE TABLES TO MOVE
104.116 315 071 071 8378X      CALL    $ATP      ADJUST TABLE POINTERS
104.121 321      8379X      POP      D
104.122 301      8380X      POP      B
104.123 311      8381X      RET
104.124 007      8382X
104.125 056 112 8383X AT5B  DR      MTABL-1      TABLE COUNT-1
104.125 056 112 8384X AT5C  DW      MTABIND      ADDRESS OF 1ST TABLE TO MANAGE

```

```

8386X **      MTD - MOVE TABLES DOWN.
8387X *
8388X *      MTD IS CALLED TO MOVE ALL THE MANAGED TABLES DOWN INTO THE LOW
8389X *      PART OF THE MEMORY AREA, SO THAT ALL OF THE FREE SPACE IS CONCEN
8390X *      AFTER THE LAST TABLE.
8391X *
8392X *      ENTRY NONE
8393X *      EXIT (DE) = FIRST FREE BYTE (LAST TABLE LWA+1)
8394X *      USES ALL
8395X
8396X
104.127 052 125 104 8397X MTD  LHLB  AT5C
104.132 072 124 104 8398X LDA   AT5C
8399X
8400X *      WONT NEED TO MOVE FIRST TABLE, FIND ITS LWA.

```

```

      B401X
104.135 043 B402X      INX      H
104.136 116 B403X      MOV      C,M
104.137 043 B404X      INX      H
104.140 106 B405X      MOV      B,M      (BC) = FWA
104.141 043 B406X      INX      H
104.142 136 B407X      MOV      E,M
104.143 043 B408X      INX      H
104.144 126 B409X      MOV      D,M      (DE) = TABLE LEN
104.145 043 B410X      INX      H
104.146 353 B411X      XCHG
104.147 011 B412X      DAD      B
104.150 353 B413X      XCHG      (DE) = TABLE LWA+1
      B414X
      B415X *      MOVE NEXT TABLE DOWN.
      B416X
104.151 365 B417X MTD1    PUSH     PSW
104.152 043 B418X      INX      H
104.153 116 B419X      MOV      C,M
104.154 163 B420X      MOV      M,E      SET NEW START ADDRESS
104.155 043 B421X      INX      H
104.156 106 B422X      MOV      B,M      (BC) = TABLE FWA
104.157 162 B423X      MOV      M,D
104.160 043 B424X      INX      H
104.161 305 B425X      PUSH     B
104.162 116 B426X      MOV      C,M
104.163 043 B427X      INX      H
104.164 106 B428X      MOV      B,M      (BC) = TABLE LENGTH
104.165 043 B429X      INX      H
104.166 343 B430X      XTHL
104.167 353 B431X      XCHG      (HL) = TABLE FWA
104.170 315 252 030 B432X      CALL     $MOVE      (DE) = FWA, (HL) = NEW ADDRESS
104.173 353 B433X      XCHG      MOVE DOWN
104.174 341 B434X      POP      H      (DE) = NEXT FREE BYTE, (HL) = INDEX POINTER
104.175 361 B435X      POP      PSW
104.176 075 B436X      DCR      A
104.177 302 151 104 B437X      JNZ     MTD1
104.202 311 B438X      RET
104.203      B439      XTEXT   DBT      EXIT

```

```

      B441X **      *DBT = DELETE BYTES FROM TABLE.
      B442X *
      B443X *      DBT DELETES BYTES FROM A MANAGED TABLE.
      B444X *
      B445X *      ENTRY (DE) = BYTES TO DELETE
      B446X *      (HL) = POINTER TO PLACE (IN TABLE) TO BEGIN DELETING (PTR
      B447X *      (RET+1, RET+2) = TABLE INDEX ADDRESS+1
      B448X *      EXIT  BYTES DELETED.
      B449X *      USES  A,F
      B450X
      B451X
104.203      B452X $DBT  EQU      *
104.203 173      B453X      MOV      A,E

```

```

104.204 057      8454X      CMA
104.205 137      8455X      MOV      E,A
104.206 172      8456X      MOV      A,D
104.207 057      8457X      CMA
104.210 127      8458X      MOV      D,A
104.211 023      8459X      INX      D      (DE) = -(BYTES TO DELETE)
104.212 067      8460X      STC      SET CARRY

```

```

8462X **      *IBT - INSERT BYTES INTO TABLE.
8463X *
8464X *      *IBT IS CALLED TO MAKE A FREE SPACE IN A MANAGED TABLE. THIS
8465X *      FREE SPACE MAY BE CREATED ANYWHERE IN A TABLE: AT THE FRONT,
8466X *      AT THE BACK, OR IN THE MIDDLE.
8467X *
8468X *      ENTRY (DE) = BYTES NEEDED (BN)
8469X *      (IF 'C' SET, DELETE BYTES)
8470X *      (HL) = POINTER TO INSERT AREA IN TABLE (PTR)
8471X *      (RET+1, RET+2) = TABLE ADDRESS
8472X *      EXIT BYTES INSERTED
8473X *      TO (RET)+2
8474X *      USES A,F
8475X
8476X

```

```

104.213 042 244 104 8477X $IBT SHLD IBTA SAVE PTR
104.216 353 8478X XCHG
104.217 343 8479X XTHL (HL) = RETURN ADDRESS
104.220 134 8480X MOV E,M
104.221 043 8481X INX H
104.222 124 8482X MOV D,M (DE) = TABLE ADDRESS
104.223 043 8483X INX H
104.224 343 8484X XTHL (HL) = BYTES NEEDED (BN)
104.225 345 8485X PUSH H SAVE ENTRY (DE)
104.226 305 8486X PUSH R
104.227 332 301 104 8487X JC IBT2 IF TO DELETE
104.232 345 8488X PUSH H SAVE BN
104.233 315 244 103 8489X CALL $ATS ALLOCATE TABLE SPACE
8490X
8491X *      MOVE (TL-PTR) BYTES FROM (IFWA+PTR) TO (IFWA+PTR+BN)
8492X *      MOVE (TL-PTR-BN) BYTES FROM (IFWA+PTR) TO (IFWA+PTR+BN)
8493X
104.236 353 8494X XCHG (HL) = TABLE ADDRESS
104.237 136 8495X MOV E,M
104.240 043 8496X INX H
104.241 126 8497X MOV D,M (DE) = TABLE FWA
104.242 043 8498X INX H
104.243 001 000 000 8499X LXI B,0 (BC) = POINTER
104.244 8500X IBTA EQU *-2
104.246 353 8501X XCHG
104.247 011 8502X DAD B (HL) = IFWA+PTR
104.250 353 8503X XCHG (DE) = IFWA+PTR
104.251 176 8504X MOV A,M
104.252 221 8505X SUB C
104.253 117 8506X MOV C,A

```

#IBT

15:48:32 16-MAY-80

104.254	043	8507X	INX	H	
104.255	176	8508X	MOV	A,M	
104.256	230	8509X	SBB	B	
104.257	107	8510X	MOV	B,A	(BC) = TL-PTR
104.260	341	8511X	POP	H	(HL) = BN
104.261	171	8512X	MOV	A,C	
104.262	225	8513X	SUB	L	
104.263	117	8514X	MOV	C,A	
104.264	170	8515X	MOV	A,B	
104.265	234	8516X	SBB	H	
104.266	107	8517X	MOV	B,A	(BC) = TL-PTR-BN
104.267	031	8518X	DAD	D	(HL) = TFWA+PTR+BN
104.270	315 252 030	8519X	IBT1	CALL	\$MOVE
104.273	301	8520X	POP	B	MOVE BLOCK
104.274	321	8521X	POP	D	RESTORE REGISTERS
104.275	052 244 104	8522X	LHLD	IBTA	RESTORE (HL)
104.300	311	8523X	RET		

8525X ** DELETE BYTES FROM TABLE.

104.301	174	8526X			
104.302	057	8527X	IBT2	MOV	A,H
104.303	147	8528X		CMA	
104.304	175	8529X		MOV	H,A
104.305	057	8530X		MOV	A,L
104.306	157	8531X		CMA	
104.307	043	8532X		MOV	L,A
		8533X		INX	H
		8534X			(HL) = BYTES TO DELETE
		8535X	*		MOVE (TL-PTR-BN) BYTES FROM (PTR+BN+TFWA) TO (PTR+TFWA)
		8536X			
104.310	353	8537X		XCHG	(HL) = ADDRESS, (DE) = BN
104.311	116	8538X		MOV	C,M
104.312	043	8539X		INX	H
104.313	106	8540X		MOV	B,M
104.314	305	8541X		PUSH	B
104.315	043	8542X		INX	H
104.316	176	8543X		MOV	A,M
104.317	223	8544X		SUB	E
104.320	117	8545X		MOV	C,A
104.321	167	8546X		MOV	M,A
104.322	043	8547X		INX	H
104.323	176	8548X		MOV	A,M
104.324	232	8549X		SBB	B
104.325	107	8550X		MOV	B,A
104.326	167	8551X		MOV	M,A
104.327	052 244 104	8552X		LHLD	IBTA
104.332	171	8553X		MOV	A,C
104.333	225	8554X		SUB	L
104.334	117	8555X		MOV	C,A
104.335	170	8556X		MOV	A,B
104.336	234	8557X		SBB	H
104.337	107	8558X		MOV	B,A
104.340	353	8559X		XCHG	(BC) = TL-PTR-BN
104.341	343	8560X		XTHL	(DE) = PTR, (HL) = BN

104.342	031	8561X	DAD	D	(HL) = PTR+TFWA
104.343	353	8562X	XCHG		(DE) = PTR+TFWA
104.344	341	8563X	POP	H	(HL) = BN
104.345	031	8564X	DAD	D	
		8565X			
		8566X *		(BC) = TL-PTR-BN	
		8567X *		(DE) = BTF+TFWA	
		8568X *		(HL) = PTR+TFWA+BN	
		8569X			
104.346	353	8570X	XCHG		
104.347	303 270 104	8571X	JMP	IBT1	MOVE DATA AND EXIT
104.352		8572	XTEXT	FFP	

```

8576X ** FPADD - FLOATING POINT ADD.
8577X *
8578X * ACCX = ACCX + (DE)
8579X *
8580X * ENTRY (DE) = POINTER TO 4 BYTE FP VALUE
8581X * EXIT ACCX = RESULT
8582X * SUPPLIED VALUE UNCHANGED
8583X * USES A,F
8584X
8585X
104.352 315 215 107 8586X FPADD CALL SPE SETUP PACKAGE ENTRY
104.355 353 8587X XCHG (HL) = ADDRESS OF VALUE
  
```

```

8589X ** ADD - PERFORM FLOATING POINT ADD.
8590X *
8591X * ACCX = ACCX + (HL)
8592X *
8593X * ENTRY (HL) = POINTER TO 4 BYTE FP VALUE
8594X * RESULT STORED IN ACCX
8595X * USES ALL
8596X
8597X
104.356 8598X ADD EQU *
104.356 315 250 107 8599X CALL LDD (BCDE) = Y
104.361 041 205 042 8600X LXI H,ACCX+3
8601X
8602X * CHECK FOR X+0, 0+Y
8603X
104.364 170 8604X MOV A,B (A) = EXP(Y)
104.365 267 8605X ORA A
104.366 310 8606X RZ IF Y=0
8607X
104.367 176 8608X ADDD MOV A,M (A) = EXP(X)
104.370 267 8609X ORA A
104.371 312 160 105 8610X JZ ADD5 X = 0; RESULT = (BCDE) /80.02,BC/
8611X
8612X * COMPARE EXPONENTS, TO SEE IF SIGNIFICANT
8613X
104.374 220 8614X SUB B
104.375 322 022 105 8615X JNC ADD1 EXPX GT EXPY
105.000 052 202 042 8616X LHLD ACCX SWAP (BCDE) WITH ACCX
105.003 353 8617X XCHG
105.004 042 202 042 8618X SHLD ACCX
105.007 052 204 042 8619X LHLD ACCX+2
105.012 305 8620X PUSH B
105.013 343 8621X XTHL
105.014 301 8622X POP B
105.015 042 204 042 8623X SHLD ACCX+2
105.020 057 8624X CMA
8625X INR A (A) = SHIFT COUNT
8626X
8627X * (A) = SHIFT COUNT FOR JUSTIFICATION
8628X
  
```

105.022	312 074 105	8629X	ADD1	JZ	ADD3	NONE TO SHIFT
105.025	376 030	8630X		CPI	24	
105.027	332 057 105	8631X		JC	ADD2.5	IS LESS THAN 24
		8632X				
		8633X	*			WOULD NEED TO SHIFT INTO INSIGNIFICANCE. JUST ADD 0
		8634X				
105.032	021 000 000	8635X		LXI	D,0	(DE) = 0
105.035	112	8636X		MOV	C,D	(C) = 0
105.036	303 074 105	8637X		JMP	ADD3	
		8638X				
		8639X	*			DO JUSTIFYING RIGHT SHIFT
		8640X				
105.041	132	8641X	ADD2	MOV	E,D	
105.042	121	8642X		MOV	D,C	
105.043	171	8643X		MOV	A,C	
105.044	027	8644X		RAL		
105.045	076 000	8645X		MVI	A,0	
105.047	237	8646X		SBB	A	
105.050	117	8647X		MOV	C,A	
105.051	174	8648X		MOV	A,H	
105.052	326 010	8649X		SUI	8	
105.054	312 074 105	8650X		JZ	ADD3	IF NO MORE
105.057	147	8651X	ADD2.5	MOV	H,A	(H) = SHIFT COUNT
105.060	376 010	8652X		CPI	8	
105.062	322 041 105	8653X		JNC	ADD2	IF MORE THAN 8
105.065	315 231 107	8654X	ADD2.7	CALL	SKS	SHIFT RIGHT WITH SIGN EXTEND
105.070	045	8655X		DCR	H	
105.071	302 065 105	8656X		JNZ	ADD2.7	
		8657X				
		8658X	*			NUMBERS ALLIGNED. PERFORM ADD
		8659X				
105.074	041 202 042	8660X	ADD3	LXI	H,ACCX	
105.077	171	8661X		MOV	A,C	
105.100	365	8662X		PUSH	PSW	SAVE OLD Y SIGN
105.101	176	8663X		MOV	A,M	
105.102	213	8664X		ADC	E	ADD WITH ROUND
105.103	137	8665X		MOV	E,A	
105.104	043	8666X		INX	H	
105.105	176	8667X		MOV	A,M	
105.106	212	8668X		ADC	D	
105.107	127	8669X		MOV	D,A	
105.110	043	8670X		INX	H	
105.111	176	8671X		MOV	A,M	
105.112	211	8672X		ADC	C	
105.113	117	8673X		MOV	C,A	(CDE) = NEW SUM
105.114	176	8674X		MOV	A,M	(A) = X SIGN
105.115	043	8675X		INX	H	
105.116	106	8676X		MOV	B,H	(B) = NEW EXPONENT
105.117	037	8677X		RAR		
105.120	147	8678X		MOV	H,A	(H) 200 BIT = CARRY, 100 BIT = X SIGN
105.121	361	8679X		POP	PSW	(A) = Y SIGN
105.122	037	8680X		RAR		
105.123	254	8681X		XRA	H	(A) 100 BIT = XSIGN XOR YSIGN
105.124	027	8682X		RAL		
105.125	251	8683X		XRA	C	(A) 200 BIT = XSIGN XOR YSIGN XOR SUMSIGN
105.126	254	8684X		XRA	H	(A) = XSIGN XOR YSIGN XOR SUMSIGN XOR CARRY

FPADD - FLOATING POINT ADD.

ADD

15:48:37 16-MAY-80

```

105.127 362 142 105 8685X      JP      ADD4      IS NOT OVERFLOW
                   8686X
                   8687X *    IS OVERFLOW, SHIFT RIGHT 1
                   8688X
105.132 174          8689X      MOV     A,H
105.133 315 232 107 8690X      CALL   SRS,      SHIFT RIGHT
105.136 004          8691X      INR    B
105.137 312 136 070 8692X      JZ     ERR.OV    IF OVERFLOW
                   8693X
                   8694X *    RESULT IN (B,C,D,E)
                   8695X
105.142 305          8696X ADD4  PUSH   B          SAVE OLD EXPONENT
105.143 315 213 105 8697X      CALL   NRM
105.146 361          8698X      POP    PSW      (A) = OLD EXPONENT
105.147 220          8699X      SUB    B
105.150 376 025     8700X      CPI    21
105.152 324 221 105 8701X      CMC   NRMO      USE 0 IF HAVE LOST 21 BITS OF SIGNIFICANCE
105.155 303 245 106 8702X      JMP    STX      STORE AND EXIT
                   8703X
                   8704X *    NORMALIZE RESULT = (BCDE)
                   8705X
105.160 315 213 105 8706X ADD5  CALL   NRM      NORMALIZE
105.163 303 245 106 8707X      JMP    STX      STORE AND EXIT
                   /80.02.6C/
                   /80.02.6C/

                   8709X **   FPSUB - FLOATING POINT SUBTRACT.
                   8710X *
                   8711X *   FPSUB COMPUTES (DE) - ACCX
                   8712X *
                   8713X *   ENTRY (DE) = POINTER TO A BYTE FP VALUE
                   8714X *   EXIT   ACCX = RESULT
                   8715X *   SUPPLIED VALUE UNCHANGED
                   8716X *   USES   A,F
                   8717X
                   8718X
105.166 315 215 107 8719X FPSUB  CALL   SPE      SETUP PACKAGE ENTRY/EXIT
105.171 353          8720X      XCHG  (HL) = ADDRESS
105.172 345          8721X SUB    PUGH   H          SAVE
105.173 315 305 105 8722X      CALL   NEG      NEGATE (ACCX)
105.176 341          8723X      POP    H        (HL) = ADDRESS OF VALUE
105.177 303 356 104 8724X      JMP    ADD      ADD, RESTORE, RETURN

```

FPNRM - FLOATING POINT NORMALIZE.

FPNRM

15:48:38 16-MAY-80

```

8728X **      FPNRM - FLOATING POINT NORMALIZE.
8729X *
8730X *      FPNRM NORMALIZES THE CONTENTS OF (ACCX).
8731X *
8732X *      ENTRY NONE
8733X *      EXIT (ACCX) NORMALIZED
8734X *      USES A,F
8735X
8736X
105.202 315 215 107 8737X FPNRM CALL SPE SETUP PACKAGE ENTRY
105.205 315 245 107 8738X NRM. CALL LBX (BCDE) = (ACCX)
105.210 303 142 105 8739X JMP ADD4 NORMALIZE AND STORE
    
```

```

8741X **      NRM - NORMALIZE NUMBER.
8742X *
8743X *      ENTRY (B,C,D,E) = NUMBER
8744X *      EXIT NORMALLIZED
8745X *      USES H,L
8746X
8747X
105.213      8748X NRM EQU *
105.213 171 8749X MOV A,C
105.214 262 8750X ORA D
105.215 263 8751X ORA E
105.216 302 242 105 8752X JNZ NRM2 IF NON-ZERO
8753X
8754X *      NUMBER IS ZERO
8755X
105.221 001 000 000 8756X NRM0 LXI B,0
105.224 120 8757X MOV D,B
105.225 130 8758X MOV E,B (BCDE) = 0
105.226 311 8759X RET
8760X
8761X *      NUMBER IS NON-ZERO
8762X
105.227 112 8763X NRM1 MOV C,D
105.230 123 8764X MOV D,E
105.231 137 8765X MOV E,A
105.232 170 8766X MOV A,B
105.233 326 011 8767X SUI 9
105.235 332 136 070 8768X JC ERR.OV IF OVERFLOW
105.240 074 8769X INR A
105.241 107 8770X MOV B,A
8771X
105.242 171 8772X NRM2 MOV A,C
105.243 027 8773X RAL
105.244 251 8774X XRA C
105.245 027 8775X RAL
105.246 330 8776X RC IF NORMALIZED
105.247 172 8777X MOV A,D
105.250 027 8778X RAL
105.251 171 8779X MOV A,C
105.252 027 8780X RAL
    
```

105.253	322	257	105	8781X	JNC	NRM3	IF PL	
105.256	074			8782X	INR	A		
105.257	247			8783X	ANA	A		
105.260	312	227	105	8784X	JZ	NRM1	IF A FULL WORD TO SHIFT	
				8785X				
				8786X	*		SHIFT LEFT UNTIL NORMALIZED	
				8787X				
105.263	315	101	107	8788X	NRM4	CALL	LSH	LSFT SHIF
105.266	005			8789X	DCR	B		
105.267	312	221	105	8790X	JZ	NRM0	UNDERFLOW	
105.272	171			8791X	MOV	A,C		
105.273	027			8792X	RAL			
105.274	251			8793X	XRA	C		
105.275	027			8794X	RAL			
105.276	322	243	105	8795X	JNC	NRM4	IF MORE TO SHIT	
105.301	311			8796X	RET		EXIT	

FPNEG - FLOATING POINT NEGATE.

FPNEG

15:48:40 16-MAY-80

```

8800X **      FPNEG - FLOATING POINT NEGATE.
8801X *
8802X *      FPNEG NEGATES THE CONTENTS OF ACCX.
8803X *
8804X *      ENTRY NONE
8805X *      EXIT   (ACCX) = -(ACCX)
8806X *      USES   A,F
8807X
8808X
105.302 315 215 107 8809X FPNEG CALL   SPE      SETUP PACKAGE ENTRY
105.305 315 245 107 8810X NEG   CALL   LDX      (BCDE) = (ACCX)
105.310 315 260 107 8811X      CALL   TCV      TWO'S COMPLEMENT IT
105.313 303 245 106 8812X      JMP    STX      STORE AND RETURN

```

```

8815X **      FPTST - FLOATING POINT TEST.
8816X *
8817X *      FPTST TESTS THE SIGN AND VALUE OF (ACCX).
8818X *
8819X *      ENTRY NONE
8820X *      EXIT   'Z' SET IF (ACCX) = 0
8821X *      EXIT   'M' SET IF (ACCX) < 0
8822X *      USES   A,F
8823X
8824X
105.316 072 204 042 8825X FPTST LDA    ACCX+2
105.321 247          8826X ANA    A          SET CONDITION CODE
105.322 311          8827X RET

```

```

      8830X **      FPMUL - FLOATING POINT MULTIPLY.
      8831X *
      8832X *      ENTRY (DE) = ADDRESS OF Y
      8833X *      EXIT ACCX = ACCX * Y
      8834X *      USES A,F
      8835X
      8836X
      105.323 315 215 107 8837X FPMUL CALL SPE      SETUP PACKAGE ENTRY
      105.326 353      8838X XCHG      (HL) = ADDRESS OF VALUE
  
```

```

      8840X **      MUL - FLOATING POINT MULTIPLY.
      8841X *
      8842X
      8843X
      105.327      8844X MUL EQU *
      105.327 021 200 000 8845X LXI D,M1,ADDB (DE) = 'ADD B', 'NOP'
      105.332 315 114 107 8846X CALL FMD PREPARE MULTIPLY
      105.335 312 240 106 8847X JZ MUL5 IS ZERO
      105.340 332 136 070 8848X JC ERR.OV IS OVERFLOW
      105.343 147 8849X MOV H,A SAVE NEW EXPONENT
      105.344 345 8850X PUSH H SAVE NEW EXP AND SIGN
      105.345 171 8851X MOV A,C
      105.346 062 034 106 8852X STA MULA SETUP MULTIPLICAND
      105.351 062 076 106 8853X STA MULD
      105.354 062 143 106 8854X STA MULH
      105.357 172 8855X MOV A,D
      105.360 062 072 106 8856X STA MULC
      105.363 062 137 106 8857X STA MULG
      105.366 173 8858X MOV A,E
      105.367 062 133 106 8859X STA MULF
      105.372 041 204 042 8860X LXI H,ACCX+2
      105.375 176 8861X MOV A,M
      105.376 062 121 106 8862X STA MULE
      106.001 053 8863X DCX H
      106.002 176 8864X MOV A,M
      106.003 062 051 106 8865X STA MULB
      106.006 053 8866X DCX H
      106.007 106 8867X MOV B,M
      106.010 046 007 8868X MVI H,7
      106.012 154 8869X MOV L,H
      106.013 021 000 000 8870X LXI D,0
      106.016 112 8871X MOV C,D ZERO ACCUMULATOR
      106.017 170 8872X MOV A,B
      106.020 247 8873X ANA A
      106.021 312 047 106 8874X JZ MUL2,5
      106.024 170 8875X L1 MOV A,B (A) = MULTIPLICAND
      106.025 037 8876X RAR
      106.026 107 8877X MOV B,A
      106.027 171 8878X MOV A,C
      106.030 322 035 106 8879X JNC L2 BIT NOT PRESENT
      106.033 306 000 8880X ADI 0
      106.034 8881X MULA EQU *-1
      106.035 037 8882X L2 RAR
  
```

106.036	117		8883X	MOV	C,A	
106.037	045		8884X	DCR	H	
106.040	362	024 106	8885X	JP	L1	
106.043	322	047 106	8886X	JNC	MUL2.5	NOT CARRY
106.046	014		8887X	INR	C	
			8888X			
			8889X *		2ND PARTIAL PRODUCT	
			8890X			
106.047	145		8891X MUL2.5	MOV	H,L	
106.050	006	000	8892X	MVI	B,0	
106.051			8893X MULE	EQU	*-1	
106.052	072	202 042	8894X	LDA	ACCX	
106.055	260		8895X	ORA	B	
106.056	312	120 106	8896X	JZ	L4.5	NONE IN LOW TWO BYTES
			8897X			
106.061	170		8898X MUL3	MOV	A,B	
106.062	037		8899X	RAR		
106.063	107		8900X	MOV	B,A	
106.064	171		8901X	MOV	A,C	
106.065	322	077 106	8902X	JNC	L4	NOT SET
106.070	172		8903X	MOV	A,B	
106.071	306	000	8904X	ADI	0	
106.072			8905X MULC	EQU	*-1	
106.073	127		8906X	MOV	D,A	
106.074	171		8907X	MOV	A,C	
106.075	316	000	8908X	ACI	0	
106.076			8909X MULD	EQU	*-1	
106.077	037		8910X L4	RAR		
106.100	117		8911X	MOV	C,A	
106.101	172		8912X	MOV	A,D	
106.102	037		8913X	RAR		
106.103	127		8914X	MOV	D,A	
106.104	045		8915X	DCR	H	
106.105	362	061 106	8916X	JP	MUL3	
106.110	322	120 106	8917X	JNC	L4.5	NOT CARRY
106.113	024		8918X	INR	D	
106.114	302	120 106	8919X	JNZ	L4.5	
106.117	014		8920X	INR	C	
106.120	006	000	8921X L4.5	MVI	B,0	
106.121			8922X MULE	EQU	*-1	
			8923X			
106.122	170		8924X L5	MOV	A,B	
106.123	037		8925X	RAR		
106.124	107		8926X	MOV	B,A	
106.125	171		8927X	MOV	A,C	
106.126	322	144 106	8928X	JNC	L6	NOT SET
106.131	173		8929X	MOV	A,E	
106.132	306	000	8930X	ADI	0	
106.133			8931X MULF	EQU	*-1	
106.134	137		8932X	MOV	E,A	
106.135	172		8933X	MOV	A,D	
106.136	316	000	8934X	ACI	0	
106.137			8935X MULG	EQU	*-1	
106.140	127		8936X	MOV	D,A	
106.141	171		8937X	MOV	A,C	
106.142	316	000	8938X	ACI	0	

MUL

106.143			8939X MULH	ERU	*-1	
106.144	037		8940X L6	RAR		
106.145	117		8941X	MOV	C,A	
106.146	172		8942X	MOV	A,D	
106.147	037		8943X	RAR		
106.150	127		8944X	MOV	D,A	
106.151	173		8945X	MOV	A,E	
106.152	037		8946X	RAR		
106.153	137		8947X	MOV	E,A	
106.154	055		8948X	DCR	L	
106.155	302 122 106		8949X	JNZ	L5	
106.160	322 174 106		8950X	JNC	L7	NOT TO ROUND UP
106.163	034		8951X	INR	E	
106.164	302 174 106		8952X	JNZ	L7	
106.167	024		8953X	INR	D	
106.170	302 174 106		8954X	JNZ	L7	
106.173	014		8955X	INR	C	
			8956X *	NORMALIZE		
			8957X			
106.174	171		8958X L7	MOV	A,C	
106.175	341		8959X	POP	H	(HL) = EXPONENT AND SIGN
106.176	104		8960X	MOV	B,H	
106.177	027		8961X	RAL		
106.200	247		8962X	ANA	A	
106.201	372 216 106		8963X	JM	MUL3.5	NORMALIZED
			8964X			
106.204	173		8965X	MOV	A,E	
106.205	027		8966X	RAL		
106.206	137		8967X	MOV	E,A	
106.207	172		8968X	MOV	A,D	
106.210	027		8969X	RAL		
106.211	127		8970X	MOV	D,A	
106.212	171		8971X	MOV	A,C	
106.213	027		8972X	RAL		
106.214	117		8973X	MOV	C,A	
106.215	005		8974X	DCR	B	ADJUST EXPONENT
106.216	004		8975X MUL3.5	INR	B	ADJUST EXPONENT
106.217	312 136 070		8976X	JZ	ERR.OV	
			8977X			
			8978X *	NEGATE IF NECESSARY		
			8979X			
106.222	175		8980X MUL4	MOV	A,L	
106.223	247		8981X	ANA	A	
106.224	374 260 107		8982X	CM	TCV	TWOS COMP VALUE
106.227	170		8983X	MOV	A,B	
106.230	247		8984X	ANA	A	
106.231	312 245 106		8985X	JZ	STX	VALUE IS 0
106.234	005		8986X	DCR	B	
106.235	302 245 106		8987X	JNZ	STX	NOT UNDERFLOW
			8988X			
			8989X *	RESULT = 0		
			8990X			
106.240	001 000 000		8991X MUL5	LXI	B,0	
106.243	120		8992X	MOV	B,B	
106.244	130		8993X	MOV	E,B	OBCDE) = 0
			8994X *	JMP	STX	

```
8996X ** STX - STORE REGISTERS INTO X VALUE.  
8997X *  
8998X * ENTRY (B,C,D,E) = VALUES  
8999X * EXIT STORED IN REG:X  
9000X  
9001X  
106.245 041 202 042 9002X STX LXI H,ACCX  
106.250 163 9003X STO MOV M,E  
106.251 043 9004X INX H  
106.252 162 9005X MOV M,H  
106.253 043 9006X INX H  
106.254 161 9007X MOV H,C  
106.255 043 9008X INX H  
106.256 160 9009X MOV M,B  
106.257 311 9010X RET
```



```

9013X **      FPDIV - FLOATING POINT DIVIDE.
9014X *
9015X *      ACCX = ACCX/Y
9016X *
9017X *      ENTRY (DE) = POINTER TO Y
9018X *      EXIT  (ACCX) = RESULT
9019X *      USES  A,F
9020X
9021X
106.260 315 215 107 9022X FPDIV CALL SPE      SETUP PACKAGE ENTRY
106.263 353          9023X          XCHG      (HL) = ADDRESS OF VALUE

9025X **      DIV - FLOATING POINT DEVIDE.
9026X *
9027X *      X=Y/X
9028X
9029X
9030X
106.264          9031X DIV ERU *
106.264 021 220 077 9032X LXI D,MI.CMC*256+MI.SUBB (DE) = 'SUB B', 'CMC'
106.267 315 114 107 9033X CALL PMD      PRESET FOR DEVICBE
106.272 302 305 106 9034X JNZ DIV0      IF NEIGHER ZERO
106.275 170          9035X MOV A,B
106.276 247          9036X ANA A
106.277 312 117 070 9037X JZ ERR.D0      (Y) = 0
106.302 303 240 106 9038X JMP MUL5      (X) = 0
9039X
106.305 332 136 070 9040X DIV0 JC ERR.D0      IF OVERFLOW
106.310 074          9041X INR A
106.311 312 136 070 9042X JZ ERR.D0      IF OVERFLOW
106.314 147          9043X MOV H,A      (H) = RESULT EXP, (L) = RESULT SIGN
106.315 345          9044X PUSH H
106.316 173          9045X MOV A,E
106.317 062 367 106 9046X STA DIVA
106.322 172          9047X MOV A,D
106.323 062 373 106 9048X STA DIVB
106.326 171          9049X MOV A,C
106.327 062 377 106 9050X STA DIVC
106.332 171          9051X MOV A,C
106.333 062 016 107 9052X STA PHAC+1
106.336 172          9053X MOV A,D
106.337 062 012 107 9054X STA PHAB+1
106.342 173          9055X MOV A,E
106.343 062 006 107 9056X STA PHAA+1
106.346 315 245 107 9057X CALL LDX      (BCDE) = X VALUE
106.351 053          9058X DCX H
106.352 345          9059X PUSH H
106.353 056 003      9060X MVI L,3      (L) = LOOP COUNT
106.355 076 002      9061X DIV1 MVI A,2
106.357 275          9062X CMP L
106.360 336 372      9063X SBI -6
106.362 147          9064X MOV H,A      (H) = 7 IF FIRST, 8 IF 2ND OR 3RD
106.363 006 000      9065X MVI B,0      (B) = RESULT

```

```

106.365 173          9066X DIV2  MOV  A,E
106.366 326.000     9067X      SUI  0
106.367            9068X DIVA  EQU  *-1
106.370 137         9069X      MOV  E,A
106.371 172         9070X      MOV  A,D
106.372 336.000     9071X      SBI  0
106.373            9072X DIVB  EQU  *-1
106.374 127         9073X      MOV  D,A
106.375 171         9074X      MOV  A,C
106.376 336.000     9075X      SBI  0
106.377            9076X DIVC  EQU  *-1
107.000 117         9077X      MOV  C,A
107.001 322 020 107 9078X      JNC  DIV3
107.004 173         9079X      MOV  A,E
107.005 306.000     9080X PMAA  ADI  0
107.007 137         9081X      MOV  E,A
107.010 172         9082X      MOV  A,D
107.011 316.000     9083X PMAB  ACI  0
107.013 127         9084X      MOV  D,A
107.014 171         9085X      MOV  A,C
107.015 316.000     9086X PMAC  ACI  0
107.017 117         9087X      MOV  C,A
107.020 077         9088X DIV3  CMC
107.021 170         9089X
107.022 027         9090X *      SET RESULT BIT IN ACCUMULATOR
107.023 107         9091X
107.024 315 101 107 9092X      MOV  A,B
107.027 045         9093X      RAL
107.030 302 365 106 9094X      MOV  B,A
107.033 343         9095X
107.034 160         9096X *      SHIFT REMAINDER VALUE LEFT 1
107.035 053         9097X
107.036 343         9098X      CALL LSH
107.037 055         9099X      DCR  H
107.040 302 355 106 9100X      JNZ  DIV2
107.043 341         9101X
107.044 043         9102X *      STORE SUBVALUE
107.045 043         9103X
107.046 130         9104X      XTHL
107.047 126         9105X      MOV  M,B
107.050 043         9106X      DCX  H
107.051 171         9107X      XTHL
107.052 116         9108X      DCR  L
107.053 341         9109X      JNZ  DIV1
107.054 104         9110X      FOP  H
107.055 147         9111X      INX  H
107.056 072 377 106 9112X      INX  H
107.057            9113X      MOV  E,B
107.058            9114X      MOV  D,M
107.059            9115X      INX  H
107.060            9116X      MOV  A,C
107.061            9117X      MOV  C,M
107.062            9118X      FOP  H
107.063            9119X      MOV  B,H
107.064            9120X      MOV  H,A
107.065            9121X      LDA  DIVC

```

(A) = REMAINDER HIGH ORDER
 (BCDE) = RESULT
 (B) = RESULTANT EXPONENT

107.061	224		9122X	SUB	H	SEE IF NEXT RESULT BIT WOULD BE 1 (OR CLOSE
107.062	334	315	107	9123X	CC	ROUND VALUE UP IF SO
107.065	171			9124X	MOV	
107.066	346	100		9125X	ANI	1000
107.070	302	216	106	9126X	JNZ	MUL3.5
107.073	315	101	107	9127X	CALL	LSH
107.076	303	222	106	9128X	JMP	MUL4

```

9132X ** LSH - LEFT SHIFT VALUE.
9133X *
9134X * ENTRY (C,D,E) = VALUE
9135X * EXIT (C,D,E) SHIFTED RIGHT 1
9136X
9137X
107.101 247 9138X LSH ANA A CLEAR CARRY
107.102 173 9139X MOV A,E
107.103 027 9140X RAL
107.104 137 9141X MOV E,A
107.105 172 9142X MOV A,D
107.106 027 9143X RAL
107.107 127 9144X MOV D,A
107.110 171 9145X MOV A,C
107.111 027 9146X RAL
107.112 117 9147X MOV C,A
107.113 311 9148X RET
    
```

```

9150X ** FMD - PRESET MULTIPLY/DIVIDE
9151X *
9152X * ENTRY (DE) = EXPONENT INSTRUCTIONS (FOR MULTIPLY OR DIVIDE)
9153X * (HL) = ADDRESS OF 'Y' VALUE
9154X * EXIT (C,D,E) = X VALUES
9155X * 'Z' SET IF VALUE ZERO
9156X * 'C' SET OF OVERFLOW
9157X * 'L' = NEW SIGN
9158X * (A) = NEW EXPONENT
9159X
9160X
107.114 9161X FMD EQU *
107.114 345 9162X PUSH H
107.115 353 9163X XCHG (HL) = EXPONENT INSTRUCTIONS
107.116 042 164 107 9164X SHLD PMDB
107.121 041 202 042 9165X LXT H,ACCX
107.124 072 204 042 9166X LDA ACCX+2
107.127 062 152 107 9167X STA PMDA SET STRN
107.132 247 9168X ANA A
107.133 374 204 107 9169X CM PMD2 IF MUST COMPLEMENT X
107.136 341 9170X POP H (HL) = ADDRESS OF Y
107.137 315 250 107 9171X CALL LDP LOAD NUMBER
107.142 171 9172X MOV A,C
107.143 157 9173X MOV L,A (L) = SIGN
107.144 247 9174X ANA A
107.145 374 260 107 9175X CM TCV IS NEGATIVE
107.150 175 9176X MOV A,L (A) = SIGN
107.151 356 000 9177X XRI 0 COMPARE SIGNS
107.152 9178X PMDA EQU * - 1 SIGN OF X
107.153 157 9179X MOV L,A
107.154 170 9180X MOV A,B
107.155 247 9181X ANA A
107.156 310 9182X RZ IF ZERO
107.157 072 205 042 9183X LDA ACCX+2
107.162 247 9184X ANA A
    
```

```

107.163 310 9185X RZ IF ZERO
107.164 200 9186X PMDB ADD B IF DIVIDE, = 'SUB B'
107.165 000 9187X NOP = 'CMC'
107.166 107 9188X MOV B,A (B) = SUM OF 2
9189X
9190X * SEE IF EXPONENT OVERFLOW
9191X
107.167 037 9192X RAR
107.170 250 9193X XRA B
107.171 170 9194X MOV A,B (A) = SUM OF EXPONENTS
107.172 362 200 107 9195X JF PMD1 OVERFLOW OR UNDERFLOW
107.175 356 200 9196X XRI 200Q
107.177 311 9197X RET (Z) SET IF UNDERFLOW
9198X
9199X * OVERFLOW OR UNDERFLOW.
9200X
107.200 007 9201X PMD1 RLC (C) IF OVERFLOW
107.201 330 9202X RC
107.202 257 9203X XRA A UNDERFLOW. SET *Z*
107.203 311 9204X RET EXIT
9205X
9206X
9207X * COMPLEMENT ACCX TO A POSITIVE NUMBER
9208X
107.204 315 245 107 9209X PMD2 CALL LDX
107.207 315 260 107 9210X CALL TCV
107.212 303 245 106 9211X JMP STX STORE AND RETURN

9213X ** SPE - SETUP PACKAGE ENTRY.
9214X *
9215X * SPE IS CALLED UPON ENTRY TO THE FLOATING POINT PACKAGE.
9216X *
9217X * IT SAVES THE REGISTERS ON THE STACK, SETS UP A RETURN ADDRESS
9218X * TO A RESTORE REGISTER ROUTINE, AND THEN ENTERS THE SELECTED
9219X * ROUTINE.
9220X *
9221X * ENTRY (SP+0) = ADDRESS TO RETURN CONTROL TO
9222X * EXIT REGISTERS ON STACK, *SPEX* SET AS RETURN ADDRESS
9223X * USES B,C,H,L
9224X
9225X
107.215 343 9226X SPE XTHL SAVE H
107.216 325 9227X PUSH D SAVE D
107.217 305 9228X PUSH B SAVE B
107.220 001 225 107 9229X LXI B,SPEX
107.223 305 9230X PUSH B SET 'RETURN ADDRESS'
107.224 351 9231X FCHL ENTER ROUTINE
9232X
9233X * RETURN FROM ROUTINE, RESTORE REGISTERS AND RETURN TO CALLER.
9234X
107.225 301 9235X SPEX POP B
107.226 321 9236X POP D
107.227 341 9237X POP H
    
```

107.230 311 9238X RET

9240X ** SRS - SHIFT RIGHT WITH SIGN EXTEND.

9241X *

9242X * ENTRY (C,D,E) = VALUE

9243X * EXIT (C,D,E) SHIFTED RIGHT 1 BIT

9244X * USES A

9245X

107.231 9246X SRS EQU *

107.231 171 9247X MOV A,C

107.232 027 9248X SRS RAL

107.233 171 9249X SRS, MOV A,C

107.234 037 9250X RAR

107.235 117 9251X MOV C,A

107.236 172 9252X MOV A,D

107.237 037 9253X RAR

107.240 127 9254X MOV D,A

107.241 173 9255X MOV A,E

107.242 037 9256X RAR

107.243 137 9257X MOV E,A

107.244 311 9258X RET

9260X ** LDX - LOAD X VALUE INTO REGISTERS

9261X *

9262X * ENTRY NONE

9263X * EXIT (BCDE) = (ACCX)

9264X * USES ALL

9265X

9266X

107.245 041 202 042 9267X LDX LXI H,ACCX

9269X ** LDD - LOAD VALUE INTO REGISTERS.

9270X *

9271X * ENTRY (HL) = ADDRESS OF VALUE

9272X * EXIT (B,C,D,E) = X VALUE

9273X

9274X

107.250 136 9275X LDD MOV E,M

107.251 043 9276X INX H

107.252 126 9277X MOV D,M

107.253 043 9278X INX H

107.254 116 9279X MOV C,M

107.255 043 9280X INX H

107.256 106 9281X MOV B,M

107.257 311 9282X RET

```

9284X **   TCV = TWOS COMPLEMENT VALUE.
9285X *
9286X *   ENTRY (BCDE) = VALUE
9287X
107.260    9288X TCV   EQU   *
107.260 171    9289X   MOV   A,C
107.261 057    9290X   CMA
107.262 117    9291X   MOV   C,A
107.263 172    9292X   MOV   A,D
107.264 057    9293X   CMA
107.265 127    9294X   MOV   D,A
107.266 173    9295X   MOV   A,E
107.267 057    9296X   CMA
107.270 137    9297X   MOV   E,A
107.271 034    9298X   INR   E
107.272 300    9299X   RNZ
107.273 024    9300X   INR   D
107.274 300    9301X   RNZ
107.275 171    9302X   MOV   A,C           (A) = SIGN
107.276 014    9303X   INR   C
107.277 247    9304X   ANA   A
107.300 372 213 105 9305X  JM    NRM           IF POSITIVE TO NEGATIVE, NORMALIZE
107.303 171    9306X   MOV   A,C           WAS NEGATIVE TO POSITIVE, MAY NEED RIGHT SH
107.304 247    9307X   ANA   A
107.305 360    9308X   RF
107.306 004    9309X   INR   B           DONT NEED SHIFT
107.307 312 136 070 9310X  JZ   ERR,OV           IF OVERFLOW
107.312 303 233 107 9311X  JMP  SRS.,           SHIFT RIGHT AND EXIT
    
```

```

9313X **   RVU = ROUND VALUE UP.
9314X *
9315X *   RVU IS CALLED TO ADD ONE BIT TO THE VALUE.
9316X *
9317X *   ENTRY (BCDE) = VALUE
9318X *   EXIT   (BCDE), ADJUSTED
9319X *   USES   A,F,B,C,D,E
9320X
9321X
107.315 034    9322X RVU   INR   E
107.316 300    9323X   RNZ           NO CARRY
107.317 024    9324X   INR   D
107.320 300    9325X   RNZ           NO CARRY
107.321 014    9326X   INR   C
107.322 311    9327X   RET
107.323        9328   XTEXT FPC
    
```

```

9331X **      ATF - ASCII TO FLOATING.
9332X *
9333X *
9334X *      ATF CONVERTS AN ASCII STRING INTO A FLOATING POINT VALUE
9335X *      IN ACCX.
9336X *
9337X *      SYNTAX
9338X *      NNNN [C,NNNN] [E [+|-] NN]
9339X *
9340X *      NO LEADING BLANKS ALLOWED; A SINGLE LEADING
9341X *      '-' IS ALLOWED; AND PROCESSED.
9342X *
9343X *      ENTRY (HL) = ADDRESS OF TEXT
9344X *      EXIT (HL) UPDATED
9345X *      (ACCX) = VALUE
9346X *
9347X *      USES  A,F,H,L
9348X
107.323      9349X ATF  EQU  *
107.323 305  9350X  PUSH  B          SAVE REGISTERS
107.324 325  9351X  PUSH  D
107.325 176  9352X  MOV   A,M          SEE IF '-'
107.326 376 055 9353X  CPI   '-'
107.330 365  9354X  PUSH  PSW          SAVE RESULTS UNTIL THE VERY END
107.331 302 335 107 9355X  JNE  ATFO          NOT -
107.334 043  9356X  INX   H          SKIP '-'
107.335 345  9357X ATF0  PUSH  H          SAVE TEXT POINTER
107.336 006 006  9358X  MVI  B,6          DIGIT COUNT+2
9359X
9360X *      COUNT # OF SIGNIFICANT DIGITS
9361X
107.340 005  9362X ATF1  DCR   B
107.341 312 053 110 9363X  JZ   ATF3          TOO MANY DIGITS
107.344 176  9364X  MOV   A,M
107.345 043  9365X  INX   H
107.346 376 056  9366X  CPI   ','
107.350 312 340 107 9367X  JE   ATF1          DONT COUNT DECIMAL POINT
107.353 376 060  9368X  CPI   '0'
107.355 332 365 107 9369X  JC   ATF1.5        NOT DIGIT
107.360 376 072  9370X  CPI   '9'+1
107.362 332 340 107 9371X  JC   ATF1          IS DIGIT
9372X
9373X *      WILL DECODE NUMBER AS DECIMAL INTEGER
9374X
107.365 341  9375X ATF1.5  POP   H          (HL) = START OF NUMBER
107.366 021 000 000 9376X  LXI  D,0
107.371 315 202 111 9377X  CALL DDN1        DECODE DECIMAL NUMBER
107.374 006 000  9378X  MVI  B,0          ZERO AFTER-DECIMAL COUNT
107.376 076 056  9379X  MVI  A,' '
110.000 276  9380X  CMP  M
110.001 314 235 111 9381X  CE   DDN2        DECODE FRACTIONAL, IF ANY
110.004 305  9382X  PUSH  R          SAVE DF COUNT
110.005 112  9383X  MOV  C,D
110.006 123  9384X  MOV  D,E
110.007 257  9385X  XRA  A          CLEAR CARRY
110.010 137  9386X  MOV  E,A          (E) = 0

```



```

110.011 103          9387X      MOV      B,E          (B) = 0
110.012 171          9388X      MOV      A,C
110.013 262          9389X      ORA      D
110.014 312 035 110  9390X      JZ       ATF2.5      IS 0
110.017 006 217      9391X      MVI      B,217R
                  9392X
                  9393X *      NORMALIZE
                  9394X
110.021 172          9395X ATF2   MOV      A,D
110.022 027          9396X      RAL
110.023 127          9397X      MOV      D,A
110.024 171          9398X      MOV      A,C
110.025 027          9399X      RAL
110.026 117          9400X      MOV      C,A
110.027 005          9401X      DCR      B
110.030 346 100      9402X      ANI      100Q
110.032 312 021 110  9403X      JZ       ATF2          MORE TO GO
110.035 353          9404X ATF2.5  XCHG
110.036 042 202 042  9405X      SHLD    ACCX          SET LOW-ORDER
110.041 140          9406X      MOV      H,B
110.042 151          9407X      MOV      L,C
110.043 042 204 042  9408X      SHLD    ACCX+2        SET HIGH-ORDER
110.046 353          9409X      XCHG          (HL) = NEXT BYTE ADDR
110.047 301          9410X      POP      B          (B) = SCALE COUNT
110.050 303 102 110  9411X      JMP      ATF5          CHECK FOR EXPONENT
                  9412X
                  9413X *      MUST DECODE VIA FLOATING NUMBERS.
                  9414X
110.053 315 240 106  9415X ATF3   CALL    MUL5          CLEAR ACCX
110.056 006 207      9416X      MVI      B,227R-16
110.060 041 210 042  9417X      LXI      H,ACCY
110.063 315 250 106  9418X      CALL    STD          SETUP Y
110.066 341          9419X      POP      H          (HL) = NUMBER START
110.067 315 237 111  9420X ATF4   CALL    DFD          DECODE FLOATING DECIMAL
110.072 006 000      9421X      MVI      B,0          CLEAR DF COUNT
110.074 076 056      9422X      MVI      A,'.'
110.076 276          9423X      CMP      M
110.077 314 267 111  9424X      CE       DFD1          IF FRACTIONAL PART
                  9425X
                  9426X *      HAVE FLOATING VALUE, LOOK FOR E+-NN
                  9427X *      (B) = DF SCALE COUNT
                  9428X
110.102 076 105      9429X ATF5   MVI      A,'E'
110.104 276          9430X      CMP      H
110.105 076 000      9431X      MVI      A,0          ASSUME HAVE ONE
110.107 302 160 110  9432X      JNE     ATF8          HAVE NONE
110.112 043          9433X      INX      H          INCREMENT PAST 'E'
                  9434X
                  9435X *      DECODE EXPONENT.
                  9436X
110.113 176          9437X      MOV      A,M          (A) = NEXT CHARACTER
110.114 326 053      9438X      SUI      '+'
110.116 312 132 110  9439X      JZ       ATF6          IS +
110.121 376 002      9440X      CPI      '-','+'
110.123 076 200      9441X      MVI      A,80H        ASSUME -
110.125 312 132 110  9442X      JE       ATF6          IS -

```

110.130	257		9443X	XRA	A	IS NONE. USE +	
110.131	053		9444X	DCX	H		
110.132	043		9445X	ATF6	INX	H	ADVANCE PAST + OR -
110.133	365		9446X	PUSH	PSW		SAVE SIGN
110.134	110		9447X	MOV	C,B		(C) = DP COUNT
110.135	315	171 111	9448X	CALL	DDN		DECODE DECIMAL DIGITS
110.140	101		9449X	MOV	B,C		RESTORE DP COUNT
110.141	343		9450X	XTHL			SAVE (HL); (H) = EXPONENT SIGN
110.142	172		9451X	MOV	A,D		
110.143	247		9452X	ANA	A		
110.144	302	122 070	9453X	JNZ	ERR,IN		IF TOO LARGE
110.147	174		9454X	MOV	A,H		
110.150	027		9455X	RAL			'C' SET IF NEGATIVE
110.151	173		9456X	MOV	A,E		
110.152	322	157 110	9457X	JNC	ATF7		NOT NEGATIVE
110.155	057		9458X	CMA			
110.156	074		9459X	INR	A		
110.157	341		9460X	ATF7	POP	H	
110.160	200		9461X	ATF8	ADD	B	(A) = SCALE COUNT
110.161	312	230 110	9462X	JZ	ATF11		NO SCALEING
110.164	345		9463X	PUSH	H		SAVE (HL)
110.165	041	327 105	9464X	LXI	H,MUL		ASSUME *
110.170	042	217 110	9465X	SHLD	ATFA		/78.10.GC/
110.173	041	153 112	9466X	LXI	H,FP10.		ASSUME *10
110.176	362	213 110	9467X	JP	ATF9		IS POSITIVE
110.201	345		9468X	PUSH	H		/78.10.GC/
110.202	041	264 106	9469X	LXI	H,IV		/78.10.GC/
110.205	042	217 110	9470X	SHLD	ATFA		/78.10.GC/
110.210	341		9471X	POP	H		/78.10.GC/
110.211	057		9472X	CMA			
110.212	074		9473X	INR	A		(A) = COUNT
110.213	117		9474X	ATF9	MOV	C,A	(C) = SCALE COUNT
110.214	305		9475X	ATF10	PUSH	B	
110.215	345		9476X	PUSH	H		
110.216	315	327 105	9477X	CALL	MUL		SCALE
110.217			9478X	ATFA	EQU	*-2	
110.221	341		9479X	POP	H		
110.222	301		9480X	POP	B		
110.223	015		9481X	DCR	C		
110.224	302	214 110	9482X	JNZ	ATF10		IF MORE TO GO
110.227	341		9483X	POP	H		RESTORE (HL)
			9484X				
			9485X	*	DONE.		
			9486X				
110.230	361		9487X	ATF11	POP	PSW	(PSW) = RESULTS OF EARLY CHECK
110.231	314	302 105	9488X	CE	FPNEG		MUST NEGATE
110.234	321		9489X	POP	D		
110.235	301		9490X	POP	B		
110.236	311		9491X	RET			

```

9494X **      FTA - FLOATING TO ASCII.
9495X *
9496X *      FTA CONVERTS A FLOATING POINT NUMBER INTO AN ASCII
9497X *      REPRESENTATION..
9498X *
9499X *      ENTRY (ACCX) = VALUE
9500X *      (HCL) = ADDRESS TO STORE TEXT
9501X *      EXIT (A) = LENGTH OF STRING DECODED
9502X *      (DE) = ADDRESS OF LAST BYTE
9503X *      USES A,F,D,E
9504X
9505X
110.237      9506X FTA EQU *
110.237      9507X PUSH B
110.240      9508X PUSH H
110.241      066 040 9509X MVI M,' ' INSURE LEADING BLANK
110.243      072 204 042 9510X LDA ACCX+2
110.246      247 9511X ANA A TEST VALUE
110.247      362 261 110 9512X JP FTA1
110.252      043 9513X INX H ADD MINUS SIGN
110.253      066 055 9514X MVI M,'-'
110.255      315 302 105 9515X CALL FPNEG INVERT IT
110.260      264 9516X ORA H CLEAR 'Z'
110.261      043 9517X FTA1 INX H
110.262      006 001 9518X MVI B,1 (B) = EXPONENT
110.264      312 356 110 9519X JZ FTA2.7 IS 0
9520X
9521X *      SCALE NUMBER
9522X
110.267      021 267 110 9523X FTA2 LXI D,FTA2
110.272      325 9524X PUSH D SET 'RETURN ADDRESS'
110.273      021 153 112 9525X LXI D,FP10.
110.276      072 205 042 9526X LDA ACCX+3
110.301      005 9527X INR B
110.302      376 201 9528X CPI 2010
110.304      332 323 105 9529X JC FPMUL ACCX = ACCX * 10
110.307      004 9530X INR B
110.310      004 9531X INR B
110.311      326 205 9532X SUI 2050
110.313      322 260 106 9533X JNC FFDIV ACCX = ACCX / 10
110.316      074 9534X INR A
110.317      372 332 110 9535X JM FTA2.5 IS SCALED
110.322      072 204 042 9536X LDA ACCX+2
110.325      376 120 9537X CPI 1200
110.327      322 260 106 9538X JNC FFDIV
110.332      005 9539X FTA2.5 INR B
110.333      321 9540X POP D DISCARD 'RETURN ADDRESS'
9541X
9542X *      ROUND NUMBER
9543X
110.334      072 204 042 9544X LDA ACCX+2
110.337      365 9545X PUSH FSW SAVE HIGH ORDER PART
110.340      021 165 111 9546X LXI D,FTAA
110.343      315 352 104 9547X CALL FPADD ROUND UP
110.346      321 9548X POP D (D) = OLD MANTISSA
110.347      072 204 042 9549X LDA ACCX+2
    
```

110.352	272			9550X	CMF	D	
110.353	302	267	110	9551X	JNE	FTA2	CAUSED MAJOR CHANGE, ROUND AGAIN
				9552X			
				9553X	*		SCALED, (B) = DECIMAL PLACE
				9554X			
110.354				9555X	FTA2.7	EQU	*
110.356	170			9556X		MOV	A,B
110.357	376	007		9557X		CPI	7
110.360				9558X	FTAC	EQU	*-1
110.361	365			9559X		PUSH	PSW
110.362	332	367	110	9560X		JC	FTA3
110.365	006	001		9561X		MVI	B,1
110.367	016	007		9562X	FTA3	MVI	C,7
110.370				9563X	FTAD	EQU	*-1
110.371	004			9564X		INR	B
				9565X			(B) = DIGITS BEFORE DP (+1)
				9566X	*		SEE IF TO PLACE DECIMAL POINT
				9567X			
110.372	005			9568X	FTA4	DCR	B
110.373	302	001	111	9569X		JNZ	FTA4.5
110.376	066	056		9570X		MVI	M,7
111.000	043			9571X		INX	H
111.001	015			9572X	FTA4.5	DCR	C
111.002	312	066	111	9573X		JZ	FTA8.5
				9574X			IF ROOM FOR NO MORE DIGITS
				9575X	*		DECODE DIGIT
				9576X			
111.005	345			9577X	FTA5	PUSH	H
111.006	041	205	042	9578X		LXI	H,ACCX+3
111.011	126			9579X		MOV	D,M
111.012	172			9580X		MOV	A,D
111.013	376	201		9581X		CPI	201H
111.015	076	000		9582X		MVI	A,0
111.017	332	045	111	9583X		JC	FTA7.5
111.022	257			9584X		XRA	A
111.023	067			9585X	FTA6	STC	
111.024	037			9586X		RAR	
111.025	025			9587X		DCR	D
111.026	372	023	111	9588X		JM	FTA6
111.031	126			9589X		MOV	D,M
111.032	053			9590X		DCX	H
111.033	246			9591X		ANA	M
111.034	137			9592X		MOV	E,A
111.035	256			9593X		XRA	M
111.036	167			9594X		MOV	M,A
111.037	173			9595X		MOV	A,E
111.040	007			9596X	FTA7	RLC	
111.041	025			9597X		DCR	D
111.042	372	040	111	9598X		JM	FTA7
111.045	306	060		9599X	FTA7.5	ADI	'0'
111.047	341			9600X		POP	H
111.050	167			9601X		MOV	M,A
111.051	043			9602X		INX	H
111.052	315	202	105	9603X		CALL	FPNRM
111.055				9604X	FTA8	EQU	*
111.055	021	153	112	9605X		LXI	D,FP10,

```

111.080 315 323 105 9606X CALL FPAUL
111.083 303 372 110 9607X JMP FTA4 HAVE NOT PRINTED DECIMAL YET
9608X
9609X * ADD EXPONENT, IF NECESSARY
9610X
111.066 361 9611X FTA8.5 POP PSW
111.087 332 135 111 9612X JC FTA12 NOT SCIENTIFIC
9613X
9614X * ADD EXPONENT
9615X
111.072 066 105 9616X MVI M, 'E'
111.074 043 9617X INX H
111.075 066 053 9618X MVI M, 'F'
111.077 075 9619X DCR A
111.100 362 107 111 9620X JP FTA9
111.103 066 055 9621X MVI M, '-'
111.105 057 9622X CMA
111.106 074 9623X INR A
111.107 043 9624X FTA9 INX H
111.110 066 057 9625X MVI M, '0'-1
111.112 064 9626X FTA10 INR M DECODE 10S DIGIT
111.113 326 012 9627X SUI 10
111.115 362 112 111 9628X JP FTA10
111.120 306 012 9629X ADI 10
111.122 043 9630X INX H
111.123 066 057 9631X MVI M, '0'-1
111.125 064 9632X FTA11 INR M
111.126 075 9633X DCR A
111.127 362 125 111 9634X JP FTA11
111.132 303 152 111 9635X JMP FTA13 DONT TRIM TRAILING THINGS
9636X
9637X * DONE STRIP TRAILING ZEROS.
9638X
111.135 053 9639X FTA12 DCX H
111.136 176 9640X MOV A, M
111.137 376 060 9641X CPI '0'
111.141 312 135 111 9642X JE FTA12
111.144 376 056 9643X CPI ' '
111.146 302 152 111 9644X JNE FTA13 NOT
111.151 053 9645X DCX H
111.152 043 9646X FTA13 INX H
111.153 066 040 9647X MVI M, ' ' ADD TRAILING BLANK
111.155 043 9648X INX H
9649X
111.156 321 9650X POP D (DE) = NUMBER FWA
111.157 175 9651X MOV A, L
111.160 223 9652X SUB E
111.161 353 9653X XCHG
111.162 033 9654X BCX D
111.163 301 9655X POP B
111.164 311 9656X RET
9657X
111.165 051 000 000 9658X FTA4 DB 510,0,0,2000 '5.E-7'
    
```

```

9660X ** DDN - DECODE DECIMAL NUMBER.
9661X *
9662X * ENTRY (HL) = TEXT POINTER
9663X * EXIT (DE) = VALUE (IF NON-NULL)
9664X * (HL) UPDATED
9665X * TO 'DDNERR' IF NULL
9666X * USES ALL
9667X
9668X
111.171 9669X DDN EQU *
111.171 315 320 111 9670X CALL $CVD CHECK DECIMAL VALUE
111.174 332 122 070 9671X JC DDNERR HAVE NO DECIMAL DIGITS
111.177 021 000 000 9672X LXI D,0 (DE) = ACCUMULATOR
111.202 315 320 111 9673X DDN1 CALL $CVD CHECK DECIMAL VALUE
111.205 330 9674X RC NO MORE DIGITS
111.206 345 9675X PUSH H SAVE TEXT POINTER
111.207 353 9676X XCHG (HL) = MULTIPLIER
111.210 051 9677X DAD H (HL) = X*2
111.211 124 9678X MOV D,H
111.212 135 9679X MOV E,L
111.213 051 9680X DAD H (HL) = X*4
111.214 051 9681X DAD H (HL) = X*8
111.215 031 9682X DAD D (HL) = X*10
111.216 332 122 070 9683X JC DDNERR OVERFLOW
111.221 137 9684X MOV E,A
111.222 026 000 9685X MVI D,0 (DE) = DIGIT VALUE
111.224 031 9686X DAD D
111.225 332 122 070 9687X JC DDNERR NO GOOD
111.230 353 9688X XCHG (DE) = VALUE
111.231 341 9689X POP H
111.232 005 9690X DCR B COUNT DF
111.233 043 9691X DDN2 INX H
111.234 303 202 111 9692X JMP DDN1 ACCEPT ANOTHER

```

```

9694X ** DFD - DECODE FLOATING DECIMAL.
9695X *
9696X * DFD PERFORMS THE EQUIVALENT TO DDN, BUT DOES IT IN
9697X * THE FLOATING POINT ACCUMULATOR.
9698X *
9699X
9700X
111.237 315 320 111 9701X DFD CALL $CVD CHECK VALID DEC
111.242 330 9702X RC NO GOOD
111.243 062 212 042 9703X STA ACCY+2
111.246 345 9704X PUSH H
111.247 305 9705X PUSH B SAVE (B)
111.250 041 153 112 9706X LXI H,FP10.
111.253 315 327 105 9707X CALL MUL SCALE ACCUM
111.256 041 210 042 9708X LXI H,ACCY
111.261 315 356 104 9709X CALL ADD ADD VALUE
111.264 301 9710X POP B
111.265 341 9711X POP H
111.266 005 9712X DCR B COUNT DIGIT

```

111.267 043 9713X DFD1 INX H
 111.270 303 237 111 9714X JMP DFD ANOTHER DIGIT
 9715 LDF C
 111.273 9716 XTEXT WER

9718X ** \$WER - WRITE ENABLE RAM.
 9719X *
 9720X * \$WER IS CALLED TO ENABLE WRITING TO THE H17 CONTROLLER'S
 9721X * RAM AREA.
 9722X *
 9723X * ENTRY NONE
 9724X * EXIT NONE
 9725X * USES NONE
 9726X

031.241 9727X
 9728X \$WER EQU 31241A IN H17 ROM

9730X ** \$WDR - WRITE DISABLE RAM.
 9731X *
 9732X * \$WDR IS CALLED TO DISABLE WRITING TO THE H17 CONTROLLER'S
 9733X * RAM AREA.
 9734X *
 9735X * ENTRY NONE
 9736X * EXIT NONE
 9737X * USES NONE

9738X
 9739X
 031.222 9740X \$WDR EQU 31222A IN H17 ROM
 070.122 9741 DDNERR EQU ERR.IN
 111.273 9742 XTEXT CLL

9744X ** CLL - COMPUTE LINE LENGTH.
 9745X *
 9746X * CLL COUNTS THE NUMBER OF CHARACTERS IN A SOURCE LINE.
 9747X * THE LINE IS TERMINATED BY A 00 BYTE; THE 00 BYTE IS ENCLUDED
 9748X * IN THE COUNT.
 9749X *
 9750X * ENTRY (HL) = FWA OF LINE
 9751X * EXIT (HL) UNCHANGED
 9752X * (A) = LENGTH OF LINE
 9753X * USES A,F

9754X
 9755X
 111.273 345 9756X \$CLL PUSH H SAVE STARTING ADDRESS
 111.274 325 9757X PUSH D
 111.275 026 000 9758X MVI B,0
 9759X

CLL

111.277	176	9760X	CLL1	MOV	A,H	
111.300	024	9761X		INR	D	
111.301	247	9762X		ANA	A	
111.302	043	9763X		INX	H	
111.303	302 277 111	9764X		JNZ	CLL1	SCAN FOR END
111.306	172	9765X		MOV	A,D	
111.307	321	9766X		POP	B	
111.310	341	9767X		POP	H	
111.311	311	9768X		RET		
111.312		9769		XTEXT	CRLF	

9771X ** \$CRLF - TYPE CARRIAGE RETURN/ LINE FEED
 9772X *
 9773X * \$CRLF IS USED TO GENERATE PADDED CRLF'S.
 9774X *
 9775X * ENTRY NONE
 9776X * EXIT (A) = 0
 9777X * USES A-F
 9778X
 9779X

111.312	076 012	9780X	\$CRLF	MVI	A,NL	
111.314	377 002	9781X		DB	SYSCALL,SCOUT	
111.316	257	9782X		XRA	A	
111.317	311	9783X		RET		
111.320		9784		XTEXT	CVD	

9786X ** \$CVD - CHECK FOR VALID DIGIT.
 9787X *
 9788X * CVD EXAMINES A DIGIT TO SEE IF IT IS A VALID DECIMAL DIGIT.
 9789X *
 9790X * ENTRY (HL) = ADDRESS OF CHARACTER
 9791X * EXIT 'C' SET IF ILLEGAL
 9792X * (A) = VALUE
 9793X * USES A-F
 9794X
 9795X

111.320	176	9796X	\$CVD	MOV	A,H	(A) = CHARACTER
111.321	326 060	9797X	\$CVD.	SUI	'0'	
111.323	330	9798X		RC		ILLEGAL
111.324	376 012	9799X		CPI	9+1	
111.326	077	9800X		CAC		
111.327	311	9801X		RET		
111.330		9802		XTEXT	ZERO	

\$ZERO

9804X ** \$ZERO - ZERO MEMORY
 9805X *
 9806X * \$ZERO ZEROS A BLOCK OF MEMORY.
 9807X *
 9808X * ENTRY (HL) = ADDRESS
 9809X * (B) = COUNT
 9810X * EXIT (A) = 0
 9811X * USES A,B,F,H,L
 9812X
 9813X
 031.212 9814X \$ZERO EQU 31212A IN H17 ROM
 111.330 9815 XTEXT SOB

9817X ** \$SOB - SKIP OVER BLANKS.
 9818X *
 9819X * \$SOB IS CALLED TO SKIP AN ARBITRARILY LONG STRING OF BLANKS AND TABS.
 9820X *
 9821X * ENTRY (HL) = FWA OF (POSSIBLE) BLANK STRING
 9822X * EXIT (HL) = LWA+1 OF BLANK STRING (UNCHANGED IF NO BLANKS)
 9823X * (A) = FIRST NON-BLANK, NON-TAB CHARACTER EEN
 9824X * USES A,F,H,L
 9825X
 9826X
 111.330 053 9827X \$SOB DCX H PRE-DECREMENT
 111.331 043 9828X \$SOB1 INX H
 111.332 176 9829X MOV A,M
 111.333 376 040 9830X CPI '
 111.335 312 331 111 9831X JE \$SOB1 GOT BLANK
 111.340 376 011 9832X CPI TAB
 111.342 312 331 111 9833X JE \$SOB1 GOT TAB
 111.345 311 9834X RET
 111.346 9835 XTEXT CDEHL

9837X ** \$CDEHL - COMPARE (DE) TO (HL)
 9838X *
 9839X * \$CDEHL COMPARES (DE) TO (HL) FOR EQUALITY.
 9840X *
 9841X * ENTRY NONE
 9842X * EXIT 'Z' SET IF (DE) = (HL)
 9843X * USES A,F
 9844X
 9845X
 030.218 9846X \$CDEHL EQU 30216A IN H17 ROM
 111.346 9847 XTEXT HLCFDE
 9848X ** HLCFDE - (HL) COMPARED TO (DE)
 9849X *
 9850X * THIS ROUTINE IS DOUBLE WORD COMPARE OF REGISTER PAIRS (DE) AND (HL).
 9851X *
 9852X * ENTRY: (HL)&(DE) SET UP
 9853X *

```

9854X *      EXIT: (PSW) =
9855X *      'Z' SET IF (HL) = (DE)
9856X *      'C' SET IF (HL) < (DE)
9857X *      'C' CLEAR IF (HL) >= (DE)
9858X *
9859X *
9860X *      USES: (PSW)
9861X *
9862X
111.346 174 9863X HLCPE MOV A,H
111.347 272 9864X CMP D 'C' SET => (A) < (D)
111.350 300 9865X RNZ
111.351 175 9866X MOV A,L
111.352 273 9867X CMP E 'C' SET => (L) < (E)
111.353 311 9868X RET
111.354 9869 XTEXT DU66
  
```

```

9871X **    $DU66 - UNSIGNED 16 / 16 DIVIDE.
9872X *
9873X *      (HL) = (BC)/(DE)
9874X *
9875X *      ENTRY (BC), (DE) PRESET
9876X *      EXIT (HL) = RESULT
9877X *      (DE) = REMAINDER
9878X *      USES ALL
9879X
9880X
030.106 9881X $DU66 EQU 30106A IN H17 ROM
111.354 9882 XTEXT MUB6
  
```

```

9884X **    $MUB6 - MULTIPLY 8X16 UNSIGNED.
9885X *
9886X *      $MUB6 MULTIPLIES A 16 BIT VALUE BY A 8
9887X *      BIT VALUE.
9888X *
9889X *      ENTRY (A) = MULTIPLIER
9890X *      (DE) = MULTIPLICAND
9891X *      EXIT (HL) = RESULT
9892X *      'Z' SET IF NOT OVERFLOW
9893X *      USES A,F,H,L
9894X
9895X
031.007 9896X $MUB6 EQU 31007A IN H17 ROM
111.354 9897 XTEXT ZEROS
  
```

9899X ** B CONSTANT ZERO BYTES.
 9900X *
 031.320 9901X \$ZEROS EQU 31320A IN H17 ROM
 111.354 9902 XTEXT UDD

9904X ** \$UDD - UNPACK DECIMAL DIGITS.
 9905X *
 9906X * UDD CONVERTS A 16 BIT VALUE INTO A SPECIFIED NUMBER OF
 9907X * DECIMAL DIGITS. THE RESULT IS ZERO FILLED.
 9908X *
 9909X * ENTRY (B,C) = ADDRESS VALUE
 9910X * (A) = DIGIT COUNT
 9911X * (H,L) = MEMORY ADDRESS
 9912X * EXIT (HL) = (HL) + (A)
 9913X * USES ALL
 9914X
 9915X
 031.157 9916X \$UDD EQU 31157A IN H17 ROM
 111.354 9917 XTEXT CCO

9919X ** \$CCO - CLEAR CONTROL-0
 9920X *
 9921X * \$CCO IS CALLED TO CLEAR THE EFFECT OF THE CTL-0 CHARACTER.
 9922X *
 9923X * ENTRY NONE
 9924X * EXIT NONE
 9925X * USES NONE
 9926X
 9927X
 111.354 315.054.031 9928X \$CCO CALL \$SAVALL SAVE REGISTERS
 111.357 076.004 9929X MVI A,I,CONFL
 111.361 001.001.000 9930X LXI B,CO,FLG CLEAR CO,FLG
 111.364 377.006 9931X DB SYSCALL,CONSL
 111.366 303.047.031 9932X JMP \$RSTALL RESTORE REGISTERS AND RETURN
 111.371 9933 XTEXT DADA

9935X ** \$DADA - PERFORM (H,L) = (H,L) + (07A)
 9936X *
 9937X * ENTRY (H,L) = BEFORE VALUE
 9938X * (A) = BEFORE VALUE
 9939X * EXIT (H,L) = (H,L) + (07A)
 9940X * 'C' SET IF OVERFLOW
 9941X * USES F,H,L
 9942X
 9943X
 030.072 9944X \$DADA EQU 30072A IN H17 ROM
 111.371 9945 XTEXT DADA2

\$DADA

```

9947X ** $DADA. - ADD (0,A) TO (H,L)
9948X *
9949X * ENTRY NONE
9950X * EXIT (HL) = (HL) + (0A)
9951X * USES A,F,H,L
9952X *
9953X *
030.101 9954X $DADA. EQU 30101A IN H17 ROM
111.371 9955 XTEXT MOVE
  
```

```

9957X ** $MOVE - MOVE DATA
9958X *
9959X * $MOVE MOVES A BLOCK OF BYTES TO A NEW MEMORY ADDRESS,
9960X * IF THE MOVE IS TO A LOWER ADDRESS, THE BYTES ARE MOVED FROM
9961X * FIRST TO LAST.
9962X *
9963X * IF THE MOVE IS TO A HIGHER ADDRESS, THE BYTES ARE MOVED FROM
9964X * LAST TO FIRST.
9965X *
9966X * THIS IS DONE SO THAT AN OVERLAPED MOVE WILL NOT 'RIPPLE'.
9967X *
9968X * ENTRY (BC) = COUNT
9969X * (DE) = FROM
9970X * (HL) = TO
9971X * EXIT MOVED
9972X * (DE) = ADDRESS OF NEXT FROM BYTE
9973X * (HL) = ADDRESS OF NEXT TO* BYTE
9974X * 'C' CLEAR
9975X * USES ALL
9976X *
9977X *
030.252 9978X $MOVE EQU 30252A IN H17 ROM
111.371 9979 XTEXT MU66
  
```

```

9981X ** $MU66 - UNSIGNED 16X16 MULTIPLY.
9982X *
9983X * ENTRY (BC) = MULTIPLICAND
9984X * (DE) = MULTIPLIER
9985X * EXIT (HL) = RESULT
9986X * 'Z' SET IF NOT OVERFLOW
9987X * USES ALL
9988X *
9989X *
030.337 9990X $MU66 EQU 30337A IN H17 ROM
111.371 9991 XTEXT TBCS
  
```

\$TBLS

```

9993X ** $TBLS - TABLE SEARCH
9994X *
9995X * TABLE FORMAT
9996X *
9997X * DB KEY1,VAL1.
9998X *
9999X *
10000X * DB KEYN,VALN
10001X * DB 0
10002X *
10003X * ENTRY (A) = PATTERN
10004X * (H,L) = TABLE FWA
10005X * EXIT (A) = PATTERN IF FOUND
10006X * 'Z' SET IF FOUND
10007X * 'Z' CLEAR IF NOT FOUND OR PATTERN=0 /78.10.6C/
10008X * USES A,F,H,L
10009X
10010X
111.371 305 10011X $TBLS PUSH B
111.372 376 000 10012X CPI 0 /78.10.6C/
111.374 312 016 112 10013X JZ TBL2 /78.10.6C/
111.377 107 10014X MOV B,A
112.000 176 10015X TBL1 MOV A,M (A) = CHARACTER
112.001 043 10016X INX H
112.002 270 10017X CMP B
112.003 312 020 112 10018X JZ TBL3 IF MATCH
112.006 247 10019X ANA A
112.007 043 10020X INX H SKIP PAST
112.010 302 000 112 10021X JNZ TBL1 IF NOT END OF TABLE
112.013 053 10022X DCX H
112.014 053 10023X DCX H
112.015 257 10024X XRA A SET TO ZERO FOR OLD USERS /78.10.6C/
112.016 376 001 10025X TBL2 CPI 1 CLEAR ZERO /78.10.6C/
10026X
10027X * DONE
10028X
112.020 301 10029X TBL3 POP B
112.021 311 10030X RET
112.022 10031 XTEXT TBRA

```

```

10033X ** $TBRA - BRANCH RELATIVE THROUGH TABLE.
10034X *
10035X * $TBRA USES THE SUPPLIED INDEX TO SELECT A BYTE FROM THE
10036X * JUMP TABLE. THE CONTENTS OF THIS BYTE ARE ADDED TO THE
10037X * ADDRESS OF THE BYTE, YEILDING THE PROCESSOR ADDRESS.
10038X *
10039X * CALL $TBRA
10040X * DB LAB1-* INDEX = 0 FOR LAB1
10041X * DB LAB2-* INDEX = 1 FOR LAB2
10042X * DB LABN-* INDEX = N-1 FOR LABN
10043X *
10044X * ENTRY (A) = INDEX
10045X * (RET) = TABLE FWA

```

*TBRA

```

10046X *      EXIT      TO COMPUTED ADDRESS
10047X *      USES      F,H,L
10048X
10049X
031.076      10050X $TBRA EQU      31076A      IN H17 ROM
112.022      10051      XTEXT    TJMP
.
10053X **     $TJMP - TABLE JUMP.
10054X *
10055X *      USAGE
10056X *
10057X *      CALL      $TJMP      (A) = INDEX
10058X *      DW        ADDR1
10059X *      .
10060X *      .
10061X *      .
10062X *      DW        ADDRN
10063X *
10064X *      ENTRY      (A) = INDEX
10065X *      EXIT      TO PROCESSOR
10066X *      (A) = INDEX*2
10067X *      USES      NONE.
10068X
10069X
031.061      10070X $TJMP EQU      31061A      IN H17 ROM, (A) = INDEX*2
10071X
031.062      10072X $TJMP EQU      31062A      IN H17 ROM
112.022      10073      XTEXT    TYPCH
.
10075X **     $TYPCH - TYPE SINGLE CHARACTER.
10076X *
10077X *      ENTRY      (RET) = CHARACTER
10078X *      EXIT      TO (RET)+1
10079X *      (A) = CHARACTER TYPED
10080X
10081X
112.022 343  10082X $TYPCH XTHL      (HL) = RETURN ADDRESS
112.023 176  10083X      MOV      A,M      (A) = CHARACTER
112.024 043  10084X      INX      H
112.025 343  10085X      XTHL      RESTORE ADVANCED EXIT ADDRESS
10086X
10087X **     $TYPC: - TYPE SINGLE CHARACTER.
10088X *
10089X *      ENTRY      (A) = CHARACTER
10090X *      EXIT      TO (RET)
10091X
112.026 377 002 10092X $TYPC. DB      SYSCALL, SCOUT
112.030 311  10093X      RET
112.031      10094      XTEXT    TYPTX

```

```

10096X ** $TYPTX - TYPE TEXT.
10097X *
10098X * $TYPTX IS CALLED TO TYPE A BLOCK OF TEXT ON THE SYSTEM CONSOLE.
10099X *
10100X * IMBEDDED ZERO BYTES INDICATE A CARRIAGE RETURN LINE FEED,
10101X * A BYTE WITH THE 2000 BIT SET IS THE LAST BYTE IN THE MESSAGE.
10102X *
10103X * ENTRY (RET) = TEXT
10104X * EXIT TO (RET+LENGTH)
10105X * USES A,F
10106X
10107X
031.136 10108X $TYPTX EQU 31136A IN H17 ROM
10109X
031.144 10110X $TYPTX. EQU 31144A IN H17 ROM
112.031 10111 XTEXT GNL
  
```

```

10113X ** $GNL - GUARANTEE NEW LINE.
10114X *
10115X * $GNL GUARANTEES THE START OF A NEW LINE BY ISSUING A CRLF
10116X * IF THE CURSOR IS NOT AT COLUMN 1..
10117X *
10118X * ENTRY NONE
10119X * EXIT NONE
10120X * USES ALL
10121X
10122X
112.031 076 002 10123X $GNL MVI A,I,CUSOR
112.033 001 000 000 10124X LXI B,0
112.036 377 006 10125X DB SYSCALL,CONSL READ CURSOR
112.040 075 10126X DCR A
112.041 310 10127X RZ AT COLUMN 1
112.042 303 312 111 10128X JMP $CRLF NEW LINE
112.045 10129 XTEXT CHL
  
```

```

10131X ** $CHL - COMPLEMENT (HL).
10132X *
10133X * (HL) = -(HL) TWO'S COMPLEMENT
10134X *
10135X * ENTRY NONE
10136X * EXIT NONE
10137X * USES A,F,H,L
10138X
10139X
030.224 10140X $CHL EQU 30224A IN H17 ROM
112.045 10141 XTEXT COMP
  
```

*COMP

```

10143X **      *COMP - COMPARE TWO CHARACTER STRINGS.
10144X *
10145X *      *COMP COMPARES TWO BYTE STRINGS.
10146X *
10147X *      ENTRY  (C) = COMPARE COUNT
10148X *          (DE) = FWA OF STRING #1
10149X *          (HL) = FWA OF STRING #2
10150X *      EXIT   'Z' CLEAR, IS MIS-MATCH
10151X *          (C) = LENGTH REMAINING
10152X *          (DE) = ADDRESS OF MISMATCH IN STRING#1
10153X *          (HL) = ADDRESS OF MISMATCH IN STRING #2
10154X *          'C' SET, HAVE MATCH
10155X *          (C) = 0
10156X *          (DE) = (DE) + (0C)
10157X *          (HL) = (HL) + (0C)
10158X *      USES  A,F,C,D,E,H,L
10159X
10160X
030.060      10161X *COMP EQU 30060A      IN H17 ROM
112.045      10162      XTEXT  MCU
  
```

```

10164X **      MCU - MAP LOWER CASE TO UPPER CASE.
10165X *
10166X *      MCU MAPS A LOWER CASE ALPHABETIC TO UPPER
10167X *      CASE.
10168X *
10169X *      ENTRY  (A) = CHARACTER
10170X *      EXIT  (A) = CHARACTER RESULT
10171X *      USES  A,F
10172X
10173X
112.045  376 141 10174X *MCU  CPI      'a'
112.047  330      10175X      RC              NOT LOWER CASE
112.050  376 173 10176X      CPI      'z'+1
112.052  320      10177X      RNC              NOT LOWER CASE
112.053  326 040 10178X      SUI      'a'-'A'
112.055  311      10179X      RET
112.056      10180      XTEXT  MU10
  
```

```

10182X **      *MU10 - MULTIPLY UNSIGNED 16 BIT QUANTITY BY 10.
10183X *
10184X *      (HL) = (DE)*10
10185X *
10186X *      ENTRY  (DE) = MULTIPLIER
10187X *      EXIT  'C' CLEAR IF OK
10188X *          (HL) = PRODUCT
10189X *          'C' SET IF ERROR
10190X *      USES  D,E,H,L,F
10191X
10192X
  
```


030.324 10193X *MU10 EQU 30324A IN H17 ROM
 112.056 10194 XTEXT SAVALL

10196X ** \$RSTALL - RESTORE ALL REGISTERS.
 10197X *
 10198X * \$RSTALL RESTORES ALL THE REGISTERS OFF THE STACK, AND
 10199X * RETURNS TO THE PREVIOUS CALLER.
 10200X *
 10201X * ENTRY (SP) = PSW
 10202X * (SP+2) = BC
 10203X * (SP+4) = DE
 10204X * (SP+6) = HL
 10205X * (SP+8) = RET
 10206X * EXIT TO *RET*, REGISTERS RESTORED
 10207X * USES ALL
 10208X
 10209X

031.047 10210X *RSTALL EQU 31047A IN H17 ROM

10212X ** \$SAVALL - SAVE ALL REGISTERS ON STACK.
 10213X *
 10214X * \$SAVALL SAVES ALL THE REGISTERS ON THE STACK.
 10215X *
 10216X * ENTRY NONE
 10217X * EXIT (SP) = PSW
 10218X * (SP+2) = BC
 10219X * (SP+4) = DE
 10220X * (SP+6) = HL
 10221X * USES H,L
 10222X
 10223X

031.054 10224X *SAVALL EQU 31054A IN H17 ROM
 112.056 10225 XTEXT INDL

10227X ** \$INDL - INDEXED LOAD.
 10228X *
 10229X * \$INDL LOADS DE WITH THE TWO BYTES AT (HL)+DISPLACEMENT
 10230X *
 10231X * THIS ACTS AS AN INDEXED FULL WORD LOAD.
 10232X *
 10233X * (DE) = ((HL) + DISPLACEMENT)
 10234X *
 10235X * ENTRY ((RET)) = DISPLACEMENT (FULL WORD)
 10236X * (HL) = TABLE ADDRESS
 10237X * EXIT TO (RET+2)
 10238X * USES A,F,D,E
 10239X
 10240X

030.234 10241X *INDL EQU 30234A IN H17 ROM

112.056

10242

XTEXT MTD0C

10244X *** MANAGED TABLES.
10245X *
10246X * THE FOLLOWING STRUCTURES ARE MANAGED TABLES.
10247X *
10248X * SEVERAL TABLES OF DATA ARE 'MANAGED' BY A SUBROUTINE
10249X * PACKAGE SO THAT THEIR SIZES MAY VARY INDEFINITELY.
10250X *
10251X * EACH TABLE HAS A CERTAIN AMOUNT OF FREE SPACE LOCATED AFTER
10252X * IT. WHEN A TABLE NEEDS TO BE ENLARGED, %ATS (ALLOCATE
10253X * TABLE SPACE) PERFORMS THE ALLOCATION. IF SUFFICIENT FREE SPACE
10254X * FOLLOWS THE TABLE, IT IS SIMPLY ALLOCATED.
10255X *
10256X * IF THE FREE SPACE FOLLOWING THE TABLE IS INSUFFICIENT, ALL
10257X * TABLES ARE MOVED, REDUCING THE FREE SPACE BEHIND EACH ONE, IN
10258X * ORDER TO CONCENTRATE SUFFICIENT FREE SPACE BEHIND THE ONE
10259X * NEEDING IT. THUS, WHEN TABLE OVERFLOW OCCURS, ALL TABLES HAVE
10260X * OVERFLOWED, IN THAT THERE IS NO MORE FREE SPACE AVAILABLE
10261X * BEHIND ANY OF THEM.
10262X *
10263X * STORAGE USED:
10264X *
10265X * THE MANAGED TABLE PACKAGE USES MEMORY STARTING AT SYMBOL %TAREA
10266X * EXTENDING TO THE VALUE IN (%MNL). (%MNL) MAY BE INCREASED DURING
10267X * EXECUTION, BUT IT SHOULD NOT BE DECREASED.
10268X *
10269X * FREE SPACE ALLOCATION:
10270X *
10271X * WHEN THE TABLES MUST BE MOVED, %ATS DIVIDES UP THE MEMORY FREE
10272X * SPACE AMONG THE TABLES. HOWEVER, THIS SPLITTING IS NOT NECESSARY
10273X * EVEN. EACH TABLE CONTAINS A ONE BYTE ALLOCATION FACTOR,
10274X * INDICATING HOW MANY 1/16THS SHARES IT WILL RECEIVE. THESE
10275X * NUMBERS MUST ALL ADD UP TO 16 (THUS, THE NEXT NUMBER OF TABLES
10276X * IS 16, SINCE NO ALLOCATION FACTOR MAY BE 0).
10277X *
10278X * TABLE USAGE:
10279X *
10280X * NO TABLE ITEM (EXCEPT ITEMS IN THE 1ST TABLE) MAY BE REFERENCED
10281X * BY ADDRESS, SINCE THE ADDRESS MAY BE CHANGED (VIA TABLE MOVES)
10282X * AT ANY TIME. INSTEAD, THE ITEMS SHOULD BE REFERENCED BY
10283X * TABLE INDEX, THAT IS, THEIR SEQUENTIAL POSITION WITHIN THE
10284X * TABLE.

10286X ** TABLE INDEX.
10287X *
10288X * THE FOLLOWING INDEXES ARE USED TO KEEP TRACK OF TABLES. ALL
10289X * TABLE INDEXES MUST APPEAR CONTIGUOUSLY IN MEMORY.
10290X *
10291X *
10292X * MTABIND EQU *
10293X * [INDEX FOR TABLE 1]
10294X *
10295X *
10296X * [INDEX FOR TABLE N]
10297X * DB 0 DUMY ALLOCATION BYTE
10298X * MEML DW 0 MEMORY LIMIT
10299X *MTABL EQU *-MTABIND/5 NUMBER OF TABLES.
10300X *
10301X * INDEX FORMAT:
10302X *
10303X * DB FACT ALLOCATION FACTOR (NUMBER OF 1/16THS)
10304X * DW FWA TABLE FWA
10305X * DW LEN TABLE LENGTH
10306X
000.000 10307X MT.AFC EQU 0 ALLOCATION FACTOR
000.001 10308X MT.FWA EQU 1 FWA INDEX
000.003 10309X MT.LEN EQU 3 LENGTH FIELD
112.054 10310 MTABIND EQU * FWA OF 1ST TABLE HEADER

```

10314 **      TXTTAB - USER SOURCE TEXT TABLE.
10315 *
10316 *      FORMAT:
10317 *
10318 *      DW      LINE      LINE NUMBER
10319 *      DB      'TEXT'   LINE TEXT
10320 *      DB      0        END OF LINE
10321 *
10322 *      LINE NUMBER 65535 (377377A) IS ALWAYS PRESENT IN THE TABLE,
10323 *      BUT MAY NOT BE ALTERED OR DISPLAYED.
10324 *
112.056 001   10325 TXTTAB DB      1      ALLOCATION COUNT
112.057 346 114 10326 DW      MTAREA  FWA
112.061 003 000 10327 DW      3      LENGTH

10329 **      SYMTAB - SYMBOL TABLE.
10330 *
10331 *      SYMTAB CONTAINS THE USER SYMBOL TABLE.
10332 *      AN ENTRY IS PRESENT FOR EACH
10333 *
10334 *      1) SCALAR NUMERIC VARIABLE
10335 *      2) SCALAR NUMERIC FUNCTION
10336 *      3) SCALAR STRING VARIABLE
10337 *      4) SCALAR STRING FUNCTION
10338 *      5) NUMERIC VECTOR
10339 *      6) STRING VECTOR
10340 *
10341 *      ENTRY  FORMAT:
10342 *
10343 *      THE ENTRY FORMAT DEPENDS UPON THE SYMBOL TYPE.
10344 *      ALL SCALAR ENTRIES ARE 6 BYTES LONG WITH VECTORS BEING LONGER.(SEE BELOW)
10345 *      THE FIRST TWO BYTES OF ALL ENTRIES ARE ALWAYS FORMATTED:
10346 *
10347 *      DB      'C'      1ST CHARACTER OF VARIABLE NAME
10348 *      DB      N+F     N * 2ND CHARACTER INDEX
10349 *                      (0=NONE, 0001B='0',...,1010B='9')
10350 *                      F=00000000 SCALAR NUMERIC VARIABLE
10351 *                      =00000001 SCALAR STRING VARIABLE
10352 *                      =00000010 NUMERIC VECTOR
10353 *                      =00000011 STRING VECTOR
10354 *
10355 *      THE REMAINING  BYTES ARE FORMATTED:
10356 *
10357 *      1) SCALAR NUMERIC VARIABLE:
10358 *
10359 *      DW      V1      4 BYTE FLOATING POINT VALUE
10360 *      DW      V2
10361 *
10362 *      2) SCALAR NUMERIC FUNCTION
10363 *
10364 *      DB      201*   DB      2010      FUNCTION FLAG
10365 *      DW      ADDR  TEXT ADDRESS OF FUNCTION LINE
10366 *      DB      0      UNUSED

```

```

10367 *
10368 * 3) SCALAR STRING VARIABLE
10369 *
10370 * DB LEN,0 LENGTH
10371 * DW STRNAM STRING NAME ((LABEL) SEE SYMTAB)
10372 *
10373 * 4) SCALAR STRING FUNCTION
10374 *
10375 * DB 2010 FUNCTION FLAG
10376 * DW ADDR TEXT ADDRESS OF FUNCTION LINE
10377 * DB 0 UNUSED
10378 *
10379 * 5) NUMERIC VECTOR
10380 *
10381 * DB DIM,0 NUMBER OF DIMENSIONS
10382 * DW SIZE SIZE OF ARRAY (# OF BYTES FROM L1 TO NEXT ENTRY)
10383 * L1 DW DIM 1 DIMENSION 1
10384 * . . .
10385 * . . .
10386 * . . .
10387 * DW DIM N DIMENSION N
10388 * DW V1 4 BYTE FLOATING POINT VALUE
10389 * DW V2
10390 * . . .
10391 * . . .
10392 * . . .
10393 * DW V M-1
10394 * DW V M
10395 *
10396 * 6) STRING VECTOR
10397 *
10398 * DB DIM,0 NUMBER OF DIMENSIONS
10399 * DW SIZE SIZE OF ARRAY
10400 * DW DIM 1 DIMENSION 1
10401 * . . .
10402 * . . .
10403 * . . .
10404 * DW DIM N DIMENSION N
10405 * DW LABEL 1 STRING LABEL
10406 * DW LEN 1 LENGTH OF STRING
10407 * . . .
10408 * . . .
10409 * . . .
10410 * DW LABEL M
10411 * DW LEN M
10412 *
10413 *
112.063 001 10414 SYMTAB DB 1 ALLOCATION FACTOR
112.064 351 114 10415 DW NTAREA+3
112.066 000 000 10416 DW 0

```

10418 ** FORTAB - FOR/NEXT LOOP TABLE.
 10419 *
 10420 * FORTAB IS USED TO KEEP TRACK OF THE INDEX VARIABLE FOR
 10421 * 'FOR/NEXT' LOOPS.
 10422 *
 10423 * ENTRY FORMAT:
 10424 *
 10425 * DB /C,N+I SYMBOL TABLE KEY (SEE SYMTAB) /80,01,0C/
 10426 * DW INC,INC INCREMENT VALUE
 10427 * DW TRM,TRM TERMINATEION VALUE
 10428 * DW LOOPADR ADDRESS FOR 'FOR' LOOP
 10429 *
 10430 *
 112,070 001 10431 FORTAB DB 1 ALLOCATION FACTOR
 112,071 351 114 10432 DW MTAREA+3
 112,073 000 000 10433 DW 0 LENGTH

10435 ** GOSTAB - SOSUB TABLE.
 10436 *
 10437 * GOSTAB CONTAINS THE RETURN ADDRESSES (AND LINE NUMBERS)
 10438 * FOR GOSUB CONSTRUCTS.
 10439 *
 10440 * ENTRY FORMAT:
 10441 *
 10442 * DW ADDR RETURN TEXT ADDRESS
 10443 * DW STATNO RETURN LINE NUMBER
 10444 *
 10445 *
 112,075 001 10446 GOSTAB DB 1 ALLOCATION FACTOR
 112,076 351 114 10447 DW MTAREA+3
 112,100 000 000 10448 DW 0

10450 ** WRKTAB - WORKING STORAGE TABLE.
 10451 *
 10452 * WRKTAB IS USED BY THE EXPRESSION EVALUATOR TO STORE
 10453 * (ON A STACK) WORKING VALUES.
 10454 *
 10455 * EACH ENTRY CONSISTS OF 5 BYTES; USUALLY A DESCRIPTOR BYTE
 10456 * AND 4 VALUE BYTES.
 10457 *
 10458 *
 112,102 001 10459 WRKTAB DB 1 ALLOCATION INDEX
 112,103 351 114 10460 DW MTAREA+3
 112,105 000 000 10461 DW 0

```

10483 ** STRTAB - PERMANENT STRING TABLE.
10464 *
10485 * STRTAB HOLDS PERMANENT STRING VARIABLES USED IN BASIC.
10466 *
10487 * EACH STRING IS INDEXED BY AN ENTRY IN SYMTAB OR UECTAB.
10468 *
10489 * ENTRY FORMAT:
10470 *
10471 * EACH STRING APPEARS CONTIGUOUSLY IN MEMORY, NO TRAILING
10472 * CHARACTER IS USED SINCE LENGTHS ARE KNOWN IN THE POINTER.
10473 * EXAMPLE:
10474 *
10475 * DS 2 STRING LABEL (2NN NNN FOR PERM. STRING; 3NN NNN
10476 * FOR A TEMPORARY STRING)
10477 * DS N ASCII STRING ( N=1 TO 256 )
10478 * .
10479 * .
10480 * .
10481 * DS 2 NTH LABEL
10482 * DS N
10483
10484
112.107 002 10485 STRTAB DB 2 ALLOCATION INDEX
112.110 351 114 10486 DW MTAREA+3
112.112 000 000 10487 STRLEN DW 0
  
```

```

10489 ** TSITAB - TEMPORARY STRING TABLE
10490 *
10491 * TSITAB HOLDS ALL TEMPORARY STRING VARIABLES USED IN BASIC.
10492 *
10493 * THE FORMAT USED IS SIMILAR TO THAT OF STRTAB.
10494
10495
112.114 001 10496 TSITAB DB 1
112.115 351 114 10497 DW MTAREA+3
112.117 000 000 10498 DW 0
  
```

```

10500 ** FILE TABLE.
10501 *
10502 * CONTAINS BUFFER FOR EACH OPEN FILE.
10503
112.121 000 10504 FILTAB DB 0 ALLOCATION INDEX
112.122 351 114 10505 DW MTAREA+3 FWA
112.124 000 000 10506 DW 0 LWA
  
```

```

10508 **      DUMY LAST TABLE.
10509 *
10510 *      FORMATTED LIKE REGULAR TABLE, BUT CONTAINS
10511 *      MOVE COUNT, AND MEMORY LIMIT VALUES.
10512
000.010      10513 MTABL EQU      *-MTABIND/5      NUMBER OF TABLES
112.124 000      10514 DB          0              STORAGE MOVES (IN ALLOCATING INDEX CELL)
112.127 351 114      10515 MEML DW      MTAREA+3      MEMORY LIMIT ADDRESS (IN FWA CELL)
112.131          10516 DS          2              TABLE LENGTH CELL NOT USED
10517
000.005      10518 MTABLEN EQU      5              LENGTH OF EACH TABLE HEADER

```

```

10520 **      POINTERS TO CURRENT INFORMATION ABOUT RUN.
10521
112.133 000 000      10522 CURNUM DW      0              CURRENT LINE NUMBER
112.135 000 000      10523 CURADR DW      0              CURRENT LINE ADDRESS
112.137 000          10524 LCKFLG DB      0              DATA LOCK FLAG
10525
10526 **      CURRENT I.O CHANNEL.
10527 *
10528 *      =0      SYSTEM CONSOLE
10529 *      =1      INTERNAL FILE
10530 *      =1+N    BASIC CHANNEL N (N=1 TO X, IF N=0 THEN IOCHAN=0)
10531
112.140 000          10532 IOCHAN DB      0
10533
112.141 000          10534 DULMAN DB      0              <> IF TO LOCK OVERLAY
10535
112.142 000          10537 CTLFLAG DB      0              CTL CHARACTERS FLAG BYTE
000.001          10538 CFCTLG EQU      0010          CTL-C HIT
000.002          10539 CFCTLE EQU      0020          CTL-R HIT

```

```

10541 **      STRING INDEXES.
10542 *
10543
112.143 200 000      10544 STRVJ DW      000200A
112.145 300 000      10545 STRTI DW      000300A

```

```

10547 **      FLOATING POINT VALUES.
10548 *
10549
112.147 000 000 100 10550 FP1.0 DB      0,0,1000,2010
112.153 000 000 120 10551 FP10. DB      0,0,1200,2040
112.157 146 146 146 10552 FP0.1 DB      1460,1460,1460,1750
031.320          10553 FP0.0 EQU      $ZEROS
112.163 022 170 233 10554 NPI.2 DB      0220,1700,2330,2010      -PI/2
112.167 022 170 233 10555 NPI.2 DB      0220,1700,2330,2030      -PI*2
112.173 022 170 233 10556 NPI DB      0220,1700,2330,2020      -PI
112.177 022 170 233 10557 NPI.4 DB      0220,1700,2330,2000      -PI/4

```


112.203 356 207 144 10558 PI.4 DB 356Q,207Q,144Q,200Q PI/4

112.207 040 10559
10560 SPACE DB SPACE CHARACTER

```

10563 ** PRS - PRESET BASIC.
10564 *
10565 * PRS PERFORMS PRESET INITIALIZATION.
10566 *
10567
112.210 10568 PRS EQU *
10569
10570 * CHECK THE HDOS VERSION
10571
112.210 377 011 10572 DB SYSCALL,VERS
112.212 332 014 113 10573 JC PRSERR1 NO SYSTEM CALL
112.215 376 026 10574 CPI VERS
112.217 302 014 113 10575 JNZ PRSERR1 NOT THE CORRECT VERSION
10576
10577 * REQUEST MINIMAL MEMORY
10578
112.222 041 346 114 10579 LXI H,MTAREA
112.225 377 052 10580 DB SYSCALL,SETTP
112.227 332 016 113 10581 JC PRSERR NOT EVEN ENOUGH MEMORY TO START
10582
10583 * SET UP THE INTERNAL WORK FILE BLOCK
10584
112.232 052 120 041 10585 LHLD S,SCR HL = ADDRESS OF *HDOS* SCRATCH BUFFER
112.235 042 232 042 10586 SHLD FBSCR+2+0
112.240 042 234 042 10587 SHLD FBSCR+2+2
112.243 042 236 042 10588 SHLD FBSCR+2+4
112.246 021 000 002 10589 LXI D,512
112.251 031 10590 DAD D
112.252 042 240 042 10591 SHLD FBSCR+2+6
10592
10593 * PROCEED WITH INITIALIZATION
10594
112.255 315 357 073 10595 CALL DTS DELETE TEMP. STRINGS
112.260 072 033 040 10596 LDA .TICCNT INITIALIZE RANDOM NUMBER SEED
112.263 147 10597 MOV H,A
112.264 157 10598 MOV L,A
112.265 042 101 061 10599 SHLD RNDA INITIALIZE SEED
112.270 021 016 000 10600 LXI D,14 /80.01.6C/
112.273 315 003 046 10601 CALL CNTL4 SET TAB-FIELD WIDTH TO 14 /80.01.6C/
112.276 041 370 100 10602 LXI H,CBINT
112.301 076 002 10603 MVI A,CTLB
112.303 377 041 10604 DB SYSCALL,.CTLC SETUP CTL-B HANDLER
112.305 041 363 100 10605 LXI H,CCINT
112.310 076 003 10606 MVI A,CTLC
112.312 377 041 10607 DB SYSCALL,.CTLC SETUP CTL-C HANDLER
112.314 315 136 031 10608 CALL $TYPTX
112.317 012 012 105 10609 PRSA DB NL,NL,Extended Benton Harbor BASIC #110.05.00,ENL
112.371 315 115 074 10610 CALL FDC SET TABLES TO MAXIMUM AREA
112.374 315 360 044 10611 CALL SCR SCRATCH TEXT
10612
10613 *****
10614 *****
10615 ** **
10616 ** Note: Be very careful about the following initializations. **
10617 ** Be sure that the instructions do not destroy thems- **
10618 ** selves. **

```

```

10619 **
10620 ** Note: If you don't understand the following error messages **
10621 ** neither do I, just love it and leave it. **
10622 **
10623 *****
10624 *****
10625 *****
10626 XRA A
10627
112.377 257 10628 STA ZERO CLEAR LINE-1
10629 SET ZERO
113.000 062 345 114 10630 IF *-1/
114.345 10631 ERRMI ,--PRSB *-1 <
10632 ENDIF * < PRSB
10633
113.003 062 272 113 10634 STA LINE+LINEL+6 INSURE 0 AT END OF LINE
113.272 10635 SET LINE+LINEL+6
10636 IF *-1/
10637 ERRMI ,--PRSB *-1 <
10638 ENDIF * < PRSB
10639
113.006 062 300 114 10640 STA LINE2+LINEL+6 INSURE 0 AT END OF LINE
114.300 10641 SET LINE2+LINEL+6
10642 IF *-1/
10643 ERRMI ,--PRSB *-1 <
10644 ENDIF * < PRSB
10645
113.011 303 124 043 10646 JMP RESTART START PROGRAM
113.014 10647 PRSB EQU *
10648
113.014 076 050 10649 PRSERR1 MVI A,EC.NCV NOT THE CORRECT VERSION OF *HDOS*
10650
113.016 046 012 10651 PRSERR MVI H,NL
113.020 377 057 10652 DB SYSCALL,ERROR OUTPUT THE ERROR
113.022 257 10653 XRA A
113.023 377 000 10654 DB SYSCALL,EXIT QUIT BEFORE PROBLEMS ARISE
10655
113.025 10656 PRSLIM EQU * LWA OF PRS CODE
10657
113.025 10658 LOADL EQU * LOAD LWA
10659
10660
10661 ** OVERLAID BUFFER AREA
10662
112.253 10663 ORG PRSLIM-106
10664
10665 ** COLUMN COUNTERS.
10666 *
10667 * SINCE SEVERAL CHANNELS MAY BE PRINTED ON, INTERMINGLED,
10668 * A SEPERATE COLUMN COUNTER IS KEPT FOR EACH.
10669 * THIS TABLE IS INDEXED BY THE CONTENTS OF IOCHAN
10670
112.253 10671 COLCNTS DS CHANMAX+1+2 ONE FOR EACH CHANNEL, +2 FOR TTY AND INTERNAL
10672
10673
112.263 10674 DS 2 USED BY ITL (WHEN CALLED BY BUILD)

```

112.265	10675	LINE	DS	0	LINE BUFFER	/80.01.6C/
112.265	10676		DS	255		/80.01.6C/
000.377	10677	LINE1	EQU	*-LINE	LINE LENGTH	
000.237	10678		ERRMI	*-PRSLIM	FOLLOWING CELLS CHANGED BY PRS CODE	
113.264	10679		DS	6	ROOM FOR EXPANDED LINE NUMBER	/78.10.6C/
113.272	10680		DS	1	ALWAYS 0 TO GUARANTEE END OF LINE	
	10681					
113.273	10682	LINE2	DS	LINE1	WORK AREA	
114.272	10683		DS	6	ROOM FOR EXPANDED LINE NUMBER	/78.10.6C/
114.300	10684		DS	1	ALWAYS ZERO TO GUARANTEE END OF LINE	
	10685					
112.265	10686	FNRMA	EQU	LINE	FNRM WORK AREA	
	10687					
114.301	10688	RUNMOD	DS	1		
114.302	10689	STATE	DS	1		
114.303	10690	DATPTR	DS	2		

	10692	**			PATCH AREA.	
	10693					
114.305	10694	PATCH	DS	32		

	10696	**			BEGINNING OF MANAGED TABLE ADDRESS.	
	10697	*				
	10698					
114.345	10699	ZERO	DS	1	DUMY END OF FIRST LINE -1	
114.346	10700	MTAREA	EQU	*	BEGINNING OF MANAGED TABLES AREA	
	10701					
114.346	10702		DS	100	AUX. PATCH AREA	
	10703					
115.112	10704				END	

ASSEMBLY COMPLETE
10704 STATEMENTS
0 ERRORS DETECTED
18656 BYTES FREE

CROSS REFERENCE TABLE

.EXIT	000000	536L	1250	7573	7579	10654															
.HORN	002140	303E																			
.IDENT	000000	298E																			
.IOWRK	040002	321E	2432	2434	3841	3842															
.LINK	000040	553L	2796																		
.LOAD	001267	300E																			
.LOADD	000062	571L																			
.LOADO	000010	544L																			
.MFLAG	040010	325E	1050																		
.MONMS	000202	580L																			
.MOUNT	000200	578L																			
.NAME	000054	565L																			
.OPENC	000045	558L																			
.OPENR	000042	555L	7590																		
.OPENU	000044	557L	7592																		
.OPENW	000043	554L	7591																		
.PEHL	002264	306E																			
.POSIT	000047	560L																			
.PRINT	000003	539L	1821	2012																	
.RCK	003260	314E	3816																		
.READ	000004	540L	8123																		
.REGI	040005	322E																			
.REGFTR	040035	333E																			
.RENAM	000051	562L																			
.RESET	000204	582L																			
.RNB	002331	309E																			
.RNF	002325	308E																			
.SCIN	000001	537L	3488	6986	8191																
.SCOUT	000002	538L	8178	8195	9781	10092															
.SETTF	000052	563L	6199	10580																	
.SRS	002245	307E																			
.START	040000	320E																			
.SYSRES	000012	546L																			
.TICCNT	040033	332E	2480	2483	10596																
.TFERR	002205	305E																			
.TFERRX	040031	331E																			
.UIVEC	040037	334E																			
.VERS	000011	545L	10572																		
.UNR	003024	312E																			
.UNP	003017	311E																			
.WRITE	000005	541L	7844	7952	8019																
ABS	057055	3348	3428L																		
ABS.DOB	000010	841L	845																		
ABS.ENT	000006	839L																			
ABS.ID	000000	835L																			
ABS.LDA	000002	837L																			
ABS.LEN	000004	838L																			
ACCX	042202	855L	2047	2262	3162	3269	3299	3336	3391	3428	3441	3456	3457								
		3465	3513	3559	3656	3658	3689	3749	3797	3830	3870	3877	3901	3934							
		3953	3954	3963	3971	4017	4065	4091	4145	4162	4208	4219	4313	4341							
		4367	4417	4450	4463	4491	4511	4536	4599	4603	4638	4718	4771	5399							
		5415	5444	5448	5744	5938	5953	5972	6342	6375	6801	6841	6870	6922							
		7412	8600	8616	8618	8619	8623	8660	8825	8860	8894	9002	9165	9166							
		9183	9267	9405	9408	9510	9526	9536	9544	9549	9578										
ACEY	042310	857L	3600	3646	3662	3795	4095	4147	4156	4214	4328	4393	4458								
		4690	4732	4749	5745	5954	6887	6888	6933	7413	9417	9703	9708								
ACTLE	044216	1174E	1296	1479																	
ADD	104356	4392	4394	4462	4509	4556	4570	4625	4694	4769	8598E	8724	9709								

ATSA	103356	8218	8285E			
ATSB	104124	8326	8383L	8398		
ATSC	104125	8384L	8397			
AUV	071202	2053	2082	4277	5394L	6774
AUV1	071222	5410L				
AYS	071146	1247	1259	5367L		
BAS1	043203	961	968L			
BAS2	043240	974	986L			
BAS3	043233	972	983L			
BEC.AC	000230	393L	5123			
BEC.CB	000201	370L	5063			
BEC.CC	000200	369L	5060			
BEC.CIU	000233	396L	5135			
BEC.DO	000203	372L	5069			
BEC.DE	000202	371L	5066			
BEC.EN	000224	389L	1730			
BEC.FAE	000226	391L	5117			
BEC.FND	000231	394L	5126			
BEC.IC	000222	387L	5114			
BEC.ILF	000227	392L	5120			
BEC.IN	000204	373L	5072			
BEC.IU	000205	374L	5075			
BEC.LK	000206	375L	5078			
BEC.LTL	000232	395L				
BEC.ND	000221	386L	5111			
BEC.NV	000207	376L	5081			
BEC.OV	000210	377L	5084			
BEC.RE	000211	378L	5087			
BEC.SC	000220	385L	5108			
BEC.SL	000212	379L	5090			
BEC.SN	000213	380L	5093			
BEC.SR	000217	384L	5105			
BEC.ST	000225	390L	2781			
BEC.SY	000214	381L	1233	5094		
BEC.TC	000215	382L	5099			
BEC.TD	000216	383L	5102			
BEC.UD	000223	388L	5132			
BELL	000007	343E	1232	5041	5156	5368
BKSP	000010	345E				
BLD1	044255	1211L	1227	1238		
BLD2	044320	1218	1231L			
ROOT.P	000001	758E				
BUILD	044247	1111	1208E			
BYE	044337	1112	1245E			
C.STX	000002	347E				
C.SYN	000026	346E				
CAS	071334	5465L				
CAS1	071346	5474E	5487			
CB.CLI	000100	268E	283			
CB.MTL	000040	267E				
CB.SPK	000200	269E				
CB.SSI	000020	266E				
CBINT	100370	930	7469L	10602		
CBINT1	100372	7460	7470L			
CBT	103042	7624	7753	7794	7912	8044L
CBT1	103051	8049L	8058			
CCINT	100363	933	7459L	10605		
CDB.H84	000001	701E				

CT.STP	000255	161L	5031						
CT.STR	000345	233L	5029						
CT.SYE	000212	123L	4727	5041					
CT.TAB	000346	234L	2550	5032					
CT.TAN	000347	235L	5033						
CT.THM	000316	205L	1934	5034					
CT.TO	000317	206L	1786	5035					
CT.UHF	000245	150L	5036						
CT.UHL	000246	151L	5037						
CT.UNS	000247	152L	5038						
CT.VAL	000356	246L	5039						
CT.VARH	000307	193E	2020	3293	6459	6703			
CT.VARL	000300	192E	1313	2018	3291	6452	6701		
CT.VUV	000302	190L							
CT.VSV	000303	191L							
CT.WRI	000313	202L	2363	5040					
CTR	103070	772E	7773	7888	7915	8070L			
CTB1	103101	8076L	8085						
CTLA	000001	354E							
CTLB	000002	355E	931	10603					
CTLC	000003	356E	934	10606					
CTLD	000004	357E							
CTLFLAG	112142	949	1027	2164	2506	6982	7482	10537L	
CTLO	000017	358E							
CTLP	000020	359E							
CTLQ	000021	360E							
CTLS	000023	361E							
CTLZ	000032	362E							
CTP.2SR	000010	664E							
CTP.BKM	000002	665E							
CTP.BKS	000200	661E							
CTP.MLI	000040	662E							
CTP.NLQ	000020	663E							
CTP.TAB	000001	666E							
CUF	073104	5862E	7049						
CUF1	073107	5866L	5874						
CUF2	073126	5872	5878E						
CUF3	073163	5886	5904L						
CUF4	073172	5890	5912L						
CURADR	112135	1168	1300	1369	1409	1729	1917	10523L	
CURNUM	112133	1071	2710	2772	6416	7287	10522L		
CVX	073210	2221	2255	4168	4684	4748	5936L		
CXV	073237	2236	2884	5969L					
CXV	073240	5405	5970L						
CXY	073223	4319	4388	4456	4679	4725	4746	4767	5951E
D.CON	040110	616L							
D.RAM	040240	619L							
D.VEC	040130	618L							
DATFTR	114303	1308	2651	2653	10690L				
DCN	073253	1983	2094	2542	5995L				
DCN.	073273	1422	2370	6000	6009L				
DCN..	073302	6019L							
DCN1	073322	6026	6028L						
DDN	111171	5177	9448	9669E					
DDN1	111202	9377	9473L	9692					
DDN2	111233	9381	9691L						
DDNERR	070122	9671	9683	9687	9741E				
DEF	046133	1155	1568E						

BASIC - HEATH BASIC INTERPRETER.
CROSS REFERENCE TABLE

XREF V1.1
PAGE 230

DEFALTD	043100	924L	2415						
DEFALTF	043072	923L	2723	2731	2809	7073			
DELETE	046162	1114	1592E						
DF.CLR	000376	468E							
DF.EMP	000377	467E							
DFD	111237	9420	9701L	9714					
DFD1	111267	9424	9713L						
DIM	046236	1127	1624E	1715					
DIM2	046265	1638L	1662						
DIM3	047011	1703L	1708						
DIMS	047033	1627	1719L						
DIMA	047034	1626	1720E						
DIR.ALD	000025	483L							
DIR.CLU	000015	476L							
DIR.CRD	000023	482L							
DIR.EXT	000010	471L							
DIR.FGN	000020	479L							
DIR.FLG	000016	477L							
DIR.LGN	000021	480L							
DIR.LSI	000022	481L							
DIR.NAM	000000	470L							
DIR.PRO	000013	472L							
DIR.VER	000014	473L							
DIRELEN	000027	485E	516	792					
DIRIDL	000015	474E							
DIV	106264	4460	4574	4658	4728	4750	9031E	9469	
DIV0	106305	9034	9040L						
DIV1	106355	9061L	9109						
DIV2	106365	9066L	9100						
DIV3	107020	9078	9088L						
DIVA	106367	9046	9068E						
DIVB	106373	9048	9072E						
DIVC	106377	9050	9076E	9121					
DM.MR	000000	273E							
DM.MW	000001	274E							
DM.RR	000002	275E							
DM.RW	000003	276E							
DNF	073326	1429	6044L	6054					
DTS	073357	1089	1281	6068L	10595				
D TSA	073366	1298	6071E						
EC.CNA	000004	406L							
EC.DDA	000027	425L							
EC.DIF	000017	417L							
EC.DIW	000035	431L							
EC.DNI	000045	439L							
EC.DNR	000046	440L							
EC.DNS	000005	407L							
EC.DSC	000047	441L							
EC.EOF	000001	403L	5129	7613	7743	8132			
EC.EOM	000002	404L							
EC.FAD	000031	427L	7543						
EC.FAP	000026	424L							
EC.FL	000030	426L							
EC.FNF	000014	414L	2726						
EC.FND	000011	411L	7631						
EC.FNR	000034	430L							
EC.FOD	000043	437L							
EC.FUC	000013	413L							

M.CLWA	000014	815L																			
M.COBT	000010	813L																			
M.CFRE	000003	809L																			
M.CRUB	000004	810L																			
M.CSLC	000002	808L																			
M.FOX	000303	293E																			
M.FAMB	000021	292E																			
M.SALO	000001	807L																			
M.SYSM	000000	806L																			
MATC2.3	060257	3715	3747L																		
MATC2.5	060260	3719	3748L																		
MATCH	060111	3378	3683E																		
MATCH1	060225	3726L	3745																		
MATCH2	060247	3728	3741L																		
MATCH3	060273	3737	3757L																		
MATCHA	060307	3684	3703	3767L																	
MATCHB	060276	3707	3760E																		
MATCHC	060313	3692	3699	3768L																	
MAX	060317	3357	3780L																		
MAX1	060325	3787L	3804																		
MAX2	061002	3789	3808L																		
MEML	112127	1873	6186	6193	8271	8327	10515L														
MI.ADDR	000200	52E	8845																		
MI.CMC	000077	54E	9032																		
MI.IN	000333	61E	3840																		
MI.JMF	000303	53E																			
MI.LDA	000072	55E																			
MI.LXIB	000001	64E	5061	5064	5067	5070	5073	5076	5079	5082	5085	5088	5091								
		5094	5097	5100	5103	5106	5109	5112	5115	5118	5121	5124	5127	5130							
		5133																			
MI.LXIB	000021	63E	3000																		
MI.LXIH	000041	62E																			
MI.MVIA	000076	56E	2302	3780																	
MI.NOP	000000	59E	947	5300																	
MI.OBT	000323	57E	2431																		
MI.RET	000311	60E	6715																		
MI.SUBB	000220	58E	9032																		
MID#	057314	3379	3581E																		
MID#1	057365	3582	3615E																		
MID#2	060032	3609	3623	3642E																	
MID#3	060043	3649	3651L																		
MID#4	060050	3652	3654L																		
MIN	060320	3358	3781L																		
MOV	071015	3958	3975	4160	4166	5243L	5452														
MOV4	076051	1792	1799	3685	3693	4220	5939	5973	6668L												
MOV5	076045	5955	6663E	6910	6948																
MT.AFC	000000	10307E																			
MT.FWA	000001	1342	2229	2690	5197	5224	5329	5422	5436	5767	5788	5880	6304								
		6307	6568	6906	7181	10308E															
MT.LEN	000003	1283	1284	1293	1294	1295	1625	1721	1816	2228	2280	2283	2386								
		2672	2700	5141	5531	5593	5631	5866	6044	6054	6069	6565	6900	6903							
		7127	7178	10309E																	
MTABIND	112056	1816	5141	5593	8384	10310E	10513														
MTABL	000010	1818	5596	8383	10513E																
MTABLEN	000005	10518E																			
MTAREA	114346	885	896	896	896	896	902	902	902	902	908	908	908								
		908	914	914	914	914	914	920	920	920	920	1299	1307	1611	1728						
		5595	6246	7129	7130	10326	10415	10432	10447	10460	10486	10497	10505	10515							

BASIC - HEATH BASIC INTERPRETER.
CROSS REFERENCE TABLE

XREF V1.1
PAGE 242

S.MOUNT	041032	754L				
S.OFWA	040350	708L	1539			
S.OHAX	040324	649L	1553	6182		
S.OSN	041004	737L				
S.OVLE	041000	734L				
S.OVFL	040371	730L				
S.OVLS	040376	733L				
S.OVSTR	041035	762L				
S.RFWA	040356	711L				
S.SCI	041024	751L				
S.SCR	041120	800L	10585			
S.SDD	041010	747L				
S.SDVR	041146	623L	625			
S.SSN	041002	736L				
S.SYSM	040320	645L	1545	6175		
S.TIME	040312	642L				
S.UCSF	040372	731L				
S.UCSL	040374	732L				
S.USRM	040322	647L	6195			
S.VAL	040277	620L	638			
SAVE	053302	1118	2720E			
SAVE1	053324	2684	2731L			
SCR.	044360	1261L	2300	10611		
SCRA	077320	1261	5149	7068	7126L	
SCRATCH	044351	1119	1257E			
SEG	061170	3364	3919L			
SERKOR	070223	5137E	6200			
SFS	077342	1154	1585	7145L	7148	7282
SFS.	077362	1750	7172L			
SFS.	077352	2217	7166L			
SFS0	077375	7170	7177L			
SFS1	100025	7187	7198L	7221		
SFS2	100060	7211	7215L			
SFS3	100073	7200	7225L			
SFS4	100074	7214	7229L			
SFS5	100075	7230L	7253			
SFS6	100120	7209	7250L			
SGN	061205	3365	3933L			
SIN.	064117	3366	4484E			
SOP	100126	1939	2852	2920	6125	7262L 7268
SQB1	100137	7264	7267L			
SPACE	112207	2636	10560L			
SPE	107215	8586	8719	8737	8809	8837 9022 9226L
SPEX	107225	9229	9235L			
SQR	063360	3368	4414E			
SQRT1	064011	4435L				
SQRT2	064015	4431	4438L			
SQRT3	064112	4421	4470L			
SRA	100143	1186	1900	2324	7280L	
SRS	107231	6355	8654	9246E		
SRS.	107232	8690	9248L			
SRS.	107233	3532	9249L	9311		
STACK	042200	627E	943			
STACKL	001032	625E				
START	043106	929E	1891			
STATE	114302	10689L				
STEP	053356	1120	2752L			
STEP1	053374	2762L	2769			

BASIC - HEATH BASIC INTERPRETER,
CROSS REFERENCE TABLE

XREF V1.1
PAGE 244

VERS	000026	527E	10574																		
WEL	100225	2581	2631	7340L																	
WELA	100241	7343	7347L																		
WLF	100242	2162	7340L																		
WLF1	100251	2572	2638	7311	7345	7372L															
WLF2	100301	7383	7393L																		
WRNTAB	112102	1295	6900	6903	6906	6945	10459L														
XCY	100317	3783	3803	3809	4192	4207	4778	7409L													
XCY1	100332	7415L	7423																		
XPOLYQ	065142	4575	4608	4637L																	
ZERO	114345	1373	1885	2173	2743	5375	7092	10628	10629	10699L											
ZRO	100351	5441	7439L	7445																	

13574 BYTES FREE