

altair<sup>TM</sup>  
FLOPPY DISK DOCUMENTATION



mits





PRELIMINARY DOCUMENTATION RELEASE

This manual is incomplete in its present form. This page and an additional section will be sent to you within a short period for insertion.

This documentation contains the entire assembly and check-out information for both the disk controller and drive units. The Theory of Operation and some additional information will be in the insertation.

altair FLOPPY DISK  
DRIVE AND CONTROLLER  
HARDWARE DOCUMENTATION



## ATTENTION

### Floppy Disk Owners

On Controller Board #1, look for the revision number in the lower right-hand corner. On Controller Board #2, look for the revision number in the upper middle portion of the board. If Board #1 is Revision 0X4, and if Board #2 is Revision 1, use the attached insert pages to replace the corresponding pages in the assembly section of the manual. Please note that the pages listed below have no corresponding replacement page and should be completely deleted.

- a) 98A
- b) 106
- c) 107
- d) 110
- e) 111



88-DCDD  
PARTS LIST  
FEBRUARY, 1977

BAG 1

5	74L00	101080
6	74L02	101072
8	74L04	101073
3	74L10	101081
1	74LS11	101089
1	74L20	101039
1	74L30	101082
7	74L73	101084
2	74LS74	101088
5	74L75	101075
1	7493	101030
8	74123	101060
1	74164	101091
1	74166	101092
3	93L16	101093
5	8T97 or 74367	101040
1	8T98	101045
2	7805	101074

NOTE: 74LS ICs may be substituted for 74L ICs.

BAG 2

37	.1mf 12v 20%	100348
----	--------------	--------

BAG 3

1	430pf 500v 5%	100322
1	910pf 500v 5%	100356
2	.001mf 1KV 20%	100328
1	.01mf 16v 20%	100321
2	.047mf 100v 5%	100332
2	.1mf 100v 5%	100339
1	.22mf 100v 5%	100349
2	.68mf 100v 5%	100343
1	1.0mf 100v 5%	100373
1	5mf 25V	100323
1	10mf 16v	100350
4	33mf 16v	100326
3	470 pf disk	100316

BAG 4

4	220 ohm 1/2W 5%	101925
4	330 ohm 1/2W 5%	101926
10	1K 1/2W 5%	101928
1	5.6K 1/2W 5%	102091
1	6.8K 1/2W 5%	101931
7	10K 1/2W 5%	101932
2	15K 1/2W 5%	102083
1	18K 1/2W 5%	101941
2	20K 1/2W 5%	101940
1	39K 1/2W 5%	101967
3	470 ohm 1/2W 5%	101927
1	22K 1/2W 5%	101933

BAG 5

2	IN914	100705
10	#6-32 x 3/8" Screw	100925
2	#6-32 Nut	100933
2	#6 Lock Washer	100942
4	#4-40 x 3/8" Screw	100908
4	#4-40 Nut	100932
4	#4 Lock Washer	100941
1	3 ft. 18 Pair Cable	103066
1	37 Pin Adapter Bracket	101795

BAG 6

2	100 Pin Edge Connector	101864
1	DC37S Connector	102114
2	10 Pin Right Angle Wafer	101798
2	20 Pin Right Angle Wafer	101788
2	10 Pin Connector	101720
2	20 Pin Connector	101789
70	Terminal Pins	101723
4	Polarizing Keys	101791
2	Fastwrap	1013037
1	Heat Sink Grease	
2	Heat Sink (large)	101870
4	Card Guides	101714

BAG 7

16	Test Points	101663
3	Ferrite Beads	101876
36	14-pin Sockets	102102
23	16-pin Sockets	102103

MISC.

1	Controller PC Board 1	100216
1	Controller PC Board 2	100217
1	Disk Extended BASIC Manual	101578



88-DISC  
PARTS LIST  
MARCH, 1977

BAG 1

1	74L30	101082
2	7805	101074
1	7824	101079
4	8T97 or 74367	101040
1	8T98	101045
1	9601	101033

BAG 2

4	.1mf 12v	100348
3	.1mf 50v	100312
3	33mf 50v	100311
1	500mf 15-25v	100310
1	100mf 25v	100365
1	2200mf 50v	100376
1	3300mf 16v	100315

BAG 3

3	150 ohm 1/2W	101915
17	330 ohm 1/2W	101926
1	1K 1/2W	101928
1	39K 1/2W	101967
1	7.5 ohm 5W	101987
1	33 ohm 1/2W	101921

BAG 4

17	220 ohm 1/2W	101925
3	RL21	100702
2	VJ048	100711
2	IN4004	100718
*1	TIP 145 or 146	102820
1	IN914	100705

BAG 5

1	12 ft. 18 Pair Cable	103066
2	6 ft. #20 Black	103062
3	2 ft. #20 Orange	103063
2	3 ft. #26 White	103060

\*With Mica Insulator and  
Shoulder Washer

BAG 6

8	#4-40 x 5/16" Screw	100912
2	#4-40 x 1/2" Screw Flat Head	100903
2	#4-40 x 1" Screw	100913
10	#4-40 Nut	100932
8	#4 Lock Washer	100941
4	#4 Flat Washer	100940
6	#6-32 x 3/8" Pan Head Screw	100925
6	#6-32 x 1/2" Pan Head Screw	100918
4	#6-32 x 5/8" Pan Head Screw	100916
2	#6-32 x 3/4" Pan Head Screw	100935
4	#6-32 x 1" Pan Head Screw	100919
4	#6-32 x 2" Flat Head Screw	100937
27	#6-32 Nut	100933
35	#6 Lock Washer	100942
1	#6 Ground Lug	101801
2	.15" Spacer	101823
6	5/16" Spacer	101829
2	.6" Spacer	101824
4	#6 Flat Washer	100943
2	#6-32 x 1/4" Screw	100917

BAG 7

1	Heat Sink	101775
1	Heat Sink	101835
1	Disk Drive Spacer 1/2"	101841
1	Right Angle Bracket	101717
1	Strain Relief	101719
1	Terminal Block	101868
30	Insulated Terminal	101803
1	Fuse Holder	101813
2	DC37S Connector	102114
2	DC37P Connector	102115
2	DC37 Connector Cover	101799
1	Toggle Switch ST1-1C	101879
1	44-Pin Edge Connector	101800
1	Keying Pin (for above)	101660
15	Fastwrap	103037
1	Heat Sink Grease	
1	Fuse 2ASB 3AG	101762
3	#6-32 x 3/4" Self Tap Screw	100957

MISC.

1	Power Cord 3 Wire	101742
1	Disk Mechanism (Pertec) FD400	101602
1	Case	100511
1	Disk Rail	101862
1	Fan Filter	101757
1	Fan and (4) clips	101869
1	Transformer, 26V	102612
1	Programmer Transformer, 24V, 9V	102620
1	Diskette (blank)	101712
1	Power Supply PC Board	100171
1	Buffer PC Board	100172
1	"Altair Disk" Nameplate	101808
1	Serial Number Sticker	101833
1	Assy, Theory, Oper. Manual	101531






# ASSEMBLY HINTS

Before beginning the construction of your unit, it is important that you read the "MITS Kits Assembly Hints" booklet included with your kit. Pay particular attention to the section on soldering, because most problems in the Altair occur as the result of poor soldering. It is essential that you use the correct type of soldering iron. A 25-30 watt iron with a chisel tip (such as an Ungar 776 with a 7155 tip) is recommended in the assembly hints booklet.

Some important warnings are also included in the hints booklet. Read them carefully before you begin work on your unit -- failure to heed these warnings could cause you to void your warranty.

Check the contents of your kit against the enclosed parts list to make sure you have all the required components, hardware and parts. The components are in plastic envelopes; do not open them until you need the components for an assembly step. You will need the tools called for in the "Kits Assembly Hints" booklet.

As you construct your kit, follow the instructions in the order they are presented in the assembly manual. Always complete each section before going on to the next. Two organizational aids are provided throughout the manual to assist you: 1) Boxed-off parts identification lists, with spaces provided to check off the components as they are installed; 2) Reproductions of the silk screens showing a) previously installed components, b) components being installed and c) components yet to be installed. (see below)




## COMPONENT INSTALLATION METHODS

This section of the manual describes the proper procedures for installing various types of components in your kit.

Read these instructions over very carefully and refer back to them whenever necessary. Failure to properly install components may cause permanent damage to the component or the rest of the unit; it will definitely void your warranty.


More specific instructions, or procedures of a less general nature, will be included within the assembly text itself.

Under no circumstances should you proceed with an assembly step without fully understanding the procedures involved. A little patience at this stage will save a great deal of time and potential "head-aches" later.



INTEGRATED CIRCUITS (IC's) CAN COME WITH ANY ONE OF, OR A COMBINATION OF, SEVERAL DIFFERENT MARKINGS. THESE MARKINGS ARE VERY IMPORTANT IN DETERMINING THE CORRECT ORIENTATION FOR THE IC's WHEN THEY ARE PLACED ON THE PRINTED CIRCUIT BOARDS. REFER TO THE ABOVE DRAWING TO LOCATE PIN 1 OF THE IC's, THEN USE THIS INFORMATION IN CONJUNCTION WITH THE INFORMATION BELOW TO PROPERLY ORIENT EACH IC FOR INSTALLATION.

**WARNING:** INCORRECTLY ORIENTED IC's MAY CAUSE PERMANENT DAMAGE!



THE DRAWING ON THE LEFT INDICATES VARIOUS METHODS USED TO SHOW THE POSITION OF IC's ON THE PRINTED CIRCUIT BOARDS. THESE ARE SILK-SCREENED DIRECTLY ON THE BOARD. THE ARROWHEAD INDICATES THE POSITION FOR PIN 1 WHEN THE IC IS INSTALLED.

## IC Installation

All ICs must be oriented so that the notched end is toward the end with the arrowhead printed on the PC board. Pin 1 of the IC should correspond with the pad marked with the arrowhead. If the IC does not have a notch on one end, refer to the IC Identification Chart to identify Pin 1.

### To prepare ICs for installation:

All ICs are damaged easily and should be handled carefully -- especially static-sensitive MOS ICs. Always try to hold the IC by the ends, touching the pins as little as possible. When you remove the IC from its holder, CAPEFULLY straighten any bent pins using needle-nose pliers. All pins should be evenly spaced and should be aligned in a straight line, perpendicular to the body of the IC itself.

#### A. Installing ICs without sockets:


1. Orient the IC so that Pin 1 coincides with the arrowhead on the PC board.
2. Align the pins on one side of the IC so that just the tips are inserted into the proper holes on the board.
3. Lower the other side of the IC into place. If the pins don't go into their holes right away, rock the IC back, exerting a little inward pressure, and try again. Be patient. The tip of a small screwdriver may be used to help guide the pins into place. When the tips of all the pins have been started into their holes, push the IC into the board the rest of the way. Tape the IC to the board with a piece of masking tape.
4. Turn the board over and solder each pin to the foil pattern on the back side of the board. Be sure to solder each pin and be careful not to leave any solder bridges. Remove the masking tape.

#### WARNING:

Make sure none of the pins have been pushed underneath the IC during insertion.

#### B. Installing ICs with sockets:

1. Referring to the drawing below, set the IC socket into the designated holes on the board and secure it with a piece of masking tape.




2. Turn the board over and solder each pin to the foil pattern on the back side of the board. Be sure to solder each pin and be careful not to leave any solder bridges. Remove the masking tape.
3. Orient the IC over the socket so that Pin 1 coincides with the arrowhead on the PC board.
4. Align the pins on one side of the socket so that just the tips are inserted into the holes.
5. Lower the other side of the IC into place. If the pins don't go into their holes right away, rock the IC back, exerting a little inward pressure, and try again. Be patient. When the tips of all the pins have been started into their holes, push the IC into the socket the rest of the way.

## Resistor Installation

Resistors have four (or possibly five) color-coded bands as represented in the chart below. The fourth band is gold or silver and indicates the tolerance. NOTE: In assembling a MITS kit, you need only be concerned with the three bands of color to the one side of the gold or silver (tolerance) band. These three bands denote the resistor's value in ohms. The first two bands correspond to the first two digits of the resistor's value and the third band represents a multiplier.

For example: a resistor with red, violet, yellow and silver bands has a value of 270,000 ohms and a tolerance of 10%. By looking at the chart below, you see that red is 2 and violet 7. By multiplying 27 by the yellow multiplier band (10,000), you find you have a 270,000 ohm (270K) resistor. The silver band denotes the 10% tolerance. Use this process to choose the correct resistor called for in the manual.



RESISTOR COLOR CODES		
COLOR	BANDS 1&2	3rd BAND (Multiplier)
Black	0	1
Brown	1	10
Red	2	10 <sup>2</sup>
Orange	3	10 <sup>3</sup>
Yellow	4	10 <sup>4</sup>
Green	5	10 <sup>5</sup>
Blue	6	10 <sup>6</sup>
Violet	7	10 <sup>7</sup>
Gray	8	10 <sup>8</sup>
White	9	10 <sup>9</sup>

Use the following procedure to install the resistors onto the boards. Make sure the colored bands on each resistor match the colors called for in the list of Resistor Values and Color Codes given for each board.


1. Using needle-nose pliers, bend the leads of the resistor at right angles to match their respective holes on the PC board.
2. Install the resistor into the correct holes on the silk-screened side of the PC board.
3. Holding the resistor in place with one hand, turn the board over and bend the two leads slightly outward.
4. Solder the leads to the foil pattern on the back side of the board; then clip off any excess lead lengths.

## Capacitor Installation

### A. Electrolytic and Tantalum Capacitors

Polarity requirements must be noted on the electrolytic capacitors and the tantalum capacitor before they are installed.

The electrolytic capacitors contained in your kit may have one or possibly two of three types of polarity markings. To determine the correct orientation, look for the following.



One type will have plus (+) signs on the positive end; another will have a band or a groove around the positive side in addition to the plus signs. The third type will have an arrow on it; in the tip of the arrow there is a negative (-) sign and the capacitor must be oriented so the arrow points to the negative polarity side.

The tantalum capacitor is metallic in appearance and smaller than the electrolytic capacitors. Its positive end has a plus sign on it or a red dot.

Refer to the chart included for each board for correct Capacitor Values and install the electrolytic capacitors and tantalum capacitors using the following procedure.

1. Bend the two leads of the capacitor at right angles to match their respective holes on the board. Insert the capacitor into the holes on the silk-screened side of the board. Be sure to align the positive polarity side with the "+" signs printed on the board.
2. Holding the capacitor in place, turn the board over and bend the two leads slightly outward. Solder the leads to the foil pattern and clip off any excess lead lengths.

### B. Ceramic Disk Capacitors

Refer to the chart included for each board for correct Capacitor Values, and install the ceramic disk capacitors using the following procedure.

1. Choose the correct value capacitor and straighten the two leads as necessary to fit their respective holes on the PC board.
2. Insert the capacitor into the correct holes from the silk-screened side of the board. Push the capacitor down until the ceramic insulation almost touches the foil pattern.
3. Holding the capacitor in place, turn the board over and bend the two leads slightly outward.
4. Solder the two leads to the foil pattern on the back side of the board; then clip off any excess lead lengths.

## Transistor Installation

To install transistors, use the following instructions.

NOTE: Always check the part number of each transistor before you install it. (See Listing of Transistor Part Numbers for each board.) Some transistors look identical but differ in electrical characteristics, according to part number. If you have received substitute part numbers for the transistors in you kit, check the Transistor Identification Chart which follows these instructions to be sure you make the correct substitutions.

NOTE: Always make sure the transistor is oriented so that the emitter lead is installed in the hole on the PC board labeled with an "E." To determine which lead is the emitter lead, refer to the Transistor Identification Chart.

1. After the correct transistor has been selected and the leads have been properly oriented, insert the transistor into the holes on the silk-screened side of the board.
2. Holding the transistor in place, turn the board over and bend the three leads slightly outward.
3. Solder the leads to the foil pattern on the back side of the board; then clip off any excess lead lengths.
















## Diode Installation

NOTE: Diodes are marked with a band on one end indicating the cathode end. Each diode must be installed so that the end with the band is oriented towards the band printed on the PC board. Failure to orient the diodes correctly may result in permanent damage to your unit.

Use the following procedure to install diodes onto the board. Refer to the list of Diode Part Numbers included for each board to make sure you install the correct diode each time.

1. Bend the leads of the diode at right angles to match their respective holes on the board.
2. Insert the diode into the correct holes on the silk screen, making sure the cathode end is properly oriented. Turn the board over and bend the leads slightly outward.
3. Solder the two leads to the foil pattern on the back side of the board; then clip off any excess lead lengths.

## TRANSISTOR IDENTIFICATION CHART

   EN2907* CS4438 CS4439 CS4437 CS4410 2N4250 2N3842 2N3845 (NO FLAT)	   MPF-105 MPF-111	   TIS98 TIS 92	   DIST2 2N6028	   ST2907 ST 98 S38473 2N820 2N4410 EN4410 PN2907 2N2907 EN2907*
--	---	--	---	--

IN THE ILLUSTRATION ABOVE THE OUTLINE OF EACH TYPE OF TRANSISTOR IS SHOWN OVER THE PADS ON THE CIRCUIT BOARD WITH THE CORRECT DESIGNATION FOR EACH OF THE THREE LEADS. USE THIS INFORMATION TOGETHER WITH THE INFORMATION IN THE ASSEMBLY MANUAL FOR THE CORRECT ORIENTATION OF THE TRANSISTORS AS YOU INSTALL THEM.

THE FOLLOWING IS A LIST OF POSSIBLE SUBSTITUTIONS: IF ANY OTHERS ARE USED YOU WILL RISK DAMAGING YOUR UNIT:

2N4410 = EN4410 = CS4410 = CS4437, CS4438, TIS98, ST98, S38473 (NPN)  
 EN2907 = 2N2907 = PN2907 = ST2907, CS4439 (PNP)

WHEN MAKING SUBSTITUTIONS, REFER TO THE ILLUSTRATION TO DETERMINE THE CORRECT ORIENTATION FOR THE THREE LEADS.

\*Configuration of the leads on EN2907 may vary.




# altair FLOPPY DISK DISK DRIVE ASSEMBLY PROCEDURE



## CASE TOP REMOVAL

Remove the top from the Disk Drive case by withdrawing the two screws indicated in the drawing below. Slide the case top backwards, lifting the back slightly, to remove it entirely from the chassis.


Also remove the 4 screws in the side of the case bottom, and remove the entire chassis assembly.



### DISK DRIVE BACK PANEL ASSEMBLY

Remove the back panel from the case by withdrawing each of the four screws in the corners of the panel. These four screws are shown inserted in the drawing below.

Save these four screws for remounting the back panel later in the assembly procedure.




### Terminal Block Installation

Mount the terminal block to the back panel as shown in the drawing below. Use the screw sizes and other hardware indicated in the drawing.

NOTE: Be sure that the back panel is oriented as shown; be careful not to mount the terminal block on the wrong side of the panel.

Tighten all four screws firmly into place.



## Transformer Installation

There are two transformers included in this kit. The larger of the two will be referred to as T1, the smaller as T2.

### Wire Preparation

Before mounting these transformers, the wires must be cut to the proper length and screw-mount crimp terminals attached to each of them. There are also three wires which will not be used at all, and will be cut off at the transformer coil.

Referring to the drawing on the opposite page, cut the wires on transformers T1 and T2 to the lengths indicated. The three unused wires should be cut off at the point where they enter the transformer coil itself.

Next, as indicated in the bottom of the drawing, strip exactly 1/2" of insulation from each of the eleven wires and bend the exposed portion in half to 1/4".

There are several screw-mount crimp terminals included with this kit. These have a slot in one end and an insulated portion on the other end (usually red) for attaching wires. One of these crimp terminals must be attached to each of the eleven transformer wires.

Insert one of the wires into one of the terminals as shown in the drawing. Push the wire in as far as it will go without distorting it or pushing it all the way through.

The wire should then be permanently connected to the terminal by either soldering it in place or crimping. To crimp the terminal use a crimping tool, if available, or else flatten the insulated portion of the terminal as tightly as possible using pliers.

Prepare each of the eleven transformer wires in the above manner.

### Mounting



Referring to the drawings following the "Transformer Wire Preparation" drawing, mount transformers T1 & T2 to the back panel.

NOTE: For proper orientation, transformer T1 should have the two yellow wires towards the top of the panel (with reference to the drawings), and T2 should have the two black wires towards the top of the panel.


Be sure to install a terminal lug on transformer T1 as shown in the drawing. This is a solder type lug, and not the screw-mount type used for the transformer wires.



Use the hardware indicated in the drawings to mount the transformers and tighten the screws firmly into place.

NOTE: Save all wires that you cut off for later use.



TRANSFORMER WIRE PREPARATION








### Fuse Holder Installation

Referring to the drawing below, mount the fuse holder to the back panel using the rubber washer and nut provided. Tighten it firmly into place.

Remove the cap and place the fuse provided with your kit into the holder, then replace the cap.




## 90° ANGLE CLIP INSTALLATION

The drawing below illustrates the hardware and orientation for mounting the 90° angle clip included with this kit.

**NOTE:** One side of the clip is slightly shorter than the other. The shorter side should be mounted against the back panel with the longer side extending at 90°.

Install the clip as shown below and tighten the screws firmly into place. Be sure that clip remains "square" with the panel when tightening the screws.



## Fan Installation


Before the cooling fan is installed onto the back panel, two lengths of wire must be prepared and connected to it.

There is some black wire included with the kit; cut two 6 1/2 inch lengths of this wire. Strip 1/2 inch of insulation from one end of each of the wires, and 1/4 inch of insulation from the other.

In the same manner as described on page , attach a screw-mount crimp terminal to the 1/2" stripped end of each of the two wires. Tin the 1/4" stripped ends of the wires by applying a thin coat of solder.

There are two terminals on the fan in one of the corners. Solder the ends of the two wires opposite the crimp terminals to the terminals on the fan.

Referring to the drawing below, mount the fan and screen to the back panel using the hardware indicated. For proper orientation, the terminals with the two wires attached should be towards the bottom on the side nearest the terminal block. The arrow printed on the fan to indicate airflow should be facing towards the screen. The screen itself has a bump on one side in each of the four corners. The side with the bumps should be towards the fan.



### Power Cord Installation


There is a 3-wire power cord included with this kit which must be prepared as follows before installation.

- 1) Strip 4" of the cord casing from the wires by cutting a circle 4" from the end and pulling off the black insulation. Be careful not to cut into the insulation on any of the wires inside.
- 2) The green wire inside should already be at the correct length of 4 inches. Cut the white wire to 3 1/2 inches, and the black wire to 1 1/4 inches. Strip 1/4 inch of insulation from the ends of each of the three wires.
- 3) Tin the exposed 1/4" of the black wire by applying a thin coat of solder.
- 4) Solder or crimp screw-mount crimp terminals to the white and green wires.

Place the strain relief, included with the kit, over the power cord. Be sure that the larger diameter end of the relief is towards the male plug end of the cord.

Be sure that there is approximately three inches of the cord's black insulation case extending beyond the strain relief\*, then snap it into place on the back panel as shown below.

\* The black wire should reach to the center of the fuse holder when the cord & strain relief are in place.



## Wire Preparation

Using the wire supplied with this kit, and the length of yellow/green wire cut from transformer T1, prepare the power supply interconnect wires according to the following instructions.

To avoid confusion, it would be best to prepare these wires one at a time.

The list on the right indicates the color of each wire, the length to which it should be cut, and a reference "tag".

Use the following steps to prepare each wire:

- 1) Cut the specified color wire to the length indicated.
- 2) Strip 1/2 inch of insulation from one end and 1/4 inch from the other.
- 3) Tin the wire exposed 1/4 inch by applying a thin coat of solder.
- 4) According to the instructions on page , connect a screw-mount crimp terminal to the 1/2 inch stripped end.
- 5) Approximately 5 inches from the 1/4 inch tinned end of the wire label it, using masking tape, with the reference tag indicated.

An additional length of BLACK wire should be cut to 22 1/2 inches and 1/4 inch of insulation stripped from each end. Tin both ends by applying a thin coat of solder. Label this wire "FUSE".

## Interconnect Wires

<u>COLOR</u>	<u>LENGTH</u>		<u>TAG</u>
Yellow/ Green*	2	inches	3
Black	22 3/4	"	3
Black	17 3/4	"	9
Black	17 1/2	"	10
Black	25	"	1
White	18	"	6
White	17 3/4	"	8
Orange	17 3/4	"	7
Orange	18 1/2	"	4
Orange	18 1/4	"	5

\*From transformer T1,  
This wire need not be  
labeled.

### Back Panel Wiring

The disk back panel assembly may now be completed by connecting all of the wires to their appropriate locations.

(See drawing page 23)

Three solder connections are necessary and should be made first. These include the black power cord wire, the yellow/green wire and the black 22 1/2 inch wire labeled "FUSE".

- 1) Solder the 1/4 inch tinned end of the yellow/green wire to the solder lug on transformer T1.
- 2) Solder the black power cord wire to the center terminal on the fuse holder.
- 3) Solder one end of the black "FUSE" wire to the other fuse holder terminal.

The remaining connections will be made to the terminal block.

The drawing (P.23) shows the proper orientation and connections for all of the wires on the back panel. The "tags" on the wires you prepared earlier refer to the numbers shown on the terminal block.

**WARNING:** The power supply is a critical part of any electronic system. Check the wiring here several times to be sure you have it correct. Be sure that each of the wires is in the proper location and that all of the screws on the terminal block are tight.


Use the drawing below for reference and connect all of the wires as indicated. Match the "tags" on the wires prepared earlier with the numbered positions on the terminal block. There should be a total of 25 crimp terminal connections made to the block.

**NOTE:** Where two terminals are to be connected to the same screw, place them "back to back". In this position they will fit flat together, and make a much more solid connection.

The ON-OFF Switch may also be soldered in at this time. Use the free end of the black "FUSE" wire and the free end of the wire labeled "1" to connect to the switch terminals. There are three terminals on the switch. Use the center terminal and one to either side of it. (The switch position towards the side where the connections are made will be its OFF position.


Install the 4 tie wraps in the positions shown in the top drawing on page 23.

# WIRE ROUTING & TIE WRAPS



\*TIE WRAPS (4)

# BACK PANEL WIRING



## DISK POWER SUPPLY BOARD ASSEMBLY

NOTE: Save all component leads clipped off during assembly until the entire unit is complete. Some of the leads will be used during the assembly process.


### RESISTOR INSTALLATION

Install the following 2 resistors according to the instructions listed on page 5 .

### RESISTOR VALUES AND COLOR CODES

- ( ) R1 is 33 ohm (orange-orange-black) 1/2 W
- ( ) R2 is 7.5 ohm, 5 W (this may be color coded, violet-green-3rd band white or gold; or it may be a solid body color, with the value printed directly on the resistor itself.







### CAPACITOR INSTALLATION


Install the following 3 ceramic disk capacitors according to the instructions on page 6 .

### CAPACITOR VALUES

( ) C2 = .1uf, 50V

( ) C5 = .1uf, 50V

( ) C8 = .1uf, 50V




### CAPACITOR INSTALLATION

Install the following 6 electrolytic capacitors according to the instructions listed on page 6 .

### CAPACITOR VALUES

- ( ) C1 = 2200uf, 50V
- ( ) C3 = 33uf, 50V
- ( ) C4 = 3300uf, 16V
- ( ) C6 = 33uf, 50V
- ( ) C7 = 1000uf, 25V
- ( ) C9 = 33uf, 50V






# DIODE INSTALLATION

Install the following 2 diodes  
according to the instructions  
on page 7.

( ) D1 = 1N4004

( ) D2 = 1N4004



## VOLTAGE REGULATOR INSTALLATION

There are 2 voltage regulators to be installed on the silk-screened side of the power supply board, X1 & X3.


These are to be installed according to the following procedure. (see drawing-right)

- (1) Set the regulator in place over the board so that the mounting hole in the regulator and the board align.
- (2) Use a pencil to mark the point on each of the regulator's three leads directly over its corresponding hole in the board.
- (3) Bend the three leads, using needle-nose pliers, at right angles from the printed side of the component.

NOTE: Use heat-sink grease when installing this component. Apply it to the surface where the regulator & board come in contact.

- (4) Referring to the drawing, set the regulator in place on the silk-screened side of the board. Secure it to the board using a #6-32 nut and screw. Hold the regulator in place as you tighten the nut to keep from twisting the leads.
- (5) Turn the board over and solder the three leads to the foil pattern on the back side of the board. Be sure not to leave any solder bridges.
- (6) Clip off any excess lead lengths.

Use the above procedure to install both of the regulators, X1 & X3.






# VOLTAGE REGULATOR INSTALLATION

( ) X1 = 7824

( ) X3 = 7805



## BRIDGE RECTIFIER INSTALLATION

There are two bridge rectifiers, BR1 & BR2, to be installed on the power supply board.

WARNING: Read the following instructions closely. Proper orientation of these two components is absolutely critical.

These two components are indicated on the silk-screen by broken lines. This is to indicate that they are to be mounted on the bottom (non-silk-screened) side of the board.

You will observe a "+" sign printed near one corner of the rectifier. The lead nearest this "+" sign is the positive lead of the rectifier. This lead must be inserted into the hole marked on the silk-screen with a "+" sign.

NOTE: There is also a "-" sign printed on the regulator. The lead nearest this sign is the negative lead of the rectifier, and should be diagonally opposite the "+" lead on the board.

BE ABSOLUTELY SURE THAT THE PROPER ORIENTATION IS USED WHEN INSTALLING THESE TWO COMPONENTS.

Install the rectifiers according to the following procedure:

- (1) Insert the four leads of the BR1 rectifier into their respective holes from the non-silk-screened side of the board. Be sure the "+" lead of the rectifier is inserted in the hole labeled "+" on the silk-screened side of the board.

- (2) Insert the BR2 rectifier in the same manner. Be sure both rectifiers are pushed all the way against the board.
- (3) There is a 90° angle bracket included with your parts. Each of the two sides has two holes in it.

Using the side with the two holes the furthest apart, set the angle bracket over the two rectifiers. The holes in the bracket, the rectifiers, and the board should align.

Temporarily attach the bracket & rectifiers to the board through these holes using #6-32 & 5/8" screws and nuts.


- (4) Check the orientation once more, then solder all four leads of each rectifier to the board on the silk-screened side.
- (5) Clip off any excess lead lengths. Leave the angle bracket in place for the next procedure.

NOTE: Apply heat-sink compound to all mating surfaces.

### BRIDGE RECTIFIER INSTALLATION

( ) BR1 = VJ048

( ) BR2 = VJ048






# DISK BUFFER BOARD ASSEMBLY

## IC INSTALLATION

Install the following 7 ICs onto the Disk Buffer Board according to the method described on page 4 .

## IC SILK-SCREEN DESIGNATIONS AND PART NUMBERS

- ( ) A, B, D, & E = 8T97
- ( ) C = 8T98
- ( ) F = 74L30
- ( ) G = 9601



### RESISTOR INSTALLATION

Install the following 39 resistors according to the instructions listed on page 5 .


#### NOTE

The following modifications connect the "pwr" indicator to the door open timer. This allows the door open timer to indicate when the Disk Drive can be enabled.

1. Stand R36 up on end in the pad nearest D3-K.
2. Connect a jumper from the top end of R36 to pin 8 of IC G.

### RESISTOR VALUES AND COLOR CODES

- |   |  |
|---|--|
| ( ) R9, R7, R5 are 220 ohm<br>(red-red-brown) 1/2 W               | ( ) R40 is 220 ohm<br>(red-red-brown) 1/2 W .                |
| ( ) R10, R8, R6 are 330 ohm<br>(orange-orange-brown) 1/2 W        | ( ) R39 is 330 ohm<br>(orange-orange-brown) 1/2 W            |
| ( ) R12, R14, R16 are 330 ohm<br>(orange-orange-brown) 1/2 W      | ( ) R38 is 1K ohm<br>(brown-black-red) 1/2 W                 |
| ( ) R11, R13, R15 are 220 ohm<br>(red-red-brown) 1/2 W            | ( ) R41 is 39K ohm<br>(orange-white-orange) 1/2 W            |
| ( ) R33 is 220 ohm<br>(red-red-brown) 1/2 W                       | ( ) R20, R22, R24 are 330 ohm<br>(orange-orange-brown) 1/2 W |
| ( ) R34 is 330 ohm<br>(orange-orange-brown) 1/2 W                 | ( ) R19, R21, R23 are 220 ohm<br>(red-red-brown) 1/2 W       |
| ( ) R31, R29, R27, R25 are 220 ohm<br>(red-red-brown) 1/2 W       | ( ) R4 & R18 are 330 ohm<br>(orange-orange-brown) 1/2 W      |
| ( ) R32, R30, R28, R26 are 330 ohm<br>(orange-orange-brown) 1/2 W | ( ) R3 & R17 are 220 ohm<br>(red-red-brown) 1/2 W            |
| ( ) R36, R35, R37 are 150 ohm<br>(brown-green-brown) 1/4 W        |  |








# DIODE INSTALLATION

Install diode D6 according to the instructions on page 7 .

( ) D6 = 1N914



### CAPACITOR INSTALLATION


Capacitor C14 is an electrolytic capacitor. Capacitors C10, C11, C12, and C13 are ceramic disk capacitors.

Install these components according to the instructions listed on page 6 .

### CAPACITOR VALUES

( Different voltages may be substituted in some cases.)

- ( ) C14 = 500 uf, 25V electrolytic
- ( ) C10, C11, C12 & C13 are .1 uf, 12V ceramic disks.



## DISK DRIVE RIBBON CABLE ASSEMBLY

### Ribbon Cable Preparation

There are three ribbon cable assemblies to be prepared for installation in the disk drive unit. A 12' length of 18-twisted pairs cable has been provided for this purpose.

First, cut the 12' length of cable into two 18-inch lengths and one 25-inch length. The remainder of the cable should be saved for later use.

The following two pages contain diagrams for the proper lengths and arrangement for the three cable pieces you have just cut. The two 18" lengths will be prepared identically.


The cable sheath itself may be cut using scissors, and can be stripped by simply pulling it apart. You will note that the plastic sheath has "welds" approximately every inch between the twisted pairs. Try not to make any cuts on the welds themselves.

Each time a 1/4" of insulation is stripped from the wires themselves, the bare ends should be tinned by applying a thin coat of solder.

Study the diagrams on the next two pages and prepare the three cable assemblies as shown. Be careful to cut the wires precisely as indicated, and do not damage the wire insulation when cutting the cable sheath.

18 INCH RIBBON CABLES


CUT TO 2" : STRIP 1/8" & TIN



# 25 INCH RIBBON CABLE

CUT TO 5" : STRIP 1/2" & TIN  
4 PAIR

CUT TO 2" : STRIP 1/4" & TIN



There are several 37-pin connectors in this kit. One male connector and one female connector will be used now to connect onto one end of each of the two 18 inch lengths of ribbon cable that you have just prepared. The other end of the two cables will connect directly to the Disk Buffer board.

#### Connector Preparation

The two 37-pin connectors must first be prepared for attaching to the cables. It may be helpful to solidly mount the connectors to some steady object during this and the following procedures.

- 1) Place the connector in front of you with the hollow solder pins facing upwards.
- 2) Using your soldering iron, very carefully heat each pin one at a time and fill the hollow space with solder. The solder should not quite fill the pin and should have a slightly concave surface.

Prepare all 37 pins on one male and one female connector in this manner. Be sure not to leave any solder bridges between the pins, and be careful not to melt any of the nylon insulation around them.

#### WARNING

During the following procedure, and later steps involving ribbon cable, be sure that you fully understand all of the instructions before you begin. These points are the most likely areas for assembly errors to occur.

#### Cable Assembly

The following procedure should be used for assembling both of the 18 inch cables. In order to minimize the possibility of error, the cables will be attached to the 37-pin connectors and the Disk Buffer board during the same procedure. Read this entire procedure over carefully before beginning.

You will note that the pins on the 37-pin connectors are all numbered. Note also that the numbers on the male connector are the reverse of the female. The male connector will be wired to the rows of pads on the buffer board labeled "TO". The female connector will be wired to the rows of pads labeled "FROM". The numbers on the connector pins correspond directly with the numbers that label the pads on the buffer board.

The following pages contain drawings of both the 37-pin connectors, and the Disk Buffer board silk-screen. There is a space provided to "check-off" each of the twisted-pair wires as they are connected. Double arrows are also shown to indicate the connection points for each of the twisted-pairs.

Orient one of the 18 inch cables so that the "stepped" edge of the cable casing is along the rows of pads on the buffer board labeled "TO". The longest wires should be near the pads labeled "19 & 37" and the shortest wires near the pads labeled "1 & 20". Place the MALE 37-pin connector near the other end of the cable.

Begin with the shortest twisted-pair of wires, nearest the outside edge of the cable casing, on the buffer board end.

Separate the two wires slightly, then solder them into the two pads labeled "1 & 20" on the buffer board. Do this by inserting the wires from the silk-screened side of the board and soldering them on the back. Be careful not to push any of the wire insulation into the holes. Clip off any excess wire from the connections and then check-off the appropriate space on the silk-screen drawing.

The same twisted-pair of wires should now be connected to the pins numbered "1 & 20" on the 37-pin connector.

Observe the color of the wire now connected to the pad on the buffer board labeled "1". Be sure to connect this same wire to the pin numbered "1" on the connector. Do the same with pad "20" and pin "20".


Make the connections by re-melting the solder in the pins and inserting the wires up to their insulation. Remove the heat from the pins while still holding the wires in place until the solder cools. Check-off the appropriate space on the connector drawing.

Move to the next twisted-pair of wires in the ribbon cable and use the same procedure to connect pads "2 & 21" with pins "2 & 21". Continue in this manner, moving across the ribbon cable one pair at a time, until all 18 twisted-pairs are in place. Be sure that you do not connect any wires to pin "12" on the connector.

**NOTE:** Take your time and be careful while soldering the wires to the connectors. Do not melt any of the wire insulation or leave any solder bridges.

Check your work as you go along and be sure that 1 is connected to 1, 2 to 2, 3 to 3, etc., because corrections will be very difficult later.


Use this procedure to assemble both of the 18 inch cables. Be sure that the MALE 37-pin connector goes to the pads labeled "TO" and the FEMALE connector to the pads labeled "FROM". Refer to the drawing on page to get a rough idea of how these and the next cable will appear when connected to the board.






# 37-PIN MALE CONNECTOR


PIN 12 NOT USED





# 37-PIN FEMALE CONNECTOR

PIN 12 NOT USED





Due to its complexity, the 25 inch length of ribbon cable will be assembled in a slightly different manner.

The following two pages contain drawings of one end of the ribbon cable and the 44-pin edge connector included with this kit. These connections, on one end of the ribbon cable only, will be made first.

**NOTE:** Be sure to observe that the orientation of the edge connector is not the same in all of the drawings. Use the pin designations themselves for any reference when making connections.


Orient the 25 inch ribbon cable as shown in the drawing on page 46. The end that is shown at the top of this drawing will be attached to the 44-pin edge connector. The Connection Chart on the following page also refers to this drawing for the proper orientation. Twisted-pair #1 is the pair furthest to the right in the drawing, and pair #18 is furthest to the left. It is very important to begin numbering from the correct side when making the connections.

The Connection Chart on the following page indicates where on the edge connector each twisted-pair should be attached. The pin designations in the chart and in the drawings refer to those stamped into the plastic of the connector itself. Be sure that you connect the proper wires to the correct pins according to the designations stamped on the connector.

In most cases a single wire will connect to a single pin on the connector. Make these connections by first making a good mechanical connection, and then soldering the wire into place. Be careful not to leave any solder bridges, or to melt any insulation.

For twisted-pair #12, and pair #13, you will connect both wires of the pair to a single pin instead of each to a separate one.

For twisted-pairs #15 & #16, all four of the wires should first be twisted together and then all four attached to both of the pins A & B. Do the same for pairs #17 & #18 to connect them to pins D & E. Be sure that there is a solid electrical connection between both of the pins in each case. (see drawing below)



A\*=pairs #15 & #16

B\*=pairs #17 & #18

Be sure to check-off the appropriate space on the chart as you make each of the connections.


Use a small piece of ribbon cable wire to connect pin 18 to pin V on the edge connector.


Insert the plastic key, packaged with the edge connector, into the slot between pins 5 & 6 as shown in the drawing on the bottom of page .

# CONNECTION CHART


PAIR #	CONNECTOR PIN(S)	PAIR #	CONNECTOR PIN(S)
1	6 & F ( )	10	19 & W ( )
2	7 & H ( )	11	20 & X ( )
3	8 & J ( )	12	21 ( )
4	9 & K ( )	13	Y ( )
5	10 & L ( )	14	22 & Z ( )
6	11 & M ( )	15 }	A & B ( )
7	15 & S ( )	16 }	
8	16 & T ( )	17 }	D & E ( )
9	17 & U ( )	18 }	

( ) Jumper 18 to V





- † - NOT USED  
 \* - POWER SUPPLY BOARD  
 \*\* - JUMPER WIRE (18 to V)



The other end of the ribbon cable will connect to both the Disk Buffer board and the Power Supply board.

When making these connections, the same numbering system will be used for the twisted-pairs as previously. That is, the pair furthest to the right in the drawing on page        will be referred to as pair #1.

Page contains silk-screen drawings of both PC boards, with arrows to indicate the twisted-pair connections and a space to check-off each as it is completed.

The first eleven twisted-pairs will connect to the remaining row of pads on the Disk Buffer board. Make these connections in the same manner as the previous ribbon cable connections to this board.

Begin with pair #1 and connect one of its wires to pad 6 and the other to pad 7 on the board. Observe the color of the wires connected to the equivalent pins on the edge connector. Be sure you connect pin 6 to pad 6, F to F, etc., as when making the previous connections. Continue the connections through the first eleven of the twisted-pairs in this manner, checking-off the appropriate space as each is completed.

The next seven twisted-pairs will connect to the Power Supply board in nearly the same manner, except that all but two of the connections involve more than one of the wires.

The two wires of pair #12 should be twisted together and both connected to pad D. Pair #13 should connect to pad F in the same manner.

Twisted-pairs #15 & #16 should have all four wires (2 each) twisted together and connected to pad A. Pairs #17 & #18 should be connected to pad B in the same manner.

Only twisted-pair #14 should be separated and connected to pads J & H in the same manner as the first eleven pair.

Make all of the Power Supply board connections as described, checking-off the appropriate space as you complete each of them.

Starting approximately 1 inch from the cable casing, and moving along the Power Supply cable wires, attach a tie-wrap approximately every inch until 5 of them are used. Do these as necessary to make a neat, tight cable.




There are two other wires which should be installed at this time. Using the same wire that you used when making the connections to the terminal block, cut one 8 inch length of orange wire and one 8 inch length of black wire. Strip 1/4 inch of insulation from both ends on each of them and tin the exposed portion.


Connect the orange wire between pad C on the Power Supply board and pad C on the buffer board.

Insert the wire from the silk-screened side of the board and solder it on the bottom.

Connect the black wire between E and E  
in the same manner. GND







#### VOLTAGE REGULATOR INSTALLATION

The next two components will be mounted on the bottom side of the Power Supply board. These components will also be mounted to the 90° angle bracket, as with BR1 & BR2, in the two remaining holes.

When installing these components refer to the drawing above and orient them so that the markings on the components face away from the bracket.

Insert the two regulators from the bottom side of the board as shown. \*Use heatsink compound between all mating surfaces. Be sure to place the mica insulating washer between Q1 and the bracket, and the shoulder washer between Q1 and the mounting nut.

Tighten the mounting screws firmly, being sure not to twist the component leads as you do so.


Solder all three leads of both components to the board on the silk-screened side.

Clip off the excess lead lengths; then remove the two screws used earlier to mount BR1 & BR2. The screws mounting X2 & Q1 should remain.

# VOLTAGE REGULATOR INSTALLATION

( ) X2 = 7805

( ) Q1 - TIP 145 (w/Mica insulating washer and shoulder washer)




### DISK CHASSIS ASSEMBLY

The next step in the assembly procedure is to prepare the chassis itself for mounting the boards and drive unit.

- 1) Referring to the drawing on the following page, mount the cross beam as shown using the existing screws now holding it in place. Note the number of holes for proper placement.
- 2) To make the following procedures as simple as possible, remove the front panels at this time. Save the screws used to mount the panel to the chassis.
- 3) Referring to the same drawing again, mount the rail as shown in the 2nd hole from the front. Be sure to include the 2 spacers as shown on each side.

There are 6 additional screws to be added to the chassis members, 4 on the beam and 2 on the rail.

- 4) Install two #6-32 x 3/4" screws onto the rail in the positions indicated on the same drawing. Insert them from the bottom and tighten them firmly using #6-32 lockwashers and nuts.
- 5) Install two 4-40 x 1" screws and two 6-32 x 1" screws on the cross beam as shown using the indicated hardware.






### BACK PANEL MOUNTING

Mount the back panel to the rear of the chassis as shown below using the same screws previously used to mount it.

Be careful not to catch any wires between the chassis and the panel.




#### POWER SUPPLY BOARD MOUNTING

Referring to the drawing on the following page, mount the Power Supply board to the 90° angle clip and bracket as shown. Study the drawing carefully before beginning.

NOTE: The #4-40 screw shown are those installed earlier.

Be careful not to disturb the wire connects previously made between this board and the buffer board and cables.






#### DISK BUFFER BOARD MOUNTING

Referring to the drawing on the following page, mount the Disk Buffer board as shown.

Again, study the drawing carefully before beginning. The screws shown have already been installed.

The connectors on the three cables should face towards the back panel.





## POWER SUPPLY WIRING


Referring to the silk-screen drawing below, and the wiring diagram on the following page, connect the wires from the terminal block to the pads on the Power Supply board.

Use the following procedure:

- 1) All of the wires should be connected to the pads on the board marked with the same designation as the tags placed on them earlier.
- 2) Insert all of the wires from the silk-screened side of the board, almost to the insulation. Add solder from the same side of the board except wire "3-G", and then continue applying heat while pushing the wires down as far as possible until the insulation just touches the solder. Be careful not to melt any insulation.
- 3) Turn the board over to solder wire "3-G" and then clip off all excess lead lengths.

Check this wiring over again carefully, and then remove the tags from the wires.






ALTAIR FLOPPY DISK DRIVE  
POWER SUPPLY WIRING DIAGRAM

### CONNECTOR MOUNTING

Referring to the drawing below, mount the two 37-pin connectors to the back panel as shown.

Be sure to mount the male connector into the slot labeled "TO" and the female connector into the slot labeled "FROM".

On both connectors pin 1 should be towards the top.




### FRONT PANEL MOUNTING

The front sub panel and dress panel can now be re-installed. Use the same four screws previously used to mount the sub panel to re-mount it to the chassis as shown in the drawing below.

Note when setting the dress panel in place that it is a "floating" panel. Installing the power switch, as shown, at this time will temporarily hold it in place.

Be sure the lettering on the dress panel is facing outwards.



## LED INSTALLATION

There are three RL-21 Light-Emitting-Diodes (LED's) to be installed on the Disk Buffer Board. These LED's have a cathode and anode lead on each of them which must be properly oriented for installation on the board. The diagram below shows you how to determine the cathode and anode leads of an RL-21. Hold the LED up to a light and you will be able to see inside. The larger of the two elements inside the plastic casing is the cathode.



The silk-screen on the board itself has the cathode leads for the three LED's marked with a "K". The anode lead is marked with an "A". When you install these components, make sure that the cathode leads are in the pads marked "K" and the anode leads in the pads marked "A". Improper orientation when installing LED's may cause permanent damage to the component.

As is shown in the drawing on this page, these three components also require special spacing and bending of the leads in order to fit the unit properly.

- 1) Set the LED's in place one at a time and bend as necessary to fit as shown in drawing [3].
- 2) Cut the leads as shown in [2] and place the LED's on the board properly.
- 3) Solder them in place from the top side of the board. LED's are very heat sensitive, so use a minimum of heat for the shortest amount of time possible to make the connection.


When properly installed, the LED's should fit as shown in the drawing below.

- [1] SET THE LED IN PLACE  
AND MARK THE LEADS



- [2] CUT THE EXCESS LEAD  
TO LEAVE 1/8 INCH

- [3] SOLDER TO FIT IN PLACE  
AS SHOWN






WARNING: RL-21 LED's are very sensitive to heat. Use a minimum application of heat with your iron when making these solder connections.

#### LED Installation

- ( ) D3 = RL-21 LED
- ( ) D4 = RL-21 LED
- ( ) D5 = RL-21 LED



### DISK DRIVE UNIT INSTALLATION

The Disk Drive unit itself can now be installed into the chassis.

- 1) The first step in this process is to set the chassis on end, with the front panel facing upwards.
- 2) Remove the screws and rubber feet on the bottom of the drive unit if they were factory installed.
- 3) Being careful not to catch any of the wires or cables, slowly lower the drive unit into the chassis. Refer to the drawing on the following page for the proper orientation.
- 4) Referring again to the drawing on the following page, insert the two mounting screws and lockwashers on the front side of the drive unit. Do not tighten the screws down at this time.
- 5) Referring to the same drawing, install the 1/4 X 1/2 X 1" spacer bar and mounting hardware for the right rear end of the drive unit  
Tighten all three mounting screws firmly.
- 6) The 44-pin edge connector should now be plugged into the rear of the drive unit. Line up the connector with the finger pads on the units PC board and align the plastic key between pins 5 & 6 with the slot in the board. Push the connector firmly into place.

### WARNING

Be sure connector is wired and installed correctly. Incorrect installation will damage the drive.

# Insert Page

## ALTAIR FLOPPY DISK

### Disk Drive Assembly Procedure

#### addendum to page 74, Disk Drive Unit Installation

If the mounting holes on the PERTEC FD-400 are already tapped, proceed to the instructions on page 74.

If the mounting holes are not tapped, follow the procedure below.

A. Before beginning the steps listed on page 74, the mounting holes in the Disk Drive Unit must be threaded. Use the following procedure to thread the four mounting holes:


1. Place the unit upside down. Place a strip of masking tape under each mounting hole to catch any metal particles.
2. Install a #6-32 x 3/4" self tapping screw (MITS part number 100957, Bag 7) into each hole.
3. Remove the screws and the masking tape.

-----

B. Step #2 of the instructions given on page 74 may be omitted.



DISK DRIVE UNIT



## DISK DRIVE PRELIMINARY CHECK OUT

1. With no diskette in drive and the chassis unit not installed in cabinet, and no address jumpers installed, turn power on.

A) Fan and disk drive motor should turn.

B) Power indicator should light.

2. If voltmeter is available, measure:

A) +24 volt supply at + end of C3 (with respect to chassis) on the power supply board.

B) +5 volt supply at + end of C6 on the power supply board.

C) -5 volt supply at point "J" of the power supply board.

All voltages should be within 5% of rated output. If the disk drive motor does not start up, or the power indicator does not light, or the power supply voltages are wrong, consult the Theory of Operation and recheck wiring.

3. A) With a cliplead, ground to chassis wire #13 (Disk Enable) on the left edge of the buffer board (Pin 13 of "To Controller").

The Disk Enable light should come on.

B) Now open disk drive door. The drive motor should stop and Disk Enable light should turn off. Close the door and the motor should start up. 5-10 seconds later, the Disk Enable light should turn on (timing controlled by IC G).

C) With another clip lead, test the mechanical disk functions by grounding (on the left edge of board)

1. Wire #8 (Head Load)

The Head Load solenoid should energize as long as #8 is grounded, and Head Load light should turn on.

2. Wire #6 (Step In)

The track stepping motor shaft should turn as point #6 is intermittently grounded, simulating stepping pulses. The head carriage should move towards the front of the Disk Drive.

3. Wire #7 (Step Out)

The track stepping motor shaft should turn as Point #7 is intermittently grounded, simulating stepping pulses. The head carriage should move towards the rear of the Disk Drive.

This completes the preliminary check out of the Disk Drive.

Remove the clip leads, and install the disk address jumpers as indicated on page 77 .


### ADDRESS SELECTION

There are four jumper wires to be installed on the buffer board in order to select the I/O address.

Use component leads saved earlier for this purpose. Install them from the silk-screened side of the board and solder them on either side.

To comply with MITS software, the board should be jumpered to address 0 unless it is a part of a multiple disk drive system.

Referring to the silk-screen drawing on the right, jumper as follows for address 0:



<u>PAD</u>	<u>TO</u>	<u>PAD</u>
1	—	$\bar{A}$
2	—	$\bar{B}$
3	—	$\bar{C}$
4	—	$\bar{D}$

Consult the jumper chart in the Theory of Operation section if a different address is desired.


### FINAL ASSEMBLY

The chassis assembly can now be installed into the outer case.

Refer to the drawing on the following page and mount the chassis as shown.

To insert it, start by setting it slightly towards the back of the case, and then slide it forward until the screw holes align. Tighten the four screws firmly.






### CASE TOP INSTALLATION

Re-install the case top onto the unit as shown below. Do not, however, use the same screws which held it originally.

Use #6-32 x 1/4" screws to secure the case top.



# altair FLOPPY DISK DISK CONTROLLER ASSEMBLY PROCEDURE



## DISK CONTROLLER ASSEMBLY

The Disk Controller will now be assembled. This consists of two PC boards and inter-connecting cables.

The Disk Controller mounts directly into the computer main-chassis and uses two slots.


## IC Installation

Install the following 28 ICs with sockets according to the IC Installation Instructions, Section B, on page 4.

### NOTE

74LS ICs may be substituted for 74L ICs.

<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>			
( ) A1	74123	16-pin	( ) F3	74L02	14-pin
( ) A2	74L73	14-pin	( ) F4	74L02	14-pin
( ) A3	93L16	16-pin	( ) G2	74L04	14-pin
( ) A4	93L16	16-pin	( ) G3	74L75	16-pin
( ) B1	74123	16-pin	<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>
( ) B2	74123	16-pin	( ) G4	74L04	14-pin
( ) B3	74123	16-pin	( ) H1	74L02	14-pin
( ) B4	74L04	14-pin	( ) H2	74166	16-pin
( ) E1	74L00	14-pin	( ) H3	74L75	16-pin
( ) E2	74L73	14-pin	( ) H4	74L04	14-pin
( ) E3	74L00	14-pin	( ) J1	74L02	14-pin
( ) E4	74L10	14-pin	( ) J2	8T98	16-pin
( ) F1	74L02	14-pin	( ) J3	74L75	16-pin
( ) F2	74L73	14-pin	( ) J4	74L74	14-pin
			( ) K3	8T97 or 74367	16-pin




### Resistor Installation

Install the following 13 resistors according to the instructions on page 5.

#### Resistor

( ) R1	10K ohm (brown, black, orange) 1/4 or 1/2W
( ) R2	10K ohm (brown, black, orange) 1/4 or 1/2W
( ) R3	39K ohm (orange, white, orange) 1/4 or 1/2W
( ) R4	10K ohm (brown, black orange) 1/4 or 1/2W
( ) R5	15K ohm (brown, green, orange) 1/4 or 1/2W
( ) R6	220 ohm (red, red, brown) 1/4 or 1/2W
( ) R7	330 ohms (orange, orange, brown) 1/4 or 1/2W
( ) R8	15K ohm (brown, green, orange) 1/4 or 1/2W
( ) R9	6.8K ohm (blue, gray, red) 1/4 or 1/2W
( ) R10	16K ohm (brown, blue orange) 1/4 or 1/2W
( ) R11	1K ohm (brown, black, red) 1/4 or 1/2W
( ) R12	1K ohm (brown, black, red) 1/4 or 1/2W
( ) R13	1K ohm (brown, black, red) 1/4 or 1/2W






## Capacitor Installation

Install the following 29 capacitors according to the instructions on page 6. Note that all capacitors are installed in the same manner, except for electrolytic capacitors.

<u>Capacitor</u>	<u>Value</u>		
( ) C1	.001 $\mu$ f	( ) C15	.1 $\mu$ f
( ) C2	.001 $\mu$ f	( ) C16	.1 $\mu$ f
( ) C3	1.0 $\mu$ f	( ) C17	.1 $\mu$ f
( ) C4	.22 $\mu$ f	( ) C18	.1 $\mu$ f
( ) C5, electrolytic	5 $\mu$ f	( ) C19	.1 $\mu$ f
( ) C6, electrolytic	10 $\mu$ f	( ) C20	.1 $\mu$ f
( ) C7	.1 $\mu$ f	( ) C21	.1 $\mu$ f
( ) C8	.1 $\mu$ f	( ) C22	.1 $\mu$ f
( ) C9, electrolytic	33 or 35 $\mu$ f	( ) C23	.1 $\mu$ f
( ) C10	.1 $\mu$ f	( ) C24	.1 $\mu$ f
( ) C11	.1 $\mu$ f	( ) C25	.1 $\mu$ f
( ) C12	.1 $\mu$ f	( ) C26	.1 $\mu$ f
( ) C13	.1 $\mu$ f	( ) C29	.1 $\mu$ f
( ) C14	.1 $\mu$ f	( ) C30	.1 $\mu$ f
		( ) C31, electrolytic	33 or 35 $\mu$ f




### Diode Installation

Install the following two diodes according to the instructions on page 7 .

#### DIODES

( ) D1, 1N914

( ) D2, 1N914




### Voltage Regulator Installation

Install the voltage regulator according to the instructions on page 32 .

VOLTAGE REGULATOR


(\*) 7805



## Connector Installation

There are two "boxes" marked on the silk-screen. These are to indicate the positions for a 10-pin and a 20-pin male connector.

The drawing below illustrates the installation of a typical connector of this type.



Referring to the drawing, install the two male connectors onto the silk-screened side of the board. The long 90° bent pins should point towards the right side of the board. The 10-pin connector goes between "CC1" & "CC10"; while the 20-pin connector goes between "CD1" & "CD20".

Two pins should now be cut off. These are the 2nd pin from the top on the 10-pin connector, and the 4th from the top on the 20-pin connector. Cut them off right at the plastic body of the connector. (These pins are both labelled "KEY" on the silkscreen.)

There is a row of 20 pads along the right edge of the board labelled CB1 through CB20.

Remove 10 twisted-pairs of wire from an 8-inch length of ribbon cable. Leave the two wires in each pair twisted together. Strip 1/4 inch of insulation from both ends of all of the wires and tin the exposed portions.


Beginning with the bottom pad on the board, connect one of the twisted-pairs to pads CB1 & CB2. Continue up the row of pads, connecting a twisted-pair to each two pads as you go along.

**NOTE:** The twisted-pairs each have one wire the same color in each of them (usually black or white). Make the connection to pad CB1 with this wire on the 1st pair, and use this wire for the 1st connection on each of the following pairs as you go up the row of 20 pads.

Insert all of the wires from the silk-screened side of the board and solder them on the bottom side. Clip off any excess lead lengths.

Cut the free ends of all 20 wires so that only 1/8 inch of tinned wire is exposed beyond the insulation.







A 20-pin female connector will now be attached to the free ends of the 20 wires.



First, connector pins must be attached to the ends of all of the wires. The drawings below illustrate a typical connector of this type, and the method for attaching and inserting the pins.

Connect a pin to each of the wires\* as shown, and solder them carefully into place. Do not use too much solder or the pins will not fit into the connector properly.

NOTE: Two of the wires, both labeled CB17 on the PC board (see silk-screen), should be attached to a single pin.

Pins 1 & 20 are marked on the plastic body of the female connector. Referring to the silk-screen, insert the pins into the connector so that pad CB1 goes to pin 1, CB2 to pin 2, CB3 to pin 3, etc., being sure not to insert any wires into pin 15 on the connector. A plastic key should be inserted into pin 15 of the female connector, inserting it from the opposite side as the wires.

Place a tie-wrap approximately in the center between the connector and the board to hold the wires together. Place another tie-wrap around the wires and also through the holes in the PC board just to the right of the 20 pads.



## CONTROLLER BOARD #1 ASSEMBLY

### IC Installation

Install the following 31 ICs with sockets according to the IC Installation Instructions, Section B, page 4.

#### NOTE

74LS ICs may be substituted for 74L ICs.

<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>	<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>
( ) A1	74123	16-pin	( ) F2	74L73	14-pin
( ) A2	74L02	14-pin	( ) F3	74L73	14-pin
( ) A3	74L20	14-pin	( ) F4	74123	16-pin
( ) A4	74L10	14-pin	( ) F5	74L30	14-pin
( ) A5	74L10	14-pin	( ) G1	74164	14-pin
( ) B1	93L16	16-pin	( ) G2	74L00	14-pin
( ) B2	74L74	14-pin	( ) G3	74L75	16-pin
( ) B3	74L73	14-pin	( ) G4	7493	14-pin
( ) B4	74L11	14-pin	( ) G5	74L04	14-pin
( ) B5	74L04	14-pin	( ) H1	74L75	16-pin
( ) E1	74123	16-pin	( ) H2	8T97 or 74367	16-pin
( ) E2	74L00	14-pin	( ) H3	8T97 or 74367	16-pin
( ) E3	74L73	14-pin	( ) H4	8T97 or 74367	16-pin
( ) E4	74L04	14-pin	( ) H5	8T97 or 74367	16-pin
( ) E5	74L00	14-pin	( ) J3	74L04	14-pin
( ) F1	74123	16-pin			

### Terminal Test Point Installation


Install the 8 test points, TP1 through TP8 on Controller Board #1 according to the following instructions.

1. Insert the pin through the silkscreened (top) side of the board and solder in place on the silkscreened side.
2. Turn the board over and solder the pin on the foil (bottom) side of the board.
3. Return the board to the silk-screened (top) side. Straighten the pin if necessary, and resolder.

#### NOTE

Do not clip off the portion of the test point that protrudes from the bottom of the board; it can be used during testing and troubleshooting.





## Resistor Installation


Install the following 24 resistors according to the instructions on page 5.

### NOTE

Save three excess resistor leads for ferrite bead installation on page 108A.

<u>Resistor</u>	<u>Value</u>		
( ) R1	330 ohm (orange, orange, brown) 1/4 or 1/2 W	( ) R13	220 ohm (red, red, brown) 1/4 or 1/2 W
( ) R2	220 ohm (red, red, brown) 1/4 or 1/2 W	( ) R14	330 ohm (orange, orange, brown) 1/4 or 1/2 W
( ) R3	10K ohm (brown, black, orange) 1/4 or 1/2 W	( ) R15	10K ohm (brown, black, orange) 1/4 or 1/2 W
( ) R4	20K ohm (red, black, orange) 1/4 or 1/2 W	( ) R16	5.6K ohm (green, blue, red) 1/4 or 1/2 W
( ) R5	10K ohm (brown, black, orange) 1/4 or 1/2 W	( ) R17	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R6	20K ohm (red, black, orange) 1/4 or 1/2 W	( ) R18	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R7	470 ohm (yellow, violet, brown) 1/4 or 1/2 W	( ) R19	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R8	470 ohm (yellow, violet, brown) 1/4 or 1/2 W	( ) R20	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R9	330 ohm (orange, orange, brown) 1/4 or 1/2 W	( ) R21	470 ohm (yellow, violet, brown) 1/4 or 1/2 W
( ) R10	220 ohm (red, red, brown) 1/4 or 1/2 W	( ) R22	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R11	10K ohm (brown, black, orange) 1/4 or 1/2 W	( ) R23	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R12	20K ohm (red, black, orange) 1/4 or 1/2 W	( ) R24	1K ohm (brown, black, red) 1/4 or 1/2 W






## Capacitor Installation

Install the following 30 capacitors according to the instructions on page 6.

### NOTE

Mica and Mylar capacitors are similar in appearance to epoxy dipped ceramic capacitors and should be installed in the same manner.

<u>Capacitor</u>	<u>Value</u>		
( ) C1, Ceramic Disk	.1 mf, 12-16V	( ) C15, Ceramic Disk	.1 mf, 12-16V
( ) C2, Mylar	.68 mf, 100V	( ) C16, Ceramic Disk	.1 mf, 12-16V
( ) C3, Mylar	.047 mf, 250V	( ) C17, Ceramic Disk	.1 mf, 12-16V
( ) C4, Mylar	.68 mf, 100V	( ) C18, Ceramic Disk	.1 mf, 12-16V
( ) C5, Mica	430 pf, 500V	( ) C19, Ceramic Disk	.1 mf, 12-16V
( ) C6, Mica	910 pf, 500V	( ) C20, Ceramic Disk	470 pf, 500-1KV
( ) C7, Electrolytic	33 mf, 16-35V	( ) C21, Ceramic Disk	.1 mf, 12-16V
( ) C8, Ceramic Disk	.01 mf, 12-500V	( ) C22, Ceramic Disk	.1 mf, 12-16V
( ) C9, Mylar	.047 mf, 250V	( ) C23, Ceramic Disk	.1 mf, 12-16V
( ) C10, Ceramic Disk	.1 mf, 12-16V	( ) C24, Ceramic Disk	.1 mf, 12-16V
( ) C11, Electrolytic	33 mf, 16-35V	( ) C25, Ceramic Disk	.1 mf, 12-16V
( ) C12, Ceramic Disk	.1 mf, 12-16V	( ) C26, Ceramic Disk	.1 mf, 12-16V
( ) C13, Ceramic Disk	.1 mf, 12-16V	( ) C27, Ceramic Disk	.1 mf, 12-16V
( ) C14, Ceramic Disk	.1 mf, 12-16V	( ) C28, Ceramic Disk	.1 mf, 12-16V
		( ) C29, Ceramic Disk	470 pf, 500-1KV
		( ) C30, Ceramic Disk	470 pf, 500-1KV




### Voltage Regulator Installation

Install the voltage regulator according to the instructions on page 32 .

VOLTAGE REGULATOR

( ) K1, 7805





### Connector Installation

Install a 10-pin and a 20-pin male connector onto the board in the same manner as described on page 94 for Board #2.

#### NOTE

The only exceptions to the above statement are that pin 6 is to be cut off instead of pin 4 on the 20-pin connector and pin 3 of the 10-pin connector is to be cut off instead of pin 2.


### Ferrite Bead Installation

Install three ferrite beads, L1, L2 and L3, on Controller Board #1 according to the following instructions.

1. Using the excess resistor leads saved from page 100, cut three 1-inch lead lengths.
2. Insert the lead through the bead and bend the ends of the lead to conform to the designated holes on the board.
3. Insert the lead into the proper holes from the silkscreened side of the board, and solder to the foil (bottom) side of the board. Be sure not to leave any solder bridges, and clip off any excess lead lengths.









### Controller Cable Assembly


Referring to the drawing on the following page, and to the previous instructions beginning on page 44, cut a 21 inch length of ribbon cable and prepare it as shown in the drawing.

The 37-pin connector shown at the top of the drawing is one of the FEMALE connectors included with your kit. The 10 & 20 pin connectors shown at the bottom of the drawing are of the same type as that on page 97 (female connectors), and should be assembled in the same manner.

Use the drawing on the following page, and the chart and drawing following after that, to construct this cable in the same relative manner as the previous ribbon cables.




DISK CONTROLLER CABLE



The drawing below illustrates the pin positions where each of the 18 twisted-pairs should be attached to the 37-pin connector. Be sure to use a female connector. This portion of the assembly is essentially identical with that shown on page 51.

Use the orientation for this process shown on page 113. It would be advisable to connect the varied colored wires from each pair to pins 1 through 19, and the same colored wire from each pair to pins 20 through 37.

#### 37-PIN FEMALE CONNECTOR






The drawing on the right illustrates the same three female connectors as shown on the bottom of the drawing on page 113. The orientation in the drawing on the right is the same as that on page 113, only rotated 90° counterclockwise.

The first step in this assembly process is to attach connector pins to the ends of each of the wires. Do this in the same manner as described on page 97. Note that two of the twisted-pairs have both of their wires attached to a single connector pin.

Once this is completed, the pins can be inserted into the female connectors. The numbers in the drawing on the right refer to the 37-pin connector pin numbers. Use the same procedure as with the previous ribbon cables and insert the pins into the connectors, correlating the 37-pin connector pin numbers on the right with the wires and positions with the proper wires and positions on the 3 female connectors.

Insert the the plastic keys in the positions shown. Be sure to insert them from the opposite side that the wires are inserted from.




\* NO WIRE CONNECTION

### CONTROLLER/DRIVE INTERCONNECT CABLE ASSEMBLY

There is one more cable to be assembled for the disk system. This cable will be used to connect the Disk Drive unit with the ALTAIR containing the controller.

- 1) The first step is to cut a 6 foot length of ribbon cable and remove 2 inches of the cable sheath from each end.
- 2) There are two grey plastic connector covers included in your kit. Slip one of these over each end of the cable, with the small holes towards the center of the cable and the larger holes towards the free ends. Push the covers down at least a foot so that they will not interfere with the rest of this procedure.
- 3) Strip 1/8 inch of insulation from both ends of each of the cable wires and tin the exposed portion.
- 4) Prepare the two remaining 37-pin connectors (one male & one female) in the same manner as the previous 37-pin connectors.
- 5) For this cable the connections will simply run pin-to-pin. That is, connect pin 1 of the male connector to pin 1 of the female connector. BE SURE NOT TO CONNECT ANY WIRES TO PIN 12 OF EITHER CONNECTOR.

- 6) Once all 36 wires have been connected on both ends, push the ends of the cable into a fold as shown on the right, and secure it with a double wrap of masking tape. Keep the fold as close as possible to the connector itself.



- 7) Push the connector covers into place over the two connectors. Do not use any of the hardware supplied with the covers by the factory. Simply mount the 37-pin connectors to the covers using standard 4-40 X 5/16 " screws.



### DISK/COMPUTER INTERFACE

Refer to the preliminary documentation release included with this manual for a description of how to hook-up and operate this system.

The above mentioned documentation includes an abbreviated version of both the theory and the operation of the ALTAIR FLOPPY DISK SYSTEM.

An updated, complete version of this documentation will be sent at a later date, as described in the front of this manual.

# DISK CONTROLLER CHECK OUT WITH DISK DRIVE

## A) Preliminary Test

This tests the primary functions of the Disk Drive and Disk Controller.

Enter the following program and then single step through (with Controller and Drive connected).

Address	Instruction	
000,000	076 MVI A	
1	000 Disk Drive Addr (0)	} NOTE 1
2	323 Output	
3	010 Disk Enable Channel	
4	076 MVI A	
5	004 Head Load (Bit D2=1)	} NOTE 2
6	323 Output	
7	011 Disk Control Channel	
10	333 Input	
11	011 Sector Position Channel	} NOTE 3
12	333 Input	} NOTE 4
13	010 Disk Status Channel	

### Note 1

Disk Drive should be enabled at the end of these 4 instructions.

### Note 2

Disk Drive Head should be loaded at the end of these 4 instructions.

### Note 3

After single stepping these two instructions, the ALTAIR data lights should indicate as follows:

D0 on all the time  
 D1 on all the time (flashing very fast)  
 D2 on all the time (flashing very fast)  
 D3 flashing very fast  
 D4 flashing slower  
 D5 flashing slowest  
 D6 on-not used  
 D7 on-not used

The flashing lights indicate the index/sector circuits are functioning properly.

#### Note 4

The last two instructions, when single stepped through, indicate the status of the disk on the data lights as follows:

- D0 - (ENWD) - On
- D1 - (MH) - Off
- D2 - (HS) - Off
- D3 - Not used - Off
- D4 - Not used - off
- D5 - (INTE) - On if "INTE" on front panel off
- D6 - (TRACK 0) - Off if disk head on track 0
- D7 - (NRDA) - Flickering, half on - indicates that read circuit is OK.

#### B) Testing Individual Functions

To test individual disk functions, an output of the correct data pattern must be done on Channel 011.

For example, to step the head in, use this program. Note--The disk must be enabled before doing any disk functions.

Address	Instruction
000,000	076 MVI A
1	000 Disk Drive Addr.
2	323 Output
3	010 Disk Enable Chan.
4	333 Input
5	377 From Sense SW
6	323 Output
7	011 Disk Control Channel

Set Sense Switch 8 up, others down when single stepping this program. Change switch pattern to control other functions.

# SERVICE

Should you have a problem with your unit, it can be returned to MITS for repair. If it is still under warranty any defective part will be replaced free of charge. The purchaser is responsible for all postage. In no case should a unit be shipped back without the outer case fully assembled.

If you need to return the unit to us for any reason, remove the top cover of the drive unit and install the wood block over the door mechanism as it was shipped to you. Secure cover and pack the unit in a sturdy cardboard container and surround it on all sides with a thick layer of packing material. You can use shredded newspaper, foamed plastic or excelsior. The packed carton should be neatly sealed with gummed tape and tied with a stout cord. Be sure to tape a letter containing your name and address, a description of the malfunction, and the original invoice (if the unit is still under warranty) to the outside of the box.

Mail the carton by parcel post or UPS--for extra fast service, ship by air parcel post. Be sure to insure the package.

SHIP TO:        MITS, Inc.  
                 2450 Alamo SE  
                 Albuquerque, NM 87106

All warranties are void if any changes have been made to the basic design of the machine or if the internal workings have been tampered with in any way.

# ALTAIR DISK TEST PROGRAMS

Reprinted from Computer Notes, April, 1976

Listed below are some Altair Disk Test programs that will check out all the normal functions of the Disk Drive. These check-out procedures will also be included in the Altair Disk Theory of Operation manual.

## A. Disk Read/Write Test Program

This program writes data on disk on sector 0 of the track it is positioned on, then reads the data back, stores it in memory, then outputs it to an I/O device. It is used for testing all read/write functions.

WRITE: The number of write data bytes is set by the position of the sense switches (maximum of 220<sub>8</sub>). Write data consists of:

1st byte = 377<sub>8</sub> (D7 = 1 - sync bit)  
2nd byte = data on sense switch  
3rd byte = 2nd - 1  
4th byte = 2nd - 2  
.  
.  
.  
"n"th byte = 001  
last byte = 000

If sense switch is set to 000, program will stop.

READ: The read data is stored in memory, starting at address 001,236<sub>8</sub> and consists of the data written by the write program

OUTPUT: After the read program, the data is outputted to a terminal (Teletype, CRT, etc.). The output program is set to output on channel 1. To obtain a useful output pattern, change the sense switches until a desirable pattern is printed. The characters printed will consist of all printable ASCII characters in reversed order (as in 987654321 and zyxwvu . . . ). This pattern repeats itself and is easily observed for errors.

## B. Stepping Program

This program steps the disk head out 77 times to track 0 and then in 77 times to track 76, continuously repeating with the computer in the run mode.

This program is useful for testing the disk enable, MH status, track 0 status, and stepping functions of the disk.

While stepping with this program, the head is unloaded, so it may be run continuously without wear on the read/write head surface. A squeaking sound caused by the head load mechanism is normal in this test.

To loop with the read/write program, see next section.

For stepping program, disk drive address of 000 is used. To change disk drive tested, the address is contained in location (001,001).

#### Looping With Stepping Program

To check the read/write and step functions simultaneously, the two programs may be run together by changing:

- 1) Data in locations (000,154) and (000,155) to 037, 001 as indicated.
- 2) Data in location (001,034) to 303 as indicated.

Start the program at (001,000), the start of the stepping program.

The disk head will step out to track 0.

The head will then load and a write/read will occur. The head will then unload and output will take place. After output, the head will step in once, starting the write/read sequence again. After this repeats 76 times, the head is stepped out to track 0, and it begins again. \*\*



- NOTE: \*\*
- 1) For read/write program, disk drive address of 000 is used. To change disk drive tested, the address is contained in location (000,001) and (000,150).
  - 2) Output device addresses are in locations (000,133) (status) and (000,141) (data).

# READ/WRITE/OUTPUT PROGRAM

TAG	MEMORIC	ADDRESS	OCTAL CODE	EXPLANATION
LMD	MVI(A)	000,000	076	Disk drive address
	OUT	1	000	
	OUT	2	323	
	MVI(A)	3	010	Disk controller enable channel
WRTLP	OUT	4	076	
	OUT	5	004	Load head bit
	OUT	6	323	
	IN	7	011	Disk function control channel
RSECT	IN	10	333	Input # of bytes to be written
	MOV(C)←(A)	11	377	Sense switch
	MVI(D)	12	117	Store in "C" reg.
	MVI(D)	13	026	Store in "D" reg.
RSECT	MVI(B)	14	377	First write byte
	MVI(B)	15	006	Store in "B" reg.
	MVI(B)	16	001	"END" status mask
	IN	17	333	Write sector test
RSECT	IN	20	011	Sector position channel
	CPI	21	376	
	JNZ	22	300	# sector
	JNZ	23	302	Jump if not start of # sect.
RSECT	JNZ	24	017	to "RSECT"
	JNZ	25	000	
	MVI(A)	26	076	
	MVI(A)	27	200	Write enable bit
RSECT	OUT	30	323	
	OUT	31	011	Disk function control channel
	OUT	32	333	First byte test
	OUT	33	010	Disk status channel
RSECT	ANA(A)/(B)	34	240	Test for "END" status
	JNZ	35	302	Jump if "END" false (=1)
	JNZ	36	032	to "RSECT"
	JNZ	37	000	
RSECT	MOV(A)(D)	40	172	Move 377 into accum.
	OUT	41	323	Output first byte
	OUT	42	012	Disk data channel
	IN	43	333	Start of write data sequence
RSECT	ANA	44	010	Disk status channel
	ANA	45	240	Test for "END" status
	JNZ	46	302	Jump if "END" false (=1)
	JNZ	47	043	to "RSECT"
RSECT	JNZ	50	000	
	MOV(A)←(C)	51	171	Move "DATA" byte to accum.
	OUT	52	323	
	OUT	53	012	Disk data channel
RSECT	OCR(C)	54	015	Decrement "DATA" byte
	JNZ	55	302	Jump if data byte = #.
	JNZ	56	043	to "RSECT", write another byte
	JNZ	57	000	
RSECT	IN	60	333	Start of zero byte
	OUT	61	010	Output sequence
	ANA(A)←(B)	62	240	Test "END" (last byte written)
	JNZ	63	302	Jump if "END" false
RSECT	JNZ	64	060	To WRT
	JNZ	65	000	
	XRA(A)(A)	66	257	Zeros accumulator
	OUT	67	323	Output zero byte
RSECT	OUT	70	012	Disk data channel (end of write, start of read)
	LXI	71	041	Load H-L reg. with:
	LXI	72	236	Starting addr. to store read data
	LXI	73	001	



TAG	MEMORIC	ADDRESS	OCTAL CODE	EXPLANATION
RSECT	MVI(B)	74	006	Store in "B" reg.
	NOP	75	200	"NRDA" mask
	NOP	76	000	
	NOP	77	000	
RSECT	IN	100	333	Read sector test
	IN	101	011	Sector position channel
	CPI	102	376	
	JNZ	103	300	# sector
RSECT	JNZ	104	302	Jump if not start of # sect.
	JNZ	105	100	to "RSECT"
	JNZ	106	000	
	IN	107	333	Start of "NRDA" test
RSECT	IN	110	010	Disk status channel
	ANA(A)/(B)	111	240	Test for "NRDA" status
	JNZ	112	302	Jump if "NRDA" false (=1)
	JNZ	113	107	to "RSECT"
RSECT	JNZ	114	000	
	IN	115	333	Input read data
	IN	116	012	Disk data channel
	MOV(M)←(A)	117	167	Store data in memory (H-L)
RSECT	INR(L)	120	054	Increment L reg. (mem addr)
	JNZ	121	302	Jump if L reg. # 0
	JNZ	122	107	to RUTST
	JNZ	123	000	
RSECT	MOV(A)←(D)	124	172	Move 377 byte to accum.
	OUT	125	323	Disable disk by output logic 1 on
	OUT	126	010	07 to disk enable chan. (end of read start of output)
	LXI(H-L)	127	041	Load H-L with:
RSECT	LXI(H-L)	130	236	Starting addr of data stored by read program
	LXI(H-L)	131	001	
RSECT	IN	132	333	Test output device for busy
	IN	133	000	Status chan. of terminal
	RLC	134	007	Test bit #, rotate into carry
	JC	135	332	Jump if carry (bit # = 1)
RSECT	JC	136	132	to "RUTST"
	JC	137	000	
	MOV(A)←(H)	140	176	Move data from mem(H-L)
	OUT	141	323	Output data
RSECT	OUT	142	001	Data channel for term
	INR(L)	143	054	Increment L register
	JNZ	144	302	Jump if L reg # 0, output another byte
	JNZ	145	132	to "RUTST"
RSECT	JNZ	146	000	
	MVI(A)	147	076	
	MVI(A)	150	000	Enable disk
	OUT	151	323	
RSECT	OUT	152	010	
	JMP	153	303	
	JMP	154	004	To "LMD"
	JMP	155	000	
RSECT	JMP	156		
	JMP	157		
	JMP			
	JMP			

\*\*\*For R/W-step loop change  
Data at (000,154) to 037  
Data at (000,155) to 001





# STEPPING PROGRAM



TAG	INSTRUCTION	ADDRESS	INITIAL VALUE	EXPLANATION
STEP	MVI(A)	001,000	076	
	OUT	1 000		Disk drive addr 0
		2 323		Output (data-000) to
		3 010		Disk CTRL enable channel
NOS	MVI(E)	4 036		Initialize E register
		5 115		=77 (number of steps + 1)
SOUT	IN	6 333		Test "H" status bit (move head)
		7 010		Disk status channel
	ANI	10 346		Test
		11 002		D1 mask
	JNZ	12 302		Jump if "H" false (D1=1)
		13 006		To "SOUT"
		14 001		
	MVI(A)	15 076		
		16 002		Bit D1=1 (step out)
	OUT	17 323		Output (data 002) to
		20 011		Disk function control channel
	DCR(E)	21 035		Decrement step counter (E reg.)
	JNZ	22 302		Jump if E reg. = 0
		23 006		To "SOUT"
		24 001		
T2	IN	25 333		Test for track 0 status
		26 010		Disk status channel
	ANI	27 346		Test
		30 100		D6 mask
	JNZ	31 302		Jump if track 0 false (D6=1)
		32 025		To "T2"
		33 001		
LOOP	NOP	34 000		
	NOP	35 000		
	NOP	36 000		
SIN	IN	37 333		Test "H" status bit (move head)
		40 010		Disk status channel
	ANI	41 346		Test
		42 002		D1 mask
	JNZ	43 302		Jump if "H" false (D1=1)
		44 037		To "SIN"
		45 001		
	MVI(A)	46 076		
		47 001		Bit D0 = 1
	OUT	50 323		Output (Data 001) to
		51 011		Disk function control channel
	INR(E)	52 034		Add 1 to "E" register
	MVI(A)	53 076		
		54 114		76 steps
	CP(A)/(E)	55 273		Compare "E" reg. to 76
	JNZ	56 302		Jump if "E" reg. = 76
		57 034		To "Loop"
		60 001		To "Loop"
	JMP	61 303		Jump if "E" reg. = 76
		62 004		To "NOS"
		63 001		
		64		
		65		
		66		
		67		

\*--Change to 303 for Step = 2/W loop



PRELIMINARY DOCUMENTATION RELEASE

THE FOLLOWING INFORMATION IS A PRELIMINARY RELEASE ONLY.

THE COMPLETE THEORY OF OPERATION WILL BE ADDED TO THE ASSEMBLY MANUAL AT A LATER DATE. THE OPERATORS MANUAL AND DOS DOCUMENTATION WILL BE DEVELOPED IN A SINGLE MANUAL ALSO. BOTH OF THESE, AND ANY UPDATES TO THIS ENTIRE SYSTEM DOCUMENTATION WILL BE SENT IMMEDIATELY UPON THEIR PRINTING DATE.

## Disk Hardware Notes

By Tom Durston

If you are having difficulties with your 88-DCDD hardware, follow these guidelines for servicing:

## A. Controller Boards:

1. On Controller Board #1 be sure the bus strips are soldered on both the top and bottom of the P.C. Board. Do not apply pressure to bus strips after installation.
2. On Controller Board #1 jumper the top end of R16 (VHB) to the track from pin 7 of IC F2 (on back of card). This ties floating inputs of sector logic high to prevent noise pickup.
3. On Controller Board #1 check the track from Pin 9 of IC H1 where it goes through the board on the plated hole. Some P.C. Cards had shorts to the adjacent track on the back of the card.
4. On Controller Board #1 check jumper wires to be sure there are no shorts to bus strips (insulation on wires melted), and check jumper wires for correct wiring.
5. On both Board 1 and 2 check Stab Connector for shorts on fingers. File at an angle along the length of the Stab Connector and the bevel edge of the card to remove any shorts.
6. Be sure all interconnect cables are wired correctly and the pins are making good contact.
7. Check one shot timing on both boards as follows, using the Disk Test Program that appeared in April '76 Computer Notes, pages 12 and 15.

## a) Controller Board #1:

<u>FUNCTION</u>	<u>IC and PIN #</u>	<u>POSITIVE PULSE WIDTH RANGE</u>
Read Clock Mask	IC A1 Pin 15	0.7us to 1.2us
Read Data Window	IC A1 Pin 5	2.6us to 2.9us
Sector Pulse Mask	IC E1 Pin 15	150us to 600us
Index Pulse Window	IC E1 Pin 5	3.3ms to 4.5ms
Read Clear	IC F1 Pin 15	150us to 150us
Index Pulse Verification	IC F1 Pin 5	3.3ms to 4.5ms
Sector True	IC F4 Pin 15	20us to 40us
Write Data Enable	IC F4 Pin 5	250us to 300us

b) Controller Board #2:

<u>FUNCTION</u>	<u>IC and PIN #</u>	<u>POSITIVE PULSE WIDTH RANGE</u>
Repeat Step OK (Status)	IC A1 Pin 13	0.4ms to 0.8ms
Step Inhibit 1 (Status)	IC A1 Pin 5	9.5ms to 11.5ms
Head Settle	IC B1 Pin 13	35ms to 70ms
Step Inhibit 2 (Status)	IC B1 Pin 5	17ms to 30ms
Trim Erase Start Delay	IC B2 Pin 13	180us to 225us
Trim Erase End Delay	IC B2 Pin 5	420us to 520us
Disk Enable Timer	IC B3 Pin 13	1.5us to 4.5us
Disk Power Disable	IC B3 Pin 5	1.5us to 4.5us

c) If the measured time constants are not within the specified tolerance, vary the resistor value for the one shot affected.

d) We have had difficulty using National 74123 ICs for B3 on Board #2. Replace with Signetics or TI ICs if you suspect problems.

8. If you are using 4K Dynamic cards, be sure they are using only one wait state. See May '76 Computer Notes, pages 9 and 10.

9. Check the Power Supply to be sure the negative peaks of the +8V unregulated do not go below +7V.

B. Disk Drive Chassis:

1. On the Buffer Card the most common difficulty is incorrect wiring or incorrectly installed ICs.
2. On the Power Supply Board be sure X1 and X3 are properly installed as indicated on the errata sheet.
3. If you suspect difficulty with the Disk Drive, DO NOT attempt to service it. Any work done on the Pertec FD-400 will void the warranty. Typical service charges for customer damaged FD-400's are \$100.00.
4. Do not plug the FD-400 connector in backwards. Be sure to install the polarizing key as the instructions indicate. Plugging in the connector backwards will destroy 5-10 ICs and will cost at least \$100.00 for repair.
5. If you must ship the Pertec FD-400 or complete Disk Drive Unit, reinstall the Disk door block or strap. Any damage to the mechanism as a result of incorrect shipping typically costs the customer \$100.00 in repair charges.
6. Our dealers now have Pertec FD-400 service manuals. If you suspect difficulty with the FD-400, contact your nearest dealer for his advice and service.
7. If you can't remedy the difficulty, don't try to save postage by just returning the FD-400 alone. Please return your complete 33-DCDD including Cables, Controller Boards, and Drive Chassis. This will allow us to check your system out completely and save you time, money, and hassle.

I. DESCRIPTION OF SYSTEM

A) DISK SPEC SHEET

B) DISK SYSTEM BLOCK DIAGRAM DESCRIPTION

1. CONTROLLER BOARD 1:

Controller Board 1 does all input functions to the ALTAIR bus (Read Data, Sector Data, Status Information), as well as Control Addressing of all Disk to ALTAIR I/O.

2. CONTROLLER BOARD 2:

Controller Board 2 performs all output functions from the ALTAIR bus (Write Data, Disk Control, Disk Enable and Drive Selection).

3. INTERCONNECT CABLE:

An 18 pair flat cable with two 37 pin connectors, a male on one end, a female on the other. This cable connects the Disk Drive to the ALTAIR Disk Controller and "Daisy Chains" one Disk Drive to another in multiple Disk systems.

4. DISK DRIVE CABINET:

a) POWER SUPPLY:

The Disk Drive Cabinet contains a power supply for powering the Disk Buffer and Disk Drive.

b) THE DISK BUFFER:

The Disk Buffer board contains the necessary line drivers and receivers for interconnection with long cables to the Disk Drive. In addition, it contains the Disk Drive Address circuitry that allows the Controller to select one of 16 Disk Drives.

The Disk Buffer board also contains the line drivers for connection of multiple Disk Systems.

c) THE DISK DRIVE:

The Disk Drive, a Pertec FD-400, contains the mechanism and electronics that actually reads and writes data on the Diskette.

## II. CONNECTION OF DISK SYSTEM:

### A) CONTROLLER BOARDS:

#### 1. Items Supplied:

- a) CONTROLLER BOARD 1 (white vert strips)
- b) CONTROLLER BOARD 2 (with short cable wired to it)
- c) CONTROLLER CABLE (with 37 pin on one end, 3 Molex connectors on the other end)
- d) Connector Mounting Bracket and Hardware

#### 2. Connection of Controller Boards

- a) Take cover off ALTAIR (power off!)
- b) Feed Molex (flat) connector ends of Controller cable through hole in back of ALTAIR on connector panel: (37 pin connector outside chassis, molex connectors inside chassis).
- c) Lay board 1 flat in front of you on the ALTAIR chassis with components up and stab connector to your right (as facing the front of the ALTAIR).
- d) Take the short wired cable of board 2 and connect it to the 20 pin connector on board 1 (note polarization key of connector and missing pin on the PC board).
- e) Place board 2 flat, to the left of board 1.
- f) Connect 20 pin Molex connector on the Controller cable to the 20 pin connector on board 2. Note Keying.
- g) Take the 10 pin connector on the Controller cable with the orange and yellow wires connected to it and connect it to the 10 pin connector on board 2. Note Keying.
- h) Take the remaining 10 pin connector on the Controller cable with white and gray wires on it and connect it to the 10 pin connector on board 1. Note Keying.
- i) Take both boards, hold together and slide into slots, with board 1 on right, board 2 on the left. Be sure wires from connector go out between card guides, and do not catch on card guides.
- j) Push cards firmly into connector in ALTAIR mother board.
- k) Install 37 pin connector in bracket and on back of ALTAIR, straddling 2 connector holes. Use #4-40 x 5/16 screws, lockwashers and #4-40 nuts.

### B) DISK DRIVE CONNECTION TO ALTAIR:

Take the 6 ft. flat cable with 1 male and 1 female connector; connect male end to Disk Controller connector on ALTAIR, and female end to connector on the Disk Drive marked "To Controller".

### C) MULTIPLE DISK DRIVE CONNECTION:

1. With multiple Disk Drives, the Disks should have sequential addresses (i.e., for a 3 drive system you should have Disks with addresses 0, 1, and 2). They may be connected in any order. The serial # sticker has the Disk Address written on it. The Disk Address is determined by four jumper wires in the Disk Buffer P.C. card inside the Drive, and may be changed.
2. Connect the Disks by using the 6 ft. flat cable. Connect the male connector to the connector marked "From Next Disk" on the Disk Drive connected to the Controller. The other end of the cable connects to the next Disk Drive connector marked "To Controller". This procedure is repeated for added Disk Drive.

### III. USING THE DISK DRIVE:

#### A) DISKETTE INFORMATION:

1. Always keep Diskette in envelope when not in use.
2. Keep Diskette away from heat, magnetic fields (fluorescent lights, power transformers, etc.) and dust and dirt.
3. Never touch recording surface of Diskette (opposite label side).
4. Always mark your Diskette with what is on them. Use adhesive labels, but don't write on them after they are attached to the Diskette.
5. The Diskette used is hard Sector (32 Sector holes, 1 index hole). Blank Diskettes are available from MITS for \$15.00 each. The Diskettes are not IBM compatible.

#### B) OPERATING THE DISK DRIVE:

1. Open door to Disk Drive by pulling out and down.
2. Insert Diskette into Drive with label side up, making sure it catches on retaining tab.
3. Close door to Disk Drive.
4. The "pwr" LED will indicate the "on" state except for about 5 seconds when the power is turned on, or for about 5 seconds after the door is closed. When the "pwr" light is on, it indicates that the Disk Drive may be enabled and that programs may be activated to access the disk.
5. NEVER: open Disk Drive door or turn power off when Disk Enable and Head Load lights are on. There would be a good possibility that you would interrupt the software during a write function, and destroy data on the Diskette.
6. Consult software documentation on methods used to load basic or use software. For applications where the user wishes to write his own software. See last section, "Controller I/O Information".



## ALTAIR DISK CONTROLLER I/O INFORMATION

### A. Address codes for I/O

	<u>Address</u>	<u>Mode</u>	
1.	010	Out	Select, latches and enables controller and disk drive.
2.	010	In	Indicates status of disk drive and controller.
3.	011	Out	Controls disk function.
4.	011	In	Indicates sector position of disk.
5.	012	Out	Write data.
6.	012	In	Read data.

### B. Definitions (In order as listed above)

#### 1. Selection of Disk Drive "OUT" on CH #010

D0 LSB	Enables 1 of 16 drives (each drive has a unique address, selected by 4 jumper wires) and enables controller (on disk drive buffer P.C. card).
D1	
D2	
D3 MSB	
D4	
D5	Not used, don't care.
D6	
D7	Clears disk control if set to 1 (D0-D6 don't care). Disables disk control. Disk control also cleared by opening door of disk drive or turning disk drive power off.

- NOTE:
- a) If disk drive door is open, drive and controller cannot be enabled.
  - b) If disk power is off, drive and controller cannot be enabled.
  - c) If disk interconnect cable is not connected between the controller and the drive, drive and controller cannot be enabled.

2. Status (010 - INP) indicates disk status when drive and controller enabled. Also gives valid "INTE" status (D5) from the ALTAIR bus when controller enabled.

True condition = 0, False = 1.

All false if disk and controller are not enabled, and all false if no disk in drive.

- D0 - ENWD - Enter new Write data - indicates write circuit is ready for new data byte to be written. It occurs every 32  $\mu$ s and starts 280  $\mu$ s after sector true (when Write enabled). It is reset by outputting to the Write data channel (012).
- D1 - Move Head - Indicates head movement allowed when true (step IN, step OUT,). Goes false for 10 ms, true 1 ms, false 20 ms after step command. May step every 10 ms. Goes false for 40 ms after head load. Goes false during Write and 475  $\mu$ s after Write to allow completion of trim erase.
- D2 - HS - Head Status - True 40 ms after head loaded or step command (if stepping with head already loaded). Indicates when head is properly loaded for reading and writing. Also enables sector position channel when true.
- D3 - Not Used, = 0.
- D4 - Not Used, = 0.
- D5 - INTE - Indicates interrupt enabled.
- D6 - TRACK 0 - Indicates when head is on outermost track.
- D7 - NRDA - New read data available - indicates that the read circuit has 1 byte of data ready to be taken from the read data channel (012). After the SYNC\* bit is detected, it occurs every 32  $\mu$ s and is reset by an input instruction on channel 012. The byte containing the SYNC bit is the first byte read from the disk.

\* See "Write Enable"

3. Control (Ø11 - Out) - Controls Disk operations when disk drive and controller enabled. A true signal, logic 1, on a data line will control the disk as follows:
- DØ - Step IN - steps disk head in one position to higher numbered track.
  - D1 - Step OUT - steps disk head out one position to lower numbered track.
  - D2 - Head Load - loads head onto disk - enables sector position status.
  - D3 - Head Unload - removes head from disk surface, may be unloaded immediately after "Write Enable" (write and trim erase circuits hold head loaded until through).
  - D4 - IE - Interrupt Enable - enables interrupts to occur when SRØ true (see sector definition).
  - D5 - ID - Interrupt Disable - disables interrupt circuit. Interrupt circuit also disabled by clearing disk control.
  - D6 - HCS - Head Current Switch - must be true when outputting a write instruction with the head on tracks 43-76. This reduces head current and optimizes resolution on inner tracks (automatically reset at end of writing a sector).
  - D7 - Write Enable - initiates write sequence as follows:
    - 1. Disk selected and enabled, head loaded, enabling sector status.
    - 2. (Sector True) detected for desired sector, write circuit enabled by software.
    - 3. 200 µs from Write Enable, trim erase automatically turned on. 280 µs from start of sector, "ENWD" goes true, sync byte written by software.
    - 4. First byte written always has most significant (D7) bit A "1" (SYNC Bit) (most significant bit written first).
    - 5. ENWD goes true every 32 µs. MAX. no. of data bytes per sector 137 (including SYNC).
    - 6. Last or 138th byte written must be a 000. This will be written for the remainder of the sector. Ignore "ENWD" from this point to end of sector.
    - 7. At end of sector, the write circuit automatically disabled, trim erase disabled 475 µs later.

- NOTE: a) Write circuit will continue writing last byte outputted on CH #012 to the end of that sector.
- b) Head may be unloaded anytime during write cycle if no read or write function is expected after current write cycle. Once Write is enabled, it holds the head loaded for the required time. (For writing and trim erase).


4. Sector Position (011 - INP) with disk drive and controller enabled, and 40 ms after head is loaded, the sector information is as follows:

D0 - SR0 - Sector True - True when = 0, and is 30  $\mu$ s long. The write mode should begin as close as possible to the time that D0 goes true. Write data will be requested 280  $\mu$ s after D0 goes true. Read data will be available 140  $\mu$ s after SR0 goes true.

SECTOR #	0	1	2	3.....31
D1-SR1-	0	1	0	1.....1
D2-SR2-	0	0	1	1.....1
D3-SR3-	0	0	0	0.....1
D4-SR4-	0	0	0	0.....1
D5-SR5-	0	0	0	0.....1


5. Write Data (012-OUT) Outputted on the "ENWD" status request.
6. Read Data (012-IN) Inputted on the "NRDA" status flag.

# READ/WRITE TIMING DURING READ OR WRITE FUNCTION






DISK SYSTEM BLOCK DIAGRAM










88 DISK BLOCK DIAGRAM




# DISK CONTROLLER BLOCK DIAGRAM SHEET 1 EXTERNAL CONNECTIONS AND ADDRESS SELECT






**DISK CONTROLLER BLOCK DIAGRAM**  
**SHEET 2 INTERNAL CONNECTIONS**








\* HEATSINK ON CHASSIS

DISK DRIVE POWER SUPPLY










REF/SPARE	TYPE	VCC	GND
A,B,D,E	8T97	16	8
C	8T98	16	8
F	74LS0	14	7
G	9601	14	7

NOTE:  
"IN" CONNECTOR LABELED "TO CONTROLLER!"  
"OUT" CONNECTOR LABELED "FROM NEXT DISK!"



DISK BUFFER PC CARD SCHEMATIC





\* ON REV 1 BOARD ONLY

DISK CONTROLLER BOARD #1 SHEET 1 OF 3

ADDRESS/I-O SELECT & SECTOR CIRCUITS










DISK CONTROLLER BOARD #2 SHEET 1 OF 3

WRITE DATA & DISK ENABLE CIRCUITS








POWER CONNECTIONS				
REF	TYPE	VCC	GRD	SUBSTITUTIONS
F1,F3,F4,H1,J1	74L02	14	7	74LS02
E1,E3	74L00	14	7	74LS00
B4,G2,G4,H4	74L04	14	7	74LS04
J2	8T98	16	8	74LS68
E4	74L10	14	7	74LS10
H2	74L66	16	8	74LS166
G3,H3,J3	74L75	5	12	74LS75
A3,A4	93L16	16	8	74LS161
J4	74L74	14	7	74LS74
A2,E2,F2	74L73	4	11	74LS73
A1,B1,B2,B3	74L23	16	8	
K3	8T97	16	8	74367
L1	7805	2	3	

- NOTES:
1. ALL RESISTORS 1/2 W UNLESS SPECIFIED.
  2. ALL CAPACITORS IN UF.
  3. ALL DIODES IN 914.
  4. (40ms) NOMINAL TIME CONSTANT.







**mits**

**2450 Alamo SE  
Albuquerque, NM 87106**

88-DCDD Documentation

Erratum, December, 1977

Page 229:

( ) E1, E2 -- 14-pin -- 74L00

CHANGE TO:

( ) E1, E3 -- 14-pin -- 74L00

DEC 9 1977



SYSTEM TIMING MODIFICATION FOR ALTAIR FLOPPY DISK

IMPORTANT

If assembling a new unit, disregard the component removal instructions and install new components in place of the components provided with the 88-DCDD kit.



## I. Introduction

To increase Diskette interchangeability from Drive to Drive and minimize Disk I/O errors, two time constants on the 88-DCDD Controller Board #1 have been reevaluated. The effect of the timing change is to center the data within the Sector, allowing a greater tolerance of Disk Drive misalignment.

A Diskette written with the new write delay should be marked "NWD" for identification purposes. All BASIC and DOS Diskettes shipped from MITS after August 31, 1977, are written with the new write delay and are marked "NWD." All Diskettes written with the new write delay are compatible with unmodified systems. The Read Clear Timing must be changed to take advantage of the new write delay modification. When Diskette interchangeability is not required and there is no difficulty with Disk I/O Errors, the complete modification is not mandatory; however, changing the Write Delay as in Section II, Step A is recommended. The modification is strongly recommended for multiple Drive systems or single Drive systems where Diskette interchange is required.

If facilities for performing the modification are not available, return Controller Board #1 for special modification at no extra charge. The board will be modified except for replacement of the Read Clear One Shot timing resistor, R5. The correct resistor for R5 will be returned with the board and should be installed after all Disk software copying or rewriting is completed as indicated in Section IV of the modification procedure.

An important modification includes changing the timing IC to 74LS221. This is done because the 74LS221 is more stable and predictable than the 74123, and eliminates the need for trimming or adjusting the timing resistors.

The modification procedure is outlined in Section II and IC installation and identification instructions are provided in Section III. The recommended procedure for copying Disk software for single and multiple Drive systems is explained in Section IV.

The following is a list of the parts included in the modification kit:

<u>Quantity</u>	<u>Value</u>	<u>MITS Part #</u>	<u>Component Location</u>
2	74LS221 IC	101466	F1, F4
1	6.65K $\pm$ 1% resistor	102225	R5
1	12.1K $\pm$ 1% resistor	102226	R12
1	4.32K $\pm$ 1% resistor	102227	R11
1	8.45K $\pm$ 1% resistor	102228	R6

## II. Modification Procedure

- A. Change the Write Clear One Shot timing from 280 $\mu$ s to 389 $\mu$ s.
  1. Remove resistors R11 and R12. Be careful not to damage the plated portion around the holes in the PC board.
  2. Install a 4.32K ohm ( $\pm$  1% tolerance) resistor in the R11 position and a 12.1K ohm ( $\pm$  1% tolerance) resistor in the R12 location, according to the following instructions.
    - a. Using needle-nose pliers, bend the leads of the resistors at right angles to match their respective holes in the PC board.
    - b. Install the resistors into the correct holes in the silkscreened side of the board.
    - c. Holding the resistor in place with one hand, turn the board over and bend the two leads slightly outward.
    - d. Solder the leads to the foil pattern on the back side of the board. Then clip off any excess lead lengths.
  3. Remove IC F4 from its socket and install the 74LS221 IC in its place according to the installation instructions in Section III, Part C. If IC F4 is installed directly into the board, follow the removal and installation instructions in Section III, Part B.
  4. If available, use an oscilloscope to measure the positive pulse width at TP-8 (IC F4 pin 5). This step is not mandatory due to the timing predictability of the 74LS221 IC. The pulse width should be in the range of 355 $\mu$ s to 425 $\mu$ s (389 $\mu$ s nominal  $\pm$  10%) when the Drive is enabled and a Diskette installed.
- B. Copy all Diskettes using the procedures and instructions listed in Section IV. If the Read Timing is not to be changed, it is not necessary to copy the Diskettes.



- C. Change the Read Clear One Shot timing from 140 $\mu$ s to 214 $\mu$ s.
1. Remove R5 and R6 being careful not to damage the plated portion around the holes in the PC board.
  2. Install a 6.65K ( $\pm$  1% tolerance) resistor in the R5 position and an 8.25K ( $\pm$  1% tolerance) resistor in the R6 position according to the resistor installation procedures followed in Part A, Step 2 of this section.
  3. Remove IC F1 from its socket and install the 74LS221 IC in its place according to the installation instructions in Section III, Part C. If IC F1 is installed directly into the board, follow the removal and installation instructions in Section III, Part B.
  4. If available, use an oscilloscope to measure the positive pulse width at TP-5 (IC F1 pin 13). This step is not mandatory due to the timing predictability of the 74LS221 IC. The pulse width should be in the range of 195 $\mu$ s to 230 $\mu$ s (214 $\mu$ s nominal  $\pm$  10%) when the Drive is enabled and a Diskette is installed.
- D. Change the schematic to coincide with the modification.


### III. IC Identification and Installation

#### A. IC Identification Instructions.


All integrated circuits (ICs) must be oriented so that the notched end is toward the arrowhead printed on the PC board. Pin 1 of the IC should correspond with the pad marked with the arrowhead. If the IC does not have a notch on one end, refer to the IC Identification Chart to identify pin 1.

ICs may have any one, or a combination, of several different markings which are very important in determining correct orientation when the ICs are placed on the printed circuit boards. Incorrect orientation of ICs may cause permanent damage.

IC Identification Chart



The chart below indicates the various methods used to show the position of ICs on the printed circuit boards. These outlines are silkscreened directly on the board. The arrowhead indicates the pin 1 position.



All ICs can be easily damaged and should be handled carefully. Always try to hold the IC by the ends, touching the pins as little as possible. When removing the IC from its holder, carefully straighten any bent pins with needle-nose pliers. All pins should be evenly spaced and should be aligned in a straight line, perpendicular to the body of the IC itself.

B. Removal and Installation of ICs Without Sockets.

1. Cut all the pins and carefully remove each pin one by one.
2. Clean the holes by using solder wick or a solder removing tool. Be careful not to remove the plated portion of the hole.
3. To install the new IC, orient the IC so that pin 1 coincides with the arrowhead on the PC board.
4. Align the pins on one side of the IC so that just the tips are inserted into the proper holes on the board.

5. Lower the other side of the IC into place. If the pins cannot be easily inserted into their holes, rock the IC back, exert a little inward pressure, and try again. Be patient. The tip of a small screwdriver may be used to help guide the pins into place. When the tips of all the pins have been started into their holes, push the IC into the board all the way. Tape the IC to the board with masking tape.
6. Turn the board over and solder each pin to the foil pattern on the back of the board. Turn the board over and again solder each pin on the component side of the board to insure proper feed-through connection. Be sure each pin is soldered and there are no solder bridges.

**WARNING**

Make sure none of the pins have been pushed underneath the IC during insertion.

**C. Installing ICs in Socket.**

1. After removing the old IC from the socket, orient the IC to be installed over the socket so that pin 1 coincides with the arrowhead on the PC board.
2. Align the pins on one side of the socket so that just the tips are inserted into the holes.
3. Lower the other side of the IC into place. If the pins cannot be easily inserted into their holes, rock the IC back, exert a little inward pressure, and try again. Be patient. When the tips of all the pins have been started into their holes, push the IC into the socket all the way.

#### IV. Copy/Rewrite Procedures

The following procedures are recommended to copy Disk software for the new Disk Read/Write modifications.

##### CAUTION

All Disk software copying should be done AFTER the Write modification has been made, but BEFORE the Read modification is made.

##### A. With a Two or More Disk Drive System.

METHOD 1 - If using Disk BASIC versions 3.3, 3.4, 4.0 or 4.1, the PIP Utility Program provided on the system Diskette may be utilized to copy onto a new Diskette. A listing of PIP and instructions on its use are included in Section IV, Part C.

STEP 1. Load Disk BASIC. Initialize the system for at least two Disk Drives, i.e., HIGHEST DISK NUMBER? should be answered with 1 or higher.

STEP 2. MOUNT the Diskette with BASIC and PIP on it. Do not attempt to MOUNT a Diskette that is brand new (never had BASIC or files on it).

STEP 3. LOAD PIP and type RUN.

STEP 4. Use the PIP Copy command to copy the old Diskette (the one with BASIC and your files) onto the new Diskette. COP takes approximately 30 minutes, so have patience.

STEP 5. Check the new Diskette by re-loading BASIC (from the new Diskette), MOUNTing, printing a directory of files to make sure everything was copied correctly.

STEP 6. Now make the Disk Read modification.

METHOD II - When using DOS (Disk Operating System) and Disk BASIC, Disk BASIC and the PIP Utility Program can be used to copy the DOS Diskettes. Follow the procedure in Method I, except:

STEP 3. LOAD "PIP" but UNLOAD the Diskette with BASIC on it before RUNning PIP. Place the DOS Diskette in the Drive where BASIC was. It is not necessary to MOUNT to copy with PIP. Now RUN PIP, and proceed with STEP 4 of Method I.

STEP 5. Check the new Diskette by loading DOS, MOUNTing, issuing a DIR command and possibly running a couple of the programs. Proceed with STEP 6 of METHOD I.

B. With a Single Drive System.

METHOD I - If Disk BASIC versions 3.3, 3.4, 4.0 or 4.1 are being used, the following program is used to copy a Diskette onto itself by changing the write delay timing with which each Sector of the Diskette is written. The program is necessary in order to take advantage of the changes to the Read and Write time delays on the Altair 88-DCDD Disk Controller cards. Together, the program and hardware modifications change the physical position within a Sector of a Diskette where the data is written to and read from.

The program works by buffering an entire track of data at a time. This is done by allocating one element to the string array A\$ for each Sector on a track. The data on a specific track is then read into this array and verified by rereading each Sector to make sure it was read correctly the first time. If for some reason the data for a given Sector will not verify, the Sector is read back into the array again and reread a second time. This process is repeated until verification occurs. Once an entire track has been read and verified, the data is then written back onto the same physical track of the Diskette. In order to insure that the entire operation is done correctly, the newly written data is reread and compared against the original data. Again, if a specific

Sector will not verify, it is rewritten from the original data and reread to verify the write. This process continues until all rewritten data on the track is verified.

The program should work without encountering many REREAD or REWRITE errors if the Disk Drive is in correct operating condition and there is nothing wrong with the Diskette. If a large number of these errors are encountered, there is usually something physically wrong with the Drive (alignment, transport, etc.) or the Diskette.

To use the program, first make the modifications to the write time delay circuit on Controller Board #1 as described in Section II, Part A. Then bring up BASIC and enter the program. It can be saved on the Diskette. Now the program must be run on all Diskettes containing programs or data for future use. Once this is done, make the modifications to the read time delay circuitry on Controller Board #1 as described in Section II, Part C. This entire procedure should greatly reduce the frequency of Disk I/O Errors due to Drive alignment problems.

NOTE

This program takes about 30 minutes to run. It can be made to run faster by increasing the amount of string space cleared in line 100. Currently, a minimum 4658 (137\*34) bytes are cleared. This should be changed to clear as much string space as there is memory available after the program is loaded. Make sure the Diskette is up to speed before typing "RUN."

```

100 CLEAR 137*34
110 PRINT:PRINT"DISK SELF COPY"
120 / GET TO TRACK ZERO
130 OUT8,0
140 IF (INP(8)AND 64) <> 0 THEN WAIT8,2,2:OUT9,2:GOTO140
150 / DO IT FOR ALL 77 TRACKS
160 FORT=0T076
170 PRINT:PRINT"READ T";T
180 DIM A$(31)
190 FOR S=0 TO 31  READ & COMPARE ALL SECTORS
200 A$(S)=DSKI$(S)
210 B$=DSKI$(S)
220 IF B$ <> A$(S) THEN PRINT"REREAD T";T;"S";S:GOTO 200
230 NEXT S
240 PRINT:PRINT"WRITE T";T
250 FOR S=0 TO 31  WRITE NEW TRACK
260 DSKO$A$(S),S
270 NEXT S
280 FOR S=0 TO 31  CHECK NEW DATA
290 B$=DSKI$(S)
300 IF A$(S)<>B$ THEN PRINT"REWRITE T";T;"S";S:DSKO$A$(S),S:GOTO 290
310 NEXT S
320 / GOTO NEW TRACK
330 ERASE A$
340 IF T=76 THEN 360
350 WAIT 8,2,2:OUT 9,1
360 NEXT T
370 CLEAR 200
380 PRINT:PRINT"THAT SHOULD DO IT"
390 END

```



METHOD II - A program to update the Write Timing on a Diskette which runs under DOS using only a single Floppy Disk Drive is now available free of charge to those who purchased a copy of DOS prior to December 1, 1977. Send a copy of the invoice or proof of purchase of DOS to MITS and request the DOS Rewrite Diskette.

When the DOS Rewrite Diskette is received, perform the following procedure. This procedure assumes only one Disk Drive is available.

- STEP 1. Perform the modifications to the Write Circuits of the Disk Controller (reference Section II, Part A).
- STEP 2. Put your old DOS Diskette in Drive 0. Bootstrap and perform initialization as usual. Do not MNT it.
- STEP 3. Remove old DOS Diskette from Drive 0.
- STEP 4. Place Diskette containing Write Time Delay update program in Drive 0.
- STEP 5. Issue the command MNT 0.
- STEP 6. Run the Write Time Delay program by typing TIMING in response to the "." (prompt). If you have more than one Drive and the Diskette is in a Drive other than 0, the command is RUN TIMING n, where n is the Drive number.
- STEP 7. The program will type out CHANGE WRITE TIME DELAY ENTER DEVICE NBR. Type 0. Do not hit RETURN.
- STEP 8. Remove the Diskette from Drive 0. Place the Diskette to be rewritten in Drive 0.
- STEP 9. Hit RETURN. The program will begin executing. First it will DSM the Diskette, then it will go around a loop 77 times; once for each track into memory. Then the entire track will be compared with the contents of memory. Any Sector which does not compare will be reread and compared again until they do match. Then the entire

track will be rewritten with the new Write Time Delays. The entire track will be compared with memory. Any Sector which does not compare will be rewritten and recompared. When this is complete, the program will go on to the next track. When the last track is done, the Diskette is MNT'd. This execution takes approximately 3 minutes.

STEP 10. If you have more than one Diskette to update, perform a DSM 0 command. Go to Step 4.

STEP 11. Perform the modifications to the Read Circuits of the Disk Controller.

#### C. PIP Utility Program.

A BASIC Utility program has been provided to perform such common functions as printing directories, initializing disks, copying disks, etc.

##### NOTE

Some of the PIP commands (LIS, DIR) require that one <file number>.be configured during the Disk BASIC initialization dialog. This is done by answering the "HOW MANY FILES?" question with a value greater than zero. If an attempt is made to perform a LIS or DIR without following this procedure, a BAD FILE NUMBER error will occur.

Once the BASIC Diskette has been mounted, type the following command:

RUN "PIP"<carriage return>  
(PIP will type)

\*

PIP is now ready to accept commands. To exit PIP, type a carriage return to the prompt asterisk. To initialize the Floppy Disk in Drive 0, type:

\*INI0

PIP will type "DONE" when it is finished. Any Disk number may be substituted for the 0 in the above command and PIP will format the Diskette in that Drive. Any previous files on the Diskette initialized will be lost. If you wish to use blank Diskettes with Disk BASIC, they must be initialized in this fashion before they can be MOUNTed.

**NOTE**

Do not initialize the Disk with Disk Extended BASIC on it. This will wipe out all the files provided on the Disk.

The COP command is used to copy a Diskette placed in one Drive to a Diskette on another Drive. Neither Diskette need be MOUNTed for the COP command to work properly.

Syntax:

COP<old Disk number>,<new Disk number>

Before the copy is done, PIP verifies the action by printing the following message:

FROM<Disk number>TO<Disk number>

Typing Y followed by a carriage return causes execution to proceed. Any other response aborts the command. Example:

\*COP0,1 FROM 0 TO 1? Y<carriage return> DONE \*

DELETED  
PAGES



88-DCDD  
PARTS LIST  
FEBRUARY, 1977

BAG 1

5	74L00	101080
6	74L02	101072
8	74L04	101073
3	74L10	101081
1	74LS11	101089
1	74L20	101039
1	74L30	101082
7	74L73	101084
2	74LS74	101088
5	74L75	101075
1	7493	101030
8	74123	101060
1	74164	101091
1	74166	101092
3	93L16	101093
5	8T97 or 74367	101040
1	8T98	101045
2	7805	101074

NOTE: 74LS ICs may be substituted for 74L ICs.

BAG 2

37	.1mf 12v 20%	100348
----	--------------	--------

BAG 3

1	430pf 500v 5%	100322
1	910pf 500v 5%	100356
2	.001mf 1KV 20%	100328
1	.01mf 16v 20%	100321
2	.047mf 100v 5%	100332
2	.1mf 100v 5%	100339
1	.22mf 100v 5%	100349
2	.68mf 100v 5%	100343
1	1.0mf 100v 5%	100373
1	5mf 25V	100323
1	10mf 16v	100350
4	33mf 16v	100326
3	470 pf disk	100316

BAG 4

4	220 ohm 1/2W 5%	101925
4	330 ohm 1/2W 5%	101926
10	1K 1/2W 5%	101928
1	5.6K 1/2W 5%	102091
1	6.8K 1/2W 5%	101931
7	10K 1/2W 5%	101932
2	15K 1/2W 5%	102083
1	16K 1/2W 5%	101942
3	20K 1/2W 5%	101940
1	39K 1/2W 5%	101967
3	470 ohm 1/2W 5%	101927

BAG 5

2	IN914	100705
10	#6-32 x 3/8" Screw	100925
2	#6-32 Nut	100933
2	#6 Lock Washer	100942
4	#4-40 x 3/8" Screw	100908
4	#4-40 Nut	100932
4	#4 Lock Washer	100941
1	3 ft. 18 Pair Cable	103066
1	37 Pin Adapter Bracket	101795

BAG 6

2	100 Pin Edge Connector	101864
1	DC37S Connector	102114
2	10 Pin Right Angle Wafer	101798
2	20 Pin Right Angle Wafer	101788
2	10 Pin Connector	101720
2	20 Pin Connector	101789
70	Terminal Pins	101723
4	Polarizing Keys	101791
2	Fastwrap	1013037
1	Heat Sink Grease	
2	Heat Sink (large)	101870
4	Card Guides	101714

BAG 7

16	Test Points	101663
3	Ferrite Beads	101876
36	14-pin Sockets	102102
23	16-pin Sockets	102103

MISC.

1	Controller PC Board 1	100216
1	Controller PC Board 2	100217
1	Disk Extended BASIC Manual	101578



88-DISC  
PARTS LIST  
MARCH, 1977

BAG 1

1	74L30	101082
2	7805	101074
1	7824	101079
4	8T97 or 74367	101040
1	8T98	101045
1	9601	101033

BAG 2

4	.1mf 12v	100348
3	.1mf 50v	100312
3	33mf 50v	100311
1	500mf 15-25v	100310
1	100mf 25v	100365
1	2200mf 50v	100376
1	3300mf 16v	100315

BAG 3

3	150 ohm 1/2W	101915
17	330 ohm 1/2W	101926
1	1K 1/2W	101928
1	39K 1/2W	101967
1	7.5 ohm 5W	101987
1	33 ohm 1/2W	101921

BAG 4

17	220 ohm 1/2W	101925
3	RL21	100702
2	VJ048	100711
2	IN4004	100718
*1	TIP 145 or 146	102820
1	IN914	100705

BAG 5

1	12 ft. 18 Pair Cable	103066
2	6 ft. #20 Black	103062
3	2 ft. #20 Orange	103063
2	3 ft. #26 White	103060

\*With Mica Insulator and  
Shoulder Washer

BAG 6

8	#4-40 x 5/16" Screw	100912
2	#4-40 x 1/2" Screw Flat Head	100903
2	#4-40 x 1" Screw	100913
10	#4-40 Nut	100932
8	#4 Lock Washer	100941
4	#4 Flat Washer	100940
6	#6-32 x 3/8" Pan Head Screw	100925
6	#6-32 x 1/2" Pan Head Screw	100918
4	#6-32 x 5/8" Pan Head Screw	100916
2	#6-32 x 3/4" Pan Head Screw	100935
4	#6-32 x 1" Pan Head Screw	100919
4	#6-32 x 2" Flat Head Screw	100937
27	#6-32 Nut	100933
35	#6 Lock Washer	100942
1	#6 Ground Lug	101801
2	.15" Spacer	101823
6	5/16" Spacer	101829
2	.6" Spacer	101824
4	#6 Flat Washer	100943
2	#6-32 x 1/4" Screw	100917

BAG 7

1	Heat Sink	101775
1	Heat Sink	101835
1	Disk Drive Spacer 1/2"	101841
1	Right Angle Bracket	101717
1	Strain Relief	101719
1	Terminal Block	101868
30	Insulated Terminal	101803
1	Fuse Holder	101813
2	DC37S Connector	102114
2	DC37P Connector	102115
2	DC37 Connector Cover	101799
1	Toggle Switch ST1-1C	101879
1	44-Pin Edge Connector	101800
1	Keying Pin (for above)	101660
15	Fastwrap	103037
1	Heat Sink Grease	
1	Fuse 2ASB 3AG	101762
3	#6-32 x 3/4" Self Tap Screw	100957

MISC.

1	Power Cord 3 Wire	101742
1	Disk Mechanism (Pertec) FD400	101602
1	Case	100511
1	Disk Rail	101862
1	Fan Filter	101757
1	Fan and (4) clips	101869
1	Transformer, 26V	102612
1	Programmer Transformer, 24V, 9V	102620
1	Diskette (blank)	101712
1	Power Supply PC Board	100171
1	Buffer PC Board	100172
1	"Altair Disk" Nameplate	101808
1	Serial Number Sticker	101833
1	Assy, Theory, Oper. Manual	101531





## IC Installation

All ICs must be oriented so that the notched end is toward the end with the arrowhead printed on the PC board. Pin 1 of the IC should correspond with the pad marked with the arrowhead. If the IC does not have a notch on one end, refer to the IC Identification Chart to identify Pin 1.

### To prepare ICs for installation:


All ICs are damaged easily and should be handled carefully -- especially static-sensitive MOS ICs. Always try to hold the IC by the ends, touching the pins as little as possible. When you remove the IC from its holder, CAREFULLY straighten any bent pins using needle-nose pliers. All pins should be evenly spaced and should be aligned in a straight line, perpendicular to the body of the IC itself.

#### A. Installing ICs without sockets:

1. Orient the IC so that Pin 1 coincides with the arrowhead on the PC board.
2. Align the pins on one side of the IC so that just the tips are inserted into the proper holes on the board.
3. Lower the other side of the IC into place. If the pins don't go into their holes right away, rock the IC back, exerting a little inward pressure, and try again. Be patient. The tip of a small screwdriver may be used to help guide the pins into place. When the tips of all the pins have been started into their holes, push the IC into the board the rest of the way. Tape the IC to the board with a piece of masking tape.
4. Turn the board over and solder each pin to the foil pattern on the back side of the board. Be sure to solder each pin and be careful not to leave any solder bridges. Remove the masking tape.

#### B. Installing ICs with sockets:

1. Referring to the drawing below, set the IC socket into the designated holes on the board and secure it with a piece of masking tape.



2. Turn the board over and solder each pin to the foil pattern on the back side of the board. Be sure to solder each pin and be careful not to leave any solder bridges. Remove the masking tape.
3. Orient the IC over the socket so that Pin 1 coincides with the arrowhead on the PC board.
4. Align the pins on one side of the socket so that just the tips are inserted into the holes.
5. Lower the other side of the IC into place. If the pins don't go into their holes right away, rock the IC back, exerting a little inward pressure, and try again. Be patient. When the tips of all the pins have been started into their holes, push the IC into the socket the rest of the way.

#### WARNING:

Make sure none of the pins have been pushed underneath the IC during insertion.



## 1c Installation

Install the following 28 ICs with sockets according to the IC Installation Instructions, Section B, on page 4.

### NOTE

74LS ICs may be substituted for 74L ICs.

<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>			
( ) A1	74123	16-pin	( ) F3	74L02	14-pin
( ) A2	74L73	14-pin	( ) F4	74L02	14-pin
( ) A3	93L16	16-pin	( ) G2	74L04	14-pin
( ) A4	93L16	16-pin	( ) G3	74L75	16-pin
( ) B1	74123	16-pin	<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>
( ) B2	74123	16-pin	( ) G4	74L04	14-pin
( ) B3	74123	16-pin	( ) H1	74L02	14-pin
( ) B4	74L04	14-pin	( ) H2	74166	16-pin
( ) E1	74L00	14-pin	( ) H3	74L75	16-pin
( ) E2	74L73	14-pin	( ) H4	74L04	14-pin
( ) E3	74L00	14-pin	( ) J1	74L02	14-pin
( ) E4	74L10	14-pin	( ) J2	8T98	16-pin
( ) F1	74L02	14-pin	( ) J3	74L75	16-pin
( ) F2	74L73	14-pin	( ) J4	74L74	14-pin
			( ) K3	8T97 or 74367	16-pin



## Final Test Point Installation

Install the 8 test points, TP1 through TP8 on Controller Board #2 according to the following instructions.

1. Insert the pin through the silk-screened side of the board and solder in place on the silk-screened side.
2. Turn the board over and solder the pin on the foil (bottom) side of the board.
3. Return the board to the silk-screened (top) side. Straighten the pin if necessary, and resolder.

### NOTE

Do not clip off the portion of the test point that protrudes from the bottom of the board; it can be used during testing and troubleshooting.



### Terminal Test Point Installation

Install the 8 test points, TP1 through TP8 on Controller Board #2 according to the following instructions.


1. Insert the pin through the silk-screened side of the board and solder in place on the silk-screened side.
2. Turn the board over and solder the pin on the foil (bottom) side of the board.
3. Return the board to the silk-screened (top) side. Straighten the pin if necessary, and resolder.

#### NOTE

Do not clip off the portion of the test point that protrudes from the bottom of the board; it can be used during testing and troubleshooting.










## Resistor Installation

Install the following 13 resistors according to the instructions on page 5.

### Resistor

( ) R1	10K ohm (brown, black, orange) 1/4 or 1/2W
( ) R2	10K ohm (brown, black, orange) 1/4 or 1/2W
( ) R3	39K ohm (orange, white, orange) 1/4 or 1/2W
( ) R4	10K ohm (brown, black orange) 1/4 or 1/2W
( ) R5	15K ohm (brown, green, orange) 1/4 or 1/2W
( ) R6	220 ohm (red, red, brown) 1/4 or 1/2W
( ) R7	330 ohms (orange, orange, brown) 1/4 or 1/2W
( ) R8	15K ohm (brown, green, orange) 1/4 or 1/2W
( ) R9	6.8K ohm (blue, gray, red) 1/4 or 1/2W
( ) R10	16K ohm (brown, blue orange) 1/4 or 1/2W
( ) R11	1K ohm (brown, black, red) 1/4 or 1/2W
( ) R12	1K ohm (brown, black, red) 1/4 or 1/2W
( ) R13	1K ohm (brown, black, red) 1/4 or 1/2W








## Capacitor Installation

Install the following 29 capacitors according to the instructions on page 6. Note that all capacitors are installed in the same manner, except for electrolytic capacitors.


<u>Capacitor</u>	<u>Value</u>		
( ) C1	.001 $\mu$ f	( ) C15	.1 $\mu$ f
( ) C2	.001 $\mu$ f	( ) C16	.1 $\mu$ f
( ) C3	1.0 $\mu$ f	( ) C17	.1 $\mu$ f
( ) C4	.22 $\mu$ f	( ) C18	.1 $\mu$ f
( ) C5, electrolytic	5 $\mu$ f	( ) C19	.1 $\mu$ f
( ) C6, electrolytic	10 $\mu$ f	( ) C20	.1 $\mu$ f
( ) C7	.1 $\mu$ f	( ) C21	.1 $\mu$ f
( ) C8	.1 $\mu$ f	( ) C22	.1 $\mu$ f
( ) C9, electrolytic	33 or 35 $\mu$ f	( ) C23	.1 $\mu$ f
( ) C10	.1 $\mu$ f	( ) C24	.1 $\mu$ f
( ) C11	.1 $\mu$ f	( ) C25	.1 $\mu$ f
( ) C12	.1 $\mu$ f	( ) C26	.1 $\mu$ f
( ) C13	.1 $\mu$ f	( ) C29	.1 $\mu$ f
( ) C14	.1 $\mu$ f	( ) C30	.1 $\mu$ f
		( ) C31, electrolytic	33 or 35 $\mu$ f



















## Connector Installation

There are two "boxes" marked on the silk-screen. These are to indicate the positions for a 10-pin and a 20-pin male connector.

The drawing below illustrates the installation of a typical connector of this type.



Referring to the drawing, install the two male connectors onto the silk-screened side of the board. The long 90° bent pins should point towards the right side of the board. The 10-pin connector goes between "CC1" & "CC10"; while the 20-pin connector goes between "CD1" & "CD20".

Two pins should now be cut off. These are the 2nd pin from the top on the 10-pin connector, and the 4th from the top on the 20-pin connector. Cut them off right at the plastic body of the connector. (These pins are both labelled "KEY" on the silkscreen.)

There is a row of 20 pads along the right edge of the board labelled CB1 through CB20.

Remove 10 twisted-pairs of wire from an 8-inch length of ribbon cable. Leave the two wires in each pair twisted together. Strip 1/4 inch of insulation from both ends of all of the wires and tin the exposed portions.

Beginning with the bottom pad on the board, connect one of the twisted-pairs to pads CB1 & CB2. Continue up the row of pads, connecting a twisted-pair to each two pads as you go along.


**NOTE:** The twisted-pairs each have one wire the same color in each of them (usually black or white). Make the connection to pad CB1 with this wire on the 1st pair, and use this wire for the 1st connection on each of the following pairs as you go up the row of 20 pads.

Insert all of the wires from the silk-screened side of the board and solder them on the bottom side. Clip off any excess lead lengths.

Cut the free ends of all 20 wires so that only 1/8 inch of tinned wire is exposed beyond the insulation.









A 20-pin female connector will now be attached to the free ends of the 20 wires.


First, connector pins must be attached to the ends of all of the wires. The drawings below illustrate a typical connector of this type, and the method for attaching and inserting the pins.

Connect a pin to each of the wires\* as shown, and solder them carefully into place. Do not use too much solder or the pins will not fit into the connector properly.

NOTE: Two of the wires, both labeled CB17 on the PC board (see silk-screen), should be attached to a single pin.

Pins 1 & 20 are marked on the plastic body of the female connector. Referring to the silk-screen, insert the pins into the connector so that pad CB1 goes to pin 1, CB2 to pin 2, CB3 to pin 3, etc., being sure not to insert any wires into pin 15 on the connector. A plastic key should be inserted into pin 15 of the female connector, inserting it from the opposite side as the wires.

Place a tie-wrap approximately in the center between the connector and the board to hold the wires together. Place another tie-wrap around the wires and also through the holes in the PC board just to the right of the 20 pads.





# CONTROLLER BOARD #1 ASSEMBLY

## IC Installation

Install the following 31 ICs with sockets according to the IC Installation Instructions, Section B, page 4.

### NOTE

74LS ICs may be substituted for 74L ICs.

<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>	<u>Silkscreen Designation</u>	<u>Part Number</u>	<u>Socket Size</u>
( ) A1	74123	16-pin	( ) F2	74L73	14-pin
( ) A2	74L02	14-pin	( ) F3	74L73	14-pin
( ) A3	74L20	14-pin	( ) F4	74123	16-pin
( ) A4	74L10	14-pin	( ) F5	74L30	14-pin
( ) A5	74L10	14-pin	( ) G1	74164	14-pin
( ) B1	93L16	16-pin	( ) G2	74L00	14-pin
( ) B2	74L74	14-pin	( ) G3	74L75	16-pin
( ) B3	74L73	14-pin	( ) G4	7493	14-pin
( ) B4	74L11	14-pin	( ) G5	74L04	14-pin
( ) B5	74L04	14-pin	( ) H1	74L75	16-pin
( ) E1	74123	16-pin	( ) H2	8T97 or 74367	16-pin
( ) E2	74L00	14-pin	( ) H3	8T97 or 74367	16-pin
( ) E3	74L73	14-pin	( ) H4	8T97 or 74367	16-pin
( ) E4	74L04	14-pin	( ) H5	8T97 or 74367	16-pin
( ) E5	74L00	14-pin	( ) J3	74L04	14-pin
( ) F1	74123	16-pin			



### Terminal Test Point Installation

Install the 8 test points, TP1 through TP8 on Controller Board #1 according to the following instructions.


1. Insert the pin through the silkscreened (top) side of the board and solder in place on the silkscreened side.
2. Turn the board over and solder the pin on the foil (bottom) side of the board.
3. Return the board to the silkscreened (top) side. Straighten the pin if necessary, and resolder.

#### NOTE

Do not clip off the portion of the test point that protrudes from the bottom of the board; it can be used during testing and troubleshooting.









## Resistor Installation


Install the following 24 resistors according to the instructions on page 5.

### NOTE

Save three excess resistor leads for ferrite bead installation on page 108A.

<u>Resistor</u>	<u>Value</u>		
( ) R1	330 ohm (orange, orange, brown) 1/4 or 1/2 W	( ) R13	220 ohm (red, red, brown) 1/4 or 1/2 W
( ) R2	220 ohm (red, red, brown) 1/4 or 1/2 W	( ) R14	330 ohm (orange, orange, brown) 1/4 or 1/2 W
( ) R3	10K ohm (brown, black, orange) 1/4 or 1/2 W	( ) R15	10K ohm (brown, black, orange) 1/4 or 1/2 W
( ) R4	20K ohm (red, black, orange) 1/4 or 1/2 W	( ) R16	5.6K ohm (green, blue, red) 1/4 or 1/2 W
( ) R5	10K ohm (brown, black, orange) 1/4 or 1/2 W	( ) R17	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R6	20K ohm (red, black, orange) 1/4 or 1/2 W	( ) R18	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R7	470 ohm (yellow, violet, brown) 1/4 or 1/2 W	( ) R19	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R8	470 ohm (yellow, violet, brown) 1/4 or 1/2 W	( ) R20	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R9	330 ohm (orange, orange, brown) 1/4 or 1/2 W	( ) R21	470 ohm (yellow, violet, brown) 1/4 or 1/2 W
( ) R10	220 ohm (red, red, brown) 1/4 or 1/2 W	( ) R22	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R11	10K ohm (brown, black, orange) 1/4 or 1/2 W	( ) R23	1K ohm (brown, black, red) 1/4 or 1/2 W
( ) R12	20K ohm (red, black, orange) 1/4 or 1/2 W	( ) R24	1K ohm (brown, black, red) 1/4 or 1/2 W







## Capacitor Installation

Install the following 30 capacitors according to the instructions on page 6.


### NOTE

Mica and Mylar capacitors are similar in appearance to epoxy dipped ceramic capacitors and should be installed in the same manner.


<u>Capacitor</u>	<u>Value</u>		
( ) C1, Ceramic Disk	.1 mf, 12-16V	( ) C15, Ceramic Disk	.1 mf, 12-16V
( ) C2, Mylar	.68 mf, 100V	( ) C16, Ceramic Disk	.1 mf, 12-16V
( ) C3, Mylar	.047 mf, 250V	( ) C17, Ceramic Disk	.1 mf, 12-16V
( ) C4, Mylar	.68 mf, 100V	( ) C18, Ceramic Disk	.1 mf, 12-16V
( ) C5, Mica	430 pf, 500V	( ) C19, Ceramic Disk	.1 mf, 12-16V
( ) C6, Mica	910 pf, 500V	( ) C20, Ceramic Disk	470 pf, 500-1KV
( ) C7, Electrolytic	33 mf, 16-35V	( ) C21, Ceramic Disk	.1 mf, 12-16V
( ) C8, Ceramic Disk	.01 mf, 12-500V	( ) C22, Ceramic Disk	.1 mf, 12-16V
( ) C9, Mylar	.047 mf, 250V	( ) C23, Ceramic Disk	.1 mf, 12-16V
( ) C10, Ceramic Disk	.1 mf, 12-16V	( ) C24, Ceramic Disk	.1 mf, 12-16V
( ) C11, Electrolytic	33 mf, 16-35V	( ) C25, Ceramic Disk	.1 mf, 12-16V
( ) C12, Ceramic Disk	.1 mf, 12-16V	( ) C26, Ceramic Disk	.1 mf, 12-16V
( ) C13, Ceramic Disk	.1 mf, 12-16V	( ) C27, Ceramic Disk	.1 mf, 12-16V
( ) C14, Ceramic Disk	.1 mf, 12-16V	( ) C28, Ceramic Disk	.1 mf, 12-16V
		( ) C29, Ceramic Disk	470 pf, 500-1KV
		( ) C30, Ceramic Disk	470 pf, 500-1KV













### Connector Installation

Install a 10-pin and a 20-pin male connector onto the board in the same manner as described on page 94 for Board #2.

#### NOTE


The only exceptions to the above statement are that pin 6 is to be cut off instead of pin 4 on the 20-pin connector and pin 3 of the 10-pin connector is to be cut off instead of pin 2.

### Ferrite Bead Installation

Install three ferrite beads, L1, L2 and L3, on Controller Board #1 according to the following instructions.

1. Using the excess resistor leads saved from page 100, cut three 1-inch lead lengths.
2. Insert the lead through the bead and bend the ends of the lead to conform to the designated holes on the board.
3. Insert the lead into the proper holes from the silkscreened side of the board, and solder to the foil (bottom) side of the board. Be sure not to leave any solder bridges, and clip off any excess lead lengths.









# altair

## FLOPPY DISK DOCUMENTATION



Floppy Disk Documentation

Errata

April, 1977

1) Disk Board #1 Schematic (sheet 1 of 3):

R12 should be changed from 20K to 22K

2) Disk Board #2 Schematic (sheet 2 of 3):

R10 should be changed from 16K to 18K



## Floppy Disk Documentation


### Addenda

January, 1977

We are changing our transformers so they may be wired for either 110 volt or 220 volt operation. If your kit has been supplied with both new transformers (part numbers 102612 and 102620), connection may be made to 220v as shown. If only one of the transformers has the new dual primary windings, the unit can be wired for 110v only.

For a 220 volt supply, Be sure to wire the 110v fan as shown, with one fan wire connected to the brown/white transformer wire and the other fan wire connected to the junction of the brown and black/white transformer wires.

The older transformers may be identified by two black wires for the primary winding.



NOTE: ON SMALL TRANSFORMER  
(102620), USE THESE CONNECTIONS  
FOR 110 VOLT FAN

